


EDB9300ENP
00420052

Lenze

Operating Instructions



Global Drive
*9300 servo positioning
controller*

This documentation applies to 9300 servo positioning controllers as of version:

Type	33.932X	EP	1x	2x	(9321 - 9328)
	33.9329	EP	0x	2x	(9329)
	33.933X	EP	0x	2x	(9330 - 9332)
	33.932X	CP	1x	2x	(9321 - 9328)

Design:
C = Cold Plate
E = Enclosure IP20
IB = Module


Hardware version and index


Software version and index

Explanation


What is new / what has changed ?

Material No.	Version	Important	Contents
397404	12/97	1st edition	
404605	10/98	replaces 397404	Types 9321 to 9324 with 200 % overcurrent New function "Automatic controller parameter identification"
413320	01/00	replaces 404605	Chapters "Commissioning", "Troubleshooting" are new
420052	2.3 02/01 TD 02	replaces 413320	<ul style="list-style-type: none">• Chapter Installation: Tightening torques for motor connection/mains connection• Chapter Appendix: Motor table






1 Preface and general information	1-1
1.1 About these Operating Instructions	1-1
1.1.1 Terminology used	1-1
1.2 Packing list	1-1
1.3 Legal regulations	1-2
2 Safety information	2-1
2.1 General safety and application notes for Lenze controllers	2-1
2.2 Layout of the safety information	2-2
2.3 Residual hazards	2-2
3 Technical data	3-1
3.1 Features	3-1
3.2 General data/operating conditions	3-2
3.3 Rated data	3-3
3.3.1 Types 9321 to 9325	3-3
3.3.2 Types 9321 to 9324 with 200 % overcurrent	3-4
3.3.3 Types 9326 to 9332	3-5
3.3.4 Fuses and cable cross-sections	3-6
3.3.5 Mains filter	3-7
3.4 Dimensions	3-7




Contents

4 Installation	4-1
4.1 Mechanical installation	4-1
4.1.1 Important notes	4-1
4.1.2 Standard assembly with fixing rails or fixing brackets	4-2
4.1.3 Assembly with thermally separated power stage ("punching")	4-3
4.1.4 Assembly of variants	4-6
4.2 Electrical installation	4-9
4.2.1 Protection of persons	4-9
4.2.1.1 Residual-current circuit breakers	4-9
4.2.1.2 Insulation	4-10
4.2.1.3 Replacement of defective fuses	4-10
4.2.1.4 Mains disconnection	4-10
4.2.2 Protection of the controller	4-11
4.2.3 Motor protection	4-11
4.2.4 Mains types/conditions	4-12
4.2.5 Interaction with compensation equipment	4-12
4.2.6 Specification of all cables used	4-12
4.2.7 Power connections	4-13
4.2.7.1 Mains connection	4-13
4.2.7.2 Motor connection	4-15
4.2.7.3 Connection of a brake unit	4-17
4.2.7.4 DC bus connection of several drives	4-18
4.2.8 Control connections	4-20
4.2.8.1 Control cables	4-20
4.2.8.2 Assignment of the control terminals	4-20
4.2.8.3 Connection diagrams	4-22
4.2.9 Motor temperature monitoring	4-28
4.2.9.1 User-specific characteristic for a PTC thermistor	4-29
4.2.10 Feedback systems	4-30
4.3 Installation of a CE-typical drive system	4-34




5 Commissioning	5-1
5.1 Before switching on	5-1
5.2 Initial switch-on	5-1
5.3 Commissioning sequence	5-4
5.4 Switch on the controller	5-5
5.5 Switch on PC, start GDC	5-5
5.6 Generate parameter set	5-6
5.6.1 Adapt controller to the mains	5-6
5.6.2 Adapt controller to the motor	5-7
5.6.3 Enter machine parameters	5-8
5.6.4 Parameters for manual positioning	5-9
5.6.5 Controller enable	5-10
5.7 Function test with manual control	5-11
5.8 Enter positioning profile parameters	5-13
5.8.1 Structure of a positioning program	5-13
5.8.1.1 Tools for editing	5-14
5.8.1.2 Structure of a positioning profile	5-15
5.8.1.3 Enter parameters	5-19
5.8.2 Save parameter set	5-20
5.9 Load parameter set	5-21
5.9.1 Load parameter set from the PC	5-21
5.9.2 Load parameter set from the controller	5-22
5.10 Control drive	5-23
5.10.1 Description of the dialog box	5-23
5.10.2 Parameters for homing	5-24
5.10.3 Manual homing	5-25
5.10.4 Program control	5-26
5.11 Automatic control parameter identification	5-27
5.11.1 Procedure	5-28
5.11.2 Troubleshooting	5-29
5.11.2.1 Password protection	5-30
6 During operation	6-1
6.1 Status indications	6-1
6.1.1 In Global Drive Control	6-1
6.2 Information on operation	6-2
6.2.1 Switching on the motor side	6-2
6.2.2 Controller protection by current derating	6-3
7 Configuration	7-1
7.1 Configuration with Global Drive Control	7-1
7.2 Monitoring	7-2
7.2.1 Reactions	7-2
7.2.2 Set reactions	7-3
7.2.3 Monitoring functions	7-4



Contents

8 Troubleshooting and fault elimination	8-1
8.1 Troubleshooting	8-1
8.2 Fault analysis with the history buffer	8-3
8.2.1 Structure of the history buffer	8-3
8.2.2 Working with the history buffer	8-4
8.3 Fault indications	8-5
8.4 Reset of fault messages	8-9
9 Maintenance	9-1
10 Appendix	10-1
10.1 Accessories	10-1
10.2 Code table	10-1
10.3 Selection list	10-58
10.4 Motor selection list	10-66
10.4.1 Servo motors	10-66
10.4.2 Three-phase asynchronous motors	10-69
10.5 Glossary	10-73
10.6 Table of keywords	10-74



1 Preface and general information

1.1 About these Operating Instructions


- These Operating Instructions help with the connection and the commissioning of the 93XX servo positioning controller. They contain safety information which must be observed.
- All persons working on and with the 93XX servo positioning controller must have the Operating Instructions available and must observe the information and notes relevant for their work.
- The Operating Instructions must always be in a complete and perfectly readable state.
- Further information on the controller can be obtained from the Catalog and the Manual.

1.1.1 Terminology used

Term	In the following text used for
93XX	Any type of servo positioning controller (types 9321 ... 9332)
Controller	Servo positioning controller 93XX
Drive system	Drive system with 93XX servo positioning controllers and other Lenze drive components

1.2 Packing list

Packing list	Important
<ul style="list-style-type: none">• 1 93XX servo positioning controller• 1 book of Operating Instructions• 1 accessory kit (bits and pieces for mechanical and electrical installation)	<p>After receipt of the delivery, check immediately whether the items delivered match the accompanying papers. Lenze does not accept any liability for deficiencies claimed subsequently.</p> <p>Claim</p> <ul style="list-style-type: none">• visible transport damage immediately to the forwarder.• visible deficiencies/incompleteness immediately to your Lenze representative.



Preface and general information

1.3 Legal regulations

Identification	Nameplate	CE-identification	Manufacturer
	Lenze controllers are unambiguously designated by the contents of the nameplate.	Conforms to the EC Low-Voltage Directive	Lenze GmbH & Co KG Postfach 101352 D-31763 Hameln
Application as directed	<p>The 93XX servo</p> <ul style="list-style-type: none">must only be operated under the conditions prescribed in these Instructions.are components<ul style="list-style-type: none">for open and closed loop control of variable speed drives with PM synchronous motors, asynchronous servo motors or asynchronous standard motors.for installation in a machineused for assembly together with other components to form a machine.are electric units for the installation into control cabinets or similar enclosed operating housing.comply with the requirements of the Low-Voltage Directive.are not machines for the purpose of the Machinery Directive.are not to be used as domestic appliances, but only for industrial purposes. <p>Drive systems with 93XX servo inverters</p> <ul style="list-style-type: none">comply with the EMC Directive if they are installed according to the guidelines of CE-typical drive systems.can be used<ul style="list-style-type: none">for operation on public and non-public mainsfor operation in industrial premises and residential areas.The user is responsible for the compliance of his application with the EC directives. <p>Any other use shall be deemed as inappropriate!</p>		
Liability	<ul style="list-style-type: none">The information, data, and notes in these instructions met the state of the art at the time of printing. Claims on modifications referring to controllers which have already been supplied cannot be derived from the information, illustrations, and descriptions.The specifications, processes, and circuitry described in these instructions are for guidance only and must be adapted to your own specific application. Lenze does not take responsibility for the suitability of the process and circuit proposals.The specifications in these Instructions describe the product features without guaranteeing them.Lenze does not accept any liability for damage and operating interference caused by:<ul style="list-style-type: none">disregarding the operating instructionsunauthorized modifications to the controllerOperating errorsimproper working on and with the controller		
Warranty	<ul style="list-style-type: none">Warranty conditions: see Sales and Delivery Conditions of Lenze GmbH & Co KG.Warranty claims must be made to Lenze immediately after detecting the deficiency or fault.The warranty is void in all cases where liability claims cannot be made.		
Waste disposal	Material	recycle	dispose
	Metal	•	-
	Plastic	•	-
	Assembled PCBs	-	•



2 Safety information

2.1 General safety and application notes for Lenze controllers

(according to Low-Voltage Directive 73/23/EWG)

1. General

Lenze controllers (frequency inverters, servo inverter, DC controllers) can carry a voltage or parts of the controllers can rotate during operation. Surfaces can be hot. If the required cover is removed, the controllers are used inappropriately or installed or operated incorrectly, severe damage to persons or material assets can occur. For more information please see the documentation.

All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel (IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC report 664 or DIN VDE 0110 and national regulations for the prevention of accidents must be observed).

According to this basic safety information qualified, skilled personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.

2. Application as directed

Drive controllers are components which are designed for the installation into electrical systems or machinery. They are not to be used as domestic appliances, but only for industrial purposes according to EN 61000-3-2. The documentation contains information about the compliance of the limit values to EN 61000-3-2.

When installing controllers into machines, commissioning of the drive controllers (i.e. the starting of operation as directed) is prohibited until it is proven that the machine corresponds to the regulations of the EC Directive 98/37/EG (Machinery Directive); EN 60204 (VDE 0113) must be observed.

Commissioning (i.e. starting of operation as directed) is only allowed when there is compliance with the EMC Directive (89/336/EWG).

The drive controllers meet the requirements of the Low-Voltage Directive 73/23/EWG. The harmonised standards EN 50178/DIN VDE 0160 apply to the controllers.

The technical data as well as the connection conditions can be obtained from the nameplate and the documentation. The instructions given must be strictly observed.

Warning: Controllers are products with restricted availability according to EN 61800-3. These products can cause interferences in residential premises. If controllers are used in residential premises, corresponding measures are required.

3. Transport, storage

The notes on transport, storage and appropriate handling must be observed.

Climatic conditions according to EN 50178 apply.

4. Installation

The controllers must be installed and cooled according to the regulations given in the corresponding Instructions.

Ensure careful handling and avoid mechanical overload. Do not bend any components and do not change the insulation distances during transport and storage. Electronic components and contacts must not be touched.

Controllers contain electrostatically sensitive components which can easily be damaged by inappropriate handling. Do not damage or destroy any electrical components since this could mean hazards for your health!

5. Electrical connection

When working on live controllers, the valid national regulations for the prevention of accidents (e. g. VBG 4) must be observed.

The electrical installation must be carried out in compliance with the corresponding regulations (e.g. cable cross-sections, fuses, PE connection). Additional notes and information can be obtained from the corresponding Instructions.

The Instructions contain notes concerning wiring according to EMC regulations (shielding, earthing, filters and cable routing). These notes must also be observed when using CE-marked controllers. The compliance with limit values required by the EMC legislation is the responsibility of the manufacturer of the machine or system.

6. Operation

If necessary, systems including controllers must be equipped with additional monitoring and protection devices according to the applying safety regulations (e.g. regulation for technical equipment, regulation for the prevention of accidents). The controller can be adapted to your application. Please observe the corresponding information given in the Instructions.

After a controller has been disconnected from the voltage supply, all live components and power connections must not be touched immediately because capacitors can still be charged. Please observe the corresponding stickers on the controller.

All protection covers and doors must be shut during operation.

Note for UL-approved systems with integrated controllers: UL warnings are notes which only apply to UL systems. The Instructions give UL-related information.

7. Safe standstill

The variant V004 of 9300, 9300 vector and 8220 controllers and the variant B400 of 8200 vector controllers support the function "Safe standstill", protection against unintended start, according to the requirements of Appendix I No. 1.2.7 of the EC Directive "Machinery" 98/37/EG, DIN EN 954-1 category 3 and DIN EN 1037. Please observe the notes on the function "Safe standstill" given in the corresponding Instructions.

8. Maintenance and service

Please observe the Instructions given by the manufacturer,
and the product-specific safety and application notes in these Instructions.



Safety information

2.2

Layout of the safety information

- All safety information have a uniform layout:
 - The icon characterizes the type of danger.
 - The signal word characterizes the severity of danger.
 - The note text describes the danger and gives information on how to prevent dangerous situations.



Signal word


Note

	Icons used	Signal words	
Warning of damage to persons		Warning of hazardous electrical voltage	Danger! Warns of impending danger . Consequences if disregarded: Death or severe injuries.
		Warning of a general danger	Warning! Warns of potential, very hazardous situations . Possible consequences if disregarded: Death or severe injuries.
			Caution! Warns of potential, hazardous situations . Possible consequences if disregarded: Light or minor injuries.
Warning of damage to material			Stop! Warns of potential damage to material . Possible consequences if disregarded: Damage of the controller/drive system or its environment.
Other notes			Tip! This note designates general, useful notes. If you observe it, handling of the controller/drive system is made easier.

2.3

Residual hazards


Protection of persons	After mains voltage disconnection the power terminals U, V, W and +U _G , -U _G carry hazardous voltages at least 3 minutes after mains disconnection. <ul style="list-style-type: none">• Before working on the controller, check that no voltage is applied to the power terminals.
Protection of devices	Cyclic connection and disconnection of the controller supply voltage at L1, L2, L3 or +U _G , +U _G may overload the internal input current load: <ul style="list-style-type: none">• Allow at least 3 minutes between disconnection and reconnection.
Overspeeds	Drive systems can reach dangerous overspeeds (e.g. setting high field frequencies for motors and machines which are not suitable): <ul style="list-style-type: none">• The controllers do not offer any protection against these operating conditions. Use additional components for this.
Parameter set transfer	During parameter set transfer, the control terminals of the 9300 servo can have undefined states! Therefore the plugs X5 and X6 must be removed before transfer. Thus it is ensured that the controller is inhibited and all control terminals have the defined state "LOW".



3 **Technical data**

3.1 **Features**


- Single axis in narrow design
 - thus space-saving installation
- Power range: 370 W to 75 kW
 - uniform control module and thus uniform connection for the control cables over the complete power range
- Heat sink can be separated
 - the cooling can be achieved outside the control cabinet (Push-through or "Cold Plate technique).
- Power connections from the top (supply) or from the bottom (motor)
 - simple connection for multi-axis applications
- Direct connection of resolver or encoder feedback
 - simple connection via prefabricated system cables (accessories)
 - connecting cables can be plugged
- Point-to-point positioning
 - with or without velocity changeover
- Touch probe positioning
- Absolute or relative positioning
- S-ramps.
- Homing according to different modes
- Manual homing.
- Manual positioning.
- Manual positioning with intermediate stop
- Simple programming via PC
- Application configuration for control functions and input/output signals
 - comprehensive function block library
 - high flexibility in the adaptation of the internal control structure to the application
- Integrated automation interface
 - simple extensions of the controller functions
- System bus for the connection of servo inverters and for the extension of input and output terminals
- Approval of standard devices UL 508, File No. 132659 (listed).
- Approval 9371 BB (BAE) UL 508, File No. 132659 (listed).



Technical data

3.2 General data/operating conditions

Field	Values				
Vibration resistance	Germanischer Lloyd, general conditions				
Permissible moisture	Humidity class F without condensation (average relative humidity 85 %)				
Permissible temperature ranges	during transport:	-25 °C ... +70 °C			
	during storage of the controller:	-25 °C ... +55 °C			
	during operation of the controller:	0 °C ... +40 °C	without derating		
		+40 °C ... +55 °C	with power derating (controllers 9321-9326)		
		+40 °C ... +50 °C	with power derating (controllers 9327-9332)		
Permissible installation height h	$h \leq 1000$ m a.m.s.l.	without derating			
	1000 m a.m.s.l. < $h \leq 4000$ m a.m.s.l.	with derating			
Permissible pollution	VDE 0110 part 2 pollution degree 2				
Noise emission	Requirements to EN 50081-2, EN 50082-1, EN 61800-3 Limit value class A to EN 55011 (industrial area) with mains filter A Limit value class B acc. to EN 55022 (residential area) with mains filter B and installation in control cabinet				
Noise immunity	Limit values maintained using mains filter. Requirements to EN 50082-2, EN 61800-3				
	Requirements	Standard	Severity		
	Running time	EN61000-4-2	3, i.e. 8 kV at air discharge and 6 kV at contact discharge		
	RF interference (enclosure)	EN61000-4-3	3, i.e. 10 V/m; 27 to 1000 MHz		
	Burst	EN61000-4-4	3/4, i.e. 2 kV/5 kHz		
	Surge	IEC 1000-4-5	3, i.e. 1.2/50 µs, 1 kV Phase-Phase, 2 kV Phase-PE		
Insulation strength	Overvoltage category III to VDE 0110				
Packaging	to DIN 4180 9321 to 9332: Delivery packing				
Type of protection	IP20 IP41 on the heat-sink side for thermal separation (punching) NEMA 1: Protection against contact				
Approvals	CE:	Low-Voltage Directive			
	UL508:	Industrial Control Equipment			
	UL508C:	Power Conversion Equipment			



3.3 Rated data


3.3.1 Types 9321 to 9325

	Type	EVS9321-EP	EVS9322-EP	EVS9323-EP	EVS9324-EP	EVS9325-EP
Order No.	EVS9321-EP	EVS9322-EP	EVS9323-EP	EVS9324-EP	EVS9325-EP	
Type	EVS9321-CP	EVS9322-CP	EVS9323-CP	EVS9324-CP	EVS9325-CP	
Order No.	EVS9321-CP	EVS9322-CP	EVS9323-CP	EVS9324-CP	EVS9325-CP	
Mains voltage	V_f [V]	320 V - 0 % ≤ V_f ≤ 528 V + 0 % ; 45 Hz - 0 % ... 65 Hz + 0 %				
Alternative DC supply	V_{DC} [V]	460 V - 0 % ≤ V_{DC} ≤ 740 V + 0 %				
Mains current with mains filter	I_f [A]	1.5 2.1	2.5 3.5	3.9 5.5	7.0 -	12.0 16.8
Ratings for operation at a mains: 3 AC / 400V / 50Hz/60Hz						
Motor power (4-pole ASM)	P_f [kW]	0.37	0.75	1.5	3.0	5.5
	P_f [hp]	0.5	1.0	2.0	4.0	7.5
Output power U, V, W (8kHz*)	S_{f8} [kVA]	1.0	1.7	2.7	4.8	9.0
Output power + U_{DC} , - U_{DC} ²⁾	P_{DC} [kW]	2.0	0.75	2.2	0.75	0
Output current (8 kHz*)	I_{f8} [A]	1.5	2.5	3.9	7.0	13.0
Output current (16 kHz*)	I_{f16} [A]	1.1	1.8	2.9	5.2	9.7
Max. output current (8 kHz*) ¹⁾	I_{max8} [A]	2.3	3.8	5.9	10.5	19.5
Max. output current (16 kHz*) ¹⁾	I_{max16} [A]	1.7	2.7	4.4	7.8	14.6
Max. standstill current (8 kHz*)	I_{08} [A]	2.3	3.8	5.9	10.5	19.5
Max. standstill current (16 kHz*)	I_{016} [A]	1.7	2.7	4.4	7.8	14.6
Ratings for operation at a mains: 3 AC / 480V / 50Hz/60Hz						
Motor power (4-pole ASM)	P_f [kW]	0.37	0.75	1.5	3.0	5.5
	P_f [hp]	0.5	1.0	2.0	4.0	7.5
Output power U, V, W (8kHz*)	S_{f8} [kVA]	1.2	2.1	3.2	5.8	10.8
Output power + U_{DC} , - U_{DC} ²⁾	P_{DC} [kW]	2.0	0.75	2.2	0.75	0
Output current (8 kHz*)	I_{f8} [A]	1.5	2.5	3.9	7.0	13.0
Output current (16 kHz*)	I_{f16} [A]	1.1	1.8	2.9	5.2	9.7
Max. output current (8 kHz*) ¹⁾	I_{max8} [A]	2.3	3.8	5.9	10.5	19.5
Max. output current (16 kHz*) ¹⁾	I_{max16} [A]	1.7	2.7	4.4	7.8	14.6
Max. standstill current (8 kHz*)	I_{08} [A]	2.3	3.8	5.9	10.5	19.5
Max. standstill current (16 kHz*)	I_{016} [A]	1.7	2.7	4.4	7.8	14.6
Motor voltage	V_M [V]	0 - 3 × V_{Mains}				
Power loss (operation with I_{ratedx})	P_{loss} [W]	100	110	140	200	260
Power derating	[%/K] [%/m]	40 °C < T_V < 55 °C: 2% / K (not UL approved) 1000 m amsl < h ≤ 4000 m amsl: 5% / 1000m				
Weight	m [kg]	3.5	3.5	5.0	5.0	7.5

¹⁾ The currents apply to a periodical load cycle with 1 minute overcurrent with the current mentioned here and 2 minutes base load with 75% I_{ratedx}

²⁾ When operated under rated load, the controller can supply this power additionally.

* Chopper frequency of the inverter (C0018)



Technical data

3.3.2 Types 9321 to 9324 with 200 % overcurrent

Type	EVS9321-EP	EVS9322-EP	EVS9323-EP	EVS9324-EP
Ratings for operation at a mains: 3 AC / 400V / 50Hz/60Hz				
Motor power (4-pole ASM)	P _r [kW]	0.37	0.75	1.5
	P _r [hp]	0.5	1.0	2.0
Output power U, V, W (8 kHz)	S _{r8} [kVA]	1.0	1.7	2.7
Output current (8 kHz) ²⁾	I _{r8} [A]	1.5	2.5	3.9
Output current (16 kHz) ²⁾	I _{r16} [A]	1.1	1.8	2.9
max output current (8 kHz) ¹⁾	I _{max8} [A]	3.0	5.0	7.8
max output current (16 kHz) ¹⁾	I _{max16} [A]	2.2	3.6	5.8
max. standstill current (8 kHz)	I ₀₈ [A]	3.0	5.0	7.8
max. standstill current (16 kHz)	I ₀₁₆ [A]	2.2	3.6	5.8
Ratings for operation at a mains: 3 AC / 480V / 50Hz/60Hz				
Motor power (4-pole ASM)	P _r [kW]	0.37	0.75	1.5
	P _r [hp]	0.5	1.0	2.0
Output power U, V, W (8 kHz)	S _{r8} [kVA]	1.2	2.1	3.2
Output current (8 kHz) ²⁾	I _{r8} [A]	1.5	2.5	3.9
Output current (16 kHz) ²⁾	I _{r16} [A]	1.1	1.8	2.9
max output current (8 kHz) ¹⁾	I _{max8} [A]	3.0	5.0	7.8
max output current (16 kHz) ¹⁾	I _{max16} [A]	2.2	3.6	5.8
max. standstill current (8 kHz)	I ₀₈ [A]	3.0	5.0	7.8
max. standstill current (16 kHz)	I ₀₁₆ [A]	2.2	3.6	5.8

- 1) The currents apply to a periodical load cycle with 10 seconds overcurrent with the current mentioned here and 50 seconds base load with 44 % I_{rx}

Majority in indiv. cases	Setting in code C0022	thermal continuous current	Maximum current phase	Recovery phase
Continuous power	I _{max} ≤ 150 % I _{rx}	100 % I _{rx}	150 % I _{rx} for 60 s	75 % I _{rx} for 120 s
Peak power	I _{max} > 150 % I _{rx}	70 % I _{rx}	200 % I _{rx} for 10 s	44 % I _{rx} for 50 s

- 2) This output current I_{rx} applies for a maximum current to be set under C0022 which has not exceeded 150% of the rated controller current (nameplate). If the maximum current is higher than this value, the continuous current reduces automatically to 70% of the original value.


Overcurrent diagram: 7-4

All other data: 3-3



Tip!

You can switch to I_{max} > 150 % I_{rx} only if the controller is inhibited.




3.3.3 Types 9326 to 9332

	Type	EVS9326-EP	EVS9327-EP	EVS9328-EP	EVS9329-EP	EVS9330-EP	EVS9331-EP	EVS9332-EP
Order No.	EVS9326-EP	EVS9327-EP	EVS9328-EP	EVS9329-EP	EVS9330-EP	EVS9331-EP	EVS9332-EP	
Type	EVS9326-CP	EVS9327-CP	EVS9328-CP					
Order No.	EVS9326-CP	EVS9327-CP	EVS9328-CP					
Mains voltage	a_r [V]	320 V - 0 % ≤ V_r ≤ 528 V + 0 % ; 45 Hz - 0 % ... 65 Hz + 0 %						
Alternative DC supply	a_{DC} [V]	460 V - 0 % ≤ U_{DC} ≤ 740 V + 0 %						
Mains current with mains filter	I_r [A]	20.5 -	27.0 43.5	44.0 -	53.0 -	78.0 -	100 -	135 -
Ratings for operation at a mains: 3 AC / 400V / 50Hz/60Hz								
Motor power (4-pole ASM)	P_r [kW]	11.0	15.0	22.0	30.0	45.0	55.0	75.0
	P_r [hp]	15.0	20.5	30.0	40.0	60.0	73.5	100.0
Output power UW (8 kHz*)	S_{r8} [kVA]	16.3	22.2	32.6	40.9	61.6	76.2	100.5
Output power + U_{DC} , - U_{DC} ²⁾	P_{DC} [kW]	0	10	4	0	5	0	0
Output current (8 kHz*) ¹⁾	I_{r8} [A]	23.5	32.0	47.0	59.0	89.0	110.0	145.0
Output current (16 kHz*) ¹⁾	I_{r16} [A]	15.3	20.8	30.6	38.0	58.0	70.0	90.0
Max. output current (8 kHz*)	I_{max8} [A]	35.3	48.0	70.5	88.5	133.5	165.0	217.5
Max. output current (16 kHz*)	I_{max16} [A]	23.0	31.2	45.9	57.0	87.0	105.0	135.0
Max. standstill current (8 kHz*)	I_{08} [A]	23.5	32.0	47.0	52.0	80.0	110.0	126.0
Max. standstill current (16 kHz*)	I_{016} [A]	15.3	20.8	30.6	33.0	45.0	70.0	72.0
Ratings for operation at a mains: 3 AC / 480V / 50Hz/60Hz								
Motor power (4-pole ASM)	P_r [kW]	11.0	18.5	30.0	37.0	45.0	55.0	90.0
	P_r [hp]	15.0	25.0	40.0	49.5	60.0	73.5	120.0
Output power UW (8 kHz*)	S_{r8} [kVA]	18.5	25.0	37.0	46.6	69.8	87.3	104.0
Output power + U_{DC} , - U_{DC} ²⁾	P_{DC} [kW]	0	12	4.8	0	6	0	6
Output current (8 kHz*)	I_{r8} [A]	22.3	30.4	44.7	56.0	84.0	105.0	125.0
Output current (16 kHz*)	I_{r16} [A]	14.5	19.2	28.2	35.0	55.0	65.0	80.0
Max. output current (8 kHz*) ¹⁾	I_{max8} [A]	33.5	45.6	67.1	84.0	126.0	157.5	187.5
Max. output current (16 kHz*) ¹⁾	I_{max16} [A]	21.8	28.8	42.3	52.5	82.5	97.5	120.0
Max. standstill current (8 kHz*)	I_{08} [A]	22.3	30.4	44.7	49.0	72.0	105.0	111.0
Max. standstill current (16 kHz*)	I_{016} [A]	14.5	19.2	28.2	25.0	36.0	58.0	58.0
Motor voltage	a_M [V]	0 - 3 × V_{Mains}						
Power loss	P_{loss} [W]	360	430	640	810	1100	1470	1960
Power derating	[%/K] [%/K] [%/m]	9326: at 40 °C < T_a < 55 °C: 2%/K (not UL approved) 9327 - 9332: at 40 °C < T_a < 50 °C: 2.5%/K (not UL approved) 1000 m amsl < h ≤ 4000 m amsl: 5%/1000m						
Weight	m [kg]	7.5	12.5	12.5	12.5	36.5	59	59

1) The currents apply to a periodical load cycle with 1 minute overcurrent with the current mentioned here and 2 minutes base load with 75% I_{rated}

2) When operated under rated load, the controller can supply this power additionally.

* Chopper frequency of the inverter (C0018)



Technical data

3.3.4 Fuses and cable cross-sections


Type	Mains input L1, L2, L3, PE/motor connection U, V, W										Input +UG, -UG		
	Operation without mains filter					Operation with mains filter							
	Fuse	E.I.c.b.	Cable cross-section 2) mm ²	Fuse	E.I.c.b.	Cable cross-section 2) mm ²	Fuse	Cable cross-section 2) mm ²	VDE	UL	VDE	UL	AWG
9321	M 6A	5A	B 6A	1	17	M 6A	5A	B 6A	1	17	6.3A	1	17
9322	M 6A	5A	B 6A	1	17	M 6A	5A	B 6A	1	17	6.3A	1	17
9323	M 10A	10A	B 10A	1.5	15	M 10A	10A	B 10A	1.5	15	8A	1.5	15
9324	-	-	-	-	-	M 10A	10A	B 10A	1.5	15	12A	1.5	15
9325	M 32A	25A	B 32A	6	9	M 20A	20A	B 20A	4	11	20A	4	11
9326	-	-	-	-	-	M 32A	25A	B 32A	6	9	40A	6	9
9327	M 63A	63A	-	16	6	35A	35A	-	10	7	50A	10	7
9328	-	-	-	-	-	50A	50A	-	16	5	80A	16	5
9329	-	-	-	-	-	80A	80A	-	25	3	100A	25	3
9330	-	-	-	-	-	100A	100A	-	50	0	2 * 80A ¹⁾	2 * 16	2 * 5
9331	-	-	-	-	-	125A	125 A	-	70	2/0	2 * 100A ¹⁾	2 * 25	2 * 3
9332	-	-	-	-	-	160A	175 A	-	95	3/0	3 * 80A ¹⁾	3 * 16	3 * 5

1) The DC bus fuses are connected in parallel

2) The valid local regulations must be observed

For operation of the controllers in a UL-approved plant:

- Use only UL-approved fuses and fuse holders:
 - 500 V to 600 V in the mains input (AC)
 - 700 V in DC-bus voltage (DC)
 - The activation characteristic is defined by "H" or "K5".
- Use only UL-approved cables.




Tip!

UL-approved fuses and fuse holders can be obtained from, e.g. Bussmann or Ferraz.

Connection of the motor cables

- The protection of the motor cables is not necessary for functional reasons.
- Refer to the data listed in the table "Operation with mains filter".




3.3.5 Mains filter

Type	Rated data (uk ≈ 6%)		Lenze order number	
	Mains current	Inductance	for RFI degree A	for RFI degree B
9321	1.5 A	24 mH	EZN3A2400H002	EZN3B2400H002
9322	2.5 A	15 mH	EZN3A1500H003	EZN3B1500H003
9323	4 A	9 mH	EZN3A0900H004	EZN3B0900H004
9324	7 A	5 mH	EZN3A0500H007	EZN3B0500H007
9325	13 A	3 mH	EZN3A0300H013	EZN3B0300H013
9326	24 A	1.5 mH	EZN3A0150H024	EZN3B0150H024
9327	30 A	1.1 mH	EZN3A0110H030	EZN3B0110H030
9328	42 A	0.8 mH	EZN3A0080H042	EZN3B0080H042
9329	60 A	0.54 mH	EZN3A0055H060	EZN3B0055H060
9330	90 A	0.37 mH	EZN3A0037H090	EZN3B0037H090
9331	150 A	0.22 mH	EZN3A0022H150	EZN3B0022H150
9332	150 A	0.22 mH	EZN3A0022H150	EZN3B0022H150


The mains filters for RFI degree B contain additional RFI suppression components.

3.4 Dimensions

The dimensions of the controllers depend on the mechanical installation. (□ 4-1)



Technical data



4 Installation

4.1 Mechanical installation


4.1.1 Important notes

- Use the controllers only as built-in devices!
- If the cooling air contains pollutants (dust, fluff, grease, aggressive gases):
 - Take suitable preventive measures , e.g. separate air duct, installation of filters, regular cleaning, etc.
- Observe free space!
 - You can install several controllers next to each other without free space in a control cabinet.
 - Ensure unimpeded ventilation of cooling air and outlet of exhaust air!
 - Allow a free space of 100 mm at the top and at the bottom.
- Do not exceed the ambient temperature permissible during operation. (□ 3-2)
- With continuous oscillations or vibrations:
 - Check whether shock absorbers are necessary.

Possible mounting positions

Vertically on the control cabinet back panel with mains connections at the top:

- With enclosed fixing rails or fixing brackets. (□ 4-2)
- Thermally separated with external heat sink
 - Punching (□ 4-3)
 - "Cold Plate technique" (□ 4-6)



Installation

4.1.2 Standard assembly with fixing rails or fixing brackets




Fig. 4-1 Dimensions for assembly with fixing rails/fixing brackets

Type	Fig.	a	b	b1	c	c1	d	d1	e*	e1	g	k	m
9321, 9322	A	78	384	350	39	-	365	-	250	230	6.5	30	-
9323, 9324	A	97	384	350	48.5	-	365	-	250	230	6.5	30	-
9325, 9326	B	135	384	350	21.5	92	365	-	250	230	6.5	30	-
9327, 9328, 9329	C	250	402	350	22	206	370	24	250	230	6.5	24	11
9330	C	340	672	591	28.5	283	624	38	285	265	11	28	18
9331, 9332	C	450	748.5	680	30.5	389	702	38	285	265	11	28	18


* When using a plug-on fieldbus module:
Observe the free space required for the connection cables
All dimensions in mm

Controllers 9321 to 9326

- Assembly preparation:
 - Take out fixing rail(s) (accessory kit in the box) and mount them on the controller housing

Controllers 9327 to 9332

- Remove cover:
 - Loosen screws (X)
 - Swing cover to the top and detach
 - Take accessory kit out of the interior of the controller
- Assembly preparation:
 - Take out fixing bracket and screws (accessory kit) and mount them on the controller housing




4.1.3 Assembly with thermally separated power stage ("punching")

The heat sink of the controllers 9321 ... 9329 can be mounted outside the control cabinet to reduce the heat generated in the control cabinet. For this, you need an assembly frame with seal (can be ordered from Lenze).

- Distribution of the power loss:
 - approx. 65% via the separated heat sink (heat sink + blower)
 - approx. 35% inside the controller
- The type of protection of the separated cooler (heat sink and blower) is IP41.
- The ratings of the controller are still applicable.

Preparation for assembly:

1. Lay the halves of the assembly frame into the slot provided on the controller.
2. Push the frame halves together until the ends lock.
3. Slip the seal over the heat sink and lay into the slot provided.



Installation

Dimensions of the types 9321 to 9326





Fig. 4-2 Dimensions for assembly with thermally separated power stage

Type	a	b	b1	c	c1	d	d1	e*	f	g
9321, 9322	112.5	385.5	350	60	95.5	365.5	105.5	250	92	6.5
9323, 9324	131.5	385.5	350	79	114.5	365.5	105.5	250	92	6.5
9325, 9226	135	385.5	350	117	137.5	365.5	105.5	250	92	6.5

Assembly cut-out

Type	Height	Width
9321, 9322	350 ±3	82 ±3
9323, 9324	350 ±3	101 ±3
9325, 9326	350 ±3	139 ±3

* When using an attachable fieldbus module:
Observe the free space required for the connection cables
All dimensions in mm



Dimensions of the types 9327 to 9329





Fig. 4-3 Dimensions for assembly with thermally separated power stage

Type	a	b	c1	c2	c3	d1	d2	d3	d4	e *)	f	g	h
9327, 9328, 9329	280	379	28	140	252	41	141	238	338	250	90	6	9

Cut-out Z

Type	Height	Width	k	l	m	n
9327, 9328, 9329	338 ± 1	238 ± 1	20 ± 2	259 ± 2	20 ± 2	359 ± 2

* When using an attachable fieldbus module:
Observe the free space required for the connection cables
All dimensions in mm



Installation

4.1.4 Assembly of variants

Variant EVS932X-Cx ("Cold plate")

For installation in control cabinets together with other heat sinks in "Cold plate technology" (x = order abbreviation; see inner Instructions cover).

Dimensions for types 9321-Cx bis 9326-Cx





Fig. 4-4 Dimensions for assembly in "Cold Plate technique"

Type	a	b	b1	c	c2	d	e*	g
9321-Cx	78	381	350	48	-	367	168	6.5
9322-Cx	97	381	350	67	-	367	168	6.5
9323-Cx	135	381	350	105	38	367	168	6.5
9324-Cx								
9325-Cx								
9326-Cx								

* When using an attachable fieldbus module:
Observe the free space required for the connection cables
All dimensions in mm



Dimensions of the types 9327-Cx and 9328-Cx





Fig. 4-5 Dimensions for assembly in "Cold Plate technique"

Type	a	a1	b	b1	c	c1	c2	d	e*	g
9327-Cx	234	250	381	350	110	220	117	367	171	6.5
9328-Cx										

* When using an attachable fieldbus module:
Observe the free space required for the connection cables
All dimensions in mm



Installation


- Observe the following points to comply with the technical data:
 - Ensure sufficient ventilation of the heat sink.
 - The free space behind the control cabinet back panel must be at least 500 mm.
- If you install several controllers in the control cabinet:
 - Do not install the controllers on top of each other.
- The cooling path must not exceed the thermal resistances in the table:

Controller Type	Cooling path	
	Power to be dissipated P_{loss} [W]	R_{thmax} heat sink [K/W]
9321-Cx	80	0.50
9322-Cx	80	0.50
9323-Cx	100	0.40
9324-Cx	155	0.25
9325-Cx	210	0.19
9326-Cx	360	0.10
9327-Cx	410	0.09
9328-Cx	610	0.06

- The temperature of the cold plate must not exceed +85 °C.
- Penetration depth t of the screws into the basic plate of the controller:

$$8 \text{ mm} \leq t \leq 10 \text{ mm}$$

- For the bore pattern and surface quality of the heat sink please consult the factory.
- Apply the heat conducting paste (accessory kit) to the cold plate of the controller.



4.2 Electrical installation

For information about the installation according to EMC, see chapter 4.3. (4-34)

4.2.1 Protection of persons



Danger!

All power terminals carry voltage up to 3 minutes after mains disconnection.

4.2.1.1 Residual-current circuit breakers

Labelling of RCCBs	Meaning
	AC-sensitive residual-current circuit breaker (RCCB, type AC)
	Pulse-current sensitive residual-current circuit breaker (RCCB, type A)
	All-current sensitive residual-current circuit breaker (RCCB, type B)

Definition

In the following text "RCCB" is used for "residual-current circuit breaker".

Protection of persons and animals

DIN VDE 0100 with residual-current operated protective devices (RCCB):

- The controllers are equipped with a mains rectifier. If a short-circuit to frame occurs, a smooth DC residual current can block the activation of the DC sensitive or pulse-current sensitive RCCBs and thus destroy the protective function for all units connected. We therefore recommend:
 - "pulse-current sensitive RCCB" or "all-current RCCB" in systems equipped with controllers with single-phase mains connection (L1/N).
 - "all-current sensitive RCCB" in systems equipped with controllers with three-phase mains connection (L1/L2/L3).

Rated residual current

Please observe the rated residual current for the selection of the RCCB:

- Controller with single-phase mains connection: 30 mA rated residual current
- Controller with three-phase mains connection: 300 mA rated residual current

The RCCB can be activated unintentionally under the following conditions:

- In the event of capacitive leakage currents between the cable screens (especially with wall mounting).
- Simultaneous connection of several inverters to the mains
- If RFI filters are used.


Installation

The RCCB must only be installed between the supplying mains and the controller.

Standards (All-current sensitive RCCB)

All-current sensitive RCCBs are described in the European Standard EN EN 50178 and in the IEC 755.

The EN 50178 has been harmonized and has been effective since October 1997. It replaces the national standard VDE 0160.



Installation

4.2.1.2 Insulation

The controllers have an electrical isolation (insulating distance) between the power terminals and the control terminals as well as to the housing:

- Terminals X1 and X5 have a double basic insulation (double insulating distance, safe mains isolation to VDE0160, EN50178). The protection against contact is ensured without any further measures.
- The control inputs and outputs of all controllers are electrically isolated.



Danger!

- Terminals X3, X4, X6, X7, X8, X9, X10 have a single basic insulation (single insulating distance).
- Protection against contact in the event of fault is ensured only by additional measures.
- If an external voltage supply (24V DC) is used, the insulation level of the controller depends on the insulation level of the voltage source.




Fig. 4-6

Basic insulation in the controller

4.2.1.3 Replacement of defective fuses


Replace defective fuses with the prescribed type only when no voltage is applied. (§ 3-6)

- For single drives, the controller carries a hazardous voltage up to three minutes after mains disconnection.
- In a DC-bus connection, all controllers must be inhibited and separated from the mains.

4.2.1.4 Mains disconnection

Make a safety disconnection between the controller and the mains only via a contactor at the input side.

- Please observe that all drives connected to the DC bus must be inhibited.



4.2.2

Protection of the controller



Stop!

The controllers contain electrostatically sensitive components.

- Prior to assembly and service operations, the personnel must be free of electrostatic charge:
 - Discharge by touching the PE fixing screw or another grounded metal part in the control cabinet.

- Length of the screws for the connection to the screen cable/screen plate for the types 9327 to 9332: < 12 mm
- Controller protection by means of external fuses. (§ 3-6)
- Protect unused control inputs and outputs with plugs or covers (included in the contents of delivery) for the Sub-D inputs.
- Frequent mains switching can overload the internal switch-on current limitation. For cyclic mains switching, the controller can be switched on every three minutes as a maximum.
- The controllers 9324, 9326, 9328 and 9329 must only be operated with the appropriate mains filters. (§ 3-7)
- In case of condensation, connect the controller to the mains voltage only after the visible humidity has evaporated.

4.2.3


Motor protection



Stop!

As standard Lenze three-phase AC motors are equipped with PTC thermistors. If motors from other manufacturers are used, carry out all steps required for the adaptation to the controller. (§ 4-28)

- When using motors with insulation which is not suitable for inverter operation:
 - Please contact your motor supplier.
Lenze AC motors are designed for inverter operation.
- With the corresponding parameter setting, the controllers generate field frequencies up to 600 Hz:
 - With motors not suited for the application, dangerous overspeeds may occur and destroy the drive.



Installation

4.2.4

Mains types/conditions

Please observe the restrictions for each mains type!

Mains	Operation of the controllers	Notes
With grounded neutral (IT/TN mains)	No restrictions	Observe controller ratings • Mains r.m.s. current: 3-3
With isolated neutral (IT mains)	Possible, if the controller is protected in the event of an earth fault in the supplying mains. • Possible, if appropriate earth fault detections are available and • the controller is separated from the mains immediately.	Safe operation in the event of an earth fault at the inverter output cannot be guaranteed.
With grounded phase	Operation is only possible with one variant	Contact Lenze
DC-supply via +U _G /-U _G	The DC voltage must be symmetrical to PE.	The controller will be destroyed when grounding +U _G or -U _G .

4.2.5


Interaction with compensation equipment

- The controllers take up a very low fundamental reactive power from the supplying AC mains. Therefore compensation is not necessary.
- If the controllers are operated at mains with compensation, this equipment must be used with chokes.
 - For this, contact the supplier of the compensation equipment.

4.2.6

Specification of all cables used

- The cables used must comply with the required approvals of the application site (e. g. UL).
- The prescribed minimum cross-sections of PE conductors must be maintained in all cases. The cross-section of the PE conductor must be at least as large as the cross-section of the power connections.
- The screening quality of a cable is determined by
 - a good screen connection
 - a low screen resistance
Only use screens with tin-plated or nickel-plated copper braids!
Screens of steel braid are not suitable.
 - For the overlapping degree of the screen braid:
A min. of 70 % to 80 % with an overlapping angle of 90°



4.2.7 Power connections

Controller	Preparations for the power connection
9321 ... 9326	<ul style="list-style-type: none"> Remove the covers of the power connections: <ul style="list-style-type: none"> – Unlatch to the front by gentle pressure. – Pull upwards (mains connection) or downwards (motor connection).
9327 ... 9332	<ul style="list-style-type: none"> Remove cover: <ul style="list-style-type: none"> – Loosen screws (X) (see Fig. 4-1). – Swing cover to the top and detach. – Take the accessory kit out of the interior of the controller.

4.2.7.1 Mains connection

Types 9321 to 9326	Types 9327 to 9332
<p>Correct screen connection with screened cables (required parts in the accessory kit):</p> <ul style="list-style-type: none"> Screw screen plate ① on fixing bracket. ② Fix screen using cable lugs. Do not use as a strain relief! To improve the screen connection: Connect screen additionally at the PE stud next to the power connections. 	<p>Make a correct screen connection with screened cables:</p> <ul style="list-style-type: none"> Connect the screen with suitable clamp on the conducting control cabinet mounting plate. To improve the screen connection: Connect screen additionally to the PE stud next to the power connections.

Fig. 4-7


Proposal for a mains connection

- Connect mains cables to the screw terminals L1, L2, L3.
- Connect cables for brake unit (935X), supply module (934X) or further controllers in the DC bus connection to the screw terminals +UG, -UG at the top of the controller.
- Max. permissible cable cross-sections and screw tightening torques:

Type	max. permissible cable cross-sections	terminals	
		L1, L2, L3, +UG, -UG	PE connection
9321 - 9326	4 mm ² 1)	0.5 ... 0.6 Nm (4.4 ... 5.3 lb-in)	3.4 Nm (30 lb-in)
9327 - 9329	25 mm ² 2)		5 Nm (44 lb-in)
9330 - 9331	95 mm ² 2)		15 Nm (132 lb-in)
9332	120 mm ² 2)		30 Nm (264 lb-in)

1) with pin cable lug: 6 mm²
with wire crimp cap 4 mm²


2) with ring cable lug Cross-section is limited only by the cable entry in the housing



Installation

Fuses

Fuses and cable cross-sections	The specifications in Chapter 3.3.4 are recommendations and refer to the use • in control cabinets and machines • installation in the cable duct • max. ambient temperature +40 °C.	3-6
Selection of the cable cross-section	Consider the voltage drop (according to DIN 18015 part 1: ≤ 3 %).	
Protection of the cables and the controller on the AC side (L1, L2, L3)	• By standard commercial fuses. • Fuses in UL-conform plant must have UL approval. • The rated voltages of the fuses must be dimensioned according to the mains voltage at the site. The activation characteristic is defined by "H" or "K5".	
Protection of the cables and the controller on the DC side (+UG, -UG)	• By means of recommended DC fuses. • The fuses/fuse holders recommended by Lenze are all UL approved.	
For DC bus connection or supply by means of a DC source	Please observe the notes in Part F of the Systems Manual.	
Connection of a brake unit	If a brake unit is connected to the terminals +UG / -UG, the fuses and cross-sections listed in Chapter 3.3.4 do not apply. These unit-specific data can be obtained from the technical documentation of the brake unit.	
Further information	For the protection of cables and the controller please see the chapter "Accessories" under "Planning".	
Other standards	The compliance with other standards (e.g.: VDE 0113, VDE 0289, etc.) remains the responsibility of the user.	



4.2.7.2 Motor connection


We recommend the use of screened motor cables only, because of the EMC safety.



Tip!

The shielding of the motor cable is only required to comply with existing standards (e.g. VDE 0160, EN 50178).


Types 9321 to 9326



Correct screen connection with screened cables (required parts in the accessory kit):


- Screw screen plate ① on fixing bracket. ②
- Fix the screen of the motor cable and thermal contact, if necessary, (see 4-28) with cable lugs. Do not use as a strain relief!
- To improve the screen connection: Connect screens additionally to the PE stud next to the motor connections.

Types 9327 to 9329




Correct screen connection with screened cables:

- Fix the screen of the motor cable and thermal contact, if necessary, (see 4-28) with cable lugs. Do not use as a strain relief!
- To improve the screen connection: Connect screens additionally to the PE stud next to the motor connections.



Installation

Type 9330 and 9331	<ul style="list-style-type: none">• Carry out strain relief using cable binders ①.• Correct screen connection with screened cables:<ul style="list-style-type: none">– Apply motor cable screen to the screening plate using clamp and M5x12 bolts ②.– Fix the screen of the thermal contact (see 4-28) at the PE stud next to the motor connection with a surface as large as possible.
	<ul style="list-style-type: none">• Carry out strain relief using cable binders ①.• Correct screen connection with screened cables:<ul style="list-style-type: none">– Apply motor cable screen to the screening plate using clamp and M5x12 bolts ②.– Fix the screen of the thermal contact (see 4-28) at the PE stud next to the motor connection with a surface as large as possible.



Type 9332	<ul style="list-style-type: none">• Carry out strain relief using clamps and M4x12 bolts ③.<ul style="list-style-type: none">– An additional strain relief/fixing is possible with cable binders ①.• Correct screen connection with screened cables:<ul style="list-style-type: none">– Apply motor cable screen to the screening plate using clamp and M5x12 bolts ②.– Fix the screen of the thermal contact (see 4-28) at the PE stud next to the motor connection with a surface as large as possible.
	<ul style="list-style-type: none">• Carry out strain relief using clamps and M4x12 bolts ③.<ul style="list-style-type: none">– An additional strain relief/fixing is possible with cable binders ①.• Correct screen connection with screened cables:<ul style="list-style-type: none">– Apply motor cable screen to the screening plate using clamp and M5x12 bolts ②.– Fix the screen of the thermal contact (see 4-28) at the PE stud next to the motor connection with a surface as large as possible.

Fig. 4-8

Proposal for the motor connection



- Observe the max. permissible motor cable length:

	amb _r = 400 V (+10%)		amb _r = 480 V (+10%)	
Type	f _{chop} = 8 kHz	f _{chop} = 16 kHz	f _{chop} = 8 kHz	f _{chop} = 16 kHz
9321/9322	up to 50 m	up to 45 m	up to 50 m	up to 25 m
9323 - 9332	up to 50 m	up to 50 m	up to 50 m	up to 50 m
	The max. permissible motor cable length of types 9323 - 9332 will be reduced if the motor cable has more than a single core. • Two parallel single cores: L _{max} = 17 m • Three parallel single cores: L _{max} = 9 m			

- Connect motor cables to the screw terminals U, V, W.
 - Observe correct pole connection.
 - Maximum motor cable length: 50 m.
 - Max. permissible cable cross-sections and screw tightening torques:

Type	Power connections	Max. permissible cable cross-sections	Tightening torques for terminals			
			T1, T2	U, V, W	PE connection	Screen/Strain relief
9321 - 9326	4 mm ² 1)	1.5 mm ²	1.5 mm ²	0.5 ... 0.6 Nm (4.4 ... 5.3 lb-in)	3.4 Nm (30 lb-in)	M4: 1.7 Nm (15 lb-in) M5: 3.4 Nm (30 lb-in)
9327 - 9329	25 mm ² 2)			5 Nm (44 lb-in)	0.5 ... 0.6 Nm (4.4...5.3 lb-in)	
9330 - 9331	95 mm ² 2)			15 Nm (132 lb-in)		
9332	120 mm ² 2)			30 Nm (264 lb-in)		

- 1) with pin cable lug: 6 mm²
 with wire crimp cap: 4 mm²
 2) with ring cable lug: Cross-section is limited only by the cable duct in the housing



Tip!

Switching on the motor side of the controller is permitted only for emergency switch-off.


4.2.7.3 Connection of a brake unit

- When connecting a brake unit (brake module with internal brake resistor or brake chopper with external brake resistor) observe the corresponding Operating Instructions in all cases.



Stop!

- Design the circuit so that, if the temperature monitoring of the brake unit is activated,
 - the controllers are inhibited (X5/28 = LOW).
 - the mains is disconnected.
- Examples:
 - Chapter 4.3, “Installation of a CE-typical drive system”. (§ 4-34)
 - Fig. 4-9, “Decentralized supply for DC-bus connection of several drives”. (§ 4-18)



Installation

4.2.7.4 DC bus connection of several drives

Decentralized supply with brake module




Fig. 4-9 Decentralized supply for DC-bus connection of several drives`

Z1, Z2	Mains filter
Z3	Brake chopper
Z4	Brake resistor
F1...F6	Protection, see "Cable protection" (□ 3-6) / "Mains connection" (□ 4-13)
F7...F10	DC bus fuse; fuse holder with / without alarm contact, see "Cable protection" (□ 3-6) / "Mains connection" (□ 4-13)
K1	Main contactor




Stop!

- Set the DC-bus voltage thresholds of controller and brake unit to the same values.
 - Controller using C0173
 - Brake unit using switches S1 and S2
- A bimetal relais is required for the monitoring of the mains supply.



Tip!

Please observe the specifications in part F of the Manual and the application report "DC bus connection" for the dimensioning and rating of the components.



Central supply with supply module

- When connecting the supply module, the corresponding operating instructions must be observed.





Fig. 4-10 Central supply for DC-bus connection of several drives

Z1	Mains supply filter
Z2	Supply module
F1...F6	Protection, see "Cable protection" (§ 3-6) / "Mains connection" (§ 4-13)
F4...F9	DC bus fuse; fuse holder with / without alarm contact, see "Cable protection" (§ 3-6) / "Mains connection" (§ 4-13)
K1	Main contactor



Tip!

If the power supply of the supply module is not sufficient, a parallel supply can be installed via the mains supply input of a controller (see Manual, Part F). In this case, the controllers can only be operated with the assigned mains filters.



Installation


4.2.8 Control connections

4.2.8.1 Control cables

- Connect control cables to the screw terminals:

Max. permissible cable cross-section	Screw-tightening torques
1.5 mm ²	0.5 ... 0.6 Nm (4.4 ... 5.3 lbin)

- We recommend a single-ended screening of all cables for analog signals to avoid signal distortion.
 - Connect the screens of the control cables
 - with the collective screen plate to the front metal surface
(max. screw length 12 mm).



4.2.8.2 Assignment of the control terminals

Protection against inverse polarity

- The protection against polarity reversal prevents the wrong connection of the internal control inputs. It is, however, possible to overcome the protection against polarity reversal by applying great force. The controller cannot be enabled in this case.

Overview





Fig. 4-11

Layout of the control connections on the front of the controller




	Terminal	Use (Factory setting is printed in bold)	level	Data
Analog inputs	1, 2	Differential master-voltage input (not assigned)	6 4 2 5 3 1 Jumper X3	-10 V to +10 V Resolution: 5 mV (11 bit + sign)
		Differential master-current input (not assigned)	6 4 2 5 3 1 Jumper X3	-20 mA to +20 mA Resolution: 20 µA (10 bit + sign)
	3, 4	Differential master-voltage input (not assigned)	Jumper X3 has no effect	-10 V to +10 V Resolution: 5 mV (11 bit + sign)
Analog outputs	62	Monitor 1 (actual speed)	-10 V to +10 V; max. 2 mA	Resolution: 20 mV (9 bit + sign)
	63	Monitor 2 (torque setpoint)	-10 V to +10 V; max. 2 mA	Resolution: 20 mV (9 bit + sign)
	7	Internal ground, GND	-	-
Digital inputs	28	Controller enable (RFR)	HIGH	Input current for 24V: 8 mA per input Reading and writing of the inputs: once per msec (average value)
	E1	freely assignable (limit switch / positioning in negative direction)	LOW	
	E2	freely assignable (limit switch / positioning in positive direction)	LOW	
	E3	freely assignable start positioning program: Condition: terminal X5/E5 = LOW	LOW signal →HIGH	
	E4	freely assignable (reference switch and touch probe input)	HIGH	
	E5	freely assignable (program active) (TRIP-reset) (reset positioning program) (activate manual operation)	LOW LOW signal →HIGH HIGH HIGH	
Digital outputs	A1	freely assignable (reference known)	HIGH	Output current: max. 50 mA per output (external resistance at least 480 Ω for 24 V) Updating of the outputs: once per msec
	A2	freely assignable (target position reached)	HIGH	
	A3	freely assignable (RDY)	HIGH	
	A4	freely assignable (PFO1)	HIGH	
	39	Ground for digital inputs and outputs	-	
	59	Supply input for the control module: 24 V external (I > 1A)	-	



Tip!

To change the jumper, remove plug-on module, if necessary.





Installation

4.2.8.3 Connection diagrams

Connection of analog signals

Analog signals are connected via the 2 x 4-pole terminal block X6.


Depending on the use of the analog inputs, the jumper of X3 must be set accordingly.

<p>Connection for external supply voltage</p> 	<p>STOP!</p> <ul style="list-style-type: none"> The maximum permitted voltage difference between an external voltage source and the GND1 (terminal X6/7) of the controller is 10V (common mode). The maximum permitted voltage difference between GND1 (terminal X6/7) and the PE of the controller is 50V.
	<p>Limit the voltage difference</p> <ul style="list-style-type: none"> by overvoltage clamping components or by direct connection of terminal(s) X6/2, X6/4 and X6/7 to GND1 and PE (see figure).

Connection for internal voltage supply

93XX

Tip!
Use one of the predefined configurations in C0005 for this application. The output X3/63 is assigned automatically with FIXED100% (corresponds to 10 V at output X6/63) by C005 = XX1X (e.g. 1010 for speed control with control via terminals).




Connection of digital signals

Digital signals are connected via the 2 x 7-pole terminal block X5.

The levels of the digital inputs and outputs are PLC compatible.

Only use relays with low-current contacts for the switching of the signal cables (recommendation: relays with gold-plated contacts).

Connection for external voltage supply



The external voltage source supplies the digital inputs and outputs.


- If the external supply voltage is also to be used as an alternative supply for the control electronics (backup operation in case of mains failure):
 - Also establish the connection illustrated as a broken line.
 - The external voltage source must be able to drive a current > 1 A.

This ensures that all actual values are still detected and processed, even after mains disconnection.

- Connection of the external voltage source:
 - Supply voltage to X5/59
 - External mass to X5/39

STOP!


The maximum permitted voltage difference between GND2 (terminal X5/39) and the PE of the controller is 50 V.



Limit the voltage difference

- by overvoltage clamping components or
- by direct PE connection of terminal 39 (see figure).

Connection for internal voltage supply




Configuration of the internal voltage supply

- Set a freely assignable digital output (DIGOUTx) to HIGH level.
- For instance terminal X5/A1: Assign C0117/1 with FIXED1. 24V are thus applied to terminal X5/A1.

Tip!

Use one of the predefined configurations in C0005 for this application. With C0005 = XX1X (e. g. 20010 for absolute positioning; limited travelling range) FIXED1 is automatically assigned to the output X5/A1 (corresponds to 24 V at terminal X5/A1).



Installation


Digital frequency input (X9) / Digital frequency output (X10)



Tip!

For the connection to the digital frequency input (X9) or digital frequency output (X10), use prefabricated Lenze cables. Otherwise, only use cables with twisted pairs and screened cores (A, \overline{O} / B, \overline{B} / Z, \overline{Z}) (see connection diagram).

Digital frequency output X10	Digital frequency input X9																																																						
Features: <ul style="list-style-type: none"> Sub-D female connector, 9-pole Output frequency: 0 - 500 kHz Current consumption per channel: max 20mA. Two-track with inverse 5 V signals and zero track X10 has a different basic setting depending on the selected configuration (C0005) <ul style="list-style-type: none"> Default setting: Encoder simulation of the resolver signal Load capacity: <ul style="list-style-type: none"> Parallel connection: Up to 3 slave drives Series connection: 250 kHz digital master frequency: up to 22 slave drives 500 kHz digital master frequency: up to 10 slave drives When PIN 8 (EN) shows a LOW level, the master is initialized (e.g. if the mains was disconnected). The slave can thus monitor the master. 	Features: <ul style="list-style-type: none"> Sub-D male connector, 9-pole Input frequency: 0 - 500 kHz Current consumption per channel: max 6mA. Two-track with inverse 5 V signals and zero track Possible input signals: <ul style="list-style-type: none"> Incremental encoder with two 5V complementary signals (TTL encoder) shifted by 90° Encoder simulation of the master PIN 8 serves to monitor the cable or the connected controller: <ul style="list-style-type: none"> When this PIN shows a LOW level, the SD3 monitoring responds. If the monitoring is not required, this input can be connected to +5V. The input is disconnected at C0540 = 0, 1, 2 or 3. 																																																						
<p>Master X10</p> <table border="1"> <tr><td>B</td></tr> <tr><td>A</td></tr> <tr><td>A</td></tr> <tr><td>GND</td></tr> <tr><td>Z</td></tr> <tr><td>Z</td></tr> <tr><td>enable</td></tr> <tr><td>B</td></tr> <tr><td>9</td></tr> </table> <p>Cable length max. 50 m</p> <p>9 pole Sub-D connector</p>	B	A	A	GND	Z	Z	enable	B	9	<p>Slave X9</p> <table border="1"> <tr><td>1</td></tr> <tr><td>2</td></tr> <tr><td>3</td></tr> <tr><td>4</td></tr> <tr><td>5</td></tr> <tr><td>6</td></tr> <tr><td>7</td></tr> <tr><td>8</td></tr> <tr><td>9</td></tr> </table> <table border="1"> <tr><td>B</td><td>mm²</td><td>AWG</td></tr> <tr><td>A</td><td>0.14</td><td>26</td></tr> <tr><td>A</td><td>0.5</td><td>20</td></tr> <tr><td>GND</td><td>0.14</td><td>26</td></tr> <tr><td>Z</td><td>0.14</td><td>26</td></tr> <tr><td>Z</td><td>0.5</td><td>20</td></tr> <tr><td>Lamp control</td><td>0.14</td><td>26</td></tr> <tr><td>B</td><td>0.14</td><td>26</td></tr> </table> <p>For CW rotation</p>	1	2	3	4	5	6	7	8	9	B	mm ²	AWG	A	0.14	26	A	0.5	20	GND	0.14	26	Z	0.14	26	Z	0.5	20	Lamp control	0.14	26	B	0.14	26												
B																																																							
A																																																							
A																																																							
GND																																																							
Z																																																							
Z																																																							
enable																																																							
B																																																							
9																																																							
1																																																							
2																																																							
3																																																							
4																																																							
5																																																							
6																																																							
7																																																							
8																																																							
9																																																							
B	mm ²	AWG																																																					
A	0.14	26																																																					
A	0.5	20																																																					
GND	0.14	26																																																					
Z	0.14	26																																																					
Z	0.5	20																																																					
Lamp control	0.14	26																																																					
B	0.14	26																																																					
<table border="1"> <tr><th colspan="9">Pin assignment X10</th></tr> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr> <tr><td>B</td><td>\overline{O}</td><td>0</td><td>+5 V</td><td>GND</td><td>Z</td><td>Z</td><td>EN</td><td>\overline{B}</td></tr> </table>	Pin assignment X10									1	2	3	4	5	6	7	8	9	B	\overline{O}	0	+5 V	GND	Z	Z	EN	\overline{B}	<table border="1"> <tr><th colspan="9">Pin assignment X9</th></tr> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr> <tr><td>B</td><td>\overline{O}</td><td>0</td><td>+5 V</td><td>GND</td><td>Z</td><td>Z</td><td>LC</td><td>\overline{B}</td></tr> </table>	Pin assignment X9									1	2	3	4	5	6	7	8	9	B	\overline{O}	0	+5 V	GND	Z	Z	LC	\overline{B}
Pin assignment X10																																																							
1	2	3	4	5	6	7	8	9																																															
B	\overline{O}	0	+5 V	GND	Z	Z	EN	\overline{B}																																															
Pin assignment X9																																																							
1	2	3	4	5	6	7	8	9																																															
B	\overline{O}	0	+5 V	GND	Z	Z	LC	\overline{B}																																															



STATE-BUS (X5/ST)

The state bus is a controller-specific bus system for simple monitoring in a network of drives:

- Controls all drives connected to the network according to the preselected state.
- Up to 20 controllers can be connected (total cable length STATE-BUS < 5m).
- Connection of STATE-BUS cables to terminals X5/ST.



Stop!

Do not apply an external voltage across terminals X5/ST.






Fig. 4-12 Monitoring of a network of drives with the STATE-BUS

Z1	Mains filter
F1...F5	Protection, see "Cable protection" (3-6) / "Mains connection" (4-13)
K1	Main contactor



Tip!

Further information can be obtained from the Manual of your controller.



Installation

System bus connection (X4)





Fig. 4-13 Wiring system bus

RA1, RA2 Bus terminating resistors 120 Ω (included in the accessory kit)

- Connection via pluggable screw terminals (double terminals can be used).
- Only connect terminals of the same designation.
- Features of the system cable:

Total cable length	up to 300 m	300 m to 1000 m
Cable type	LIYCY 2 x 2 x 0.5 mm ² twisted-pair with screening Pair 1: CAN-LOW (LO) and CAN-HIGH (HI) Pair 2: 2*GND	CYPIMF 2 x 2 x 0.5 mm ² twisted-pair with screening Pair 1: CAN-LOW (LO) and CAN-HIGH (HI) Pair 2: 2*GND
Cable resistance	$\chi \leq 40 \Omega/\text{km}$	$\leq 40 \Omega/\text{km}$
Capacitance per unit length	$\leq 130 \text{ nF/km}$	$\leq 60 \text{ nF/km}$

- Connection of the bus terminating resistors:
 - One resistor 120 Ω each on the first and last bus device.
 - On the 93XX controller the resistor can be screwed directly under the terminals X4/HI and X4/LO.



Features:

- CAN-based with bus protocol according to CANopen (CAL-based Communication Profile DS301)
- Bus extension:
 - 25 m for max. 1 Mbit/s baud rate
 - up to 1 km with reduced baud rate
- Very reliable data transmission (Hamming distance = 6)
- Signal level according to ISO 11898
- Up to 63 bus devices are possible
- Access to all Lenze parameters
- Master functions are integrated into the controller
 - Data exchange possible between controllers without participation of a master system (current ratio control, speed synchronization, etc.)

The following connections of the system bus connection are possible:

- Connection to a decentral terminal extension for digital and analog inputs and outputs
- Connection to a superimposed control (PLC, position control, operating terminal)
- Connection between several controllers




Tip!

Further information can be obtained from the Manual of your controller.

Automation interface (X1)

The automation interface (X1) is used for the connection of different plug-on modules

- Operating module
- Fieldbus modules
 - 2102 LECOM-A/B/LI
 - 2111 INTERBUS
 - 2112 INTERBUS loop
 - 2131 PROFIBUS-DP and 2133 PROFIBUS-DP
 - 2174 CAN addressing module
 - 2175 DeviceNet / CANopen



Installation

4.2.9 Motor temperature monitoring

Selection of the feedback system	<ul style="list-style-type: none"> Continuous temperature sensor KTY <ul style="list-style-type: none"> “Linear” temperature sensor in the motor winding (standard for Lenze motors MDXKK, MDXQA and MDXMA) Temperature sensor PTC <ul style="list-style-type: none"> PTC thermistor with defined tripping temperature (acc. to DIN 44081 and DIN 44082) Thermal contact TKO <ul style="list-style-type: none"> Thermostat/normally closed contact
Other monitoring	KTY, PTC and TKO do not offer full protection. To improve the monitoring, Lenze recommends a bimetal relay.
Alternative monitoring	Comparators (CMP1 ... CMP3) monitor and a time element (TRANS1 ... TRANS4) limits the motor current for small speeds or motor standstill. This function can be implemented by interconnecting the corresponding function blocks.
Reactions	different, depending on the temperature monitoring. 7-2



Stop!

Do not connect an external voltage to the inputs.

	Lenze motors		Motors of other manufacturers			
	MDXKK, MDXQA and MDXMA	with thermal contact	with sensor for continuous temperature detection	with thermal contact or PTC acc. to DIN 44081/44082		
Connection	<ul style="list-style-type: none"> Resolver input X7: <ul style="list-style-type: none"> Pin X7/8 = +, Pin X7/9 = - Encoder input X8: <ul style="list-style-type: none"> Pin X8/8 = +, Pin X8/5 = - 	Terminals T1/T2 next to the terminals U, V, W	<ul style="list-style-type: none"> Resolver input X7: <ul style="list-style-type: none"> Pin X7/8 = +, Pin X7/9 = - Encoder input X8: <ul style="list-style-type: none"> Pin X8/8 = +, Pin X8/5 = - 	<ul style="list-style-type: none"> Resolver input X7: <ul style="list-style-type: none"> Pin X7/8 = +, Pin X7/9 = - Encoder input X8: <ul style="list-style-type: none"> Pin X8/8 = +, Pin X8/5 = - 	<ul style="list-style-type: none"> Terminals T1/T2 next to the terminals U, V, W 	
Fault messages	(MONIT-)OH3	(MONIT-)OH7	(MONIT-)OH8	(MONIT-)OH3	(MONIT-)OH7	(MONIT-)OH8
Possible reactions	The corresponding monitoring and thus the following codes are preset under C0086					
	<ul style="list-style-type: none"> Trip (C0583 = 0) OFF (C0583 = 3) 	<ul style="list-style-type: none"> Warning (C0584 = 2) OFF (C0584 = 3) 	<ul style="list-style-type: none"> Trip (C0585 = 0) Warning (C0585 = 2) OFF (C0585 = 3) 	<ul style="list-style-type: none"> Trip (C0583 = 0) OFF (C0583 = 3) 	<ul style="list-style-type: none"> Warning (C0584 = 2) OFF (C0584 = 3) 	<ul style="list-style-type: none"> Trip (C0585 = 0) Warning (C0585 = 2) OFF (C0585 = 3)
Tripping temperature	fixed at 150 °C	adjustable 45°C ... 150°C (C0121)	fixed, (depending on the PTC/thermal contact): PTC: at R _θ > 1600 Ω	fixed at 150 °C	adjustable 45°C ... 150°C (C0121)	fixed, (depending on the PTC/thermal contact): PTC: at R _θ > 1600 Ω
Notes	<ul style="list-style-type: none"> Monitoring is active in the default setting. If resolver (X7) and encoder (X8) are operated together: <ul style="list-style-type: none"> Connect KTY only at one connector (X7 or X8) Do not connect KTY connection of the other female connector For further information on the connection of the thermal sensor, please consult the description of the feedback system 	<ul style="list-style-type: none"> Deactivate monitoring via X7 or X8 under C0583=3 and C0584=3 Connection to DIN 44081 (see also Fig. 4-14). 	<ul style="list-style-type: none"> Input characteristic. 4-29 Deactivate monitoring via X7 or X8 under C0583=3 and C0584=3 		<ul style="list-style-type: none"> Deactivate monitoring via X7 or X8 under C0583=3 and C0584=3 Connection to DIN 44081 (see also Fig. 4-14). We recommend a Ziehl PTC (up to 150 °C): K15301075 or a thermostat. 	





Fig. 4-14

Connection of a thermistor or PTC thermistor to terminals T1 and T2 and internal connection




Note!

- In the prefabricated Lenze system cables for **Lenze servo motors** the cable for the temperature feedback is already included. The cables are designed for wiring according to EMC.
- If you use cables of your own:
 - Always lay cables separately from motor cables.

4.2.9.1 User-specific characteristic for a PTC thermistor

		Code	Subcode	Description
R [Ohm]		C1190	0 (operating mode 1)	Evaluation of the Lenze standard motor temperature sensor
			1 (operating mode 2)	Evaluation of a user-specific thermal sensor. The operating point is in the almost linear area (a) of the sensor characteristic. The operating point is provided by two interpolation points. Interpolation between these two points.
		C1191	1 (100 °C) 2 (150 °C)	Definition of the temperature interpolation points which are assigned to the resistances of the sensor.
		C1192	1 (1670 Ω) 2 (2225 Ω)	Definition of the sensor resistances

Example of a sensor characteristic for continuous temperature detection



Installation

4.2.10 Feedback systems

Different feedback systems can be connected to the controller:

- Resolver feedback (factory setting)
- Encoder feedback
 - Incremental encoder TTL
 - Sin/cos encoder
 - Sin/cos encoder with serial communication (single turn)
 - Sin/cos encoder with serial communication (multi turn)


Resolver signal or encoder signal can be output for slaves at the digital frequency output X10.

- Connection as shown in the figures:
 - Use twisted pair cables and screened pair cables.
 - Connect the screen at both ends.
 - Use indicated cable cross-sections.
- The feedback system is activated under C0025.

Sensorless control SSC

The sensorless controller (SSC) should not be used for new drive solutions (C0025 = 1).

Instead use a vector control EVF 9300 or contact Lenze.



Resolver connection (X7)

- In all configurations predefined under C0005, a resolver can be used as feedback system. An adjustment is not necessary.



Note!

Use pre-cut Lenze system cables to connect the resolver.

Please contact Lenze before you use other resolvers.

Features:

- 2-pole resolver ($V = 10 \text{ V}$, $f = 4 \text{ kHz}$)
- Resolver and resolver cable are monitored for open circuit (fault indication Sd2)





Fig. 4-15 Resolver connection

Assignment of the female connector (X7)


Pin	1	2	3	4	5	6	7	8	9
Signal	+Ref	-Ref	GND1	+COS	-COS	+SIN	-SIN	+PTC (4-28)	-PTC (4-28)



Installation

Encoder connection (X8)

An incremental encoder or a sin/cos encoder can be connected to this input.



Note!

Use pre-cut Lenze system cables to connect the encoder.

- The encoder supply voltage V_{CC5_E} can be adjusted in the range from 5 V to 8 V under C0421
 - to set the encoder supply
 - to compensate the voltage drop on the encoder cable, if necessary
 $\Delta U \approx 2 * \text{cable length} * \text{resistance/m} * I_{\text{encoder}}$



Stop!

Observe the connection voltage of the encoder system used. If C0421 is set too high, the encoder might be destroyed.





Fig. 4-16

Encoder connection



Incremental encoder

Features:

- Incremental encoders with two 5 V complementary signals which are shifted by 90 ° (TTL encoder) can be connected.
 - The zero track can be connected (as option).
- 9-pole Sub-D female connector
- Input frequency: 0 - 500 kHz
- Current consumption per channel: 6 mA

Assignment of the male connector (X8)									
Pin	1	2	3	4	5	6	7	8	9
Signal	B	0	0	V _{CC5_E}	GND (-PTC)	Z	Z	+PTC (4-28)	̄B

Sin/cos encoder

Features:


- The following encoders can be connected
 - sin/cos encoders with a rated voltage from 5 V to 8 V.
 - Sine-cosine encoders with a communication interface of type Stegmann SCS/M70xxx (The initialization time of the controller is increased to approx. 2 seconds).
- 9-pole Sub-D female connector
- Internal resistance R_i = 221 Ω
- Voltage sine and cosine track: 1 Vpp ±0.2 V
- Voltage RefSIN and RefCOS: +2.5 V



Note!

For drives with track indications assign: sine, sine and cosine, cosine:
Assign RefSIN with sine and RefCOS with cosine .

Assignment of the male connector (X8)									
Pin	1	2	3	4	5	6	7	8	9
Signal	SIN	RefCOS	COS	V _{CC5_E}	GND (-PTC)	̄Z or -RS485	Z or +RS485	+PTC (4-28)	RefSIN



Installation

4.3

Installation of a CE-typical drive system

General notes	<ul style="list-style-type: none">The electromagnetic compatibility of a machine depends on the type of installation and care taken. Please observe:<ul style="list-style-type: none">– Assembly– Filters– Shielding– GroundingFor diverging installations, the conformity to the CE EMC Directive requires a check of the machine or system regarding the EMC limit values. This is for instance valid for<ul style="list-style-type: none">– Use of unscreened cables– Use of group RFI filters instead of assigned RFI filters– Operation without mains filterThe compliance of the machine application with the EMC Directive is in the responsibility of the user.<ul style="list-style-type: none">– If you observe the following measures, you can assume that the machine will operate without any EMC problems caused by the drive system, and that compliance with the EMC Directive and the EMC law is achieved.– If devices which do not comply with the CE requirement concerning noise immunity EN 50082-2 are operated close to the controller, these devices may be disturbed electromagnetically by the controllers.
Assembly	<ul style="list-style-type: none">Connect controller, mains choke, and mains filter to the grounded mounting plate with a wire of large a cross-section as possible:<ul style="list-style-type: none">– Mounting plates with conductive surfaces (zinc-coated, stainless steel) allow permanent contact.– Painted plates are not suitable for installation in accordance with the EMC.If you use several mounting plates:<ul style="list-style-type: none">– Connect as much surface as possible of the mounting plates (e.g. with copper bands).Ensure the separation of motor cable and signal or mains cable.Do not use the same terminal strip for mains input and motor output.Cable guides as close as possible to the reference potential. Unguided cables have the same effect as aerials.
Filters	<ul style="list-style-type: none">Use mains filters or RFI filters and mains chokes which are assigned to the controller:<ul style="list-style-type: none">– RFI filters reduce impermissible high-frequency interference to a permissible value.– Mains chokes reduce low-frequency interferences which depend on the motor cable and its length.– Mains filters combine the functions of mains choke and RFI filter.
Shielding	<ul style="list-style-type: none">Connect the screen of the motor cable to the controller<ul style="list-style-type: none">– to the screen connection of the controller.– additionally to the mounting plate with a surface as large as possible.– Recommendation: For the connection, use ground clamps on bare metal mounting surfaces.If contactors, motor-protecting switches or terminals are located in the motor cable:<ul style="list-style-type: none">– Connect the screens of the connected cables also to the mounting plate, with a surface as large as possible.Connect the screen in the motor terminal box or on the motor housing to PE:<ul style="list-style-type: none">– Metal glands at the motor terminal box ensure a connection of the screen and the motor housing.If the mains cable between mains filter and controller is longer than 300mm:<ul style="list-style-type: none">– Screen mains cables.– Connect the screen of the mains cable directly to the inverter and to the mains filter and connect it to the mounting plate with as large a surface as possible.Use of a brake chopper:<ul style="list-style-type: none">– Connect the screen of the brake resistor cable directly to the mounting plate, at the brake chopper and the brake resistor with as large a surface as possible.– Connect the screen of the cable between controller and brake chopper directly to the mounting plate, at the inverter and the brake chopper with a surface as large as possible.Screen the control cables:<ul style="list-style-type: none">– Connect both screen ends of the digital control cables.– Connect one screen end of the analog control cables.– Always connect the screens to the screen connection at the controller over the shortest possible distance.Application of controllers in residential areas:<ul style="list-style-type: none">– To limit the radio interference, use an additional screen damping ≥ 10 dB. This is usually achieved by installation in enclosed and grounded control cabinets made of metal.
Grounding	<ul style="list-style-type: none">Ground all metallically conductive components (controller, mains filter, motor filter, mains choke) using suitable cables connected to a central point (PE bar).Maintain the minimum cross-sections prescribed in the safety regulations:<ul style="list-style-type: none">– For the EMC, not the cable cross-section is important, but the surface and the contact with a cross-section as large as possible, i.e. large surface.







Fig. 4-17 Example for wiring in accordance with EMC regulations

- | | |
|---------|---|
| F1...F5 | Protection, see "Cable protection" (3-6) / "Mains connection" (4-13) |
| K1 | Mains contactor |
| Z1 | For mains filter "A" or "B" see Accessories. |
| Z2 | Brake mode, see Accessories. |
| -X1 | Terminal strip in control cabinet |
| PES | HF screening by connection to PE with a surface as large as possible (see "Shielding") 4-34) |



Installation



5 Commissioning

5.1 Before switching on

Prior to initial switch-on of the controller, check the wiring for completeness, short-circuit, and earth fault:


- Power connection:
 - Supply via terminals L1, L2 and L3 (direct mains connection) or alternatively via terminals +UG, -UG (DC bus connection, network of drives).
- Motor connection:
 - In-phase connection to the motor (direction of rotation).
- Feedback system (resolver, incremental encoder, ...).
- Control terminals:
 - Controller enable: terminal X5/28 (reference potential: X5/39).
- Cover of the power terminals:
 - Put on cover(s) and fix.
- **Keep to the switch-on sequence!**
- All commissioning steps described in this chapter refer to the default setting.

5.2 Initial switch-on



Tip!

- Use a PC with the Lenze program "Global Drive Control" (GDC) under Windows for commissioning. The convenient menu includes the codes for the most important settings.
- A fieldbus module type 2102 "RS232, RS485, fibre optics" (Lecom A/B) is required to run the GDC.
- GDC and fieldbus module are not included in the scope of supply of the controller.



Commissioning

ON

Commissioning using an example





Fig. 5-1 Example of a drive control with default setting

Switch	Function
S1	Limit switch for negative direction of positioning (system protection)
S2	Limit switch for positive direction of positioning (system protection)
S3	Start positioning program
S4	Reference label for homing Tip: Set E4 to HIGH if there is no homing mark.
S5	Change-over from positioning to manual operation


Positioning profile	Name	Function
	a1	Acceleration forwards
v1	v1	positioning speed forwards
a2	a2	Deceleration forwards
v2	v2	Creeping for target approach
t1	t1	Waiting time (e.g. processing of a workpiece)
a3	a3	Acceleration backwards
v3	v3	positioning speed backwards
a4	a4	Deceleration backwards

K35.0126



The following table lists the procedure for the commissioning of a position control according to the example in Fig. 5-1. A comprehensive description of the commissioning of position controls can be obtained from the following chapters.

Section	Action	Detailed description
Switch on controller	<ol style="list-style-type: none"> Assign terminal X5/28 (controller enable) to LOW signal. Assign terminals X5/E1 and X5/E2 to HIGH signal (+13...+30V). Assign terminals X5/E3 to X5/E5 to LOW signal. Switch on mains: <ul style="list-style-type: none"> The controller is ready for operation after approx. 1s (2 s for drives with sine-cosine encoder with serial interface). 	<input type="checkbox"/> 5-5
Switch on PC	<p>Start GDC on the PC</p> <ul style="list-style-type: none"> Set the communication parameters for online operation in the "Momentary drive" dialog box. Confirm with "OK". Select the controller in the "Assign controller description" dialog box. Confirm with "OK". 	<input type="checkbox"/> 5-5
Generate parameter set	<ol style="list-style-type: none"> Adapt controller to the mains Adapt controller to the motor Enter machine parameters 	<input type="checkbox"/> 5-6 <input type="checkbox"/> 5-7 <input type="checkbox"/> 5-8
Manual control	<ol style="list-style-type: none"> Enter parameters for manual positioning or use default setting Enable controller Function test with manual control 	<input type="checkbox"/> 5-9 <input type="checkbox"/> 5-10 <input type="checkbox"/> 5-11
Enter parameters for positioning profile	<ol style="list-style-type: none"> Enter positioning data in the "Programming" dialog box. Connect the X5 terminals in the "Terminal monitor 93XX (digital)" menu <ul style="list-style-type: none"> When the digital terminals X5 are supplied with internal voltage; Assign output X5/A1 with "FIXED1". The output on terminal X5/A1 is approx. 24V. <p>TIP! For this application, you may use one of the predefined configurations in C0005. C0005 = XXX1X (e.g. 20010 = absolute positioning with control via terminals) assigns FIXED1 automatically to the output X5/A1.</p>	<input type="checkbox"/> 5-13
Control drive	<ol style="list-style-type: none"> Check whether the drive is ready for operation: <ul style="list-style-type: none"> When the green LED is flashing: Controller is ready for operation, go on with step 2. When green LED is off and red LED is flashing: Interference. Before proceeding with commissioning, eliminate the fault. Enable controller <ul style="list-style-type: none"> Green LED is illuminated when a HIGH signal (+13...+30V) is assigned and no other source of the controller inhibit is active. For operation with a fieldbus module, additional settings are necessary (see operating instructions of the fieldbus module). The motor now rotates with the provided set-value and the selected direction of rotation. 	<input type="checkbox"/> 5-23 <input type="checkbox"/> 8-1



Commissioning

5.3 Commissioning sequence





Fig. 5-2

Commissioning sequence



5.4 Switch on the controller

1. Assign LOW level to terminal X5/28 (controller enable).
2. Connect the positioning limit switch to terminals X5/E1 and X5/E2 (§ 4-20)

Note:

If you do not use positioning limit switches, assign the terminals to HIGH level.

3. Assign LOW level to terminals X5/E3 to X5/E5.
4. Switch on mains:
 - The controller is ready for operation after approx. 1s (2 s for drives with sin/cos encoders with serial interface).
5. Check whether the controller is ready for operation:
 - If the green LED is flashing:
Controller is ready for operation.
 - When green LED is off and red LED is blinking:
There is a fault. Before proceeding with commissioning, eliminate the fault. (§ 8-1)
6. For operation with a fieldbus module, additional settings are necessary (see Operating Instructions for the fieldbus module used).

5.5 Switch on PC, start GDC


- Switch on PC.
- Start the GDC program under Windows.

When GDC is in "online operation"

- The "Find LECOM A/B drives" dialog box is opened.
- Click "Find". GDC will now search for a controller.
- GDC selects the first controller found.
- GDC tests all baud rates which can be set.
- GDC loads the parameter set description for the connected controller.
 - If GDC does not find a parameter set description, you are asked which description you want to load alternatively.
- GDC automatically reads the parameter set from the controller.

When GDC is in "offline operation"

- You have to select the controller manually.
 - You can change to "online operation". GDC automatically selects a controller.
- Open the "Controller" menu in the menu bar and click "Select". Make your choice for:
 - the desired parameter set description.
 - Baud rate.
 - Controller address.



Commissioning

ON

5.6

Generate parameter set



Warning!

Do not change any controller settings that are not mentioned in this chapter. For more complex positioning tasks consult the Manual.

The instructions for the generation of a parameter set in this Chapter are based on the factory setting.

Proceed systematically when generating a parameter set:

1. Adapt controller to mains conditions.
2. Adapt controller to motor.
3. Enter machine parameters.
4. Enter parameters for manual positioning. (Then carry out a function test.)
5. Enter parameters for positioning profile.



Tip!

Make a positioning profile of your positioning task and, using this drawing, determine as much positioning data as possible. (§ 5-13)

5.6.1

Adapt controller to the mains





Fig. 5-3

"Basic settings" dialog box

Field	Command	Function
1	Click on field	Select values for the actual mains and operating conditions.



5.6.2 Adapt controller to the motor

To achieve an optimum speed-torque characteristic for the drive, it is necessary to enter the nameplate data of the connected motor.

When you use a Lenze motor:

Field	Command	Function
2	Click "motor type (A)".	Select connected motor.
3	Click "encoder (B)".	Selected feedback system used.
4	Click on field "position polarity".	Select direction of rotation.

For motors with a resolver, use the eight-digit designation of the motor nameplate "encoder" (as an option).

- For this change to the parameter menu (see button Fig. 5-4) and select the menu "Motor/feedback system".




Fig. 5-4 How to find the menus "Motor setting" and "Feedback systems"

In the menu "Feedback systems":


Field	Command	Function
	Select C0416	Resolver fault. Enter value from the motor nameplate
	Select C0003	Save data (C0003 = 1).

If you use a motor other than from Lenze:

Change to the menu "Motor setting" (see Fig. 5-4).

In the menu "Motor setting":

Field	Command	Function
	Select C0086	Select a motor which best matches the motor used. List of the motors available:
	Select C0006	Operating mode of the motor control
	Select C0022	Adapt I_{max} to the maximum motor current.
	Select C0081	Rated motor power
	Select C0084	Stator resistance of the motor (only for very high demands on the control characteristics).
	Select C0085	Stray inductance of the motor (only for very high demands on the control characteristics).
	Select C0087	Rated motor speed
	Select C0088	Rated motor current
	Select C0089	Rated motor frequency
	Select C0090	Rated motor voltage
	Select C0091	Motor cos φ .
	Select C0003	Save data (C0003 = 1).



Commissioning

5.6.3 Enter machine parameters





Fig. 5-5

"Base settings" dialog box

Field	Command	Function	
1	Click on field "Gearbox numerator"	Enter denominator for the gearbox ratio.	$i = \frac{n_{motor}}{n_{gearbox\ output}}$
2	Click on field "Gearbox denominator"	Enter numerator for the gearbox ratio.	The value results from the number of units (e. g. mm) being moved forward during one rotation at the gearbox output side.
3	Click on field "Feed constant"	Enter feed of the spindle.	
4	Click on field "Speed (n-max)"	Enter upper speed limit of the motor	
5	Click on field "speed (v-max)"	Enter fastest positioning speed of the machine	
6	Click on field "Acceleration (a-max)"	Maximum permissible acceleration (with interference or during approach to position limit switches a-max cannot be activated).	
7	Click on field "QSP ramp"	Time from release of fault or approach to a position limit switch to machine standstill.	



5.6.4

Parameters for manual positioning



Stop!

Check the parameters for manual positioning. To check the configuration, select small values for acceleration and speed (e.g. factory setting).

The factory setting of the parameters is sufficient for most applications. Enter the settings as follows:





Fig. 5-6 Menu "Manual positioning" in the parameter menu

Step	Command	Function
1	Select "Basic settings" dialog box.	
2	Click on "Parameter menu" button.	Open parameter menu
3	Click on "Positioning functions" menu.	Open "Positioning functions" menu.
4	Click on "Manual positioning" menu.	Open "Manual positioning" menu.
5	Click on C1243. Enter new value.	Manual positioning speed. Factory setting: 5 % of vmax
6	Click on C1252. Enter new value.	Manual positioning acceleration. Factory setting: 10 % of amax
7	Click on C0003.	Save settings
8	Click on "Dialog control" menu.	Open "Control" dialog box.



ON

Commissioning

5.6.5 Controller enable

- The controller is enabled only when all sources of the controller inhibit are reset.
 - When the controller is enabled, the green LED on the controller is illuminated.
- For the display of active sources of a controller inhibit see Chapter “Troubleshooting”. (§ 8-1)

The following table shows the conditions for controller enable:

Source controller inhibit	Controller inhibited	Controller enabled	Note
Terminal X5/28	0 V ... +4 V	+13 V ... +30 V	-
Fault	In case of TRIP In case of Message	TRIP reset	Check, see § 8-1
System bus (CAN)	Transmission of the control information INHIBIT via C0135	Transmission of the control information ENABLE via C0135	§ Manual
Field bus module	See operating instructions of the corresponding fieldbus module		-




Tip!

All sources of controller inhibit act like a series connection of switches, independent of each other.



Stop!

When the internal control structure is changed, another terminal assignment may result.



5.7

Function test with manual control

Test the function with manual control after every new or modified configuration.



Warning!

Provide suitable emergency stops for manual operation so that you will be able to stop the drive in the event of unpredictable movements.





Fig. 5-7

Dialog box "Control"

Field	Command	Function
3	Select "Manual operation"	Manual operation active
5		With drive diagnostics "Ok", "Enable" is possible. 6-1
4	Controller "Enable"	Enables the controller, if there is no interference.
2	Select "Manual positive" Reset "Manual positive"	The drive moves in the positive direction towards the limit switch. <ul style="list-style-type: none"> • Test positioning limits • Override positioning limit switch to test its function. The drive stops.



Commissioning




Fig. 5-8


Dialog box "Control"

Field	Command	Function
1	Select "Manual negative"	The drive positions in the negative direction towards the limit switch. <ul style="list-style-type: none">• Test positioning limits• Override positioning limit switch to test its function.
	Reset "Manual negative"	The drive stops.
1, 2	"Manual positive" and "Manual negative" selected	The drive brakes with a-max down to standstill.



Tip!

- To assign the reverse direction to the function "Manual positive" and "Manual negative", change to the dialog box "Base settings" and set the field "Position polarity" to "inverted".
- You can quit overridden limit switches only by changing the positioning direction ("Manual positive" or "Manual negative").



5.8 Enter positioning profile parameters

5.8.1 Structure of a positioning program

- The positioning program consists of max. 32 program sets (PS).
- The sequence of processing the PS within the positioning program can be freely selected.
- The PS determine the sequence of the positioning. The functions within a PS are processed according to a fixed sequence (see Fig. 5-14). These functions include:
 - Type of positioning (relative or absolute positioning with or without touch probe)
 - Speed profile of the positioning
 - Access to data in the variable tables (VT).
 - Reaction on external events via digital inputs (PFI)
 - Processing of waiting times
 - Repetition of number of pieces
 - Output of control signals via digital outputs (PFO)





Fig. 5-9

PS input dialog

- The positioning is carried out according to the positioning profile parameters. These parameters are listed in the variable tables (VT). The following VTs are available:
 - VTPOS for the target position
 - VTEL for the positioning speed and final speed
 - VTACC for the acceleration and deceleration
 - VTPCS for the number of pieces or repeat function
 - VTTIME for the waiting time



Commissioning

5.8.1.1 Tools for editing

For a simple and fast input of parameter data, GDC provides tools for editing. These are explained in the PS templates displayed in the program.






Fig. 5-10 Editing tools for the program sets

Field	Function	Description
1, 3	Selection of a PS	Click on "Go to ..." (3). The dialog box (1) is opened. Select a PS which you want to modify. At the same time you can write notes about the PS. For this, click on "Documentation" (13) (see also 7).
2	Browsing the PS	Select the previous or next PS or jump to the first or last PS.
4	Insert PS	Inserts a new PS at this place and displaces all following PS by one position. The last PS is deleted.
5	Delete PS	Deletes the current PS and displaces all following PS by one position.
6	Reset PS	Resets all parameters of the current PS to factory setting.
7, 10, 11, 12	Write comments on the PS	Documentation of current PS. In the dialog box (10) you can enter a name for the PS (12) and add an explanatory text as comment (11).
8	Print PS	Output of the current or all PS to a printer.
9	Select dialog box "Control".	Direct change to the dialog box "Control", e.g. to test modifications in manual operation. 5-11



5.8.1.2 Structure of a positioning profile

- Make a positioning profile of your task (e.g. Fig. 5-11, Fig. 5-12)
- For more complex positioning profiles, generate the positioning program with several PS (e.g. for different positioning speeds).



K35.0127


Fig. 5-11 Structure of a positioning profile (example of a point-to-point positioning)

In the example, a total of three program sets are required for the complete input of all parameters. Every PS uses the same input template. The input template is described in the next Chapter.


Program sets

The parameter data for the positioning profile are saved in the program sets.

- Thanks to the template of the program sets.
 - the sequence of the input is determined. (Fig. 5-19)
 - complex positionings are divided into individual sections (sets).
- Every program set can be called up again and again without further programming.
- A total of 32 program sets are available.




Commissioning



K35.0128

Fig. 5-12 Structure of a positioning profile (example of a point-to-point positioning)

Name	Program set (PS)	Function
a1	PS01	Acceleration forwards
t1	PS01	Time until v1 is reached
v1	PS01	Positioning speed forwards
t2	PS01	Calculated time of braking to reach v2 in t3
a2	PS01	Deceleration 1 forwards
t3	PS01	Start creeping with v2
v2	PS01, PS02	Final speed (PS01), positioning speed (PS02)
t4	PS02	Drive approaches position
a3	PS02	Deceleration 2 forwards
t5	PS02	Position reached, then waiting time (e.g. processing of a workpiece)
t6	PS03	Start backward motion
a4	PS03	Acceleration backwards
t7	PS03	Time until v3 is reached
v3	PS03	positioning speed backwards
t8	PS03	Time until a5 starts (calculated)
a5	PS03	Deceleration backwards
t9	PS03	Time until the start is reached again



Description of the input template

Click on the "Programming" button in the "Basic settings" dialog box.





Fig. 5-13 Dialog box for entering the positioning data

Field	Function	Description
1	Dialog box for a program set (PS)	All necessary positioning profile parameters for a PS are entered as well as possible branches to further PS.
2, 3	Parameter field	Click on field. A dialog box (3) for selecting a parameter is opened.
4, 5, 6	Selection field	A parameter is selected. Click on desired parameter. For variable tables (VT) you can describe the table items. For this, click on "Input" (5). A dialog box (6) for entering a parameter is opened.
6	Dialog box	Dialog box for entering a parameter in the variable table
7	Input field	Input of the desired parameter
8	Comment on the parameter	You can write a comment to the parameter, e.g. for which function it is required.



Commissioning

Processing a program set

The following chart shows the processing of a program set (PS).





Fig. 5-14

Processing a program set



5.8.1.3 Enter parameters





Fig. 5-15 Dialog box for entering the positioning data

Field	Function	Description
1	Inactive or no. of a PFI 0 level or 1 level	Program function input (PFI). A digital input signal via an FB or terminal initiates the processing of the PS.
2	Inactive or no. of a PFO (0 or 1 level)	Program function output (PFO). A digital output signal indicates the state via an FB or via terminal.
3	Type of positioning	e.g. absolute positioning, relative positioning or special function (set reference).
4	Position target of VTPOS	Input of a position target from the variable table VTPOS.
5	Positioning speed from VTVEL	Input of a speed from the variable table VTVEL.
6	Acceleration from VTACC	Input of an acceleration from the variable table VTACC.
7	Deceleration from VTACC	Input of a deceleration from the variable table VTACC.
8	Final speed from VTVEL	Input of a speed from the variable table VTVEL or standstill.
9	TP window from VTPOS	Input of a position value from the variable table VTPOS.
10→20	TP residual distance from VTPOS	Input of a position value from the variable table VTPOS. If there is no touch probe during a touch probe positioning, the program branches/jumps ("if PS CANCEL or no TP") to a PS or program end.
11	Inactive or no. of a PFO (0 or 1 level)	Program function output (PFO). A digital output signal indicates the state via an FB or via terminal.
12	Inactive or time from VTTIME	Input of a waiting time from the variable table VTTIME until the next program function is processed.
13→19	Inactive or no. of a PFI 0 level or 1 level	Program function input (PFI). If a digital input signal is applied during a request (via a FB or a terminal), the program branches ("Jump to") to a PS or to the program end.
14→18	Inactive or no. of a PFI 0 level or 1 level	Program function input (PFI). If a digital input signal is applied during a request (via a FB or a terminal), the program branches ("Jump to") to a PS or to the program end.
15→17	Inactive or number from VTPCS	Input of a set piece number from the variable table VTPCS. As long as the set piece number is not reached, the program branches to a PS or to the program end.
16	Jump to the next PS or program end	Input of a PS or program end to which the program branches after the current PS has been processed.



Commissioning

5.8.2 Save parameter set

The operating menu GDC (see Fig. 5-16) allows you to save a new or modified parameter set:

- Saving on the hard drive of the PC or a diskette by "Write all parameter sets to file"
- Saving in the controller by "Write current parameter set to the controller (F5)"
 - You can save the data as non-volatile with C0003=1 in the "Parameter set management" menu.



Tip!

Comments can be entered for the parameter set when saving on the hard drive or diskette.

1. Click on "Drive parameters" in the menu bar of GDC.





Fig. 5-16

Dialog box "Write parameter set to file"

2. Select "Write all parameter sets to file".
3. Enter the file names and select the disk drive on which you want to save the parameter set.
4. Write a comment on the parameter set in the "Commentary" field and confirm with "Ok".



5.9 Load parameter set

5.9.1 Load parameter set from the PC

The operating menu (Fig. 5-17) allows the loading of a parameter set

- from the hard disk of the PC or a diskette in GDC by "Read all parameter sets from file"
- from the PC to the drive by "Write current parameter set to the controller (F5)"



Warning!

- The controller is re-initialized by the parameter set transfer from the PC to the controller:
 - System configurations and terminal assignments may be modified. Ensure, that your wiring and drive configuration correspond to the settings of the parameter set.
- Only use terminal X5/28 or the STOP function of GDC as a source for the controller inhibit. A parameter set transfer is only possible when the controller is inhibited.

1. Insert a diskette with the parameter set into the disk drive of the PC. Click on "Drive parameters" in the menu bar of GDC.





Fig. 5-17

Dialog box "Read all parameter sets from file"

2. Select "Read all parameter sets from file".
3. Select the disk drive and the parameter set which is to be loaded. Confirm with "OK".
4. Make sure that your wiring and drive configuration match the settings of the new parameter set.



ON

Commissioning

5.9.2 Load parameter set from the controller


The operating menu (Fig. 5-17) allows the loading of a parameter set

- from the controller to the PC by "Read current parameter set from the controller (F7)"
 - C0002 offers the following options in the menu "Parameter set management":
 1. Loading of factory setting (C0002=0)
 2. Loading of customer-specific parameter set (C0002=1)



Tip!

The RDY message is not displayed while the parameter set is loaded since the controller cannot be operated then.



5.10 Control drive

5.10.1 Description of the dialog box

- Click on the "Control" button in the "Basic settings" dialog box.





Fig. 5-18 Dialog box "Control"

Field	Function	Description
1	Manual control	§ 5-11
2	Manual homing	§ 5-25
3	Menu "Diagnostics"	§ 6-1
4	"Enable", "Inhibit" controller and drive diagnostics	§ 5-10, "Controller enable" § 5-11, "Function test with manual control" § 5-25, "Manual homing" § 5-26, "Program control"
5	Status display	Important values for program control § 5-26
6	Program control	§ 5-26



Commissioning

5.10.2 Parameters for homing





Fig. 5-19 Menu "Homing" in the parameter menu

The factory setting of the parameters is sufficient for most applications. Enter the settings as follows:

Step	Command	Function
1	Select "Basic settings" dialog box.	
2	Click on "Parameter menu" button.	Open parameter menu
3	Click on "Positioning functions" menu.	Open "Positioning functions" menu.
4	Click on "Homing" menu.	Open "Homing" menu.
5	Click on C1242. Enter new value.	Homing speed. Default setting: 5 % of vmax
6	Click on C1251. Enter new value.	Homing acceleration. Default setting: 10 % of amax
7	Click on C1213. Select positioning direction. Default setting: + home Setting: - home	Homing mode • The drive moves in the positive direction towards the limit switch. • The drive positions in the negative direction towards the limit switch.
8	Click on C0003.	Save settings
9	Click on "Dialog control" menu.	Open "Control" dialog box.



5.10.3 Manual homing

The controller can perform all positioning tasks only with a defined reference point (zero point).

- Click on the "Control" button in the "Basic settings" dialog box.





Fig. 5-20 Dialog box "Control"

Field	Command	Function
1	Select "Manual operation"	Manual operation active
5		With drive diagnostics "Ok", "Enable" is possible. 6-1
4	Controller "Enable"	Enables the controller, if there is no interference.
2	Select "Manual homing". Reset "Manual homing". Override the reference switch.	The drive uses the reference parameters for positioning. 5-24 The drive stops. The drive positions until the next zero position of the rotor and brakes to standstill. This position is now defined to be the reference point for all position values.
3		Status display "Reference Ok" is displayed after successful reference homing. Terminal X5/A4 = HIGH



Commissioning

5.10.4 Program control





Fig. 5-21 Dialog box "Control"

Field	Command	Function
	Activate program operation	For factory setting • Switch terminal X5/E5 = HIGH.
1	Reset "Manual operation".	Manual operation switched off.
4		With drive diagnostics "Ok", "Enable" is possible. 6-1
2	Controller "Enable"	Enables the controller, if there is no interference.
8	Select "Program start".	The drive moves according to the loaded positioning profile.
	Reset "Program start" and select again.	The program restarts, or is continued after an interrupt ("Program stop").
5		Display of the current position and the current program state.
7	Select "Program stop".	The program is interrupted, the drive stops.
	Reset "Program stop".	The program can be continued with "Program start".
6	Select "Program reset".	The program interrupts, the drive stops. Resets the piece counter and all PFO. 5-13
6	Reset "Program reset".	Loads the first PS with which the program is to start. The program can be restarted with "Program start".



5.11 Automatic control parameter identification


With the function "Automatic control parameter identification"

- mechanical distance parameters are identified by a short movement and
- an automatic adjustment of the speed and position encoder based on the parameters is identified or selected.




Stop!

- An identification can only be carried out if the drive is not subject to external torque. In the event of hanging loads (or similar) a motion cannot be activated through the function!
- Release the brake (if mounted) before executing this function.
- Ensure the following to keep the number of revolutions:
 - Brake resistor or regenerative power supply and
 - constant moment of inertia.
- If the values differ too much from the default setting of codes C1182 - C1185, deviations in the identification of distance parameters and thus controller setting may occur.
- The motion to be carried out by the function must be set in a way that even the slowest rotating element of the controller train is still clearly moving.



Commissioning

5.11.1 Procedure



The function is activated through mode (C1180). Inhibit the controller (Ctrl. inhibit) and stop the drive. Otherwise the function will not be executed and the status (C1181) with the corresponding error code will be set. If the function is activated again, the error will be reset, and initialization and the corresponding function will restart. Enter 0 to reset the function.

Calculation of control parameters (mode = 1)

This function only calculates control parameters.

Identification/identification and calculation of control parameters (mode = 2/3)

The function "Identification" or "Identification and calculation of control parameters" activates drive motion. Reset controller inhibit (Ctrl. inhibit) to enable the motion after the function has been activated. After the motion is completed, the controller must be inhibited again to end the function.






Fig. 5-22 Dialog box "Control parameter identification"

5.11.2 Troubleshooting

If an error occurs during parameter identification, the status (C1181) helps to detect the error.

Status (C1181)	Cause	Remedy
2	Control parameter calculation not possible	Check whether distance parameters are set reasonably (C1187/C1188).
3	Too few scanning points.	Change motion conditions (C1182-C1185), i. e. increase torque, increase number of revolutions, increase speed, reduce torque rise time.
4	Reference torque too low	<ul style="list-style-type: none"> • Increase Imax (C0022) • Check maximum torque (C0057)
5	Speed at start ≠ 0	Stop drive and reactivate function
6	Controller inhibit during motion	Repeat identification
7	Minimum brake torque not reached Torque ramp too flat or maximum torque too low	Change motion conditions (C1182-C1185), i. e. increase torque, increase number of revolutions, increase speed, reduce torque rise time.
8	Time overflow	Select higher torque or shorter torque rise time
9	Blocking	Release brake, check motor cable, eliminate blocking



Commissioning

5.11.2.1 Password protection


Code	LCD	Possible settings			IMPORTANT
		Lenze	Selection		
C0094	Password	0	0 {1} 9999		Password <ul style="list-style-type: none">Parameter access protection for the operating module. When the password is activated, only the codes of the user menus can be accessed. For further selection possibilities see C0096
[C0096]		1 AIF protect. 2 CAN protect.	0 0 1 1 2 2 3 3	No password protection Read protection Write protection Read/Write protection	Extended password protection for bus systems with activated password (C0094). <ul style="list-style-type: none">All codes in the user menu can be accessed.

You can restrict the code access via the operating module using the password protection in C0094.

- Reading C0094 using the operating module:
 - C0094 = 0: password protection is not activated.
 - C0094 = 9999: password protection is activated.
- Activate password protection:
 - Enter four-digit number in C0094.
 - Confirm using SH + PRG.
- Deactivate password protection:
 - Enter four-digit number again.
 - All other inputs are refused.

Effect

- Working with the operating module:
 - The codes listed in the USER menu can still be read and changed.
 - All other codes are no longer displayed.
- Working with the fieldbus:
 - It is possible to extend the protection for codes via the fieldbus under C0096/1 (AIF) and C0096/2 (CAN).



6 During operation

6.1 Status indications

6.1.1 In Global Drive Control

1. Click on the "Control" button in the "Basic settings" dialog box.
2. Click on the "Diagnostics" button in the "Control" dialog box.





Fig. 6-1 Dialog box "Diagnostics 9300"

- 1 Type of fault
- 2 Actual speed
- 3 Actual motor voltage
- 4 Actual motor current
- 5 Motor torque
- 6 DC-bus voltage
- 7 Heatsink temperature
- 8 Motor temperature
- 9 Controller load
- 10 Reset fault
- 11 Time when the supply voltage was applied
- 12 Time when the controller was enabled
- 13 Actual fault with time and frequency of the fault. □ 8-3
- 14 Fault history with time and frequency of the fault. □ 8-4
- 15 Reset history buffer. □ 8-4



During operation

6.2

Information on operation

When operating the controller, please observe the following notes:




Stop!

- Cyclic connection and disconnection of the controller supply voltage at L1, L2, L3 or $+U_G$, $-U_G$ may overload the internal input current load:
 - Allow at least 3 minutes between disconnection and reconnection.
- During mains switching (L1,L2,L3) it is not important whether further controllers are supplied via the DC bus.

6.2.1

Switching on the motor side

- Switching on the motor side of the inverter is permissible for emergency switch-off.
- Please note:
 - Switching while a controller is enabled may cause the fault indication "0Cx" (short-circuit/earth fault in operating case x).
 - For long motor cables and operation of controllers with smaller output power, leakage currents through interfering cable capacitances may cause the fault indication "OCx".
 - Switching equipment on the motor side must be dimensioned for DC voltages ($U_{DC\ max} = 800\ V$).



6.2.2

Controller protection by current derating

Valid for the types 9326 to 9332.

For field frequencies < 5 Hz the controller automatically derates the maximum permissible output current.

- For operation with chopping frequency = 8 kHz (C0018=1, optimum power):
 - The current is derated, depending on the heat sink temperature (see Fig. 6-2).
- For operation with chopping frequency = 16 kHz (C0018=2, optimum noise):
 - The current is always derated to $I_{r16} = I_{016}$.
- For operation with automatic change-over of the chopping frequency (C0018=0):
 - Below the threshold, the controller operates with 16 kHz (optimum noise). The function of the current derating follows the characteristic "I_{max} 16 kHz" (see Fig. 6-2).
 - If a higher torque is required from the machine for example for acceleration, the controller automatically switches to 8 kHz (optimum power). The function of the current derating follows the characteristic "I_{max} 8 kHz" (see Fig. 6-2).




Fig. 6-2

Current derating function of the controllers 9326 to 9332.

ϑ_K

Heat sink temperature

I_{rx}

Rated current at U, V, W depending on the chopping frequency


f_d

Field frequency at the output U, V, W


I_{0x}

max. standstill current for field frequency = 0 Hz

See chapter "Rated data". (3-3)



During operation



7 Configuration

7.1 Configuration with Global Drive Control

With the PC program Global Drive Control (GDC) LENZE offers

- an easy to understand,
- well structured,
- convenient

tool for the configuration of your specific drive task.

Function block library

- GDC provides an easy-to-read library of available function blocks (FB).
- GDC also displays the complete assignment of a FB.

Signal configuration

The signal configuration is done with only one dialog box. It is a convenient way

- to display every FB as a block diagram.
- to see the assignment of all signal inputs at a glance.
- to enter the FB in the processing table.
- to print your signal configuration.

Terminal assignment


Freely assignable terminals can be configured using two dialog boxes:

- Dialog box - to link digital inputs and outputs.
- Dialog box - to link analog inputs and outputs.



Tip!

Further information can be obtained from the Manual of your controller.



Configuration

7.2 Monitoring

Various monitoring functions protect the drive from impermissible operating conditions. (□ 7-4).

If a monitoring function is activated,


- a reaction to protect the drive will be activated (configuration (□ 7-3)).
- a digital output is set, if it is assigned to the corresponding reaction.
- the fault indication is entered at the first position in the history buffer. (□ 8-3)

7.2.1 Reactions

According to the interferences one or several of the following reactions are possible via the monitoring function:

- TRIP (highest priority)
- Message
- FAIL-QSP
- Warning
- Off

Reaction	Effects on drive or controller		Danger notes	
TRIP	<ul style="list-style-type: none"> • Switches the power outputs U, V, W to a high resistance until TRIP is reset • The drive is idling (no control!). • After TRIP reset the drive accelerates to its setpoint along the set ramps. (□ 8-9) 			
Message	<ul style="list-style-type: none"> • Switches the power outputs U, V, W to a high resistance as long as the message is active. 		 <p>The drive restarts automatically if the message is removed.</p>	
	<ul style="list-style-type: none"> • Short-term message ≤ 0.5 s The drive is idling (no control!) as long as the message is active If the message is removed, the drive accelerates to its setpoint with maximum torque. 			
	<ul style="list-style-type: none"> • Long-term message > 0.5 s The drive is idling (because of internal controller inhibit!) as long as the message is active. If necessary, restart positioning program. 			
FAIL-QSP	<ul style="list-style-type: none"> Brakes the drive to standstill via the QSP ramp via code C0105. • The time for the QSP ramp is set in the "Basic settings" dialog box. • Default setting of FAIL-QSP: (□ 8-5) 			
Warning	<ul style="list-style-type: none"> • Only display of the operating fault • The drive operates under control. 		 <p>Since these reactions have no effect on the drive behaviour, the drive may be destroyed.</p>	
Off	<ul style="list-style-type: none"> • No reaction to operating faults! Monitoring is deactivated. 			



7.2.2 Set reactions

1. Click on the "Parameter menu" button in the "Basic settings" dialog box.
2. Open the "Dialog Diagnostics" menu by a double-click.




Fig. 7-1 Dialog box "Diagnostic 9300"

3. Click the button "Monitorings...".





Fig. 7-2 "Monitoring configuration 93xx" dialog box

4. Click on the required monitoring function.
5. Select the possible or permitted reaction and confirm it with "OK".

An overview of the monitoring functions and the settings can be obtained from the following chapter.




Configuration

7.2.3 Monitoring functions

Overview of the fault sources detected by the controller, and the corresponding reactions

Display	Meaning	TRIP	Meldung	Warning	FAIL-QSP	off	Code
CCr	System error	•	-	-	-	-	-
CE0	Communication error (AIF)	✓	-	✓	-	•	C0126
CE1	Communication error at the process data input object CAN-IN1 (time monitoring can be set under C0357/1)	✓	-	✓	-	•	C0591
CE2	Communication error at the process data input object CAN-IN2 (time monitoring can be set under C0357/2)	✓	-	✓	-	•	C0592
CE3	Communication error at the process data input object CAN-IN3 (time monitoring can be set under C0357/3)	✓	-	✓	-	•	C0593
CE4	BUS-OFF state (many communication errors occurred)	✓	-	✓	-	•	C0595
EEr	External monitoring	•	✓	✓	✓	✓	C0581
H05, H07	Internal error	•	-	-	-	-	-
H10	Sensor fault heatsink temperature	•	-	-	-	✓	C0588
H11	Sensor fault: internal temperature	•	-	-	-	✓	
LP1	Motor phase failure detection (function block must be entered in C0465)	✓	-	✓	-	•	C0597
LU	Undervoltage	-	•	-	-	-	-
NMAX	Maximum speed exceeded (C0596)	•	-	-	-	-	-
OC1	Short circuit	•	-	-	-	-	-
OC2	Earth fault	•	-	-	-	-	-
OC5	I x t overload	•	-	-	-	-	-
OH	Heatsink temperature 1 (max. permissible, fixed)	•	-	-	-	-	-
OH3	Motor temperature 1 (max. permissible, fixed)	•	-	-	-	✓	C0583
OH4	Heatsink temperature 2 (adjustable; C0122)	-	-	•	-	✓	C0582
OH7	Motor temperature 2 (can be set; code: C0121)	-	-	•	-	✓	C0584
OH8	Motor temperature (fixed) via inputs T1/T2	✓	-	✓*	-	•	C0585
OU	Oversupply in the DC bus	-	•	-	-	-	-
P01	Limit switch negative = LOW	✓	-	-	•	-	C1285/1
P02	Limit switch positive = LOW	✓	-	-	•	-	C1285/2
P03	Contouring error - digital frequency > C0255	✓	-	•	-	✓	C0589
P04	Position limit exceeded in negative direction	✓	-	-	•	-	C1285/3
P05	Position limit exceeded in positive direction	✓	-	-	•	-	C1285/4
P06	No reference	✓	-	-	•	-	C1287/1
P07	Parameter set mode absolute	✓	-	-	•	-	C1291/1
P08	Actual offset out of range	✓	-	-	•	-	C1291/2
P09	Impermissible programming	✓	-	-	•	-	C1291/3
P12	Encoder range exceeded	✓	-	-	•	-	C1288/1
P13	Phase overflow	•	-	✓	-	✓	C0590
P14	1st contouring error POS > C1218/1	✓	-	✓	•	✓	C1286/1
P15	2nd contouring error POS > C1218/2	✓	-	✓	✓	•	C1286/2
P16	Sync error	✓	-	✓	•	✓	C1290/1
P17	TP control error	✓	-	✓	•	✓	C1289/1
P18	Internal limitation	✓	-	•	✓	✓	C1289/2
PEr	Program error	•	-	-	-	-	-
PI	Fault during initialization	•	-	-	-	-	-
PR0	General fault in parameter sets	•	-	-	-	-	-
PR1	Fault in parameter set 1	•	-	-	-	-	-
Sd2	Resolver fault	•	-	✓*	-	✓	C0586
Sd3	Encoder fault at X9 PIN 8	✓	-	✓*	-	•	C0587


Configuration




Display	Meaning	TRIP	Meldung	Warning	FAIL-QSP	off	Code
Sd5	Encoder fault at X6/1 X6/2 (C0034 = 1)	✓	-	✓	-	•	C0598
Sd6	Sensor fault: motor temperature (X7 or X8)	•	-	✓	-	✓	C0594
Sd7	Fault in the absolute value encoder at X8	✓	-	-	-	•	C0025

Configuration

- Default setting
- ✓ possible
- not possible
- ✓* possible, but the drive can be destroyed if the fault is not removed immediately.



Configuration



8

Troubleshooting and fault elimination

- You can recognize immediately whether a fault has occurred from the display elements or status information. (§ 8-1, chapter "Troubleshooting")
- You can analyze the fault
 - by means of the history buffer (§ 8-3)
 - and by means of the list "Fault indications". (§ 8-5)
- The list "Fault indications" indicates how to eliminate faults. (§ 8-5)

8.1

Troubleshooting

Display on the controller

Two LEDs on the front of the controller indicate the controller status.

LED green	LED red	Cause	Check
■	□	Controller enabled; no fault	
★	□	Controller inhibit, switch-on inhibit	C0183; or C0168/1
□	★	Fail	C0168/1
■	★	Warning, fail-QSP	C0168/1

■ : on


□ : off

★ : blinking

Display in Global-Drive-Control

Double-click "Dialog Diagnostic" in the parameter menu of the GDC to open the dialog box *Diagnostic 9300*.

- The dialog box *Diagnostic 9300* informs about the controller status:



Display on the keypad

Status messages in the display indicate the controller status.


Display	Controller status	Check
RDY	Controller ready for operation, controller can be inhibited	C0183, C0168/1
IMP	Pulses at the power stage inhibited	C0183, C0168/1
I _{max}	Max. current reached	
M _{max}	Max. torque reached	
Fail	Fault through TRIP, message, fail QSP or warning	C0183, C0168/1



Troubleshooting and fault elimination

Display via the LECOM status word C0150

Bit	Meaning			
0	FREE 0	freely combinable		
1	IMP (pulse inhibit)	0 = Pulses enabled for power stage 1 = Pulses inhibited for power stage		
2	FREE 2	freely combinable		
3	FREE 3	freely combinable		
4	FREE 4	freely combinable		
5	FREE 5	freely combinable		
6	$f_d = 0$ (actual speed value = 0)	0 = $[n \neq 0]$ 1 = $[n = 0]$		
7	RSP (controller inhibit)	0 = No controller inhibit 1 = Controller inhibit		
8-11	Controller status	hex	bin	
		0	0000	Unit initialisation
		1	0001	Switch-on inhibit
		3	0011	Operation inhibited (controller inhibit)
		6	0110	Operation enabled
		7	0111	Message active
		8	1000	Active fault
		9	1001	Power off
		A	1010	Fail-QSP
12	Warning	0 = No warning 1 = Warning		
13	Meldung	0 = No message 1 = Message		
14	FREE 14	freely combinable		
15	FREE 15	freely combinable		




8.2

Fault analysis with the history buffer

- The history buffer is used to trace faults.
- Fault messages are stored in the order of their occurrence.


Double click "Dialog Diagnostic" in the parameter menu of the GDC to open the dialog box *Diagnostic 9300*:



8.2.1

Structure of the history buffer

- The history buffer has 8 memory units. The fields under "fault history" show the memory units 2 to 7.
- The fields under "Actual fault" show memory unit 1. It contains information on the active fault.
 - The first memory unit is written only after the elimination or acknowledgement of the active fault. This entry eliminates the last fault from the history buffer so that it can no longer be read.
- The history buffer contains three information items for every fault occurred:



- ① Fault recognition and reaction
- ② Time of the fault
- ③ Frequency of the fault

The following table shows the assignment of information to the codes.


Code and information to be called	C0168	C0169	C0170	Subcode	Memory unit
Fault recognition and reaction		Time of the last occurrence	Frequency of the immediately following occurrence	1 2 3 4 5 6 7 8	Active fault Memory unit 1 Memory unit 2 Memory unit 3 Memory unit 4 Memory unit 5 Memory unit 6 Memory unit 7



Troubleshooting and fault elimination

8.2.2

Working with the history buffer



Fault recognition and reaction ①

- Contains the fault recognition for every memory unit and the reaction to the fault.
 - e. g. "OH3 TRIP"
 - For a fieldbus, the fault indications are always represented by a fault number.
([8-5, column 2](#))

Please note:

- For faults occurring at the same time with different reactions:
 - Only the reaction with the highest priority is entered in the history buffer
(Priority = TRIP → Message → FAIL-QSP → Warning).
- For faults occurring at the same time with the same reaction (e. g. 2 messages):
 - Only the fault which occurred first is entered in the history buffer.

Time ②

- Contains the times when the faults occurred.
 - e.g. "1234567 s"
 - Reference time is the mains switch-on time (see dialog box *Diagnostic 9300*, field top right)

Please note:

- If a fault is immediately followed by another fault for several times, only the time of the last occurrence is stored.

Frequency ③

- Contains the frequency of a fault immediately followed by the same fault. The time of the last occurrence is stored.

Reset fault ④

- Click the **TRIP reset** button to reset the fault.

Clear history buffer ⑤

- This function is only possible when no fault is active.
- Click the **Fault history reset** button to clear the history buffer.



8.3 Fault indications



Note!

If the fault indication is requested by a fieldbus (C0168/x), the fault indication is represented by a fault number in column 2 of the table.

Display	Fault No.: <input type="checkbox"/> xxx 0 - TRIP 1 - Message 2 - Warning 3 - FAIL-QSP	Error	Cause	Remedy
---	---	No fault	-	-
CCr	<input type="checkbox"/> 071	System error	Strong interference on control cables For 9300 cam profiler: Selection of too many points Ground or earth loops in the wiring	Screen control cables For 9300 cam profiler: Reduce number of points to max. 2 points per ms) PE wiring. 4-34
CDA	<input type="checkbox"/> 220	Data error	Attempt to accept faulty data	New data transfer.
	<input type="checkbox"/> 221	Data error warning	The checksum of the data transferred is not correct.	New data transfer and check.
CEO	<input type="checkbox"/> 061	Communication error	Interference during transmission of control commands via automation interface X1	Plug in automation module firmly, bolt down, if necessary
CE1	<input type="checkbox"/> 062	Communication error at the process data input object CAN_IN_1	CAN_IN_1 object receives faulty data, or communication is interrupted	<ul style="list-style-type: none"> • Check cable at X4 • Check transmitter • Increase monitoring time under C0357/1 if necessary
CE2	<input type="checkbox"/> 063	Communication error at the process data input object CAN_IN_2	CAN_IN_2 object receives faulty data, or communication is interrupted	<ul style="list-style-type: none"> • Check cable at X4 • Check transmitter • Increase monitoring time under C0357/2 if necessary
CE3	<input type="checkbox"/> 064	Communication error at the process data input object CAN_IN_3	CAN_IN_3 object receives faulty data, or communication is interrupted	<ul style="list-style-type: none"> • Check cable at X4 • Check transmitter • Increase monitoring time under C0357/3 if necessary
CE4	<input type="checkbox"/> 065	BUS-OFF state	Controller has received too many incorrect telegrams via system bus X4, and has disconnected from the bus	<ul style="list-style-type: none"> • Check wiring • Check bus termination (if any) • Check screen contact of the cables • Check PE connection • Check bus load: • Reduce baud rate (observe cable length)
EEr	<input type="checkbox"/> 091	External fault (TRIP-Set)	A digital input assigned to the TRIP-Set function has been activated.	Check external encoder
H05	<input type="checkbox"/> 105	Internal error		Contact Lenze
H07	<input type="checkbox"/> 107	Incorrect power stage	During initialization of the controller, an incorrect power stage was detected	Contact Lenze
H10	<input type="checkbox"/> 110	Sensor fault heat sink temperature	Sensor for heat sink temperature detection indicates indefinite values	Contact Lenze
H11	<input type="checkbox"/> 111	Senso fault indoor temperature	Sensor for indoor temperature detection indicates indefinite values	Contact Lenze
LP1	<input type="checkbox"/> 032	Motor phase failure	A current-carrying motor phase has failed	<ul style="list-style-type: none"> • Check motor • Check supply module
			The current limit is set too high	Set a lower current limit value under C0599
			This monitoring is not suitable for: <ul style="list-style-type: none"> • Synchronous servo motors • at field frequencies > 480 Hz 	Deactivate monitoring with C0597= 3
LU	<input type="checkbox"/> 030	Undervoltage	DC bus voltage is smaller than the value fixed under C0173	<ul style="list-style-type: none"> • Check mains voltage • Check supply cable
rMAX	<input type="checkbox"/> 200	Max. speed exceeded (C0596)	Active load (e.g. for hoists) too high Drive is not speed-controlled, torque excessively limited.	Check drive dimensioning. Increase torque limit if necessary.



Troubleshooting and fault elimination

Display	Fault No.: <input type="checkbox"/> xxx 0 - TRIP 1 - Message 2 - Warning 3 - FAIL-QSP	Error	Cause	Remedy
OC1	<input type="checkbox"/> 011	Short-circuit	Short-circuit. Excessive capacitive charging current of the motor cable.	Find out cause of short-circuit; check cable. Use motor cable which is shorter or of lower capacitance.
OC2	<input type="checkbox"/> 012	Earth fault	One of the motor phases has earth contact. Excessive capacitive charging current of the motor cable.	<ul style="list-style-type: none">Check motorCheck supply module Use motor cable which is shorter or of lower capacitance.
OC5	<input type="checkbox"/> 015	Ixt overload	Frequent and overlong acceleration with overcurrent Continuous overload with $I_{motor} > 1.05 \times I_{rx}$	Check drive dimensioning.
OH	<input type="checkbox"/> 050	Heat sink temperature is higher than the value set in the controller	Ambient temperature $T_{amb} > 40^{\circ}\text{C}$ or 50°C .	<ul style="list-style-type: none">Allow controller to cool and ensure better ventilation.Check ambient temperature in the control cabinet.
			Heat sink very dirty.	Clean heat sink
			Incorrect mounting position.	Change mounting position.
OH3 1)	<input type="checkbox"/> 053	Heat sink temperature is higher than the value set in the controller	Motor too hot because of excessive current or frequent and overlong acceleration	Check drive dimensioning.
			No PTC connected.	Connect PTC or switch-off monitoring (C0583=3).
OH4	<input type="checkbox"/> 054	Heat sink temperature is higher than the value set under C0122.	Ambient temperature $T_{amb} > 40^{\circ}\text{C}$ or 50°C .	<ul style="list-style-type: none">Allow controller to cool and ensure better ventilation.Check ambient temperature in the control cabinet.
			Heat sink very dirty.	Clean heat sink
			Incorrect mounting position.	Change mounting position.
			Value set under C0122 was too low.	Enter higher value.
OH7 1)	<input type="checkbox"/> 057	Motor temperature is higher than the value set under C0121.	Motor too hot because of excessive current or frequent and overlong acceleration	Check drive dimensioning.
			No PTC connected.	Connect PTC or switch-off monitoring (C0584=3).
			Value set under C0121 was too low.	Enter higher value.
OH8	<input type="checkbox"/> 058	PTC at terminals T1, T2 indicates motor overheat.	Motor too hot because of excessive current or frequent and overlong acceleration	Check drive dimensioning.
			Terminals T1, T2 are not assigned.	Connect PTC or thermostat or switch off monitoring (C0585=3).
OU	<input type="checkbox"/> 020	Overvoltage	Excessive brake energy (DC bus voltage higher than set under C0173).	Use brake module or energy recovery module.
			Negative limit switch was reached.	<ul style="list-style-type: none">Control drive in positive directionCheck terminal connection X5/E2.
P01	<input type="checkbox"/> 151	Limit switch negative	Positive limit switch was reached.	<ul style="list-style-type: none">Control drive in negative directionCheck terminal connection X5/E1.
			Phase difference between set and actual position is larger than the contouring error limit set under C0255.	<ul style="list-style-type: none">Extend contouring error limit under C0255Switch off the monitoring if necessary (C0589 = 3).
P03	<input type="checkbox"/> 153	Second contouring error	Drive cannot follow the digital frequency (f_{max} limit).	Check drive dimensioning.
			Negative position limit (C1224) was not reached.	Find out why the value was not reached (e.g. "incorrect" position targets, set function position value) and adjust the negative position limit (C1224) if necessary.
P04	<input type="checkbox"/> 154	Negative position limit	Positive position limit (C1223) was exceeded.	Find out why the value was exceeded (e.g. "incorrect" position targets, set function position value) and adjust the positive position limit (C1223) if necessary.
P05	<input type="checkbox"/> 155	Positive position limit	The homing point is unknown. For absolute positioning no homing was performed before the first positioning.	Perform one of the following functions and restart: <ul style="list-style-type: none">Manual homing.Start homing in the program.Set reference.
P06	<input type="checkbox"/> 156	No reference		

Troubleshooting and fault elimination




Display	Fault No.: <input type="checkbox"/> xxx 0 - TRIP 1 - Message 2 - Warning 3 - FAIL-QSP	Error	Cause	Remedy						
P07	<input type="checkbox"/> 157	PS Absolute mode instead of relative mode.	An absolute PS (C1311) was performed during relative positioning (position mode C1210).	Perform one of the following functions and restart: <ul style="list-style-type: none">• Change from absolute PS to relative PS.• Change position mode.						
P08	<input type="checkbox"/> 158	Actual offset out of range.	Actual home offset (C1226) out of position limits. Fault of the program function "Set position value".	Adjust position limits if necessary, or check whether program function "Set position value" is to be applied.						
P09	<input type="checkbox"/> 159	Impermissible programming	Impermissible programming	Check position program: <ul style="list-style-type: none">• After a PS with final speed a PS with positioning has to follow; waiting for input is not permissible.						
P12	<input type="checkbox"/> 162	Encoder range	The range of the absolute encoder was exceeded.	<ul style="list-style-type: none">• Return drive by manual positioning.• Check position limits and adjustment of the encoder.• The absolute encoder has to be dimensioned and mounted such that its range is not exceeded over the complete positioning range.						
P13	<input type="checkbox"/> 163	Phase overflow	<ul style="list-style-type: none">• Phase controller limit reached• Drive cannot follow the digital frequency (I_{max} limit).	<ul style="list-style-type: none">• Enable drive• Check drive dimensioning						
P14	<input type="checkbox"/> 164	1st contouring error	The drive cannot follow the setpoint. Contouring error is higher than limit value in C1218/1.	<ul style="list-style-type: none">• Increase current limit C0022 (observe max. motor current).• Reduce acceleration.• Check drive dimensioning.• Increase limit value under C1218.						
P15	<input type="checkbox"/> 165	2nd contouring error	The drive cannot follow the setpoint. Contouring error is higher than limit value in C1218/2.	<ul style="list-style-type: none">• Increase current limit C0022 (observe max. motor current).• Reduce acceleration.• Check drive dimensioning.• Increase limit value under C1218.						
P16	<input type="checkbox"/> 166	Transmission error of a synch telegram on the system bus.	Sync telegram from master (PLC) is out of time pattern. * Sync telegram of master (PLC) is not received. * Controller enable (RER) too soon.	<table border="1"><tr> <td>Sync telegram from master (PLC) is out of time pattern. *</td><td>Set C1121 (Sync cycle) to the transmission cycle of the master (PLC).</td></tr> <tr> <td>Sync telegram of master (PLC) is not received. *</td><td><ul style="list-style-type: none">• Check communication channel.• Check baud rate, controller address.</td></tr> <tr> <td>Controller enable (RER) too soon.</td><td>Enable controller with delay. The required delay depends on the time between the synch telegrams.</td></tr> </table>	Sync telegram from master (PLC) is out of time pattern. *	Set C1121 (Sync cycle) to the transmission cycle of the master (PLC).	Sync telegram of master (PLC) is not received. *	<ul style="list-style-type: none">• Check communication channel.• Check baud rate, controller address.	Controller enable (RER) too soon.	Enable controller with delay. The required delay depends on the time between the synch telegrams.
Sync telegram from master (PLC) is out of time pattern. *	Set C1121 (Sync cycle) to the transmission cycle of the master (PLC).									
Sync telegram of master (PLC) is not received. *	<ul style="list-style-type: none">• Check communication channel.• Check baud rate, controller address.									
Controller enable (RER) too soon.	Enable controller with delay. The required delay depends on the time between the synch telegrams.									
P17	<input type="checkbox"/> 167	TP control error	Simultaneous use of the TP input by different function blocks (e.g. FB DFSET and POS). A conflict occurs.	Configure another TP input for FB POS (not possible for DFSET) or switch off monitoring under C0580.						



Troubleshooting and fault elimination

Display	Fault No.: <input type="checkbox"/> xxx 0 - TRIP 1 - Message 2 - Warning 3 - FAIL-QSP	Error	Cause	Remedy
P18	<input type="checkbox"/> 168	Internal limitation	<p>Data generated by calculations of the 9300 servo positioning controller cannot be varied arbitrarily. If the value falls below or exceeds the internal limit value the warning "P18" will be set and the value is limited to the minimum or maximum.</p> <p>C1298 = 1: The negative position limit in C1223 is outside the possible display range of $1 \leq (C1223 * C1205) \leq 1.07E9$ incr</p> <p>C1298 = 2: The positive position limit in C1224 is outside the possible display range of $1 \leq (C1224 * C1205) \leq 1.07E9$ incr</p> <p>C1298 = 3: The maximum speed v_{max} under C1240 exceeds the possible display range of $1 \leq (C1240 * C1205 * 16,384) \leq 2.14E9$ incr or $v_{max} \text{ hot C1240 / C1204 * 60} \leq 1.5 * n_{max}$</p> <p>C1298 = 4: The maximum acceleration a_{max} in C1250 exceeds the possible display range of $1 \leq (C1250 * C1205 * 16,384 / 1000) \leq 2.8634E7$ incr</p> <p>C1298 = 5: An internal value range has been exceeded for a speed normalization. Valid range: $1 \leq (C0011 * C1207/1 / C1207/2 * 65536 / 60000) \leq 32767$</p>	<p>Check the entries under C1202-4, C1207/1.2. If necessary, read the value decreased in the event of a fault under C1220/10 and overwrite the value entered under C1223.</p> <p>Check the entries under C1202-4, C1207/1.2. If necessary, read the value decreased in the event of a fault under C1220/11 and overwrite the value entered under C1224.</p> <p>Check the entries under C0011, C1202-4, C1207/1.2. If necessary, read the value decreased in the event of a fault under C1220/12 and overwrite the value entered under C1240. Adapt the value under C1240 to C0011.</p> <p>Check the entries under C1202-4, C1207/1.2. If necessary, read the value decreased in the event of a fault under C1220/13 and overwrite the value entered under C1250.</p>
P21	<input type="checkbox"/> 171	Contouring error RC	<p>Phase difference between set and actual position is larger than the contouring error limit set under C1328.</p> <p>Drive cannot follow the digital frequency (f_{max} limit).</p>	<p>Extend contouring error limit with C1328. If necessary, switch off the monitoring (C1329=3).</p> <p>Check drive dimensioning.</p>
PEr	<input type="checkbox"/> 074	Program fault	A fault in the program was detected.	Send controller with data (on diskette) to Lenze.
PI	<input type="checkbox"/> 079	Initializing error	<ul style="list-style-type: none"> A fault was detected during transfer of parameter set between the controllers Parameter set does not match controller. 	Correct parameter set.
PR0 PR1	<input type="checkbox"/> 075 <input type="checkbox"/> 072	Parameter set error	<p>Fault when loading a parameter set. CAUTION: The factory setting loaded automatically.</p>	<ul style="list-style-type: none"> Set the required parameters and store them under C0003. For PRO the supply voltage must be switched off additionally.
Sd2	<input type="checkbox"/> 082	Resolver fault	Resolver cable interrupted.	<ul style="list-style-type: none"> Check the resolver cable for open circuit. Check resolver. or switch off monitoring (C0586 = 3).
Sd3	<input type="checkbox"/> 083	Encoder fault at X9/8	<p>Cable interrupted.</p> <p>Input X9 PIN 8 not assigned.</p>	<p>Check cable for open circuit.</p> <p>Assign input X9 PIN 8 with 5V or switch off monitoring (C0587 = 3).</p>
Sd5	<input type="checkbox"/> 085	Master current source defective	Master current at X6/1 X6/2 < 2mA.	<ul style="list-style-type: none"> Check cable for open circuit. Check master current source.
Sd6	<input type="checkbox"/> 086	Sensor fault	Encoder of the motor temperature detection at X7 or X8 indicates indefinite values.	Check supply cable for firm connection. Switch off monitoring with C0594 = 3 if necessary.
Sd7	<input type="checkbox"/> 087	Encoder fault	Absolute encoder with RS485 interface does not transmit data.	<p>Check supply cable. Check encoder. Check voltage supply C0421. No Stegmann encoder connected.</p>

1) Temperature detection via resolver or incremental encoder.




8.4 Reset of fault messages

Reaction on operating errors	Measures for re-commissioning	Danger notes
TRIP/ FAIL-QSP	<ul style="list-style-type: none"> After the error has been eliminated, the drive can be restarted when an acknowledgement has been sent. TRIP / FAIL-QSP acknowledgement by: <ul style="list-style-type: none"> – Global-Drive-Control: Click "Trip reset" in dialog box "Diagnostics 9300". ☞ 8-4, ("Working with the history buffer") – Keypad 9371 BB: Press STOP key. Then press RUN to enable the controller again. – Fieldbus module: Set C0043 = 0 – Control word C0135 – Terminal X5/E5 (default setting) or "DCTRL-TRIP-RESET" – Control word AIF – Control word system bus (CAN) 	 <p>If a TRIP source is still active, TRIP cannot be reset.</p>
Message	<ul style="list-style-type: none"> After eliminating the fault, the message is reset automatically. 	 <p>The drive restarts automatically if the fault is eliminated.</p>
Warning	<ul style="list-style-type: none"> After eliminating the fault, the warning is reset automatically. 	



Troubleshooting and fault elimination



9 Maintenance

- The controller is free of maintenance if the prescribed conditions of operation are observed. (§ 3-2)
- If the ambient air is polluted, the air vents of the controller may be obstructed. Therefore, check the air vents periodically (depending on the degree of pollution approx. every four weeks):

Free the obstructed air vents using a vacuum cleaner.




Stop!

Do not use sharp or pointed tools such as knives or screwdrivers to clean the air vents.



Maintenance



10 Appendix

10.1 Accessories

For the controllers, Lenze offers the following accessories:

- Mains filter
- Fuses
- Fuse holders
- System cable for resolver
- System cable for digital frequency coupling

A PC can be connected to the controller via the field bus module LECOM A/B (RS232, RS485 or fibre optics). The Global-Drive-Control (GDC) PC program allows a simple programming of the controller.

Global Drive Control (GDC) PC program

The program runs under Windows and is supplied with drivers for LECOM A/B (RS232, RS485 or optical fibre).

Further functions of the PC program:


- Process signal visualization
- Diagnostics and troubleshooting
- Commissioning support
- Oscilloscope function

10.2 Code table

How to read the code table:

Row	Abbreviation	Meaning
Code	C0039	Code C0039
	1	Subcode 1 of code C0039
	2	Subcode 2 of code C0039


	14	Subcode 14 of code C0039
	15	Subcode 15 of code C0039
	[C0005]	Parameter value of the code can only be modified when the controller is inhibited
LCD		Keypad LCD • Display of the short text, e.g. <i>PAR LOAD</i>
Lenze		Factory setting of the code
	*	The row "Important" contains further information
	[Disp]	Codes only display values. They cannot be configured.
Choice	1 {1 %} 99	Minimum value {smallest step/unit} maximum value
Important	-	Additional, important explanation of the code
		Printed in bold: Code name in GDC
	10-1	Reference to a page indicating further information on a code.




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0002	PAR LOAD	0		Load parameter set
			0 Load default	Load factory setting into RAM
			1 Load PS1	Load parameter set x into the RAM and activate <ul style="list-style-type: none">• Parameter set is loaded automatically after every mains connection.
			11 Load ext PS1	Load parameter set x from the keypad into the RAM and activate
C0003	PAR SAVE	0		Save parameter set
			0 Ready	Saving completed
			1 Save PS1	Save current parameter set x non-volatile
			11 Save extern	Transmit all parameter sets to the keypad
C0004	OP-DISPLAY	56	All available codes	Operating display Keypad shows selected code in the operating level if no other status indications of C0183 are active.
[C0005]	SIGNAL CFG	20000	0 Common 100 CFG:empty 1000 Speed mode 20000 Standard pos 20003 abs AIF 20010 abs/supply 20013 abs/supply AIF 20200 relativ 20203 rel AIF 20210 rel/supply 20213 rel/supply AIF 22000 abs/sp 22003 abs/sp AIF 22010 abs/sp/sply 22013 abs/sp/sply AIF 22200 rel/sp 22203 rel/sp AIF 22210 rel/sp/sply 22213 rel/sp/sply AIF 26000 set pos.sel 26010 set pos.sel	Signal configuration (Predefined basic configurations)
[C0006]	OP MODE	*		Operating mode of motor control → depending on C0086 <ul style="list-style-type: none">• Change of C0086 resets value to the assigned default setting• Change of C0006 sets C0086 = 0!
			2 Servo async Y	Servo control asynchronous motors in star connection
			3 Servo PM-SM Y	Servo control synchronous motors in star connection
			22 Servo async	Servo control asynchronous motors in delta connection
C0009	LECOM ADDRESS	1	1 {1}	99 LECOM controller address Bus device number when operated via interface <ul style="list-style-type: none">• 10, 20, ..., 90 reserved for broadcast to device groups for RS232, RS485, fibre optics.

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0011	NMAX	3000	500 {1 rpm}	16000	Maximum speed Nmax Reference value for the absolute and relative setpoint selection for the acceleration and deceleration times. • Parameter setting via interface: Large changes in one step should only be made when the controller is inhibited.
C0012	TIR (ACC)	0.000	0.000 {0.001 s}	999.900	NSET acceleration time T_{ir} for the main setpoint of NSET • Refers to speed change 0...n _{max} .
C0013	TIF (DEC)	0.000	0.000 {0.001 s}	999.900	NSET deceleration time T_{if} for the main setpoint of NSET • Refers to speed change 0...n _{max} .
C0017	FCODE (QMIN)	50	-16000 {1 rpm}	16000	FCODE Qmin Switching threshold n _{act.} < n _x • n _{act.} < C0017 activates the comparator output CMP1-OUT
C0018	FCHOP	1	0 16/8 kHz sin 1 8 kHz sin 2 16 kHz sin		Chopper frequency fchop Optimum noise reduction with automatic change-over to 8 kHz Operation with optimum power Noise optimised operation
C0019	NRCT=0 CURRENT	0	0 {1 rpm}	16000	Threshold nact = 0 Detection of threshold at n _{act.} = 0.
C0021	SLIPCOMP	0.00	0.00 {0.01 %}	20.00	Slip compensation • active only in sensorless control below the value of C0291
C0022	IMAXTHRESH	*3.75	0 {0.01 A}	1.50 I _r	I_{max} limit current → depending on C0086 • Change of C0086 resets value to the assigned factory setting (1.5 *Imotor)
[C0025]	FEEDBACK TYPE	10			Feedback • Input of the encoder specified on the nameplate of the Lenze motor: • C0025 automatically changes C0420, C0490, C0495
			0 COMMON		C0420, C0490 or C0495 was changed subsequently
			10 RSx (Resolver)		The resolver is designated with RSxxxxxx.
			110 IT-512-5V		Incremental encoder with TTL level
			111 IT-1024-5V		
			112 IT-2048-5V		
			113 IT-4096-5V		
C0026	1 FCODE (OFFSET)	0.00	-199.99 {0.01 %}	199.99	Freely assignable code for relative analog signals • Used for: – Offset for terminal X6/1,2 – Offset for terminal X6/3,4




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0027 1 2	FCODE (GAIN) FCODE (GAIN)	100.00 100.00	-199.99 {0.01 %} 199.99		FCODE (AIN) , Freely assignable code for relative analog signals <ul style="list-style-type: none">Used for:<ul style="list-style-type: none">Gain X6/1,2Gain X6/3,4
C0030	DFOUT CONST	3	0 256 inc/rev 1 512 inc/rev 2 1024 inc/rev 3 2048 inc/rev 4 4096 inc/rev 5 8192 inc/rev 6 16384 inc/rev		DFOUT constant , constant for the digital frequency output in increments per revolution
C0032	FCODE GEARBOX	1	-32767 {1}	32767	FCODE (gearbox factor numerator) , freely assignable code <ul style="list-style-type: none">Used for:<ul style="list-style-type: none">Gearbox factor numerator
C0033	GERRBOX DENOM	1	1 {1}	32767	DFSET Gearbox factor denominator
C0034	MST CURRENT	0 1 2	0 -10 V ... + 10 V 1 +4 mA ... +20 mA 2 -20 mA ... +20 mA		Selection: Master voltage/master current for setpoint selection
C0037	SET-VALUE RPM	0	-16000 {1 rpm}	16000	Setpoint input in rpm
C0039 1 2 3 4 5 ... 14 15	JOG SET-VALUE JOG SET-VALUE JOG SET-VALUE JOG SET-VALUE JOG SET-VALUE ... JOG SET-VALUE JOG SET-VALUE	100.0 75.00 50.00 25.00 0.00 ... 0.00 0.00	-199.99 {0.01} 199.99		Fixed speeds selectable via digital inputs NSET JOG setpoints
C0040	CTRL ENRABLE	1	0 Ctrl inhibit 1 Ctrl enable		Controller inhibit <ul style="list-style-type: none">Write:<ul style="list-style-type: none">controls the codeRead:<ul style="list-style-type: none">reads the controller status
C0042	QSP	[Disp]	0 QSP inactive 1 QSP active		Status Quick stop
C0043	TRIP RESET		0 no/trip reset 1 trip active		TRIP reset , resets an active TRIP: <ul style="list-style-type: none">Set C0043 = 0
C0045	Act JOG	[Disp]	0 Nset active 1 JOG 1 2 JOG 2 ... 15 JOG 15		NSET JOG selection
C0046	N	[Disp]	-199.99 {0.01 %} 199.99		Main setpoint
C0049	NADD	[Disp]	-199.99 {0.01 %} 199.99		Additional setpoint
C0050	MCTRL-NSET2	[Disp]	-100.00 {0.01 %} 100.00		n _{Set} at the speed controller input
C0051	MCTRL-NACT	[Disp]	-30000 {1 rpm} 30000		Actual speed
C0052	MCTRL-UMODE	[Disp]	0 {1 V} 800		Actual motor voltage
C0053	UG-VOLTAGE	[Disp]	0 {1 V} 900		DC-bus voltage

Appendix




Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
C0054	<i>IM0E</i>	[Disp]	0.0	{0.1 A}	500.0	Actual motor current
C0056	<i>M0E RL-MSEZ2</i>	[Disp]	-100.00	{0.01 %}	100.00	Torque setpoint (output of the speed controller)
C0057	<i>MAX TORQUE</i>	[Disp]	0.0	{0.1 Nm}	500.0	Maximum possible torque of the drive configuration • depending on C0022, C0086
C0058	<i>ROTOR DIFF</i>		-180.0	{0.1 °}	179.9	Rotor angle , zero angle of the rotor of synchronous motors (C0095)
C0059	<i>MOE POLE NO.</i>	[Disp]	1	{1}	50	Pole pair number of the motor
C0060	<i>ROTOR POS</i>	[Disp]	0	{1}	2047	Current rotor position • 1 turn = 2048 inc
C0061	<i>HEATSINK TEMP</i>	[Disp]	0	{1 °C}	100	Heatsink temperature
C0063	<i>MOE TEMP</i>	[Disp]	0	{1 °C}	200	Motor temperature
C0064	<i>UTILIZATION</i>	[Disp]	0	{1 %}	150	Controller load I x t during the last 180 s • C0064 > 100 % releases Trip OC5 • Trip reset is possible only if C0064 < 95 %
C0067	<i>Rect. TRIP</i>	[Disp]	All fault indications	→ Selection list 10		Momentary fault indication
C0070	<i>Vp SPEED-CTRL</i>	*	0.0	{0.5}	255.0	V_{pn} speed controller → depending on C0086 • Change of C0086 resets value to the assigned default setting
C0071	<i>Tn SPEED-CTRL</i>	*	1.0 >512 ms	{0.5 ms} switched off	600.0	T_{nn} speed controller → depending on C0086 • Change of C0086 resets value to the assigned default setting
C0072	<i>Td SPEED-CTRL</i>	0.0	0.0	{0.1 ms}	32.0	T_{dn} speed controller
C0075	<i>Vp cURR-CTRL</i>	*	0.00	{0.01}	15.99	V_{pi} Current controller → depending on C0086 • Change of C0086 resets value to the assigned default setting
C0076	<i>Tn cURR-CTRL</i>	*	0.5 2000 ms	{0.1 ms} switched off	1999.0	T_{ni} Current controller → depending on C0086 • Change of C0086 resets value to the assigned default setting
C0077	<i>Vp FIELD-CTRL</i>	0.25	0.00	{0.01}	15.99	V_{pF} field controller
C0078	<i>Tn FIELD-CTRL</i>	15.0	1.0 8000 ms	{0.5 ms} switched off	7999.0	T_{nF} field controller
[C0081]	<i>MOE POWER</i>	*	0.01	{0.01 kW}	500.00	Rated motor power , rated motor power according to nameplate → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0081 sets C0086 = 0
[C0084]	<i>MOE RS</i>	*	0.00	{0.01 Ω}	100.00	Motor stator resistance required for C0006 = 1 → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0084 sets C0086 = 0
[C0085]	<i>MOE LS</i>	*	0.00	{0.01}	200.00	Leakage inductance motor required for C0006 = 1 → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0085 sets C0086 = 0




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
[C0086]	MOT TYPE	*		Selection motor type → depends on the controller • Change of C0086 resets C0006, C0022, C0070, C0071, C0081, C0084, C0085, C0087, C0088, C0089, C0090, C0091 to the assigned default setting
0 COMMON				no Lenze motor
New generation Lenze asynchronous servo motors				<ul style="list-style-type: none">with integrated temperature monitoring via resolver or encoder cable.The temperature monitoring via resolver or encoder cable is activated automatically, i.e.: C0583 = 0 C0584 = 2 C0594 = 0
10 DSKA56-140				MDSKAXX056-22, f _r : 140Hz
11 DFKA71-120				MDFKAXX071-22, f _r : 120Hz
12 DSKA71-140				MDSKAXX071-22, f _r : 140Hz
13 DFKA80-60				MDFKAXX080-22, f _r : 60Hz
14 DSKA80-70				MDSKAXX080-22, f _r : 70Hz
15 DFKA80-120				MDFKAXX080-22, f _r : 120Hz
16 DSKA80-140				MDSKAXX080-22, f _r : 140Hz
17 DFKA90-60				MDFKAXX090-22, f _r : 60Hz
18 DSKA90-80				MDSKAXX090-22, f _r : 80Hz
19 DFKA90-120				MDFKAXX090-22, f _r : 120Hz
20 DSKA90-140				MDSKAXX090-22, f _r : 140Hz
21 DFKA100-60				MDFKAXX100-22, f _r : 60Hz
22 DSKA100-80				MDSKAXX100-22, f _r : 80Hz
23 DFKA100-120				MDFKAXX100-22, f _r : 120Hz
24 DSKA100-140				MDSKAXX100-22, f _r : 140Hz
25 DFKA112-60				MDFKAXX112-22, f _r : 60Hz
26 DSKA112-85				MDSKAXX112-22, f _r : 85Hz
27 DFKA112-120				MDFKAXX112-22, f _r : 120Hz
28 DSKA112-140				MDSKAXX112-22, f _r : 140Hz
30 DFQA100-50				MDFOQAXX100-50, f _r : 50Hz
31 DFQA100-100				MDFOQAXX100-100, f _r : 100Hz
32 DFQA112-28				MDFOQAXX112-28, f _r : 28Hz
33 DFQA112-58				MDFOQAXX112-58, f _r : 58Hz
34 DFQA132-20				MDFOQAXX132-20, f _r : 20Hz
35 DFQA132-42				MDFOQAXX132-42, f _r : 42Hz
40 DFQA112-50				MDFOQAXX112-50, f _r : 50Hz
41 DFQA112-100				MDFOQAXX112-100, f _r : 100Hz
42 DFQA132-36				MDFOQAXX132-36, f _r : 36Hz
43 DFQA132-76				MDFOQAXX132-76, f _r : 76Hz

Appendix




Code	LCD	Possible settings		IMPORTANT																																																																																																																	
		Lenze	Choice																																																																																																																		
			Lenze asynchronous servo motors	<ul style="list-style-type: none"> without integrated temperature monitoring The temperature monitoring via resolver or encoder cable is deactivated automatically, i.e.: <ul style="list-style-type: none"> C0583 = 3 C0584 = 3 C0594 = 3 																																																																																																																	
		*	<table> <tbody> <tr><td>50</td><td>DSVA56-140</td><td>DSVAXX056-22, f_r: 140Hz</td></tr> <tr><td>51</td><td>DFVA71-120</td><td>DFVAXX071-22, f_r: 120Hz</td></tr> <tr><td>52</td><td>DSVA71-140</td><td>DSVAXX071-22, f_r: 140Hz</td></tr> <tr><td>53</td><td>DFVA80-60</td><td>DFVAXX080-22, f_r: 60Hz</td></tr> <tr><td>54</td><td>DSVA80-70</td><td>DSVAXX080-22, f_r: 70Hz</td></tr> <tr><td>55</td><td>DFVA80-120</td><td>DFVAXX080-22, f_r: 120Hz</td></tr> <tr><td>56</td><td>DSVA80-140</td><td>DSVAXX080-22, f_r: 140Hz</td></tr> <tr><td>57</td><td>DFVA90-60</td><td>DFVAXX090-22, f_r: 60Hz</td></tr> <tr><td>58</td><td>DSVA90-80</td><td>DSVAXX090-22, f_r: 80Hz</td></tr> <tr><td>59</td><td>DFVA90-120</td><td>DFVAXX090-22, f_r: 120Hz</td></tr> <tr><td>60</td><td>DSVA90-140</td><td>DSVAXX090-22, f_r: 140Hz</td></tr> <tr><td>61</td><td>DFVA100-60</td><td>DFVAXX100-22, f_r: 60Hz</td></tr> <tr><td>62</td><td>DSVA100-80</td><td>DSVAXX100-22, f_r: 80Hz</td></tr> <tr><td>63</td><td>DFVA100-120</td><td>DFVAXX100-22, f_r: 120Hz</td></tr> <tr><td>64</td><td>DSVA100-140</td><td>DSVAXX100-22, f_r: 140Hz</td></tr> <tr><td>65</td><td>DFVA112-60</td><td>DFVAXX112-22, f_r: 60Hz</td></tr> <tr><td>66</td><td>DSVA112-85</td><td>DSVAXX112-22, f_r: 85Hz</td></tr> <tr><td>67</td><td>DFVA112-120</td><td>DFVAXX112-22, f_r: 120Hz</td></tr> <tr><td>68</td><td>DSVA112-140</td><td>DSVAXX112-22, f_r: 140Hz</td></tr> </tbody> </table> <table> <tbody> <tr><td></td><td>New generation Lenze synchronous servo motors</td><td></td></tr> <tr><td>108</td><td>DSKS36-13-200</td><td>MDSKXXX036-13, f_r:200Hz</td></tr> <tr><td>109</td><td>DSKS36-23-200</td><td>MDSKXXX036-23, f_r:200Hz</td></tr> <tr><td>110</td><td>DSKS56-23-150</td><td>MDSKXXX056-23, f_r: 150Hz</td></tr> <tr><td>111</td><td>DSKS56-33-150</td><td>MDSKXXX056-33, f_r: 150Hz</td></tr> <tr><td>112</td><td>DSKS71-13-150</td><td>MDSKXXX071-13, f_r: 150Hz</td></tr> <tr><td>113</td><td>DFKS71-13-150</td><td>MDFKSXX071-13, f_r: 150Hz</td></tr> <tr><td>114</td><td>DSKS71-23-150</td><td>MDSKXXX071-23, f_r: 150Hz</td></tr> <tr><td>115</td><td>DFKS71-23-150</td><td>MDFKSXX071-23, f_r: 150Hz</td></tr> <tr><td>116</td><td>DSKS71-33-150</td><td>MDSKXXX071-33, f_r: 150Hz</td></tr> <tr><td>117</td><td>DFKS71-33-150</td><td>MDFKSXX071-33, f_r: 150Hz</td></tr> <tr><td>160</td><td>DSKS56-23-190</td><td>MDSKXXX56-23-190,f_r:190Hz</td></tr> <tr><td>161</td><td>DSKS56-33-200</td><td>MDSKXXX56-33-200,f_r:200Hz</td></tr> <tr><td>162</td><td>DFKS71-03-170</td><td>MDFKSXX71-03-170,f_r:170Hz</td></tr> <tr><td>163</td><td>DSKS71-03-165</td><td>MDSKXXX71-03-165,f_r:165Hz</td></tr> <tr><td>164</td><td>DSKS71-13-185</td><td>MDSKXXX71-13-185,f_r:185Hz</td></tr> <tr><td>165</td><td>DFKS71-13-180</td><td>MDFKSXX71-13-180,f_r:180Hz</td></tr> <tr><td>166</td><td>DSKS71-33-180</td><td>MDSKXXX71-33-180,f_r:180Hz</td></tr> <tr><td>167</td><td>DFKS71-33-175</td><td>MDFKSXX71-33-175,f_r:175Hz</td></tr> </tbody> </table>	50	DSVA56-140	DSVAXX056-22, f _r : 140Hz	51	DFVA71-120	DFVAXX071-22, f _r : 120Hz	52	DSVA71-140	DSVAXX071-22, f _r : 140Hz	53	DFVA80-60	DFVAXX080-22, f _r : 60Hz	54	DSVA80-70	DSVAXX080-22, f _r : 70Hz	55	DFVA80-120	DFVAXX080-22, f _r : 120Hz	56	DSVA80-140	DSVAXX080-22, f _r : 140Hz	57	DFVA90-60	DFVAXX090-22, f _r : 60Hz	58	DSVA90-80	DSVAXX090-22, f _r : 80Hz	59	DFVA90-120	DFVAXX090-22, f _r : 120Hz	60	DSVA90-140	DSVAXX090-22, f _r : 140Hz	61	DFVA100-60	DFVAXX100-22, f _r : 60Hz	62	DSVA100-80	DSVAXX100-22, f _r : 80Hz	63	DFVA100-120	DFVAXX100-22, f _r : 120Hz	64	DSVA100-140	DSVAXX100-22, f _r : 140Hz	65	DFVA112-60	DFVAXX112-22, f _r : 60Hz	66	DSVA112-85	DSVAXX112-22, f _r : 85Hz	67	DFVA112-120	DFVAXX112-22, f _r : 120Hz	68	DSVA112-140	DSVAXX112-22, f _r : 140Hz		New generation Lenze synchronous servo motors		108	DSKS36-13-200	MDSKXXX036-13, f _r :200Hz	109	DSKS36-23-200	MDSKXXX036-23, f _r :200Hz	110	DSKS56-23-150	MDSKXXX056-23, f _r : 150Hz	111	DSKS56-33-150	MDSKXXX056-33, f _r : 150Hz	112	DSKS71-13-150	MDSKXXX071-13, f _r : 150Hz	113	DFKS71-13-150	MDFKSXX071-13, f _r : 150Hz	114	DSKS71-23-150	MDSKXXX071-23, f _r : 150Hz	115	DFKS71-23-150	MDFKSXX071-23, f _r : 150Hz	116	DSKS71-33-150	MDSKXXX071-33, f _r : 150Hz	117	DFKS71-33-150	MDFKSXX071-33, f _r : 150Hz	160	DSKS56-23-190	MDSKXXX56-23-190,f _r :190Hz	161	DSKS56-33-200	MDSKXXX56-33-200,f _r :200Hz	162	DFKS71-03-170	MDFKSXX71-03-170,f _r :170Hz	163	DSKS71-03-165	MDSKXXX71-03-165,f _r :165Hz	164	DSKS71-13-185	MDSKXXX71-13-185,f _r :185Hz	165	DFKS71-13-180	MDFKSXX71-13-180,f _r :180Hz	166	DSKS71-33-180	MDSKXXX71-33-180,f _r :180Hz	167	DFKS71-33-175	MDFKSXX71-33-175,f _r :175Hz
50	DSVA56-140	DSVAXX056-22, f _r : 140Hz																																																																																																																			
51	DFVA71-120	DFVAXX071-22, f _r : 120Hz																																																																																																																			
52	DSVA71-140	DSVAXX071-22, f _r : 140Hz																																																																																																																			
53	DFVA80-60	DFVAXX080-22, f _r : 60Hz																																																																																																																			
54	DSVA80-70	DSVAXX080-22, f _r : 70Hz																																																																																																																			
55	DFVA80-120	DFVAXX080-22, f _r : 120Hz																																																																																																																			
56	DSVA80-140	DSVAXX080-22, f _r : 140Hz																																																																																																																			
57	DFVA90-60	DFVAXX090-22, f _r : 60Hz																																																																																																																			
58	DSVA90-80	DSVAXX090-22, f _r : 80Hz																																																																																																																			
59	DFVA90-120	DFVAXX090-22, f _r : 120Hz																																																																																																																			
60	DSVA90-140	DSVAXX090-22, f _r : 140Hz																																																																																																																			
61	DFVA100-60	DFVAXX100-22, f _r : 60Hz																																																																																																																			
62	DSVA100-80	DSVAXX100-22, f _r : 80Hz																																																																																																																			
63	DFVA100-120	DFVAXX100-22, f _r : 120Hz																																																																																																																			
64	DSVA100-140	DSVAXX100-22, f _r : 140Hz																																																																																																																			
65	DFVA112-60	DFVAXX112-22, f _r : 60Hz																																																																																																																			
66	DSVA112-85	DSVAXX112-22, f _r : 85Hz																																																																																																																			
67	DFVA112-120	DFVAXX112-22, f _r : 120Hz																																																																																																																			
68	DSVA112-140	DSVAXX112-22, f _r : 140Hz																																																																																																																			
	New generation Lenze synchronous servo motors																																																																																																																				
108	DSKS36-13-200	MDSKXXX036-13, f _r :200Hz																																																																																																																			
109	DSKS36-23-200	MDSKXXX036-23, f _r :200Hz																																																																																																																			
110	DSKS56-23-150	MDSKXXX056-23, f _r : 150Hz																																																																																																																			
111	DSKS56-33-150	MDSKXXX056-33, f _r : 150Hz																																																																																																																			
112	DSKS71-13-150	MDSKXXX071-13, f _r : 150Hz																																																																																																																			
113	DFKS71-13-150	MDFKSXX071-13, f _r : 150Hz																																																																																																																			
114	DSKS71-23-150	MDSKXXX071-23, f _r : 150Hz																																																																																																																			
115	DFKS71-23-150	MDFKSXX071-23, f _r : 150Hz																																																																																																																			
116	DSKS71-33-150	MDSKXXX071-33, f _r : 150Hz																																																																																																																			
117	DFKS71-33-150	MDFKSXX071-33, f _r : 150Hz																																																																																																																			
160	DSKS56-23-190	MDSKXXX56-23-190,f _r :190Hz																																																																																																																			
161	DSKS56-33-200	MDSKXXX56-33-200,f _r :200Hz																																																																																																																			
162	DFKS71-03-170	MDFKSXX71-03-170,f _r :170Hz																																																																																																																			
163	DSKS71-03-165	MDSKXXX71-03-165,f _r :165Hz																																																																																																																			
164	DSKS71-13-185	MDSKXXX71-13-185,f _r :185Hz																																																																																																																			
165	DFKS71-13-180	MDFKSXX71-13-180,f _r :180Hz																																																																																																																			
166	DSKS71-33-180	MDSKXXX71-33-180,f _r :180Hz																																																																																																																			
167	DFKS71-33-175	MDFKSXX71-33-175,f _r :175Hz																																																																																																																			




Appendix

Code	LCD	Possible settings		IMPORTANT	
		Lenze	Choice		
			Lenze inverter motor in star connection	<ul style="list-style-type: none"> The temperature monitoring via resolver or encoder cable is deactivated automatically, i.e.: C0583 = 3 C0584 = 3 C0594 = 3 <p>DXRAXX071-12, f_d: 50Hz DXRAXX071-22, f_d: 50Hz DXRAXX080-12, f_d: 50Hz DXRAXX090-12, f_d: 50Hz DXRAXX090-32, f_d: 50Hz DXRAXX100-22, f_d: 50Hz DXRAXX100-32, f_d: 50Hz DXRAXX112-12, f_d: 50Hz DXRAXX132-12, f_d: 50Hz DXRAXX132-22, f_d: 50Hz DXRAXX160-12, f_d: 50Hz DXRAXX160-22, f_d: 50Hz DXRAXX180-12, f_d: 50Hz DXRAXX180-22, f_d: 50Hz</p>	
			Lenze inverter motor in delta connection	<ul style="list-style-type: none"> The temperature monitoring via resolver or encoder cable is deactivated automatically, i.e.: C0583 = 3 C0584 = 3 C0594 = 3 <p>DXRAXX071-12, f_d: 87Hz DXRAXX071-22, f_d: 87Hz DXRAXX080-12, f_d: 87Hz DXRAXX090-12, f_d: 87Hz DXRAXX090-32, f_d: 87Hz DXRAXX100-22, f_d: 87Hz DXRAXX100-32, f_d: 87Hz DXRAXX112-12, f_d: 87Hz DXRAXX132-12, f_d: 87Hz DXRAXX132-22, f_d: 87Hz DXRAXX160-12, f_d: 87Hz DXRAXX160-22, f_d: 87Hz DXRAXX180-12, f_d: 87Hz DXRAXX180-22, f_d: 87Hz</p>	
[C0087]	Mot SPEED	*	300 {1 rpm}	16000	Rated motor speed → depending on C0086 <ul style="list-style-type: none"> Change of C0086 resets value to the assigned default setting Change of C0087 sets C0086 = 0
[C0088]	Mot CURRENT	*	0.5 {0.1 A}	500.0	Rated motor current → depending on C0086 <ul style="list-style-type: none"> Change of C0086 resets value to the assigned default setting Change of C0088 sets C0086 = 0

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
[C0089]	Mot Frequency	*	10 1 Hz	1000	Rated motor frequency → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0089 sets C0086 = 0
[C0090]	Mot Voltage	*	50 1 V	500	Rated motor voltage → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0090 sets C0086 = 0
[C0091]	Mot cos PHI	*	0.50 0.01	1.00	Motor cos φ → depending on C0086 • Change of C0086 resets value to the assigned default setting • Change of C0091 sets C0086 = 0
C0093	Drive Ident	Disp	0 invalid 1 none 93xx 93xx		Controller identification Type Lenze positioning controller
C0094	Password	0	0	9999	Password • Parameter access protection for the operating module. When the password is activated, only the codes of the user menus can be accessed. For further selection possibilities see C0096
[C0095]	Rotor Pos Adj	0	0 inactive 1 active		Rotor position adjustment of a synchronous motor • C0058 displays the zero angle of the rotor • C0095 = 1 starts position adjustment
[C0096] 1 2	RIF PROTECT. CAN PROTECT.	0 0	0 No password protection 1 Read protection 2 Write protection 3 Read/Write protection		Parameter access protection Extended password protection for bus systems with activated password (C0094). • All codes in the user menu can be accessed.
C0099	S/W Version	Disp	x.xx		Software version
C0101 1 2 ... 15	ROD TIR ROD TIR ...	0.000 0.000 ...	0.000 {0.001 s}	999.900	NSET-Tir Additional acceleration times T_{ir} for the main setpoint of NSET • Refers to speed change 0...n _{max} .
C0103 1 2 ... 15	ROD TIF ROD TIF ...	0.000 0.000 ...	0.000 {0.001 s}	999.900	NSET-Tif , additional deceleration times T_{if} for the main setpoint of NSET • Refers to speed change 0...n _{max} .
C0105	QSP TIF	0.000	0.000 {0.001 s}	999.900	QSP deceleration time for quick stop (QSP) • Refers to speed change 0...n _{max} .
C0108 1 2	FCODE (GAIN) FCODE (GAIN)	100.00 100.00	-199.99 {0.01 %}	199.99	FCOD (gain AOUT) Freely assignable code for relative analog signals
C0109 1 2	FCODE (OFFSET) FCODE (OFFSET)	0.00 0.00	-199.99 {0.01 %}	199.99	FCOD (offset AOUT) Freely assignable code for relative analog signals
C0114 1 2 3 4 5	DIGIN POL	1 1 0 0 0	0 HIGH active 1 LOW active		DIGINx polarity , (terminal polarity) X5/E1 X5/E2 X5/E3 X5/E4 X5/E5




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
[C0116] 1 ... 32	<i>FDO-0</i> <i>...</i> <i>FDO-31</i>	1000	FIXED 0 → Selection list 2	FDO (free digital output) • Signal assignment of the free digital outputs. Used for LECOM or system bus.
[C0117] 1 2 3 4	<i>DIGOUT</i> <i>DIGOUT</i> <i>DIGOUT</i> <i>DIGOUT</i>	*	30101 30013 500 30012	DCTRL-TRIP CMP1-OUT DCTRL-RDY MCTRL-MMAX → Selection list 2 Signal configuration DIGOUT → depending on C0005 X5/A1 X5/A2 X5/A3 X5/A4
C0118 1 2 3 4	<i>DIGOUT POL</i> <i>DIGOUT POL</i> <i>DIGOUT POL</i> <i>DIGOUT POL</i>	0 0 0 0	0 1	High active Low active Terminal polarity DIGOUT X5/A1 X5/A2 X5/A3 X5/A4
C0121	<i>OH7 LIMt</i>	150	45	{1 °C}
C0122	<i>OH4 LIMt</i>	85	45	{1 °C}
C0125	<i>BAUDRATE</i>	0 1 2 3 4	0 1 2 3 4	9600 baud 4800 baud 2400 baud 1200 baud 19200 baud LECOM baud rate for accessory module 2102
C0126	<i>MONIT CEO</i>	3	0 2 3	Trip Warning Off Conf. CEO , configuration communication error monitoring with automation interface CEO
C0130	<i>Rct Ti</i>		0 1 2 ... 14 15	C12/C13 Ti 1 Ti 2 ... Ti 14 Ti 15 active Ti times of NSET C0012/C0013 active Ti _{r1} /Ti _{f1} active Ti _{r2} /Ti _{f2} active ... Ti _{r14} /Ti _{f14} active Ti _{r15} /Ti _{f15} active
C0134	<i>RFG CHARAC</i>		0 1	linear S-shaped NSET RFG characteristic , ramp function generator characteristic for main setpoint linear S-shaped
C0135	<i>CONTROL WORD</i>		0	{1}
C0136 1	<i>CTRLWORD</i>		0	{1}
C0136 2	<i>CTRLWORD</i>		0	{1}
C0136 3	<i>CTRLWORD</i>		0	{1}
C0141	<i>FCODE (SEEPVAL)</i>	0.00	-199.99	{0.01 %}
			199.99	Main setpoint , freely configurable code for relative analog signals • used as main setpoint in the configurations C0005 = xxx1

Appendix




Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C0142	START OPTIONS	1	0 Start lock 1 Auto start			Start option, 0 = start protection 1 = automatic start Start conditions are executed: <ul style="list-style-type: none"> • after mains connection • after message ($t > 0.5s$) • after trip
C0150	STATUS WORD	Disp	Bit00 Config0* Bit01 IMP Bit02 Config2* Bit03 Config3* Bit04 Config4* Bit05 Config5* Bit06 n = 0 Bit07 Ctrl. inhibit * freely configurable	Bit08 Status code Bit09 Status code Bit10 Status code Bit11 Status code Bit12 Warning Bit13 Message Bit14 Config14* Bit15 Config15*		Status word decimal when networked with automation interfaces <ul style="list-style-type: none"> • Binary interpretation indicates the bit states
C0151	FDO (DW)	Disp	output signals configured with C0116			Hexadecimal signal assignment of the free digital outputs. <ul style="list-style-type: none"> • Binary interpretation indicates the bit states
C0155	STATUS WORD 2	Disp	Bit00 Fail Bit01 Mmax Bit02 Imax Bit03 IMP Bit04 RDY Bit05 Ctrl. inhibit Bit06 Trip Bit07 Init	Bit08 CW/CCW Bit09 - Bit10 - Bit11 - Bit12 - Bit13 - Bit14 - Bit15 -		Status word 2 Extended decimal status word <ul style="list-style-type: none"> • Binary interpretation indicates the bit states
[C0156]	1 START.B0 2 START.B2 3 START.B3 4 START.B4 5 START.B5 6 START.B14 7 START.B15	1000 30012 1000 10600 30013 15004 500	PAR*1 MCTRL-IMAX MCTRL-MMAX NSET-RFG l=0 CMP1-OUT DCTRL-CW/CCW DCTRL-RDY	→ Selection list 2		Configuration of the free bits of the status word
C0157	1 START.B0 2 START.B2 3 START.B3 4 START.B4 5 START.B5 6 START.B14 7 START.B15	Disp	0		1	Status of the free bits of the status word
C0161	RCT TRIP	Disp	All fault indications			Momentary fault indication (as under C0168/1)
C0167	RESET FAILMEM	0	0 No reset 1 Reset			History buffer reset Clears the history buffer
C0168	1 FAIL NO. RCT 2 FAIL NO. OLD1 3 FAIL NO. OLD2 4 FAIL NO. OLD3 5 FAIL NO. OLD4 6 FAIL NO. OLD5 7 FAIL NO. OLD6 8 FAIL NO. OLD7	Disp	All fault indications			Faults occurred History buffer <ul style="list-style-type: none"> • List of faults occurred 1: active 2: last 3: last but one 4: last but three 5: last but four 6: last but five 7: last but six 8: last but seven




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0169		[Disp]	Corresponding mains switch-on time	<p>Occurrence of the faults History buffer</p> <ul style="list-style-type: none"> • List of times when the faults have occurred under C0168 • Related to C0179 <p>1: active 2: last 3: last but one 4: last but three 5: last but four 6: last but five 7: last but six 8: last but seven</p>
C0170		[Disp]	Corresponding mains switch-on time	<p>Fault frequency History buffer</p> <ul style="list-style-type: none"> • List showing how often the faults have occurred consecutively under C0168 <p>1: active 2: last 3: last but one 4: last but three 5: last but four 6: last but five 7: last but six 8: last but seven</p>
[C0173]	UG LIMIT	1		<p>Adaptation UG thresholds UG = DC-bus voltage</p> <ul style="list-style-type: none"> • check during commissioning and adapt, if necessary • all drive components in DC bus connections must have the same thresholds <p>Operation on mains < 400 V with or without brake unit Operation on 400 V mains with or without brake unit Operation on 460 V mains with or without brake unit Operation on 480 V mains without brake unit Operation on 480 V mains with brake unit</p>
C0178	OP TIMER	[Disp]	0 {1 s} 4294967295	<p>Elapsed operating time meter</p> <ul style="list-style-type: none"> • Time when the controller was enabled
C0179	MAINS TIMER	[Disp]	0 {1 s} 4294967295	<p>Mains switch-on time meter</p> <ul style="list-style-type: none"> • Time when the mains was switched on
C0182	T <small>i</small> S-SHAPED	20.00	0.01 s {0.01 s} 50.00 s	<p>NSET T<small>i</small>-S-shaped RFG</p> <p>T<small>i</small> time of the S-curve ramp function generator for NSET</p> <p>Determines the S-shape</p> <ul style="list-style-type: none"> • low values ⇒ small S inaccuracy • high values ⇒ big S inaccuracy

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0183	DIAGNOSTICS	[Disp]	0 OK 10 Init 91 Trip-Set C135 92 Trip-Set AIF 93 Trip-Set CAN 102 Trip 103 RFG P-OFF 104 IMP Message 105 Power off 111 BSP C135 112 BSP AIF 113 BSP CAN 121 CINH term 28 122 CINH int 1 123 CINH int 2 124 CINH C135/STP 125 CINH AIF 126 CINH CAN 131 FAIL-QSP 141 Lock mode 142 IMP 151 QSP ext term 152 QSP C135/STP 153 QSP AIF 154 QSP CAN 250 Warning	Drive diagnostics <ul style="list-style-type: none"> • indicates fault or status information • if several items or fault or status information are to be shown, the information with the smallest number is displayed 0: No fault 10: Initialisation phase 102: TRIP active 103: Emergency stop 104: Message active 111: Operation inhibited 121: Controller inhibited through X5/28 122: DCTRL-CINH1 123: DCTRL-CINH2 124: STOP key of 9371BB 125: Controller inhibited through AIF 126: Controller inhibited through CAN 131: Fault reaction 141: Restart protection active 142: High resistance power outputs 151: QSP via MCTRL-QSP 152: QSP via STOP key 153: QSP via AIF 154: QSP via CAN 250: Warning active
C0190	NSET ARIT	0	0 OUT = C46 1 C46 + C49 2 C46 - C49 3 C46 * C49 4 C46 / C49 5 C46/(100 - C49)	NSET arithmetic function Arithmetics block in the function block NSET <ul style="list-style-type: none"> • Connects main setpoint C0046 and additional setpoint C0049
C0195	BRKE T Rct	99.9	0.0 {0.1 s} 99.9 s infinite	Brake engagement time <ul style="list-style-type: none"> • Engagement time of the mechanical holding brake (see technical data of the brake). • After the time elapsed under C0195, the status "mechanical brake closed" is reached
C0196	BRK T RELEASE	0.0	0.0 {0.1 s}	Brake disengagement time <ul style="list-style-type: none"> • Disengagement time of the mechanical holding brake (see technical data of the brake). • After the time has elapsed under C0196, the status "mechanic brake open" is reached.
C0200	S/W ID	[Disp]		Software identification
C0201	S/W DRT	[Disp]		Software release date
C0202	INTERNAL ID	[Disp]	0 {0.001}	100 Internal identification
C0203	KOMM.-NO.	[Disp]	x / xxxx / xxxx	Commission number
C0204	SERIAL-NO.	[Disp]	0 {1}	65535 Serial number
C0206	PRODUKT DRT	[Disp]		Production date
C0207	DL INFO 1	[Disp]		Download-info 1
C0208	DL INFO 2	[Disp]		Download-info 2
C0209	DL INFO 3	[Disp]		Download-info 3




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0220	NSET TIR ADD	0.000	0.000 {0.001 s}	999.900	NSET Tir additional setpoint Acceleration time T_{ir} of the additional set-point for NSET • Refers to speed change 0...n _{max} .
C0221	NSET TIF ADD	0.000	0.000 {0.001 s}	999.900	NSET Tif additional setpoint Deceleration time T_{if} of the additional set-point for NSET • Refers to speed change 0...n _{max} .
C0222	PCTRL VP	1.0	0.1 {0.1}	500.0	Process controller Vp gain
C0223	PCTRL TN	400	20 {1 ms} 99999 ms switched off	99999	Process controller Tn integral component
C0224	PCTRL KD	0.0	0.0 {0.1}	5.0	Process controller Kd differential component
C0241	NSET RFG I = 0	1.00	0.00 {0.01 %} 100 % = n _{max}	100.00	NSET threshold RFG ON=OFF for main setpoint
C0244	BRK n SEE	0.00	-100.00 {0.01 %} 100 % = value of C0057	100.00	Holding torque of the DC brake
C0250	FCODE 1B1E				FCODE 1 bit digital
C0252	RANGLE OFFSET	0	-245760000 {1 inc}	245760000	DFSET phase offset Fixed phase offset for digital frequency configuration • 1 turn = 65536 inc
C0253	RANGLE N-TRIM	*	-32767 {1 inc}	32767	DFSET n-dependent phase trimming speed-dependent phase trimming → depending on C0005, C0025, C0490 • Change of C0005, C0025, or C0490 re-sets C0253 to the default setting • 1 turn = 65536 inc • C0253 is reached at 15000 rpm
C0254	VP RANGLE-CTRL	0.2000	0.0000 {0.0001}	3.9999	MCTRL Vp phase controller
C0255	THRESHOLD P03	327680	10 {1 inc}	1800000000	Contouring error limit P03 • 1 turn = 65536 inc • Following error > C0255 releases fault "P03"
C0260	MPOT1 HIGH	100.00	-199.99 {0.01 %}	199.99	MPOT1 (motor potentiometer) upper limit • Mandatory: C0260 > C0261
C0261	MPOT1 LOW	-100.0	-199.99 {0.01 %}	199.99	MPOT1 (motor potentiometer) lower limit • Mandatory: C0261 < C0260
C0262	MPOT1 TIR	10.0	0.1 {0.1 s}	6000.0	MPOT1 (motor potentiometer) Acceleration time Tir • Refers to change 0...100 %
C0263	MPOT1 TIF	10.0	0.1 {0.1 s}	6000.0	MPOT1 (motor potentiometer) Deceleration time Tif • Refers to change 0...100 %
C0264	MPOT1 ON/OFF	0	0 No function 1 Down to 0% 2 Down to C261 3 Jump 0% 4 Jump to C261 5 Up to C260		MPOT1 on/off Deactivation function of motor potentiometer • Function which is executed when motor potentiometer is deactivated via the input MPOT1-INACTIVE. no change Deceleration with T_{if} to 0% Deceleration with T_{if} to C0261 Inhibit with $T_{if} = 0$ to 0% Inhibit with $T_{if} = 0$ to C0261 Acceleration with T_{ir} to C0260

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0265	MOTP1 INIT	0	0 Power off 1 C261 2 0%	MOTP1 initialisation • Value which is accepted during mains switching and activated motor pot. Value during mains failure lower limit of C0261 0 %
[C0267]				→ Selection list 2
1	UP	1000	FIXED 0	Configuration of the digital inputs of motor pot MOTP1
2	DOWN	1000	FIXED 0	Digital input acceleration Digital input deceleration
[C0268]	INRCT	1000	FIXED 0	→ Selection list 2
C0269		Disp		Configuration of the motor pot input MOTP1-INACTIVE
1	UP			Input signals motor potentiometer
2	DOWN			
3	INACTIVE			
C0325	Vp2 RDRPT	1.0	0.1 {0.1}	500.0 Process controller adaptation gain (V_{p2})
C0326	Vp3 RDRPT	1.0	0.1 {0.1}	500.0 Process controller adaptation gain (V_{p3})
C0327	SET2 RDRPT	100.00	0.00 {0.01 %}	100.00 Process controller adaptation n_{set2} Set speed threshold of the process controller adaptation • Mandatory: C0327 > C0328
C0328	SET1 RDRPT	0.00	0.00 {0.01 %}	100.00 Process controller adaptation n_{set1} Set speed threshold of the process controller adaptation • Mandatory: C0328 < C0327
C0329	RDRPT ON/OFF	0	0 no 1 Extern Vp 2 Setpoint 3 Ctrl diff	Activate process controller adaptation No process controller adaptation External via input Adaptation via setpoint Adaptation via control difference
C0332	PCTRL TIR	0.000	0.000 {0.001 s}	999.900 Process controller acceleration time T_{ir} • Related to setpoint change 0...100 %
C0333	PCTRL TIF	0.000	0.000 {0.001 s}	999.900 Process controller deceleration time T_{if} • Related to setpoint change 0...100 %
C0336	Rel VP	Disp	0.0 {0.1}	500.0 Process controller momentary V_p
C0337	BI/UNIPOLAR	0	0 bipolar 1 unipolar	Process controller range bipolar/unipolar
C0338	RRIT1 FUNCT	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 4 IN1 / IN2 5 IN1/(100 - IN2)	Function arithmetic block ARIT1 • links inputs IN1 and IN2
[C0339]				→ Selection list 1
1	/IN	1000	FIXED 0 %	Configuration arithmetic block ARIT1
2	/IN	1000	FIXED 0 %	
C0340		Disp		Input signals arithmetic block ARIT1
1	/IN			
2	/IN			
[C0350]	CAN ADDRESS	1	1 {1}	63 CAN bus node address
[C0351]	CAN BAUDRATE	0	0 500 kbit/s 1 250 kbit/s 2 125 kbit/s 3 50 kbit/s 4 1000 kbit/s	CAN bus baud rate




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
[C0352]	CAN MSE	0 1	0 slave Master		CAN master operation set up
C0353 1 2 3	CAN ADDR SEL1 CAN ADDR SEL2 CAN ADDR SEL3	0 0 0	0 C350 1 C354		Source for CAN bus IN/OUT addresses
C0354 1 2 3 4 5 6	IN1 ADDR2 OUT1 ADDR2 IN2 ADDR2 OUT2 ADDR2 IN3 ADDR2 OUT3 ADDR2	129 1 257 258 385 386	1 {1}	512	CAN bus IN/OUT node addresses
C0355 1 2 3 4 5 6	CAN-IN1 ID CAN-OUT1 ID CAN-IN2 ID CAN-OUT2 ID CAN-IN3 ID CAN-OUT3 ID	[Disp]	0 {1}	2047	CAN bus identifier
C0356 1 2 3 4	CAN BOOT UP CAN-OUT2 T CAN-OUT3 T CAN DELAY	3000 0 0 20	0 {1 ms}	65000	CAN bus time settings
[C0357] 1 2 3	CE1MONIT TIME CE2MONIT TIME CE3MONIT TIME	3000 3000 3000	0 {1 ms}	65000	CE1 monitoring time CAN bus monitoring time for I _{rx}
C0358	RESET MODE	0 1	no function CAN reset		CAN reset node Install CAN bus reset node
C0359	CAN STATE	[Disp]	0 1 2 3	Operational Pre-Operat Warning Bus off	CAN status
C0360 1 2 3 4 5 6 7 8 9 10 11 12	MESSAGE OUT MESSAGE IN MESSAGE OUT1 MESSAGE OUT2 MESSAGE OUT3 MESSAGE POUT1 MESSAGE POUT2 MESSAGE IN1 MESSAGE IN2 MESSAGE IN3 MESSAGE PIN1 MESSAGE PIN2	[Disp]	0 {1}	65535	Messages , telegram counter (number of telegrams) • for values > 65535 the counting restarts at 0 1: all sent 2: all received 3: sent to CAN-OUT1 4: sent to CAN-OUT2 5: sent to CAN-OUT3 6: sent to parameter channel 1 7: sent to parameter channel 2 8: received from CAN-IN1 9: received from CAN-IN2 10: received from CAN-IN3 11: received from parameter channel 1 12: received from parameter channel 2

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0361		[Disp]	0 {1 %}	100	Bus load , CAN bus load <ul style="list-style-type: none"> To ensure a perfect operation, the total bus load (all connected devices) should be less than 80% 1: all sent 2: all received 3: sent to CAN-OUT1 4: sent to CAN-OUT2 5: sent to CAN-OUT3 6: sent to parameter channel 1 7: sent to parameter channel 2 8: received from CAN-IN1 9: received from CAN-IN2 10: received from CAN-IN3 11: received from parameter channel 1 12: received from parameter channel 2
1	LORD OUT				
2	LORD IN				
3	LORD OUT1				
4	LORD OUT2				
5	LORD OUT3				
6	LORD POUT1				
7	LORD POUT2				
8	LORD IN1				
9	LORD IN2				
10	LORD IN3				
11	LORD PIN1				
12	LORD PIN2				
C0362	SYNC CYCLE	[Disp]	0 {1 ms}	30	Time between two sync telegrams on the system bus
C0363	SYNC CORR	1	1 0.8 µs 2 1.6 µs 3 2.4 µs 4 3.2 µs 5 4.0 µs		CAN Sync correction Correction value for C0362
[C0364]	CFG.CAN ACTIV	1000	FIXED 0	→ Selection list 2	Switch from Pre-operat. to operat. , process data must be activated externally
C0365	CAN ACTIV	[Disp]	0	1	Input signal CAN active
C0366	SYNC RESPONSE	1	0 no sync response 1 sync response		CAN Sync Response
C0367	SYNC RX ID	128	1 {1}	256	CAN Sync Rx Identifier
C0368	SYNC TX ID	128	1 {1}	256	CAN Sync Tx Identifier
C0369	SYNC TX TIME	0	0 {1 ms}	65000	CAN Sync Tx Time
C0400	OUT	[Disp]	-199.99 {0,01 %}	199.99	Output of AIN1
[C0402]	OFFSET	19502	FCODE-26/1	→ Selection list 1	Configuration offset of AIN1
[C0403]	GAIN	19504	FCODE-27/1	→ Selection list 1	Configuration gain of AIN1
C0404		[Disp]	-199.99 {0.01 %}	199.99	Input signals of AIN1
1	OFFSET				
2	GAIN				
C0405	OUT	[Disp]	-199.99 {1 %}	199.99	Output of AIN2
[C0407]	OFFSET	19503	FCODE-26/2	→ Selection list 1	Configuration offset of AIN2
[C0408]	GAIN	19505	FCODE-27/2	→ Selection list 1	Configuration gain of AIN2
C0409		[Disp]	-199.99 {0.01 %}	199.99	Input signals of AIN2
1	OFFSET				
2	GAIN				
[C0416]	RESOLVER ADJ	0	0 {1}	99999999	Correction Resolver fault For Lenze motors: <ul style="list-style-type: none"> Read resolver error from the nameplate
[C0420]	ENCODER CONST	512	1 {1 inc/rev}	8192	Encoder constant for encoder input X8 in increments per revolution
[C0421]	ENCODER VOLT	5.00	5.00 {0.1V}	8.00	Encoder voltage supply setting <ul style="list-style-type: none"> CAUTION: incorrect input may destroy the encoder
C0425	DFIN CONST	3	0 256 inc/rev 1 512 inc/rev 2 1024 inc/rev 3 2048 inc/rev 4 4096 inc/rev 5 8192 inc/rev 6 16384 inc/rev		Constant for digital frequency input in increments per revolution




Appendix

Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
C0426	DUT	[Disp]	-32767	{1 rpm}	32767	Output signal of DFIN
C0427	DFIN FUNKTION	0	0 1 2	2-phase A puls / B dir Puls A or B		DFIN function , type of the digital frequency signal 0 = Quadrature 1 = Pulse / Direction 2 = Pulse A / Pulse B
C0429	TP5 DELAY	0	-32767	{1 inc}	32767	TP5 delay , dead time compensation for the TP function of DFSET and DFRFG
C0429	TP5 DELAY	0	-32767	{1 inc}	32767	Dead time compensation for the TP function of DFSET and DFRFG
C0430			0.000	{0.001 ms}	2.000	TP1 delay
1	TP1 DELAY	0.218				
2	TP2 DELAY	0.218				
3	TP3 DELAY	0.218				
4	TP4 DELAY	0.218				
C0430			0.000	{0.001 ms}	2.000	TP1 delay
1	TP1 DELAY	0.218				
2	TP2 DELAY	0.218				
3	TP3 DELAY	0.218				
4	TP4 DELAY	0.218				
[C0431]	IN	5001	MCTRL-NACT	→ Selection list 1	Configuration input of AOUT1	[10-58
[C0432]	OFFSET	19512	FCODE-109/1	→ Selection list 1	Configuration offset of AOUT1	[10-58
[C0433]	GAIN	19510	FCODE-108/1	→ Selection list 1	Configuration gain of AOUT1	[10-58
C0434		[Disp]	-199.99	{0.01 %}	199.99	Input signals of AOUT1
1	IN					
2	OFFSET					
3	GAIN					
[C0436]	IN	5002	MCTRL-MSET2	→ Selection list 1	Configuration input of AOUT2	[10-58
[C0437]	OFFSET	19513	FCODE-109/2	→ Selection list 1	Configuration offset of AOUT2	[10-58
[C0438]	GAIN	19511	FCODE-108/2	→ Selection list 1	Configuration gain of AOUT2	[10-58
C0439		[Disp]	-199.99	{0.01 %}	199.99	Input signals of AOUT2
1	IN					
2	OFFSET					
3	GAIN					
[C0440]	STATE-BUS	1000		→ Selection list 2	Configuration state bus X5/ST	[10-58
C0441	STATE-BUS	[Disp]			Monitoring signal state bus	
C0443	DIGIN-OUT	[Disp]	0	{1}	255	Signals at X5/E1 to X5/E5 decimal value • Binary interpretation indicates terminal signals
C0444		[Disp]	0		1	Signals at X5/A1 to X5/A4
1	DIGOUT1					
2	DIGOUT2					
3	DIGOUT3					
4	DIGOUT4					
[C0450]	NX	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of BRK1	[10-58
[C0451]	ON	1000	FIXED 0	→ Selection list 2	Configuration digital input of BRK1	[10-58
[C0452]	SIGN	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of BRK1	[10-58
C0458		[Disp]	-199.99	{0.01 %}	199.99	Analog input signals of BRK1
1	NX					
2	SIGN					
C0459	ON	[Disp]				Digital input signal of BRK1

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0464	CUSTOMER I/F	[Disp]	0 original 1 changed	Customer interface , status of the selected basic configuration <ul style="list-style-type: none"> Reassignment of terminals in a basic configuration from C0005 does not change C0005 and sets C0464 = 1 Adding or removing of function blocks or changing the signal flow among the function blocks in a basic configuration of C0005 sets C0005 = 0 and C0464= 1
[C0465]		*		→ Selection list 5
1	FB LIST	200		
2	FB LIST	0		
3	FB LIST	50		
4	FB LIST	0		
5	FB LIST	0		
6	FB LIST	55		
7	FB LIST	0		
8	FB LIST	0		
9	FB LIST	10250		
10	FB LIST	0		
11	FB LIST	0		
12	FB LIST	0		
13	FB LIST	5650		
14	FB LIST	0		
15	FB LIST	0		
16	FB LIST	5050		
...	FB LIST	0		
19	...	5700		
...	FB LIST	0		
22	...	10650		
...	FB LIST	0		
25	...	70		
...	FB LIST	0		
28	...	75		
...	FB LIST	0		
31	...	250		
...	FB LIST	0		
41	...	25000		
42	FB LIST	20000		
...	FB LIST	0		
49	...	0		
50	FB LIST	0		
C0466	CPU T REMAIN	[Disp]		Processing time remaining for processing function blocks
[C0469]	Fct STOP KEY			Function key Stop of the operating module <ul style="list-style-type: none"> Function is activated when pressing the STOP key. Deactivated Controller inhibit Quick stop
C0470		0	{1}	255
1	FCODE BIT 0-7	0		Freely assignable code for digital signals
2	FCODE BIT 8-15	0		<ul style="list-style-type: none"> The data words C0470 and C0471 are in parallel and are identical
3	FCODE BIT 16-23	0		
4	FCODE BIT 24-31	0		
C0471	FCODE 32 BIT	0	0 {1} 4294967296	Freely assignable code for digital signals
				<ul style="list-style-type: none"> The data words C0470 and C0471 are in parallel and are identical




Appendix

Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
C0472			-199.99 0.00 0.00 100.00 100.00 ... 0.00 0.00	{0.01 %} 199.99	Freely assignable code for relative analog signals	
1 2 3 6 ... 19 20	FCODE ANALOG FCODE ANALOG FCODE ANALOG FCODE ANALOG FCODE ANALOG FCODE ANALOG					
C0473			-32767 1 1 0 ... 0 0	{1} 32767	Freely assignable code for absolute analog signals	
1 2 3 ... 9 10	FCODE ABS FCODE ABS FCODE ABS FCODE ABS FCODE ABS					
C0474			-2147483648 0 0 ... 0	{1} 2147483648	FCODE phase , freely configurable code for phase signals • 1 turn = 65536 inc	
1 2 ... 5	FCODE PH FCODE PH FCODE PH					
C0475			-16000 0 0	{1 rpm} 16000	FCODE phase difference , freely configurable code for phase difference signals • 1 turn = 65536 inc	
1 2	FCODE DF FCODE DF					
[C0490]	FEEDBACK POS		0 0 1 2 3 4	Resolver Encoder TTL Encoder sin Absolut ST Absolut MT	Position feedback system controller • C0490 = 0, 1, 2 can be mixed with C0495 = 0, 1, 2 • C0490 = 3, 4 also sets C0495 to the same value Resolver at X7 Encoder TTL at X8 sin/cos encoder at X8 Absolute value encoder ST at X8 Absolute value encoder MT at X8	
[C0495]	FEEDBACK N		0 0 1 2 3 4	Resolver Encoder TTL Encoder sin Absolut ST Absolut MT	Speed feedback system controller • C0495 = 0, 1, 2 can be mixed with C0490 = 0, 1, 2 • C0495 = 3, 4 also sets C0490 to the same value Resolver at X7 Encoder TTL at X8 sin/cos encoder at X8 Absolute value encoder ST at X8 Absolute value encoder MT at X8	
C0497	NACT-FILTER	2.0	0.0 0 ms	{0.1 ms} switched off	50.0	Nact-filter time constant (for actual speed)

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0517			0 {1} 199900		
1	USER MENU	51.00	C0051/0 MCTRL-NACT		
2	USER MENU	54.00	C0054/0 Imot		
3	USER MENU	56.00	C0056/0 MCTRL-MSET2		
4	USER MENU	46.00	C0046/0 DIS: N		
5	USER MENU	49.00	C0049/0 DIS: NADD		
6	USER MENU	183.00	C0183/0 Diagnostics		
7	USER MENU	168.01	C0168/1 Fail no. act		
8	USER MENU	86.00	C0086/0 Mot type		
9	USER MENU	22.00	C0022/0 Imax current		
10	USER MENU	5.00	C0005/0 Signal cfg		
11	USER MENU	11.00	C0011/0 Nmax		
12	USER MENU	12.00	C0012/0 Tir		
13	USER MENU	13.00	C0013/0 Tif		
14	USER MENU	105.00	C0105/0 QSP Tif		
15	USER MENU	39.01	C0039/1 JOG setpoint		
16	USER MENU	70.00	C0070/0 Vp speed CTRL		
17	USER MENU	71.00	C0071/0 Tn speed CTRL		
18	USER MENU	0	not assigned		
...	USER MENU		
30	...	0	not assigned		
31	USER MENU	94.00	C0094/0 Password		
32	USER MENU	3.00	C0003/0 Par save		
[C0520]	I/N	1000	FIXEDPHI-0 → Selection list 4	Configuration input of DFSET	10-58
[C0521]	V/P-DIV	1000	FIXED 0 % → Selection list 1	Configuration gain factor numerator of DFSET	10-58
[C0522]	R/R-DIV	1000	FIXED 0 % → Selection list 1	Configuration gearbox factor numerator of DFSET	10-58
[C0523]	R-TRIM	1000	FIXED 0 % → Selection list 1	Configuration phase trimming of DFSET	10-58
[C0524]	N-TRIM	1000	FIXED 0 % → Selection list 1	Configuration speed trimming of DFSET	10-58
[C0525]	0-PULSE	1000	FIXED 0 → Selection list 2	Configuration one-time zero pulse activation of DFSET	10-58
[C0526]	RESET	1000	FIXED 0 → Selection list 2	Configuration reset integrators of DFSET	10-58
[C0527]	SET	1000	FIXED 0 → Selection list 2	Configuration set integrators of DFSET	10-58
C0528			-2000000000 {1 inc} 2000000000	Zero pulse phase difference Phase difference between two zero pulses Offset of C0523+C0529 + C0252	
1	0-PULSE R	Disp			
2	OFFSEE				
C0529	MULTIP OFFSET	1	-20000 {1} 20000	Offset multiplier	
C0530	DF EVALUATION	1	0 with g factor 1 without g factor	DFSET digital frequency evaluation Evaluation of the setpoint integrator of DFSET (with/without gearbox factor)	
C0531	RCT 0 DIV	1	1 {1} 16384	DFSET act. zero pulse divider	
C0532	0-PULSE/TP	1	1 0-pulse 2 Touch probe	DFSET zero pulse/touch probe Selection zero pulse of the feedback system or touch probe for DFSET	
C0533	V/P DENOM	1	1 {1} 32767	Gain factor Vp denominator of DFSET	
C0534	0-PULSE FCT	0	0 Not active 1 Continuous 2 Cont. switch 10 Once, fast way 11 Once, cw 12 Once, ccw 13 Once, 2*0-puls	Zero pulse function of DFSET	
C0535	SET 0 DIV	1	1 {1} 16384	Set zero pulse divider of DFSET	




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0536 1 2 3	V/P-DIV RAT-DIV R-TRIMM	[Disp]	-32767 {1}	32767	Absolute analog input signals of DFSET
C0537	I/Y-RI	[Disp]	-199.99 {0.01 %}	199.99	Relative analog input signal of DFSET
C0538 1 2 3	D-PULSE RESET SET	[Disp]			Digital input signals of DFSET
C0539	I/Y	[Disp]	-32767 {1 rpm}	32767	Input signal of DFSET
[C0540]	FUNCTION	2	0 1 2 3 4 5	Analog input PH diff input Res + int 0 Res + ext 0 OUT = DFIN OUT = encoder	• X9 is inhibited if 0, 1, 2 or 3 was selected • The input signals get a gain
					Analog input
					Phase difference input
					Resolver simulation + zero pulse
					Resolver simulation without zero pulse
					X9 is output on X10 X8 is output on X10
[C0541]	RIN/RIN	0	MCTRL-NACT	→ Selection list 1	Configuration analog input of DFOUT
[C0542]	DF-I/Y	1000	FIXEDPHI 0	→ Selection list 4	Configuration digital frequency input of DFOUT
[C0544]	SYN-ROD	1000	FIXED 0	→ Selection list 2	Configuration synchronization signal for the zero pulse of DFOUT
C0545	PH_OFFSET	0	0 {1 inc}	65535	DFOUT phase offset • 1 turn = 65535 inc
C0546	RIN/INC/REV	1000	1 {1 inc}	2147483647	• 1 turn = 65535 inc
C0547	RIN/I/Y	[Disp]	-199.99 {0.01 %}	199.99	Relative analog input signal of DFOUT
C0548	SYN-ROD	[Disp]	0 {1 rpm}	1	Digital input signal of DFOUT
C0549	DF-I/Y	[Disp]	-32767 {1 rpm}	32767	Absolute analog input signal of DFOUT
C0560 1 2 3 4 5 ... 14 15	FIX SET-VALUE FIX SET-VALUE FIX SET-VALUE FIX SET-VALUE FIX SET-VALUE ... FIX SET-VALUE FIX SET-VALUE	100.00 75.00 50.00 25.00 0.00 ... 0.00 0.00	-199.99 {0.01 %}	199.99	FIXSET1 Fixed setpoints
[C0561]	RIN	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of FIXSET1
[C0562] 1 2 3 4	I/Y	1000 1000 1000 1000	FIXED 0 FIXED 0 FIXED 0 FIXED 0	→ Selection list 2	Configuration digital inputs of FIXSET1
C0563	RIN	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of FIXSET1
C0564 1 2 3 4	I/Y	[Disp]			Digital input signals of FIXSET1
[C0570]	I/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of S&H1
[C0571]	LORD	1000	FIXED 0	→ Selection list 2	Configuration digital input of S&H1
C0572	I/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of S&H1
C0573	LORD	[Disp]			Digital input signal of S&H1

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0577	<i>Vp FLD WERK</i>	3.0	0.00 {0.01 ms}	15.99	VP field weakening controller Vp = gain
C0578	<i>Tn FLD WERK</i>	10	2.0 {0.5 ms} 8000 ms switched off	8192.0	Tn-field weakening controller Tn = adjustment time
C0581	<i>MONIT EER</i>	0	0 Trip 1 Message 2 Warning 3 Off 4 Fail-QSP		Conf. EEr(external) Configuration for the monitoring of external faults
C0582	<i>MONIT OH4</i>	2	2 Warning 3 Off		Conf. OH4 Configuration of the heatsink temperature monitoring
C0583	<i>MONIT OH3</i>	*	0 Trip 3 Off		Conf.OH3 , configuration of the fixed motor temperature monitoring → depending on C0086
C0584	<i>MONIT OH7</i>	*	2 Warning 3 Off		Conf.OH7 , Configuration monitoring OH7 (Motor temperature adjustable) → depending on C0086 • Temperature monitoring via resolver input
C0585	<i>MONIT OH8</i>	3	0 Trip 2 Warning 3 Off		Conf.OH8 Configuration monitoring OH8 (Motor temperature adjustable) • Temperature monitoring via PTC input
C0586	<i>MONIT SD2</i>	0	0 Trip 2 Warning 3 Off		Conf. SD2 Configuration monitoring SD2 (Resolver)
C0587	<i>MONIT SD3</i>	3	0 Trip 2 Warning 3 Off		Conf. SD3 Configuration monitoring SD3 (Encoder at X9)
C0588	<i>MONIT H10/H11</i>	3	0 Trip 2 Warning 3 Off		Conf. H10 / H11 Configuration monitoring H10 and H11 (thermal sensors in the controller)
C0589	<i>MONIT P03</i>	2	0 Trip 2 Warning 3 Off		Conf. P03 (contouring error DFSET)
C0590	<i>MONIT P13</i>	0	0 Trip 2 Warning 3 Off		Conf. P13 (phase fault DFSET)
C0591	<i>MONIT CE1</i>	3	0 Trip 2 Warning 3 Off		Conf. CE1 Configuration monitoring CE1 (CAN-IN1 fault)
C0592	<i>MONIT CE2</i>	3	0 Trip 2 Warning 3 Off		Conf. CE2 Configuration monitoring CE2 (CAN-IN2 fault)
C0593	<i>MONIT CE3</i>	3	0 Trip 2 Warning 3 Off		Conf. CE3 Configuration monitoring CE3 (CAN-IN3 fault)
C0594	<i>MONIT SD6</i>	*	0 Trip 2 Warning 3 Off		Conf. SD6 Configuration monitoring SD6 (Sensor motor temperature) → depending on C0086
C0595	<i>MONIT CE4</i>	3	0 Trip 2 Warning 3 Off		Conf. CE4 Configuration monitoring CE4 (CAN-bus Off)
C0596	<i>MAX LIME</i>	5500	0 {1 rpm}	16000	System speed monitoring Monitoring: machine speed
C0597	<i>MONIT LP1</i>	3	0 Trip 2 Warning 3 Off		Conf. LP1 Configuration monitoring motor phase failure




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0598	MONIT SDS	3	0 Trip 2 Warning 3 Off		Conf. SD5 Configuration monitoring master current at X5/1.2 < 2mA
C0599	LIMI LP 1	5.0	1.0 {0.1}	10.0	Current limit LP1 Current limit for motor phase failure monitoring
C0600	FUNCTION	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 4 IN1 / IN2 5 IN1/(100 - IN2)		Function arithmetic block ARIT2 • links inputs IN1 and IN2
[C0601] 1 2	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog inputs of ARIT2
	/Y	1000	FIXED 0 %		10-58
C0602 1 2	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signals of ARIT2
[C0610] 1 2 3	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog inputs of addition block ADD1
	/Y	1000	FIXED 0 %		10-58
	/Y	1000	FIXED 0 %		• Adds inputs IN1, IN2 and IN3
C0611 1 2 3	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signals of ADD1
	/Y				
C0620	DB1 GRIN	1.00	-10.00 {0.01}	10.00	DB gain Gain dead band component DB1
C0621	DB1 VALUE	1.00	0.00 {0.01 %}	100.00	DB1 dead band
[C0622]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of DB1
	/Y	[Disp]	-199.99 {0.01 %}	199.99	10-58
C0623	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of DB1
C0630	MAX LIMITE	100.00	-199.99 {0.01 %}	199.99	LIM upper limit of the limiter
C0631	RIM LIMIT	-100.0	-199.99 {0.01 %}	199.99	LIM lower limit of the limiter
[C0632]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of LIM1
	/Y	[Disp]	-199.99 {0.01 %}	199.99	10-58
C0633	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of LIM1
C0640	DELAY T	20.00	0.01 {0.01 s}	50.00	PT1-1 time constant
[C0641]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of PT1-1
	/Y	[Disp]	-199.99 {0.01 %}	199.99	10-58
C0642	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of PT1-1
C0650	DT1-1 GRIN	1.00	-320.00 {0.01}	320.00	DT1-1 gain
C0651	DELAY T	1.00	0.005 {0.01 s}	5.000	DT1-1 time constant
[C0652]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of DT1-1
	/Y	[Disp]	-199.99 {0.01 %}	199.99	10-58
C0653	SENSIBILITY	1	1 15-bit 2 14-bit 3 13-bit 4 12-bit 5 11-bit 6 10-bit 7 9-bit		DT1-1 sensitivity
C0654	/Y	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of DT1-1
C0655	NUMERATOR	1	-32767 {1}	32767	CONV5 Numerator Numerator for CONV5
C0656	DENOMINATOR	1	1 {1}	32767	CONV5 Denominator Denominator for CONV5
[C0657]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of CONV5
	/Y	[Disp]	-199.99 {0.01 %}	199.99	10-58

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C0658	/N	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of CONV5
[C0661]	/N	1000	FIXED 0 %	→ Selection list 1	Configuration analog input absolute-value generator ABS1
C0662	/N	[Disp]	-199.99 {0.01 %}	199.99	Analog input signal of ABS1
C0671	RFG1 T/R	0.000	0.000 {0.01 s}	999.900	RFG1 Tir (acceleration time) of the ramp function generator
C0672	RFG1 T/F	0.000	0.000 {0.01 s}	999.900	RFG1 Tif (deceleration time)
[C0673]	/N	1000	FIXED 0 %	→ Selection list 1	Configuration analog input of RFG1
[C0674]	SET	1000	FIXED 0 %	→ Selection list 1	Configuration set input of RFG1
[C0675]	LORD	1000	FIXED 0	→ Selection list 2	Configuration digital input of RFG1
C0676	1 /N 2 SET	[Disp]	-199.99 {0.01 %}	199.99	Analog input signals of RFG1
C0677	LORD	[Disp]			Digital input signal of RFG1
C0680	FUNCTION	6	1 IN1 = IN2 2 IN1 > IN2 3 IN1 < IN2 4 IN1 = IN2 5 IN1 > IN2 6 IN1 < IN2		CMP1 comparator function Function comparator CMP1 • Compares the inputs IN1 and IN2
C0681	HYSERESIS	1.00	0.00 {0.01 %}	100.00 %	CMP1 hysteresis
C0682	WINDOW	1.00	0.00 {0.01 %}	100.00 %	CMP1 window
[C0683]	1 /N 2 /N	1000 1000	MCTRL-NACT FCODE-17	→ Selection list 1	Configuration analog inputs of CMP1
C0684	1 /N 2 /N	[Disp]	-199.99 {0.01 %}	199.99	Analog input signals of CMP1
C0685	FUNCTION	1	1 IN1 = IN2 2 IN1 > IN2 3 IN1 < IN2 4 IN1 = IN2 5 IN1 > IN2 6 IN1 < IN2		CMP2 Comparator function Function comparator CMP2 • Compares the inputs IN1 and IN2
C0686	HYSERESIS	1.00	0.00 {0.01 %}	100.00 %	CMP2 hysteresis
C0687	WINDOW	1.00	0.00 {0.01 %}	100.00 %	CMP2 window
[C0688]	1 /N 2 /N	1000 1000	FIXED 0% FIXED 0%	→ Selection list 1	Configuration analog inputs of CMP2
C0689	1 /N 2 /N	[Disp]	-199.99 {0.01 %}	199.99	Analog input signals of CMP2
C0690	FUNCTION	1	1 IN1 = IN2 2 IN1 > IN2 3 IN1 < IN2 4 IN1 = IN2 5 IN1 > IN2 6 IN1 < IN2		CMP3 comparator function Function comparator CMP3 • Compares the inputs IN1 and IN2
C0691	HYSERESIS	1.00	0.00 {0.01 %}	100.00 %	CMP3 hysteresis
C0692	WINDOW	1.00	0.00 {0.01 %}	100.00 %	CMP3 window
[C0693]	1 /N 2 /N	1000 1000	FIXED 0% FIXED 0%	→ Selection list 1	Configuration analog inputs of CMP3




Appendix

Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C0694 1 2	/Y	[Disp]	-199.99 {0.01 %}	199.99		Analog input signals of CMP3
[C0700]	/Y	19523	FCODE-472/3	→ Selection list 1	Configuration input of von ANEG1	□ 10-58
C0701	/Y	[Disp]	-199.99 {0.01 %}	199.99	Input signal of ANEG1	
[C0703]	/Y	1000	FIXED 0 %	→ Selection list 1	Configuration input of ANEG2	□ 10-58
C0704	/Y	[Disp]	-199.99 {0.01 %}	199.99	Input signal ANEG2	
C0710	FUNCTION	0 1 2	0 Rising trans 1 Falling trans 2 Both trans		TRANS1 function Signal evaluation	
C0711	PULSE T	0.001	0.001 {0.001 s}	60.000	TRANS1 pulse duration	
[C0713]	/Y	1000	FIXED 0	→ Selection list 2	Configuration digital input of TRANS1	□ 10-58
C0714	/Y	[Disp]			Digital input signal of TRANS1	
C0715	FUNCTION	0 1 2	0 Rising trans 1 Falling trans 2 Both trans		TRANS2 function Signal evaluation	
C0716	PULSE T	0.001	0.001 {0.001 s}	60.000	TRANS2 pulse time	
[C0718]	/Y	1000	FIXED 0	→ Selection list 2	Configuration digital input of TRANS2	□ 10-58
C0719	/Y	[Disp]			Digital input signal of TRANS2	
C0720	FUNCTION	2	0 On delay 1 Off delay 2 On/Off delay		DIGDEL1 function Function: digital delay element	
C0721	DELAY T	1.000	0.001 {0.001 s}	60.000	DIGDEL1 delay time	
[C0723]	/Y	1000	FIXED 0	→ Selection list 2	Configuration digital input of DIGDEL1	□ 10-58
C0724	/Y	[Disp]			Digital input signal of DIGDEL1	
C0725	FUNCTION	0 1 2	0 On delay 1 Off delay 2 On/Off delay		DIGDEL2 function Digital delay element	
C0726	DELAY T	1.0	0.001 {0.001 s}	60.000	DIGDEL2 delay time	
[C0728]	/Y	1000	FIXED0	→ Selection list 2	Configuration digital input of DIGDEL2	□ 10-58
C0729	/Y	[Disp]			Digital input signal of DIGDEL2	
C0730	MODUS	0 1	0 Start measurement 1 Stop measurement		OSZ mode Start / Stop of the measurement recording of OSZ	
C0731	STATUS	[Disp]	0 1 2 3 4 5	Measurement completed Measurement active Trigger detected Cancel Cancel after trigger Read memory	OSZ status Current operating status of OSZ	
[C0732] 1 2 3 4	KANAL1 KANAL2 KANAL3 KANAL4	1000	FIXED0%	→ Selection list 1	CFG: OSZ channelx Configuration analog inputs of OSZ	□ 10-58
[C0733] 1	DIG. TRIGGER	1000	FIXED0	→ Selection list 2	CFG: OSZ trigger input Configuration of the OSZ trigger input	□ 10-58
C0734	TRIGGER-QUELLE	1 2 3 4	0 Dig. trigger input 1 Channel 1 2 Channel 2 3 Channel 3 4 Channel 4		Selection of the OSZ trigger source	
C0735	TRIGGER PEGEL	0	-32767 {1}	32767	Trigger level setting for channel 1 ... 4 of OSZ	

Appendix




Code	LCD	Possible settings		IMPORTANT		
		Lenze	Choice			
C0736	TRIGGER FLÄNKE	0	0 LOW/HIGH edge 1 HIGH/LOW edge	Selection of Trigger edge of OSC		
C0737	TRIGGER DELAY	0.0	-100.0 {0.1 %} 999.99	Trigger delay Setting pre and post triggering of OSZ		
C0738	RÜTERSTPERIODE	3	3 1 ms 4 2 ms 5 5 ms 6 10 ms 7 20 ms 8 50 msec 9 100 ms 10 200 ms 11 500 ms 12 1 s 13 2 sec 14 5 s 15 10 s 16 20 s 17 50 s 18 1 min 19 2 min 20 5 min 21 10 min	Selection of scanning period of OSC		
C0739	KANALANZAHL	4	1 {1}	4	Number of channels to be measured (OSZ)	
C0740	1 SERR	0	0 {1}	16383	Start point for reading Determine start point when reading the data memory of OSZ Selection of a memory block	
	2 FREI/SPERREN	0	0 Data reading inhibited 1 Data reading enabled		Data reading enabled/inhibited The data memory of OSZ must be enabled for reading	
C0741	1 VERSION OSZ 2 LENGTH MEMORY 3 DATA WIDTH 4 RMZAHL KANÄLE	[Disp]			Version OSZ Sub1 Version Sub2 Memory size Sub3 Data width Sub4 Number of channels	
C0742	LENGTH OF DB	[Disp]			Data block length of OSC	
C0743	READ DB	[Disp]			Data block reading of a 8 byte data block	
C0744	SPEICHERGRÖSSE	2048	512 0 1024 1 1536 2 2048 3 3072 4 4096 5 8192 6		Memory capacity must be adapted to the measuring task	
C0749	1 INDEX ABBRUCH 2 INDEX TRIGGER 3 INDEX ENDE				Information about storing measured values	




Appendix

Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
C0750	<i>Vp DENOM</i>	16	1 2 4 8 16 32 64 128 256 512 1024 2048 4096 8192 16384	Gain = 1 Gain = 1/2 Gain = 1/4 Gain = 1/8 Gain = 1/16 Gain = 1/32 Gain = 1/64 Gain = 1/128 Gain = 1/256 Gain = 1/512 Gain = 1/1024 Gain = 1/2048 Gain = 1/4096 Gain = 1/8192 Gain = 1/16384	DFRFG1 Vp denominator position Denominator gain of position controller of DFRFG1	
C0751	<i>DFRFG1 TIR</i>	1.000	0.001	{0.001 s}	999.900	DFRFG1 Tir (acceleration time)
C0752	<i>MAX SPEED</i>	3000	1	{1 rpm}	16000	DFRFG1 max. speed Maximum make up speed
C0753	<i>DFRFG1 QSP</i>	0.000	0.000	{0.001 s}	999.900	Deceleration time T_{if} for QSP of DFRFG1
C0754	<i>PH ERROR</i>	*	10	{1 inc}	2000000000	Contouring error of DFRFG1 → 2000000000 • 1 turn = 65535 inc
C0755	<i>SYN WINDOW</i>	100	0	{1 inc}	65535	Synchronization window of DFRFG1
C0756	<i>OFFSET</i>	0	-1*10 ⁹	{1 inc}	1*10 ⁹	Offset of DFRFG1
C0757	<i>FUNCTION</i>	0	0 1	no TP start with TP start		Function of DFRFG1
[C0758]	<i>#n</i>	1000	FIXEDPHI-0		→ Selection list 4	Configuration phase input of DFRFG1
[C0759]	<i>QSP</i>	1000	FIXED0		→ Selection list 2	Configuration digital input (triggering QSP) of DFRFG1
[C0760]	<i>STOP</i>	1000	FIXED0		→ Selection list 2	Configuration digital input (ramp generator stop) of DFRFG1
[C0761]	<i>RESET</i>	1000	FIXED0		→ Selection list 2	Configuration digital input (reset integrators) of DFRFG1
C0764	1 <i>QSP</i> 2 <i>STOP</i> 3 <i>RESET</i>					Digital input signals of DFRFG1
C0765	<i>#n</i>		-32767	{1 rpm}	32767	Absolute analog input signal of DFRFG1
C0766	<i>DREHRICHTUNG</i>	1	1 2 3	cw/ccw cw cww		Direction of rotation Direction of rotation (cw/ccw) Direction of rotation (cw) Direction of rotation (ccw)
[C0770]	<i>D</i>	1000	FIXED0		→ Selection list 2	Configuration data input of FLIP1
[C0771]	<i>cLK</i>	1000	FIXED0		→ Selection list 2	Configuration clock input of FLIP1
[C0772]	<i>cLR</i>	1000	FIXED0		→ Selection list 2	Configuration reset input of FLIP1
C0773	1 <i>D</i> 2 <i>CLK</i> 3 <i>cLR</i>					Digital input signals of FLIP1
[C0775]	<i>D</i>	1000	FIXED0		→ Selection list 2	Configuration data input of FLIP2
[C0776]	<i>cLK</i>	1000	FIXED0		→ Selection list 2	Configuration clock input of FLIP2
[C0777]	<i>cLR</i>	1000	FIXED0		→ Selection list 2	Configuration reset input of FLIP2
C0778	1 <i>D</i> 2 <i>CLK</i> 3 <i>cLR</i>					Digital input signals of FLIP2

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
[C0780]	<i>N</i>	1000	AIN1-OUT → Selection list 1	Configuration main setpoint input of NSET [10-58]
[C0781]	<i>N-INV</i>	1000	CW/CCW/Q-CW/CCW → Selection list 2	Configuration main setpoint inversion of NSET [10-58]
[C0782]	<i>NADD</i>	1000	ASW1-OUT → Selection list 1	Configuration additional setpoint input of NSET [10-58]
[C0783]	<i>NADD-INV</i>	1000	FIXED0 → Selection list 2	Configuration additional setpoint inversion of NSET [10-58]
[C0784]	<i>cINH-VRL</i>	1000	MCTRL-NACT → Selection list 1	Configuration output signal with controller inhibit of NSET [10-58]
[C0785]	<i>SET</i>	1000	MCTRL-NSET2 → Selection list 1	Configuration ramp generator of NSET [10-58]
[C0786]	<i>LORD</i>	1000	MCTRL-QSP-OUT → Selection list 2	Configuration digital input (load ramp generator) of NSET [10-58]
[C0787]	1 <i>JOG*1</i> 2 <i>JOG*2</i> 3 <i>JOG*4</i> 4 <i>JOG*8</i>	1000 1000 1000 1000	DIGIN3 FIXED0 FIXED0 FIXED0 → Selection list 2	Configuration JOG selection and JOG activation of NSET • Binary interpretation [10-58]
[C0788]	1 <i>T1*1</i> 2 <i>T1*2</i> 3 <i>T1*4</i> 4 <i>T1*8</i>	1000 1000 1000 1000	FIXED0 FIXED0 FIXED0 FIXED0 → Selection list 2	Configuration T1 selection and T1 activation of NSET • Binary interpretation • T1r and T1f pairs are identical [10-58]
[C0789]	<i>RFG-D</i>	1000	FIXED0 → Selection list 2	Configuration digital input (ramp generator 0) of NSET [10-58]
[C0790]	<i>RFG-STOP</i>	1000	FIXED0 → Selection list 2	Configuration digital input (ramp generator stop) of NSET [10-58]
C0798	1 <i>cINH-VRL</i> 2 <i>SET</i>		-199.99 {0.01 %} 199.99	Analog input signals of NSET
C0799	1 <i>N-INV</i> 2 <i>NADD-INV</i> 3 <i>LORD</i> 4 <i>JOG*1</i> 5 <i>JOG*2</i> 6 <i>JOG*4</i> 7 <i>JOG*8</i> 8 <i>T1*1</i> 9 <i>T1*2</i> 10 <i>T1*4</i> 11 <i>T1*8</i> 12 <i>DIS RFG-D</i> 13 <i>RFG-STOP</i>			Digital input signals of NSET
[C0800]	<i>SET</i>	1000	FIXED0% → Selection list 1	Configuration setpoint input of process controller PCTRL1 [10-58]
[C0801]	<i>Rct</i>	1000	FIXED0% → Selection list 1	Configuration actual value input of PCTRL1 [10-58]
[C0802]	<i>INFLU</i>	1000	FIXED0% → Selection list 1	Configuration evaluation input of PCTRL1 [10-58]
[C0803]	<i>RDRPct</i>	1000	FIXED0% → Selection list 1	Configuration adaptation input of PCTRL1 [10-58]
[C0804]	<i>INRct</i>	1000	FIXED0 → Selection list 2	Configuration deactivation input of PCTRL1 [10-58]
[C0805]	<i>I-OFF</i>	1000	FIXED0 → Selection list 2	Configuration digital input (switch off I-component) of PCTRL1 [10-58]
C0808	1 <i>SET</i> 2 <i>Rct</i> 3 <i>INFLU</i> 4 <i>RDRPct</i>		-199.99 {0.01 %} 199.99	Analog input signals of PCTRL1




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0809 1 2	#NRct #OFF			Digital input signals of PCTRL1
[C0810] 1 2	/I /I	1000 1000	AIN2-OUT FIXED0%	→ Selection list 1 Configuration analog inputs of analog switch ASW1
[C0811]	SEt	1000	FIXED0	→ Selection list 2 Configuration digital input of ASW1
C0812 1 2	/I /I		-199.99 {0.01 %} 199.99	Analog input signals of ASW1
C0813	SEt			Digital input signal of ASW1
[C0815] 1 2	/I /I	1000 1000	FIXED0% FIXED0%	→ Selection list 1 Configuration analog inputs of analog switch ASW2
[C0816]	SEt	1000	FIXED0	→ Selection list 2 Configuration digital input of ASW2
C0817 1 2	/I /I		-199.99 {0.01 %} 199.99	Analog input signals of ASW2
C0818	SEt			Digital input signal of ASW2
[C0820] 1 2 3	/I /I /I	1000 1000 1000	FIXED0 FIXED0 FIXED0	→ Selection list 2 Configuration digital inputs of the AND element AND1
C0821 1 2 3	/I /I /I			Digital input signals of AND1
[C0822] 1 2 3	/I /I /I	1000 1000 1000	FIXED0 FIXED0 FIXED0	→ Selection list 2 Configuration digital inputs of the AND element AND2
C0823 1 2 3	/I /I /I			Digital input signals of AND2
[C0824] 1 2 3	/I /I /I	1000 1000 1000	FIXED0 FIXED0 FIXED0	→ Selection list 2 Configuration digital inputs of the AND element AND3
C0825 1 2 3	/I /I /I			Digital input signals of AND3
[C0826] 1 2 3	/I /I /I	1000 1000 1000	FIXED0 FIXED0 FIXED0	→ Selection list 2 Configuration digital inputs of the AND element AND4
C0827 1 2 3	/I /I /I	[Disp]		Digital input signals of AND4
[C0828] 1 2 3	/I /I /I	1000 1000 1000	FIXED0 FIXED0 FIXED0	→ Selection list 2 Configuration digital inputs of the AND element AND5

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0829 1 //N 2 //N 3 //N		[Disp]		Digital input signals of AND5
[C0830] 1 //N 2 //N 3 //N		1000	FIXED0	→ Selection list 2 Configuration digital inputs of the OR element OR1
C0831 1 //N 2 //N 3 //N		[Disp]		Digital input signals of OR1
[C0832] 1 //N 2 //N 3 //N		1000	FIXED0	→ Selection list 2 Configuration digital inputs of the OR element OR2
C0833 1 //N 2 //N 3 //N		[Disp]		Digital input signals of OR2
[C0834] 1 //N 2 //N 3 //N		1000	FIXED0	→ Selection list 2 Configuration digital inputs of the OR element OR3
C0835 1 //N 2 //N 3 //N		[Disp]		Digital input signals of OR3
[C0836] 1 //N 2 //N 3 //N		1000	FIXED0	→ Selection list 2 Configuration digital inputs of the OR element OR4
C0837 1 //N 2 //N 3 //N		[Disp]		Digital input signals of OR4
[C0838] 1 //N 2 //N 3 //N		1000	FIXED0	→ Selection list 2 Configuration digital inputs of the OR element OR5
C0839 1 //N 2 //N 3 //N		[Disp]		Digital input signals of OR5
[C0840] //N	1000	FIXED0	→ Selection list 2	Configuration digital input of the digital NOT element NOT1
C0841 //N	[Disp]			Digital input signal of NOT1
[C0842] //N	1000	FIXED0	→ Selection list 2	Configuration digital input of the digital NOT element NOT2
C0843 //N	[Disp]			Digital input signal of NOT2
[C0844] //N	1000	FIXED0	→ Selection list 2	Configuration digital input of the digital NOT element NOT3
C0845 //N	[Disp]			Digital input signal of NOT3
[C0846] //N	1000	FIXED0	→ Selection list 2	Configuration digital input of the digital NOT element NOT4
C0847 //N	[Disp]			Digital input signal of NOT4




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
[C0848]	I/Y	1000	FIXED0 → Selection list 2	Configuration digital input of the digital NOT element NOT5 █ 10-58
C0849	I/Y	Disp		Digital input signal of NOT5
[C0850] 1 2 3	OUT.U1 OUT.U2 OUT.U3	1000 1000 1000	FIXED0% FIXED0% FIXED0%	→ Selection list 1 Configuration process output words for automation interface AIF (X1) █ 10-58
[C0851] 1	OUT.D1	1000	FIXED0INC → Selection list 3	Configuration 32-bit phase information █ 10-58
C0852	TYPE OUT.U2	0	0 Analog 1 digital 0-15 2 D1: low phase 3 D2: high phase	Configuration process output word 2 for automation interface AIF (X1)
C0853	TYPE OUT.U3	0	0 Analog 1 digital 16-31 2 high phase	Configuration process output word 3 for automation interface AIF (X1)
C0854	TYPE OUT.U1	0	0 Analog 3 D2: low phase	Configuration process output word 1 for automation interface AIF (X1)
C0855	I/Y (0-15) I/Y (16-31)	Disp	0 FFFF	Process input words hexadecimal for automation interface X1
C0856 1 2 3	IN.U1 IN.U2 IN.U3	Disp	-199.99 {0.01%} 199.99	Process input words decimal • 100% = 16384
C0857	I/Y.D1	Disp	-2147483648 {1} 2147483647	32-bit phase information
C0858 1 2 3	OUT.U1 OUT.U2 OUT.U3	Disp	-199.99 {0.01 %} 199.99	Process output words • 100% = 16384
C0859	OUT.D1	Disp	-2147483648 {1} 2147483647	32-bit phase information
[C0860] 1 2 3 4 5 6 7 8 9 10 11	OUT1.U1 OUT1.U2 OUT1.U3 OUT2.U1 OUT2.U2 OUT2.U3 OUT2.U4 OUT3.U1 OUT3.U2 OUT3.U3 OUT3.U4	5001 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000	FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0% FIXED0%	→ Selection list 1 Configuration process output words for system bus output blocks (CAN) █ 10-58
[C0861] 1 2 3	OUT1.D1 OUT2.D1 OUT3.D1	30021 1000 1000	FIXED0INC FIXED0INC FIXED0INC → Selection list 3	Configuration 32-bit phase information for system bus output blocks (CAN) █ 10-58
C0863 1 2 3 4 5 6	INI DIG0 INI DIG16 IN2 DIG0 IN2 DIG16 IN3 DIG0 IN3 DIG16	Disp	0 FFFF	Process input words hexadecimal for system bus (CAN)
C0864 1 2 3	TYPE OUT1.U2 TYPE OUT2.U1 TYPE OUT3.U1	0 0 0	0 analog sign 1 digital 0-15 2 low phase	Configuration process output words for system bus (CAN)

Appendix




Code	LCD	Possible settings		IMPORTANT	
		Lenze	Choice		
C0865 1 2 3	TYPE OUT1.W3 TYPE OUT2.W2 TYPE OUT3.W2	0 0 0	0 analog sign 1 digital 16-31 2 high phase	Configuration process output words for system bus (CAN)	
C0866 1 2 3 4 5 6 7 8 9 10 11	IN1.W1 IN1.W2 IN1.W3 IN2.W1 IN2.W2 IN2.W3 IN2.W4 IN3.W1 IN3.W2 IN3.W3 IN3.W4	[Disp]	-199.99 {0.01 %}	199.99	Process input words for system bus (CAN) • 100% = 16384
C0867 1 2 3	IN1.D1 IN2.D1 IN3.D1	[Disp]	-2147483648 {1}	2147483647	32-bit phase information for system bus (CAN)
C0868 1 2 3 4 5 6 7 8 9 10 11	OUT1.W1 OUT1.W2 OUT1.W3 OUT2.W1 OUT2.W2 OUT2.W3 OUT2.W4 OUT3.W1 OUT3.W2 OUT3.W3 OUT3.W4	[Disp]	-199.99 {0.01 %}	199.99	Process output words system bus (CAN) • 100% = 16384
C0869 1 2 3	OUT1.D1 OUT2.D1 OUT3.D1	[Disp]	-2147483648 {1}	2147483647	32-bit phase information for system bus (CAN)
[C0870] 1 2	CINH CINH	1000 1000	FIXED0 FIXED0	→ Selection list 2	Configuration digital inputs (inhibit controller) of DCTRL
[C0871]	TRIP-SET	1000	DIGIN 4	→ Selection list 2	Configuration digital input (TRIP-Set) of DCTRL
[C0876]	TRIP-RES	55	DIGIN 5	→ Selection list 2	Configuration digital input (TRIP-Reset) of DCTRL
C0878 1 2 3 4	CINH1 CINH2 TRIP-SET TRIP-RES	[Disp]			Digital input signals of DCTRL
C0879 1 2 3	RESET C135 RESET RIF RESET CRM	0	0 no reset 1 reset	Reset control words • C0879 = 1 performs one reset	
[C0885]	R	1000	DIGIN 1	→ Selection list 2	Configuration digital input (CW rotation) of CW/CCW/Q
[C0886]	L	1000	DIGIN 2	→ Selection list 2	Configuration digital input (CCW rotation) of CW/CCW/Q




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C0889 1 2	R L	[Disp]		Digital input signals of CW/CCW/Q
[C0890] N-SEE	30020	NSET-NOUT	→ Selection list 1	Configuration speed setpoint input motor control of MCTRL
[C0891] M-ADD	30021	FIXED0%	→ Selection list 1	Configuration torque setpoint input of MCTRL
[C0892] LO-M-LIM	5700	ANEGL1-OUT	→ Selection list 1	Configuration lower torque limit of MCTRL
[C0893] HI-M-LIM	19523	FCODE-472/3	→ Selection list 1	Configuration upper torque limit of MCTRL
[C0894] PHI-SEE	30020	FIXED0INC	→ Selection list 3	Configuration rotor position setpoint of MCTRL
[C0895] PHI-LIM	19526	FIXED100%	→ Selection list 1	Configuration phase controller limit of MCTRL
[C0896] N2-LIM	1000	FIXED0%	→ Selection list 1	Configuration second speed limitation of MCTRL
[C0897] PHI-ON	1001	FIXED0	→ Selection list 2	Configuration switch-on signal phase controller of MCTRL
[C0898] FLD-WERK	1006	FIXED100%	→ Selection list 1	Configuration signal for field weakening of MCTRL
[C0899] N/M-SWE	1000	FIXED0	→ Selection list 2	Configuration changeover between speed control and torque control MCTRL
[C0900] QSP	1000	CW/CCW/Q-QSP	→ Selection list 2	Configuration control signal to activate QSP of MCTRL
[C0901] I-SEE	1000	FIXED0%	→ Selection list 1	Configuration load I-component of the MCTRL speed controller
[C0902] I-LORD	1000	FIXED0	→ Selection list 2	Configuration release signal to load the I-component of the MCTRL speed controller
[C0903] P-ADAPT	1006	FIXED0	→ Selection list 1	Configuration adaptation phase controller
C0906 1 2 3 4 5 6 7 8	N-SEE M-ADD LO-M-LIM HI-M-LIM PHI-LIM N2-LIM FLD-WERK I-SEE	[Disp]	-199.99 {0.01 %} 199.99	Analog input signals of MCTRL
C0907 1 2 3 4	PHI-ON N/M-SWE QSP I-LORD	[Disp]		Digital input signals of MCTRL
C0908 PHI-SEE	[Disp]	-2147483647 {1 inc} 2147483647	Set phase signal of MCTRL • 1 turn = 65536 inc	
C0909 SPEED LIMIT	1 2 3	1 +/- 175 % 2 0 .. +175 % 3 -175 .. 0 %	Speed limitation for the speed setpoint of MCTRL	
C0940 NUMERATOR	1	-32767 {1}	32767	CONV1 numerator Numerator for CONV1
C0941 DENOMINATOR	1	1 {1}	32767	CONV1 denominator Denominator for CONV1
[C0942] IN	1000	FIXED0%	→ Selection list 1	Configuration analog input CONV1
C0943 IN	[Disp]	-199.99 {0.01 %} 199.99	Relative analog input signal of CONV1	
C0945 NUMERATOR	1	-32767 {1}	32767	CONV2 numerator Numerator for CONV2

Appendix




Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C0946	DENOMINATOR	1	1	{1}	32767	CONV2 denominator Denominator for CONV2
[C0947]	I/N	1000	FIXED0%		→ Selection list 1	Configuration analog input CONV2
C0948	I/N	Disp	-199.99	{0.01 %}	199.99	Relative analog input signal of CONV2
C0950	NUMERATOR	1	-32767	{1}	32767	CONV3 numerator Numerator for CONV3
C0951	DENOMINATOR	1	1	{1}	32767	CONV3 denominator Denominator for CONV3
[C0952]	I/N	1000	FIXEDPHIO		→ Selection list 4	Configuration analog input CONV3
C0953	I/N	Disp	-32767	{1 rpm}	32767	Absolute analog input signal of CONV3
C0955	NUMERATOR	1	-32767	{1}	32767	CONV4 numerator Numerator for CONV4
C0956	DENOMINATOR	1	1	{1}	32767	CONV4 denominator Denominator for CONV4
[C0957]	I/N	1000	FIXEDPHIO		→ Selection list 4	Configuration analog input CONV4
C0958	I/N	Disp	-32767	{1 rpm}	32767	Absolute analog input signal of CONV4
C0960	FUNCTION	1	1 2 3	Function1 Function2 Function3		Characteristic CURVE1-IN
C0961	y0	0.00	0.00	{0.01 %}	199.99	Ordinate of the pair ($x=0\%/y0$) of CURVE1
C0962	y1	50.00	0.00	{0.01 %}	199.99	Ordinate of the pair ($x1/y1$) of CURVE1
C0963	y2	75.00	0.00	{0.01 %}	199.99	Ordinate of the pair ($x2/y2$) of CURVE1
C0964	y100	100.00	0.00	{0.01 %}	199.99	Ordinate of the pair ($x=100\%/y100$) of CURVE1
C0965	x1	50.00	0.01	{0.01 %}	100.00	Abscissa of the pair ($x1/y1$) of CURVE1
C0966	x2	75.00	0.01	{0.01 %}	99.00	Abscissa of the pair ($x2/y2$) of CURVE1
[C0967]	I/N	1000	FIXED0%		→ Selection list 1	Configuration characteristic CURVE1-IN
C0968	I/N	Disp	-199.99	{0.01 %}	199.99	Display of CURVE1-IN
[C0990]	I/N	1000	FIXEDPHIO		→ Selection list 4	Configuration input phase integrator PHINT1
[C0991]	RESET	1000	FIXED0		→ Selection list 2	Configuration reset input of PHINT1
C0992	I/N	Disp	-32767	{1}	32767	Input signal of PHINT1
C0993	RESET	Disp				Digital input signal of PHINT1
C0995	DIVISION	0	-31	{1}	31	Factor
[C0996]	I/N	1000	FIXED0INC		→ Auswahliste 3	Configuration input phase division PHDIV1
C0997	(C0996)	Disp	-2147483647	{1}	2147483647	
C1000	DIVISION	1	0	{1}	31	Factor
[C1001]	I/N	1000	FIXED0INC		→ Selection list 3	Configuration input of CONVPHA1
C1002	I/N	Disp	-2147483647	{1}	2147483647	Input signal of CONVPHA1
C1010	FUNCTION	1	0 1 2 3 14 21 22	OUT = IN1 IN1 + IN2 IN1 - IN2 IN1 * IN2 IN1 / IN2 IN1 + IN2 (no limit) IN1 - IN2 (no limit)		Function of ARITPH1
[C1011]	1 I/N 2 I/N	1000 1000	FIXED0INC FIXED0INC		→ Selection list 3	Configuration inputs ARITPH1
C1012	1 I/N 2 I/N	Disp	-2147483647	{1}	2147483647	Input signals ARITPH1




Appendix

Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C1020	FUNCTION	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 14 IN1 / IN2			Function of ARITPH2
[C1021] 1 2	/IN	1000 1000	100 {1} 25103 → Selection list 3			Configuration inputs ARITPH2 10-58
C1022 1 2	/IN	Disp	-2147483647 {1} 2147483647			Input signals ARITPH2
C1025	FUNCTION	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 14 IN1 / IN2			Function of ARITPH3
[C1026] 1 2	/IN	1000 1000	100 {1} 25103 → Selection list 3			Configuration inputs ARITPH3 10-58
C1027 1 2	/IN	Disp	-2147483648 {1} 2147483647			Input signals ARITPH3
C1090	OUTPUT SIGNAL	Disp	-2147483648 {1} 2147483647			Output signal of FEVAN1
C1091	CODE	141	2 {1} 2000			Code for FEVAN1
C1092	Subcode	0	0 {1} 255			Subcode for FEVAN1
C1093	NUMERATOR	1.0000	0.0001 {0.0001} 100000.0000			Numerator for FEVAN1
C1094	DENOMINATOR	0.0001	0.0001 {1} 100000.0000			Denominator for FEVAN1
C1095	OFFSET	0	0 {1} 1000000000			Offset for FEVAN1
[C1096]	/IN	1000	FIXED0% → Selection list 1			Configuration analog input of FEVAN1 10-58
[C1097] 1 2 3	LORD BUSY-IN FAIL-IN	1000 1000 1000	FIXED0 → Selection list 2			Configuration digital inputs of FEVAN1 10-58
C1098	/IN	Disp	-32768 {1} 32767			Analog input signal of FEVAN1
C1099 1 2 3	LORD BUSY-IN FAIL-IN	Disp				Digital input signal of FEVAN1
C1100	FUNCTION	1	1 Return 2 Hold			Function of FCNT1
[C1101] 1 2	LD-VAL CMP-VAL	1000 1000	FIXED0% FIXED0% → Selection list 1			Configuration analog inputs of FCNT1 10-58
[C1102] 1 2 3	CLKUP CLKDOWN LORD	1000 1000 1000	FIXED0 FIXED0 FIXED0 → Selection list 2			Configuration digital inputs of FCNT1 10-58
C1103 1 2	LD-VAL CMP-VAL	Disp	-32768 {1} 32768			Analog input signals of FCNT1
C1104 1 2 3	CLKUP CLKDOWN LORD	Disp				Digital input signals of FCNT1
C1105	FUNCTION	1	1 Return 2 Hold			Function of FCNT2

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
[C1106]					
1	LD-VRL	1000	50	{1}	25104
2	CMP-VRL	1000		→ Selection list 1	Configuration analog inputs of FCNT2
[C1107]					
1	CLKUP	1000	50	{1}	25132
2	CLKDOWN	1000		→ Selection list 1	Configuration digital inputs of FCNT2
3	LORD	1000			
C1108					
1	LD-VRL		-32767	{1}	32767
2	CMP-VRL				Analog input signals of FCNT2
C1109					
1	CLKUP		0		1
2	CLKDOWN				Digital input signals of FCNT2
3	LORD				
C1110	FUNCTION	1	1	Return	
			2	Hold	Function of FCNT3
[C1111]					
1	LD-VRL	1000	50	{1}	25104
2	CMP-VRL	1000		→ Selection list 1	Configuration analog inputs of FCNT3
[C1112]					
1	CLKUP	1000	51	{1}	25132
2	CLKDOWN	1000		→ Selection list 2	Configuration digital inputs of FCNT3
3	LORD	1000			
C1113					
1	LD-VRL		-32767	{1}	32767
2	CMP-VRL				Analog input signals of FCNT3
C1114					
1	CLKUP		0		1
2	CLKDOWN				Digital input signals of FCNT3
3	LORD				
C1120	SYNC MODE	2	0	off	
			1	CAN sync	Function of SYNC1
			2	Terminal sync	
[C1121]		2	0	{1 ms}	13
1	SYNC CYCLE				SYNC1
2	INTERPOL. CYCL				Definition of the cycle time of the sync signals (in the slave) • for SYSTEM BUS only
C1122	SYNC TIME	0.460	0.000	{0.001 ms}	10.000
					Phase shift between the CAN sync and internal control program cycle • for SYSTEM BUS only • depends on baud rate and bus load
C1123					
1	PHASESHIFT	0	-0.450	{0.001 ms}	0.450
2	SYNC WINDOW	0	-0.450	{0.001 ms}	0.450
					• Phase shifting between terminal sync and internal control program cycle • only for terminal sync
					Synchronization window for the synchronisation edge of the terminal sync (LOW/HIGH signal) • only for terminal sync • activated when the sync start window is quit
[C1124]	IN1	1000	FIXED0INC	→ Selection list 3	Configuration input 1 of SYNC1
[C1125]	IN2	1000	FIXED0INC	→ Selection list 3	Configuration input 2 of SYNC1




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
[C1126]	I/Y3	1000	FIXED0INC → Selection list 3		Configuration input 3 of SYNC1
C1127	I/Y1	[Disp]	-2147483647 {1} 2147483647		Input signal 1 of SYNC1
C1128	I/Y2	[Disp]	-2147483647 {1} 2147483647		Input signal 2 of SYNC1
C1129	I/Y3	[Disp]	-2147483647 {1} 2147483647		Input signal 3 of SYNC1
[C1130] 1 2	NUM DEN	1000 1000	50 {1} 25104 → Selection list 1		CFG: CONVPHPH2-NUM
[C1131]	ACT	1000	51 {1} 25132 → Selection list 2		CFG: CONVPHPH2-ACT
[C1132]	I/Y	1000	50 {1} 25104 → Selection list 3		CFG: CONVPHPH2-IN
C1135 1 2	NUM DEN	[Disp]	-32767 {1} 32767		DIS: CONVPHPH2-..
C1136	ACT	[Disp]	0 1		DIS: CONVPHPH2-ACT
C1137	I/Y	[Disp]	-2147483647 {1 incr} 2147483647		DIS: CONVPHPH2-IN
[C1160] 1 2	I/Y I/Y	1000 1000	FIXED0% FIXED0% → Selection list 1		Configuration analog inputs of ASW3
[C1161]	SET	1000	FIXED0 → Selection list 2		Configuration digital input of ASW3
C1162 1 2	I/Y I/Y	[Disp]	-199.99 {0.01 %} 199.99		Analog input signals of ASW3
C1163	SET	[Disp]			Digital input signal of ASW3
[C1165] 1 2	I/Y I/Y	1000 1000	FIXED0% FIXED0% → Selection list 1		Configuration analog inputs of ASW4
[C1166]	SET	1000	FIXED0 → Selection list 2		Configuration digital input of ASW4
C1167 1 2	I/Y I/Y	[Disp]	-199.99 {0.01 %} 199.99		Analog input signals of ASW4
C1168	SET	[Disp]			Digital input signal of ASW4
C1180	IDEN MODE	0	0 inactive 1 calculate 2 Identify 3 ident&calc.	Mode: control parameter identification not active Calculate control parameters from data set Identify only parameters Calculate only parameters for control system and control	
C1181	ID STABE	[Disp]	0 inactive 1 busy 2 Error: no calculation 3 Error: no identification 4 Error: C0057 small 5 Error: n <> 0 6 Error: RSP 7 Error: C1185 big 8 Error: overtime 9 Error: bad condition	Status: controller ident. Not active busy Fault	5-27 5-29

Appendix




Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
			10 11 12 99	wait for start motion wait for RSP Error: internal	Waiting for enable to start the movement Waiting for end of movement Waiting for controller inhibit for completion Internal error	
C1182	<i>PHI-ID PHASE</i>	100	0.5	{0.1 rev}	3000	phi max controller ident.
C1183	<i>N-ID MAX</i>	100	10	{1 %}	100	n max controller ident.
C1184	<i>M-ID MAX</i>	100	10	{1 %}	100	m max controller ident.
C1185	<i>M RISETIME</i>	100	10	{1 ms}	10000	M acceleration time
C1186	<i>OPIMIZE ID</i>	0	0 1	Optimum control Error		Optimisation: controller ident.
C1187	<i>INERIA</i>	0	0	{0.1 kg·cm²}	214000	Inertia
C1188	<i>FRICTION</i>	0	0	{1 %}	100	Friction load component (n-prop.)
C1190	<i>MODE PTC-SEL.</i>	0	0 1	standard Characterist.		motor PTC selection
C1191	<i>CHAR.: TEMP 1</i> 1 <i>CHAR.: TEMP 2</i> 2	100 150	0	{1 °C}	255	Characteristic: Temp. 1 Selection of PTC temperature characteristic
C1192	<i>CHAR.: OHM 1</i> 1 <i>CHAR.: OHM 2</i> 2	1670 2225	0	{1 Ω}	30000	Characteristic: resistor 1 Selection of resistance characteristic for PTC
[C1195]	<i>OUT.D2</i>	1000	FIXED0INC	→ Selection list 3		Configuration input phase signal of AIF
C1196	<i>OUT.D2</i>	[Disp]	-2147483647	{1}	2147483647	Input signal of AIF
C1197	<i>IN.D2</i>	[Disp]	-2147483647	{1}	2147483647	AIF-IN.D2
C1202	<i>RATIO NUM.</i>	1	1	{1}	65535	Gearbox factor numerator
C1203	<i>RATIO DENUM.</i>	1	1	{1}	65535	Gearbox factor denominator
C1204	<i>FEED CONSTANTE</i>	1.0000	0.0001	{0.0001}	214000	Feed constant <ul style="list-style-type: none">Feed of the machine in units per revolution of the load side of the gearbox.
C1205	<i>POS. RESOLUE.</i>	[Disp]	0	{0.0001 incr/unit}	214000	Position resolution <ul style="list-style-type: none">The position resolution indicates the number of increments which resolves a unit determined by the user.
[C1206]	<i>SET POLARITY</i>	0	0 1	Not inverse Inverse		Polarity position setpoint <ul style="list-style-type: none">Reversal of the position direction
C1207	<i>FDBK RAL NUM</i> 1 <i>FDBK RAL DEN</i> 2	1 1	1	{1}	65335	Position encoder gearbox factor <ul style="list-style-type: none">Gearbox factor between motor and position encoder.Numerator/denominator corresponds to motor speed/encoder speed.Encoder to motor shaft: 1/1
C1208	<i>RAL POLARITY</i>	0	0 1	not inverse inverse		Polarity actual position <ul style="list-style-type: none">Inversion of the actual position, e.g. when using a separate position encoder behind the gearbox.
C1209	<i>REF END-POINT</i>	0	0 1 61 71 101	Ref-point Real-0 VTPOS-No 060 VTPOS-No 070 VTPOS-No 100		Homing end point <ul style="list-style-type: none">Point where the drive is to be positioned after homing
C1210	<i>POS. MODE</i>	0	0 1 2	Absolute Pos Relative Pos Abs.Pos/Store		Positioning mode <ul style="list-style-type: none">With "absolute positioning", relative as well as absolute positionings are possible. With "relative positioning" however, only relative positionings are possible.




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1211	S _E R _R E PS NO.	1	1 {1} 32	Start-PS no. <ul style="list-style-type: none">Program set no. at which the positioning program is processed after the edge at the "PRG-START" input.
C1212	R _c t. PS NO.	[Disp]	0 Prog. end 1 PS 01 2 PS 02 3 PS 03 ... 31 PS 31 32 PS 32	Actual PS no. <ul style="list-style-type: none">Display of the momentary program set no. or operating mode.
C1213	REF. MODE	0	0 + home 1 -home 2 + LIM,-home 3 -LIM,+ home 4 + MARK,-home 5 -MARK,+ home 6 + MARK,+ TP 7 -MARK,-TP 8 + TP 9 - TP 10 + LIM,-TP 11 -LIM,+ TP	Homing mode <ul style="list-style-type: none">Mode for homing (valid for manual mode and program homing).
C1214	REF TP-INPUT	4	1 TP-IN-E01 2 TP-IN-E02 3 TP-IN-E03 4 TP-IN-E04	Homing touch probe <ul style="list-style-type: none">Selection of the touch probe input terminal for homing acc. to modes 6...9. When using an incremental encoder, the TP input E04 is particularly suitable.
C1215 1 ... 4	T _P -TRANS T _P -TRANS	0 ... 0	0 + slope 1 -slope	TP input edge <ul style="list-style-type: none">Selection of the edge for the touch probe input terminals (valid for homing acc. to modes 6 to 9, TP positioning, TP storing).
C1216	V-REF2 R _c tIV.	0	0 inactive 1 active	Activation of 2nd homing speed
C1218 1 2	FOL _E OLERANCE FOL _E OLERANCE	4.0000 1.0000	0 {0.0001 units} 214000	Contouring error tolerance
C1220 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15	P _O S-TARGET P _O S-SETPOS P _O S-ACTPOS R _c t-FOLLOWERR ACTPOS ABS. REFMARK D-IMP R _c t-HOME OFS R _c t-HOME POS. R _c t. WAY R _c t. C1223 R _c t. C1224 R _c t. C1240 R _c t. C1250 R _c t. VNORM R _c t. ANORM	[Disp]	-214000 {0.0001 units} 214000	1 = Current position target 2 = Current position setpoint 3 = Current position 4 = Current contouring error 5 = Read absolute value 6 = Distance REF-MARK to zero pulse 7 = Current reference offset 8 = Current reference position 9 = Distance to be traversed 10 - 13 = Effective internal code value: C1223/C1224/C1240/C125010 (internal limitation possible: see chapter: Troubleshooting, "Message P18") 14 - 15 = Internal fault analysis value

Appendix




Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C1221						
1	POS-TARGET					
2	POS-SETPOS					
3	POS-RCTPOS					
4	Rct.FOLLOWERR					
5	RCTPOS Rb5.					
6	REFMARK D-IMP					
7	Rct.HOME OFFS					
8	Rct.HOME POS.					
9	Rct.WAY					
10	Rct.C1223					
11	Rct.C1224					
12	Rct.C1240					
13	Rct.C1250					
14	Rct.VNORM					
15	Rct.ANORM					
[C1223]	POS.LIMt+	16000	0	{0.0001 units}	214000	Position limit positive
[C1224]	POS.LIMt-	-16000	-214000	{0.0001 units}	0	Position limit negative
C1225	HOME OFFSET	0	-214000	{0.0001 units}	214000	Homing measure offset
C1227	HOME POSITION	0	-214000	{0.0001 units}	214000	Home position
C1240	V-MAX	50	0.0001	{0.0001units/s}	214000	v-max, maximum speed
C1241	V-HOMING 2	2	0.01	{0.01 %vmax}	100	Second homing speed
C1242	V-HOMING	5	0.01	{0.01 %vmax}	100	Homing speed
C1243	V-MANUAL	5	0.01	{0.01 %vmax}	100	Manual speed
C1245						
1	POS-VSET					
2	POS-VTRAV					
3	POS-VFINAL					
C1250	A-MAX	100	0.0001	{0.0001 units/s ² }	214000	a-max, maximum acceleration/deceleration
C1251	A-HOMING	10	0.01	{0.01 %amax}	100	Homing acceleration/deceleration
C1252	A-MANUAL	10	0.01	{0.01 %amax}	100	Manual acceleration/deceleration
C1253	A-CANCEL	100	0.01	{0.01 %amax}	100	PS-CANCEL delay
C1255						
1	POS-ASET					
2	POS-ACC					
3	POS-DEC					
C1256	S-RMP: JERK	1	0.064	{0.001 s}	10	S-ramp: jerk-max
C1257	S-RMP: FILTER	10	0	{1 rpm}	1000	S-ramp: PARAM-RD filter
C1260	MANUAL MODE	0	0	No stop		Manual mode
			1	With stop		
C1261	MANU-STEP-MO	0	0	{1}	104	Intermediate stop target (no. in VTPOS)
...		...				
16	MANU-STEP-MO	15				
C1280	POS.CONTROL	0	0	{1}	65535	Control word positioning




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1283	<i>POS. STATUS</i>	[Disp]	0 program mode 5 rdy to start 10 started 11 started-dig 12 started-rem 15 started-break 20 program end 25 stopped-dig 26 stopped-rem 30 STDBY mode 35 reset-dig 36 reset-rem 50 manual-dig 51 manual-rem 55 manu-neg-dig 56 manu-neg-rem 57 manu-pos-dig 58 manu-pos-rem 59 neg+pos activ 62 manu-ref-dig 63 manu-ref-rem 80 POS-LOOP-INH 85 POS-PSET-SWT	Positioning state Update only under following conditions: <ul style="list-style-type: none">• The power stage is supplied (DCTRL-RDY=1),• No error (DCTRL-TRIP=0, DCTRL-FAIL-QSP=0),• The drive is enabled (DCTRL-CINH=0)• No quick stop (QSP) active (MCTRL-QSP-OUT=0)• No manual operation active (POS-MANUAL=0, C1280.B4=0)
C1284	<i>HOMING-STATUS</i>	[Disp]	0 not REF-OK 1 REF-OK 5 homing by prg 10 manu-ref-dig 11 manu-ref-1280 20 abs encoder 25 ext abs encod	Homing status
C1285 1 2 3 4	<i>MONIT P01</i> <i>MONIT P02</i> <i>MONIT P04</i> <i>MONIT P05</i>	4	0 Trip 4 Fail-QSP	Conf. P01 (limit switch negative)
C1286 1 2	<i>MONIT P14</i> <i>MONIT P15</i>	4 3	0 Trip 2 Warn 3 Off 4 Fail-QSP	Conf. P14 (contouring error 1)
C1287 1	<i>MONIT P06</i>	4	0 Trip 4 Fail-QSP	Conf. P06 (no reference)
C1288 1	<i>MONIT P12</i>	4	0 Trip 4 Fail-QSP	Conf. P12 (encoder range)
C1289 1 2	<i>MONIT P17</i> <i>MONIT P18</i>	4 2	0 Trip 2 Warn 3 Off 4 Fail-QSP	Conf. P17 TP control P18 display range limited/exceeded (Position limits, speeds)
C1290 1	<i>MONIT P16</i>	4	0 Trip 2 Warn 3 Off 4 Fail-QSP	Conf. P16 (Sync error)
C1291 1 2 3	<i>MONIT P07</i> <i>MONIT P08</i> <i>MONIT P09</i>	4	0 Trip 4 Fail-QSP	Conf. P07 (PS mode error)

Appendix




Code	LCD	Possible settings		IMPORTANT		
		Lenze	Choice			
C1298	P18-DIAGNOSIS	[Disp]	0 1 2 3 4 5 6	No P18 C1223 C1224 C1240 C1250 Vnorm Anorm	P18 Diagnostics: Display of the code which led to an internal limitation.	
C1299 1 ... 32	Rct. CNT Rct. CNT	[Disp]	0	{1 pcs}	65535	Actual state of piece counter
C1301 1 ... 60	VTPOS-VALUE VTPOS-VALUE	0 ...	-214000 0	{0.0001 units}	214000	Input VTPOS position value
C1302 1 2 ... 10 ... 30	VTVEL-VALUE VTVEL-VALUE ... VTVEL-VALUE ... VTVEL-VALUE	10 20 ... 100 ... 100	0.01	{0.01 %vmax}	100	Input VTVEL speeds
C1303 1 2 ... 10 ... 30	VTACC-VALUE VTACC-VALUE ... VTACC-VALUE ... VTACC-VALUE	10 20 ... 100 ... 100	0.01	{0.01 %amax}	100	Input VTACC accel./decelerations
C1304 1 ... 30	VTPCS-VALUE VTPCS-VALUE	1 ...	1 30	{1 pcs}	65535	Input VTPCS piece numbers
C1305 1 ... 30	VTTIME-VALUE VTTIME-VALUE	1 ...	0 30	{0.001 s}	65.535	Input VTTIME waiting times
C1311 1 ... 32	PS MODE PS MODE	0 ...	0 1 2 3 4 5 6 7 8 9 11 12 13 14 16 30 31 32 33 34	No pos funct. Absolute PS Relative PS Homing Set home pos. Set target Abs.TP-PS E01 Abs.TP-PS E02 Abs.TP-PS E03 Abs.TP-PS E04 Rel.TP-PS E01 Rel.TP-PS E02 Rel.TP-PS E03 Rel.TP-PS E04 Set Ref.Pos. STDBY STDBY-TP1 STDBY-TP2 STDBY-TP3 STDBY-TP4	Program set mode	




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1312 1 ... 32	TARGET-NO ... TARGET-NO	0 ... 0	{1} 104 → Selection list 11	PS position target (no. in VTPOS) □ 10-58
C1313 1 ... 32	V-TRAVEL-NO ... V-TRAVEL-NO	0 ... 0	{1} 34 → Selection list 14	PS positioning speed (no. in VTVEL) □ 10-58
C1314 1 ... 32	RCC-NO ... RCC-NO	0 ... 0	{1} 34 → Selection list 16	PS acceleration (no. in VTACC) □ 10-58
C1315 1 ... 32	DCC-NO ... DCC-NO	0 ... 0	{1} 34 → Selection list 16	PS deceleration (no. in VTACC) □ 10-58
C1316 1 ... 32	V-FINAL-NO ... V-FINAL-NO	0 ... 0	{1} 34 → Selection list 15	PS final speed (no. in VTVEL) □ 10-58
C1318 1 ... 32	WAIT-PFI-NO ... WAIT-PFI-NO	0 ... 0	0 inactive 1 PFI 01 2 PFI 02 ... 32 PFI 32	Wait for PFI (no. of the PFI)
C1319 1 ... 32	WAIT-LEVEL ... WAIT-LEVEL	0 ... 0	0 0-Level 1 1-Level	Level for Wait-PFI
C1320 1 ... 32	PFO1-NO ... PFO1-NO	0 ... 0	0 inactive 1 PFO 01 2 PFO 02 3 PFO 03 ... 31 PFO 31 32 PFO 32 100 All PFO 101 PFO 01..08 102 PFO 09..16 103 PFO 17..24 104 PFO 25..32	First switching PFO (no. of the PFO) <ul style="list-style-type: none">Program function output 1: Set an output before positioning
C1321 1 ... 32	PFO1-LEVEL ... PFO1-LEVEL	0 ... 0	0 0-Level 1 1-Level	First switching PFO level
C1322 1 ... 32	PFO2-NO ... PFO2-NO	0 ... 0	0 inactive 1 PFO 01 2 PFO 02 3 PFO 03 ... 31 PFO 31 32 PFO 32 100 All PFO 101 PFO 01..08 102 PFO 09..16 103 PFO 17..24 104 PFO 25..32	Second switching PFO (no. of the PFO) <ul style="list-style-type: none">Program function output 2: Set an output after positioning

Appendix




Code	LCD	Possible settings		IMPORTANT	
		Lenze	Choice		
C1323 1 ... 32	PFO2-LEVEL	0 ... 0	0- 1-Level		Second switching PFO level
C1324 1 ... 32	WATETIME-NO	0 ... 0	{1} → Selection list 18	34	Waiting time (no. in VTTIME) 10-58
C1325 1 ... 32	JMPI-PFI-NO	0 ... 0	inactive PFI 01 PFI 02 ... PFI 32		JMP1: PFI no. • Number of a PFI for branch 1.
C1326 1 ... 32	JMPI-LEVEL	0 ... 0	0- 1-Level		JMP1: PFI level • Level of a PFI for branch 1.
C1327 1 ... 32	JMPI-PS	0 ... 0	{1} → Selection list 19	32	JMP1: PS no. • Branch 1 to program set no. (PS). Input of the program set no. 10-58
C1328 1 ... 32	JMP-PCS-NO	0 ... 0	{1} → Selection list 17	34	JMP-PCS no.: Set piece number (no. in VTPCS) • Selection of a set piece number from VTPCS for the piece number repeat function. 10-58
C1329 1 ... 32	JMP-PCS-PS	0 ... 0	{1} → Selection list 19	32	JMP-PCS-PS: PS no. • Branch PCS if selected piece number from VTPCS was not yet reached. Input of the program set no. 10-58
C1330 1 ... 32	TP WINDOW	0 ... 0	{1} → Selection list 12	104	TP window (no. in VTPOS) • Selection of a range window for TP. Within this range, the TP is "activated". 10-58
C1331 1 ... 32	TP DISTANCE	0 ... 0	{1} → Selection list 13	104	TP final distance (no. in VTPOS) • Selection of a final distance from VTPOS for TP. 10-58
C1333 1 ... 32	JMP-TP-PS	0 ... 0	{1} → Selection list 19	32	JMP-TP: PS no. • Branch TP if no touch probe has occurred before the position target (1312) was reached. Input of the program set no. 10-58
C1334 1 ... 32	JMP2-PFI-NO	0 ... 0	inactive PFI 01 PFI 02 ... PFI 32		JMP2: PFI-Nr. • Number of a PFI for branch 2.
C1335 1 ... 32	JMP2-LEVEL	0 ... 0	0- 1-Level		JMP2: PFI level • Level of a PFI for branch 1.
C1336 1 ... 32	JMP2-PS	0 ... 0	{1} → Selection list 19	32	JMP2: PS no. • Branch 2 to program set no. (PS). Input of the program set no. 10-58




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1349 1 ... 32	JMP-PS JMP-PS		0 {1} 32 → Selection list 19	JMP: PS no. • Unconditioned branch to PS no. <input type="checkbox"/> 10-58
[C1350] 1 ... 10	VTPOS-IN VTPOS-IN	1000 ... 1000	→ Selection list 3	CFG: VTPOS-IN <input type="checkbox"/> 10-58
C1351 1 ... 10	VTPOS-IN VTPOS-IN	[Disp]	-2147483647 {1 incr} 2147483647	DIS: VTPOS-IN
[C1352] 1 ... 4	VTVEL-IN VTVEL-IN	1000 ... 1000	→ Selection list 3	CFG: VTVEL-IN <input type="checkbox"/> 10-58
C1353 1 ... 4	VTVEL-IN VTVEL-IN	[Disp]	-2147483647 {1} 2147483647	DIS: VTVEL-IN
[C1354] 1 ... 4	VTACC-IN VTACC-IN	1000 ... 1000	→ Selection list 3	CFG: VTACC-IN <input type="checkbox"/> 10-58
C1355 1 ... 4	VTACC-IN VTACC-IN	[Disp]	-2147483647 {1} 2147483647	DIS: VTACC-IN
[C1356] 1 ... 4	VTPCS-IN VTPCS-IN	1000 ... 1000	→ Selection list 1	CFG: VTPCS-IN <input type="checkbox"/> 10-58
C1357 1 ... 4	VTPCS-IN VTPCS-IN	[Disp]	-32768 {1} 32767	DIS: VTPCS-IN
C1358 1 ... 4	CFG:VTTIME-IN CFG:VTTIME-IN	1000 ... 1000	→ Selection list 1	CFG: VTTIME-IN <input type="checkbox"/> 10-58
C1359 1 ... 4	DIS:VTTIME-IN DIS:VTTIME-IN	[Disp]	-32768 {1} 32767	DIS: VTTIME-IN

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
[C1360]				→ Selection list 2
1	<i>CFG:PRG-START</i>	53		CFG: POS-PRG-START
2	<i>CFG:PRG-STOP</i>	20201		
3	<i>CFG:PRG-RESET</i>	55		
4	<i>CFG:LIM-NEG</i>	51		
5	<i>CFG:LIM-POS</i>	52		
6	<i>CFG:MANUAL</i>	55		
7	<i>CFG:MANU-NEG</i>	20202		
8	<i>CFG:MANU-POS</i>	20203		
9	<i>CFG:MANU-REF</i>	20204		
10	<i>CFG:REF-MARK</i>	54		
11	<i>CFG:TP1-ENRBL</i>	1000		
12	<i>CFG:TP2-ENRBL</i>	1000		
13	<i>CFG:TP3-ENRBL</i>	1000		
14	<i>CFG:TP4-ENRBL</i>	1000		
15	<i>CFG:PS-CANCEL</i>	20208		
16	<i>CFG:STDBY-STP</i>	20205		
17	<i>CFG:S-RAMPS</i>	19522		
18	<i>CFG:PARAM-RD</i>	20206		
19	<i>CFG:LOOP-INH</i>	20207		
20	<i>CFG:PSET-SWT</i>	1000		
21	<i>CFG:ABS-SET</i>	1000		
22	<i>CFG:WAITSTATE</i>	1000		
C1361		Disp		DIS: POS-PRG-START
1	<i>DIS:PRG-START</i>			
2	<i>DIS:PRG-STOP</i>			
3	<i>DIS:PRG-RESET</i>			
4	<i>DIS:LIM-NEG</i>			
5	<i>DIS:LIM-POS</i>			
6	<i>DIS:MANUAL</i>			
7	<i>DIS:MANU-NEG</i>			
8	<i>DIS:MANU-POS</i>			
9	<i>DIS:MANU-REF</i>			
10	<i>DIS:REF-MARK</i>			
11	<i>DIS:ENRBL-TPI</i>			
12	<i>DIS:ENRBL-TP2</i>			
13	<i>DIS:ENRBL-TP3</i>			
14	<i>DIS:ENRBL-TP4</i>			
15	<i>DIS:PS-CANCEL</i>			
16	<i>DIS:STDBY-STP</i>			
17	<i>DIS:S-RAMPS</i>			
18	<i>DIS:PARAM-RD</i>			
19	<i>DIS:LOOP-INH</i>			
20	<i>DIS:PSET-SWT</i>			
21	<i>DIS:ABS-SET</i>			
22	<i>DIS:WAITSTATE</i>			
[C1362]			50 {1} → Selection list 1	CFG: POS-START-PS
1	<i>CFG:START-PS</i>	19517		
2	<i>CFG:V-OVERRID</i>	1006		
3	<i>CFG:A-OVERRID</i>	1006		
4	<i>CFG:N-IN</i>	1000		
5	<i>CFG:NOUT-GAIN</i>	1006		
6	<i>CFG:A-IN</i>	1000		
7	<i>CFG:NOUT-GAIN</i>	1000		
8	<i>CFG:JERK-RED</i>	1006		




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C1363 1 2 3 4 5 6 7 8	<i>DIS:START-PS</i> <i>DIS:V-OVERRID</i> <i>DIS:A-OVERRID</i> <i>DIS:N-IN</i> <i>DIS:MOUT-GAIN</i> <i>DIS:M-IN</i> <i>DIS:MOUT-GAIN</i> <i>DIS:JERK-RED</i>	[Disp]	-32768 {1}	32767	DIS: POS-START-PS
[C1364] 1 2 3	<i>CFG:PSET-EXT</i> <i>CFG:RBS-IN</i> <i>CFG:P-IN</i>	1000 5000 1000	100 {1} → Selection list 3	25103	CFG: POS-PSET-EXT □ 10-58
C1365 1 2 3	<i>DIS:PSET-EXT</i> <i>DIS:RBS-IN</i> <i>DIS:P-IN</i>	[Disp]	-2147483647 {1 incr}	2147483647	DIS: POS-PSET-EXT
[C1370] 1 2 ... 30 31 32	<i>CFG:PFI</i> <i>CFG:PFI</i> ... <i>CFG:PFI</i> <i>CFG:PFI</i> <i>CFG:PFI</i>	20201 20202 ... 20230 53 54		→ Selection list 2	CFG: POS-PFI □ 10-58
C1371 1 2	<i>PFI-LOW</i> <i>PFI-HIGH</i>	[Disp]	0 {1 hex}	65535	DIS: POS-PFI-LOW (01..16)
C1372 1 2	<i>PFO-LOW</i> <i>PFO-HIGH</i>	[Disp]	0 {1 hex}	65535	DIS: POS-PFO-LOW (01..16)
C1380 1 ... 104	<i>VTP05</i> ...	[Disp]	-214000 {0.0001 units}	214000	DIS: VTPOS (01..104)
C1381 1 ... 104	<i>VTP05</i> ...	[Disp]	-2147483647 {1 incr}	2147483647	DIS: VTPOS (01..104)
C1382 1 ... 34	<i>VTVEL</i> ...	[Disp]	0.01 {0.01 %vmax}	100	DIS: VTVEL (01..34)
C1383 1 ... 34	<i>VTVEL</i> ...	[Disp]	-2147483647 {1 x/T}	2147483647	DIS: VTVEL (01..34)
C1384 1 ... 34	<i>VTACC</i> ...	[Disp]	0.01 {0.01 %amax}	100	DIS: VTACC (01..34)
C1385 1 ... 34	<i>VTACC</i> ...	[Disp]	-2147483647 {1 x/T2}	2147483647	DIS: VTACC (01..34)
C1386 1 ... 34	<i>VTPCS</i> ...	[Disp]	0 {1 pcs}	65535	DIS: VTPCS (01..34)

Appendix




Code	LCD	Possible settings			IMPORTANT	
		Lenze	Choice			
C1387 1 ... 34	VTTIME ... VTTIME	[Disp]	0	{0.001 s}	65535	DIS: VTTIME (01..34)
[C1400] 1 2 3 4	SET NEXT CLR LORD	1000 1000 1000 1000	5	{1} → Selection list 2	25132	CFG: TEACH1-SET
[C1401] 1	L-IN	1000	100	{1} → Selection list 3	25103	CFG: TEACH1-L-IN
C1402 1 2 3 4	SET NEXT CLR LORD	[Disp]	-2147483647	{1}	2147483647	DIS: TEACH1-SET
C1403	CNT	[Disp]	0	{1}	65535	DIS: TEACH1-CNT
C1404 1	L-IN	[Disp]	-2147483647	{1 incr}	2147483647	DIS: TEACH1-L-IN
[C1405] 1	LOWRL	1000	50	{1} → Selection list 1	25104	CFG: TEACH1-LDVAL
C1406 1	LOWRL	[Disp]	-32768	{1}	32768	DIS: TEACH1-LDVAL
C1500	OUTPUT SIGNAL	[Disp]	-2147483648	{1}	2147483647	Output signal of FEVAN2
C1501	CODE	141	2	{1}	2000	FEVAN2 code
C1502	Subcode	0	0	{1}	255	FEVAN2 subcode
C1503	NUMERATOR	1	0	{1}	100000	FEVAN2 numerator
C1504	DENOMINATOR	0.0001	0.0001	{0.0001}	100000	FEVAN2 denominator
C1505	OFFSET	0	0	{1}	1000000000	FEVAN2 offset
[C1506]	IN	1000	50	{1} → Selection list 1	25104	CFG: FEVAN2-IN
[C1507] 1 2 3	LORD BUSY-IN FAIL-IN	1000 1000 1000	51	{1} → Selection list 2	25132	CFG: FEVAN2-LOAD
C1508	IN	[Disp]	-32768	{1}	32768	DIS: FEVAN2-IN
C1509 1 2 3	LORD BUSY-IN FAIL-IN	[Disp]	0		1	DIS: FEVAN2-LOAD
C1510	OUTPUT SIGNAL	[Disp]	-2147483647	{1}	2147483647	Output signal of FEVAN3
C1511	CODE	141	2	{1}	2000	FEVAN3 code
C1512	Subcode	0	0	{1}	255	FEVAN3 subcode
C1513	NUMERATOR	1	0	{1}	100000	FEVAN3 numerator
C1514	DENOMINATOR	0.0001	0.0001	{0.0001}	100000	FEVAN3 denominator
C1515	OFFSET	0	0	{1}	1000000000	FEVAN3 Offset
[C1516]	IN	1000	50	{1} → Selection list 1	25104	CFG: FEVAN3-IN
[C1517] 1 2 3	LORD BUSY-IN FAIL-IN	1000 1000 1000	51	{1} → Selection list 2	25132	CFG: FEVAN3-LOAD
C1518	IN	[Disp]	-32768	{1}	32768	DIS: FEVAN3-IN




Appendix

Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1519	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	[Disp]	0	1 DIS: FEVAN3-LOAD
C1520	<i>OUTPUT SIGNAL</i>	[Disp]	-2147483647 {1} 2147483647	Output signal of FEVAN4
C1521	<i>CODE</i>	141	2 {1} 2000	FEVAN4 code
C1522	<i>SubCODE</i>	0	0 {1} 255	FEVAN4 subcode
C1523	<i>NUMERATOR</i>	1	0 {1} 100000	FEVAN4 numerator
C1524	<i>DENOMINATOR</i>	0.0001	0.0001 {0.0001} 100000	FEVAN4 denominator
C1525	<i>OFFSET</i>	0	0 {1} 1000000000	FEVAN4 offset
[C1526]	<i>IN</i>	1000	50 {1} 25104 → Selection list 1	CFG: FEVAN4-IN [10-58
[C1527]	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	1000 1000 1000	51 {1} 25132 → Selection list 2	CFG: FEVAN4-LOAD [10-58
C1528	<i>IN</i>	[Disp]	-32768 {1} 32768	DIS: FEVAN4-IN
C1529	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	[Disp]	0 {1} 1	DIS: FEVAN4-LOAD
C1530	<i>OUTPUT SIGNAL</i>	[Disp]	-2147483647 {1} 2147483647	Output signal of FEVAN5
C1531	<i>CODE</i>	141	2 {1} 2000	FEVAN5 code
C1532	<i>SubCODE</i>	0	0 {1} 255	FEVAN5 subcode
C1533	<i>NUMERATOR</i>	1	0 {1} 100000	FEVAN5 numerator
C1534	<i>DENOMINATOR</i>	0.0001	0.0001 {0.0001} 100000	FEVAN5 denominator
C1535	<i>OFFSET</i>	0	0 {1} 1000000000	FEVAN5 offset
[C1536]	<i>IN</i>	1000	50 {1} 25104 → Selection list 1	CFG: FEVAN5-IN [10-58
[C1537]	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	1000 1000 1000	51 {1} 25132 → Selection list 2	CFG: FEVAN5-LOAD [10-58
C1538	<i>IN</i>	[Disp]	-32768 {1} 32768	DIS: FEVAN5-IN
C1539	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	[Disp]	0 {1} 1	DIS: FEVAN5-LOAD
C1540	<i>OUTPUT SIGNAL</i>	[Disp]	-2147483647 {1} 2147483647	Output signal of FEVAN6
C1541	<i>CODE</i>	141	2 {1} 2000	FEVAN6 code
C1542	<i>SubCODE</i>	0	0 {1} 255	FEVAN6 subcode
C1543	<i>NUMERATOR</i>	1	0 {1} 100000	FEVAN6 numerator
C1544	<i>DENOMINATOR</i>	0.0001	0.0001 {0.0001} 100000	FEVAN6 denominator
C1545	<i>OFFSET</i>	0	0 {1} 1000000000	FEVAN6 offset
[C1546]	<i>IN</i>	1000	50 {1} 25104 → Selection list 1	CFG: FEVAN6-IN [10-58
[C1547]	1 2 3 <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	1000 1000 1000	51 {1} 25132 → Selection list 2	CFG: FEVAN6-LOAD [10-58
C1548	<i>IN</i>	[Disp]	-32768 {1} 32768	DIS: FEVAN6-IN

Appendix




Code	LCD	Possible settings		IMPORTANT
		Lenze	Choice	
C1549 1 <i>LORD</i> 2 <i>BUSY-IN</i> 3 <i>FAIL-IN</i>		[Disp]	0	1 DIS: FEV/AN6-LOAD
C1550	<i>ARITPH4 FUNCT</i>	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 14 IN1 / IN2	Function of ARITPH4
[C1551] 1 <i>/N</i> 2 <i>/N</i>		1000 1000	100 {1} 25103 → Selection list 3	Configuration inputs ARITPH4 [10-58
C1552 1 <i>/N</i> 2 <i>/N</i>		[Disp]	-2147483647 {1} 2147483647	Input signals ARITPH4
C1555	<i>ARITPH5 FUNCT</i>	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 14 IN1 / IN2	Function of ARITPH5
[C1556] 1 <i>/N</i> 2 <i>/N</i>		1000 1000	100 {1} 25103 → Selection list 3	Configuration inputs ARITPH5 [10-58
C1557 1 <i>/N</i> 2 <i>/N</i>		[Disp]	-2147483647 {1} 2147483647	Input signals ARITPH5
C1560	<i>ARITPH6 FUNCT</i>	1	0 OUT = IN1 1 IN1 + IN2 2 IN1 - IN2 3 IN1 * IN2 14 IN1 / IN2	Function of ARITPH6
[C1561] 1 <i>/N</i> 2 <i>/N</i>		1000 1000	100 {1} 25103 → Selection list 3	Configuration inputs ARITPH6 [10-58
C1562 1 <i>/N</i> 2 <i>/N</i>		[Disp]	-2147483647 {1} 2147483647	Input signals ARITPH6
[C1570] 1 <i>B0</i> 2 <i>B1</i> 3 <i>B2</i> 4 <i>B3</i> 5 <i>B4</i> 6 <i>B5</i> 7 <i>B6</i> 8 <i>B7</i> 9 <i>B8</i> 10 <i>B9</i> 11 <i>B10</i> 12 <i>B11</i> 13 <i>B12</i> 14 <i>B13</i> 15 <i>B14</i> 16 <i>SIGN</i>		1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000 1000	51 {1} 25132 → Selection list 2	CFG: CONVDA1.B0 [10-58
C1571	<i>RESULT</i>	[Disp]	0 {1 hex}	65536 DIS: result




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
[C1573]			51 {1} 25132 → Selection list 2		CFG: CONVDA2.B0
1	B0	1000			10-58
2	B1	1000			
3	B2	1000			
4	B3	1000			
5	B4	1000			
6	B5	1000			
7	B6	1000			
8	B7	1000			
9	B8	1000			
10	B9	1000			
11	B10	1000			
12	B11	1000			
13	B12	1000			
14	B13	1000			
15	B14	1000			
16	SIGN	1000			
C1574	RESULT	[Disp]	0 {1 hex} 65536	DIS: result	
[C1576]			51 {1} 25132 → Selection list 2	CFG: CONVDA3.B0	10-58
1	B0	1000			
2	B1	1000			
3	B2	1000			
4	B3	1000			
5	B4	1000			
6	B5	1000			
7	B6	1000			
8	B7	1000			
9	B8	1000			
10	B9	1000			
11	B10	1000			
12	B11	1000			
13	B12	1000			
14	B13	1000			
15	B14	1000			
16	SIGN	1000			
C1577	RESULT	[Disp]	0 {1 hex} 65536	DIS: result	
[C1580]	/\Y	1000	50 {1} 25104 → Selection list 1	CFG: CONVAD1-IN	10-58
C1581	/\Y	[Disp]	-32768 {1} 32768	DIS: CONVAD1-IN	
[C1582]	/\Y	1000	50 {1} 25104 → Selection list 1	CFG: CONVAD2-IN	10-58
C1583	/\Y	[Disp]	-32768 {1} 32768	DIS: CONVAD2-IN	
C1590	NUMERATOR	1	-32768 {1} 32768	CONVAPH1 numerator	
C1591	DENOMINATOR	1	1 {1} 32768	CONVAPH1 denominator	
[C1593]	/\Y	1000	50 {1} 25104 → Selection list 1	CFG: CONVAPH1-IN	10-58
C1594	/\Y	[Disp]	-32768 {1} 32768	DIS: CONVAPH1-IN	
C1595	NUMERATOR	1	-32768 {1} 32768	CONVAPH2 numerator	
C1596	DENOMINATOR	1	1 {1} 32768	CONVAPH2 denominator	
[C1598]	/\Y	1000	50 {1} 25104 → Selection list 1	CFG: CONVAPH2-IN	10-58
C1599	/\Y	[Disp]	-32768 {1} 32768	DIS: CONVAPH2-IN	
C1600	NUMERATOR	1	-32768 {1} 32768	CONVAPH3 numerator	
C1601	DENOMINATOR	1	1 {1} 32768	CONVAPH3 denominator	
[C1603]	/\Y	1000	50 {1} 25104 → Selection list 1	CFG: CONVAPH3-IN	10-58
C1604	D/S IN	[Disp]	-32768 {1} 32768	DIS: CONVAPH3-IN	

Appendix




Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C1610	DIVISION	1	1 {1}	31	Factor
[C1611]	IN	1000	100 {1}	25103 → Selection list 3	Configuration input of CONVPHA2
C1612	IN	Disp	-2147483647 {1 incr}	2147483647	Input signal of CONVPHA2
C1615	DIVISION	1	1 {1}	31	Factor
[C1616]	IN	1000	100 {1}	25103 → Selection list 3	Configuration input of CONVPHA3
C1617	IN	Disp	-2147483647 {1 incr}	2147483647	Input signal of CONVPHA3
[C1640]	1 RESET	1000	51 {1}	25132 → Selection list 2	CFG: SP1-RESET
C1641					
1	SP-VALUE 1-1	1000	1 {1}	104	SP value for IN1-1
2	SP-VALUE 1-2	1000			
3	SP-VALUE 2-1	1000			
4	SP-VALUE 2-2	1000			
5	SP-VALUE 3-1	1000			
6	SP-VALUE 3-2	1000			
7	SP-VALUE 4-1	1000			
8	SP-VALUE 4-2	1000			
9	SP-VALUE 5-1	1000			
10	SP-VALUE 5-2	1000			
11	SP-VALUE 6-1	1000			
12	SP-VALUE 6-2	1000			
13	SP-VALUE 7-1	1000			
14	SP-VALUE 7-2	1000			
15	SP-VALUE 8-1	1000			
16	SP-VALUE 8-2	1000			
[C1642]	1 L-IN	1000	100 {1}	25103 → Selection list 3	CFG: SP1-L-IN
C1643	1 RESET	Disp	0	1	DIS: SP1-RESET
C1644	1 L-IN	Disp	-1073741824 {1 incr}	1073741823	DIS: SP1-L-IN
C1645	MODE	0	0 on / off 1 centre/range		SP1 mode
[C1650]	1 RESET	1000	51 {1}	25132 → Selection list 2	CFG: SP2-RESET
C1651					
1	SP-VALUE 1-1	1000	1 {1}	104	SP value for IN1-1
2	SP-VALUE 1-2	1000			
3	SP-VALUE 2-1	1000			
4	SP-VALUE 2-2	1000			
5	SP-VALUE 3-1	1000			
6	SP-VALUE 3-2	1000			
7	SP-VALUE 4-1	1000			
8	SP-VALUE 4-2	1000			
9	SP-VALUE 5-1	1000			
10	SP-VALUE 5-2	1000			
11	SP-VALUE 6-1	1000			
12	SP-VALUE 6-2	1000			
13	SP-VALUE 7-1	1000			
14	SP-VALUE 7-2	1000			
15	SP-VALUE 8-1	1000			
16	SP-VALUE 8-2	1000			
[C1652]	1 L-IN	1000	100 {1}	25103 → Selection list 3	CFG: SP2-L-IN




Appendix

Code	LCD	Possible settings			IMPORTANT
		Lenze	Choice		
C1653 1	RESET	[Disp]	0	1	DIS: SP2-RESET
C1654 1	L-IN	[Disp]	-1073741824 {1 incr} 1073741823		DIS: SP2-L-IN
C1655	MODE	0	0 on / off 1 centre/range		SP2 mode
C1657 1 ... 4	DEADTIME	0 ...	-30000 {1 ms} 30000		SP2 dead time
C1658	HYSERESIS	0	-214000 {0.0001 units} 214000		SP2 hysteresis
C1659	FILTER	1	0 Filter off 1 Filter 1 ms 2 Filter 2 ms 4 Filter 4 ms 8 Filter 8 ms 6 Filter 16 ms		Filters
C1660	Rct.SEL.	[Disp]	0 {1} 8		DIS: act. Choice
[C1661]	SELECT	1000	50 {1} 25104 → Selection list 1		CFG: SELPH1-SELECT □ 10-58
[C1662] 1 ... 8	/\	1000 ...	50 {1} 25104 → Selection list 3		CFG: SELPH1-IN □ 10-58
C1663	SELECT	[Disp]	-32768 {1} 32768		DIS: SELPH1-SELECT
C1664 1 ... 8	/\	[Disp]	-2147483647 {1 incr} 2147483647		DIS: SELPH1-IN
C1665	Rct.SEL.	[Disp]	0 {1} 8		DIS: act. Choice
[C1666]	SELECT	1000	50 {1} 25104 → Selection list 1		CFG: SELPH2-SELECT □ 10-58
[C1667] 1 ... 8	/\	1000 ...	50 {1} 25104 → Selection list 3		CFG: SELPH2-IN □ 10-58
C1668	SELECT	[Disp]	-32768 {1} 32768		DIS: SELPH2-SELECT
C1669 1 ... 8	/\	[Disp]	-2147483647 {1 incr} 2147483647		DIS: SELPH2-IN
C1670	FUNCTION	1	1 IN1 = IN2 2 IN1 > IN2 3 IN1 < IN2 4 IN1 = IN2 5 IN1 > IN2 6 IN1 < IN2		CMPPH1 function
C1671	HYSERESIS	50	0 {1 incr} 1073741824		CMPPH1 hysteresis
C1672	WINDOW	0	0 {1 incr} 1073741824		CMPPH1 window
[C1673] 1 2	/\	1000 1000	50 {1} 25104 → Selection list 3		CFG: CMPPH1-IN □ 10-58
C1674 1 2	/\	[Disp]	-2147483647 {1 incr} 2147483647		DIS: CMPPH1-IN

Appendix




Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C1675	FUNCTION	1	1 2 3 4 5 6	IN1 = IN2 IN1 > IN2 IN1 < IN2 IN1 = IN2 IN1 > IN2 IN1 < IN2		CMPPH2 function
C1676	HYSERESIS	50	0	{1 incr}	1073741824	CMPPH2 hysteresis
C1677	WINDOW	0	0	{1 incr}	1073741824	CMPPH2 window
[C1678] 1 2	/N /N	1000 1000	50	{1} → Selection list 3	25104	CFG: CMPPH2-IN ■ 10-58
C1679 1 2	/N /N	[Disp]	-2147483647	{1 incr}	2147483647	DIS: CMPPH2-IN
C1680	FUNCTION	1	1 2 3 4 5 6	IN1 = IN2 IN1 > IN2 IN1 < IN2 IN1 = IN2 IN1 > IN2 IN1 < IN2		CMPPH3 function
C1681	HYSERESIS	50	0	{1 incr}	1073741824	CMPPH3 hysteresis
C1682	WINDOW	0	0	{1 incr}	1073741824	CMPPH3 window
[C1683] 1 2	/N /N	1000 1000	50	{1} → Selection list 3	25104	CFG: CMPPH3-IN ■ 10-58
C1684 1 2	/N /N	[Disp]	-2147483647	{1 incr}	2147483647	DIS: CMPPH3-IN
[C1690] 1 ... 10	/N ... /N	1000 ... 1000	50	{1} → Selection list 1	25104	CFG: DISA-IN ■ 10-58
C1691 1 ... 10	/N (%) ... /N (%)	[Disp]	-199.99	{0.01 %}	199.99	DIS: DISA-IN (%)
C1692 1 ... 10	/N (VAL) ... /N (VAL)	[Disp]	-32768	{1}	32768	DIS: DISA-IN (value)
C1693 1 ... 10	/N (HEX) ... /N (HEX)	[Disp]	0	{1 hex}	65536	DIS: IN (HEX)
[C1695] 1 ... 10	/N ... /N	1000 ... 1000	50	{1} → Selection list 3	25104	CFG: DISPH-IN ■ 10-58
C1696 1 ... 10	/N ... /N	[Disp]	-2147483647	{1 incr}	2147483647	DIS: DISPH-IN
C1700 1 2	OUTPUT SIGNAL BCD RESULT	[Disp]	-2147483647	{1}	2147483647	Signal output
C1701	CODE	141	11	{1}	2000	BCD1 Code




Appendix

Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C1702	<i>Subcode</i>	0	0	{1}	255	BCD1 Subcode
C1703	<i>NUMERATOR</i>	1	0	{1}	100000	BCD1 numerator
C1704	<i>DENOMINATOR</i>	0.0001	0.0001	{0.0001}	100000	BCD1 denominator
C1705	<i>OFFSET</i>	0	0	{1}	1000000000	BCD1 Offset
C1706	<i>BCD MODUS</i>	0	0	no hand-shake with hand-shake	1	BCD mode
C1707	<i>BCD DELAY</i>	10	0	{1 ms}	255	BCD delay
[C1708]			51	{1}	25132	CFG: BCD1-READ
1	<i>RERO</i>	1000				□ 10-58
2	<i>DATR1</i>	1000				
3	<i>DATR2</i>	1000				
4	<i>DATR3</i>	1000				
5	<i>DATR4</i>	1000				
6	<i>LORD</i>	1000				
7	<i>BUSY-IN</i>	1000				
8	<i>FAIL-IN</i>	1000				
C1709		[Disp]	0		1	DIS: BCD1-READ
1	<i>RERO</i>					
2	<i>DATR1</i>					
3	<i>DATR2</i>					
4	<i>DATR3</i>					
5	<i>DATR4</i>					
6	<i>LORD</i>					
7	<i>BUSY-IN</i>					
8	<i>FAIL-IN</i>					
C1710		[Disp]	-2147483647	{1}	2147483647	Signal output
1	<i>OUTPUT SIGNAL</i>					
2	<i>BCD RESULT</i>					
C1711	<i>CODE</i>	141	11	{1}	2000	BCD2 code
C1712	<i>Subcode</i>	0	0	{1}	255	BCD2 subcode
C1713	<i>NUMERATOR</i>	1	0	{1}	100000	BCD2 numerator
C1714	<i>DENOMINATOR</i>	0.0001	0.0001	{0.0001}	100000	BCD2 denominator
C1715	<i>OFFSET</i>	0	0	{1}	1000000000	BCD2 offset
C1716	<i>BCD MODUS</i>	0	0	no hand-shake with hand-shake	1	BCD mode
C1717	<i>BCD DELAY</i>	10	0	{1 ms}	255	BCD delay
[C1718]			51	{1}	25132	CFG: BCD2-READ
1	<i>RERO</i>	1000				□ 10-58
2	<i>DATR1</i>	1000				
3	<i>DATR2</i>	1000				
4	<i>DATR3</i>	1000				
5	<i>DATR4</i>	1000				
6	<i>LORD</i>	1000				
7	<i>BUSY-IN</i>	1000				
8	<i>FAIL-IN</i>	1000				
C1719		[Disp]	0		1	DIS: BCD2-READ
1	<i>RERO</i>					
2	<i>DATR1</i>					
3	<i>DATR2</i>					
4	<i>DATR3</i>					
5	<i>DATR4</i>					
6	<i>LORD</i>					
7	<i>LORD</i>					
8	<i>BUSY-IN</i>					

Appendix



Code	LCD	Possible settings				IMPORTANT
		Lenze	Choice			
C1720 1 2	<i>OUTPUT SIGNAL</i> <i>BCD RESULT</i>	[Disp]	-2147483647	{1}	2147483647	Signal output
C1721	<i>CODE</i>	141	11	{1}	2000	BCD3 code
C1722	<i>Subcode</i>	0	0	{1}	255	BCD3 subcode
C1723	<i>NUMERATOR</i>	1	0	{1}	100000	BCD3 numerator
C1724	<i>DENOMINATOR</i>	0.0001	0.0001	{0.0001}	100000	BCD3 denominator
C1725	<i>OFFSET</i>	0	0	{1}	1000000000	BCD3 offset
C1726	<i>BCD MODEUS</i>	0	0	no hand-shake with hand-shake		BCD mode
C1727	<i>BCD DELAY</i>	10	0	{1 ms}	255	BCD delay
[C1728] 1 2 3 4 5 6 7 8	<i>RERO</i> <i>DATA1</i> <i>DATA2</i> <i>DATA3</i> <i>DATA4</i> <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	1000	51	{1}	25132 → Selection list 2	CFG: BCD3-READ
C1729 1 2 3 4 5 6 7 8	<i>READ</i> <i>DATA1</i> <i>DATA2</i> <i>DATA3</i> <i>DATA4</i> <i>LORD</i> <i>BUSY-IN</i> <i>FAIL-IN</i>	[Disp]	0		1	DIS: BCD3-READ
C1799	<i>DFOUT F_{max}</i>	1250	20	{1 kHz}	1250	DFOUT f max (kHz) Maximum output frequency at X10 in kHz



Appendix


10.3 Selection list

List 1: Analog signal sources

000050:	AIN1-OUT	019522:	FCODE-472/2
000055:	AIN2-OUT	019523:	FCODE-472/3
000100:	DFSET-NOUT	019524:	FCODE-472/4
001000:	FIXED 0%	019525:	FCODE-472/5
001006:	FIXED 100%	019526:	FCODE-472/6
001007:	FIXED -100%	019527:	FCODE-472/7
005000:	MCTRL-NSET2	019528:	FCODE-472/8
005001:	MCTRL-NACT	019529:	FCODE-472/9
005002:	MCTRL-MSET2	019530:	FCODE-472/10
005003:	MCTRL-MACT	019531:	FCODE-472/11
005004:	MCTRL-IACT	019532:	FCODE-472/12
005005:	MCTRL-DCVOLT	019533:	FCODE-472/13
005009:	MCTRL-PHI-ANA	019534:	FCODE-472/14
005050:	NSET-NOUT	019535:	FCODE-472/15
005051:	NSET-RFG-I	019536:	FCODE-472/16
005100:	MPOT1-OUT	019537:	FCODE-472/17
005550:	ADD1-OUT	019538:	FCODE-472/18
005600:	RFG1-OUT	019539:	FCODE-472/19
005650:	ASW1-OUT	019540:	FCODE-472/20
005700:	ASW2-OUT	019551:	FCODE-473/1
005705:	ANEG1-OUT	019552:	FCODE-473/2
006200:	CONV1-OUT	019553:	FCODE-473/3
006205:	CONV2-OUT	019554:	FCODE-473/4
006210:	CONV3-OUT	019555:	FCODE-473/5
006215:	CONV4-OUT	019556:	FCODE-473/6
006230:	CONVPHA1-OUT	019557:	FCODE-473/7
006232:	CONVPHA2-OUT	019558:	FCODE-473/8
006234:	CONVPHA3-OUT	019559:	FCODE-473/9
006300:	S&H1-OUT	019560:	FCODE-473/10
006350:	CURVE1-OUT	020101:	CAN-IN1.W1
006400:	FCNT1-OUT	020102:	CAN-IN1.W2
006405:	FCNT2-OUT	020103:	CAN-IN1.W3
006410:	FCNT3-OUT	020201:	CAN-IN2.W1
006550:	TEACH1-CNT	020202:	CAN-IN2.W2
006600:	SYNC1-OUT3	020203:	CAN-IN2.W3
007200:	CONVDA1-OUT	020204:	CAN-IN2.W4
007205:	CONVDA2-OUT	020301:	CAN-IN3.W1
007210:	CONVDA3-OUT	020302:	CAN-IN3.W2
010000:	BRK1-M-SET	020303:	CAN-IN3.W3
011200:	RFGX1-OUT	020304:	CAN-IN3.W4
011201:	RFGX1-VSOUT	025101:	AIF-IN.W1
011300:	SELA1-OUT1	025102:	AIF-IN.W2
011301:	SELA1-OUT2	025103:	AIF-IN.W3
011302:	SELA1-SELECT	030000:	POS-ACT-PS-NO
015028:	Utilization	030010:	POS-NSET
019500:	FCODE-17	030020:	POS-NOUT
019502:	FCODE-26/1	030021:	POS-MOUT
019503:	FCODE-26/2	030030:	POS-POUT-NORM
019504:	FCODE-27/1	031301:	VTTIME-OUT1
019505:	FCODE-27/2	031302:	VTTIME-OUT2
019506:	FCODE-32	031303:	VTTIME-OUT3
019507:	FCODE-37	031304:	VTTIME-OUT4
019510:	FCODE-108/1	031351:	VTPCS-OUT1
019511:	FCODE-108/2	031352:	VTPCS-OUT2
019512:	FCODE-109/1	031353:	VTPCS-OUT3
019513:	FCODE-109/2	031354:	VTPCS-OUT4


List 2: Digital signal sources

000051:	DIGIN1	007172:	CONVAD2-2
000052:	DIGIN2	007173:	CONVAD2-3
000053:	DIGIN3	007174:	CONVAD2-4
000054:	DIGIN4	007175:	CONVAD2-5
000055:	DIGIN5	007176:	CONVAD2-6
000060:	STATE-BUS-0	007177:	CONVAD2-7
000065:	DIGIN-CINH	007178:	CONVAD2-8
000100:	DFSET-ACK	007179:	CONVAD2-9
000500:	DCTRL-RDY	007180:	CONVAD2-10
000501:	DCTRL-CINH	007181:	CONVAD2-11
000502:	DCTRL-INIT	007182:	CONVAD2-12
000503:	DCTRL-IMP	007183:	CONVAD2-13
000504:	DCTRL-NACT=0	007184:	CONVAD2-14
000505:	DCTRL-CW/CCW	007185:	CONVAD2-SIGN
001000:	FIXED 0	010000:	BRK1-OUT
001001:	FIXED 1	010001:	BRK1-CINH
005001:	MCTRL-QSP-OUT	010002:	BRK1-QSP
005002:	MCTRL-IMAX	010003:	BRK1-M-STORE
005003:	MCTRL-MMAX	010250:	R/L/Q-QSP
005050:	NSET-RFG-I=0	010251:	R/L/Q-R/L
006000:	DFRGF1-FAIL	010500:	AND1-OUT
006001:	DFRGF1-SYNC	010505:	AND2-OUT
006400:	FCNT1-EQUAL	010510:	AND3-OUT
006405:	FCNT2-EQUAL	010515:	AND4-OUT
006410:	FCNT3-EQUAL	010520:	AND5-OUT
006450:	SP1-STATUS-01	010550:	OR1-OUT
006451:	SP1-STATUS-02	010555:	OR2-OUT
006452:	SP1-STATUS-03	010560:	OR3-OUT
006453:	SP1-STATUS-04	010565:	OR4-OUT
006454:	SP1-STATUS-05	010570:	OR5-OUT
006455:	SP1-STATUS-06	010600:	NOT1-OUT
006456:	SP1-STATUS-07	010605:	NOT2-OUT
006457:	SP1-STATUS-08	010610:	NOT3-OUT
006460:	SP2-STATUS-01	010615:	NOT4-OUT
006461:	SP2-STATUS-02	010620:	NOT5-OUT
006462:	SP2-STATUS-03	010650:	CMP1-OUT
006463:	SP2-STATUS-04	010655:	CMP2-OUT
006464:	SP2-STATUS-05	010700:	DIGDEL1-OUT
006465:	SP2-STATUS-06	010705:	DIGDEL2-OUT
006466:	SP2-STATUS-07	010750:	TRANS1-OUT
006467:	SP2-STATUS-08	010755:	TRANS2-OUT
006600:	SYNC1-STAT	010900:	FLIP1-OUT
007150:	CONVAD1-0	010905:	FLIP2-OUT
007151:	CONVAD1-1	011000:	CMPPH1-OUT
007152:	CONVAD1-2	011005:	CMPPH2-OUT
007153:	CONVAD1-3	011010:	CMPPH3-OUT
007154:	CONVAD1-4	012000:	PHINT1-FAIL
007155:	CONVAD1-5	013000:	FEVAN1-BUSY
007156:	CONVAD1-6	013001:	FEVAN1-FAIL
007157:	CONVAD1-7	013005:	FEVAN2-BUSY
007158:	CONVAD1-8	013006:	FEVAN2-FAIL
007159:	CONVAD1-9	013010:	FEVAN3-BUSY
007160:	CONVAD1-10	013011:	FEVAN3-FAIL
007161:	CONVAD1-11	013015:	FEVAN4-BUSY
007162:	CONVAD1-12	013016:	FEVAN4-FAIL
007163:	CONVAD1-13	013021:	FEVAN5-BUSY
007164:	CONVAD1-14	013025:	FEVAN6-BUSY
007165:	CONVAD1-SIGN	013026:	FEVAN6-FAIL
007170:	CONVAD2-0	013050:	BCD1-SEL1
007171:	CONVAD2-1	013051:	BCD1-SEL2



List 2 (continued):

013052:	BCD1-SEL3	015028:	MONIT-OC5	019756:	FCODE-135.B5	020213:	CAN-IN2.B12
013053:	BCD1-SEL4	015029:	MONIT-SD5	019757:	FCODE-135.B6	020214:	CAN-IN2.B13
013054:	BCD1-SEL5	015030:	MONIT-SD6	019758:	FCODE-135.B7	020215:	CAN-IN2.B14
013055:	BCD1-SEL6	015031:	MONIT-SD7	019763:	FCODE-135.B12	020216:	CAN-IN2.B15
013056:	BCD1-SEL7	015032:	MONIT-H07	019764:	FCODE-135.B13	020217:	CAN-IN2.B16
013057:	BCD1-SEL8	015033:	MONIT-H10	019765:	FCODE-135.B14	020218:	CAN-IN2.B17
013058:	BCD1-SIGN	015034:	MONIT-H11	019766:	FCODE-135.B15	020219:	CAN-IN2.B18
013059:	BCD1-NEW-DATA	015040:	MONIT-CE1	020001:	CAN-CTRL.B0	020220:	CAN-IN2.B19
013060:	BCD1-EOT	015041:	MONIT-CE2	020002:	CAN-CTRL.B1	020221:	CAN-IN2.B20
013061:	BCD1-DATA-FLT	015042:	MONIT-CE3	020003:	CAN-CTRL.B2	020222:	CAN-IN2.B21
013062:	BCD1-BUSY	015043:	MONIT-CE4	020005:	CAN-CTRL.B4	020223:	CAN-IN2.B22
013063:	BCD1-FAIL	015301:	MONIT-P01	020006:	CAN-CTRL.B5	020224:	CAN-IN2.B23
013065:	BCD2-SEL1	015302:	MONIT-P02	020007:	CAN-CTRL.B6	020225:	CAN-IN2.B24
013066:	BCD2-SEL2	015304:	MONIT-P04	020008:	CAN-CTRL.B7	020226:	CAN-IN2.B25
013067:	BCD2-SEL3	015305:	MONIT-P05	020013:	CAN-CTRL.B12	020227:	CAN-IN2.B26
013068:	BCD2-SEL4	015306:	MONIT-P06	020014:	CAN-CTRL.B13	020228:	CAN-IN2.B27
013069:	BCD2-SEL5	015307:	MONIT-P07	020015:	CAN-CTRL.B14	020229:	CAN-IN2.B28
013070:	BCD2-SEL6	015308:	MONIT-P08	020016:	CAN-CTRL.B15	020230:	CAN-IN2.B29
013071:	BCD2-SEL7	015309:	MONIT-P09	020101:	CAN-IN1.B0	020231:	CAN-IN2.B30
013072:	BCD2-SEL8	015312:	MONIT-P12	020102:	CAN-IN1.B1	020232:	CAN-IN2.B31
013073:	BCD2-SIGN	015314:	MONIT-P14	020103:	CAN-IN1.B2	020301:	CAN-IN3.B0
013074:	BCD2-NEW-DATA	015315:	MONIT-P15	020104:	CAN-IN1.B3	020302:	CAN-IN3.B1
013075:	BCD2-EOT	015316:	MONIT-P16	020105:	CAN-IN1.B4	020303:	CAN-IN3.B2
013076:	BCD2-DATA-FLT	015317:	MONIT-P17	020106:	CAN-IN1.B5	020304:	CAN-IN3.B3
013077:	BCD2-BUSY	015318:	MONIT-P18	020107:	CAN-IN1.B6	020305:	CAN-IN3.B4
013078:	BCD2-FAIL	019500:	FCODE-250	020108:	CAN-IN1.B7	020306:	CAN-IN3.B5
013080:	BCD3-SEL1	019521:	FCODE-471.B0	020109:	CAN-IN1.B8	020307:	CAN-IN3.B6
013081:	BCD3-SEL2	019522:	FCODE-471.B1	020110:	CAN-IN1.B9	020308:	CAN-IN3.B7
013082:	BCD3-SEL3	019523:	FCODE-471.B2	020111:	CAN-IN1.B10	020309:	CAN-IN3.B8
013083:	BCD3-SEL4	019524:	FCODE-471.B3	020112:	CAN-IN1.B11	020310:	CAN-IN3.B9
013084:	BCD3-SEL5	019525:	FCODE-471.B4	020113:	CAN-IN1.B12	020311:	CAN-IN3.B10
013085:	BCD3-SEL6	019526:	FCODE-471.B5	020114:	CAN-IN1.B13	020312:	CAN-IN3.B11
013086:	BCD3-SEL7	019527:	FCODE-471.B6	020115:	CAN-IN1.B14	020313:	CAN-IN3.B12
013087:	BCD3-SEL8	019528:	FCODE-471.B7	020116:	CAN-IN1.B15	020314:	CAN-IN3.B13
013088:	BCD3-SIGN	019529:	FCODE-471.B8	020117:	CAN-IN1.B16	020315:	CAN-IN3.B14
013089:	BCD3-NEW-DATA	019530:	FCODE-471.B9	020118:	CAN-IN1.B17	020316:	CAN-IN3.B15
013090:	BCD3-EOT	019531:	FCODE-471.B10	020119:	CAN-IN1.B18	020317:	CAN-IN3.B16
013091:	BCD3-DATA-FLT	019532:	FCODE-471.B11	020120:	CAN-IN1.B19	020318:	CAN-IN3.B17
013092:	BCD3-BUSY	019533:	FCODE-471.B12	020121:	CAN-IN1.B20	020319:	CAN-IN3.B18
013093:	BCD3-FAIL	019534:	FCODE-471.B13	020122:	CAN-IN1.B21	020320:	CAN-IN3.B19
015000:	DCTRL-TRIP	019535:	FCODE-471.B14	020123:	CAN-IN1.B22	020321:	CAN-IN3.B20
015001:	DCTRL-MESS	019536:	FCODE-471.B15	020124:	CAN-IN1.B23	020322:	CAN-IN3.B21
015002:	DCTRL-WARN	019537:	FCODE-471.B16	020125:	CAN-IN1.B24	020323:	CAN-IN3.B22
015003:	DCTRL-FAIL	019538:	FCODE-471.B17	020126:	CAN-IN1.B25	020324:	CAN-IN3.B23
015004:	DCTRL-FAILQSP	019539:	FCODE-471.B18	020127:	CAN-IN1.B26	020325:	CAN-IN3.B24
015010:	MONIT-LU	019540:	FCODE-471.B19	020128:	CAN-IN1.B27	020326:	CAN-IN3.B25
015011:	MONIT-OU	019541:	FCODE-471.B20	020129:	CAN-IN1.B28	020327:	CAN-IN3.B26
015012:	MONIT-EEr	019542:	FCODE-471.B21	020130:	CAN-IN1.B29	020328:	CAN-IN3.B27
015013:	MONIT-OC1	019543:	FCODE-471.B22	020131:	CAN-IN1.B30	020329:	CAN-IN3.B28
015014:	MONIT-OC2	019544:	FCODE-471.B23	020132:	CAN-IN1.B31	020330:	CAN-IN3.B29
015015:	MONIT-LP1	019545:	FCODE-471.B24	020201:	CAN-IN2.B0	020331:	CAN-IN3.B30
015016:	MONIT-OH	019546:	FCODE-471.B25	020202:	CAN-IN2.B1	020332:	CAN-IN3.B31
015017:	MONIT-OH3	019547:	FCODE-471.B26	020203:	CAN-IN2.B2	025001:	AIF-CTRL.B0
015018:	MONIT-OH4	019548:	FCODE-471.B27	020204:	CAN-IN2.B3	025002:	AIF-CTRL.B1
015019:	MONIT-OH7	019549:	FCODE-471.B28	020205:	CAN-IN2.B4	025003:	AIF-CTRL.B2
015020:	MONIT-OH8	019550:	FCODE-471.B29	020206:	CAN-IN2.B5	025005:	AIF-CTRL.B4
015021:	MONIT-Sd2	019551:	FCODE-471.B30	020207:	CAN-IN2.B6	025006:	AIF-CTRL.B5
015022:	MONIT-Sd3	019552:	FCODE-471.B31	020208:	CAN-IN2.B7	025007:	AIF-CTRL.B6
015023:	MONIT-P03	019751:	FCODE-135.B0	020209:	CAN-IN2.B8	025008:	AIF-CTRL.B7
015024:	MONIT-P13	019752:	FCODE-135.B1	020210:	CAN-IN2.B9	025013:	AIF-CTRL.B12
015026:	MONIT-CE0	019753:	FCODE-135.B2	020211:	CAN-IN2.B10	025014:	AIF-CTRL.B13
015027:	MONIT-NMAX	019755:	FCODE-135.B4	020212:	CAN-IN2.B11	025015:	AIF-CTRL.B14
						025016:	AIF-CTRL.B15




Appendix

List 2 (continued):


025101: AIF-IN.B0
025102: AIF-IN.B1
025103: AIF-IN.B2
025104: AIF-IN.B3
025105: AIF-IN.B4
025106: AIF-IN.B5
025107: AIF-IN.B6
025108: AIF-IN.B7
025109: AIF-IN.B8
025110: AIF-IN.B9
025111: AIF-IN.B10
025112: AIF-IN.B11
025113: AIF-IN.B12
025114: AIF-IN.B13
025115: AIF-IN.B14
025116: AIF-IN.B15
025117: AIF-IN.B16
025118: AIF-IN.B17
025119: AIF-IN.B18
025120: AIF-IN.B19
025121: AIF-IN.B20
025122: AIF-IN.B21
025123: AIF-IN.B22
025124: AIF-IN.B23
025125: AIF-IN.B24
025126: AIF-IN.B25
025127: AIF-IN.B26
025128: AIF-IN.B27
025129: AIF-IN.B28
025130: AIF-IN.B29
025131: AIF-IN.B30
025132: AIF-IN.B31
030000: POS-STARTED
030001: POS-STOPED
030002: POS-ENDED
030003: POS-RESETED
030010: POS-STDBY-ACT
030011: POS-MANU-ACT
030012: POS-REF-OK
030013: POS-IN-TARGET
030014: POS-VTRAV-REA
030015: POS-VFIN-REAC
030016: POS-ACC-RAMP
030017: POS-DCC-RAMP
030101: POS-PF01
030102: POS-PF02
030103: POS-PF03
030104: POS-PF04
030105: POS-PF05
030106: POS-PF06
030107: POS-PF07
030108: POS-PF08
030109: POS-PF09
030110: POS-PF010
030111: POS-PF011
030112: POS-PF012
030113: POS-PF013
030114: POS-PF014
030115: POS-PF015
030116: POS-PF016
030117: POS-PF017
030118: POS-PF018
030119: POS-PF019
030120: POS-PF020
030121: POS-PF021
030122: POS-PF022
030123: POS-PF023
030124: POS-PF024
030125: POS-PF025
030126: POS-PF026
030127: POS-PF027
030128: POS-PF028
030129: POS-PF029
030130: POS-PF030
030131: POS-PF031
030132: POS-PF032
030200: POS-TP1-EN
030201: POS-TP1-RECOG
030202: POS-TP2-EN
030203: POS-TP2-RECOG
030204: POS-TP3-EN
030205: POS-TP3-RECOG
030206: POS-TP4-EN
030207: POS-TP4-RECOG

List 3: Phase signal sources

000100: DFSET-PSET
000101: DFSET-PSET2
001000: FIXEDOINC
005000: MCTRL-PHI-ANG
005520: ARITPH1-OUT
005525: ARITPH2-OUT
005530: ARITPH3-OUT
005535: ARITPH4-OUT
005540: ARITPH5-OUT
005545: ARITPH6-OUT
005775: SELPH1-OUT
005780: SELPH2-OUT
006237: CONVPHPH2-OUT
006600: SYNC1-OUT2
007050: CONVAPH1-OUT
007055: CONVAPH2-OUT
007060: CONVAPH3-OUT
012000: PHINT1-OUT
012050: PHDIV1-OUT
019521: FCODE-474/1
019522: FCODE-474/2
019523: FCODE-474/3
019524: FCODE-474/4
019525: FCODE-474/5
019526: FCODE-474/6
019527: FCODE-474/7
019528: FCODE-474/8
019529: FCODE-474/9
019530: FCODE-474/10
020103: CAN-IN1.D1
020201: CAN-IN2.D1
020202: CAN-IN2.D2
020301: CAN-IN3.D1
020302: CAN-IN3.D2
025103: AIF-IN.D1
025104: AIF-IN.D2
030010: POS-TARGET
030011: POS-VTRAV
030012: POS-VFINAL
030013: POS-ACC
030014: POS-DCC
030015: POS-ASET
030016: POS-VSET
030017: POS-SETPOS
030020: POS-POUT
030021: POS-ACTPOS
031001: VTPOS-OUT1
031002: VTPOS-OUT2
031003: VTPOS-OUT3
031004: VTPOS-OUT4
031005: VTPOS-OUT5
031006: VTPOS-OUT6
031007: VTPOS-OUT7
031008: VTPOS-OUT8
031009: VTPOS-OUT9
031010: VTPOS-OUT10
031011: VTPOS-OUT11
031012: VTPOS-OUT12
031013: VTPOS-OUT13
031014: VTPOS-OUT14
031015: VTPOS-OUT15
031016: VTPOS-OUT16
031017: VTPOS-OUT17
031018: VTPOS-OUT18
031019: VTPOS-OUT19
031020: VTPOS-OUT20
031021: VTPOS-OUT21
031022: VTPOS-OUT22
031023: VTPOS-OUT23
031024: VTPOS-OUT24
031025: VTPOS-OUT25
031026: VTPOS-OUT26
031027: VTPOS-OUT27
031028: VTPOS-OUT28
031029: VTPOS-OUT29
031030: VTPOS-OUT30
031031: VTPOS-OUT31
031032: VTPOS-OUT32
031033: VTPOS-OUT33
031034: VTPOS-OUT34
031035: VTPOS-OUT35
031036: VTPOS-OUT36
031037: VTPOS-OUT37
031038: VTPOS-OUT38
031039: VTPOS-OUT39
031040: VTPOS-OUT40
031041: VTPOS-OUT41
031042: VTPOS-OUT42
031043: VTPOS-OUT43
031044: VTPOS-OUT44
031045: VTPOS-OUT45
031046: VTPOS-OUT46
031047: VTPOS-OUT47
031048: VTPOS-OUT48
031049: VTPOS-OUT49
031050: VTPOS-OUT50
031051: VTPOS-OUT51
031052: VTPOS-OUT52
031053: VTPOS-OUT53
031054: VTPOS-OUT54
031055: VTPOS-OUT55
031056: VTPOS-OUT56
031057: VTPOS-OUT57
031058: VTPOS-OUT58
031059: VTPOS-OUT59
031060: VTPOS-OUT60
031061: VTPOS-OUT61
031062: VTPOS-OUT62
031063: VTPOS-OUT63
031064: VTPOS-OUT64
031065: VTPOS-OUT65
031066: VTPOS-OUT66
031067: VTPOS-OUT67
031068: VTPOS-OUT68
031069: VTPOS-OUT69
031070: VTPOS-OUT70
031071: VTPOS-OUT71
031072: VTPOS-OUT72
031073: VTPOS-OUT73
031074: VTPOS-OUT74
031075: VTPOS-OUT75
031076: VTPOS-OUT76
031077: VTPOS-OUT77
031078: VTPOS-OUT78
031079: VTPOS-OUT79



List 3 (continued):	List 4:	Phase difference signal sources	List 5:	Function blocks	(see processing table)
031080: VTPOS-OUT80	000050: DFIN-OUT		000000: empty	010560: OR3	
031081: VTPOS-OUT81	000100: DFSET-POUT		000050: AIN1	010565: OR4	
031082: VTPOS-OUT82	000250: DFOUT-OUT		000055: AIN2	010570: OR5	
031083: VTPOS-OUT83	001000: FIXEDPHI-0		000070: AOUT1	010600: NOT1	
031084: VTPOS-OUT84	005000: MCTRL-PHI-ACT		000075: AOUT2	010605: NOT2	
031085: VTPOS-OUT85	006000: DFRFG1-OUT		001000: DFSET	010610: NOT3	
031086: VTPOS-OUT86	006220: CONV5-OUT		000200: DFIN	010615: NOT4	
031087: VTPOS-OUT87	006600: SYNC1-OUT1		000250: DFOUT	010620: NOT5	
031088: VTPOS-OUT88	019521: FCODE-475/1		005050: NSET	010650: CMP1	
031089: VTPOS-OUT89	019522: FCODE-475/2		005100: MPOT1	010655: CMP2	
031090: VTPOS-OUT90	030000: POS-PHI-SET		005520: ARITPH1	010700: DIGDEL1	
031091: VTPOS-OUT91			005525: ARITPH2	010705: DIGDEL2	
031092: VTPOS-OUT92			005530: ARITPH3	010750: TRANS1	
031093: VTPOS-OUT93			005535: ARITPH4	010755: TRANS2	
031094: VTPOS-OUT94			005540: ARITPH5	010900: FLIP1	
031095: VTPOS-OUT95			005545: ARITPH6	010905: FLIP2	
031096: VTPOS-OUT96			005550: ADD1	011000: CMPPH1	
031097: VTPOS-OUT97			005600: RFG1	011005: CMPPH2	
031098: VTPOS-OUT98			005650: ASW1	011010: CMPPH3	
031099: VTPOS-OUT99			005655: ASW2	012000: PHINT1	
031100: VTPOS-OUT100			005700: ANEG1	012050: PHDIV1	
031101: VTPOS-OUT101			005705: ANEG2	013000: FEVAN1	
031102: VTPOS-OUT102			005775: SELPH1	013005: FEVAN2	
031103: VTPOS-OUT103			005780: SELPH2	013010: FEVAN3	
031104: VTPOS-OUT104			006000: DFRFG1	013015: FEVAN4	
031201: VTVEL-OUT1			006200: CONV1	013020: FEVAN5	
031202: VTVEL-OUT2			006205: CONV2	013025: FEVAN6	
031203: VTVEL-OUT3			006210: CONV3	013050: BCD1	
031204: VTVEL-OUT4			006215: CONV4	013065: BCD2	
031251: VTACC-OUT1			006220: CONV5	013080: BCD3	
031252: VTACC-OUT2			006230: CONVPHA1	015100: MLP1	
031253: VTACC-OUT3			006232: CONVPHA2	020000: CAN-OUT	
031254: VTACC-OUT4			006234: CONVPHA3	025000: AIF-OUT	
			006237: CONVPHPH2	030000: POS	
			006300: S&H1	030050: POS-SRAMPS	
			006350: CURVE1	031000: VTPOS	
			006400: FCNT1	031200: VTVEL	
			006405: FCNT2	031250: VTACC	
			006410: FCNT3	031300: VTTIME	
			006450: SP1	031350: VTPCS	
			006460: SP2		
			006550: TEACH1		
			006600: SYNC1		
			007050: CONVAPH1		
			007055: CONVAPH2		
			007060: CONVAPH3		
			007150: CONVAD1		
			007170: CONVAD2		
			007200: CONVDA1		
			007205: CONVDA2		
			007210: CONVDA3		
			008000: DISA		
			008050: DISPH		
			010000: BRK1		
			010250: RL/Q		
			010500: AND1		
			010505: AND2		
			010510: AND3		
			010515: AND4		
			010520: AND5		
			010550: OR1		
			010555: OR2		




Appendix

List 10: Faults

000000: No fail
000011: OC1 trip
000012: OC2 trip
000015: OC5 trip
000022: LUQ trip
000032: LP1 trip
000050: OH trip
000053: OH3 trip
000057: OH7 trip
000058: OH8 trip
000061: CEO trip
000062: CE1 trip
000063: CE2 trip
000064: CE3 trip
000065: CE4 trip
000070: U15 trip
000071: CCr trip
000072: Pr1 trip
000073: Pr2 trip
000074: PEr trip
000075: Pr0 trip
000077: Pr3 trip
000078: Pr4 trip
000079: Pl trip
000082: Sd2 trip
000083: Sd3 trip
000085: Sd5 trip
000086: Sd6 trip
000087: Sd7 trip
000091: EEr trip
000105: H05 trip
000107: H07 trip
000110: H10 trip
000111: H11 trip
000151: P01 trip
000152: P02 trip
000153: P03 trip
000154: P04 trip
000155: P05 trip
000156: P06 trip
000157: P07 trip
000158: P08 trip
000159: P09 trip
000162: P12 trip
000163: P13 trip
000164: P14 trip
000165: P15 trip
000166: P16 trip
000167: P17 trip
000168: P18 trip
000200: NMAX trip
001030: LU message
001091: EEr message
002032: LP1 warning
002054: OH4 warning
002057: OH7 warning
002058: OH8 warning
002061: CEO warning
002062: CE1 warning
002063: CE2 warning
002064: CE3 warning
002065: CE4 warning
002082: Sd2 warning
002083: Sd3 warning
002085: Sd5 warning
002086: Sd6 warning
002091: EER warning
002153: P03 warning
002163: P13 warning
002164: P14 warning
002165: P15 warning
002166: P16 warning
002167: P17 warning
002168: P18 warning
003091: EEr QSP
003151: P01 QSP
003152: P02 QSP
003154: P04 QSP
003155: P05 QSP
003156: P06 QSP
003157: P07 QSP
003158: P08 QSP
003159: P09 QSP
003162: P12 QSP
003163: P13 QSP
003164: P14 QSP
003165: P15 QSP
003166: P16 QSP
003167: P17 QSP
003168: P18 QSP

List 11:

000000: Real Zero
000001: VTPOS-No 001
000002: VTPOS-No 002
000003: VTPOS-No 003
000004: VTPOS-No 004
000005: VTPOS-No 005
000006: VTPOS-No 006
000007: VTPOS-No 007
000008: VTPOS-No 008
000009: VTPOS-No 009
000010: VTPOS-No 010
000011: VTPOS-No 011
000012: VTPOS-No 012
000013: VTPOS-No 013
000014: VTPOS-No 014
000015: VTPOS-No 015
000016: VTPOS-No 016
000017: VTPOS-No 017
000018: VTPOS-No 018
000019: VTPOS-No 019
000020: VTPOS-No 020
000021: VTPOS-No 021
000022: VTPOS-No 022
000023: VTPOS-No 023
000024: VTPOS-No 024
000025: VTPOS-No 025
000026: VTPOS-No 026
000027: VTPOS-No 027
000028: VTPOS-No 028
000029: VTPOS-No 029
000030: VTPOS-No 030
000031: VTPOS-No 031
000032: VTPOS-No 032
000033: VTPOS-No 033
000034: VTPOS-No 034
000035: VTPOS-No 035
000036: VTPOS-No 036
000037: VTPOS-No 037
000038: VTPOS-No 038
000039: VTPOS-No 039
000040: VTPOS-No 040
000041: VTPOS-No 041
000042: VTPOS-No 042
000043: VTPOS-No 043
000044: VTPOS-No 044
000045: VTPOS-No 045
000046: VTPOS-No 046
000047: VTPOS-No 047
000048: VTPOS-No 048
000049: VTPOS-No 049
000050: VTPOS-No 050
000051: VTPOS-No 051
000052: VTPOS-No 052
000053: VTPOS-No 053
000054: VTPOS-No 054
000056: VTPOS-No 056
000055: VTPOS-No 055
000057: VTPOS-No 057
000058: VTPOS-No 058
000059: VTPOS-No 059
000060: VTPOS-No 060
000061: VTPOS-No 061




List 12:

000000:	Trav. Range	000062:	VTPOS-No 062
000001:	VTPOS-No 001	000063:	VTPOS-No 063
000002:	VTPOS-No 002	000064:	VTPOS-No 064
000003:	VTPOS-No 003	000065:	VTPOS-No 065
000004:	VTPOS-No 004	000066:	VTPOS-No 066
000005:	VTPOS-No 005	000067:	VTPOS-No 067
000006:	VTPOS-No 006	000068:	VTPOS-No 068
000007:	VTPOS-No 007	000069:	VTPOS-No 069
000008:	VTPOS-No 008	000070:	VTPOS-No 070
000009:	VTPOS-No 009	000071:	VTPOS-No 071
000010:	VTPOS-No 010	000072:	VTPOS-No 072
000011:	VTPOS-No 011	000073:	VTPOS-No 073
000012:	VTPOS-No 012	000074:	VTPOS-No 074
000013:	VTPOS-No 013	000075:	VTPOS-No 075
000014:	VTPOS-No 014	000076:	VTPOS-No 076
000015:	VTPOS-No 015	000077:	VTPOS-No 077
000016:	VTPOS-No 016	000078:	VTPOS-No 078
000017:	VTPOS-No 017	000079:	VTPOS-No 079
000018:	VTPOS-No 018	000080:	VTPOS-No 080
000019:	VTPOS-No 019	000081:	VTPOS-No 081
000020:	VTPOS-No 020	000082:	VTPOS-No 082
000021:	VTPOS-No 021	000083:	VTPOS-No 083
000022:	VTPOS-No 022	000084:	VTPOS-No 084
000023:	VTPOS-No 023	000085:	VTPOS-No 085
000024:	VTPOS-No 024	000086:	VTPOS-No 086
000025:	VTPOS-No 025	000087:	VTPOS-No 087
000026:	VTPOS-No 026	000088:	VTPOS-No 088
000027:	VTPOS-No 027	000089:	VTPOS-No 089
000028:	VTPOS-No 028	000090:	VTPOS-No 090
000029:	VTPOS-No 029	000091:	VTPOS-No 091
000030:	VTPOS-No 030	000092:	VTPOS-No 092
000031:	VTPOS-No 031	000093:	VTPOS-No 093
000032:	VTPOS-No 032	000094:	VTPOS-No 094
000033:	VTPOS-No 033	000095:	VTPOS-No 095
000034:	VTPOS-No 034	000096:	VTPOS-No 096
000035:	VTPOS-No 035	000097:	VTPOS-No 097
000036:	VTPOS-No 036	000098:	VTPOS-No 098
000037:	VTPOS-No 037	000099:	VTPOS-No 099
000038:	VTPOS-No 038	000100:	VTPOS-No 100
000039:	VTPOS-No 039	000101:	VTPOS-No 101
000040:	VTPOS-No 040	000102:	VTPOS-No 102
000041:	VTPOS-No 041	000103:	VTPOS-No 103
000042:	VTPOS-No 042	000104:	VTPOS-No 104
000043:	VTPOS-No 043		
000044:	VTPOS-No 044		
000045:	VTPOS-No 045		
000046:	VTPOS-No 046		
000047:	VTPOS-No 047		
000048:	VTPOS-No 048		
000049:	VTPOS-No 049		
000050:	VTPOS-No 050		
000051:	VTPOS-No 051		
000052:	VTPOS-No 052		
000053:	VTPOS-No 053		
000054:	VTPOS-No 054		
000055:	VTPOS-No 055		
000056:	VTPOS-No 056		
000057:	VTPOS-No 057		
000058:	VTPOS-No 058		
000059:	VTPOS-No 059		
000060:	VTPOS-No 060		
000061:	VTPOS-No 061		

List 13:


000000:	Target = TP	000062:	VTPOS-No 062
000001:	VTPOS-No 001	000063:	VTPOS-No 063
000002:	VTPOS-No 002	000064:	VTPOS-No 064
000003:	VTPOS-No 003	000065:	VTPOS-No 065
000004:	VTPOS-No 004	000066:	VTPOS-No 066
000005:	VTPOS-No 005	000067:	VTPOS-No 067
000006:	VTPOS-No 006	000068:	VTPOS-No 068
000007:	VTPOS-No 007	000069:	VTPOS-No 069
000008:	VTPOS-No 008	000070:	VTPOS-No 070
000009:	VTPOS-No 009	000071:	VTPOS-No 071
000010:	VTPOS-No 010	000072:	VTPOS-No 072
000011:	VTPOS-No 011	000073:	VTPOS-No 073
000012:	VTPOS-No 012	000074:	VTPOS-No 074
000013:	VTPOS-No 013	000075:	VTPOS-No 075
000014:	VTPOS-No 014	000076:	VTPOS-No 076
000015:	VTPOS-No 015	000077:	VTPOS-No 077
000016:	VTPOS-No 016	000078:	VTPOS-No 078
000017:	VTPOS-No 017	000079:	VTPOS-No 079
000018:	VTPOS-No 018	000080:	VTPOS-No 080
000019:	VTPOS-No 019	000081:	VTPOS-No 081
000020:	VTPOS-No 020	000082:	VTPOS-No 082
000021:	VTPOS-No 021	000083:	VTPOS-No 083
000022:	VTPOS-No 022	000084:	VTPOS-No 084
000023:	VTPOS-No 023	000085:	VTPOS-No 085
000024:	VTPOS-No 024	000086:	VTPOS-No 086
000025:	VTPOS-No 025	000087:	VTPOS-No 087
000026:	VTPOS-No 026	000088:	VTPOS-No 088
000027:	VTPOS-No 027	000089:	VTPOS-No 089
000028:	VTPOS-No 028	000090:	VTPOS-No 090
000029:	VTPOS-No 029	000091:	VTPOS-No 091
000030:	VTPOS-No 030	000092:	VTPOS-No 092
000031:	VTPOS-No 031	000093:	VTPOS-No 093
000032:	VTPOS-No 032	000094:	VTPOS-No 094
000033:	VTPOS-No 033	000095:	VTPOS-No 095
000034:	VTPOS-No 034	000096:	VTPOS-No 096
000035:	VTPOS-No 035	000097:	VTPOS-No 097
000036:	VTPOS-No 036	000098:	VTPOS-No 098
000037:	VTPOS-No 037	000099:	VTPOS-No 099
000038:	VTPOS-No 038	000100:	VTPOS-No 100
000039:	VTPOS-No 039	000101:	VTPOS-No 101
000040:	VTPOS-No 040	000102:	VTPOS-No 102
000041:	VTPOS-No 041	000103:	VTPOS-No 103
000042:	VTPOS-No 042	000104:	VTPOS-No 104
000043:	VTPOS-No 043		
000044:	VTPOS-No 044		
000045:	VTPOS-No 045		
000046:	VTPOS-No 046		
000047:	VTPOS-No 047		
000048:	VTPOS-No 048		
000049:	VTPOS-No 049		
000050:	VTPOS-No 050		
000051:	VTPOS-No 051		
000052:	VTPOS-No 052		
000053:	VTPOS-No 053		
000054:	VTPOS-No 054		
000055:	VTPOS-No 055		
000056:	VTPOS-No 056		
000057:	VTPOS-No 057		
000058:	VTPOS-No 058		
000059:	VTPOS-No 059		
000060:	VTPOS-No 060		
000061:	VTPOS-No 061		



Appendix

List 14:	List 15:	List 16:	List 17:
000000: v-max	000000: Standstill	000000: a-max	000000: inactive
000001: VTVEL-No 01	000001: VTVEL-No 01	000001: VTACC-No 01	000001: VTPCS-No 01
000002: VTVEL-No 02	000002: VTVEL-No 02	000002: VTACC-No 02	000002: VTPCS-No 02
000003: VTVEL-No 03	000003: VTVEL-No 03	000003: VTACC-No 03	000003: VTPCS-No 03
000004: VTVEL-No 04	000004: VTVEL-No 04	000004: VTACC-No 04	000004: VTPCS-No 04
000005: VTVEL-No 05	000005: VTVEL-No 05	000005: VTACC-No 05	000005: VTPCS-No 05
000006: VTVEL-No 06	000006: VTVEL-No 06	000006: VTACC-No 06	000006: VTPCS-No 06
000007: VTVEL-No 07	000007: VTVEL-No 07	000007: VTACC-No 07	000007: VTPCS-No 07
000008: VTVEL-No 08	000008: VTVEL-No 08	000008: VTACC-No 08	000008: VTPCS-No 08
000009: VTVEL-No 09	000009: VTVEL-No 09	000009: VTACC-No 09	000009: VTPCS-No 09
000010: VTVEL-No 10	000010: VTVEL-No 10	000010: VTACC-No 10	000010: VTPCS-No 10
000011: VTVEL-No 11	000011: VTVEL-No 11	000011: VTACC-No 11	000011: VTPCS-No 11
000012: VTVEL-No 12	000012: VTVEL-No 12	000012: VTACC-No 12	000012: VTPCS-No 12
000013: VTVEL-No 13	000013: VTVEL-No 13	000013: VTACC-No 13	000013: VTPCS-No 13
000014: VTVEL-No 14	000014: VTVEL-No 14	000014: VTACC-No 14	000014: VTPCS-No 14
000015: VTVEL-No 15	000015: VTVEL-No 15	000015: VTACC-No 15	000015: VTPCS-No 15
000016: VTVEL-No 16	000016: VTVEL-No 16	000016: VTACC-No 16	000016: VTPCS-No 16
000017: VTVEL-No 17	000017: VTVEL-No 17	000017: VTACC-No 17	000017: VTPCS-No 17
000018: VTVEL-No 18	000018: VTVEL-No 18	000018: VTACC-No 18	000018: VTPCS-No 18
000019: VTVEL-No 19	000019: VTVEL-No 19	000019: VTACC-No 19	000019: VTPCS-No 19
000020: VTVEL-No 20	000020: VTVEL-No 20	000020: VTACC-No 20	000020: VTPCS-No 20
000021: VTVEL-No 21	000021: VTVEL-No 21	000021: VTACC-No 21	000021: VTPCS-No 21
000022: VTVEL-No 22	000022: VTVEL-No 22	000022: VTACC-No 22	000022: VTPCS-No 22
000023: VTVEL-No 23	000023: VTVEL-No 23	000023: VTACC-No 23	000023: VTPCS-No 23
000024: VTVEL-No 24	000024: VTVEL-No 24	000024: VTACC-No 24	000024: VTPCS-No 24
000025: VTVEL-No 25	000025: VTVEL-No 25	000025: VTACC-No 25	000025: VTPCS-No 25
000026: VTVEL-No 26	000026: VTVEL-No 26	000026: VTACC-No 26	000026: VTPCS-No 26
000027: VTVEL-No 27	000027: VTVEL-No 27	000027: VTACC-No 27	000027: VTPCS-No 27
000028: VTVEL-No 28	000028: VTVEL-No 28	000028: VTACC-No 28	000028: VTPCS-No 28
000029: VTVEL-No 29	000029: VTVEL-No 29	000029: VTACC-No 29	000029: VTPCS-No 29
000030: VTVEL-No 30	000030: VTVEL-No 30	000030: VTACC-No 30	000030: VTPCS-No 30
000031: VTVEL-No 31	000031: VTVEL-No 31	000031: VTACC-No 31	000031: VTPCS-No 31
000032: VTVEL-No 32	000032: VTVEL-No 32	000032: VTACC-No 32	000032: VTPCS-No 32
000033: VTVEL-No 33	000033: VTVEL-No 33	000033: VTACC-No 33	000033: VTPCS-No 33
000034: VTVEL-No 34	000034: VTVEL-No 34	000034: VTACC-No 34	000034: VTPCS-No 34

Appendix



List 18:


000000: inactive
 000001: VTTIME-No 01
 000002: VTTIME-No 02
 000003: VTTIME-No 03
 000004: VTTIME-No 04
 000005: VTTIME-No 05
 000006: VTTIME-No 06
 000007: VTTIME-No 07
 000008: VTTIME-No 08
 000009: VTTIME-No 09
 000010: VTTIME-No 10
 000011: VTTIME-No 11
 000012: VTTIME-No 12
 000013: VTTIME-No 13
 000014: VTTIME-No 14
 000015: VTTIME-No 15
 000016: VTTIME-No 16
 000017: VTTIME-No 17
 000018: VTTIME-No 18
 000019: VTTIME-No 19
 000020: VTTIME-No 20
 000021: VTTIME-No 21
 000022: VTTIME-No 22
 000023: VTTIME-No 23
 000024: VTTIME-No 24
 000025: VTTIME-No 25
 000026: VTTIME-No 26
 000027: VTTIME-No 27
 000028: VTTIME-No 28
 000029: VTTIME-No 29
 000030: VTTIME-No 30
 000031: VTTIME-No 31
 000032: VTTIME-No 32
 000033: VTTIME-No 33
 000034: VTTIME-No 34

List 19:

000000: Prg. end
 000001: PS 01
 000002: PS 02
 000003: PS 03
 000004: PS 04
 000005: PS 05
 000006: PS 06
 000007: PS 07
 000008: PS 08
 000009: PS 09
 000010: PS 10
 000011: PS 11
 000012: PS 12
 000013: PS 13
 000014: PS 14
 000015: PS 15
 000016: PS 16
 000017: PS 17
 000018: PS 18
 000019: PS 19
 000020: PS 20
 000021: PS 21
 000022: PS 22
 000023: PS 23
 000024: PS 24
 000025: PS 25
 000026: PS 26
 000027: PS 27
 000028: PS 28
 000029: PS 29
 000030: PS 30
 000031: PS 31
 000032: PS 32

List 20:

000000: inactive
 000001: VTPOS-No 001
 000002: VTPOS-No 002
 000003: VTPOS-No 003
 000004: VTPOS-No 004
 000005: VTPOS-No 005
 000006: VTPOS-No 006
 000007: VTPOS-No 007
 000008: VTPOS-No 008
 000009: VTPOS-No 009
 000010: VTPOS-No 010
 000011: VTPOS-No 011
 000012: VTPOS-No 012
 000013: VTPOS-No 013
 000014: VTPOS-No 014
 000015: VTPOS-No 015
 000016: VTPOS-No 016
 000017: VTPOS-No 017
 000018: VTPOS-No 018
 000019: VTPOS-No 019
 000020: VTPOS-No 020
 000021: VTPOS-No 021
 000022: VTPOS-No 022
 000023: VTPOS-No 023
 000024: VTPOS-No 024
 000025: VTPOS-No 025
 000026: VTPOS-No 026
 000027: VTPOS-No 027
 000028: VTPOS-No 028
 000029: VTPOS-No 029
 000030: VTPOS-No 030
 000031: VTPOS-No 031
 000032: VTPOS-No 032
 000033: VTPOS-No 033
 000034: VTPOS-No 034
 000035: VTPOS-No 035
 000036: VTPOS-No 036
 000037: VTPOS-No 037
 000038: VTPOS-No 038
 000039: VTPOS-No 039
 000040: VTPOS-No 040
 000041: VTPOS-No 041
 000042: VTPOS-No 042
 000043: VTPOS-No 043
 000044: VTPOS-No 044
 000045: VTPOS-No 045
 000046: VTPOS-No 046
 000047: VTPOS-No 047
 000048: VTPOS-No 048
 000049: VTPOS-No 049
 000050: VTPOS-No 050
 000051: VTPOS-No 051
 000052: VTPOS-No 052
 000053: VTPOS-No 053
 000054: VTPOS-No 054
 000055: VTPOS-No 055
 000056: VTPOS-No 056
 000057: VTPOS-No 057
 000058: VTPOS-No 058
 000059: VTPOS-No 059
 000060: VTPOS-No 060
 000061: VTPOS-No 061



Appendix

10.4 Motor selection list

10.4.1 Servo motors




Tip!

For the parameter setting of the drive the available motor type is to be entered under code C0086. This value is indicated on the nameplate.

Example: "161". The motor designation behind this number is shown in the display "DSKS56-33-200".


If the code value is > 269:
See Reference List for servo
motors




9300std201

C0086 Value	Name	Lenze motor type	C0081 P _N [kW]	C0087 n _N [rpm]	C0088 I _N [A]	C0089 f _N [Hz]	C0090 a _N [V]	Motor type	Thermal sensor
10	MDSKA56-140	MDSKAXX056-22	0.80	3950	2.4	140		390	Asynchronous servo motor
11	MDFKA71-120	MDFKAXX071-22	2.20	3410	6.0	120			
12	MDSKA71-140	MDSKAXX071-22	1.70	4050	4.4	140			
13	MDFKA80-60	MDFKAXX080-22	2.10	1635	4.8	60			
14	MDSKA80-70	MDSKAXX080-22	1.40	2000	3.3	70			
15	MDFKA80-120	MDFKAXX080-22	3.90	3455	9.1	120			
16	MDSKA80-140	MDSKAXX080-22	2.30	4100	5.8	140			
17	MDFKA90-60	MDFKAXX090-22	3.80	1680	8.5	60			
18	MDSKA90-80	MDSKAXX090-22	2.60	2300	5.5	80			
19	MDFKA90-120	MDFKAXX090-22	6.90	3480	15.8	120			
20	MDSKA90-140	MDSKAXX090-22	4.10	4110	10.2	140	350		
21	MDFKA100-60	MDFKAXX100-22	6.40	1700	13.9	60		390	KTY
22	MDSKA100-80	MDSKAXX100-22	4.00	2340	8.2	80			
23	MDFKA100-120	MDFKAXX100-22	13.20	3510	28.7	120			
24	MDSKA100-140	MDSKAXX100-22	5.20	4150	14.0	140	330	360	
25	MDFKA112-60	MDFKAXX112-22	11.00	1710	22.5	60			
26	MDSKA112-85	MDSKAXX112-22	6.40	2490	13.5	85			
27	MDFKA112-120	MDFKAXX112-22	20.30	3520	42.5	120			
28	MDSKA112-140	MDSKAXX112-22	7.40	4160	19.8	140	320		
30	DFQA100-50	MDFQAXX100-22	10.60	1420	26.5	50			
31	DFQA100-100	MDFQAXX100-22	20.30	2930	46.9	100			
32	DFQA112-28	MDFQAXX112-22	11.50	760	27.2	28			
33	DFQA112-58	MDFQAXX112-22	22.70	1670	49.1	58			
34	DFQA132-20	MDFQAXX132-32	17.00	550	45.2	20			
35	DFQA132-42	MDFQAXX132-32	40.30	1200	88.8	42			
40	DFQA112-50	MDFQAXX112-22	20.10	1425	43.7	50			
41	DFQA112-100	MDFQAXX112-22	38.40	2935	81.9	100			
42	DFQA132-36	MDFQAXX132-32	36.40	1030	77.4	39			
43	DFQA132-76	MDFQAXX132-32	60.10	2235	144.8	76	340		

Appendix



C0086 Value	Lenze motor type Name	C0081 P _N [kW]	C0087 n _N [rpm]	C0088 I _N [A]	C0089 f _N [Hz]	C0090 a _N [V]	Motor type	Thermal sensor	
50	DSVA56-140	DSVAXX056-22	0.80	3950	2.4	140	390	TKO (Thermostat)	
51	DFVA71-120	DFVAXX071-22	2.20	3410	6.0	120			
52	DSVA71-140	DSVAXX071-22	1.70	4050	4.4	140			
53	DFVA80-60	DFVAXX080-22	2.10	1635	4.8	60			
54	DSVA80-70	DSVAXX080-22	1.40	2000	3.3	70			
55	DFVA80-120	DFVAXX080-22	3.90	3455	9.1	120			
56	DSVA80-140	DSVAXX080-22	2.30	4100	5.8	140			
57	DFVA90-60	DFVAXX090-22	3.80	1680	8.5	60			
58	DSVA90-80	DSVAXX090-22	2.60	2300	5.5	80			
59	DFVA90-120	DFVAXX090-22	6.90	3480	15.8	120			
60	DSVA90-140	DSVAXX090-22	4.10	4110	10.2	140	350		
61	DFVA100-60	DFVAXX100-22	6.40	1700	13.9	60	390	KTY	
62	DSVA100-80	DSVAXX100-22	4.00	2340	8.2	80			
63	DFVA100-120	DFVAXX100-22	13.20	3510	28.7	120			
64	DSVA100-140	DSVAXX100-22	5.20	4150	14.0	140	330		
65	DFVA112-60	DFVAXX112-22	11.00	1710	22.5	60	390		
66	DSVA112-85	DSVAXX112-22	6.40	2490	13.5	85			
67	DFVA112-120	DFVAXX112-22	20.30	3520	42.5	120			
68	DSVA112-140	DSVAXX112-22	7.40	4160	19.8	140	320		
108	DSKS36-13-200	MDSKSXX036-13	0.25	4000	0.9	200	245	Synchronous servo motor	
109	DSKS36-23-200	MDSKSXX036-23	0.54	4000	1.1	200	345		
110	MDSKS56-23-150	MDSKSXX056-23	0.60	3000	1.25	150	350		
111	MDSKS56-33-150	MDSKSXX056-33	0.91	3000	2.0	150	340		
112	MDSKS71-13-150	MDSKSXX071-13	1.57	3000	3.1	150	360		
113	MDFKS71-13-150	MDFKSXX071-13	2.29	3000	4.35	150	385		
114	MDSKS71-23-150	MDSKSXX071-23	2.33	3000	4.85	150	360		
115	MDFKS71-23-150	MDFKSXX071-23	3.14	3000	6.25	150	375		
116	MDSKS71-33-150	MDSKSXX071-33	3.11	3000	6.7	150	330		
117	MDFKS71-33-150	MDFKSXX071-33	4.24	3000	9.1	150	345		
160	DSKS56-23-190	MDSKSXX056-23	1.1	3800	2.3	190	330		
161	DSKS56-33-200	MDSKSXX056-33	1.8	4000	3.6	200	325		
162	DSKS71-03-170	MDSKSXX071-03	2.0	3400	4.2	170	330		
163	DFKS71-03-165	MDFKSXX071-03	2.6	3300	5.6	165	330		
164	DSKS71-13-185	MDSKSXX071-13	3.2	3700	7.0	185	325		
165	DFKS71-13-180	MDFKSXX071-13	4.1	3600	9.2	180	325		
166	DSKS71-33-180	MDSKSXX071-33	4.6	3600	10.0	180	325		
167	DFKS71-33-175	MDFKSXX071-33	5.9	3500	13.1	175	325		



Appendix

Reference List for servo motors




Tip!

The motors listed under "Nameplate data" are available with GDC and unit software.

1. Please enter the value stated for your motor under C0086 in GDC or the keypad.
2. Then check all codes listed in the table.
Overwrite the entry in GDC or the keypad with the values indicated in the table.
3. If necessary, codes C0070 and C0071 must be adapted to your machine.

Nameplate		Data entry													
		C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076
Field: C86	Field: Motor type	I _{max} [A]	P _r [kW]	R _s [Ω]	L _σ [mH]	n _r [rpm]	I _r [A]	f _r [Hz]	a _r [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}	
1000	MDSKA-71-22	54	3.75	0.88	8.4	34.98	1950	2.50	70	390	0.82	2	100	1.5	1.5
1001	MDFQA-112-12	33	42.60	12.90	0.45	4.3	1660	28.40	58	360	0.85	20	21	2	1
1002	MDFQA-112-12	41	70.50	21.80	0.45	4.3	2930	47.00	100	360	0.83	14	21	1.3	1
1003	MDSKA-56-22	50	6.75	1.57	2.25	6.5	6000	4.50	202	280	0.72	3	50	1.3	1.5
1004	MDSKS071-33-39	112	5.10	0.95	7.2	34.5	780	3.40	39	325	1.00	3	20	2.5	1.5
1005	MDSKS071-33-41	112	2.25	0.45	16.3	68	820	1.50	41	330	1.00	2	20	2.5	1.5
1076	MDSKS071-33-90	112	5.85	1.60	3.67	17.7	1800	3.90	90	310	1.00	10	20	0.7	1.7
1077	MDSKA-71-22	51	2.18	0.33	35.7	131.8	725	1.45	30	360	0.78	10	70	1.5	2
1103	SDSGA056-22	50	1.20	0.24	29.3	123	2790	0.80	100	390	0.71	14	150	0.35	1.8
1104	SDSGA056-22	40	2.55	0.24	29.3	123	2790	1.70	100	230	0.71	14	150	0.35	1.8
1105	SDSGA063-22	50	1.80	0.40	29.3	123	2800	1.20	100	390	0.70	14	150	0.35	1.8
1106	SDSGA063-22	40	3.15	0.40	29.3	123	2800	2.10	100	230	0.70	14	150	0.35	1.8
1107	SDSGA063-32	50	2.55	0.60	29.3	123	2800	1.70	100	390	0.70	14	150	0.35	1.8
1108	SDSGA063-32	40	4.50	0.6	29.3	123	2800	3	100	230	0.70	14	150	0.35	1.8
1109	MDSKS056-23-280	114	8.00	1.10	6.72	8.34	5600	2.30	280	320	1.00	10	20	1.3	1.5
1110	MDSKS056-23-310	114	9.00	1.10	5.42	6.78	6200	2.30	310	320	1.00	10	20	1.3	1.5
1111	MDSKS056-33-300	114	10.00	1.75	3.31	4.62	6000	3.60	300	320	1.00	10	20	1.3	1.5
1112	MDSKS056-33-265	114	8.00	1.72	4.1	5.73	5300	3.60	265	320	1.00	10	20	1.3	1.5
1113	MDSKS071-13-265	114	23.00	3.20	0.54	2.56	5300	7.00	265	320	1.00	10	20	1.3	1.5
1116	MDSKS071-33-270	114	25.00	5.70	0.38	1.91	5400	12.50	270	320	1.00	10	20	1.3	1.5



10.4.2 Three-phase asynchronous motors




Tip!

If the code is > 269:
See Reference List for motor types
MDXMA

Lenze Hans-Lenze-Straße 1 · D-31855 Aerzen						
Made in Germany						
3-MOT	Typ	MDFMA	112-22B	IP 54	I.CI F	KTY/TKO
Y/Y/Δ	400/480/400 V	50/60/87 Hz	1435/1735/2545 min ⁻¹			
4.00	80/7.10	W	8.30/8.30/14.3 A	cosφ	0.82/0.82/0.83	
Geber:			Bremse	V-	A	Nr.
C86: Y50:1022/Δ87:1023						
Auftr.Nr.			Typ-Nr.		Mot.Nr.	

Types DXRAXX

Value	GDC / Display	Nameplate	C0081	C0087	C0088	C0089	C0090	Motor type	Thermal sensor
	Name		P _r [kW]	n _r [rpm]	I _r [A]	f _r [Hz]	a _r [V]		
210	DXRAXX071-12-50	DXRAXX071-12	0.25	1410	0.9				
211	DXRAXX071-22-50	DXRAXX071-22	0.37	1398	1.2				
212	DXRAXX080-12-50	DXRAXX080-12	0.55	1400	1.7				
213	DXRAXX080-22-50	DXRAXX080-22	0.75	1410	2.3				
214	DXRAXX090-12-50	DXRAXX090-12	1.10	1420	2.7				
215	DXRAXX090-32-50	DXRAXX090-32	1.50	1415	3.6				
216	DXRAXX100-22-50	DXRAXX100-22	2.20	1425	4.8				
217	DXRAXX100-32-50	DXRAXX100-32	3.00	1415	6.6				
218	DXRAXX112-12-50	DXRAXX112-12	4.00	1435	8.3				
219	DXRAXX132-12-50	DXRAXX132-12	5.50	1450	11.0				
220	DXRAXX132-22-50	DXRAXX132-22	7.50	1450	14.6				
221	DXRAXX160-12-50	DXRAXX160-12	11.00	1460	21.0				
222	DXRAXX160-22-50	DXRAXX160-22	15.00	1460	27.8				
223	DXRAXX180-12-50	DXRAXX180-12	18.50	1470	32.8				
224	DXRAXX180-22-50	DXRAXX180-22	22.00	1456	38.8				
225	30kW-ASM-50	-	30.00	1470	52.0				
226	37kW-ASM-50	-	37.00	1470	66.0				
227	45kW-ASM-50	-	45.00	1480	82.0				
228	55kW-ASM-50	-	55.00	1480	93.0				
229	75kW-ASM-50	-	75.00	1480	132.0				



Appendix

Value	GDC / Display Name	Nameplate		C0081	C0087	C0088	C0089	C0090	Motor type		Thermal sensor	
		P _r [kW]	n _r [rpm]	I _r [A]	f _r [Hz]	a _r [V]						
250	DXRAXX071-12-87	DXRAXX071-12	0.43	2525	1.5							
251	DXRAXX071-22-87	DXRAXX071-22	0.64	2515	2.0							
252	DXRAXX080-12-87	DXRAXX080-12	0.95	2515	2.9							
253	DXRAXX080-22-87	DXRAXX080-22	1.3	2525	4.0							
254	DXRAXX090-12-87	DXRAXX090-12	2.0	2535	4.7							
255	DXRAXX090-32-87	DXRAXX090-32	2.7	2530	6.2							
256	DXRAXX100-22-87	DXRAXX100-22	3.9	2535	8.3							
257	DXRAXX100-32-87	DXRAXX100-32	5.35	2530	11.4							
258	DXRAXX112-12-87	DXRAXX112-12	7.10	2545	14.3							
259	DXRAXX132-12-87	DXRAXX132-12	9.7	2555	19.1							
260	DXRAXX132-22-87	DXRAXX132-22	13.2	2555	25.4							
261	DXRAXX160-12-87	DXRAXX160-12	19.3	2565	36.5							
262	DXRAXX160-22-87	DXRAXX160-22	26.4	2565	48.4							
263	DXRAXX180-12-87	DXRAXX180-12	32.4	2575	57.8							
264	DXRAXX180-22-87	DXRAXX180-22	38.7	2560	67.4							
265	30kW-ASM-50	-	52.00	2546	90.0							
266	37kW-ASM-50	-	64.00	2546	114.0							
267	45kW-ASM-50	-	78.00	2563	142.0							
268	55kW-ASM-50	-	95.00	2563	161.0							
269	75kW-ASM-50	-	130.00	2563	228.0							

Reference List for motor types MDXMA




Tip!


The motors listed under "Nameplate data" are available with GDC and unit software.

1. Please enter the value stated for your motor under C0086 in GDC or the keypad.
2. Then check all codes listed in the table.
Overwrite the entry in GDC or the keypad with the values indicated in the table.
3. If necessary, codes C0070 and C0071 must be adapted to your machine.

Nameplate		Data entry													
		C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076
Field: C86	Field: Motor type	Imax [A]	P _N [kW]	R _S [Ω]	L _σ [mH]	n _N [rpm]	I _N [A]	f _N [Hz]	a _N [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}	
410	MDXMAXM-071-12	210	1.23	0.25	35.80	116.80	1400	0.82	50	400	0.70	6	300	1.5	10
411	MDXMAXM-071-32	211	1.80	0.37	27.00	112.70	1400	1.20	50	400	0.71	6	300	1.5	10
412	MDXMAXM-080-12	212	2.40	0.55	16.30	78.60	1400	1.60	50	400	0.72	6	300	1.5	10
413	MDXMAXM-080-32	213	3.00	0.75	11.20	59.30	1380	2.00	50	400	0.76	6	300	1.5	10
414	MDXMAXM-090-12	214	3.90	1.10	9.14	41.80	1410	2.60	50	400	0.80	6	300	1.5	10
415	MDXMAXM-090-32	215	5.25	1.50	5.10	27.70	1420	3.50	50	400	0.80	6	300	1.5	10
416	MDXMAXM-100-12	216	8.40	2.20	2.96	18.20	1400	5.60	50	400	0.78	6	300	1.5	10
417	MDXMAXM-100-32	217	10.95	3.00	2.20	13.40	1400	7.30	50	400	0.81	6	300	1.5	10
418	MDXMAXM-112-22	218	12.75	4.00	1.50	10.80	1430	8.50	50	400	0.85	6	300	1.5	10
440	MDXMAXM-071-12	250	2.10	0.43	35.8	116.80	2510	1.40	87	400	0.70	6	300	1.5	10
441	MDXMAXM-071-32	251	3.15	0.64	27.0	112.70	2510	2.10	87	400	0.71	6	300	1.5	10
442	MDXMAXM-080-12	252	4.20	0.95	16.3	78.60	2510	2.80	87	400	0.72	6	300	1.5	10
443	MDXMAXM-080-32	253	5.25	1.30	11.2	59.30	2490	3.50	87	400	0.76	6	300	1.5	10
444	MDXMAXM-090-12	254	6.75	2.00	9.14	41.80	2520	4.50	87	400	0.80	6	300	1.5	10




Nameplate		Data entry													
		C0086	C0022	C0081	C0084	C0085	C0087	C0088	C0089	C0090	C0091	C0070	C0071	C0075	C0076
Field: C86	Field: Motor type	I _{max} [A]	P _N [kW]	R _S [Ω]	L σ [mH]	n _N [rpm]	I _N [A]	f _N [Hz]	a _N [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}	
445	MDXMAXM-090-32	255	9.15	2.70	5.1	27.70	2530	6.10	87	400	0.78	6	300	1.5	10
446	MDXMAXM-100-12	256	14.55	3.90	2.96	18.20	2510	9.70	87	400	0.81	6	300	1.5	10
447	MDXMAXM-100-32	257	19.05	5.40	2.2	13.40	2510	12.70	87	400	0.85	6	300	1.5	10
448	MDXMAXM-112-22	258	22.20	7.10	1.5	10.80	2540	14.80	87	400	0.78	6	300	1.5	10
449	MDXMAXM-112-32	259	18.75	5.50	2.45	21.40	1440	12.50	50	400	0.78	6	300	1.5	10
450	MDXMAXM-132-22	259	25.20	7.50	1.42	15.00	1460	16.80	50	400	0.77	6	300	1.5	10
451	MDXMAXM-132-32	259	29.25	9.20	1.34	14.00	1450	19.50	50	400	0.85	6	300	1.5	10
1006	MDXMAXx-071-12	210	1.28	0.25	39.90	157.20	1355	0.85	50	400	0.70	6	300	3.6	2
1007	MDXMAXx-071-12	250	2.25	0.47	39.90	157.20	2475	1.50	87	400	0.66	6	300	2	2
1008	MDXMAXx-071-32	211	1.73	0.37	25.03	122.60	1345	1.15	50	400	0.74	6	300	3.4	2
1009	MDXMAXx-071-32	251	3.00	0.67	25.03	122.60	2470	2.00	87	400	0.70	6	300	2.5	2
1010	MDXMAXx-080-12	212	2.40	0.55	20.69	89.00	1370	1.60	50	400	0.78	6	300	3.2	2
1011	MDXMAXx-080-12	252	3.90	1.00	20.69	89.00	2480	2.60	87	400	0.73	6	300	1.6	2
1012	MDXMAXx-080-32	213	2.85	0.75	11.69	65.20	1390	1.90	50	400	0.80	6	300	3.5	2
1013	MDXMAXx-080-32	253	4.95	1.35	11.69	65.20	2510	3.30	87	400	0.77	6	300	1.9	3
1014	MDXMAXx-090-12	214	3.90	1.10	10.01	40.20	1405	2.60	50	400	0.80	6	300	2.5	2
1015	MDXMAXx-090-12	254	6.75	2.00	10.01	40.20	2520	4.50	87	400	0.77	6	300	2	2
1016	MDXMAXx-090-32	215	5.25	1.50	5.85	28.80	1410	3.50	50	400	0.78	6	300	2	2
1017	MDXMAXx-090-32	255	9.15	2.70	5.85	28.80	2525	6.10	87	400	0.76	6	300	1	2
1018	MDXMAXx-100-12	216	7.20	2.20	2.90	20.00	1425	4.80	50	400	0.80	6	300	1	1.5
1019	MDXMAXx-100-12	256	12.45	3.90	2.90	20.00	2535	8.30	87	400	0.76	6	300	0.8	1.5
1020	MDXMAXx-100-32	217	9.75	3.00	2.10	17.00	1415	6.50	50	400	0.81	6	300	2.5	1.5
1021	MDXMAXx-100-32	257	17.10	5.40	2.10	17.00	2530	11.40	87	400	0.78	6	300	1.4	1.8
1022	MDXMAXx-112-22	218	12.45	4.00	1.50	11.00	1435	8.30	50	400	0.82	6	300	2	2
1023	MDXMAXx-112-22	258	21.45	7.10	1.50	11.00	2545	14.30	87	400	0.83	6	300	1	2
1024	MDXMAXx-132-12	219	16.50	5.50	0.86	13.00	1450	11.00	50	400	0.84	6	300	1.5	2
1025	MDXMAXx-132-12	259	28.65	9.70	0.86	13.00	2555	19.10	87	400	0.83	6	300	1.3	2
1026	MDXMAXx-132-22	220	21.90	7.50	0.80	11.00	1450	14.60	50	400	0.85	6	300	1.5	2
1027	MDXMAXx-132-22	260	38.10	13.20	0.80	11.00	2555	25.40	87	400	0.84	6	300	0.95	1.8
1028	MDXMAXx-160-22	221	31.50	11.00	0.50	7.00	1460	21.00	50	400	0.85	6	300	1.9	2.2
1029	MDXMAXx-160-22	261	54.75	19.30	0.50	7.00	2565	36.50	87	400	0.85	6	300	1	2
1030	MDXMAXx-160-32	222	41.70	15.00	0.40	5.50	1460	27.80	50	400	0.87	6	300	1.7	2.5
1031	MDXMAXx-160-32	262	72.60	26.40	0.40	5.50	2565	48.40	87	400	0.86	6	300	1	1.8
1032	MDXMAXx-180-12	223	49.20	18.50	0.40	4.00	1470	32.80	50	400	0.90	6	300	1.4	1.7
1033	MDXMAXx-180-12	263	86.70	32.40	0.40	4.00	2575	57.80	87	400	0.89	6	300	1	1.7
1034	MDXMAXx-180-22	224	58.20	22.00	0.20	3.80	1456	38.80	50	400	0.90	6	300	1	1.5
1035	MDXMAXx-180-22	264	101.1	38.70	0.20	3.80	2560	67.40	87	400	0.89	6	300	1	1.5
1036	MDXMAXM-63-12	210	0.68	0.12	87.58	610.53	1390	0.45	50	400	0.65	6	300	1.5	10
1037	MDXMAXM-63-12	250	1.17	0.21	87.58	610.53	2500	0.78	87	400	0.65	6	300	1.5	10
1038	MDXMAXM-63-32	210	0.98	0.18	56.90	342.11	1400	0.65	50	400	0.65	6	300	1.5	10
1039	MDXMAXM-63-32	250	1.70	0.31	56.90	342.11	2510	1.13	87	400	0.65	6	300	1.5	10
1040	MDXMAXM-112-32	219	18.75	5.50	0.86	7.20	1440	12.50	50	400	0.78	6	300	1.5	10
1041	MDXMAXM-112-32	259	32.55	9.60	0.86	7.20	2550	21.70	87	400	0.78	6	300	1.5	10
1042	MDXMAXM-132-22	220	25.20	7.50	0.54	4.80	1460	16.80	50	400	0.77	6	300	1.5	10
1043	MDXMAXM-132-22	260	43.80	13.10	0.54	4.80	2570	29.20	87	400	0.77	6	300	1.5	10
1044	MDXMAXM-132-32	221	29.25	9.20	0.46	4.70	1450	19.50	50	400	0.85	6	300	1.5	10
1045	MDXMAXM-132-32	261	50.70	16.00	0.46	4.70	2560	33.80	87	400	0.85	6	300	1.5	10
1046	MDXMAXM-160-22	260	31.50	11.00	1.27	18.97	1466	21.00	50	400	0.86	6	300	1.5	10
1047	MDXMAXM-160-32	260	42.30	15.00	0.87	14.28	1466	28.20	50	400	0.87	6	300	1.5	10
1048	MDXMAXM-180-22	260	54.60	18.50	0.40	4.00	1440	36.40	50	400	0.87	6	300	1.5	10
1049	MDXMAXM-180-32	260	66.15	22.00	0.20	3.80	1465	44.10	50	400	0.85	6	300	1.5	10
1050	MDXMAXM-200-32	260	90.00	30.00	0.17	3.50	1455	60.00	50	400	0.85	6	300	1.5	10




Appendix

Nameplate		Data entry													
Field: C86	Field: Motor type	C0086	I _{max} [A]	P _N [kW]	R _s [Ω]	L σ [mH]	n _N [rpm]	I _N [A]	f _N [Hz]	a _N [V]	cos φ	V _{pn}	T _{nn}	V _{pi}	T _{ni}
1051	MDXMAXM-225-12	260	108.0	37.00	0.15	2.00	1460	72.00	50	400	0.86	6	300	1.5	10
1052	MDXMAXM-225-22	260	128.25	45.00	0.15	2.00	1475	85.50	50	400	0.84	6	300	1.5	10
1053	MDXMAXM-063-11	210	1.43	0.18	51.00	273.7	2760	0.95	50	400	0.80	6	300	1.5	10
1054	MDXMAXM-063-31	210	1.65	0.25	33.00	93.4	2760	1.10	50	400	0.83	6	300	1.5	10
1055	MDXMAXM-071-11	211	1.50	0.37	22.50	90.2	2840	1.00	50	400	0.78	6	300	1.5	10
1056	MDXMAXM-071-31	212	2.25	0.55	16.90	62.9	2840	1.50	50	400	0.82	6	300	1.5	10
1057	MDXMAXM-080-11	213	2.85	0.75	11.36	47.4	2850	1.90	50	400	0.80	6	300	1.5	10
1058	MDXMAXM-080-31	214	4.20	1.10	6.86	33.4	2810	2.80	50	400	0.82	6	300	1.5	10
1059	MDXMAXM-090-11	215	4.80	1.50	5.10	22.2	2840	3.20	50	400	0.85	6	300	1.5	10
1060	MDXMAXM-090-31	216	7.20	2.20	3.20	14.5	2840	4.80	50	400	0.86	6	300	1.5	10
1061	MDXMAXM-100-31	217	9.30	3.00	1.81	10.7	2850	6.20	50	400	0.88	6	300	1.5	10
1062	MDXMAXM-100-41	218	12.75	4.00	1.45	8.6	2830	8.50	50	400	0.85	6	300	1.5	10
1063	MDXMAXM-112-31	250	18.30	5.50	3.10	17	2890	12.20	50	400	0.83	6	300	1.5	10
1064	MDXMAXM-112-41	250	23.25	7.50	1.96	12	2900	15.50	50	400	0.87	6	300	1.5	10
1065	MDXMAXM-132-21	250	28.05	9.00	1.41	11.292	2925	18.70	50	400	0.89	6	300	1.5	10
1066	MDXMAXM-071-13	210	1.13	0.18	58.93	342	870	0.75	50	400	0.71	6	300	1.5	10
1067	MDXMAXM-071-13	250	1.95	0.31	58.93	342	1610	1.30	87	400	0.71	6	300	1.5	10
1068	MDXMAXM-071-33	210	1.50	0.25	37.90	116.8	920	1.00	50	400	0.63	6	300	1.5	10
1069	MDXMAXM-071-33	250	2.55	0.43	37.90	116.8	1660	1.70	87	400	0.63	6	300	1.5	10
1070	MDXMAXM-080-13	211	2.10	0.37	28.00	112.7	900	1.40	50	400	0.67	6	300	1.5	10
1071	MDXMAXM-080-13	251	3.60	0.64	28.00	112.7	1640	2.40	87	400	0.67	6	300	1.5	10
1072	MDXMAXM-080-33	212	2.85	0.55	16.60	78.6	900	1.90	50	400	0.68	6	300	1.5	10
1073	MDXMAXM-080-33	252	4.95	0.95	16.60	78.6	1640	3.30	87	400	0.68	6	300	1.5	10
1078	MDFMAXx-250-22	224	147.75	55.00	0.04	1.92	1475	98.50	50	400	0.86	6	300	1	2
1079	MDFMAXx-250-22	264	255.90	95.00	0.04	1.92	2585	170.60	87	400	0.86	6	300	1	2
1080	MDEBAXM-063-12	210	0.68	0.12	87.58	610.53	1390	0.45	50	400	0.65	6	300	1.5	10
1081	MDEBAXM-063-12	250	1.17	0.21	87.58	610.53	2500	0.78	87	400	0.65	6	300	1.5	10
1082	MDEBAXM-063-32	210	0.98	0.18	56.90	342.11	1400	0.65	50	400	0.65	6	300	1.5	10
1083	MDEBAXM-063-32	250	1.70	0.31	56.90	342.11	2510	1.13	87	400	0.65	6	300	1.5	10
1084	MDEBAXM-071-12	210	1.35	0.25	39.90	157.20	1390	0.90	50	400	0.64	6	300	3.6	2
1085	MDEBAXM-071-12	250	2.34	0.43	39.90	157.20	2500	1.56	87	400	0.64	6	300	2	2
1086	MDEBAXM-071-32	211	1.95	0.37	25.03	122.60	1380	1.30	50	400	0.64	6	300	3.4	2
1087	MDEBAXM-071-32	251	3.38	0.64	25.03	122.60	2490	2.25	87	400	0.64	6	300	2.5	2
1088	MDEBAXM-080-12	212	2.40	0.55	20.69	89.00	1400	1.60	50	400	0.68	6	300	3.2	2
1089	MDEBAXM-080-12	252	4.16	0.95	20.69	89.00	2510	2.77	87	400	0.68	6	300	1.6	2
1090	MDEBAXM-080-32	213	3.00	0.75	11.69	65.20	1400	2.00	50	400	0.72	6	300	3.5	2
1091	MDEBAXM-080-32	253	5.20	1.30	11.69	65.20	2510	3.46	87	400	0.72	6	300	1.9	3
1092	MDEBAXM-090-12	214	4.05	1.10	6.40	37.00	1420	2.70	50	400	0.77	6	300	2.5	2
1093	MDEBAXM-090-12	254	7.05	2.00	6.40	37.00	2535	4.70	87	400	0.77	6	300	2	2
1094	MDEBAXM-090-32	215	5.40	1.50	4.80	26.00	1415	3.60	50	400	0.77	6	300	2	2
1095	MDEBAXM-090-32	255	9.30	2.70	4.80	26.00	2530	6.20	87	400	0.77	6	300	1	2
1096	MDEBAXM-100-12	216	7.20	2.20	2.90	20.00	1425	4.80	50	400	0.80	6	300	1	1.5
1097	MDEBAXM-100-12	256	12.45	3.90	2.90	20.00	2535	8.30	87	400	0.80	6	300	0.8	1.5
1098	MDEBAXM-100-32	217	9.90	3.00	2.10	17.00	1415	6.60	50	400	0.81	6	300	2.5	1.5
1099	MDEBAXM-100-32	257	17.10	5.35	2.10	17.00	2530	11.40	87	400	0.81	6	300	1.4	1.8
1100	MDEBAXM-112-22	218	12.45	4.00	1.50	11.00	1435	8.30	50	400	0.82	6	300	2	2
1101	MDEBAXM-112-22	258	21.45	7.10	1.50	11.00	2545	14.30	87	400	0.82	6	300	1	2
1102	MDEBAXM-112-32	219	17.85	5.50	2.71	21.40	1425	11.90	50	400	0.84	6	300	1.5	10
1114	MDFMAXx-200-32	224	83.25	30.00		1465	55.50	50	400	0.85	6	300	1	2	
1115	MDFMAXx-200-32	264	145.50	52.00		2575	97.00	87	400	0.85	6	300	1	2	



10.5 Glossary

Term	Meaning
CE	Communauté Européenne (English: European Community)
Code	For entry and display (access) of parameter values. Variable addressing according to the format "code/subcode" (Cxxxx/xx). All variables can be addressed via the code digits.
Fieldbus	For data exchange between superimposed control and positioning control, e.g. InterBus-S or PROFIBUS DP
GDC	Global Drive Control (PC-program (Windows) for Lenze controllers)
RFG	Ramp function generator
INTERBUS	Industrial communication standard to DIN E19258
Select target position	The target which is to be approached by means of a defined traversing profile.
LECOM	Lenze Communication
LU	Undervoltage
OU	Overvoltage
PC	Personal Computer
PM	Permanent magnet
QSP	Quick stop
Ctrl. enable	Controller enable
Ctrl. inhibit	Controller inhibit (= Controller enable)
Contouring error	Deviation between momentary position setpoint and actual position. Display for a momentary following error under C0908.
Contouring error tolerance	If the contouring error reaches a defined contouring error tolerance, a fault indication is released.
Contouring error monitoring	Monitors the momentary following error if the contouring error tolerance is exceeded and releases a fault indication, if necessary.



Appendix

10.6 Table of keywords

A


Accessories, 10-1
Accessory kit, 1-1
Aggressive gases, 4-1
Appendix, 10-1
Application as directed, 1-2
Application conditions, 3-2
Assembly, 4-1
with fixing rails or brackets, 4-2
Automatic control parameter identification, 5-27
Automation interface, 4-27

B

Brake unit, 4-17
Bus connection, 4-26

C

Cable cross-sections, 3-6, 4-14
Control cables, 4-20
Mains connection, 4-13
Motor connection, 4-17
Cable specification, 4-12
Calculation of control parameters, 5-28
CANopen, 4-26
Code table, 10-1
Collective screen plate, 4-20
Commissioning, 5-1
Controller, 5-5
Initial switch-on, 5-1
Sequence, 5-4
Configuration, 7-1
Global Drive Control, 7-1
Monitoring, 7-2
Connection
Brake unit, 4-17
Connection diagram, 4-22
Control cables, 4-20
Mains-, 4-13
Motor, 4-15
Connection diagrams, 4-22
Connections, Power, 4-13
Control
Describe dialog box, 5-23
Program, 5-26
Control cables, 4-20
Control connection, 4-20
Control terminals, 4-20
Max. permissible cross-sections, for motor connection, 4-20
Overview, 4-20
Protection against inverse polarity, 4-20
Terminal assignment, 4-20
Controller, 1-1
adapted to motor, 5-7
Application as directed, 1-2
Cold plate technology, 4-6
Identification, 1-2
Mains adaptation, 5-6
Switch on, 5-5
Controller enable, 5-10
Cooling air, 4-1
Current derating, 6-3
Current operated protections, 4-9



D

Definitions, 1-1
Dimensions, 3-7
Standard units, 4-2
Drive, Controller enable, 5-10
Drive system, 1-1

E

Electrical data
200 % overcurrent, 3-4
Types 9321 to 9325, 3-3
Types 9326 to 9332, 3-5
EMC
Assembly, 4-34
CE-typical drive system, Installation, 4-34
Filters, 4-34
Grounding, 4-34
Installation, 4-34
Shielding, 4-34
Encoder connection, 4-32
Enter, machine parameters, 5-8
Enter parameters, for machine, 5-8
Error messages, 8-5

F

FAIL-QSP, 7-2
Fault elimination, 8-1
Fault message, Reset, 8-9
Feedback signals, 4-30
Encoder connection, 4-32
Resolver connection, 4-31
Temperature monitoring, 4-28
Free space, 4-1
Fuses, 3-6
Mains connection, 4-14

G

GDC
Offline operation, 5-5
Online operation, 5-5
Switch on, 5-5
Generate, parameter set, 5-6
Global Drive Control, 7-1
Status indications, 6-1
Global-Drive-Control, 10-1
Diagnostics, 8-1
Glossary, 10-73

H

History buffer, 8-3
Assembly, 8-3
Working with the, 8-4
Homing
Manual homing, 5-25
Parameter, 5-24

I


Identification, 5-27
Controller, 1-2
Information on operation, 6-2
Inputs
Analog, 4-21
digital, 4-21
Installation
CE-typical drive system, 4-34
Assembly, 4-34
Filters, 4-34
Grounding, 4-34
Shielding, 4-34
Cold plate, 4-6
Electrical, 4-9
Mechanical, 4-1
Standard assembly, 4-2
Insulation, 4-10

J

Jumper, Analog setpoint selection, 4-21

K

Keypad, Status messages, 8-1



Appendix

L

LECOM, Status word C0150, 8-2
Legal regulations, 1-2
Liability, 1-2
Load, parameter set, 5-21

M

Mains, Controller adaptation, 5-6
Mains conditions, 4-12
Mains connection, 4-13
 Fuses, 4-14
Mains filter, 3-7
Mains types, 4-12
Maintenance, 9-1
Manual homing, 5-25
Manual positioning, Parameter, 5-9
Manufacturer, 1-2
Mechanical installation, 4-1
Message, 7-2
Messages, Error, 8-5
Monitor output, 4-21
Monitoring, 7-2
 FAIL-QSP, 7-2
 Message, 7-2
 Monitoring functions, 7-4
 Reactions, 7-2
 Set reactions, 7-3
 Warning, 7-2
Motor
 Controller adaptation, 5-7
 Selection list, 10-66
Motor cable, Shielding, 4-15
Motor connection, 4-15, 4-16
Motor protection, 4-11

N


Notes on operation, 6-2

O

Operation, 6-1
Oscillations, 4-1
Outputs
 Analog, 4-21
 digital, 4-21
Overspeeds, 2-2

P

Packing list, 1-1
Parameter
 Enter into program set, 5-19
 Homing, 5-24
 Manual positioning, 5-9
 Positioning profile, 5-13
Parameter set, Generation, 5-6
Parameter set transfer, 2-2
Password protection, 5-30
PC, Switch on, 5-5
PC program, Global-Drive-Control, 10-1
Positioning profile
 Assembly, 5-15
 Enter parameters, 5-13
Positioning program, Processing a program set, 5-18
Power connections, 4-13
 Max. permissible cross-sections
 for mains connection, 4-13
 for motor connection, 4-17
Processing, a program set, 5-18
Program control, 5-26
Program set, Enter parameters, 5-19
Protection against contact, 4-10
Protection against inverse polarity, 4-20
Protection of devices, 2-2
 Current derating, 6-3
Protection of persons, 2-2, 4-9
 Insulation, 4-10
 Residual-current circuit breaker, 4-9
Punching, 4-3



R

Rated data
200 % overcurrent, 3-4
Cable cross-sections, 3-6
Fuses, 3-6
Mains filter, 3-7
Types 9321 to 9325, 3-3
Types 9326 to 9332, 3-5
Reset, Fault message, 8-9
Residual hazards, 2-2
Residual-current circuit breaker, 4-9
Resolver connection, 4-31

S

Safety information, 2-1
Layout, 2-2
Other notes, 2-2
Warning of damage to material, 2-2
Warning of damage to persons, 2-2
Save, parameter set. *See* Parameter set transfer
Selection list, 10-58
Servo inverter. *See* Controller
Shielding
Control cable, 4-20
EMC, 4-34
Motor cable, 4-15
State bus, 4-25
Status indications
Global-Drive-Control, 6-1
Keypad, 6-1
Status messages, 8-1
Status word, 8-2
Switch on, 5-1
Controller, 5-5
Switch-on
GDC, 5-5
PC, 5-5
Switching on the motor side, 4-17

T

Technical data, 3-1
Dimensions, 3-7
Electrical data, 3-3
Features, 3-1
General data/application conditions, 3-2
Temperature monitoring, 4-28
Thermal separation, 4-3
Tightening torques
Control terminals, 4-20
Power terminals, 4-13, 4-17
TRIP, 7-2
Troubleshooting, 8-1

U


Use, as directed, 1-2

V

Vibrations, 4-1
Voltage drop, 4-14

W

Warning, 7-2
Warranty, 1-2
Waste disposal, 1-2



Appendix

Appendix

