

9400



E94AxHExxx

Servo Drives 9400 HighLine _____

Reference manual

EN



135569496

Lenze

Overview of technical documentation for Servo Drives 9400

Project planning, selection & ordering

- 9400 hardware manual
- Catalogue / electronic catalogue (DSC - Drive Solution Catalogue)

Mounting & wiring

- MA 9400 StateLine/HighLine
- MA for the communication module
- MA for the extension module
- MA for the safety module
- MA for the accessories
- MA for remote maintenance components

Parameter setting

- BA keypad
- SW for the »Engineer« Lenze software
- SW - controller** (9400 StateLine/HighLine/PLC)
- SW for the regenerative power supply module
- KHB for the communication module
- SW for the extension module
- SW for the safety module
- SW for the Lenze technology application
- SW for the 9400 function library

← This documentation

Configuring & programming

- SW for the »Engineer« Lenze software
- SW for the »PLC Designer« Lenze software
- SW - controller** (9400 HighLine/PLC)
- KHB for the communication module
- SW for the extension module
- SW for the safety module
- SW for the Lenze technology application
- SW for the 9400 function library

← This documentation

Drive commissioning

- Commissioning guidelines
- SW - controller** (9400 StateLine/HighLine/PLC)
 - Chapter "[Commissioning](#)" ([📖 25](#))
 - Chapter "[Oscilloscope](#)" ([📖 585](#))
 - Chapter "[Diagnostics & fault analysis](#)" ([📖 608](#))
- Remote maintenance manual

← This documentation

Networking

- KHB for the communication medium used

Legend:

- Printed documentation
- Online documentation (PDF/Engineer online help)

Abbreviations used:

- BA Operating instructions
- KHB Communication manual
- MA Mounting instructions
- SW Software manual

Contents

1	About this document	13
1.1	Conventions used	15
1.2	Terminology used	16
1.3	Definition of the notes used	17
2	Introduction	18
2.1	Parameter setting, configuring, or programming?	18
2.1.1	Basic functionalities	19
2.1.2	Technology applications	19
2.2	Communicating with the controller	20
2.2.1	Going online via diagnostic adapter	20
2.2.2	Going online via system bus (CAN on board)	23
2.2.3	Use of other communication interfaces	23
2.3	Signal types & scaling	24
3	Commissioning	25
3.1	General notes	26
3.2	Notes on commissioning using the keypad	27
3.3	Initial commissioning	28
3.4	Standard set-up	29
3.5	Controller replacement	30
3.6	Motor replacement	30

Contents

4	Drive interface	31
4.1	Machine parameters	32
4.1.1	Mains voltage	33
4.1.2	Gearbox ratio	34
4.1.3	Motor mounting direction	35
4.1.4	Feedback configuration	35
4.1.5	Unit/user-defined unit	36
4.1.6	Traversing range	37
4.1.7	Feed constant	39
4.1.8	Resolution of an encoder revolution	40
4.1.9	Max. position, speed, and acceleration that can be displayed internally	43
4.2	Device commands	45
4.2.1	Load Lenze setting	47
4.2.2	Load start parameters	48
4.2.3	ENP:Load plant data	49
4.2.4	Activate application	50
4.2.5	Save selected application	51
4.2.6	Save start parameters	52
4.2.7	Delete logbook	54
4.2.8	Archive logbook	55
4.2.9	Start application	56
4.2.10	Stop application	57
4.2.11	Reset program	58
4.2.12	Delete program	59
4.2.13	Restart program	60
4.2.14	Reset runtime measurement	61
4.2.15	Inhibit controller	63
4.2.16	Enable controller	64
4.2.17	Reset error	65
4.2.18	Activate quick stop	66
4.2.19	Reset quick stop	67
4.2.20	Identify pole position (360°)	68
4.2.21	Identify pole position (min. motion)	69
4.2.22	Resolver error identification	71
4.2.23	Load Lenze INV characteristic	72
4.2.24	Calculate inv. characteristic	73
4.2.25	Determine motor parameters	74
4.2.26	Calculate current controller parameters	75
4.2.27	Calculate speed controller parameters	77
4.2.28	CAN on board: Reset Node	78
4.2.29	CAN module: Reset node	79
4.2.30	CAN on board: Pred.Connect.Set	80
4.2.31	CAN module: Pred.Connect.Set	81
4.2.32	CAN on board: Identify node	82
4.2.33	CAN module: Identify node	83
4.2.34	Unbind/bind Ethernet module MXI1	84
4.2.35	Unbind/bind Ethernet module MXI2	85
4.2.36	Activate parameter set 1 ... 4	86
4.2.37	Activate parameter set 1 ... 4	88
4.2.38	Load cam data	90
4.2.39	Save cam data	92
4.2.40	Calculate cam data	94
4.2.41	Calculate cam data checksum	95
4.2.42	Format file system	96
4.2.43	Restore file system	97

Contents

4.2.44	Prepare firmware update	98
4.2.45	Restart controller	99
4.3	Device states	100
4.3.1	"Initialisation active" state	102
4.3.2	"Safe torque off active" state	103
4.3.3	"Device is ready to switch on" state	103
4.3.4	"Device is switched on" state	104
4.3.5	"Operation" state	104
4.3.6	"Warning active"	105
4.3.7	"Warning locked active"	105
4.3.8	"Quick stop by trouble active" state	105
4.3.9	"Trouble active" state	106
4.3.10	"Fault active" state	106
4.3.11	"System fault active" state	106
4.4	Automatic restart after mains connection/trouble...	107
4.5	Behaviour after task overflow	109
4.6	Device output power	110
4.6.1	Switching frequency	110
4.6.2	Monitoring of the device utilisation	111
4.6.3	Operation with increased continuous power	112
4.7	Internal interfaces "LS_DriveInterface" system block	113
4.7.1	Status signals	116
4.7.2	Monitoring of external events	117

Contents

5	Motor interface	118
5.1	General information	120
5.1.1	Reading out motor data from the controller	120
5.1.2	Selecting a motor from the motor catalogue in the »Engineer«	121
5.1.3	Displaying/editing motor data in »Engineer«	122
5.2	Select motor control	124
5.3	Adjusting motor and controller to each other	126
5.3.1	Accepting/adapting plant parameters	127
5.3.2	Parameterising motor encoder	129
5.3.3	Pole position identification	131
5.3.4	Optimising the switching performance of the inverter	138
5.3.5	Determining the motor parameters	141
5.4	Servo control (SC)	145
5.4.1	Optimising the control mode	146
5.4.2	Signal flow (servo control for synchronous motor)	162
5.4.3	Signal flow (servo control for asynchronous motor)	164
5.5	Sensorless vector control (SLVC)	166
5.5.1	Basic settings	167
5.5.2	Optimising motor parameters	169
5.5.3	Optimising the control mode	175
5.5.4	Signal flow	183
5.6	V/f control (VFCplus)	184
5.6.1	Basic settings	184
5.6.2	Optimising the control mode	191
5.6.3	Signal flow	199
5.7	V/f control (VFCplus)	200
5.7.1	Signal flow	201
5.8	Parameterisable additional functions	203
5.8.1	Correction of the stator leakage inductance...	204
5.8.2	Field weakening for synchronous machines	209
5.8.3	Flying restart function	212
5.8.4	DC-injection braking	215
5.9	Monitoring	217
5.9.1	Signal flow	217
5.9.2	Motor monitoring (I^2xt)	218
5.9.3	Motor temperature monitoring	225
5.9.4	Motor phase failure monitoring	229
5.9.5	Maximum current monitoring	233
5.10	Internal interfaces "LS_MotorInterface" system block	234

Contents

6	Encoder evaluation	239
6.1	Internal interfaces "LS_Feedback" system block	240
6.1.1	Use of an external position encoder	242
6.2	Signal flow	243
6.3	Parameter setting	243
6.3.1	Controller configuration	246
6.3.2	System with motor encoder	248
6.3.3	System with motor encoder and position encoder	249
6.3.4	Position feedback with a linear distance measuring device	251
6.3.5	Adaptation of the resolver evaluation dynamics	253
6.3.6	Parameterisation of an unknown Hiperface® encoder	254
6.3.7	Parameterisation of a Hiperface® encoder with increased initialisation time	254
6.3.8	Use of an SSI encoder at X8	255
6.3.9	Rotative encoder with SSI protocol	261
6.3.10	Provision of the encoder signal of input X8	263
6.3.11	Resolver error compensation	266
6.3.12	Encoder angular drift monitoring	267
7	Braking operation	269
7.1	Parameter setting	270
7.1.1	Setting the voltage threshold for braking operation	270
7.2	Monitoring	271
7.2.1	Overcurrent protection	271
7.2.2	Ixt utilisation - brake transistor	272
7.2.3	I2t utilisation - brake resistor	273
7.2.4	Overvoltage in the DC bus	275
8	I/O terminals	276
8.1	Overview	276
8.2	Analog inputs	277
8.2.1	Terminal assignment/electrical data	277
8.2.2	Parameter setting	278
8.2.3	Reconfiguring analog input 1 into current input	278
8.2.4	"LS_AnalogInput" system block	279
8.3	Analog outputs	280
8.3.1	Terminal assignment/electrical data	280
8.3.2	Parameter setting	281
8.3.3	"LS_AnalogOutput" system block	281
8.4	Digital inputs	282
8.4.1	Terminal assignment/electrical data	282
8.4.2	Parameter setting	282
8.4.3	"LS_DigitalInput" system block	283
8.5	Digital outputs	284
8.5.1	Terminal assignment/electrical data	284
8.5.2	Parameter setting	284
8.5.3	"LS_DigitalOutput" system block	285
8.6	"State bus" monitoring function	286
8.6.1	Detecting the current state	287
8.6.2	Setting the state bus to the "Error" state	287
8.7	Touch probe detection	288
8.7.1	Actual value interpolation (principle)	288
8.7.2	Dead time compensation	290
8.7.3	"LS_TouchProbe1...8" system block	291
8.7.4	"LS_TouchProbeMotor" system block	292
8.7.5	"LS_TouchProbeLoad" system block	292
8.8	Configure exception handling of the outputs	293

Contents

9	"CAN on board" system bus	295
9.1	General information	296
9.1.1	General data and application conditions	297
9.1.2	Supported protocols	297
9.1.3	Communication time	298
9.2	Possible settings by DIP switch	299
9.2.1	Setting the node address	299
9.2.2	Setting the baud rate	300
9.3	LED status displays for the system bus	301
9.4	Structure of the CAN data telegram	302
9.4.1	Identifier	302
9.4.2	User data	304
9.5	Communication phases/network management	305
9.5.1	State transitions	306
9.5.2	Network management telegram (NMT)	307
9.5.3	Parameterising the controller as CAN master	308
9.6	Process data transfer	309
9.6.1	Identifiers of the process data objects	310
9.6.2	Transmission type	311
9.6.3	Masking of the TPDOs for event control	312
9.6.4	Monitoring of the RPDOs for data reception	312
9.6.5	Synchronisation of PDOs via sync telegram	313
9.7	Parameter data transfer	318
9.7.1	Identifiers of the parameter data objects	319
9.7.2	User data	319
9.7.3	Parameter data telegram examples	325
9.8	Diagnostics	330
9.9	Monitoring	331
9.9.1	Node guarding protocol	331
9.9.2	Heartbeat protocol	337
9.9.3	Emergency telegram	341
9.10	CANopen objects implemented	342
9.11	System block "LS_SyncInput"	367
9.11.1	Behaviour of the status signal bSyncnInsideWindow	368
10	Safety engineering	369
10.1	Integration into the application	370
10.2	Selecting the required safety module	371
10.3	System block "LS_SafetyModuleInterface"	371
10.3.1	Status information	373
10.3.2	I/O status information	374
10.3.3	Control information	374

Contents

11	Basic drive functions	377
11.1	General information	378
11.1.1	Internal state machine	378
11.1.2	Function states	380
11.1.3	Interrupting/replacing states	382
11.1.4	Priorities	383
11.1.5	Requesting control via a basic function	384
11.1.6	Start acceleration/acceleration reduction when the basic function changes	385
11.1.7	Setting the S-ramp time	387
11.2	Stop	389
11.2.1	Internal interfaces "LS_Stop" system block	390
11.2.2	Parameter setting	391
11.2.3	Behaviour of the function (example)	392
11.3	Quick stop	393
11.3.1	Internal interfaces "LS_Quickstop" system block	393
11.3.2	Parameter setting	394
11.3.3	Activate/deactivate quick stop	396
11.3.4	DC-injection braking	397
11.4	Manual jog	400
11.4.1	Internal interfaces "LS_ManualJog" system block	401
11.4.2	Parameter setting	404
11.4.3	Executing manual jogging	406
11.5	Manual job, encoderless	412
11.5.1	Parameter setting	413
11.5.2	Carrying out encoderless manual jogging	414
11.5.3	Internal interfaces "LS_ManualJogOpenLoop" system block	419
11.6	Homing	421
11.6.1	Internal interfaces "LS_Homing" system block	423
11.6.2	Parameter setting	425
11.6.3	Overview of the Lenze homing modes	432
11.6.4	Overview of DS402 homing modes	445
11.6.5	Execute homing	476
11.7	Positioning	479
11.7.1	Internal interfaces "LS_Positioner" system block	480
11.7.2	Parameter setting	485
11.7.3	Carrying out positioning	487
11.8	Position follower	490
11.8.1	Internal interfaces "LS_PositionFollower" system block	491
11.8.2	Signal flow	492
11.8.3	Parameter setting	493
11.8.4	Activating setpoint interface	495
11.9	Speed follower	496
11.9.1	Internal interfaces "LS_SpeedFollower" system block	496
11.9.2	Signal flow	498
11.9.3	Parameter setting	499
11.9.4	Activating setpoint interface	500
11.10	Torque follower	501
11.10.1	Internal interfaces "LS_TorqueFollower" system block	502
11.10.2	Signal flow	503
11.10.3	Parameter setting	504
11.10.4	Activating setpoint interface	505
11.11	Limiter	506
11.11.1	Internal interfaces "LS_Limiter" system block	506
11.11.2	Parameter setting	511

Contents

11.12 Brake control	521
11.12.1 Internal interfaces "LS_Brake" system block	523
11.12.2 Parameter setting	526
11.12.3 Mode 0: Brake control is switched off	542
11.12.4 Mode 1/11: Direct control of the brake	543
11.12.5 Mode 2/12: Automatic control of the brake	544
11.12.6 Mode 22: Automatic DC-injection braking	549
11.12.7 Grinding the brake	552
11.12.8 Carrying out brake test	554
11.12.9 Control of two motor holding brakes	556
11.13 Cam data management	557
11.13.1 "Online" tab for cam data management	558
11.13.2 Internal interfaces "LS_CamInterface" system block	563
11.13.3 Parameter setting	565
11.13.4 Product/track change-over	572
11.13.5 Invalid cam data due to changed machine parameters	573
11.13.6 Behaviour after mains switching	574
11.14 Pole position identification	575
11.14.1 Internal interfaces System block "LS_PolePositionIdentification"	576
11.14.2 Parameter setting	578
11.14.3 Execution of the pole position identification	578
11.14.4 Signal characteristics	580
11.14.5 Deactivating a known pole position	582

Contents

12	Oscilloscope	585
12.1	Functional description	586
12.2	Technical data	586
12.3	Operation	587
12.3.1	User interface	588
12.3.2	Selecting the signal sources to be recorded	590
12.3.3	Selecting the recording time/sample rate	592
12.3.4	Selecting the trigger condition	593
12.3.5	Start recording	595
12.3.6	Cyclic recording	595
12.3.7	Adjusting the representation	596
12.3.8	Cursor function: Reading individual measured values	598
12.3.9	Last settings	598
12.4	Managing oscillograms (measured data records)	599
12.4.1	Commenting the oscillogram	599
12.4.2	Saving the oscillogram in a file	600
12.4.3	Loading the oscillogram file	601
12.4.4	Importing settings from another loaded oscillogram	602
12.4.5	Overlay function	603
12.4.6	Deleting an oscillogram file saved in the project	604
12.5	Variables of the motor control (oscilloscope signals)	605

Contents

13	Diagnostics & fault analysis	608
13.1	LED status display	608
13.1.1	LED status displays for the device state	609
13.2	Drive diagnostics with the »Engineer«	610
13.3	Drive diagnostics via keypad/bus system	611
13.4	Logbook	613
13.4.1	Functional description	614
13.4.2	Filtering logbook entries	614
13.4.3	Reading out logbook entries	615
13.4.4	Exporting logbook entries to a file	616
13.5	Monitoring	617
13.5.1	Setting the error response	618
13.6	Maloperation of the drive	619
13.7	Error messages of the operating system	620
13.7.1	Structure of the error number (bit coding)	620
13.7.2	Reset error message	625
13.7.3	Short overview (A-Z)	626
13.7.4	Cause & possible remedies	634
14	Parameter reference	724
14.1	Structure of the parameter descriptions	725
14.1.1	Data type	725
14.1.2	Parameters with read-only access	725
14.1.3	Parameters with write access	726
14.1.4	Parameter attributes	730
14.1.5	Abbreviations used in parameter & selection texts	730
14.2	Parameter list	731
14.3	Table of attributes	927
	Index	942
	Your opinion is important to us	967

1 About this document

1 About this document



Danger!

The Servo Drives 9400 HighLine are a source of danger which may cause death or serious personal injury.

In order to ensure protection against this danger, observe the safety instructions before switching on the Servo Drives 9400 HighLine.

Please read the safety instructions in the **mounting instructions** and **hardware manual** of the Servo Drives 9400 HighLine. Both instructions are included in the scope of supply.

Target group

This documentation addresses to all persons who want to parameterise, configure, and diagnose the Servo Drives 9400 HighLine by means of the engineering software L-force »Engineer« and the keypad.

Information regarding the validity

The information in this documentation are valid for the following standard devices:

Product range	Type designation	From software version
Servo Drives 9400	E94AxHExxx	1.5

Screenshots/application examples

All screenshots in this documentation are application examples. Depending on the firmware version of the 9400 HighLine and the software version of the engineering tools installed (»Engineer« or »EASY Starter«), the screenshots in this documentation may differ from what actually appears on the screen.

1 About this document

Document history



Version			Description
15.0	04/2019	TD06	New codes C02606 and C02872 , error corrections
12.0	07/2018	TD06	Extended oscilloscope functions, error corrections
11.0	11/2016	TD06	Extended oscilloscope functions, error corrections
10.0	11/2013	TD05	Error corrections; parameter reference V12.00.xx
9.0	12/2012	TD06	Extended by new functions for 9400 HighLine V11
8.0	12/2011	TD06	Extended by new functions for 9400 HighLine V10
7.1	10/2010	TD06	Error corrections & supplements
7.0	04/2010	TD06	Extended by new functions for 9400 HighLine V8
6.1	08/2009	TD05	Error corrections & supplements
6.0	08/2009	TD05	Extended by new functions for 9400 HighLine V7
5.2	01/2009	TD05	Error corrections & supplements
5.1	12/2008	TD05	Error corrections
5.0	11/2008	TD05	Extended by new functions for 9400 HighLine V5
4.1	07/2008	TD05	New main chapter: "CAN on board" system bus
4.0	06/2008	TD05	Supplemented with new functions for 9400 HighLine V4
3.0	11/2007	TD05	Supplemented with new functions for 9400 HighLine V3
2.0	05/2007	TD05	Extended edition
1.0	12/2006	TD05	First edition for 9400 HighLine V1.5

1 About this document

1.1 Conventions used

1.1 Conventions used




This documentation uses the following conventions to distinguish between different types of information:

Type of information	Highlighting	Examples/notes
Numeric notation		
Decimal separator	Point	The decimal point is always used. For example: 1234.56
Text		
Version information	Blue text colour	All information applying to from a certain software version of Servo Drives 9400 HighLine is marked accordingly in this documentation. Example: This function extension is available from software version V3.0!
Program name	» «	The Lenze PC software »PLC Designer«...
Window	<i>italics</i>	The <i>Message window...</i> / The dialog box <i>Options...</i>
Variable names		By setting <i>bEnable</i> to TRUE...
Control element	Bold	The OK button... / the Copy command... / the Characteristics tab... / the Name input field...
Sequence of menu commands		If several commands must be used in sequence to carry out a function, the individual commands are separated by an arrow: Select File → Open to...
Shortcut	< bold >	Use < F1 > to open the online help. If a shortcut is required for a command to be executed, a "+" has been put between the key identifiers: With < Shift >+< ESC > ...
Program code	Courier	<pre>IF var1 < var2 THEN a = a + 1 END IF</pre>
Keyword	Courier bold	
Hyperlink	<u>Underlined</u>	Optically highlighted reference to another topic. It is activated with a mouse-click in this online documentation.
Symbols		
Page reference	 15	Optically highlighted reference to another page. It is activated with a mouse-click in this online documentation.
Step-by-step instructions		Step-by-step instructions are indicated by a pictograph.

1 About this document

1.2 Terminology used

1.2 Terminology used

Term	Meaning
Engineering Tools	Software solutions for easy engineering in all project stages
	 <ul style="list-style-type: none"> »EASY Navigator« – ensures easy operator guidance • All convenient Lenze Engineering tools at a glance • Tools can be quickly selected • The clear structure simplifies the engineering process from the start
	 <ul style="list-style-type: none"> »EASY Starter« – easy-to-use tool for service technicians • Specifically designed for commissioning and maintaining Lenze devices • Graphic user interface with very few icons • Easy to run online diagnostics, set parameters and perform commissioning • No risk of accidentally changing an application • Loading off-the-shelf applications onto the device
 <ul style="list-style-type: none"> »Engineer« – multi-device engineering • For all products in our L-force portfolio • Practical user interface • Graphic interfaces make it easy to navigate • Can be applied in every phase of a project (project planning, commissioning, production) • Parameter setting and configuration 	
L-force Controller	The L-force Controller is the central component of the automation system which controls the Logic and Motion functionalities (by means of the runtime software). The L-force Controller uses the fieldbus to communicate with the field devices.
Engineering PC	The Engineering PC and the installed Engineering tools serve to configure and parameterise the system. The Engineering PC uses Ethernet to communicate with the L-force Controller.
Code	"Container" for one or several parameters by means of which you can parameterise or monitor Servo Drives 9400 HighLine.
Subcode	If a code contains several parameters, they are stored in "subcodes". This manual uses a slash "/" as a separator between code and subcode (e.g. "C00118/3").
Function block editor	Graphical interconnection tool which is provided for Servo Drives 9400 HighLine in the MotionControl HighLevel and TopLevel license level in the »Engineer« on the FB editor tab and by means of which the technology applications supplied can also be reconfigured and extended by individual functions.
Function block	A function block (FB) can be compared with an integrated circuit that contains a certain control logic and provides one or several values when being executed. <ul style="list-style-type: none"> • An instance (reproduction, copy) of the function block is always inserted into the circuit. • It is also possible to insert several instances of a function block into a circuit. • Each instance has an unequivocal identifier (the instance name) and a processing number that defines the position in which the function block is calculated during the task cycle.

1 About this document

1.3 Definition of the notes used

1.3 Definition of the notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

Safety instructions

Structure of the safety instructions:



Danger!

(characterises the type and severity of danger)

Note

(describes the danger and gives information about how to prevent dangerous situations)

Pictograph	Signal word	Meaning
	Danger!	Danger of personal injury through dangerous electrical voltage Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	Danger!	Danger of personal injury through a general source of danger Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
	Stop!	Danger of damage to material assets Reference to a possible danger that may result in the damage to material assets if the corresponding measures are not taken.

Application notes

Pictograph	Signal word	Meaning
	Note!	Important note to ensure trouble-free operation
	Tip!	Useful tip for easy handling
		Reference to another document

2 Introduction

2.1 Parameter setting, configuring, or programming?

2 Introduction

The basis of every **L-force** application is an easy and quick parameter setting of prepared technology applications and solutions*.


This chapter contains basic information on the runtime software model of **L-force** and on how you can establish an online connection between the PC and controller for parameter setting with »Engineer« very easily.

At the end of this chapter you will find an overview of the different signal types & scaling which serve to process physical values (e.g. a speed or position) within the application.

* In preparation!

2.1 Parameter setting, configuring, or programming?

The graded runtime software model of **L-force** provides a simple and consistent solution for motion and process tasks as well as for complex machine functions:



Programming*

Configuration

The HighLevel and TopLevel licenses enable you to extend the provided technology applications by individual functions using the graphic function block editor of »Engineer«. Here you can access the comprehensive function libraries of Lenze which among other things contain process controllers, arithmetic functions, logic blocks, and ramp generators and integrators.

Parameter setting

The StateLevel license includes a range of technology applications which can be put into operation easily with a keypad or via dialogs in »Engineer«.


* In preparation!

2 Introduction

2.1 Parameter setting, configuring, or programming?

2.1.1 Basic functionalities


Important basic drive functions and further basic functions are implemented in the firmware of the controller and thus are always provided, irrespective of the runtime software licence available.



2.1.2 Technology applications

Technology applications (TAs) are applications prepared by Lenze which can serve as a basis for solving typical applications.

- The technology applications available for the Servo Drives 9400 can be selected in »Engineer« from the application catalogue.



Each higher license contains additional technology applications for further application fields.

* In preparation!



Tip!

Detailed information about the individual technology applications can be found in the corresponding software manuals.

2 Introduction

2.2 Communicating with the controller

2.2 Communicating with the controller

The following interfaces/communication modules can be used to establish communication between the PC and controller:

- Diagnostic interface X6/[Going online via diagnostic adapter](#)
- CAN on board interface/[Going online via system bus \(CAN on board\)](#) (☰ 23)
- Optional interfaces which are provided by corresponding communication modules in the module slots MXI1/MXI2 of the controller.



Note!

For communication with the controller, at least the control electronics of the controller must be supplied with 24 V low voltage via plug X2. For detailed information, please see the Mounting Instructions for the controller.



Stop!

If you change parameters in the »Engineer« while the controller is connected online, the changes will be directly accepted by the controller!




Tip!

Detailed information about the individual interfaces can be found in the corresponding Communication Manuals (KHB).

2.2.1 Going online via diagnostic adapter

For initial commissioning of the controller you can for instance use the diagnostic adapter offered by Lenze:



Note!


Please observe the documentation for the diagnostic adapter!


Preconditions:

- The diagnostic adapter is connected to the controller at the diagnostic interface X6 and to the PC at a free USB port.
- The driver required for the diagnostic adapter is installed.
- The control electronics of the controller is supplied with 24 V low voltage via plug X2.

**How to build up an online connection via the diagnostic adapter:**

1. Select the 9400 HighLine controller to which you want to build up an online connection in the *Project view* of the »Engineer«:




2. Click the  icon.

If the changes you have made on the project have not been accepted yet, first a query on whether an update is to be carried out is effected.


If an update is to be carried out:



- Click **Yes** to open the *Build project* dialog box.
- Click **Build** in the *Build project* dialog box to update the changed project elements.
- After the update a note is shown, saying whether the update was carried out successfully.

If no communication path was configured yet for the controller selected, the *Communication path* dialog box is shown after the update has been carried out:



- The "Diagnostic adapter" bus connection is already preset.
3. Click on **Connect**.
 - The dialog box is closed and the online connection with the controller is built up.
 - In the *Project view* a yellow icon indicates the online connection with the controller:



Now you can use the icons  and  to easily build up and end a connection with the controller. The communication settings are only required when communication with a controller is built up for the first time.

- If you want to change the configured communication path, select the command **Online → Set communication path and go online** to open the *Communication path* dialog box and change the settings.
- When an online connection has been established, the »Engineer« displays the current parameter settings of the controller with a yellow background colour.

2 Introduction

2.2 Communicating with the controller

2.2.2 Going online via system bus (CAN on board)

As an alternative to the diagnostic adapter, you can use the integrated system bus interface (CAN on board, terminal X1) of the controller for communication.

- Lenze offers the following communication accessories for connection to the PC:

Communication accessories	PC interface
PC system bus adapter 2173 incl. connection cable and voltage supply adapter <ul style="list-style-type: none">• for DIN keyboard connection (EMF2173IB)• for PS/2 keyboard connection (EMF2173IBV002)• for PS/2 keyboard connection with electrical isolation (EMF2173IBV003)	Parallel interface (LPT port)
PC system bus adapter 2177 incl. connection cable (EMF2177IB)	USB (Universal Serial Bus)



Note!

- For detailed information about the PC system bus adapter, please see the "CAN Communication Manual".
- Please observe the documentation for the PC system bus adapter!
- The online connection is established as described in the previous chapter "[Going online via diagnostic adapter](#)", only that this time the entry "CAN system bus" is to be selected in the **Bus connection** list field of the *Communication path* dialog box. (📖 21)

2.2.3 Use of other communication interfaces

The controller can be extended by further communication interfaces, if required, e.g. Ethernet, ETHERNET Powerlink, or PROFIBUS.

- For this the controller is provided with the module slots MXI1 and MXI2 for accepting communication modules.
- Detailed information on this subject can be found in the Hardware Manual and Communication Manual for the corresponding communication system.

2.3 Signal types & scaling

It is very helpful for the parameterisation & configuration of the controller to know the signal types and their scaling listed below, which serve to process physical quantities (e.g. a speed or position) within the function block interconnection.



Note!

From software version V3.0 the resolution of an encoder revolution can be parameterised in [C00100](#) (Lenze setting: 16 bits/encoder revolution).

▶ [Resolution of an encoder revolution](#) (40)

Signal type (data type)	Connection symbol in the FB editor	Resolution	Value range (external)	Decimal positions/ signal type suffix in the identifier	
Scaled (INT)	○	16 bits	± 199.99 %	2	_a
Scaled (DINT)	●	32 bits	± 200.00 %	2	_n
Speed (INT)	◁/▷	16 bits	± 30000.0 rpm	1	_v
Speed (DINT)	◆	32 bits	± 480000.0 rpm	1	_s
Position/angle (DINT)	◁/▷	32 bits	-2 ³¹ ... 2 ³¹ -1 increments	3	_p
Digital (BOOL)	□	1 bit	0 ≡ FALSE; 1 ≡ TRUE	0	
Acceleration (DINT)	■	32 bits	± 7.69 * 10 ⁹ rpm/s	3	_x
Time	■	28 bits	0 ... 268435.456 s	3	
Other (BYTE)	■	8 bits	0 ... 255	0	
Other (WORD)	■	16 bits	0 ... 65535	0	
Other (DWORD)	■	32 bits	0 ... 4294967295	0	
Other (INT)	■	16 bits	-32768 ... 32767	0	
Other (DINT)	■	32 bits	-2147483648 ... 2147483647	0	

Scaling of physical units

Signal type	Connection symbol in the FB editor	Resolution	Standardisation	
			External value	≡ internal value
Scaled (INT)	○	16 bits	100 %	≡ 2 ¹⁴ ≡ 16384
Scaled (DINT)	●	32 bits	100 %	≡ 2 ³⁰ ≡ 1073741824
Speed (INT)	◁/▷	16 bits	15000 rpm	≡ 2 ¹⁴ ≡ 16384
Speed (DINT)	◆	32 bits	15000 rpm	≡ 2 ²⁶ ≡ 67108864
Position/angle (DINT)	◁/▷	32 bits	1 encoder revolution	≡ 2 ¹⁶ increments
Acceleration (DINT)	■	32 bits	15000000 rpm/s	≡ 2 ²² ≡ 4194304

3 Commissioning

This documentation contains detailed information on parameter setting and configuration of the controller. Sequential reading is not required.

In order to obtain the information relevant for initial commissioning, this chapter describes different commissioning scenarios which can also be used as a guide through this manual:

A. [Initial commissioning](#) (📖 28)

- **Target:** Adapting the controller to the electromechanics and the control system.

B. [Standard set-up](#) (📖 29)

- **Target:** Taking over the application and parameter set of an already preconfigured "Engineer" project into several controllers.

C. [Controller replacement](#) (📖 30)

- **Target:** Replacing a controller which has failed in a running system by a replacement device using the "old" memory module.

D. [Motor replacement](#) (📖 30)

- **Target:** Replacing a motor which has failed in a running system.

3 Commissioning

3.1 General notes

3.1 General notes



Note!

Some parameters of the controller have a setting range depending on the device type. If parameterisation is carried out offline or if the memory module is exchanged between different 9400 HighLine device types, always check the settings of the parameters listed in the following table and adapt them, if required, to prevent a parameter error after the parameter set download or module change!

Parameters	Info	Lenze setting
C00018	Switching frequency	8 kHz variable
C00022	Maximum current ▶ Accepting/adapting plant parameters (📖 127)	0.00 A
C00173 C00174	Mains voltage and undervoltage threshold (LU) ▶ Machine parameters (📖 32)	400/415 V, LU = 285 V



Tip!

The rated data of the different device types can be found in the Hardware Manual in the "Rated data" chapter.

Term definition of "Plant parameters"

The term "plant parameters" which is frequently used in the following chapters summarises all parameters which result from the combination of motor and load. They characterise the transfer behaviour of the entire controlled system including the desired monitoring functions. The plant parameters depend on the application in which the controller and motor are used.

3.2 Notes on commissioning using the keypad

For a motor with an electronic nameplate (ENP)

- A display of the plant parameters offered by ENP via keypad is not provided. The plant parameters must be edited and optimised individually.
- To avoid that the motor starts unintentionally without adjusting the plant parameters, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).
- After setting the plant parameters, they have to be saved on the memory module of the controller with mains failure protection, just as the motor data that have been read out from the ENP ([C00002](#) = "11: Save start parameters").

For a motor without an electronic nameplate (ENP)

- The motor data and plant parameters must be edited and set individually.
- To avoid that the motor starts unintentionally without adjusting the plant parameters, the maximum current is set to "0 A" in [C00022](#) by the factory.
- After setting the motor data and plant parameters, they have to be saved on the memory module of the controller with mains failure protection ([C00002](#) = "11: Save start parameters").

Commissioning of the application

- The application must already be stored on the memory module of the controller. Otherwise commissioning by only using the keypad is not possible.
- All application parameters which deviate from the factory adjustment have to be edited individually. For this the project planner has to provide a corresponding list to the commissioner (including the motor and plant data).
- In the case of a standard set-up, a pole position identification may have to be carried out for synchronous motors of a third party manufacturer or Lenze synchronous motors with a Stegmann absolute value encoder.
- After setting the parameters, they have to be saved on the memory module of the controller with mains failure protection ([C00002](#) = "11: Save start parameters").




Tip!

Detailed information on the individual technology applications can be found in the corresponding Software Manual for the technology application and the »Engineer« online help in the chapter "L-force Servo Drives 9400 → Technology applications".

3.3

Initial commissioning

Worksteps	
Parameterising motor control:	
1	Read out the motor data of the controller or select them via the »Engineer« motor catalogue. <ul style="list-style-type: none"> If the motor connected to the controller is provided with an electronic nameplate (ENP), all motor data are automatically read out from the ENP and a selection in the motor catalogue is not required. <ul style="list-style-type: none"> ▶ Reading out motor data from the controller (☞ 120) If a motor without ENP or a motor by a third-party manufacturer is used, the selection is carried out via the »Engineer« motor catalogue. ▶ Selecting a motor from the motor catalogue in the »Engineer« (☞ 121)
2.	Select motor control. (☞ 124) <ul style="list-style-type: none"> Servo control is preset for the synchronous motor.
3	Adjusting motor and controller to each other (☞ 126)
4	Carry out settings for selected motor control. <ul style="list-style-type: none"> For this see description for the corresponding motor control: <ul style="list-style-type: none"> • Servo control (SC) • Sensorless vector control (SLVC) (from software version V3.0) • V/f control (VFCplus) (from software version V3.0) • V/f control (VFCplus) (from software version V3.0)
Parameterise/configure application:	
5	Load & parameterise technology application.
	Detailed information on the individual technology applications can be found in the corresponding Software Manual for the technology application and the »Engineer« online help in the chapter "L-force Servo Drives 9400 → Technology applications".
6	If required, reconfigure the interconnection of the technology application with the function block editor.
Optimise control mode:	
7	Optimise control mode of the selected motor control. <ul style="list-style-type: none"> By means of traversing profile from the application and oscilloscope. For this see description for the corresponding motor control: <ul style="list-style-type: none"> • Servo control (SC) • Sensorless vector control (SLVC) (from software version V3.0) • V/f control (VFCplus) (from software version V3.0) • V/f control (VFCplus) (from software version V3.0)
Save project and parameter set:	
8	Execute device command C00002 = "11: Save start parameters".
9	Save »Engineer« project.


More (optional) worksteps

Worksteps	
Establish network:	
1	Insert network and machine application into the »Engineer« project.
2.	Interconnect port blocks reasonably to each other within the machine application.
3	Configure network (set addresses, baud rate, and process data channels in a reasonable manner).
4	Establish communication with the control system.
5	Establish communication with other drive components (e.g. HMIs, I/O extensions and other controllers).

Worksteps	
Check & optimise application/DC-bus operation:	
1	Traverse axis in manual operation. • See chap. Basic drive functions ▶ Manual jog (📖 400)
2.	Check area boundaries (path, speed, torque).
3	Traverse axis in automatic operation with set-up speed, possibly together with coupled axes.
4	Check coupling with other movements (master/slave axes, tools, ...).
5	Optimisation of the process at higher speeds.
6	Recording of typical signal characteristics using the oscilloscope function for the documentation. • See chapter Oscilloscope (📖 585)
Save & archive project and parameter set:	
1	Execute device command C00002 = "11: Save start parameters".
2.	Save »Engineer« project.
3	Deposit a backup copy of the »Engineer« project, e.g. on CD ROM, in the control cabinet.

3.4

Standard set-up

Worksteps	
Transfer application and parameter set to the controller:	
1	Transfer the application preconfigured in »Engineer« and the corresponding parameter set to the memory module of the controller.
2.	Execute device command C00002 = "11: Save start parameters".
For a motor with an electronic nameplate (ENP):	
3	Restart controller with connected motor to read out the motor data from the electronic nameplate (ENP). • Either by switching off/switching on again the voltage supply or by means of device command C00002 = "11000: Restart controller". • See chap. Motor interface ▶ Reading out motor data from the controller (📖 120)
4	Execute device command C00002 = "11: Save start parameters".
For a motor without an electronic nameplate (ENP):	
	Note: The motor is operated with the motor data and plant parameters identified during initial commissioning. ▶ Adjusting motor and controller to each other (📖 126)

3.5 Controller replacement

Scenario: The controller has failed in a running system.



Note!

For the procedure described in the following it is assumed that the memory module and possibly available extension modules in the controller, as well as the motor are not affected by the failure and that all parameters have been saved with mains failure protection.

Worksteps	
Replacement of the controller:	
1	Replace controller. See Mounting Instructions for the controller!
2.	Insert the memory module of the failed controller into the replacement device.
3	If further extension modules are plugged into the failed controller, they must be inserted into the replacement device as well.
Further steps are not required since all data required are on the memory module.	

3.6 Motor replacement

Scenario: The motor has failed in a running system.



Note!

For the procedure described in the following it is assumed that the controller is not affected by the failure.

Worksteps	
Replacement of the motor:	
1	Replace the motor. See Mounting Instructions for the controller!
	Note: The motor connection on the controller is accessible without having to remove the standard device from the installation backplane.
For a motor with an electronic nameplate (ENP):	
2.	Restart controller with connected motor to read out the motor data from the electronic nameplate. <ul style="list-style-type: none"> • Either by switching off/switching on again the voltage supply or by means of device command C00002 = "11000: Restart controller". • See chap. Motor interface ▶ Reading out motor data from the controller (□ 120)
3	Execute device command C00002 = "11: Save start parameters".
For a motor without an electronic nameplate (ENP):	
	Note: The motor is operated with the motor data and plant data from the memory module.

4 Drive interface

This chapter provides you with information on the drive interface via which you can control the drive controller into specific states and call different pieces of status information of the controller. Furthermore the machine constants for the motor end are entered via the drive interface.




How to get to the dialog for setting the drive interface parameters:

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the following button of the *Overview* dialog level:



Parameterisation dialog in the »Engineer«




- The white buttons indicate the configuration of the drive interface inputs. ▶ [Internal interfaces](#) | ["LS_DriveInterface" system block \(113\)](#)
 - The assignment is predefined by the technology application selected (in the example "Actuating drive – speed"). If required, this assignment configuration can be changed by clicking the corresponding buttons.
- If you click a button marked with the → symbol, you go one level deeper in the corresponding parameterisation dialog.

4 Drive interface

4.1 Machine parameters

4.1 Machine parameters

The global machine constants ("machine parameters") are set in the »Engineer« on the **Application parameters** tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:



Tip!

Detailed information on the different machine parameters can be obtained from the following subchapters.

4 Drive interface

4.1 Machine parameters

4.1.1 Mains voltage

Via the **Mains voltage** list field ([C00173](#)) the mains voltage for the controller is set.

- If you set a mains voltage with an adjustable threshold for undervoltage ("LU adjustable"), this undervoltage threshold can be set in the **Undervoltage threshold (LU)** input field ([C00174](#)).
- In the **Resp. to DC-bus overvoltage** list field ([C00600](#)) you can select the response that is to be effected when a DC-bus overvoltage occurs.



Note!

Changing the setting in [C00173](#) also affects the permissible device utilisation!



Tip!

In the chapter "Rated data" of the hardware manual the device types and their permissible device utilisation at a certain mains voltage and switching frequency are specified.


See also: [▶ Monitoring of the device utilisation](#) (📖 111)

4 Drive interface

4.1 Machine parameters

4.1.2 Gearbox ratio

The gearbox ratio indicates the number of revolutions of the motor axis it takes for exactly one revolution of the load axis (e.g. spindle or drive roll) to take place.




[4-1] Schematic diagram of gearbox ratio

- In the example shown in illustration [4-1] one revolution of the spindle is carried out at exactly 58,667 revolutions of the motor axis.

Specification of the gearbox ratio

- The gearbox ratio is to be defined in the form of a quotient (numerator/denominator); the data required can be found in the technical data for the gearbox:



[4-2] Example: Technical data relating to the gearbox (from gearbox catalogue)




Tip!

In order to specify the gearbox ratio exactly, use the number of teeth indicated on the data sheet or in the catalogue, instead of the information on the nameplate (see following calculation).

In [C02531/1](#) the gearbox factor is displayed in decimal format.

Example calculation on the basis of the technical gearbox data:



[4-3] Sample calculation

4 Drive interface

4.1 Machine parameters


4.1.3 Motor mounting direction

Depending on the motor mounting position, you can carry out an inversion of the direction of rotation via the **Motor mounting direction** list field ([C02527](#)), if required:

- [C02527](#) = "0": Clockwise rotating motor \equiv positive machine direction.
- [C02527](#) = "1": Counter-clockwise rotating motor \equiv positive machine direction.

4.1.4 Feedback configuration

In most cases the system only has one motor encoder, i.e. no separate position encoder is installed on the load side. The motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and converted with regard to the load side.



[4-4] Schematic diagram - feedback with position encoder = motor encoder

The actual position and speed values on the machine side result from the conversion via the [Gearbox ratio](#) on the motor side and the [Feed constant](#).



Tip!

Detailed information on the parameterisation of the feedback systems for the motor control can be found in the chapter "[Encoder evaluation](#)". ([239](#))

4 Drive interface

4.1 Machine parameters

4.1.5 Unit/user-defined unit

Via these machine parameters you define the real unit of the machine in which the feed constant and the parameters for a travel profile must be specified (e.g. position, speed, acceleration, and deceleration).

- If you for instance set the unit "mm" for a linear axis, the position must be specified in [mm] and the speed in [mm/s].
- By means of the user-defined unit, significant production units, like for example "bottles" can also be set.
 - For this, select the "User-defined" entry as unit in [C02525](#) and then enter the desired user-defined unit in [C02526](#).



Note!

In this documentation the term "unit" in the parameter unit data only serves as a wildcard for the real unit of the machine.

Display parameter

Parameters	Info
C02534	Time unit used
C02535	Unit used
C02537	Speed unit
C02538	Acceleration unit

Greyed out = display parameter

4.1.6 Traversing range

The selection of the traversing range ("Unlimited", "Limited", or "Modulo") in the **Traversing range** list field ([C02528](#)) serves to define the machine measuring system.




Note!

A change-over of the traversing range results in a loss of the reference information!

"Unlimited" traversing range

The drive can rotate continuously in one direction.

- By referencing and activating the software limit positions the traversing range can be limited.
- For positioning with absolute travel command the home position must be known.




[4-5] Unlimited traversing range, taking the "feed control tape" as an example

"Limited" traversing range

The travel range is limited by positive and negative position limits (mechanical limits/travel range limit switches/software limit positions). ▶ [Limitier](#) (📖 506)

- After a defined distance the drive must travel in the opposite direction again.
- For positioning in the limited traversing range the home position must be known.
- The software limit positions are basically monitored with regard to the maximum value range that can be represented internally ($\pm 2^{31}$ increments), even if monitoring has been deactivated via [C02700](#).
- An overflow of the value range results in a loss of the reference information.



[4-6] Example: Limited traversing range - "spindle drive" (linear axis)


4 Drive interface

4.1 Machine parameters

"Modulo" traversing range

The measuring system is repeated.

- If the cycle set in [C02536](#) is exceeded, a defined overflow occurs. In a rotative system, the cycle typically corresponds to a revolution or tool distance.
- For positioning in the "Modulo" traversing range the home position must be known.
- Software limit positions are not effective.
- Absolute targets can be approached by exceeding the measuring system limit, e.g. from 10° to 350°.




[4-7] Example: Modulo traversing range - "rotary table"

Dependencies - traversing range/basic drive functions

- The following table lists the different dependencies between the selected traversing range and the basic drive functions.

Basic drive function	Traversing range		
	Unlimited	Limited	Modulo
Position data for Encoder evaluation	Continuously	Continuously	Clocked
Position data for Position follower	Absolute	Absolute	Absolute (in time)
Positioning modes for Positioning	1, 2, 5, 6, 7, 8	1, 2, 5, 6, 7, 8	5, 6, 11 ... 16
Restrictions for Homing	None	None	Home position must be in time
Limit positions (Limiter)	Permitted	Permitted	Not permitted



Example 1: Unlimited/limited position display

- ① Reference setting
- ② Position in the machine measuring system
- ③ Position in the motor measuring system

Example 2: Modulo position display

- ① Cycle
- ② Position in the machine measuring system
- ③ Position in the motor measuring system


4 Drive interface

4.1 Machine parameters

4.1.7 Feed constant

The feed constant corresponds to the movement of the machine during one revolution of the gearbox output shaft.


- The entry in the **Feed constant** field ([C02524](#)) is made in the unit defined in [C02525](#) relating to one revolution.
- In the case of a conveyor drive, the feed constant is obtained from the drive roll's circumference, which, in the following example, is calculated on the basis of the indicated diameter:



$$\text{Feed constant} = \pi \cdot d \frac{[\text{Unit}]}{\text{Revolution}} = \pi \cdot 200 \frac{\text{mm}}{\text{Revolution}} = 628.3185 \frac{\text{mm}}{\text{Revolution}}$$

[4-8] Schematic diagram: Feed constant for a conveyor driver

- In the case of a spindle drive (linear axis), the feed constant is derived from the leadscrew pitch. The feed constant indicates the distance the slide travels during one revolution of the spindle (in the following example: 5.023 mm).



[4-9] Schematic diagram: Feed constant for a spindle drive

- In the case of a rotary table and its specification as an angle, the feed constant is = 360°/revolution.

4 Drive interface

4.1 Machine parameters

4.1.8 Resolution of an encoder revolution


The following applies to software versions lower than V3.0:

The resolution of an encoder revolution and hence of a position value is constantly set to 16 bits/revolution, which corresponds to 65536 increments/revolution. At this resolution, the traversing range comprises ± 32767 revolutions.

The following applies from software version V3.0:


[C00100](#) serves to adjust the resolution to the application.

- The default resolution of 16 bits/revolution is sufficient for standard applications.



[4-10] Example: standard resolution (16 bits/revolution)

- For more significant applications, a higher resolution of the position values can clearly improve the control properties and positioning accuracies:
 - Finer resolution of the position targets \rightarrow improved positioning accuracy
 - Finer quantisation of setpoints and actual values \rightarrow better control quality
 - Higher loop gain adjustable \rightarrow less following errors
- However, a higher resolution at the same time causes a restricted number of encoder revolutions, and only smaller traversing distances can be displayed.



[4-11] Example: Higher resolution (22 bits/revolution) with a restricted traversing range



Tip!

In the following subchapter "[Determining the optimum resolution](#)" (42) it is described how you can determine the optimum resolution of the position values.

**Note!**

The position values (e.g. setpoints, actual values, parameters, ...) in the signal flow always use the resolution set in [C00100](#). In this connection it is irrelevant which resolution is delivered directly by the encoder.

Multi-axis systems

In an interconnection via the electrical shaft, at least two measuring systems (master and slave) are available in the drive.

- Each measuring system is provided with an individual setting of the resolution.
- The machine parameters (gearbox factors, feed constants, encoder resolution and cycle) for the master measuring system or master value must be set identically for all drives in the system.

Technology applications "Electronic gearbox" and "Synchronism"

For these two technology applications the machine parameters of the master measuring system are defined on the *Application parameters* tab in the "Master value scaling" dialog level.

Electronic cam

The machine parameters of the master measuring system for electronic cams can be defined on the *Measuring systems* tab for the electrical shaft.

4.1.8.1 Determining the optimum resolution

This function extension is available from software version V3.0!



How to determine the optimum resolution:

In the dialog level *Overview* → *Drive interface* → *Machine parameters*:

1. Set gearbox factors.
2. Set real unit of the machine.
3. Set feed constant.
4. Click the **Optimum positional resolution** button.
 - The *Optimum positional resolution* dialog box is displayed:

5. Go to the **Max. presentable position** input field and enter the highest position which is to be entered in a parameter during operation.
 - If required, set a reserve in the **Overshoot** input field to take into account possible following errors (overshoot of actual values).

Then the maximum resolution for the position entered is shown in the **Maximum resolution for encoder revolution** field.

6. Click **Accept value** to accept the displayed resolution in [C00100](#).
7. Click **Close** to close the dialog box again.



Tip!

In order to display the position that can be maximally represented for a defined resolution, activate the second option **Determine max. presentable position**. Then you can set the resolution for which the maximally presentable position is to be displayed in the **Maximum resolution for encoder revolution** input field.

4 Drive interface

4.1 Machine parameters

4.1.9 Max. position, speed, and acceleration that can be displayed internally

By setting the following machine parameters, the connection between the real units (application units) of the machine and the internal units in the controller is described:

- Gearbox ratio ([C02520](#), [C02521](#), [C02522](#), [C02523](#))
- Feed constant ([C02524](#))
- Resolution of an encoder revolution ([C00100](#))

Possibly the defined values for position, speed, and acceleration cannot be represented in the internal units by the numerical 32-bit format used.

- The following display parameters show the values that can be maximally displayed:

Parameters	Info	Lenze setting	
		Value	Unit
C02539	Maximum position that can be displayed	-	Unit
C02540	Speed that can be maximally displayed	-	Unit/s
C02541	Acceleration that can be maximally displayed	-	Unit/s ²

Greyed out = display parameter

Response if a value that cannot be displayed internally is entered

If a position, speed, or acceleration which cannot be represented internally is defined via parameters, the value defined is limited to the maximum value that can be represented internally (± 2147483647).

The following only applies to software version V3.0:

- If a position, speed, or acceleration which cannot be represented internally is defined via parameters, the value defined is rejected.
- If an internal counter overflow of a parameter value due to a subsequent change of the machine parameters for the gearbox ratio, feed constant, or resolution of an encoder revolution is detected, the "Fault" error response is triggered and a corresponding error message is entered in the logbook of the controller:

Error number	Error message
0x00B8001A	Int. overflow C02620 (manual speed 1)
0x00B8001B	Int. overflow C02621 (manual speed 2)
0x00B8001C	Int. overflow C02622 (manual acceleration)
0x00B8001D	Int. overflow C02624 (manual deceleration)
0x00B80020	Int. overflow C02701/1 (positive SW limit position)
0x00B80021	Int. overflow C02701/2 (negative SW limit position)
0x00B80022	Int. overflow C02703 (maximum speed)
0x00B80023	Int. overflow C02705 (maximum acceleration)
0x00B80024	Int. overflow C02708/1 (limited speed 1)
0x00B80025	Int. overflow C02708/2 (limited speed 2)
0x00B80026	Int. overflow C02708/3 (limited speed 3)
0x00B80027	Int. overflow C02708/4 (limited speed 4)
0x00B80028	Int. overflow C02710/1 (decel. limited speed 1)
0x00B80029	Int. overflow C02710/2 (decel. limited speed 2)
0x00B8002A	Int. overflow C02710/3 (decel. limited speed 3)
0x00B8002B	Int. overflow C02710/4 (decel. limited speed 4)
0x00B8002C	Int. overflow C02713 (maximum distance manual jog)
0x00B8002D	Int. overflow C02642 (home position)
0x00B8002E	Int. overflow C02643 (homing: target position)
0x00B8002F	Int. overflow C02644 (homing: speed 1)
0x00B80030	Int. overflow C02645 (homing: acceleration 1)
0x00B80031	Int. overflow C02646 (homing: speed 2)
0x00B80032	Int. overflow C02647 (homing: acceleration 2)
0x00B80033	Int. overflow C02670 (positioning: tolerance for target position)



Tip!

Possible measures for error correction:

- Plausibility check of the machine parameters set for gearbox ratio, feed constant, or resolution of an encoder revolution.
- Set parameters with a counter overflow to a value which can also be represented internally.

4.2 Device commands

In the following subchapters the device commands of the controller are described, which are provided in [C00002](#) and which can be executed by means of »Engineer« or alternatively with the keypad when an online connection has been established.



Note!

Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in [C00003](#)!

The meaning of the status display in [C00003](#) can be obtained from the subchapter for the corresponding device command.

Activating frequently required device commands via the toolbar

The simplest way to execute the frequently required device commands is directly via the *Toolbar* of »Engineer« when an online connection has been established.

Symbol	Job title
	Enable controller
	Inhibit controller
	Start application
	Inhibit controller and Stop application



Note!


Device commands that can be executed via the *Toolbar* of the »Engineer« always affect the element currently selected in the *Project view* including all subelements!

- If no controller but a system module is selected in the *Project view*, the corresponding device command will be activated in all lower-level controllers having an online connection with the »Engineer«.

Before the desired action is carried out, a confirmation prompt appears first, asking whether the action is really to be carried out.

Activating device commands via the "Device commands" dialog box

All device commands of the controller are available in »Engineer« in the *Device Commands* dialog box:




- The *Device commands* dialog box can be opened by clicking on the **Device commands** list field on the **Application parameters** tab in the dialog level *Overview* → *Drive interface*.
- The *Device commands* dialog box can also be opened by clicking the setting of [C00002](#) on the **All parameters** tab.



Note!

If you click a device command in the list field of the *Device commands* dialog box, the corresponding device command is executed immediately!

- During and after the execution of the device command, the processing status is displayed in the *Device Commands* dialog box:




4 Drive interface

4.2 Device commands

4.2.1 Load Lenze setting




The [C00002](#) = "0: Load Lenze setting" device command is used to reset the parameters of the active application to the Lenze setting, which is stored in the controller firmware:



[4-12] "Load Lenze setting" function

- Only possible when the application has stopped and the controller is inhibited.
- All parameter changes made since the last saving of the parameter set will get lost!
- This device command only affects the settings of the operating system, application and module parameters, the active application or the configuration selected with the function block editor remains unchanged.

Possible status displays for this device command

Status (C00003)	Meaning
 34050	Device command in process
 0	Device command executed successfully
	1 General error
	39424 CAN fault

39679	CAN fault

Related device commands

▶ [Load start parameters](#) ([48](#))


▶ [Save start parameters](#) ([52](#))

4 Drive interface

4.2 Device commands

4.2.2 Load start parameters




Via [C00002](#) = "1: Load start parameters" the start parameters of the active application can be reloaded from the memory module to the controller:



[4-13] "Load start parameters" function

- Only possible when the application has stopped and the controller is inhibited.
- All parameter changes made since the last saving of the parameter set will get lost!
- This device command only affects the settings of the operating system, application and module parameters, the active application or the configuration selected with the function block editor remains unchanged.

Possible status displays for this device command

Status (C00003)	Meaning
	99586 Device command in process
	65536 Device command executed successfully
	65537 General error
	99371 Fault while reading the parameter set partition
	99374 No memory module available
	104960 CAN fault

105215 CAN fault	

Related device commands

- ▶ [Save start parameters](#) ([📖 52](#))
- ▶ [Load Lenze setting](#) ([📖 47](#))

4.2.3 ENP:Load plant data

If the Lenze motor connected to the controller is provided with an electronic nameplate (ENP), all motor data are automatically read out from the electronic nameplate of the motor when the controller is switched on for the first time and are temporarily stored in the controller at first.

With the device command [C00002](#) = "2: ENP: Load plant data" the motor data can be reread from the electronic nameplate (ENP) of the motor.

- Only possible when the application has stopped and the controller is inhibited.
- For a permanent acceptance of the motor data, the parameter set must be saved. ▶ [Save start parameters](#) (□ 52)
- The following plant data are read out from the ENP:

Parameters	Info
C00022	Maximum current
C00070	Speed controller gain
C00071	Speed controller reset time
C00596	Threshold max. speed reached






Note!

The two pieces of plant data [C00011](#) and [C00497](#) listed in the following table are not read out from the ENP and thus have to be checked and, if required, set manually after this device command has been executed!


Parameters	Info
C00011	Reference speed motor
C00497	Speed act. val. time const.

Possible status displays for this device command

Status (C00003)	Meaning
 165122	Device command in process
 131072	Device command executed successfully
 131073	General error

4.2.4 Activate application

Use the device command [C00002](#) = "5: Activate application" to activate the application archived on the memory module.



[4-14] "Activate application" function




- Only possible when the application has stopped and the controller is inhibited.
- Whether the application is started at the same time, depends on the auto-start setting selected in [C02104](#).
- After mains switching, the preset application will be loaded into the controller.
- The number of the currently active application is displayed with "1" in [C00007](#) after the download via the »Engineer«.



Note!

When the application is activated, the corresponding start parameter set is loaded automatically and parameter settings executed before will get lost unless the parameter set was saved before!

Possible status displays for this device command

Status (C00003)	Meaning
 361730	Device command in process
 327680	Device command executed successfully
 327681	General error

Related device commands


- ▶ [Save selected application](#) (📖 51)
- ▶ [Start application](#) (📖 56) / ▶ [Stop application](#) (📖 57)

4 Drive interface

4.2 Device commands

4.2.5 Save selected application

With the device command [C00002](#) = "7: Save selected application" the active application can be defined as start application.



[4-15] "Save selected application" function

- When this device command is executed, the parameter set is also saved automatically.
- The number of the currently active application is displayed in [C00007](#).






Note!

The application "0" (Lenze setting) is intended for the Lenze service.

During initial commissioning, the download with the Engineer causes the application "1" archived on the memory module to be defined as start application.

Possible status displays for this device command

Status (C00003)	Meaning
 492802	Device command in process
 458752	Device command executed successfully
 458753	General error


Related device commands

- ▶ [Activate application](#) (📖 50)
- ▶ [Start application](#) (📖 56)
- ▶ [Stop application](#) (📖 57)

4.2.6 Save start parameters

Controller parameter changes made via »Engineer« or keypad will get lost after mains switching of the controller or loading of another application unless the settings have been explicitly saved.

With the device command [C00002](#) = "11: Save start parameters" the current parameter settings of the active application can be saved with mains failure protection in the memory module of the controller:



[4-16] "Save start parameters" function



Tip!

With the keypad this device command can be executed via the left function key if it is currently assigned with the **SAVE** function.



Note!




The saving process can take several seconds. Before you switch off the supply voltage after having executed this device command, therefore be absolutely sure to check via the status display in [C00003](#) whether the device command has been executed successfully!

Saving of the cam data

From software version [V4.0](#), this device command also includes the powerfail-proof saving of the cam data on the memory module.

- The saving process is only carried out if the cam data in the controller and the memory module differ from each other (based on the time stamp/GUID of the cam data).
- For saving the cam data, you do not need to enter a possibly existing user password ([C02900](#)).
- The [C00002](#) = "502: Save Cam Data" device command remains available. ▶ [Save cam data](#) (□ 92)

Possible status displays for this device command

Status (C00003)	Meaning
	754946 Device command in process
	720896 Device command executed successfully
	720897 General error
	754718 Fault while writing into a file
	754734 No memory module available
	761857 Access to file has been denied since the file is already accessed from another position
	761861 I/O fault when accessing the file system
	761868 RAM is full
	761869 Access authorisation denied
	761884 No free memory on the memory module

Related device commands

- ▶ [Load start parameters](#) (📖 48)

4 Drive interface

4.2 Device commands

4.2.7 Delete logbook

The [C00002](#) = "20: Delete logbook" device command is used to delete all entries in the logbook.






Tip!

To display the logbook in the »Engineer«, click the **Logbook** button on the **Diagnostics** tab. In the *Logbook* dialog box, it is also possible to delete all logbook entries by clicking the **Delete** button.

Further information on the logbook can be found in the chapter "[Diagnostics & fault analysis](#)". ([📖 608](#))

Possible status displays for this device command

Status (C00003)	Meaning
 1344770	Device command in process
 1310720	Device command executed successfully
 1310721	General error

Related device commands

▶ [Archive logbook](#) ([📖 55](#))

4.2.8 Archive logbook

The [C00002](#) = "21: Archive logbook" device command is used to archive the entries in the logbook.






Tip!

To display the logbook in the »Engineer«, click the **Logbook** button on the **Diagnostics** tab. You can also export all entries available in the logbook into a file (*.log) by clicking the **Export** button in the *Logbook* dialog box.

Further information on the logbook can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 608)

Possible status displays for this device command


Status (C00003)	Meaning
 1410306	Device command in process
 1376256	Device command executed successfully
 1376257	General error

Related device commands

▶ [Delete logbook](#) (📖 54)

4.2.9 Start application

The [C00002](#) = "31: Start application" device command is used to start the active application in the controller.



[4-17] "Start application" function




- The number of the currently active application is displayed with "1" in [C00007](#).
- The current program status is displayed in [C02108](#).
- The active function state of the application is displayed in [C02530](#).



Tip!

This device command can also be activated via the  icon in the *Toolbar*.

Possible status displays for this device command


Status (C00003)	Meaning
 2065666	Device command in process
 2031616	Device command executed successfully
 2031617	General error

Related device commands

- ▶ [Stop application](#) ([📖 57](#))
- ▶ [Activate application](#) ([📖 50](#))
- ▶ [Save selected application](#) ([📖 51](#))

4.2.10 Stop application

The [C00002](#) = "32: Stop application" device command can be used to stop the application started in the controller again.




[4-18] "Stop application" function




- Only possible when the controller is inhibited.



Tip!

Via the  icon in the *Toolbar* the controller can be inhibited, and at the same time the application in the controller can be stopped.

Possible status displays for this device command

Status (C00003)	Meaning
 2131202	Device command in process
 2097152	Device command executed successfully
 2097153	General error

Related device commands




- ▶ [Start application](#) (📖 56)
- ▶ [Inhibit controller](#) (📖 63)
- ▶ [Activate application](#) (📖 50)
- ▶ [Save selected application](#) (📖 51)

4.2.11 Reset program

The [C00002](#) = "33: Reset program" device command is used to reset the application program in the controller.

- All variables are reset to their initialisation value.
- The situation corresponds to the start of a new program loaded into the control (cold start).

Possible status displays for this device command

Status (C00003)	Meaning
 2196738	Device command in process
 2162688	Device command executed successfully
 2162689	General error

Related device commands

- ▶ [Delete program](#) ([book 59](#))
- ▶ [Restart program](#) ([book 60](#))

4 Drive interface




4.2 Device commands

4.2.12 Delete program

The [C00002](#) = "34: Delete program" device command is used to delete the application program in the controller and reset the controller to its original state.

- All variables are reset to their initialisation value.

Possible status displays for this device command

Status (C00003)	Meaning
 2262274	Device command in process
 2228224	Device command executed successfully
 2228225	General error

Related device commands




- ▶ [Reset program](#) ([📖 58](#))
- ▶ [Restart program](#) ([📖 60](#))

4.2.13 Restart program

The [C00002](#) = "35: Restart program" device command is used to restart the application program in the controller.

- All variables except the RETAIN variables are reset to their initialisation value.
- The situation corresponds to a power failure or switching the controller off/on (warm start) while the program is running.

Possible status displays for this device command

Status (C00003)	Meaning
 2327810	Device command in process
 2293760	Device command executed successfully
 2293761	General error

Related device commands

- ▶ [Reset program](#) ([📖 58](#))
- ▶ [Delete program](#) ([📖 59](#))

4 Drive interface




4.2 Device commands

4.2.14 Reset runtime measurement

When the application is started, the controller continuously carries out a runtime measurement for the interval-controlled application task, the interval-controlled user task, and the free-running idle task and displays the current and maximum task runtimes via parameters.

The [C00002](#) = "36: Reset runtime measurement" device command is used to reset the runtime measurement, i.e. the memory for the maximum values is reset to "0".

Possible status displays for this device command

Status (C00003)	Meaning
 2393346	Device command in process
 2359296	Device command executed successfully
 2359297	General error




Note!

The runtime measurement is also reset by the following actions:

- Start application
- Reset/delete/restart program

Example for runtime measurement



[4-19] Example: Runtimes of the different tasks

Display parameter

Parameters	Info	Lenze setting	
		Value	Unit
C02121/1	Current runtime - application task	-	µs
C02121/2	Maximum runtime - application task	-	µs
C02122/1	Current runtime - user task	-	µs
C02122/2	Maximum runtime - user task	-	µs
C02123/1	Current runtime - idle task	-	µs
C02123/2	Maximum runtime - idle task	-	µs
Greyed out = display parameter			

4.2.15 Inhibit controller

The [C00002](#) = "41: Inhibit controller" device command is used to inhibit the controller ("controller inhibit"), i.e. the power output stages in the controller are inhibited and the speed/current and position controllers of the motor control are reset. The motor becomes torqueless and coasts unless it is already at standstill.

- The controller can also be inhibited by other sources, e.g. via the digital input RFR or through the application.
- [C00158](#) provides a bit coded representation of all active sources/triggers of a controller inhibit.



Note!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



Tip!

This device command can also be activated via the  icon in the *Toolbar*.

Related device commands

- ▶ [Enable controller](#) (📖 64)

4.2.16 Enable controller

The [C00002](#) = "42: Enable controller" device command is used to re-enable an inhibited controller.



Note!

Please note that the controller will only be enabled if all sources for controller inhibit are reset!

- [C00158](#) provides a bit coded representation of all active sources/triggers of a controller inhibit.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



Tip!

This device command can also be activated via the  icon in the *Toolbar*.

Related device commands

- ▶ [Inhibit controller](#) (📖 63)

4.2.17 Reset error

The [C00002](#) = "43: Reset error" device command is used to acknowledge an error message if the error cause has been eliminated and the error is thus no longer pending.



Tip!

An error message can also be acknowledged by activating the **Reset error** button in the **Diagnostics** tab.

Further information on error messages can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 608)



Note!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.

4.2.18 Activate quick stop

The [C00002](#) = "45: Activate quick stop" device command is used to activate the basic function "Quick stop", i. e. the drive is brought to standstill within the deceleration time set, irrespective of the setpoint defined.

- Quick stop can also be activated by other sources, e.g. by the application.
- [C00159](#) displays a bit code of active sources/causes for the quick stop.



Note!

The activation of quick stop may cause following errors in superimposed controls (e.g. synchronous or position control). If several drives execute a coordinated movement, the quick stop function should therefore only be used for the motion master (master drive) in order to maintain the coordination.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



Tip!

In contrast to the "stop" function, quick stop is required for a stop in the event of an error. Thus, quick stop can also be set as an error response ("quick stop by trouble) for many monitoring functions. Detailed information on this can be found in the chapter "[Diagnostics & fault analysis](#)". ([📖 608](#))

Related device commands

- ▶ [Reset quick stop](#) ([📖 67](#))

4.2.19 Reset quick stop

The [C00002](#) = "46: Reset quick stop" device command is used to exit an active quick stop again.



Note!

Please note that the quick stop is only exited if all sources for quick stop are reset!

- [C00159](#) displays a bit code of active sources/causes for the quick stop.

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.

Related device commands

- ▶ [Activate quick stop](#) (📖 66)

4.2.20 Identify pole position (360°)

If no absolute value encoder is connected, or a synchronous motor of a third-party manufacturer is driven by the controller, the [C00002](#) = "51: Identify pole position (360°)" device command is used to determine the pole position with regard to the motor encoder currently activated in [C00495](#).

- The function can only be activated if the controller is inhibited. Then the execution of the function starts automatically as soon as the controller inhibit is deactivated again.
- During the pole position identification, the motor carries out one electrical revolution. This leads to a mechanical rotation of the motor shaft.
- The determined pole position is indicated under code [C00058](#).



Note!




From software version V4.0 the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.



Tip!

Detailed information on the pole position identification can be found in the chapter "Motor interface", subchapter "[Pole position identification](#)". ([📖 131](#))

Possible status displays for this device command

Status (C00003)	Meaning
	3376386 Device command in process
	3342336 Device command executed successfully
	3342337 General error
	3382023 Pole position identification cannot be executed because of wrong motor type (asynchronous motor).
	3382024 Pole position identification has been aborted
	3382025 Pole position identification cannot be executed because another identification is already active.
	3382026 Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.
	3382027 Identification of pole position cannot be executed because current controller optimisation mode is active.
	3382033 Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.
	3382047 Pole position identification cannot be executed because an error or trouble is active.
3382065 Pole position identification cannot be executed because either the entire motor or a motor phase is not connected. • This error message is only available from software version V3.0 onwards.	

Related device commands

- ▶ [Identify pole position \(min. motion\)](#) ([📖 69](#))

4.2.21 Identify pole position (min. motion)

If no absolute value encoder is connected, or a synchronous motor of a third-party manufacturer is driven by the controller, the [C00002](#) = "52: Identify pole position (min. motion)" device command is used to determine the pole position with respect to the motor encoder currently activated in [C00495](#).

- The function can only be activated if the controller is inhibited. Then the execution of the function starts automatically as soon as the controller inhibit is deactivated again.
- During the pole position identification, the rotor aligns itself. This is compensated by a position control.
- The determined pole position is indicated under code [C00058](#).



Note!




From software version V4.0 the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.



Tip!

Detailed information on the pole position identification can be found in the chapter "Motor interface", subchapter "[Pole position identification](#)". ([131](#))

Possible status displays for this device command

Status (C00003)	Meaning
	3441922 Device command in process
	3407872 Device command executed successfully
	3407873 General error
	3447559 Pole position identification cannot be executed because of wrong motor type (asynchronous motor).
	3447560 Pole position identification has been aborted
	3447561 Pole position identification cannot be executed because another identification is already active.
	3447562 Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.
	3447563 Identification of pole position cannot be executed because current controller optimisation mode is active.
	3447569 Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable. <ul style="list-style-type: none"> • This error message is only available from software version V4.0 onwards.
	3447583 Pole position identification cannot be executed because an error or trouble is active.
	3447597 Identification of pole position cannot be executed because the rotor has moved too strongly.
3447601 Pole position identification cannot be executed because either the entire motor or a motor phase is not connected. <ul style="list-style-type: none"> • This error message is only available from software version V3.0 onwards. 	

4 Drive interface

4.2 Device commands

Related device commands

- ▶ [Identify pole position \(360°\)](#) (📖 68)

4.2.22 Resolver error identification

This function extension is available from software version V7.0!

The [C00002](#) = "59: Resolver error identification" device command serves to detect resolver errors which are caused when sine and cosine tracks do not magnetise orthogonally. The identified resolver errors serve to compensate the resolver errors.




- Only possible with servo control.



Tip!

Detailed information on the resolver error compensation can be found in the chapter "Encoder evaluation" in the subchapter "[Resolver error compensation](#)". (□ 266)

Possible status displays for this device command

Status (C00003)	Meaning
 3900674	Device command in process
 3866624	Device command executed successfully
	3866625 General error
	3906358 Resolver error identification cannot be executed since the wrong control type is active (no servo control).
	3906359 Resolver error identification cannot be executed since an error or trouble is active.
	3906360 Resolver error identification cannot be executed because another identification is already active.
3906361	Resolver error identification cannot be executed because of too small speed (< 500 rpm).

4.2.23 Load Lenze INV characteristic

This function extension is available from software version V4.0!

If determination of the so-called "inverter error characteristic" is not possible with the device command "[Calculate inv. characteristic](#)" or leads to incorrect results, the device command [C00002](#) = "70: Load Lenze INV characteristic" can be used to load a characteristic which is typical of the device in question.




- Only possible when the controller is inhibited.



Tip!

Detailed information about the determination of the inverter error characteristic can be found in the chapter "Motor interface" in the subchapter "[Optimising the switching performance of the inverter](#)". (📖 138)

Possible status displays for this device command

Status (C00003)	Meaning
 4621570	Device command in process
 4587520	Device command executed successfully
 4587521	General error

Related device commands

- ▶ [Calculate inv. characteristic](#) (📖 73)

4.2.24 Calculate inv. characteristic

If a motor of a third-party manufacturer with unknown motor parameters is driven by the controller, the [C00002](#) = "71: Determine inverter characteristic" device command can be used to determine the so-called "Inverter error characteristic" for optimising the inverter switching performance.






Tip!

Detailed information about the determination of the inverter error characteristic can be found in the chapter "Motor interface" in the subchapter "[Optimising the switching performance of the inverter](#)". (📖 138)

From software version V4.0: If the inverter error characteristic cannot be determined by means of this device command, or if the results of the determination are incorrect, the device command "[Load Lenze INV characteristic](#)" can be used to load a characteristic typical of the device. (📖 72)

Possible status displays for this device command

Status (C00003)	Meaning
	4687106 Device command in process
	4653056 Device command executed successfully
	4653057 General error
	4692754 The calculation of the inverter characteristic cannot be started since the current controller test mode is active.
	4692755 The calculation of the inverter characteristic cannot be started since the V/f test mode is active.
	4692756 The calculation of the inverter characteristic cannot be started since the pole position identification is active.
	4692757 Calculation of the inverter characteristic has been aborted.
	4692758 Calculation of the inverter characteristic has been interrupted by error.
	4692789 Determined inverter error characteristic exceeds internal limits. <ul style="list-style-type: none"> • This situation can for instance occur if the motor power is very much lower than the device power. • This error message is only available from software version V5.0 onwards.

Related device commands

- ▶ [Load Lenze INV characteristic](#) (📖 72)

4.2.25 Determine motor parameters

The [C00002](#) = "72: Determine motor parameters" device command is used to automatically determine the motor parameters for a third-party motor that are listed in the following table – if they are not known:




Parameters	Info	ASM	SM
C00079	Motor magnetising inductance	☑	
C00082	Motor rotor resistance	☑	
C00084	Motor stator resistance	☑	☑
C00085	Motor stator leakage inductance	☑	☑
C00091	Motor cosine phi	☑	
C00092	Motor magnetising current	☑	



Tip!

Detailed information about the automatic determination of the motor parameters can be found in the chapter "Motor interface" in the subchapter "[Determining the motor parameters](#)". (📖 141)

Possible status displays for this device command

Status (C00003)	Meaning
 4752642	Device command in process
 4718592	Device command executed successfully
	4718593 General error
	4758290 Motor identification cannot be started since the current controller test mode is active.
	4758291 Motor identification cannot be started since the V/f test mode is active.
	4758292 Motor identification cannot be started because pole position identification is active.
	4758293 Motor identification has been aborted.
	4758294 Motor identification has been aborted by fault.
4758332	Motor identification aborted due to inconsistent motor parameters. • This error message is only available from software version V7.0 onwards.

4.2.26 Calculate current controller parameters

This function extension is available from software version V5.0 onwards!

The device command [C00002](#) = "77: Calculate current controller parameters" is used to calculate the gain and the reset time of the current controller for a third-party motor.

Precondition: The two motor parameters "stator resistance" ([C00084](#)) and "stator leakage inductance" ([C00085](#)) either have been parameterised manually on the basis of the manufacturer information before, or have been determined automatically via the device command "[Determine motor parameters](#)".



Note!

For a Lenze motor the calculation and the subsequent optimisation of the current controller parameters is not required, as the correct current controller parameters are accepted from »Engineer« motor catalogue.

The device command is no identification procedure for determining the current controller parameters!

- The calculation is carried out according to the following formulas:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$
$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$

- After the device command has been executed successfully (see status in [C00003](#)), the two calculated values are set in [C00075](#) and [C00076](#). They serve as starting values for a subsequent optimisation of the current controller in the test mode.
- In the event of an error, codes [C00075](#) and [C00076](#) are not altered.






Tip!

Detailed information on the optimisation of the current controller in the test mode can be found in the chapter "Motor interface" in the subchapter for the respective motor control:

- Servo control (SC) ▶ [Optimise current controller](#) (147)
- Sensorless vector control (SLVC) ▶ [Optimise current controller](#) (181)
- V/f control (VFCplus) ▶ [Optimise current controller](#) (196)

Possible status displays for this device command

Status (C00003)	Meaning
	5080322 Device command in process
	5046272 Device command executed successfully
	5046273 General error
	5086002 At least one calculated value is outside the valid setting range.
	5086003 Stator resistance (C00084) too small (zero).

Related device commands

- ▶ [Determine motor parameters](#) (📖 74)
- ▶ [Calculate speed controller parameters](#) (📖 77)

4.2.27 Calculate speed controller parameters

This function extension is available from software version V5.0 onwards!

The device command [C00002](#) = "78: Calculate speed controller parameters" is used to calculate the gain, reset time, and rate time of the speed controller.

Precondition: The moments of inertia for the motor ([C00273/1](#)) and load ([C00273/2](#)) have been parameterised correctly before.



Note!

The device command is no identification procedure for determining the speed controller parameters!

- The calculation is carried out according to the following formulas, taking the actual speed value filter time constant into consideration ([C00497](#)):

$$\text{Gain} = \frac{\text{Moment of inertia of motor+load}}{4 \cdot (\text{Actual speed value filter time constant} + 500 \mu\text{s})} \cdot \frac{2\pi}{60}$$

$$\text{Reset time} = 4^2 \cdot (\text{Actual speed value filter time constant} + 500 \mu\text{s})$$

$$\text{Rate time} = 0 \text{ ms}$$

- After the device command has been executed successfully (see status in [C00003](#)), the calculated values are set in the corresponding codes:
 - [C00070](#): Speed controller gain
 - [C00071](#): Speed controller reset time
 - [C00072](#): Speed controller rate time
- In the event of an error, these codes are not altered.

Possible status displays for this device command

Status (C00003)	Meaning
5145858	Device command in process
5111808	Device command executed successfully
5111809	General error
	5151540

Related device commands

- ▶ [Calculate current controller parameters](#) (□ 75)

4.2.28 CAN on board: Reset Node




The [C00002](#) = "91: CAN on board: reset node" device command is used to reinitialise the CANopen system bus interface of the controller ("CAN on board"), which is required, for instance, after the data transfer rate, node address, or identifiers have been changed.



Tip!

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 5997826	Device command in process
 5963776	Device command executed successfully
	5963777 General error
	6003200 CAN fault

	6003455 CAN fault

Related device commands

- ▶ [CAN on board: Pred.Connect.Set](#) ([📖 80](#))
- ▶ [CAN on board: Identify node](#) ([📖 82](#))

4.2.29 CAN module: Reset node




The [C00002](#) = "92: CAN module: reset node" device command is used to reinitialise the CANopen interface of a CANopen communication module in module slot MXI1 or MXI2, which is required, for instance, after the data transfer rate, node address, or identifiers have been changed.



Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
	6063362 Device command in process
	6029312 Device command executed successfully
	6029313 General error
	6068736 CAN fault
	...
	6068991 CAN fault

Related device commands

- ▶ [CAN module: Pred.Connect.Set](#) ([📖 81](#))
- ▶ [CAN module: Identify node](#) ([📖 83](#))

4.2.30 CAN on board: Pred.Connect.Set




The [C00002](#) = "93: CAN on board: Pred.Connect.Set" device command is used to set the basic identifiers for the CANopen system bus interface of the controller ("CAN on board") according to the "Predefined Connection Set" (DS301V402).



Tip!

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6128898	Device command in process
 6094848	Device command executed successfully
 6094849	General error

Related device commands

- ▶ [CAN on board: Reset Node](#) ([📖 78](#))
- ▶ [CAN on board: Identify node](#) ([📖 82](#))

4.2.31 CAN module: Pred.Connect.Set




The [C00002](#) = "94: CAN module: pred.connect.set" device command is used to set the basic identifiers for the CANopen system bus interface of a CANopen communication module in module slot MXI1 or MXI2 according to the "Predefined Connection Set" (DS301V402).



Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6194434	Device command in process
 6160384	Device command executed successfully
 6160385	General error

Related device commands

- ▶ [CAN module: Reset node](#) ([📖 79](#))
- ▶ [CAN module: Identify node](#) ([📖 83](#))

4.2.32 CAN on board: Identify node

The [C00002](#) = "95: CAN on board: identify node" device command is used to determine the nodes connected to the CANopen system bus interface of the controller ("CAN on board").




- The result of the CAN bus scan is displayed in [C00393](#).



Tip!

For detailed information about the "CAN on board" CANopen system bus interface, please see the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6259970	Device command in process
 6225920	Device command executed successfully
 6225921	General error

Related device commands

- ▶ [CAN on board: Reset Node](#) (📖 78)
- ▶ [CAN on board: Pred.Connect.Set](#) (📖 80)

4.2.33 CAN module: Identify node

The [C00002](#) = "96: CAN module: identify node" device command is used to determine the nodes connected to the CANopen system bus interface of a CANopen communication module in module slot MXI1 or MXI2.




- The result of the CAN bus scan is displayed in C13393 (for MXI1) or in C14393 (for MXI2).



Tip!

Detailed information on the CANopen communication module (E94AYCCA) can be found in the "CAN" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6325506	Device command in process
 6291456	Device command executed successfully
 6291457	General error

Related device commands

- ▶ [CAN module: Reset node](#) ( 79)
- ▶ [CAN module: Pred.Connect.Set](#) ( 81)

4.2.34 Unbind/bind Ethernet module MXI1




The [C00002](#) = "101: Unbind/bind Ethernet module: MXI1" device command is used to reinitialise the Ethernet interface of an Ethernet communication module in module slot MXI1, e. g. to accept a newly set IP or gateway address without mains switching.



Tip!

Detailed information on the Ethernet communication module (E94AYCEN) can be found in the "Ethernet" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6653186	Device command in process
 6619136	Device command executed successfully
 6619137	General error

Related device commands

- ▶ [Unbind/bind Ethernet module MXI2](#) ( 85)

4 Drive interface

4.2 Device commands

4.2.35 Unbind/bind Ethernet module MXI2




The [C00002](#) = "102: Unbind/bind Ethernet module: MXI2" device command is used to reinitialise the Ethernet interface of an Ethernet communication module in module slot MXI2, e. g. to accept a newly set IP or gateway address without mains switching.



Tip!

Detailed information on the Ethernet communication module (E94AYCEN) can be found in the "Ethernet" Communication Manual.

Possible status displays for this device command

Status (C00003)	Meaning
 6718722	Device command in process
 6684672	Device command executed successfully
 6684673	General error

Related device commands

- ▶ [Unbind/bind Ethernet module MXI1](#) ( 84)

4.2.36 Activate parameter set 1 ... 4

In addition to the start parameters, up to four further parameter sets can be stored in the memory module for each application. Like this you can for instance define different controller settings for an application, which are then simply activated via device command, if required.


The following device commands can be used to activate the parameter set 1 ... 4 for the active application (if available on the memory module):

[C00002](#) = "201: Activate parameter set 1"

[C00002](#) = "202: Activate parameter set 2"

[C00002](#) = "203: Activate parameter set 3"

[C00002](#) = "204: Activate parameter set 4"






[4-20] Example: "Activate parameter set 1" function

- Only possible when the application has stopped and the controller is inhibited.
- All parameter changes of the previously active parameter set carried out since the last saving will get lost!
- These device commands only affect the settings of the operating system, application, and module parameters; the active application, or a configuration selected with the function block editor remain unchanged.

4 Drive interface

4.2 Device commands

Possible status displays for these device commands

Status (C00003)	for command				Meaning
	201	202	203	204	
	13206786	13272322	13337858	13403394	Device command in process
	13172736	13238272	13303808	13369344	Device command executed successfully
	13172731	13238273	13303809	13369345	General error
	13206532	13272068	13337604	13403140	File could not be opened.
	13206557	13272093	13337629	13403165	Fault while reading out of a file.
	13206558	13272094	13337630	13403166	Fault while writing into a file.
	13206559	13272095	13337631	13403167	Invalid file type.
	13206560	13272096	13337632	13403168	Unexpected end of file.
	13206562	13272098	13337634	13403170	Checksum error
	13212160	13277696	13343232	13408768	CAN fault

	13212415	13277951	13343487	13409023	CAN fault
	13213697	13279233	13344769	13410305	Access to file has been denied since the file is already accessed from another position
	13213701	13279237	13344773	13410309	I/O fault when accessing the file system
	13213708	13279244	13344780	13410316	RAM is full
13213709	13279245	13344781	13410317	Access authorisation denied	
13213724	13279260	13344796	13410332	No free memory on the memory module	

Related device commands

▶ [Activate parameter set 1 ... 4](#) (📄 88)

4 Drive interface

4.2 Device commands

4.2.37 Activate parameter set 1 ... 4

In addition to the start parameters, up to four further parameter sets can be stored in the memory module for each application. Like this you can for instance define different controller settings for an application, which are then simply activated via device command, if required.


The following device commands are used to archive the current parameter settings of the controller for the active application in the memory module as parameter set 1 ... 4:

C00002 = "301: Archive parameter set 1"

C00002 = "302: Archive parameter set 2"

C00002 = "303: Archive parameter set 3"

C00002 = "304: Archive parameter set 4"






[4-21] Example: "Archive parameter set 1" function

- Previously archived parameter settings will be overwritten with the current parameter settings!

4 Drive interface

4.2 Device commands

Possible status displays for these device commands

Status (C00003)	for command				Meaning
	301	302	303	304	
	19760386	19825922	19891458	19956994	Device command in process
	19726336	19791872	19857408	19922944	Device command executed successfully
	19726337	19791873	19857409	19922945	General error
	19760132	19825668	19891204	19956740	File could not be opened.
	19760157	19825693	19891229	19956765	Fault while reading out of a file.
	19760158	19825694	19891230	19956766	Fault while writing into a file.
	19760160	19825696	19891232	19956768	Unexpected end of file.
	19767297	19832833	19898369	19963905	Access to file has been denied since the file is already accessed from another position
	19767301	19832837	19898373	19963909	I/O fault when accessing the file system
	19767308	19832844	19898380	19963916	RAM is full
	19767309	19832845	19898381	19963917	Access authorisation denied
19767324	19832860	19898396	19963932	No free memory on the memory module	

Related device commands

▶ [Activate parameter set 1 ... 4](#) (86)

4.2.38 Load cam data

This function extension is available from software version V3.0!


The [C00002](#) = "501: Load cam data" device command serves to reload cam data from the memory module into the controller.



Note!

If you transfer the parameter set or the application from »Engineer« to the controller, the cam data are also transferred automatically to the controller.

- The new/altered cam data are accepted in the controller according to the online change mode set.
- Thus, normally this device command does not need to be executed manually.



[4-22] "Load cam data" function

- Only possible when the application has stopped and the controller is inhibited.
- If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first.






Tip!

Detailed information on the online change mode and the access protection can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". ([📖 557](#))

Procedure

1. The cam data are completely loaded from the memory module into the main memory of the controller.
2. The present cam data in the application unit are converted to the internal unit [increments] and are reorganised.
3. The processed cam data are stored in a separate main memory that can be accessed by the cam application.

Possible status displays for this device command

Status (C00003)	Meaning
	32867586 Device command in process
	32833536 Device command executed successfully
	32833537 General error
	32875521 No cam data available on the memory module
	32875523 Loading of the cam data failed
	32875525 Checksum error
	32875542 Wrong password entered
	32875545 The cam functionality is deactivated


Related device commands

- ▶ [Save cam data](#) (📖 92)
- ▶ [Calculate cam data](#) (📖 94)
- ▶ [Calculate cam data checksum](#) (📖 95)

4.2.39 Save cam data

This function extension is available from software version V3.0!

The [C00002](#) = "502: Save cam data" device command serves to save the cam data available in the main memory of the controller with mains failure protection in the memory module.



[4-23] "Save cam data" function

- This function is executed in the background and is also possible when the controller is enabled and the application is running.
 - However, this function is only executed if valid cam data are available.
 - The cam data can also be saved if previously no cam data have been available on the memory module.
- While the function is executed, no online change and no change of the cam data via parameters can be carried out.

For software versions lower than V4.0 the following applies:

- If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first.

The following applies from software version V4.0:

- For saving the cam data, you do not need to enter a possibly existing user password ([C02900](#)).






Tip!

Detailed information on the access protection can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". ([557](#))

4 Drive interface

4.2 Device commands

Possible status displays for this device command

Status (C00003)	Meaning
 32933122	Device command in process
 32899072	Device command executed successfully
	32899073 General error
	32941057 No cam data to be saved are available in the RAM of the controller
	32941060 Saving of the cam data failed
	32941078 Wrong password entered
	32941081 The cam functionality is deactivated

Related device commands

- ▶ [Load cam data](#) (📖 90)
- ▶ [Calculate cam data](#) (📖 94)
- ▶ [Calculate cam data checksum](#) (📖 95)

4.2.40 Calculate cam data

This function extension is available from software version V3.0!

The [C00002](#) = "503: Calculate cam data" device command converts the cam data stored in the main memory of the controller to the internal format and makes them available to the application. This, for instance, is necessary if one or more machine parameters affecting the internal scaling of cam data have been changed.




- The status signal *bNewDataAvailable* of the basic drive function "[Cam data management](#)" ([LS_CamInterface](#) system block) is set to TRUE and the cam data are accepted automatically or manually depending on the online change mode set. After successful data acceptance, the status signal *bNewDataAvailable* is automatically reset to FALSE.
- The user password does not have to be entered in [C02900](#).
- While the function is executed, no online change and no change of the cam data via parameters can be carried out.
- This function is executed in the background and can also be activated when the controller is enabled and the application is running.



Tip!

Detailed information on the cam functionality can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". ([📖 557](#))

Possible status displays for this device command

Status (C00003)	Meaning
 32998658	Device command in process
 32964608	Device command executed successfully
	32964609 General error
	33006617 The cam functionality is deactivated

Related device commands

- ▶ [Load cam data](#) ([📖 90](#))
- ▶ [Save cam data](#) ([📖 92](#))
- ▶ [Calculate cam data checksum](#) ([📖 95](#))

4.2.41 Calculate cam data checksum

This function extension is available from software version V3.0!

The [C00002](#) = "504: Calculate cam data checksum" device command is used to recalculate the checksum of the cam data available in the main memory of the controller. This is required if the cam data in the main memory of the controller have been changed via parameters. Afterwards the cam data can be converted to the internal format using the "503: Calculate cam data" device command, or they can be saved with mains failure protection in the memory module using the "502: Save cam data" device command.




- The user password does not have to be entered in [C02900](#).
- This function is executed in the background and can also be activated when the controller is enabled and the application is running.



Tip!

Detailed information on the cam functionality can be found in the chapter "Basic drive functions", subchapter "[Cam data management](#)". ([📖 557](#))

Possible status displays for this device command

Status (C00003)	Meaning
 33064194	Device command in process
 33030144	Device command executed successfully
	33030145 General error
	33072153 The cam functionality is deactivated

Related device commands

- ▶ [Load cam data](#) ([📖 90](#))
- ▶ [Save cam data](#) ([📖 92](#))
- ▶ [Calculate cam data](#) ([📖 94](#))

4.2.42 Format file system

The [C00002](#) = "1030: Format file system" device command is used to format the file system in the memory module.






Note!

By means of this device command all folders and files in the file system of the memory module are irrevocably deleted!

The application has to be downloaded again with »Engineer«.

Possible status displays for this device command

Status (C00003)	Meaning
 67536130	Device command in process
 67502080	Device command executed successfully
 67502081	General error

Related device commands

- ▶ [Restore file system](#) ([📖 97](#))

4.2.43 Restore file system

The [C00002](#) = "1040: Restore file system" device command is used to execute a low level formatting of the file system in the memory module.



Note!

By means of this device command all folders and files in the file system of the memory module and all pieces of internal information for the management of the file system are irrevocably deleted!

This device command has no status display in [C00003](#), i.e. the display remains unchanged showing the previous device command status.



Stop!

The low level formatting of the file system by the user is only intended for the exceptional case when the standard formatting of the file system via the [C00002](#) = "1030: Format file system" device command is no longer possible, e.g. due to damaged internal management information.

Related device commands

▶ [Format file system](#) (📖 96)

4.2.44 Prepare firmware update






Note!

For Lenze service only!

The [C00002](#) = "10000: Prepare firmware update" device command is used to set the controller to the firmware update mode to update the firmware, if required, using the corresponding software.

- Only possible when the application has stopped and the controller is inhibited.

Possible status displays for this device command

Status (C00003)	Meaning
 655394050	Device command in process
 655360000	Device command executed successfully
 655360001	General error

4 Drive interface



4.2 Device commands

4.2.45 Restart controller

The [C00002](#) = "11000: Restart controller" device command is used to restart the controller via parameter setting.

- Only possible when the application has stopped and the controller is inhibited.

Possible status displays for this device command

Status (C00003)	Meaning
 720930050	Device command in process
 720896001	General error




Note!

Due to the restart at the successful execution of the device command, this status is no longer displayed in [C00003](#).

If this device command is used, the message "Undervoltage in the DC bus (0x007b000f)" may appear in the logbook.

4.3 Device states

The state control of the drive is controlled internally via a state machine which can adopt the following "device states":



[4-24] Device state machine



Note!

The device states of the controller must not be confused with the function states of the [Basic drive functions](#). (□ 377)

- In the device state "Operation" the [Basic drive functions](#) define the motion control of the drive.

Display parameters for diagnostic purposes

- In [C00183](#) the current device state is shown.
- In [C00150](#) (status word 1) the current device state is shown in a bit coded manner via bits 8 ... 11:

Bit 11	Bit 10	Bit 9	Bit 8	Meaning
0	0	0	0	"Initialisation active" state
0	0	0	1	"Device is ready to switch on" state
0	0	1	0	-
0	0	1	1	"Device is switched on" state
0	1	0	0	-
0	1	0	1	-
0	1	1	0	"Operation" state
0	1	1	1	"Trouble active" state
1	0	0	0	-
1	0	0	1	-
1	0	1	0	"Quick stop by trouble active" state
1	0	1	1	"Safe torque off active" state Observe LED on the safety module!
1	1	0	0	"Fault active" state
1	1	0	1	-
1	1	1	0	-
1	1	1	1	-
x	x	x	x	Displayed message " Warning active " or " Warning locked active " The displayed message can occur at the same time as the device states "Device is ready to switch on", "Device is switched on" and "Operation", if a monitoring component responds for which the error response "Warning" has been parameterised.

- [C02530](#) displays the active function state.

LED status display

The control of the two LEDs "DRIVE READY" and "DRIVE ERROR" in the middle of the controller's front panel depends on the device state. ▶ [LED status displays for the device state](#) (□ 609)

4 Drive interface

4.3 Device states

Influence of the status signals of the SB LS_DriveInterface by the device state

Device status	Status signals (Outputs of the SB LS_DriveInterface)						
	DI_bReady	DI_bFail Active	DI_bImp Active	DI_bCInh Active	DI_bWarning Active	DI_bReady ToSwitchOn	DI_bOperation Enabled
Initialisation active	FALSE	FALSE	TRUE	TRUE	FALSE	FALSE	FALSE
Safe torque off active	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
Device is ready to switch on	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	TRUE	FALSE
Device is switched on	TRUE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
Operation	TRUE	FALSE	FALSE	FALSE	TRUE/FALSE	FALSE	TRUE
Warning active	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE	TRUE/FALSE	TRUE/FALSE
Warning locked active	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE/FALSE	TRUE	TRUE/FALSE	TRUE/FALSE
Quick stop by trouble active	FALSE	TRUE	FALSE	FALSE	TRUE/FALSE	FALSE	FALSE
Trouble active	FALSE	FALSE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
Fault active	FALSE	TRUE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE
System fault active	FALSE	TRUE	TRUE	TRUE	TRUE/FALSE	FALSE	FALSE

▶ [Internal interfaces | "LS_DriveInterface" system block \(113\)](#)


4.3.1 "Initialisation active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
OFF	OFF	10: Initialisation active

This is the status of the controller directly after switching on the supply voltage.

- In this device state the operating system is initialised.
- The monitoring functions are not active yet.
- Communication is not possible yet.
- The controller cannot be parameterised yet and no device commands can be carried out yet.
- When the device initialisation is completed, the device state is automatically changed to "Safe torque off active".

4.3.2 "Safe torque off active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
	OFF	101: Safe torque off active

This device state becomes active if the controller receives the "Safe torque off" request by the safety module.


- "Drive is torqueless" (0x00750003) is entered in the logbook.
- If no corresponding request by the safety module is available, a change to the subsequent state "Device is ready to switch on" is effected.



Note!

The "Safe torque off active" status is also passed through after an error has been acknowledged (see illustration [\[4-24\]](#)).

4.3.3 "Device is ready to switch on" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
	OFF	"Device is ready to switch on"

This is the device state of the controller directly after the initialisation has been completed and where no DC-bus voltage is applied yet.

- The bus systems are running and the terminals and encoders are evaluated.
- The monitoring functions are active.
- The controller can be parameterised and device commands can be executed to a limited extent.
- The functions of the user task can be used.
 - Precondition: The application has started (status display in [C02108](#)).
- The basic drive functions cannot be used yet.



Note!

The "Device is ready to switch on" status is not only activated after mains connection but also after reset of "Trouble", "Fault", or "Safe torque off active".

- In order to change from the "Device is ready to switch on" to the "Device is switched on" status when [C00142](#) = "0: inhibited", at least one of the controller inhibit sources must be active.
- When [C00142](#) = "1: Enabled", the "Device is ready to switch on" status directly changes to the "Device is switched on" status.



Danger!

If automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or request for "Safe torque off active" has been eliminated!

▶ [Automatic restart after mains connection/trouble...](#) (📖 107)

4.3.4 "Device is switched on" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
	OFF	90: Drive is switched on

The drive is in this device status if the DC bus voltage is applied and the controller is still inhibited by the user (controller inhibit).

- The bus systems are running and the terminals and encoders are evaluated.
- The monitoring functions are active.
- The controller can be parameterised and device commands can be executed to a limited extent.
- The functions of the user task can be used.
 - Precondition: The application has started (status display in [C02108](#)).
- The basic drive functions cannot be used yet.
- If the controller is enabled, the motor builds up a torque.

4.3.5 "Operation" state



LED DRIVE READY	LED DRIVE ERROR	Display in C00183
	OFF	0: Operation

In this device state the motor follows its setpoint according to the basic drive function selected.

4 Drive interface



4.3 Device states

4.3.6 "Warning active"

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
		1: Operation/warning active

This displayed message can occur at the same time as the device states "Device is ready to switch on", "Device is switched on" and "Operation", if a monitoring component responds for which the error response "Warning" has been parameterised.

4.3.7 "Warning locked active"

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
		2: Operation/warning locked active



This displayed message can occur at the same time as the device states "Device is ready to switch on", "Device is switched on" and "Operation", if a monitoring element responds for which the error response "Warning locked" has been parameterised.



Note!

Do not use this error response if a higher-level control unit with the CANopen device profile CiA402 (e.g. 9400 ServoPLC) is used.

4.3.8 "Quick stop by trouble active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
		151: Quick stop by trouble active


This device state becomes active as soon as a monitoring function responds for which the "Quick stop by trouble" error response has been parameterised.

- The drive is decelerated to standstill with torque within the deceleration time parameterised for quick stop independently of the defined setpoint and can be kept there.
- The device status can only be abandoned by acknowledging the error if the error cause is removed.
- It is also possible to skip to the "Device is switched on" state during the error status by setting controller inhibit, as controller inhibit has a higher priority. As long as the error is still available and has not been acknowledged, a change back to the "Quick stop by trouble active" state is effected when the controller is enabled afterwards.

4 Drive interface

4.3 Device states


4.3.9 "Trouble active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
OFF		104: Trouble active

This device state becomes active as soon as a monitoring function responds for which the "Trouble" error response has been parameterised.


- The motor has no torque (is coasting).
- The device state is automatically exited if the error cause is eliminated:
 - "Trouble active" state < 500 ms: Return to the original device state.
 - "Trouble active" state > 500 ms: Return via the device state "Safe torque off active".

4.3.10 "Fault active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
OFF		102: Fault active

This device state becomes active as soon as a monitoring function responds for which the "Fault" error response has been parameterised.

4.3.11 "System fault active" state

LED DRIVE READY	LED DRIVE ERROR	Display in C00183
OFF		20: System fault active

This device status becomes active if a system fault occurs.

- The device state can only be exited by mains switching.

4.4

Automatic restart after mains connection/trouble...

.../Fault/"Safe torque off active"

In [C00142](#), the starting performance of the controller after mains connection and reset of "Trouble", "Fault", or "Safe torque off active" can be parameterised.

**Danger!**


If automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or request for "Safe torque off active" has been eliminated!

**Note!**

From software version V4.0 the automatic restart is inhibited in the Lenze setting! Set the selection "1: Enabled" in [C00142](#) to obtain the former behaviour.

Auto-start option 0: Auto restart inhibited after mains connection


Controller inhibit always has to be set if the controller is to change from the "Ready to switch on" state to the "Switched on" state after mains connection or reset of "Trouble", "Fault", or "Safe torque off active". The following change to the "Operation" state is performed when the controller is enabled:



[4-25] State change when auto-restart is inhibited (C00142 = "0: Inhibited")

Auto-start option 1: Auto restart enabled after mains connection

The following illustration shows the state changes for the auto-start option 1 and their relationship to controller inhibit:



[4-26] State change when auto-restart is enabled (C00142 = "1: Enabled")

4.5 Behaviour after task overflow

Up to software version V5.0 the following applies:

- After a task overflow in the application or user task the "Error" response is effected.

The following applies from software version V5.0:

- In [C02111](#) the error response after a task overflow in the application or user task can be parameterised. The Lenze setting "Error" corresponds to the previous behaviour of the controller with software versions lower than V5.0.



Tip!

For a hoist for instance the "Quick stop by trouble" error response with engagement of the brake can be set, so that the drive is brought to standstill within the shortest time possible.

From »Engineer« version 2.10 onwards, the function block editor can also be used to configure the behaviour of the analog and digital outputs and that of the brake control and the output ports after a task overflow in order to adapt it to the respective application.

▶ [Configure exception handling of the outputs](#) (□ 293)

4.6 Device output power

The parameters described in the following subchapters influence the output power of the controller.

4.6.1 Switching frequency

The controller uses a pulse-width modulation to generate its output voltage. The switching frequency is used to change the control factor of the pulse-width modulation.

Automatic switching frequency reduction

In the Lenze setting, the "variable" switching frequency "8 kHz" has been selected in [C00018](#), which means that the controller automatically reduces the switching frequency depending on the setpoint current.

- Depending on the current amount, it is changed down to an assigned switching frequency.
- The switching thresholds are device-dependent (see 9400 hardware manual, chapter "Rated data").
- If a fixed switching frequency is selected in [C00018](#) instead of a variable one, there is no switching frequency changeover, however, (due to the field frequency range 0...5 Hz) it can only be traversed at a low continuous current and low maximum currents (see 9400 hardware manual, chapter "Rated data").



Note!

If parameterisation is carried out offline or if the memory module is exchanged between different 9400 HighLine device types, always check the setting of the switching frequency in [C00018](#) and adapt it, if required, to prevent a parameter error after the parameter set download or module change!

The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected in [C00018](#)! (See the following table.)

Switching frequency (C00018):	1 kHz	2 kHz	4 kHz	8 kHz	16 kHz	
Maximum output frequency:	125 Hz	250 Hz	500 Hz	1000 Hz	1999 Hz	
Motor - number of pole pairs:	Maximum speed [rpm]					
	1	7500	15000	30000	60000	120000
	2	3750	7500	15000	30000	60000
	3	2500	5000	10000	20000	40000
	4	1875	3750	7500	15000	30000
	5	1500	3000	6000	12000	24000
	6	1250	2500	5000	10000	20000



Tip!

If a load profile and a fixed setting of the switching frequency (e. g. 8 kHz fixed) are given, an I x t disconnection due to a high device utilisation can be avoided by selecting the variable setting for the same switching frequency instead. ▶ [Monitoring of the device utilisation](#)

Reduced switching losses through switching frequency reduction

The advantage of a switching frequency reduction are the reduced switching losses in the controller, which are monitored via an $I \times t$ evaluation.

- A reduced switching frequency enables a greater current-time area at the output than it would be the case with a higher switching frequency. However, depending on the process, you always have to make a compromise between the torque ripple and the output power.

4.6.2 Monitoring of the device utilisation

In [C00064](#) the device utilisation ($I \times t$) is displayed over the last 180 seconds in [%].

- If the value displayed in [C00064](#) exceeds the warning threshold set in [C00123](#), the error message "device utilisation $I \times t > C00123$ " is output and the fault response set in [C00604](#) occurs (default setting: "Warning").
- If the value displayed in [C00064](#) exceeds 100 %, the error message "device utilisation $I \times t > 100 \%$ " is output and the "Fault" error response occurs.
 - The fault can only be reset if the value displayed in [C00064](#) is $< 95 \%$ again.

4.6.3 Operation with increased continuous power

This function extension is available from software version V3.0!

If required, operation with an increased continuous power for the switching frequencies 1 kHz and 2 kHz can be activated in [C01199](#) for controllers from the device size 8S, if the following requirements are met:

- Controller is of E94AxxE1454 ... E94AxxE6954 type (device size 8S ... 10).
- The maximum current ([C00022](#)) is < 150 % of the rated device current.



Stop!

During operation with increased continuous power, the max. permissible ambient temperature is reduced to 40 °C.

The overload current must be reduced. An overload current of 180 % for 10 s is no longer permissible during operation with increased continuous power.



Note!

To activate operation with increased continuous power, controller inhibit must be set in the controller.

The "activated" setting in [C01199](#) is automatically reset to "deactivated" (without error message) if the previously mentioned requirements are not (no longer) met.

- This is also the case if the memory module is plugged into a controller of the small design 8 (device exchange).




Tip!

The permissible output currents and overload factors for operation with increased continuous power for different device types can be found in the Hardware Manual in the "Rated data" chapter.

4.7

Internal interfaces | "LS_DriveInterface" system block

The **LS_DriveInterface** system block provides the internal interfaces to the drive interface in the function block editor.



Inputs

Identifier DIS code data type	Information/possible settings				
DI_bSetClnh C02549/1 BOOL	<p>Set/remove controller inhibit</p> <ul style="list-style-type: none"> The controller can be inhibited by different sources, e.g. via the digital input RFR or using the device command "Inhibit controller". (□ 63) The bit code under C00158 shows the source that inhibited the controller. <table border="1"> <tr> <td>TRUE</td> <td>Set controller inhibit. <ul style="list-style-type: none"> The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset. </td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Remove controller inhibit. <ul style="list-style-type: none"> Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset! </td> </tr> </table>	TRUE	Set controller inhibit. <ul style="list-style-type: none"> The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset. 	TRUE↔FALSE	Remove controller inhibit. <ul style="list-style-type: none"> Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset!
TRUE	Set controller inhibit. <ul style="list-style-type: none"> The power output stages in the controller are inhibited and the speed, current, and position controller of the motor control are reset. 				
TRUE↔FALSE	Remove controller inhibit. <ul style="list-style-type: none"> Please note that the controller will only be enabled if <u>all</u> sources for controller inhibit are reset! 				
DI_bResetError1 C02548/1 BOOL	<p>Reset (acknowledge) error message</p> <ul style="list-style-type: none"> This function resets an active error message if the cause of the error message has been eliminated. The three inputs are linked via a logic OR gate. 				
DI_bResetError2 C02548/2 BOOL					
DI_bResetError3 C02548/3 BOOL					
DI_bSetExternError C02548/4 BOOL	<p>Activation of "External error" error message</p> <p>▶ Monitoring of external events (□ 117)</p> <table border="1"> <tr> <td>TRUE</td> <td>Activate error message with the response selected in C00581.</td> </tr> </table>	TRUE	Activate error message with the response selected in C00581 .		
TRUE	Activate error message with the response selected in C00581 .				
DI_bSwitchOn C02549/4 BOOL	<p>Deactivate switch-on inhibit</p> <ul style="list-style-type: none"> If the automatic restart is inhibited (C00142 = "0"), the state machine remains in the "Device is ready to switch on" state after mains switching. <ul style="list-style-type: none"> ▶ "Device is ready to switch on" state (□ 103) <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".</td> </tr> </table>	FALSE↔TRUE	The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".		
FALSE↔TRUE	The switch-on inhibit is deactivated and the controller changes to the device state "Device is switched on".				

Outputs

Identifier DIS code data type	Value/meaning
DI_dnState C02547 DINT	Status (bit coded)
	Status signals of the currently enabled basic function (if available):
	Bit 0 -
	Bit 1 Basic function is active (signal <i>bActive</i>).
	Bit 2 Basic function is completed (signal <i>bDone</i>).
	Bit 3 Acceleration/deceleration phase is active (signal <i>bAccDec</i>).
	Bit 4 -
	Bit 5 CCW rotation is active (signal <i>bCcw</i>).
	Bit 6 -
	Bit 7 Reference known.
	Bit 8 Brake is open.
	Bit 9 Waiting for clutch condition.
	Bit 10 Zero crossing detected or position = "0".
	Bit 11 -
	Bit 12 -
	Bit 13 -
	Bit 14 -
	Bit 15 Fault in active basic function (group signal).
	Status signals of the internal state machine for the basic functions:
	Bit 16 Torque follower active.
	Bit 17 Speed follower active.
	Bit 18 Position follower active.
	Bit 19 Setpoint follower is active (group signal for bit 16 ...18).
	Bit 20 Positioning active.
	Bit 21 Homing active.
	Bit 22 Manual jog active.
	Bit 23 Brake test is active.
	Bit 24 Drive at standstill.
	Bit 25 Drive is stopped.
	Bit 26 Quick stop active.
	Bit 27 -
	Bit 28 Controller is not ready.
Bit 29 Initialisation	
Bit 30 State "Fault active" (signal <i>DI_bFailActive</i>).	
Bit 31 State machine is not ready to receive setpoints. (Group signal for bit 28 ... 30)	
DI_bReady C02549/6 BOOL	Status signal "controller is ready for operation" TRUE The controller is ready for operation.
DI_bFailActive C02549/7 BOOL	Status signal "Error active - acknowledgement required" TRUE Monitoring with the "Fault" or "Quick stop by trouble" error response has responded and the controller is in the device state "Fault active" or "Quick stop by trouble active". For exiting the device state the fault has to be acknowledged, e. g. via the input <i>DI_bErrorReset1...3</i> .

Identifier DIS code data type	Value/meaning
DI_bImpActive C02549/8 BOOL	Status signal "Pulse inhibit set" TRUE The power output stages are switched to high impedance.
DI_bClnhActive C02549/9 BOOL	Status signal "Controller inhibit active" TRUE The controller inhibit is active.
DI_bWarningActive C02549/10 BOOL	Status signal "Warning active" TRUE There is a warning in the drive controller.
DI_bUVDetected C02549/11 BOOL	Status signal "Undervoltage detected" • The threshold for this monitoring function depends on the setting under C00173 . TRUE Undervoltage detected in DC bus.
DI_bOVDetected C02549/12 BOOL	Status signal "Overvoltage detected" • The threshold for this monitoring function depends on the setting under C00173 . TRUE Overvoltage detected in DC bus.
DI_bMainSupplyOk C02549/13 BOOL	Status signal "Mains voltage is applied" TRUE A voltage is applied to the mains voltage inputs L1, L2 and L3.
DI_bReadyToSwitchOn C02549/14 BOOL	Status signal "Controller ready to switch on" TRUE The controller has completed the initialisation and is in the "Device is ready to switch on" device state.
DI_bOperationEnabled C02549/15 BOOL	Status signal "Operation is enabled" TRUE The controller is in the "Operation" device state and the motor follows its setpoint according to the selected basic drive function or is at standstill due to stop or quick stop.
DI_dwErrorCode DWORD	Error number of the current error message ▶ Error messages of the operating system (□ 620)
DI_AxisData	Data structure, which contains all required machine constants.

4.7.1 Status signals

The following representation shows which status signals of the drive interface are set to TRUE in different typical cases:

Case 1:
Application has been transmitted to the controller.
No mains voltage available (LU fault).
Controller is inhibited (via RFR terminal).

Case 2:
Mains voltage has been connected.

Case 3:
Controller inhibit has been deactivated.

Case 4:
Error active.

Case 5:
Quick stop by trouble is active

Status	Case 1	Case 2	Case 3	Case 4	Case 5	Status signal (output)
Ready for operation	●	●	●	●	●	DI_bReady
Fault active	●	●	●	●	●	DI_bFailActive
Pulse inhibit active	●	●	●	●	●	DI_bImpActive
Controller inhibit active	●	●	●	●	●	DI_bClnhActive
Warning is active	●	●	●	●	●	DI_bWarningActive
Undervoltage detected	●	●	●	●	●	DI_bUVDetected
Overvoltage detected	●	●	●	●	●	DI_bOVDetected
Mains supply is ok	●	●	●	●	●	DI_bMainSupplyOk
Ready to switch on	●	●	●	●	●	DI_bReadyToSwitchOn
Operation enabled	●	●	●	●	●	DI_bOperationEnabled

4.7.2 Monitoring of external events

Use the input *DI_bSetExternError* of the [LS_DriveInterface](#) system block to monitor external events by means of corresponding logic operations and activate the error message "External error" in the controller.

Parameterising a response to an external error

The controller response to the error message "External error" can be selected under [C00581](#).

Activation of "External error" error message

The error message "External error" is activated by setting the input *DI_bSetExternError* to TRUE.

- After this, the error number for the error message "External error" "[0x20750000](#)" (when "Fault" has been selected as response) will be stored in the internal fault memory ([C00168](#)).

Reset error message

The error message "External error" and other active error messages are reset by setting the input *DI_bResetError* to TRUE.

- If the input *DI_bSetExternError* is still set to TRUE, the reset will not be carried out.
- Error messages can only be reset if the cause of the error has been eliminated.

5 Motor interface

This chapter provides you with information on initial commissioning of the motor and the parameterisation of the internal motor control of the controller.



Note!

The motor interface contains all control functions that are not provided by other basic drive functions.


To select application-specific setpoints, the motor interface can be extended by appropriate interfaces using the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)".

The application-specific conditioning of the encoder signals is executed with the basic function "[Encoder evaluation](#)".




How to get to the dialog for setting the motor interface parameters:

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the following button of the *Overview* dialog level:



Parameterisation dialog in the »Engineer«



- The white buttons indicate the configuration of the motor interface inputs. ▶ [Internal interfaces | "LS_MotorInterface" system block \(234\)](#)
 - The configuration is predefined by the technology application selected (in this example "Actuating drive – speed"). If required, this configuration can be changed by clicking the corresponding buttons.
- If you click a button marked with the → symbol, you go one level deeper in the corresponding parameterisation dialog.

5 Motor interface

5.1 General information

5.1 General information

5.1.1 Reading out motor data from the controller

If the Lenze motor connected to the controller has an electronic nameplate (ENP), the motor does not need to be selected in the »Engineer« motor catalogue.

- With the first switch-on of the controller all motor data are automatically read out from the electronic nameplate of the motor and at first are saved temporarily within the controller.
- For a permanent acceptance of the motor data, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- If there is an online connection between »Engineer« and the controller, the motor data can be accepted from the controller to the »Engineer« project.



How to read out the motor data from the controller:

1. Establish an online connection between »Engineer« and controller.
2. Select the **Application parameters** tab and change to the *Overview* → *Motor* → *Motor* dialog level.
3. Click on the **From Drive** button.
 - Then the motor data are read out of the controller and directly written into the corresponding codes of the »Engineer« project.


Display parameters for electronic nameplate (ENP)

Parameters	Info	Lenze setting	
		Value	Unit
C00186	ENP: Identified motor type	-	
C00187	ENP: Identified serial number	-	
C00188	ENP: Status	-	

5.1.2 Selecting a motor from the motor catalogue in the »Engineer«

If the Lenze motor does not have an electronic nameplate (ENP) or if a motor of a third-party manufacturer is used, select the motor in »Engineer« via the motor catalogue and transfer the motor data to the controller.

- If a checkmark is set in the **Motor** control field in the "Other components" dialog when the controller is inserted into the project, the motor for the controller can be selected from the motor catalogue in another dialog:



- Alternatively, the motor can be inserted into the project at a later time via the **Insert a component** command.



Tip!

If a third party manufacturer's motor is used, select a Lenze motor from the motor catalogue first which is similar in terms of current, voltage and speed rating. Adapt the preselected motor data exactly to the real motor afterwards.


- [Displaying/editing motor data in »Engineer«](#) (122)

5.1.3 Displaying/editing motor data in »Engineer«

The term "Motor data" combines all parameters that only depend on the motor. They solely characterise the electrical behaviour of the machine.

- The motor data do not depend on the application in which the controller and motor are used.
- The motor data are, if available in »Engineer« via electronic nameplate or motor catalogue, accepted by the controller without confirmation prompt.

In »Engineer« the motor data are shown on the **Application parameters** tab in the dialog level *Overview*→*Motor*→*Motor*:



- If you use a motor of a third-party manufacturer, the displayed motor data can be adapted exactly to the existing motor by clicking the **From Project** button and then selecting the "Own motor settings" entry in the **Motor selection** dialog box.
- Via the **From Motor Catalogue** button, the motor catalogue can be opened to select another motor. ▶ [Selecting a motor from the motor catalogue in the »Engineer«](#) (121)
- If an online connection has been established, the motor data set in the controller can be accepted in »Engineer« via the button **From Drive**. ▶ [Reading out motor data from the controller](#) (120)

5 Motor interface

5.1 General information

Overview of motor data

Parameters	Info	Lenze setting *	
		Value	Unit
C00052	Motor voltage	-	V
C00054	Motor current	-	A
C00057/1	Maximum torque	-	Nm
C00057/2	Motor reference torque	-	Nm
C00059	Motor - number of pole pairs	-	
C00060	Motor pole angle	-	
C00079	Motor magnetising inductance	-	mH
C00081	Rated motor power		kW
C00082	Motor rotor resistance	-	Ohm
C00083	Motor rotor time constant	-	ms
C00084	Motor stator resistance		Ohm
C00085	Motor stator leakage inductance		mH
C00087	Rated motor speed		rpm
C00088	Rated motor current		A
C00089	Rated motor frequency		Hz
C00090	Rated motor voltage		V
C00091	Motor cosine phi		
C00092	Motor magnetising current	-	A
C00128/1	Therm. time constant coil		min
C00128/2	Therm. time constant plates		min
C00273/1	Motor moment of inertia		kg cm ²
C01190	Motor thermal sensor		
C01191/1	Spec. characteristic: temperature		°C
C01191/2	Spec. characteristic: temperature		°C
C01192/1	Spec. characteristic: resistance		Ohm
C01192/2	Spec. characteristic: resistance		Ohm

Greyed out = display parameter

* depending on the selected motor type



Note!

If the motor has been selected via the »Engineer« motor catalogue, or if the motor data have been adapted offline in »Engineer«, all motor data have to be transferred to the controller afterwards when an online connection has been established and have to be saved in the memory module with mains failure protection (device command [C00002](#) = "11: Save start parameters").

5 Motor interface

5.2 Select motor control

5.2 Select motor control


In [C00006](#) the motor control is selected; the default is the servo control for synchronous motors.

Function extension from software version V3.0:

From software version V3.0, alternatively to the servo control also the V/f control and the sensorless vector control are provided as control types in [C00006](#):

Open/closed loop control	Detailed information
1 SC: Servo control for synchronous motor	▶ Servo control (SC) (📖 145)
2 SC: Servo control for asynchronous motor	
4 SLVC: sensorless vector control	▶ Sensorless vector control (SLVC) (📖 166)
6 VFCplus: V/f control open loop	▶ V/f control (VFCplus) (📖 184)
7 VFCplus: V/f control closed loop	▶ V/f control (VFCplus) (📖 200)

- The V/f control is the classic operating mode for standard applications.
- Compared to the V/f control, improved drive characteristics can be achieved with sensorless vector control by:
 - a higher torque across the entire speed range
 - a higher speed accuracy and a higher concentricity factor
 - Higher efficiency



[5-1] Comparison of V/f control and sensorless vector control



Note!

Sensorless vector control (SLVC) is only approved for powers up to 55 kW and horizontal applications (no hoists or lifting equipment)!

For the V/f control and sensorless vector control the following table helps with the selection of the correct control type:

	Selection of the motor control in C00006			
	Motor cable shielded ≤ 50 m unshielded ≤ 100 m		Motor cable shielded > 50 m unshielded > 100 m	
	recommended	Alternatively	recommended	Alternatively
Single drives				
With motor filter	6 / 7	-	6 / 7	-
With constant load	4	6 / 7	6 / 7	-
With extremely alternating loads	4	6 / 7	6 / 7	-
With high starting duty	4	6 / 7	6 / 7	-
Positioning and infeed drives	4	6 / 7	6 / 7	-
Winders/unwinders dancer	6 / 7	-	6 / 7	-
Pump and fan drives *	6 / 7	-	6 / 7	-
Three-phase reluctance motors	6 / 7	-	6 / 7	-
Three-phase sliding rotor motors	6 / 7	-	6 / 7	-
Three-phase AC motors with firmly assigned voltage/frequency characteristic	6 / 7	-	6 / 7	-
Vertical drive/hoist (up to 55 kW)	6 / 7 (with VCC**)	-	6 / 7 (with VCC**)	-
* For this application, we recommend a square-law voltage characteristic (C00950 = "1")				
** VCC = voltage vector control				
Group drives				
Depending on the resulting motor cable length:				
$I_{res} = \sqrt{i} \cdot (I_1 + I_2 + \dots + I_i)$				
Identical motors and loads	4	6 / 7	6 / 7	-
Different motors and/or alternating loads	6 / 7	-	6 / 7	-



Note!

For operation with motor encoder, we recommend to use the servo control!

For operation with motor filter, always use the V/f control!

5.3 Adjusting motor and controller to each other

This "initial commissioning" of the motor is required if no motor data suitable for the application is available yet in the memory module of the controller and in the »Engineer« project .

- The following step-by-step instructions can be used as a "check list" to correctly adjust the motor and controller to each other.
- Detailed information on the individual steps can be found in the following subchapters.

Worksteps		Motor control*		
		SC	SLVC	VFC plus
1	Accepting/adapting plant parameters. (☞ 127)	●	●	●
2.	Parameterising motor encoder. (☞ 129) • Only required for the control types with speed feedback (servo control and V/f control).	●		(●)
3	Pole position identification. (☞ 131) • Only required: • For servo control with synchronous motor of a third-party manufacturer. • For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole pair resolvers). • After changes of the motor feedback system, e.g. encoder exchange.	(●)		
4	Optimising the switching performance of the inverter. (☞ 138) • Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer! • Always required for sensorless vector control and open loop V/f control! • An optimum drive performance can only be achieved with the sensorless operating modes if the voltage errors in the inverter are compensated as exactly as possible.	(●)	●	●
5	Determining the motor parameters. (☞ 141) • Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer! • Always required for sensorless vector control! • An optimum drive performance can only be achieved with the sensorless vector control if the motor parameters correspond to the real motor as exactly as possible.	(●)	●	

* SC = servo control SLVC = sensorless vector control VFCplus = V/f control

5.3.1 Accepting/adapting plant parameters

The "plant parameters" summarise all parameters which result from the combination of motor and load. These characterise the transfer behaviour of the entire controlled system including the required monitoring modes.

- The plant parameters depend on the application in which the controller and motor are used.
- When a Lenze motor is selected in the »Engineer«, plant parameters are suggested for this motor for a load-free operation.

Overview of plant parameters

Parameters	Info	Lenze setting		Motor control*		
		Value	Unit	SC	SLVC	VFC plus
C00011	Reference speed motor	3000	rpm	●	●	●
C00022	Maximum current	0.00	A	●	●	●
C00070	Speed controller gain	0.500	Nm/rpm	●	●	● ¹
C00071	Speed controller reset time	24.0	ms	●	●	● ¹
C00072	Speed controller rate time	0.00	ms	●		
C00497	Speed act. val. time const.	2.0	ms	●	●	●
C00596	Threshold max. speed reached	6500	rpm	●	●	●

* SC = servo control SLVC = sensorless vector control VFCplus = V/f control open loop ¹ Only for V/f control closed loop



Note!

If plant data have been adapted offline in »Engineer«, all plant data have to be transferred to the control afterwards when an online connection has been established and have to be saved in the memory module with mains failure protection (device command [C00002](#) = "11: Save start parameters").

Reference speed motor

In [C00011](#) the reference speed of the motor must be set.

**Note!**

From the perspective of the application it has to be ensured that a maximum of 100 % of the reference speed set in [C00011](#) is requested as speed setpoint.

When using MCS motors, please observe the following:

The controller with software version V01.xx does not support a field weakening control for synchronous motors, so that for this version the operation of MCS motors at the voltage limit may present an undefined behaviour.

Therefore it should be detected whether the motor used exceeds the voltage limit within the desired operating range up to the maximum current/reference speed. If so, the reference speed must be reduced to a value permissible with regard to voltage.

Maximum current

In [C00022](#) the required maximum current must be set.

- To avoid that the motor starts unintentionally without adjusting the plant data, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).

Ultimate motor current I_{ULT}

[C00620](#) serves to check the set ultimate motor current I_{ULT} .

**Note!**

When you select a Lenze motor from the catalogue and transfer the plant parameters of the motor to the controller, the setting in [C00620](#) is automatically adjusted to the selected motor.

The ultimate motor current I_{ULT} is a limit value to protect the motor from destruction or influence of the rated data.

- This limit value must not be travelled cyclically in the drive process.
- The maximum current parameterisable in [C00022](#) should have a sufficient distance from this limit value.
- If the instantaneous value of the motor current exceeds the limit value set in [C00620](#) the response set in [C00619](#) is executed for motor protection (Lenze setting: Fault).

Maximum motor speed

Adapt the maximum motor speed in [C00596](#) and select the error response required when this speed limit has been reached in [C00607](#).

5.3.2 Parameterising motor encoder

**Note!**

Only required for servo control and closed loop V/f control!

**Tip!**

Detailed information on the encoder evaluation and on the use of a separate position encoder can be found in the following main chapter "[Encoder evaluation](#)". (📖 239)

- The motor encoder can be parameterised on the **Application parameters** tab of »Engineer« in the *Overview* → *Motor* → *Encoder* dialog level.
- The following table shows the required settings for different encoder types:

Encoder type:	Resolver Tamagawa	CDD50	ITD21	ITD22	SEK... SEL...	SKS... SKM...	SCS70 SCM70	SRS50 SRM50	ECN1313 EQN1325	EQI1329
Motor type:	MCS MCA MDxKS MDXMA	MCA	MDFQA LMR	MDFQA LMR			MDxKS	MCS MCA	MCS MCA	MCS MCA
C00495 Motor encoder selection	0 Resolver	1 Encoder								
C00080 Number of resolver pole pairs	1	-	-	-	-	-	-	-	-	-
C00422 Encoder type	-	0 Incremental encoder (TTL signal)	1 Sin/cos encoder	2 Absolute value encoder (Hiperface)				3 Absolute value encoder (EnDat)		
C00420 Number of encoder increments	-	2048		16	128	512	1024	2048	32	
C00421 Encoder voltage	-	5 V			8 V				5 V	

**Danger!**

If the encoder/resolver is used as motor encoder:
In case of error, safe operation of the motor is no longer guaranteed!

When servo control is used:

- For the (open circuit) monitoring of the encoder/resolver for reasons of safety always the "Fault" response (Lenze setting) should be set!

When V/f control is used:

- For this type of motor control, the drive basically is to coast down after an encoder failure and may not stop, therefore the "Warning" response is to be set for the (open circuit) monitoring in this case!

Short overview: Parameters for setting the response to (open circuit) monitoring

Parameters	Info	Lenze setting
C00580	Resp. to encoder open circuit	Error
C00586	Resp. to resolver open circuit	Error
C00601	Resp. to encoder comm. error	Error

5.3.3 Pole position identification



Note!

Only required:

- For servo control with synchronous motor of a third-party manufacturer.
- For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole pair resolvers).
- After changes of the motor feedback system, e.g. encoder exchange.

For the control of permanent-magnet synchronous machines, the pole position – the angle between the motor phase U and the field axis of the rotor – must be known.

- For Lenze motors with absolute value encoder or resolver, the pole position is already set correctly in [C00058/1...3](#).
- When incremental encoders (TTL or sin/cos encoders) are used, a pole position identification (PPI) is always required after mains switching, even with Lenze motors.
- The controller can also evaluate multi-pole-pair resolvers.
 - When the number of motor pole pairs is an integer multiple of the number of pole pairs of the resolver, a pole position identification must only be executed once.
 - When the number of motor pole pairs is no integer multiple of the number of pole pairs of the resolver, a pole position identification must be executed after every mains switching.
- The device commands "Identify pole position (360°)" and "Identify pole position (min. motion)" serve to determine the pole position for the motor encoder currently activated in [C00495](#) (see the following instructions).



Danger!

The machine must not be braked or blocked during the pole position identification! For this reason, the pole position identification is not permitted for hanging loads!

During the pole position identification the rotor aligns itself. The motor shaft moves by max. one electrical revolution which causes the corresponding movement of the connected mechanical components!



Stop!

Check the correct parameterisation of the max. motor current monitoring ([C00619](#) and [C00620](#)) before carrying out the pole position identification to prevent the motor from being permanently damaged.

**Note!**

As of software version V4.0:

If the pole position identification is aborted, the response parameterised in [C00640](#) is activated (Lenze setting: "Fault").

- Pay attention to this changed behaviour in the Lenze setting when updating the firmware of existing systems!
- If this behaviour is not wanted, deactivate the monitoring by selecting "0: No response" in [C00640](#).

The pole position identification can be adjusted to the respective machine and the prevailing moments of inertia by means of parameters.

- In the Lenze setting of the parameters, the pole position identification remains the same as in software versions < V4.0.

▶ [Adjustment of the pole position identification](#) (135)

**How to execute the pole position identification:**

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "51: Identify pole position (360°)" or

device command [C00002](#) = "52: Identify pole position (min. motion)".

The procedure starts with controller enable, if

- a synchronous machine is selected,
- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

Note:

By means of controller inhibit, the procedure started can be cancelled anytime, if required, without carrying out a change in [C00058](#).

For detailed information about the corresponding procedure, please see the following sections:

**Tip!**

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).

Procedure for "pole position identification 360°"

If all conditions are met, the motor is energised with a direct current corresponding to the lower of the following two values:

$\sqrt{2} \cdot \text{Rated device current}$ or $\sqrt{2} \cdot \text{Rated motor current}$

- The rotor is aligned through the current flow. This is absolutely necessary for the procedure.
- To ensure that the torque-neutral axis is not accidentally energised and the rotor stops, a 45° current vector is (electrically) generated for a short instant and then (electrically) switched back to 0° (≡ phase U).
 - Then a DC current of the above-mentioned value could be measured in this motor phase.

The next steps of the procedure depend on the feedback system used:

- If an absolute value encoder with Hiperface or EnDat protocol is used, the encoder position is set to zero and the procedure is cancelled.
- If a resolver or an optical encoder without absolute track is used, the difference between the preselected current angle and the mechanical rotor angle is determined. After this, the current vector is (electrically) turned by another 22.5° and the difference between current angle and rotor angle is determined once again.
 - The procedure is repeated 16 times. This corresponds to one electrical revolution. The machine rotates by 360° (mech.)/pole pair number.
 - Take the average value of the 16 measurements to compensate for asymmetries.

Procedure for "pole position identification with minimal movement"

If all conditions are met, the motor current is increased step by step to the smaller of the following two values:

$25 \% \cdot \sqrt{2} \cdot \text{Rated device current}$ or $25 \% \cdot \sqrt{2} \cdot \text{Rated motor current}$

- By the current flow the rotor aligns itself, which, however, is compensated by a position control.
- If the rotor moves electrically by more than 20°, a fault message is output and the value measured is rejected. This may occur in the case of motors with a noticeable detent torque.
- In order to detect a non-permissible blocking of the machine, a positive and negative test angle (± 20°) relative to the current position are defined after the identification. The machine must align itself to these two test angles within a tolerance of 25 %.

**Note!**

In this procedure it is not written back into an optical absolute value encoder and all feedback systems are treated the same way.

Unlike in the "pole position identification 360°" procedure where, when an optical absolute value encoder is used, a "0" is entered into the encoder and into [C00058/2](#), for this procedure nothing needs to be entered into the encoder and the identification result is entered into [C00058/2](#).

After successful completion...

...the controller is inhibited automatically and the pole position determined for the activated feedback system is set in the corresponding subcode of [C00058](#).

- For a permanent acceptance of the identified pole position, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- The next controller inhibit and subsequent controller enable serve to cancel the controller inhibit automatically set by the procedure (e.g. by first executing the device command [C00002](#) = "41: Inhibit controller" and then executing the device command [C00002](#) = "42: Enable controller").

In the event of an error

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without making a change in [C00058](#).

If the machine was braked or blocked during the procedure, this will be recognised at the end of the measurement and no change is made in [C00058](#).

As of software version V4.0, the response parameterised in [C00640](#) (Lenze setting: "Fault") is triggered and the error message "Pole position identification cancelled" is entered in the logbook of the controller if the pole position identification process is aborted.

**Tip!**

From software version V7.0 onwards, the pole position identification is additionally available as a basic function in the form of the [LS_PolePositionIdentification](#) system block.

Basic drive functions: ▶ [Pole position identification](#) (📖 575)

5.3.3.1 Adjustment of the pole position identification

This function extension is available from software version V4.0!

The two procedures for [Pole position identification](#) (PPI) described in the previous sections can be adjusted to the respective machine and the prevailing moments of inertia by means of the parameters described below.

In the Lenze setting of the parameters, the pole position identification remains the same as in software versions < V4.0.



Note!

The two procedures for the pole position identification should give the same results. But, due to e.g. friction, bearing forces and a trapezoidal field pattern, the results may differ. A proportional increase of the current amplitude in [C00641](#) or [C00646](#) can counteract this deviation.

Parameters for the pole position identification 360°

Parameters	Info	Lenze setting	
		Value	Unit
C00641	PLI 360° current amplitude	100	%
C00642	PLI 360° ramp time	100	%
C00643	PLI 360° traversing direction	Clockwise rotating field	
C00644	PolePosId 360° fault tol.	0	°

- The current amplitude can be adjusted proportionally in [C00641](#).
 - For large machines and high mass inertia values or for linear direct drives, the current amplitude usually has to be increased.
 - The Lenze setting "100 %" corresponds to the smaller of the two following values:

$$\sqrt{2} \cdot \text{Rated device current}$$

or

$$\sqrt{2} \cdot \text{Rated motor current}$$



Stop!

If there is no temperature monitoring in the motor and/or the I^2xt motor monitoring and the maximum current monitoring are not parameterised correctly, the motor might be damaged permanently when the current amplitude is set too high (e.g. to the maximum value!

- ▶ [Motor monitoring \(\$I^2xt\$ \)](#) (☰ 218)
- ▶ [Maximum current monitoring](#) (☰ 233)



Note!

If the current amplitude is set to 100 % in [C00641](#) >, the device utilisation (Ixt) monitoring and/or one of the motor monitoring functions may respond and cause the abort of the pole position identification.

- The ramp time can be adjusted proportionally in [C00642](#).
 - For large machines and high mass inertia values, the ramp time usually has to be increased.
 - For small machines, a reduction of the ramp time can speed up the pole position identification process.
- In some situations it may be helpful to reverse the travel direction ([C00643](#)) for the pole position identification (e.g. for linear motor at the end stop).
- The "pole position identification 360°" procedure comprises a plausibility check. If the rotor position determined via the encoder system does not correspond to the controlled output position:
 - the pole position identification procedure is aborted.
 - the response parameterised in [C00640](#) (Lenze setting: "Fault") is activated.
 - the error message "Pole position identification cancelled" is entered into the logbook of the controller.
- The preset fault tolerance for the plausibility check can be changed via [C00644](#).

Parameters for the pole position identification with minimal movement

Parameters	Info	Lenze setting	
		Value	Unit
C00646	PLI min. motion current amplitude	100	%
C00647	PolePosId min.mov. cur.rise rate	100	%
C00648	PolePosId min.mov. gain Vp	0	
C00649	PolePosId min.mov. reset time Tn	62.5	ms
C00650	PLI min. motion max. perm. motion	20	°

- The current amplitude can be adjusted proportionally in [C00646](#).
 - For large machines and high mass inertia values or for linear direct drives, the current amplitude usually has to be increased.
 - The Lenze setting "100 %" corresponds to the smaller of the two following values:

$$25 \% \cdot \sqrt{2} \cdot \text{Rated device current}$$

or

$$25 \% \cdot \sqrt{2} \cdot \text{Rated motor current}$$



Stop!

If there is no temperature monitoring in the motor and/or the I^2xt motor monitoring and the maximum current monitoring are not parameterised correctly, the motor might be damaged permanently when the current amplitude is set too high (e.g. to the maximum value!

- ▶ [Motor monitoring \(\$I^2xt\$ \)](#) (📖 218)
- ▶ [Maximum current monitoring](#) (📖 233)



Note!

If the current amplitude is set to 400 % in [C00646](#) >, the device utilisation (Ixt) monitoring and/or one of the motor monitoring functions may respond and cause the abort of the pole position identification.

- The rate of the current rise for the pole position identification can be adjusted proportionally in [C00647](#). The Lenze setting "100 %" corresponds to the fixed rise rate setting of the software versions < V4.0.
- The P component of the PI controller for the pole position identification can be adjusted in [C00648](#). With the Lenze setting "0", the PI controller continues to work as an I controller (as in the previous software versions).
- The I component of the PI controller for the pole position identification can be adjusted in [C00649](#). Please observe the following notes:
 - The variable *Position.dnActualMotorPos* can be used to monitor the deviation of the position from the start position with the [Oscilloscope](#) function in »Engineer«.
 - In order to be able to compensate a position deviation faster, first the reset time in [C00649](#) should be reduced. If this does not result in the desired behaviour, the proportional gain can be increased in [C00648](#).
 - Ensure that the position control does not get unstable. We therefore recommend to use an I controller.
- The pole position identification comprises a monitoring function for the follow-up control. If a movement greater than the permissible movement set in [C00650](#) is detected by the encoder system:
 - the pole position identification procedure is aborted.
 - the response parameterised in [C00640](#) (Lenze setting: "Fault") is activated.
 - the error message "Pole position identification cancelled" is entered into the logbook of the controller.
- In order to detect a non-permissible blocking of the machine, a positive and negative test angle relative to the current position are defined after the identification. The machine must align itself to these two test angles within a tolerance of 25 %. The size of the test angle corresponds to the max. permissible movement set in [C00650](#).

5.3.4 Optimising the switching performance of the inverter



Note!

Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!

Always required for sensorless vector control and open loop V/f control!

- An optimum drive performance can only be achieved with the sensorless operating modes if the voltage errors in the inverter are compensated as exactly as possible.

An inverter generates a pulse-width-modulated, three-phase voltage system. Due to the design of the inverter, current-dependent and switching frequency-dependent losses inside of the inverter falsify the voltage that is output. As the voltage that is output is not measured, the losses have to be compensated by a suitable feedforward control. This compensation is based on an inverter error characteristic.

Among other things, the inverter error characteristic depends on the length of the motor cable and at least has to be individually determined once for the connected motor by means of the device command "Calculate inv. characteristic". For an automatic determination of the motor parameters, this ensures that the current has a sinusoidal form.



Danger!

This procedure may only be carried out during commissioning, not during operation!

- During the procedure the motor is energised so that:
 - it cannot be excluded that the connected mechanical components may move!
 - the windings heat up.
 If you repeat the procedure, ensure that the motor is not thermally overloaded (particularly if no temperature feedback is used).

For software versions lower than V4.0 the following applies:

- If the automatic brake operation is used, ensure that no basic function is requested or that the application is stopped before this procedure is called. Otherwise the applied holding brake could be released!
- For positioning applications you have to observe that the absolute position and the home position will get lost when this procedure is called. The loss of the home position is not signalled to the application. The following sequence has to be observed for positioning applications: 1.) Execute identification → 2.) Save parameter set → 3.) Restart controller → 4.) Execute homing procedure.



Note!

For devices of the types 6 + 7 the Ixt monitoring may be activated during the inverter error characteristic is determined.

Remedy: Only start identification at a device utilisation ([C00066](#)) of 0 % and/or reduce rated motor current ([C00088](#)) and reset it to the original value after the identification.



How to determine the inverter error characteristic:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "71: Calculate inv. error characteristic".
3. The detection of the inverter error characteristic starts with the [C00002](#) = "42: Enable controller" device command (or, alternatively, with the controller enable via terminal RFR).

Notes:

- By means of controller inhibit, the started procedure can be cancelled anytime, if required. Characteristic values that have already been determined in this case are rejected. Details on the procedure can be seen from the "Procedure" section below.
- After successful termination, the detected characteristic is set in the controller. The inverter error characteristic must only be detected again if the controller, motor, or motor cable has changed e.g. due to an exchange.

The following device commands are used to terminate the successful procedure:

4. Device command [C00002](#) = "11: Save start parameters" for a permanent acceptance of the characteristic.
5. Device command [C00002](#) = "41: Inhibit controller"
6. Device command [C00002](#) = "42: Enable controller"



Tip!

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).

Procedure

The detection of the inverter characteristic is started if

- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

If all conditions are met, the motor is energised with a maximum direct current corresponding to the lower of the following two values:

$\sqrt{2} \cdot \text{Rated device current}$ <p>or</p> $\sqrt{2} \cdot 1.8 \cdot \text{Rated motor current}$	Rated motor current, see C00088
--	---

- Ideally, the first value should be reached, the second value is to ensure that the load on the machine is not too high during this test.

During the procedure, the motor current rises up to the specified maximum value and falls back to "0" to repeat the cycle with a negative current sign.

- The maximum value is reached four times.
- The switching frequency is set to rated switching frequency and after the procedure, it is reset to the original value.
 - If the switching frequency should be changed later during operation, the characteristic will be adapted to the current switching frequency.

In the event of an error

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit and the detected characteristic is not considered.



Tip!

From software version V4.0: If it is not possible to determine the so-called "Inverter error characteristic", or if the results of the determination are incorrect, the device command [C00002](#) = "70: Load Lenze inverter characteristic" can be used to load a characteristic typical for the device. ▶ [Load Lenze INV characteristic \(□ 72\)](#)

5.3.5 Determining the motor parameters



Note!

Only required for servo control if the motor parameters are to be defined by a motor from a third-party manufacturer!

Always required for sensorless vector control!

- An optimum drive performance can only be achieved with the sensorless vector control if the motor parameters correspond to the real motor as exactly as possible.

To control an electrical machine, the motor parameters must be known.

- The motor parameters for Lenze motors are known and are already set accordingly by selecting them from the »Engineer« motor catalogue or reading out the ENP.
- The device command "Determine motor parameters" is used to automatically determine the motor parameters for a third-party motor that are listed in the following table – if they are not known:

Parameters	Info	ASM	SM
C00079	Motor magnetising inductance	<input checked="" type="checkbox"/>	
C00082	Motor rotor resistance	<input checked="" type="checkbox"/>	
C00084	Motor stator resistance	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
C00085	Motor stator leakage inductance	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
C00091	Motor cosine phi	<input checked="" type="checkbox"/>	
C00092	Motor magnetising current	<input checked="" type="checkbox"/>	



Danger!

This procedure may only be carried out during commissioning, not during operation!

- During the procedure the motor is energised so that:
 - it cannot be excluded that the connected mechanical components may move!
 - the windings heat up.
 If you repeat the procedure, ensure that the motor is not thermally overloaded (particularly if no temperature feedback is used).

For software versions lower than V4.0 the following applies:

- If the automatic brake operation is used, ensure that no basic function is requested or that the application is stopped before this procedure is called. Otherwise the applied holding brake could be released!
- For positioning applications you have to observe that the absolute position and the home position will get lost when this procedure is called. The loss of the home position is not signalled to the application. The following sequence has to be observed for positioning applications: 1.) Execute identification → 2.) Save parameter set → 3.) Restart controller → 4.) Execute homing procedure.

Prerequisites

- For the automatic determination of the motor parameters it is required that first the switching performance of the inverter has been optimised successfully, to ensure that the current has a sinusoidal form. ▶ [Optimising the switching performance of the inverter](#) (□ 138)

- The motor parameters listed in the following table are excluded from the automatic determination and must therefore be adapted to the motor used (see motor nameplate before the determination).

Parameters	Info
C00081	Rated motor power
C00084	Motor stator resistance (Default setting is used as starting value for the automatic determination.)
C00087	Rated motor speed
C00088	Rated motor current (The current amount for the procedure is derived from this specification)
C00089	Rated motor frequency
C00090	Rated motor voltage



Note!

For devices of the types 9 + 10 (from 132 kW) the automatic determination of the motor parameters may fail and a corresponding status display is output.

Remedy: Parameterise the motor parameters manually by means of the manufacturer's data sheet.



How to determine the motor parameters:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Execute device command [C00002](#) = "72: Determine motor parameters".

The procedure starts with controller enable, if

- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated under [C00003](#).

Note:

By means of controller inhibit, the started procedure can be cancelled anytime, if required, without altering the codes for the motor parameters.

For detailed information about the procedure, please see the following section "Sequence".

**Tip!**

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the device command activated under [C00002](#) is indicated under [C00003](#).

Procedure

If all conditions are met, the impedance of the controlled system is determined for approx. 30 different frequencies. These values are used to determine the electrical machine parameters by means of a mathematical procedure.

- Since the procedure starts with very low frequencies and always considers several complete periods, the whole process takes approx. 3 minutes.
- During the procedure, the motor is energised with a current, the r.m.s. value of which corresponds to the lower of the following two values:

Rated device current
or
$\frac{1}{2} \cdot \text{Rated motor current}$

After the parameters have been extracted from the impedance, they are checked for consistency with the required rated values. If an inconsistent parameter set is detected, is this an indication of faulty rated values on the nameplate.

**Note!**

During the procedure, the motor should not rotate.

With synchronous machines, this cannot always be ensured. Although the current flow is produced in the torque-neutral axis, asymmetries in the machine lead to a rotation of the rotor.

- In such a case, the measurement would be useless and would have to be repeated.
- As a remedy, we recommend to use a holding brake.

With asynchronous machines, slight rotations might possibly occur. Their influence on the measurements is, however, not worth mentioning.

- In case of uncertainties, the measurement should be repeated several times to check if the results for the stator resistance, the leakage inductance of the stator and the rotor resistance differ widely. This should not be the case.
- The mutual inductance and the $\cos(\varphi)$ values are not that important for the diagnostics, because they are strongly non-linear.

After successful completion...

...controller inhibit is set automatically and the motor data determined are set in the corresponding codes.


- For a permanent acceptance of the settings, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- With the device command [C00002](#) = "42: Enable controller" the controller inhibit set automatically during the procedure can be deactivated again.

In the event of an error

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without changing the codes for the motor parameters.

Display and manual adjustment of motor data

In »Engineer« you can have an equivalent circuit diagram with the motor parameters displayed by clicking on the **Further motor data...** button on the **Application parameters** in the dialog level *Overview*→*Motor*→*Motor*:



- The representation of the equivalent circuit diagram depends on the motor control selected ([C00006](#)).
- The motor stator resistance ([C00084](#)) and motor stator leakage inductance ([C00085](#)) can be altered directly via the input fields in the equivalent circuit diagram.
- The motor magnetising current ([C00092](#)) is displayed as comparison value to the motor current ([C00054](#)).
 - The motor magnetising current must especially be observed in case of a no-load operation, both at standstill and with rated speed.
 - The motor magnetising current is directly calculated from the rated motor current ([C00088](#)) and the motor power factor ([C00091](#)).
- The mutual motor inductance can be indirectly adapted via the parameter Lh adjustment ([C02861](#)) in the range of 50 ... 200 %. The mutual motor inductance evaluated in percent is shown in [C00079](#).
- The motor rotor resistance can be indirectly adapted via the parameter Rr adjustment ([C02860](#)) in the range of 50 ... 200 %. The motor rotor resistance evaluated in percent is shown in [C00082](#).

5 Motor interface

5.4 Servo control (SC)

5.4 Servo control (SC)

In the Lenze setting the servo control for synchronous motors is selected in [C00006](#).

After the motor and controller are optimally adjusted to each other, no more basic settings are required for servo control.



Tip!

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimising the control mode](#)". (📖 146)

From software version V2.0 the parameterisable additional function "[Field weakening for synchronous machines](#)" is provided for the servo control. (📖 209)

5.4.1 Optimising the control mode

The "optimisation steps" given in the following table serve to further optimise the control behaviour of the servo control and adjust it to the concrete application.

- Detailed information on the individual steps can be found in the following subchapters.

Optimisation steps	
1	Optimise current controller. (📖 147) <ul style="list-style-type: none"> • The current controller should always be optimised if a motor of a third-party manufacturer with unknown motor data is used!
	Parameterise selected technology application in »Engineer« and load it into the controller. <ul style="list-style-type: none"> • See description of the corresponding technology application. • During operation (with setpoint selection) further steps can be carried out to optimise the motor control:
2.	Optimising the speed controller. (📖 150) <ul style="list-style-type: none"> • Via running a typical speed profile and recording the ramp response of the speed controller with the oscilloscope.
3	If the speed controller optimisation did not achieve the intended result: Set current setpoint filter (band-stop filter). (📖 153) <ul style="list-style-type: none"> • In order to suppress or damp (mechanical) resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller which are switched off in the default setting but can be parameterised accordingly, if required. Then readjust the speed controller: Optimising the speed controller. (📖 150)
4	Optimising phase controller. (📖 156) <ul style="list-style-type: none"> • Via running a typical speed profile and recording the ramp response of the phase controller with the oscilloscope.
5	Optimising response to setpoint changes. (📖 157) <ul style="list-style-type: none"> • Via running a typical speed profile and recording the inputs and outputs of the speed controller with the oscilloscope.
6	Setting the field weakening for asynchronous machines. (📖 159) <ul style="list-style-type: none"> • By means of traversing a speed profile $0 \leftrightarrow n_{\max}$ and recording the speed, flow, and D-current setpoints/ actual values with the oscilloscope.
7	Save »Engineer« project.



Tip!

To run a typical speed profile for optimising the motor control, you can also use the basic function "manual jog" with suitably adapted manual jog parameters if this basic function is supported by the technology application selected. ▶ [Manual jog](#) (📖 400)

5.4.1.1 Optimise current controller



Note!

The current controller should always be optimised if a motor of a third-party manufacturer with unknown motor data is used!

An optimisation of the current controller is useful, as the two controller parameters gain ([C00075](#)) and reset time ([C00076](#)) depend on the maximum current required and the switching frequency set.

For this purpose, the controller parameters only need to be adapted once at a fixed switching frequency.

We recommend to select a switching frequency

- as low as possible if the controller is to be operated frequently at the maximum current limit.
- of 8 kHz (up to and including model 7) or 4 kHz (from model 8 onwards) if the maximum current limit will not be reached or will only be reached rarely.

The controller parameters are then automatically adapted to the other switching frequencies.

In a test mode you can select current setpoint step-changes and optimise the setting of both control parameters by evaluating the step responses.


- The starting values for gain and reset time can be calculated with the following formula:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$
$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$

**How to optimise the current controller in the test mode:**

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Set a fixed switching frequency using [C00018](#). Observe the above mentioned recommendations.
3. Activate one of the two following optimisation modes for the current controller:
 - [C00398](#) = "3: Current controller optimisation mode":
After controller enable, the motor is supplied with current as long as the controller is enabled.
 - From software version V7.0:
[C00398](#) = "4: Current controller optimisation mode pulse":
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
4. Select the effective value of the current setpoint step change under [C00022](#).
 - The peak value of the measurable motor current will be 1.41 times higher.
5. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in »Engineer«. ([📖 585](#))
 - Variable of the motor control to be recorded:
Current.dnActualDirectCurrent (field-oriented direct-axis current)

6. Evaluate the step response:



7. Change the gain V_p under [C00075](#) and the reset time T_n under [C00076](#).
8. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.
 - In the optimised state the current rise time typically is 0.5 ... 1 ms.
 - If the adjustment results are not satisfactory, the decoupling network can be additionally activated via the setting [C00074](#) = "1". After this, repeat the steps 2 ... 6.
 - In case of MCS, satisfying results may only be achieved with a current-dependent correction of the current controller parameters based on the saturation behaviour of the motor stator leakage inductance. For this purpose, it is required to use a motor with an electronic nameplate (ENP) or to set the saturation characteristic manually. ▶ [Correction of the stator leakage inductance...](#) (📖 204)
9. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").
10. Save parameter set ([C00002](#) = "11: Save start parameters").

5.4.1.2 Optimising the speed controller

The speed controller is designed as PID controller.

Gain setting

The proportional gain V_p is selected under [C00070](#):

1. Select the speed setpoint.
2. Increase C00070 until the drive becomes unstable (observe motor noises).
3. Reduce C00070 until the drive becomes stable again.
4. Reduce C00070 to approx. half the value.

Reset time setting

The reset time T_n is selected under [C00071](#):

1. Reduce C00071 until the drive becomes unstable (observe motor noises).
2. Increase C00071 until the drive is stable again.
3. Increase C00071 to approx. double the value.

Rate time setting

The rate time T_d is selected under [C00072](#):

- Increase C00072 during operation until an optimum control behaviour is reached.

Using the ramp response for setting the speed controller

When operation of the mechanics at the stability limit is not possible, the ramp response can be used to set the speed controller. The proceeding is similar to optimising the current controller.



Stop!


If the controller parameters are preset unfavourably, the control can tend to heavy overshoots up to instability!

- Following and speed errors can adopt very high values.
- If the mechanics are sensitive, the corresponding monitoring functions are to be activated.



How to optimise the speed controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the speed with the [Oscilloscope](#). (☒ 585)
 - Motor control variables to be recorded:
Speed.dnSpeedSetpoint (speed setpoint)
Speed.dnActualMotorSpeed (actual speed value)
2. Evaluate the ramp response:



- Solid line = ramp response (actual speed value)
- Dash line = speed setpoint

3. Change the gain V_p under [C00070](#) and the reset time T_n under [C00071](#).
4. Repeat steps 1 ... 3 until the optimum ramp response is reached.
5. Save parameter set ([C00002](#) = "11").

Setting of actual speed filter

In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible ([C00497](#)). The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay.

If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset in [C00497](#) which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection).

When using EMC-compliant systems or high-quality encoders, you can reduce the preset time constant considerably. For this purpose, the running noise of the motor can be used for setting [C00497](#) at constant speed.

If this is not possible, e.g. due to a too loud environment or because the motor is too far away, the noise of the actual speed value or the setpoint torque value can be used for evaluation by means of the [Oscilloscope](#). Please observe that the speed controller gain V_p ([C00070](#)) is used for the torque setpoint.

Dynamics of the actual value detection

Another element which influences the maximally achievable control dynamics, is the dynamics of the actual value detection itself. In case of optical encoders, the time delay by the actual value detection does not need to be considered. This does not apply to resolvers.

The resolver evaluation of the controller is adapted to the resolver types mounted in Lenze motors and offers a good compromise between the dynamic performance and interference suppression. If the resolver is used as a speed feedback system, the dynamic performance of the resolver evaluation determines, among other things, the maximum speed controller gain by means of which stable operation is possible.

From software version V5.0 onwards, it is possible to increase the dynamics of the resolver evaluation in [C00417](#) in an EMC-compliant system (with low interference) without a quality loss in the speed signal.

▶ [Adaptation of the resolver evaluation dynamics](#) (📖 253)


5 Motor interface

5.4 Servo control (SC)

5.4.1.3 Set current setpoint filter (band-stop filter)

Due to the high dynamic performance or the high limit frequency of the closed current control loop, mechanical natural frequencies can be excited, which can result in resonance and thus cause the speed control loop to become unstable.

In order to suppress or damp these resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller, which need to be parameterised. In the Lenze setting, these filters are switched off:



[5-2] Optional current setpoint filters (filter cascade) in the speed control loop

Overview of parameters for current setpoint filter

Parameters	Info	Lenze setting	
		Value	Unit
C00270/1	Freq. - current setpoint filter 1	200.0	Hz
C00270/2	Freq. - current setpoint filter 2	400.0	Hz
C00271/1	Width current setp. filter 1	20.0	Hz
C00271/2	Width current setp. filter 2	40.0	Hz
C00272/1	Depth current setp. filter 1	0	dB
C00272/2	Depth current setp. filter 2	0	dB

Use of the current setpoint filters depending on the resonant frequency




Stop!

If the filter parameters are set incorrectly, the impaired closed-loop control can respond with too large overshoots and cause the controller to become unstable, e.g. if the filter width is set to a value more than twice as large as the filter frequency.

After setting the filter parameters, the drive behaviour during stop and quick stop (QSP, Fail-QSP) must be checked. If impairments exist,

- the drive that is still running must either be coasted down by activating the controller inhibit or immediately be brought to a standstill via a brake.
- the speed controller must be optimised again afterwards.
- the test procedure must be repeated.



[5-3] Use of the current setpoint filter depending on the resonant frequency

- Resonant frequencies $\geq f_{\text{limit_SPEED}} = 70 \text{ Hz} \dots 110 \text{ Hz}$

This filter is suitable for use with resonant frequencies in the range around or above the limit frequency of the speed controller.

- Resonant frequencies $< f_{\text{limit_SPEED}}$

Please follow the Lenze recommendation and select suitable speed profiles, S-ramp or S-rounding, for avoiding resonances.

Setting of the current setpoint filter

Since the frequency response of the speed controlled system is only rarely known to such an extent that the current setpoint filters can be adjusted to the controlled system in the run-up, the following example describes an experimental procedure for setting the current setpoint filters:



How to set the current setpoint filters:

1. Adjust the current control loop.
 2. Go to [C00071](#) and adapt the reset time of the speed controller to the filter time constant of the speed filter ([C00497](#)) and the equivalent time constant of the current control loop: $C00071 = 16 * (C00497 + 200 \mu s)$
- Note:** The setting of [C00071](#) incorporates the equivalent time constant of the current control loop. The indicated 200 μs are typical in a power range of up to 20 kW. Beyond it, higher time constants may occur.
3. Slowly increase the proportional gain in [C00070](#) until the speed control loop starts to become unstable (acoustic determination or measuring of the motor current).
 4. Measure the oscillation frequency using an oscilloscope (observe current or speed).
 5. Set the measured oscillation frequency in [C00270/1](#) as filter frequency.
 6. Set "50%" of the filter frequency in [C00271/1](#) as filter width.
 - Example: filter frequency = 200 Hz → filter width = 100 Hz.
 7. Set "40 dB" in [C00272/1](#) as filter depth.
 - If the filter depth is set to "0 dB" (default setting), the filter is not active.
 8. Further increase the proportional gain in [C00070](#) until the speed control loop starts to become unstable again.
 - If the oscillation frequency has changed now, readjust the filter frequency by trimming. The use of a second filter is ineffective here.
 - If the oscillation frequency remains the same, readjust the filter depth and/or the filter width by trimming (the first reduces the amplitude, the second lets the phase rotate faster).
 - Repeat step 8 until the desired behaviour or the limit of a sensible speed controller gain has been reached.
 9. Save parameter set ([C00002](#) = "11: Save start parameters").



Note!

Readjust the speed controller after setting the current setpoint filter. ▶ [Optimising the speed controller](#). (□ 150)

5.4.1.4 Optimising phase controller




How to optimise the phase controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the phase controller with the [Oscilloscope](#). ([□ 585](#))
 - Motor control variables to be recorded:
 - Speed.dnSpeedSetpoint* (speed setpoint)
 - Speed.dnActualMotorSpeed* (actual speed value)
 - Speed.dnOutputPosCtrl* (phase controller output)
 - Position.dnEncounteringError* (following error)
2. Adjust the gain V_p of the phase controller under [C00254](#) and repeat oscilloscope recording until the intended following error behaviour is reached and the motor runs sufficiently smoothly during the constant travel phase.
3. Save parameter set ([C00002](#) = "11: Save start parameters").

5.4.1.5 Optimising response to setpoint changes

Setting the load moment of inertia under [C00273/2](#) does not always provide the optimum torque feedforward control. Depending on the application, an adjustment of the setting under [C00273/2](#) may be necessary to optimise the response to position/speed setpoint changes by means of the torque feedforward control.



[5-4] Typical signal characteristics for different settings of the load moment of inertia

Apart from the load moment of inertia, effects can be compensated with [C00273/2](#), which in the closed speed control loop are identified by the speed controller. These for example include the friction torques.

Below you will find a description of a procedure for optimising the feedforward control behaviour starting from the system's moment of inertia.



How to optimise the torque feedforward control:

- Run a typical speed profile and record the inputs and outputs of the speed controller with the [Oscilloscope](#). ([□ 585](#))
 - Motor control variables to be recorded:
 - Speed.dnSpeedSetpoint* (speed setpoint)
 - Speed.dnActualMotorSpeed* (actual speed value)
 - Torque.dnOutputSpeedCtrl* (speed controller output)
 - Torque.dnTotalTorqueAdd* (torque feedforward control)
 - Application variable to be recorded (if available):
 - L_LdMonitFollowError1.dnFollowErrorIn_p* (following error)

It is essential for optimising the response to setpoint changes to monitor the speed controller output (*Torque.dnOutputSpeedCtrl*) and the torque feedforward control (*Torque.dnTotalTorqueAdd*). The effect of the feedforward control can also be observed in the following error.

2. Select the signal source required for the torque setpoint (feedforward control path) under [C00276](#).
3. Estimate the load moment of inertia and set it under [C00273/2](#) with regard to the motor end (i.e. considering the gearbox factors).
4. Repeat the oscilloscope recording (see step 1).

Now the oscillogram should show that part of the required torque is generated by the feedforward control (*Torque.dnTotalTorqueAdd*) and the speed controller output signal (*Torque.dnOutputSpeedCtrl*) should be correspondingly smaller. The resulting following error decreases.

5. Change the setting under [C00273/2](#) and repeat the oscilloscope recording until the intended response to setpoint changes is reached.
 - The optimisation could aim at the speed controller being completely relieved (see signal characteristics in Fig. [5-4](#)).
6. Save parameter set ([C00002](#) = "11: Save start parameters").

5.4.1.6 Setting the field weakening for asynchronous machines

For the following setting instructions it is assumed that the drive has been adjusted in the base speed range (inverter error characteristic, motor parameters, current controller, speed controller, current setpoint filter, angle controller, torque feedforward control) and is running satisfactorily to the rated motor speed.



How to set the field weakening for an asynchronous machine:

1. Set the desired maximum speed (with field weakening) in [C00011](#).
2. Carry out the following basic setting for the controller parameters for third-party motors:
 - Field controller gain ([C00077](#)) = $1 / (2 * \text{C00082} * 500 \mu\text{s})$
 - Field controller reset time ([C00078](#)) = motor rotor time constant ([C00083](#))
 - Field weakening controller gain ([C00577](#)) = 0 [Vs/V]
 - Field weakening controller reset time ([C00578](#))
 = $4 \text{ ms} / (0.3 \dots 1.0 * 60) * \text{C00059} * 2\pi * \text{C00011} [\text{rpm}] * \text{s}$
 (with factor 0.3 ... 1.0 for motor with rated power of 400 kW ... 0.4 kW)

Optimising the static behaviour in the field weakening range:

3. By means of speed ramp (acceleration time several seconds), slowly accelerate to the field weakening range up to maximum speed ([C00011](#)), and decelerate to speed 0 again and record the signal characteristic using the [Oscilloscope](#) (see example oscillogram [\[5-5\]](#)).
 - From the entry into the field weakening range, the flow setpoint (output of the field weakening controller) should decrease with $1/n$. Influences of the DC-bus voltage may be seen in the flow setpoint. The signal characteristic should preferably be "smooth".
 - From the entry into the field weakening range, the D-current setpoint (output of the field controller) should always decrease with $1/n$. In the signal characteristic no heavy vibrations may occur.

Optimising the dynamic behaviour in the field weakening range:


4. Adapt the dynamic performance to the behaviour required for the machine application.
5. Repeat the recording of the speed characteristic and record the small signal range in the field weakening range ($n_1 \leftrightarrow n_2$).
 - If the flow setpoint is adapted to the speed too slowly, increase the dynamic performance of the field weakening controller: reduce the reset time ([C00578](#)) in small steps, the gain ([C00577](#)) should remain set to 0 [Vs/V] for most machines.
 - If the flow setpoint in the field weakening range falls "too early" with $1/n^2$ (stability limit of the machine reached), the leakage inductance of the motor ([C00085](#)) may be reduced a bit.
 - If the actual flow value follows the flow setpoint too slowly, increase the dynamic performance of the field controller: increase gain ([C00077](#)), reduce reset time ([C00078](#)).
 - If the actual D-current value does not correspond enough to the D-current setpoint, the dynamic performance of the current controller has to be adapted. ▶ [Optimise current controller](#) (📖 147)
 - If the motor speed does not feature the desired characteristic, the speed controller has to be readjusted with maximum speed in the field weakening range. ▶ [Optimising the speed controller](#) (📖 150)

Checking the motor parameters:

6. Carry out dynamic measurement in the range $-n_{Max} \leftrightarrow +n_{Max}$ and record the motor speed using the [Oscilloscope](#).
 - The objective is a preferably linear speed characteristic.
 - In particular check the ranges around the rated motor speed and speed 0 and, if required, improve them by adjusting R_R ([C02860](#)) or L_H ([C02861](#))!

Example oscillogram

Ch	Variable of the motor control	Unit	1/Div	Offset	Position
1	Speed.dnActualMotorSpeed (current speed)	rpm	1k	0	-4
2	Voltage.dnActualMotorVoltage (current motor voltage)	V	100	0	-5
3	Torque.dnActualMotorTorque (current motor torque)	Nm	500m	0	0
4	Speed.dnSpeedSetpoint (speed setpoint)	rpm	1k	0	-4
5	Common.dnFluxSet (flux setpoint)	%	20	0	-5
6	Common.dnActualFlux (actual flux value)	%	20	0	-5
7	Current.dnDirectCurrentSet (D-current setpoint)	A	1	0	0
8	Current.dnActualDirectCurrent (actual D-current value)	A	1	0	0




[5-5] Example oscillogram

5 Motor interface

5.4 Servo control (SC)

5.4.2 Signal flow (servo control for synchronous motor)



[5-6] Signal flow - servo control for synchronous motor

See also:


- ▶ [Signal flow - encoder evaluation](#) (📖 243)
- ▶ [Signal flow - speed follower](#) (📖 498)
- ▶ [Signal flow - torque follower](#) (📖 503)
- ▶ [Signal flow - position follower](#) (📖 492)

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ([📄 585](#))

No.	Variable of the motor control	Meaning
(1)	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
(2)	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
(3)	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
(4)	Current.dnQuadratureCurrentSet	Q current setpoint
(5)	Current.dnActualQuadratureCurrent	Actual Q current
(6)	Current.dnActualDirectCurrent	Actual D current
(7)	Current.dnDirectCurrentSet	D current setpoint
(8)	Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
(9)	Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
(10)	Voltage.dnQuadratureVoltage	Q voltage
(11)	Voltage.dnDirectVoltage	D voltage
(12)	-	
(13)	-	
(14)	Voltage.dnActualMotorVoltage	Current motor voltage

5.4.3 Signal flow (servo control for asynchronous motor)



[5-7] Signal flow - servo control for asynchronous motor

See also:

- ▶ [Signal flow - encoder evaluation](#) (📖 243)
- ▶ [Signal flow - speed follower](#) (📖 498)
- ▶ [Signal flow - torque follower](#) (📖 503)
- ▶ [Signal flow - position follower](#) (📖 492)

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ([📄 585](#))

No.	Variable of the motor control	Meaning
(1)	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
(2)	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
(3)	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
(4)	Current.dnQuadratureCurrentSet	Q current setpoint
(5)	Current.dnActualQuadratureCurrent	Actual Q current
(6)	Current.dnActualDirectCurrent	Actual D current
(7)	Current.dnDirectCurrentSet	D current setpoint
(8)	Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
(9)	Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
(10)	Voltage.dnQuadratureVoltage	Q voltage
(11)	Voltage.dnDirectVoltage	D voltage
(12)	Common.dnActualFlux	Actual flux value
(13)	Common.dnFluxSet	Flux setpoint
(14)	Voltage.dnActualMotorVoltage	Current motor voltage

5 Motor interface

5.5 Sensorless vector control (SLVC)

5.5 Sensorless vector control (SLVC)

This function extension is available from software version V3.0!

If this motor control mode is set in [C00006](#), a considerably higher torque and a lower current consumption in idle state can be achieved compared to the V/f control mode.



Note!

Observe the following application limits of the sensorless vector control:

- Only approved for power up to 55 kW and horizontal applications (no hoists or lifting equipment)
- For single drives only
- For asynchronous motors only
- Not suitable for operation in generator mode/braking operation (e. g. unwinders)




Tip!

For vertical drives/hoists, use the servo control (with feedback), or the V/f control with activated voltage vector control (VVC), which supports vertical drives/hoists up to 55 kW.

5.5.1 Basic settings

After the motor and controller have been optimally adjusted to each other, the "initial commissioning steps" described in the following table are sufficient for a quick initial commissioning.

- Detailed information on the individual steps can be found in the following subchapters.

Initial commissioning steps	
1	Parameterising speed and torque controller. (📖 168)
2.	<p>Additional "flying restart" function:</p> <ul style="list-style-type: none"> • In the Lenze setting, this parameterisable additional function is activated. • If the flying restart function is not required, deactivate this function. ▶ Flying restart function (📖 212) <p> Only deactivate the flying restart if it is ensured that the drive is always at standstill in the case of controller enable!</p>
3	<p>Additional "DC-injection braking" function:</p> <ul style="list-style-type: none"> • In the Lenze setting, this parameterisable additional function is deactivated. • If DC-injection braking is required, activate this function. ▶ DC-injection braking (📖 215)



Tip!

A precise adjustment of the motor parameters for an improved concentricity factor and stability is described in the chapter "[Optimising motor parameters](#)". (📖 169)

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimising the control mode](#)". (📖 175)

Parameterisable additional functions are described correspondingly in the chapter "[Parameterisable additional functions](#)". (📖 203)

5.5.1.1 Parameterising speed and torque controller

Short overview: Parameters for controller settings

Parameters	Info	Lenze setting	
		Value	Unit
C00070	Speed controller gain	0.500	Nm/rpm
C00071	Speed controller reset time	24.0	ms
C00987	SLVC: Torque controller gain	0.5000	Hz/A
C00988	SLVC: Torque controller reset time	10.00	ms

Typical controller settings

The following table contains typical guide values concerning the setting of the speed and torque control for different device types/motor powers:

Device type	Motor power (4-pole standard ASM)	Speed controller		Torque controller	
		Gain C00070 [Nm/rpm]	Reset time C00071 [ms]	Gain C00987 [Hz/A]	Reset time C00988 [ms]
E0024	0.37 kW	0.0122	50.00	5.0833	10.00
E0034	0.75 kW	0.0138	50.00	3.0500	10.00
E0044	1.50 kW	0.0264	50.00	1.9818	10.00
E0074	3.00 kW	0.0411	50.00	1.1077	10.00
E0134	5.50 kW	0.0674	50.00	0.5965	10.00
E0174	7.50 kW	0.1183	50.00	0.3303	10.00
E0244	11.00 kW	0.1183	50.00	0.3303	10.00
E0324	15.00 kW	0.2244	50.00	0.2368	10.00
E0474	22.00 kW	0.3442	50.00	0.1547	10.00
E0594	30.00 kW	1.1503	50.00	0.1232	10.00
E0864	45.00 kW	1.7400	50.00	0.0817	10.00
E1044	55.00 kW	2.1712	50.00	0.0661	10.00

[5-8] Typical controller settings

The gain for the field current controller ([C00985](#)) and the gain for the cross current controller ([C00986](#)) are initially set to "0.00".

5.5.2 Optimising motor parameters

Although the motor parameters have been determined before as described in the chapter "[Adjusting motor and controller to each other](#)", an additional optimisation may be required in the following cases using the adjustment processes described in this chapter:

- When the concentricity factor in the lowest speed range is to be improved.
- When the stability in the lower speed range is to be improved.
- When the rated torque is not reached in the rated point, i. e. at rated speed and rated current.
- When a too high magnetising current is injected in idle state.

General information on the motor parameter adjustment

The motor stator resistance can generally always be adjusted with a passive load since the motor is stopped when this parameter is set.

An optimisation of the mutual motor inductance, however, is only sensible when the motor rotates in the medium speed range. In the majority of cases, the no-load operation is sufficient for this adjustment. In contrast to the rated operation, the no-load operation is also possible for initial commissioning in many applications.

The motor rotor resistance can only be adjusted exactly if the current motor speed is available. Thus, for this adjustment only applications are considered where a speed measurement is possible, even with a manual tachometer. If, under operating conditions (e.g. at rated load), the motor consumes more than the rated motor current indicated, an adjustment can also be executed by reducing the mutual motor inductance.



Note!

To execute the adjustment processes described in the following subchapters, the controller must always be enabled!

5.5.2.1 Motor power factor

Together with the rated motor current, the motor power factor ([C00091](#)) defines the motor magnetising current ([C00092](#)) and thus the current consumption of the controller in idle state.



Note!

The following adjustment of the motor power factor should be executed after the motor parameters have been determined and when the value set in [C00091](#) deviates more than 10 % from the data on the motor nameplate.

If the setting of the motor power factor in [C00091](#) is changed, the setting of the mutual motor inductance also changes in [C00079](#).

For the adjustment of the motor power factor, first the motor current in idle state at rated speed is determined in the control type "V/f control". Afterwards the motor power factor is set in the control type "Sensorless vector control" so that the motor magnetising current corresponds to the previously determined no-load current.



How to adjust the motor power factor:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Select the control type "VFCplus: V/f control" in [C00006](#).
3. Select setpoint speed 0 rpm
4. Enable controller.
5. Slowly increase setpoint speed to rated speed (no field weakening) and then keep it at rated speed constantly.
6. Take down the motor current displayed in [C00054](#).
7. Slowly reduce the setpoint speed to 0 rpm again.
8. inhibit inverter.
9. Go to [C00006](#) and select the "SLVC: Sensorless vector control" again.
10. Set Lh adjustment in [C02861](#) to 100 %.
11. Set the motor power factor ([C00091](#)) so that the following applies:
motor magnetising current ([C00092](#)) \approx motor current taken down before.
12. Save parameter set ([C00002](#) = "11: Save start parameters").

5.5.2.2 Motor stator resistance

For the adjustment of the motor stator resistance, first the motor current at standstill (without load of the motor) is compared to the motor magnetising current. Afterwards the setting of the motor stator resistance is changed step by step until the motor current stably reaches the motor magnetising current.



How to adjust the motor stator resistance:

1. Select setpoint speed 0 rpm or activate quick stop.
2. Enable controller.
3. Compare the motor current displayed in [C00054](#) with the motor magnetising current displayed in [C00092](#).
4. inhibit inverter.
5. If motor current > motor magnetising current:
 - Reduce the motor stator resistance stepwise in [C00084](#).If motor current < motor magnetising current:
 - Increase the motor stator resistance stepwise in [C00084](#).
6. Repeat steps 2 ... 5 until the following applies: Motor current \approx motor magnetising current.
7. Save parameter set ([C00002](#) = "11: Save start parameters").

5.5.2.3 Motor magnetising inductance

Adjustment at rated operation

This adjustment is executed at rated speed and a defined load (e.g. measuring brake) which serves to define the rated torque. A condition for the adjustment is to know the real load torque. The motor current is compared to the rated current. At rated load, these two values should be almost identical.

If an adjustment at rated operation is not possible, alternatively execute the adjustment at no-load operation (see the following section "Adjustment at no-load operation").



How to adjust the mutual motor inductance at rated operation:

1. Set the maximum current in [C00022](#) to 110 % of the rated motor current ([C00088](#)).
2. Select setpoint speed 0 rpm
3. Enable controller.
4. Slowly increase setpoint speed to rated speed (no field weakening) and then keep it at rated speed constantly.
5. Apply rated load to the motor.
6. Compare the motor current displayed in [C00054](#) with the rated motor current displayed in [C00088](#).
7. If motor current > rated motor current:
 - Reduce the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) until the following applies: motor current \approx rated motor current.
- If motor current < rated motor current:
 - Increase the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) until the following applies: motor current \approx rated motor current.
8. Unload the motor again and slowly reduce the setpoint speed to 0 rpm again.
9. inhibit inverter.
10. Save parameter set ([C00002](#) = "11: Save start parameters").

Adjustment at no-load operation

If an adjustment at rated operation is not possible, alternatively execute the adjustment at no-load operation.

For the adjustment of the mutual motor inductance in no-load operation, first the motor current is compared to the motor magnetising current at a setpoint speed of approx. 75 % of the rated speed (without load of the motor). Afterwards the setting of the mutual motor inductance is changed step by step until the motor current just, but stably reaches the motor magnetising current.



How to adjust the mutual motor inductance at no-load operation:

1. Select setpoint speed 0 rpm
2. Enable controller.
3. Slowly increase the setpoint speed to approx. 75 % of the rated speed and keep this value constant.
 - If the controller oscillates, check the speed controller.
4. Compare the motor current displayed in [C00054](#) with the motor magnetising current displayed in [C00092](#).
5. If motor current > motor magnetising current:
 - Reduce the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) (based on 100 %) until the following applies:
motor current < motor magnetising current
 If motor current << motor magnetising current:
 - Increase the mutual motor inductance stepwise and indirectly via the Lh adjustment in [C02861](#) (based on 100 %) until the following just applies:
motor current < motor magnetising current
6. Slowly reduce the setpoint speed to 0 rpm again.
7. inhibit inverter.
8. Save parameter set ([C00002](#) = "11: Save start parameters").

5.5.2.4 Motor rotor resistance

This adjustment is carried out at a setpoint speed of approx. 75 % of the rated speed and with a defined load (e. g. measuring brake). The precondition for the adjustment is that the actual speed is known (e. g. by the use of a manual tachometer). At constant setpoint speed first the actual speed is measured while the machine is unloaded. Afterwards the motor is loaded at the same setpoint speed until the rated torque is reached (rated current). The speed measured should preferably correspond in idle state and at rated speed.



How to adjust the motor rotor resistance:

1. Select setpoint speed 0 rpm
2. Enable controller.
3. Slowly increase the setpoint speed to approx. 75 % of the rated speed and keep this value constant.
4. Measure actual speed n_{idle} (e.g. using a manual tachometer) and take it down.
5. Increase load of the motor until the motor current displayed in [C00054](#) corresponds to the rated current.
6. Measure actual speed n_{Load} .
7. If $n_{Load} < n_{idle}$:
 - Reduce motor rotor resistance stepwise and indirectly via the R_r adjustment in [C02860](#) until the following applies: $n_{Load} \approx n_{idle}$.
- If $n_{Load} > n_{idle}$:
 - Increase motor rotor resistance stepwise and indirectly via the R_r adjustment in [C02860](#) until the following applies: $n_{Load} \approx n_{idle}$.
8. Unload the motor again and slowly reduce the setpoint speed to 0 rpm again.
9. inhibit inverter.
10. Save parameter set ([C00002](#) = "11: Save start parameters").

5.5.3 Optimising the control mode

A manual optimisation of the controller settings may be required for very dynamic applications and in the field weakening range.



Note!

The processes for optimising the controller settings described in the following subchapters can only be executed while the drive is rotating and never when being at standstill!

For all optimisation processes the magnetisation phase has to be completed!

Based on the typical controller settings which are listed in the chapter "[Parameterising speed and torque controller](#)" in table [\[5-8\]](#), first the field feedforward control and the speed controller are optimised in the base speed range. Afterwards, the torque controller is optimised in the field weakening range.

For optimisation, a suitable speed ramp must be selected for the drive and the acceleration must be recorded, e.g. using the [Oscilloscope](#) function in »Engineer«. ([□ 585](#))

Short overview: Parameters for controller settings


Parameters	Info	Lenze setting	
		Value	Unit
C00070	Speed controller gain	0.500	Nm/rpm
C00071	Speed controller reset time	24.0	ms
C00985	SLVC: Field controller gain	0.00	
C00986	SLVC: Cross current controller gain	0.00	
C00987	SLVC: Torque controller gain	0.5000	Hz/A
C00988	SLVC: Torque controller reset time	10.00	ms

5.5.3.1 Optimising field feedforward control


To optimise the field feedforward control, the drive must be accelerated in the base speed range with slow setpoint ramps (e.g. acceleration time = 5 s) to speed values below the rated speed and then decelerated again.

- If the field current oscillates at the beginning of the acceleration and at the end of the deceleration (Current.dnActualDirectCurrent), these oscillations can be reduced by increasing the gain for the field current controller in [C00985](#).

Ch	Variable of the motor control	Unit	1/Div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-9] Oscilloscope 1: speed ramp (motor 55 kw) – field controller gain = 0.00



[5-10] Oscilloscope 2: speed ramp (motor 55 kw) – field controller gain = 2.00

5.5.3.2 Optimising the speed controller

To optimise the speed controller, the drive must be accelerated in the base speed range with slow setpoint ramps (e.g. acceleration time = 5 s) to speed values below the rated speed and then decelerated again.

Gain optimisation

The proportional gain V_p is selected under [C00070](#):


1. Increase [C00070](#) until the drive oscillates slightly (see picture [\[5-11\]](#)).
2. Reduce [C00070](#) until the drive runs stable again (see picture [\[5-12\]](#)).
3. Reduce [C00070](#) to approx. half the value.

Optimise the reset time


The reset time T_n is selected under [C00071](#):

1. Reduce [C00071](#) until the drive oscillates slightly.
2. Increase [C00071](#) until the drive is stable again.
3. Increase [C00071](#) to approx. double the value.

Ch	Variable of the motor control	Unit	1/Div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-11] Oscillogram 1: speed ramp (motor 55 kw) – speed controller gain = 15.49



[5-12] Oscillogram 2: speed ramp (motor 55 kw) – speed controller gain = 7.49

Setting of actual speed filter

In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible ([C00497](#)). The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay.

If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset in [C00497](#) which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection).

When using EMC-compliant systems or high-quality encoders, you can reduce the preset time constant considerably. For this purpose, the running noise of the motor can be used for setting [C00497](#) at constant speed.

If this is not possible, e.g. due to a too loud environment or because the motor is too far away, the noise of the actual speed value or the setpoint torque value can be used for evaluation by means of the [Oscilloscope](#). Please observe that the speed controller gain V_p ([C00070](#)) is used for the torque setpoint.

5.5.3.3 Optimising torque controller

To optimise the torque controller a steep speed ramp is required which reaches into the field weakening range (e.g. $1.2 \cdot$ rated speed). For this purpose, the drive must be operated at its current and voltage limit.



Stop!

Reduce the maximum current in [C00022](#) for this adjustment to approx. 130 % of the motor magnetising current ([C00092](#)) to prevent shocks on the drive!




Note!

If no field weakening operation is required, the adjustment must be executed in the base speed range.


The gain ([C00987](#)) and reset time ([C00988](#)) of the torque controller are to be set so that the actual cross current can preferably follow the cross current setpoint.

- If oscillations occur during the cross current (see illustration [\[5-13\]](#)), the gain ([C00987](#)) is to be reduced until the drive is stable again (see illustration [\[5-14\]](#)).
- Afterwards the reset time ([C00988](#)) can be reduced as long as the drive accelerates in a stable way.

Ch	Variable of the motor control	Unit	1/Div	Offset	Position
1	Speed.dnSpeedSetpoint (speed setpoint)	rpm	0.2k	0	-4
2	Speed.dnActualMotorSpeed (current speed)	rpm	0.2k	0	-4
3	Current.dnActualDirectCurrent (actual field current)	A	10	0	0
4	Current.dnQuadratureCurrentSet (cross current setpoint)	A	10	0	0
5	Current.dnActualQuadratureCurrent (actual cross current)	A	10	0	0



[5-13] Oscillogram 1: speed ramp (motor 55 kw) – torque controller gain = 0.0661



[5-14] Oscillogram 2: speed ramp (motor 55 kw) – torque controller gain = 0.0361

5.5.3.4 Optimise current controller



Note!

Only required for sensorless vector control if one of the following functions is used.

- [Flying restart function](#) (📖 212)
- [DC-injection braking](#) (📖 215)

In a test mode you can select current setpoint step-changes and optimise the parameter settings of the current controller (gain and reset time) by evaluating the step responses.

- The starting values for gain and reset time can be calculated with the following formula:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$


$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$



How to optimise the current controller in the test mode:


1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Activate one of the two following optimisation modes for the current controller:
 - [C00398](#) = "3: Current controller optimisation mode":
After controller enable, the motor is supplied with current as long as the controller is enabled.
 - [From software version V7.0:](#)
[C00398](#) = "4: Current controller optimisation mode pulse":
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
3. Select the effective value of the current setpoint step change under [C00022](#).
 - The peak value of the measurable motor current will be 1.41 times higher.
4. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in »Engineer«. (📖 585)
 - Variable of the motor control to be recorded:
Current.dnActualDirectCurrent (field-oriented direct-axis current)

5. Evaluate the step response:



6. Change the gain V_p under [C00075](#) and the reset time T_n under [C00076](#).
7. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.
 - In the optimised state the current rise time typically is 0.5 ... 1 ms.
8. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").
9. Save parameter set ([C00002](#) = "11: Save start parameters").

5.5.4 Signal flow



[5-15] Signal flow - sensorless vector control

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (585)

No.	Variable of the motor control	Meaning
(1)	Torque.dnTorqueSetpoint	Torque setpoint
(2)	Current.dnQuadratureCurrentSet	Q current setpoint
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Actual speed value
(5)	Common.dnActualFlux	Actual flux value
(6)	Frequency.dnActualSlipFrequency	Actual slip frequency
(7)	Frequency.dnActualRotatingFieldFrequency	Current field frequency
(8)	Voltage.dnQuadratureVoltage	Q voltage
(9)	Voltage.dnDirectVoltage	D voltage
(10)	Voltage.dnActualMotorVoltage	Current motor voltage
(11)	Current.dnDirectCurrentSet	D current setpoint
(12)	Current.dnActualDirectCurrent	Actual D current

5.6 V/f control (VFCplus)

This function extension is available from software version V3.0!

If this motor control mode is set in [C00006](#), the output voltage of the controller follows a firmly defined characteristic.




Note!

The operation of vertical drives/hoists is only supported up to 55 kW by the V/f control!

5.6.1 Basic settings

After the motor and controller have been optimally adjusted to each other, the "initial commissioning steps" described in the following table are sufficient for a simple characteristic control.

- Detailed information on the individual steps can be found in the following subchapters.

Initial commissioning steps	
1	Defining the V/f characteristic. (📖 185)
2.	Setting the voltage boost. (📖 186)
3	Parameterising load adjustment. (📖 188)
4	Activating voltage vector control. (📖 189) <ul style="list-style-type: none"> • The <i>Voltage Vector Control (VCC)</i>, which can be activated, serves to provide a torque at low field frequencies. This task is executed by a current controller the output voltage of which is added to the voltage from the characteristic.
5	Defining the current limit (Imax controller). (📖 190)
6	Additional "flying restart" function: <ul style="list-style-type: none"> • In the Lenze setting, this parameterisable additional function is activated. • If the flying restart function is not required, deactivate this function. ▶ Flying restart function (📖 212) <div style="text-align: center;">  </div> <p>Only deactivate the flying restart if it is ensured that the drive is always at standstill in the case of controller enable!</p>
7	Additional "DC-injection braking" function: <ul style="list-style-type: none"> • In the Lenze setting, this parameterisable additional function is deactivated. • If DC-injection braking is required, activate this function. ▶ DC-injection braking (📖 215)



Tip!

How to optimise the control behaviour and adjust it to the concrete application is described in the chapter "[Optimising the control mode](#)". (📖 191)


Parameterisable additional functions are described correspondingly in the chapter "[Parameterisable additional functions](#)". (📖 203)

5.6.1.1 Defining the V/f characteristic

Linear/square-law characteristic

[C00950](#) serves to select the shape of the characteristic to adjust the characteristic to different load profiles:

- Linear characteristic for drives with constant load torque over the speed.
- Square-law characteristic for drives with a linear or square-law load torque over the speed:
 - Square-law V/f characteristics are mostly used in centrifugal pump and fan drives. However, it must be checked in each individual case if your pump or fan drive can be used in this operating mode!
 - If your pump or fan drive is not suitable for operation with a square-law V/f characteristic, you have to use the linear or user-definable V/f characteristic or the sensorless vector control instead of the V/f control.



[5-16] Linear/square-law V/f characteristic

- The calculation of the characteristic considers the rated motor voltage ([C00090](#)) and the V/f base frequency ([C00951](#)).

Short overview: Parameters for V/f characteristic

Parameters	Info	Lenze setting	
		Value	Unit
C00950	VFC: V/f characteristic shape	Linear (V/f)	
C00951	VFC: V/f base frequency	50	Hz
C00952/1...11	VFC: Frequency interpol. point n	▶ Defining a user-defined V/f characteristic (□ 192)	
C00953/1...11	VFC: Voltage interpol. point n		
C00954/1...11	VFC: Activat. interpol. point n		

5.6.1.2 Setting the voltage boost

[C00960](#) and the *MI_dnBoostSet_n* input of the motor interface serve to define a constant, load independent voltage boost at low speeds (below the V/f rated frequency) or at motor standstill to optimise the starting performance.



Stop!

If the motor is operated at standstill for a longer time - especially in case of smaller motors - the motor can be destroyed by overtemperature!

- Connect the thermal contact (NC contact), PTC, or KTY of the motor and activate the motor temperature monitoring of the controller.
- Operate self-ventilated motors with a blower, if required.



Note!

When device types > BF7 are used, the voltage boost only functions in a restricted way due to the hardware properties!

Depending on the required starting torque, the voltage boost must be set so that the required motor current will be available after controller enable (starting current $\sim V_{\min}$).



Tip!

The required voltage can be calculated by multiplying the stator resistance by the rated magnetising current:

$$U_{\min} = R_S \cdot I_{mN}$$

Optionally, the voltage can be determined empirically by increasing the value for the voltage boost until the rated magnetising current flows.


Calculate voltage boost V_{Boost}	
$U_{\text{Boost}} = MI_dnBoostSet_n \cdot \frac{1000V}{100\%} + C00960$	
MI_dnBoostSet_n	The value for the <i>MI_dnBoostSet_n</i> input is a voltage related to 1000 V given in [%]. ▶ Internal interfaces "LS_MotorInterface" system block
C00960	In C00960 , the voltage must be set directly in [V]. Notes: <ul style="list-style-type: none"> • Only positive voltage values can be selected, negative values are limited to 0 V. • The voltages in C00960 and the relative <i>MI_dnBoostSet_n</i> value are to be understood as peak values of the phase voltage.

The resulting voltage V is calculated from the geometrical addition of V_{Boost} and the characteristic voltage:

$$U = \sqrt{U_{\text{Characteristic}}^2 + U_{\text{Boost}}^2}$$

5 Motor interface

5.6 V/f control (VFCplus)



[5-17] Voltage boost at linear/square-law V/f characteristic

Short overview: Parameters for voltage boost

Parameters	Info	Lenze setting	
		Value	Unit
C00960	VFC: V/f voltage boost	0	V



Tip!

For magnetising the motor, consider a sufficient time from the controller enable to the start of the speed ramp function generator.

- The bigger the motor the longer the time required for magnetisation. A motor with a power of 90 kW requires up to 2 seconds.

5.6.1.3 Parameterising load adjustment

[C00962](#) serves to parameterise a load adjustment in [%] proportionally to the rated torque to obtain a correspondingly "rigid" drive behaviour even after the starting action.

- When starting torque = rated torque, a load adjustment of 50 % is suitable for most applications.



Stop!

If the load adjustment is too high, the motor current may increase in idle state and the motor may overheat!

The [C00961](#) parameter serves to adjust the characteristic depending on the load at CW and CCW rotation:

Setting in C00961	Info
0: CW rotation in motor mode/CCW rotation in motor mode	The motor operates in motor mode in both directions.
1: CW rotation in motor mode/CCW rotation in generator mode	Application example: Hoist without counterweight
2: CW rotation in generator mode/CCW rotation in motor mode	Application example: Dancer-controlled unwinder

Short overview: Parameters for load adjustment

Parameters	Info	Lenze setting	
		Value	Unit
C00961	VFC: Load - cw/ccw-operation	CW: mot. / CCW: mot.	
C00962	VFC: Load adjustment	20.00	%

5.6.1.4 Activating voltage vector control

The *Voltage Vector Control* (VCC), which can be activated, is an alternative to the voltage boost. The voltage vector control is used if a high starting torque has to be ensured. The voltage vector control ensures that the motor current required for this purpose is available in the zero speed range.



Note!

A disadvantage of the voltage vector control is the increased current at low speeds. This causes higher losses and thus an increased heating of the machine.

The voltage vector control is activated by defining a current setpoint in [C00957](#) and can be deactivated again by setting "0.0 A".

- The voltage vector control is additive to the voltage boost.
 - ▶ [Setting the voltage boost](#) (186)
- When the current setpoint is defined, provide a reserve of 20 % to prevent a motor stalling caused by sudden additional loads.
- Example for starting torque = rated motor torque:
The current setpoint must be parameterised in [C00957](#) to approx. 120 % of the load current.

Setting of the controller parameters

For the gain ([C00958](#)) and the reset time ([C00959](#)), accept the values that have been detected for the current controller gain ([C00075](#)) and reset time ([C00076](#)) in the test mode. ▶ [Optimise current controller](#) (196)

Since the voltage vector control controls the current value which has a higher background noise due to its calculation, the reset time might possibly be increased.

Short overview: Parameters for voltage vector control

Parameters	Info	Lenze setting	
		Value	Unit
C00957	VFC: VVC current setpoint	0.00	A
C00958	VFC: VVC gain	0.00	V/A
C00959	VFC: VVC reset time	2000.00	ms



Tip!

For controllers with a power > 55 kW we recommend to use the voltage vector control for horizontal drives for improving the smooth running characteristics.

5.6.1.5 Defining the current limit (Imax controller)

The current limit for the I_{max} controller is defined by the maximum current which must be set in [C00022](#). If the motor current exceeds the value set in [C00022](#), the I_{max} controller gets active.

- The I_{max} controller changes the field frequency so that the motor current does not exceed the current limit. In motor mode, the frequency is reduced and in generator mode it is increased.
- Gain and reset time of the I_{max} controller can be parameterised in [C00963](#) and [C00964](#).

Short overview: Parameters for I_{max} controller

Parameters	Info	Lenze setting	
		Value	Unit
C00022	Maximum current	0.00	A
C00963	VFC: Gain - I _{max} controller	0.001	Hz/A
C00964	VFC: Reset time - I _{max} controller	100.0	ms

Optimising the I_{max} controller

- If oscillations occur during operation at the current limit, the I_{max} controller has to be decelerated:
 - Reduce gain ([C00963](#))
 - Increase reset time ([C00964](#))
- If the I_{max} controller does not operate fast enough after having exceeded the current limit, it must be accelerated:
 - Increase gain ([C00963](#))
 - Reduce reset time ([C00964](#)).

5.6.2 Optimising the control mode

The "optimisation steps" given in the following table serve to further optimise the control behaviour of the V/f control and adjust it to the concrete application.


- Detailed information on the individual steps can be found in the following subchapters.

Optimisation steps	
1	Defining a user-defined V/f characteristic. (📖 192) <ul style="list-style-type: none">• Individual adjustment of the motor magnetisation to the concrete application if linear and square-law characteristics are not suitable.
2.	Parameterising slip compensation. (📖 193)
3	Parameterising oscillation damping. (📖 194)
4	When the flying restart function is used: Optimise flying restart process. ▶ Flying restart function (📖 212)
5	Optimise current controller. (📖 196) <ul style="list-style-type: none">• Only required if one of the following functions is used:<ul style="list-style-type: none">• Voltage vector control (📖 189)• Flying restart function (📖 212)• DC-injection braking (📖 215)
6	Save »Engineer« project.

5.6.2.1 Defining a user-defined V/f characteristic

To individually adjust the motor magnetisation to the real application, a user-definable characteristic can be selected in [C00950](#) if the linear and square-law characteristic are not suitable.

- The interpolation points (voltage/frequency values) of this characteristic are selected via the 11 subcodes of [C00952](#) and [C00953](#).
- If less interpolation points are required, the interpolation points that are not needed have to be deactivated via the subcodes of [C00954](#).
- In the Lenze setting the 11 grid points represent a linear characteristic:



	P1	P2	P3	P4	P5	P6	P7	P8	P9	P10	P11
V	400 V	320 V	240 V	160 V	80 V	0 V	80 V	160 V	240 V	320 V	400 V
f	-50 Hz	-40 Hz	-30 Hz	-20 Hz	-10 Hz	0 Hz	10 Hz	20 Hz	30 Hz	40 Hz	50 Hz

[5-18] User-definable characteristic (Lenze setting)

5 Motor interface

5.6 V/f control (VFCplus)

5.6.2.2 Parameterising slip compensation

The slip compensation serves to automatically compensate a load-dependent speed loss. In order that the slip compensation can operate correctly, the rated slip of the motor is required. This is calculated from the rated frequency ([C00089](#)) and the rated speed ([C00087](#)), thus both parameters must be parameterised correctly.

- A percentage adjustment of the calculated slip can be made in [C00965](#), e.g. when the real motor data deviate from the data given on the nameplate. A value of 100 % in [C00965](#) corresponds to the rated slip of the machine.
- The time behaviour of the slip compensation can be parameterised in [C00966](#).

Short overview: Parameters for slip compensation

Parameters	Info	Lenze setting	
		Value	Unit
C00965	VFC: Gain - slip compensation	0.00	%
C00966	VFC: Time const. slip comp.	2000	ms

5.6.2.3 Parameterising oscillation damping

The oscillation damping serves to reduce the oscillations during no-load operation which are caused by energy oscillating between the mechanical system (mass inertia) and the electrical system (DC bus). Furthermore, the oscillation damping can also be used to compensate resonances.



Note!


Observe the following restrictions:

- Oscillations occurring sporadically cannot be damped.
- Damping is possible only for constant oscillations at a steady-state operating point.
- Oscillation damping is not suitable for oscillations occurring during dynamic processes (e.g. accelerations or load changes).

Job title

The determination of the oscillation is based on the active current. In order to obtain the alternating component of the active current, this current is differentiated. This signal is then passed through a PT1 filter.

- The base frequency of the PT1 filter has to be set in such a way that the oscillation can be damped and higher-frequency components are filtered out of the signal. For this purpose the time constant ([C00968](#)) is used.
- [C00967](#) serves to parameterise the gain of the oscillation signal. The maximum amplitude of the frequency change determined by the oscillation damping is set via [C00969](#).
- Oscillation damping is only active if the setpoint speed is greater than 10 rpm and the DC-bus voltage exceeds a value of 100 V.
- In the lower speed range, the oscillation damping may have a negative impact on the concentricity factor.
 - Therefore from software version V5.0 a ramp end frequency can be set in [C00970](#), up to which the gain of the oscillation damping ([C00967](#)) from 10 rpm is slowly increased with increasing rotational frequency.



Identification of the oscillation

Before the oscillation damping can be parameterised, the oscillation has to be identified. One way is to examine the motor current while oscillation damping is switched off ([C00967](#) = 0 %). At steady-state operation, a constant current flows. If the drive oscillates, these oscillations are also visible on the motor current. It is therefore possible to determine the frequency and the amplitude of the oscillation from the alternating component of the motor current. In the following, this alternating component is referred to as "current oscillation".

Parameter setting

- The time constant ([C00968](#)) is determined from the reciprocal value of twice the frequency of the current oscillation:

$$\text{Time constant} = \frac{1}{2 \cdot \text{Oscillation frequency}}$$

- The gain factor ([C00967](#)) is calculated with the following formula based on the relationship between the amplitude of the current oscillation and the maximum device current:

$$\text{Gain} = \frac{\text{Current amplitude}}{\sqrt{2} \cdot \text{Maximum device current (C00789)}} \cdot 100 \%$$

- The maximum oscillation frequency ([C00969](#)) serves to the absolute limitation of the oscillation frequency calculated before it is added to the field frequency. It can be derived from the amplitude of the current oscillation, the rated motor current, and the slip frequency of the motor connected:

$$\text{Max. frequency} = \frac{2 \cdot \text{Amplitude of the current oscillation}}{\text{Rated motor current}} \cdot \text{Rated slip frequency}$$

- From software version V5.0:** The ramp end frequency ([C00970](#)) defines the rotational frequency from which the gain factor is to have reached its nominal value ([C00967](#)).
 - The ramp end frequency refers to the rated motor frequency in percent ([C00089](#)).
 - Below a speed of 10 rpm, the oscillation damping remains deactivated.
 - For machines with a power greater than 55 kW a ramp end frequency of 20 % is recommended.

Short overview: Parameters for oscillation damping

Parameters	Info	Lenze setting	
		Value	Unit
C00967	VFC: Gain - oscillation damping	20	%
C00968	VFC: Time const. - oscill. damp.	5	ms
C00969	VFC: Limitation - oscillation damping	0.2	Hz
C00970	VFC: Ramp end freq. - oscillation damping	0	%

5.6.2.4 Optimise current controller



Note!

Only required if one of the following functions is used:

- [Voltage vector control](#) (📖 189)
- [Flying restart function](#) (📖 212)
- [DC-injection braking](#) (📖 215)

In a test mode you can select current setpoint step-changes and optimise the parameter settings of the current controller (gain and reset time) by evaluating the step responses.

- The starting values for gain and reset time can be calculated with the following formula:

$$\text{Gain} = \frac{\text{Stator leakage inductance}}{340 \mu\text{s}}$$

$$\text{Reset time} = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$




How to optimise the current controller in the test mode:

1. If the controller is enabled, inhibit the controller, e. g. with the device command [C00002](#) = "41: Inhibit controller".
2. Activate one of the two following optimisation modes for the current controller:
 - [C00398](#) = "3: Current controller optimisation mode":
After controller enable, the motor is supplied with current as long as the controller is enabled.
 - [From software version V7.0:](#)
[C00398](#) = "4: Current controller optimisation mode pulse":
The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
3. Select the effective value of the current setpoint step change under [C00022](#).
 - The peak value of the measurable motor current will be 1.41 times higher.
4. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in »Engineer«. (📖 585)
 - Variable of the motor control to be recorded:
Current.dnActualDirectCurrent (field-oriented direct-axis current)

5 Motor interface


5.6 V/f control (VFCplus)

5. Evaluate the step response:



6. Change the gain V_p under [C00075](#) and the reset time T_n under [C00076](#).
7. Repeat steps 4 ... 6 until the optimum step response of the motor current is reached.
 - In the optimised state the current rise time typically is 0.5 ... 1 ms.
8. After the optimisation has been completed, deactivate the test mode again ([C00398](#) = "0: Test mode deactivated").
9. If the I_{min} control is used, both calculated controller parameters can also be used for the I_{min} controller:
 - [C00075](#) → [C00958](#) (I_{min} controller: gain)
 - [C00076](#) → [C00959](#) (I_{min} controller: reset time)
10. Save parameter set ([C00002](#) = "11: Save start parameters").

5.6.2.5 Optimising pull-out slip limitation



[5-19] Speed/torque curve of the asynchronous motor with two field weakening ranges **B** and **C**


The operating range of an asynchronous motor consists of the voltage control range **A** and the field weakening range. The field weakening range again is divided into two ranges:

- In the first range **B**, the power can be kept constant without causing motor stalling.
- The second field weakening range **C** is characterised by the fact that the maximum permissible stator current (defined via [C00022](#) "Maximum current") is reduced to prevent motor stalling.

The override point (n_2, M_2) can be influenced via [C00980](#) ("VFC: Override point of field weakening"). If the motor stalls in the field weakening range, the override point (n_2, M_2) can be adjusted by decreasing [C00980](#) so that motor stalling is avoided.

If the motor does not provide sufficient torque in the field weakening range, [C00980](#) must be increased.

5.6.3 Signal flow



[5-20] Signal flow - V/f control

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (585)

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Current.Current.dnActualMotorCurrent	Actual motor current
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Current motor speed
(5)	Frequency.dnActualSlipFrequency	Actual slip frequency
(6)	Frequency.dnActualRotatingFieldFrequency	Current field frequency
(7)	Voltage.dnOutputQuadratureVoltage	Q voltage
(8)	Voltage.dnOutputDirectCurrentCtrl	D voltage
(9)	Voltage.dnActualMotorVoltage	Current motor voltage

5 Motor interface

5.7 V/f control (VFCplus)

5.7 V/f control (VFCplus)

This function extension is available from software version V3.0!



Note!

The descriptions in chapter "[V/f control \(VFCplus\)](#)" also apply to the V/f control. ([184](#))

When this motor control mode is used, the operation can be continued if the encoder fails. For this, the encoder monitoring must be parameterised to "Warning". If the encoder fails, the speed controller is "frozen" so that the slip correction via the speed controller is maintained.


For the closed loop V/f control, the speed controller (also called "slip regulator") also has to be parameterised for the speed feedback.

- [C00971](#) serves to define the influence of the speed controller in [%] with regard to the reference speed of the motor ([C00011](#)). If the influence is adjusted to the slip expected under normal operating conditions, the motor cannot accelerate in an uncontrolled way when the encoder fails.
- To activate the speed controller, parameterise the gain ([C00972](#)) and the reset time ([C00973](#)).

Short overview: Parameters for speed controller

Parameters	Info	Lenze setting	
		Value	Unit
C00971	VFC: Influence - speed controller	10.00	%
C00972	VFC: Gain - speed controller	0.000	Hz/rpm
C00973	VFC: Reset time - speed controller	6000.0	ms

5.7.1 Signal flow



[5-21] Signal flow for closed loop V/f control

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ([📄 585](#))

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Current.Current.dnActualMotorCurrent	Actual motor current
(3)	Current.dnActualQuadratureCurrent	Actual Q current
(4)	Speed.dnActualMotorSpeed	Current motor speed
(6)	Frequency.dnActualRotatingFieldFrequency	Current field frequency
(7)	Voltage.dnOutputQuadratureVoltage	Q voltage
(8)	Voltage.dnOutputDirectCurrentCtrl	D voltage
(9)	Voltage.dnActualMotorVoltage	Current motor voltage

5.8 Parameterisable additional functions

Detailed information on the parameterisable additional functions can be found in the following subchapters:

Parameterisable additional functions	Available from software version	Motor control*		
		SC	SLVC	VFC plus
Correction of the stator leakage inductance... (📖 204)	V10	●		
Field weakening for synchronous machines (📖 209)	V2.0	●		
Flying restart function (📖 212)	V3.0		●	●
DC-injection braking (📖 215)	V3.0		●	●

* SC = servo control SLVC = sensorless vector control VFCplus = V/f control

5.8.1 Correction of the stator leakage inductance...

...and the current controller parameters by means of the saturation characteristic




Note!

Function only possible for servo control!

The current controller must be adjusted to the electrical characteristics of the motor stator resistance ([C00084](#)) and stator leakage inductance ([C00085](#)). In case of modern motors, the stator leakage inductance changes with the height of the current so that a new current controller setting is required for each current height.

When the motor is operated with very low and very high currents (e.g. in *Pick and place* applications), it is not always possible to achieve a satisfactory current controller setting for all operating points. For this purpose, the correction of the stator leakage inductance and current controller parameters is now possible via an adjustable saturation characteristic that can be set in [C02853](#) (17 interpolation points).

The following picture shows a typical saturation characteristic of an MCS motor:



[5-22] Saturation characteristic: Inductance referring to the inductance for rated current

- By optimising the current controller with different current setpoints such a characteristic can be determined "by trial" and set in [C02853](#).
- The correction by means of this saturation characteristic can be switched on/off via [C02859](#).




Note!

The saturation characteristic is not only used for the correction of the current controller but also influences the current controller feedforward control ([C00074](#)).

Distribution of the grid points

- The saturation characteristic is defined by 17 interpolation points which are distributed linearly on the x axis.
- Interpolation point 17 represents 100 % of the maximum motor current in the process ([C02855](#)).



[5-23] Saturation characteristic: Distribution of the grid points

Example for determining the saturation characteristic


Given values:

- Rated motor current: 5 A
- Maximum motor current: 20 A
- Maximum process current: 15 A (must be set later in [C00022](#))

Procedure:

1. Deactivate correction ([C02859](#) = "OFF").
2. Set the maximum current up to which the motor is to be operated in the process in [C02855](#) (in this example "15 A").
 - The value set in [C02855](#) has to be greater or the same as [C00022](#).
3. Adjust the current controller with different current setpoints and take down the corresponding settings for Vp and Tn.
 - The procedure for the adjustment is described in the chapter "[Optimise current controller](#)".
 - The current setpoints that are to be set for the respective adjustment in [C00022](#) result from the scaling of the maximum process current to the x axis of the saturation characteristic.
 - The grid points which are required to define the saturation characteristic with a sufficient quality varies from motor to motor and thus has to be determined individually.

- For this example currents were selected that are part of the interpolation points 5, 9, 13, and 15, and a measurement at rated motor current was carried out:




[5-24] Saturation characteristic: Distribution of the grid points

Specifications for adjustment			Measured values	
Grid point	Standardisation	Setting in C00022	Vp [V/A]	Tn [ms]
5	$0.25 \cdot 15 \text{ A} =$	3.75 A	13	6.5
9	$0.5 \cdot 15 \text{ A} =$	7.5 A	8	4
13	$0.75 \cdot 15 \text{ A} =$	11.25 A	5	2.5
15	$0.875 \cdot 15 \text{ A} =$	12.38 A	4	2
17	$1.0 \cdot 15 \text{ A} =$	15 A	3	1.7
Rated motor current =		5 A	10	5

4. Create a characteristic based on the values calculated for Vp.

- Here, the values of the grid points which have not been adjusted must be determined by interpolation between two values.
- **Note:** In this example it was assumed that the inductance does not change considerably below 3.75 A. For this reason the same Vp value resulting from a measurement with a motor current of 3.75 A was used for all grid points below 3.75 A.




[5-25] Determined saturation characteristic

5. Set the gain V_p in [C00075](#) and the reset time T_n in [C00076](#), which have been determined during the adjustment with rated motor current (in this example "5 A"):


- Set [C00075](#) = "10 V/A".
- Set [C00076](#) = "5 ms".

6. Scale the V_p values on the Y axis of the characteristic to the 100 % V_p setting in [C00075](#):



[5-26] Scaling of the determined saturation characteristic to the "100 %" setting in C00075

7. Enter the V_p values in percent, which are placed on the interpolation point, in [C02853/1...17](#):



[5-27] Grid point values of the saturation characteristic determined

Grid point	setting	Grid point	setting
1	C02853/1 = 130 %	10	C02853/10 = 72.5 %
2	C02853/2 = 130 %	11	C02853/11 = 65 %
3	C02853/3 = 130 %	12	C02853/12 = 57.5 %
4	C02853/4 = 130 %	13	C02853/13 = 50 %
5	C02853/5 = 130 %	14	C02853/14 = 45 %
6	C02853/6 = 107 %	15	C02853/15 = 40 %
7	C02853/7 = 95 %	16	C02853/16 = 35 %
8	C02853/8 = 87.5 %	17	C02853/17 = 30 %
9	C02853/9 = 80 %		

8. Enter the maximum process current ("15 A") in [C00022](#).

9. Switch on the correction ([C02859](#) = "ON").
 - When the correction of the stator leakage inductance is switched on, the same current characteristic should occur, irrespective of the current magnitude.
 - Since the current controller gain is corrected actively, the step responses may differ slightly compared to the previous measurements. In this case [C00075](#) and [C00076](#) must be optimised one last time.
10. Save parameter set ([C00002](#) = "11: Save start parameters").


5.8.2 Field weakening for synchronous machines

This function is available from software version V2.0!

**Note!**

Function only possible for servo control!

If required, the field weakening mode can be switched on in [C00093](#) for synchronous machines.




- When field weakening is switched on, the motor magnetising current is increased from 0 A to the maximally effective magnetising current via an internal control loop when the voltage limit is reached.
- As a result, a higher speed can be reached at the same motor voltage or DC-bus voltage.

[5-28] Voltage/speed characteristic with switched-on field weakening

$$n_{\max} = n_{\text{nenn_mot}} \cdot \frac{800\text{V}}{\sqrt{2} \cdot U_{\text{nenn_mot}}}$$

[5-29] Calculation of the maximally reachable speed with switched-on field weakening



[5-30] Speed/torque characteristics of a synchronous servo motor with field weakening

-
- The maximally effective motor magnetising current is calculated based on the motor data set in C00084 to C00091. Then the calculated value is internally limited to 98 % of the maximum current set in [C00022](#).
 - When field weakening is switched on, the actually used maximum effective motor magnetising current is shown in [C00092](#), if field weakening is switched off, "0 A" are displayed, as before.

**Note!****If a Lenze motor is used:**

The controller is parameterised automatically so that the field weakening works optimally and there is no danger to the devices.

**Stop!****If an OEM motor is used:**

If pulse inhibit is set in the controller, the DC bus is loaded with the voltage that corresponds to the current speed of the machine.

Since with switched-on field weakening higher speeds can be achieved at a correspondingly higher rotor voltage of the motor, the DC bus can be loaded to a voltage higher than the set DC-bus voltage in case of pulse inhibit and a currently high motor speed and even exceed the maximally permissible voltage of 800 V!


In order to protect the device, either use a brake chopper, or parameterise the speed monitoring via [C00596](#) and [C00607](#), so that only a maximum motor speed is possible that could also be reached with $V_{dc-bus} = 800 \text{ V}$ without field weakening.

▶ [Maximum motor speed](#) (📖 127)

Example: Voltage increase in the DC bus when field weakening is switched off

(For instance by an active setting of the controller inhibit or by tripping a fault or error at high motor speed.)

Field weakening	Speed n	Motor voltage peak value
Switched off	4000 rpm	560 V
	5700 rpm	800 V
	6000 rpm	840 V
Switched on	6000 rpm	560 V



- If pulse inhibit occurs at 6000 rpm and switched-on field weakening, the DC bus is loaded to more than 800 V (❶).
- A speed limitation to 5700 rpm is required since this speed causes a DC-bus voltage of 800 V if field weakening is switched off.

[5-31] Example: Possible DC-bus voltage > 800 V if field weakening gets lost

5.8.3 Flying restart function

This function is available from software version V3.0!



Note!

Function only possible for V/f control or sensorless vector control!

In the case of V/f control or sensorless vector control, the current motor speed is only provided to the controller if the motor control is active. However, if the controller is enabled, one cannot always assume that the drive is at standstill. The drive for example may still coast down, or be further operated by a load. It cannot always be assumed that fans are at standstill if the controller is enabled, e. g. if the fan impeller is further driven by an air flow in an undefined direction.

If the flying restart mode is activated in [C00990](#), after controller inhibit is deactivated (or DC-injection braking is cancelled), a flying restart process is automatically started to determine the current motor speed if the following conditions are met:

- V/f control or sensorless vector control are selected as motor control in [C00006](#).
- The position control structure is set to "Phase controller is active" in [C02570](#).
- The *MI_bFlyingSyncBlocked* control input of the motor interface is not assigned or set to FALSE.
- The holding brake, if available, is not applied.



Stop!

If the flying restart function is deactivated and the controller is not enabled at standstill, the output voltage and output frequency does not match the current motor speed. High compensation currents may flow!

- The drive is first braked towards 0 Hz and is then accelerated again!
- This may cause the following error messages:
 - Controller: Overload during acceleration phases (fault)
 - Device utilisation $I_{xt} > C00123$ (warning)
 - Device utilisation $I_{xt} > 100\%$ (fault)
 - Motor load $I^2_{xt} > C00127$ (warning)
 - Motor load $I^2_{xt} > C00120$ (error)
 - Overcurrent detected (fault)
 - Overvoltage in DC bus (trouble)




Note!

The flying restart algorithm requires the motor voltage as exact as possible. Therefore it is absolutely necessary to predetermine the inverter error characteristic. ▶ [Optimising the switching performance of the inverter](#) (□ 138)

In addition to the exact motor voltage, the stator resistance must also be known exactly. If the flying restart function should not work as required, slightly adjust the setting of the stator resistance in [C00084](#).

Procedure



- A. Initial situation: basic function "Speed follower" is enabled and active.
- B. The controller is inhibited while the drive is not at standstill.
- C. The motor coasts down (torqueless).
- D. The controller inhibit is deactivated again.
- E. The flying restart process starts.

[5-32] Process example: Speed follower is active → Controller inhibit → Controller enable

Flying restart process

The controller calculates the output frequency required for the momentary speed of the coasting motor, then connects to the system, and accelerates the motor to the defined setpoint again.

- The flying restart process serves to prevent the motor from decelerating to zero speed with subsequent acceleration.
- The currently detected flying restart speed is provided to the application via the current motor speed $MI_dnActualMotorSpeed_s$.

Parameter setting

- The flying restart algorithm injects a current into the motor to identify the current speed. This flying restart current can be parameterised in [C00991](#) in [%] relating to the rated motor current.
 - The higher the current, the higher the torque acting on the motor.
 - In case of a too low current, a wrong speed can be detected.
- The starting frequency of the flying restart algorithm can be set in [C00992](#).
 - If it is predictable at which frequency the motor can be restarted on the fly, set this frequency here.
- The integration time of the phase controller is set in [C00993](#).
 - The Lenze setting "60 ms" is adapted for machines with a medium power (45 kW).
 - A guide value for the integration time can be calculated with the following equation as a function of the motor power ([C00081](#)):

$$T_i = 1.1 \frac{\mu\text{s}}{\text{W}} \cdot \text{Motor power (C00081)} + 9.4 \text{ ms}$$

- For accelerating the flying restart process, this guide value can be reduced.
- If the flying restart frequency (*Frequency.dnActualRotatingFieldFrequency*) oscillates too much, the integration time has to be increased again.
- A longer integration time increases the time for "catching" the drive.
- To avoid starting a flying restart process at short-time controller inhibit, a time can be set in [C00995](#) for the minimum active controller inhibit time.
 - Since a pulse inhibit > 500 ms causes a controller inhibit, this also applies to the pulse inhibit.

Short overview: Parameters for flying restart process

Parameters	Info	Lenze setting	
		Value	Unit
C00990	Flying restart: Activation	Off	
C00991	Flying restart: Current	15	%
C00992	Flying restart circuit: start frequency	20.0	Hz
C00993	Flying restart: Integration time	60	ms
C00994	Flying restart: Min. deviation	5.00	°
C00995	Flying restart: Delay time	0	ms

5.8.4 DC-injection braking

This function is available from software version V3.0!



Note!

Function only possible for V/f control or sensorless vector control!

DC-injection braking can be divided into three functionalities:

Manual DC-injection braking

Braking can be activated and deactivated via the internal interface `QSP_bActivateDCBrake` of the basic function "[Quick stop](#)".



Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Quick stop](#)":

▶ [DC-injection braking](#)". (📖 397)

DC-injection braking instead of quick stop

If DC-injection braking is activated in [C00976](#) instead of quick stop, DC-injection braking is executed automatically when quick stop is activated.



Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Quick stop](#)":

▶ [DC-injection braking when quick stop is activated](#)". (📖 399)

Automatic DC-injection braking

This functionality is part of the basic function "[Brake control](#)".

If mode 22 has been selected for the brake control in [C02580](#), DC-injection braking is executed automatically if the current speed setpoint falls below the speed threshold set in [C02581](#).



Tip!

A detailed description of this functionality can be found in the main chapter "Basic drive functions", subchapter "[Brake control](#)":

▶ [Mode 22: Automatic DC-injection braking](#)". (📖 397)

Short overview: Parameters for DC-injection braking


Parameters	Info	Lenze setting	
		Value	Unit
C00974	DC brakes: Current	0.00	A
C00975	DC brakes Current for quick stop	0.00	A
C00976	DC brake: Activat. by quick stop	Off	

5 Motor interface

5.9 Monitoring

5.9 Monitoring

5.9.1 Signal flow



[5-33] Signal flow of motor interface (monitoring)

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ([585](#))

No.	Variable of the motor control	Meaning
(15)	Voltage.dnActualDCBusVoltage	Current DC-bus voltage
(16)	Current.dnActualCurrentPhaseU	Actual motor current (phase U)
(17)	Current.dnActualCurrentPhaseV	Actual motor current (phase V)
(18)	Current.dnActualCurrentPhaseW	Actual motor current (phase W)

5.9.2 Motor monitoring (I²xt)

The "Servo Drives 9400" are provided with an extended, sensorless thermal I²xt motor monitoring function which is based on a mathematical model that calculates a thermal motor utilisation from the detected motor currents.

- The calculation considers the speed dependency of the torque (difference between standstill torque and rated torque).
- [C00066](#) indicates the calculated motor utilisation in [%].
- If the motor utilisation exceeds the advance warning threshold set in [C00127](#), the error message "I2t motor overload OC8" is output and the response (default setting: "Warning") set in [C00606](#) is activated..
- If the switch-off threshold set in [C00120](#) is exceeded, the error message "I2t motor overload OC6" is output and the "Fault" response is activated.
- **From software version V11.0:**
After mains switching, the thermal model of the I²xt motor monitoring is initialised with the starting value initialised in [C01197](#).



Stop!

The I²xt motor monitoring function is no full motor protection!

Since the motor utilisation calculated in the thermal model gets lost after mains switching, the following operating states cannot be determined correctly:

- Restarting (after mains switching) of a motor that is already very hot.
- Change of the cooling conditions (e.g. cooling air flow interrupted or too warm).

Full motor protection requires additional measures such as the evaluation of temperature sensors that are located directly in the winding or the use of thermal contacts.




Note!

The result of the calculated thermal motor utilisation may be too low for quick traversing cycles (so-called pick-and-place applications) which include acceleration and deceleration times of less than 100 ms during overload operation of the motor (often used: linear motor).

Structure of the I²t monitoring

The introduction of a two-component model with two time constants (one for the winding and the other for the housing/laminated core) serves to display the thermal behaviour of the motor up to 500% of the rated current:



[5-34] Structure of the motor monitoring

Parameters		setting
$I_{\text{act motor}}$	Actual motor current	C00054
$I_{\text{perm motor (n)}}$	Permissible motor current (speed-dependent)	-
τ_1	Therm. time constant coil	C00128/1
k_1	Percentage of the winding in the final temperature	C01195
τ_2	Therm. time constant plates	C00128/2
k_2	Percentage of the steel plates in the final temperature	100 % - C01195

Calculation with only one time constant

With [C01195](#) = "0 %" the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/laminated core.

- The setting [C01195](#) = "0 %" is reasonable if for example the two time constants are not known.
- The calculation simplified due to this setting corresponds to the calculation in the previous Lenze devices (e.g. 9300 servo inverter or ECS).

Speed-dependent evaluation of the motor current

By selecting a characteristic in [C01196/1...8](#) the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation.

Parameters	Characteristic	point
C01196/1	n_1/n_n	Speed = "0" (standstill)
C01196/2	I_1/I_n	Permissible motor current at standstill
C01196/3	n_2/n_n	Speed from which the torque must be reduced for self-ventilated motors. • Below this speed the cooling air flow of the integral fan is not sufficient anymore.
C01196/4	I_2/I_n	Permissible motor current at speed n_2 (torque reduction)
C01196/5	n_3/n_n	Rated speed
C01196/6	I_3/I_n	Permissible motor current at rated speed
C01196/7	n_4/n_n	Speed above the rated speed (in the field weakening range for asynchronous motors)
C01196/8	I_4/I_n	Permissible motor current at speed n_4 (field weakening)

- The speed-dependent evaluation can be more or less switched off by setting [C01196/1...8](#) to "100 %" each. The calculation simplified due to this setting corresponds to the calculation in previous Lenze devices (e.g. 9300 servo inverter or ECS).



Note!

Self-ventilated standard motors are protected insufficiently at low speeds by setting [C01196/1...8](#) to "100 %" each.

Servo motors, however, do not have a point from which the torque must be reduced due to a too low speed.

- When setting the characteristic in [C01196/1...8](#) this point must not be ignored. Hence, point 2 is to be set ideally to point 1 or point 3.

5 Motor interface


5.9 Monitoring

5.9.2.1 Example for entry of the characteristic for asynchronous servo motor

Motor type: MDFMARS 090-32

Data from the catalogue:

- Rated speed n_{rated} : 1410 rpm → Setting in [C00087](#)
- Rated current I: 6.1 A → Setting in [C00088](#)
- Rated torque M_{rated} : 10.2 Nm
- Characteristic of maximum torques (50 Hz, star connection):



[5-35] Torque/speed characteristic for motor type MDFMARS 090-32 from catalogue



Note!

At present, relative current values are still expected for the specification of the interpolation points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values, the entry of which shall be possible at a later date.


Parameters	setting	Info
C00128/1	1.0 min	Thermal time constant - winding • Is unknown and is therefore deactivated by setting C01195 = "0 %".
C00128/2	5.0 min	Thermal time constant - laminated core/housing
C01195	0 %	Percentage of the winding in the final temperature.
C01196/1	0 %	Speed = "0" (standstill)
C01196/2	Permissible motor torque at standstill	
Self-ventilated:	60 %	= 6.1 Nm / 10.2 Nm * 100 %
Forced-ventilated:	100 %	= 10.2 Nm / 10.2 Nm * 100 %
C01196/3	Speed n_2 from which the torque must be reduced for self-ventilated motors.	
Self-ventilated:	43 %	= 600 rpm / 1410 rpm * 100 %
Forced-ventilated:	0 %	No torque reduction required.
C01196/4	100 %	Permissible motor torque at speed n_2 (torque reduction)
C01196/5	100 %	Rated speed (\equiv 1410 rpm)
C01196/6	100 %	Permissible motor torque at rated speed (\equiv 10.2 Nm)
C01196/7	213 %	Speed above the rated speed (in the field weakening range for asynchronous motors) = 3000 rpm / 1410 rpm * 100 %
C01196/8	44 %	Permissible motor torque at speed n_4 (field weakening) = 4.5 Nm / 10.2 Nm * 100 %

5.9.2.2 Example for entry of the characteristic for synchronous servo motor

Motor type: MCS 06C60

Data from the catalogue:

- Rated speed n_{rated} : 6000 rpm → Setting in [C00087](#)
- Rated current I: 2.4 A → Setting in [C00088](#)
- Rated torque M_N : 0.5 Nm (in S1 operation: 0.55 Nm)
- Characteristic - maximum torques:



[5-36] Torque/speed characteristic for motor type MCS 06C60 from the catalogue



Note!

At present, relative current values are still expected for the specification of the interpolation points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values, the entry of which shall be possible at a later date.

Parameters	setting	Info
C00128/1	1.0 min	Thermal time constant - winding
C00128/2	14.2 min	Thermal time constant - laminated core/housing
C01195	27 %	Percentage of the winding in the final temperature. (Only the laminated core percentage is known.)
C01196/1	0 %	Speed = "0" (standstill)
C01196/2	160 %	Permissible motor torque at standstill = 0.8 Nm / 0.5 Nm * 100 %
C01196/3	0 %	Speed n_2 from which the torque must be reduced for self-ventilated motors.
C01196/4	160 %	Permissible motor torque at speed n_2 (torque reduction)
C01196/5	100 %	Rated speed (\equiv 6000 rpm)
C01196/6	100 %	Permissible motor torque at rated speed (\equiv 0.5 Nm)
C01196/7	100 %	Speed above rated speed
C01196/8	100 %	Permissible motor torque at speed n_4 (field weakening)

5.9.2.3 UL 508-compliant I²x motor temperature monitoring

The following test steps 1 ... 3 are part of the UL 508C-compliant device acceptance. They have to be executed successfully during the I²x motor monitoring.

Test step 1

- Motor overload: $6 \times I_{\text{rated,mot}}$ ($I_{\text{rated,mot}}$: Rated motor current ([C00088](#)))
- Trigger time: Max. 20 s after the overload has occurred

Code	setting	Info
C00128/2	≤ 11.8 min	Thermal time constant - laminated core/housing
C01195	0 %	Percentage of the winding in the final temperature
C00120	100 %	Switch-off threshold of motor overload protection (I ² x)

Test step 2

- Motor overload: $1,1 \times I_{\text{rated,mot}}$ ($I_{\text{rated,mot}}$: Rated motor current ([C00088](#)))
- In case of a motor field frequency of 10 Hz, the I²x motor monitoring has to be tripped faster than with a motor field frequency of 20 Hz.

Code	setting	Info
C01196/1	0 %	Speed = 0 (standstill)
C01196/2	< 100 %	Permissible motor torque at standstill
C01196/3	$(20 \text{ Hz} / \text{C00089}) * 100 \%$	Speed n_2 from which on the torque must be reduced
C01196/4	100 %	Permissible motor torque at speed n_2 (torque reduction)

Test step 3

- After mains switching and a motor load > 100 % of the (motor current ([C00054](#)) > rated motor current ([C00088](#)), I²x motor monitoring must be tripped faster than before mains switching with the same overload.
- From software version V11.0:
Initial value of the thermal model of the I²x motor monitoring: [C01197](#) > 0 %.

Example for a UL 508C-compliant total parameterisation of the I²xT motor monitoring of the device:

Code	setting	Info
C00120	100 %	Switch-off threshold of motor overload protection (I ² xT)
C00128/2	≤ 11.8 min	Thermal time constant - laminated core/housing
C01195	0 %	Percentage of the winding in the final temperature
C01196/1	0 %	Speed = 0 (standstill)
C01196/2	< 100 %	Permissible motor torque at standstill
C01196/3	(20 Hz / C00089) * 100 %	Speed n ₂ from which on the torque must be reduced
C01196/4	100 %	Permissible motor torque at speed n ₂ (torque reduction)
C01196/5	100 %	Rated speed
C01196/6	100 %	Permissible motor torque at rated speed
C01196/7	100 %	Rated speed
C01196/8	100 %	Speed above rated speed
C01197	> 0 %	Initial value of the thermal model of the I ² xT motor monitoring

5.9.3 Motor temperature monitoring

If the winding temperature detected by the motor temperature sensor exceeds the limit value set in [C00121](#), the response set in [C00584](#) is activated as advance warning.

- In the Lenze setting the "Warning" response occurs if the winding temperature exceeds 120 °C.
- As soon as the fixed limit value of 150 °C is exceeded, the response set in [C00583](#) is activated (default setting: "Fault").
- If an open circuit is detected in the motor temperature sensor, the response set in [C00594](#) (default setting: "Fault") is activated.



Note!

By setting [C00583](#) = "0" the monitoring response and the temperature correction is switched off within the motor control (identification and parameter correction)

This setting for example is reasonable if no usable winding temperature signal is available.




Tip!

The winding temperature currently detected by the motor temperature sensor is displayed in [C00063](#).

5.9.3.1 Specific characteristic for the motor temperature sensor

If required, you can define and activate a special characteristic for the motor temperature sensor.

- The specific characteristic is defined on the basis of two grid points which must be set in [C01191](#) and [C01192](#). Those two points define a line which is extrapolated to the right and to the left.
- The special characteristic is activated by setting [C01190](#) = "1".
- In the Lenze setting, the specific characteristic is defined as follows:



[5-37] Lenze setting of the special characteristic

- Interpolation point ❶
 - [C01191/1](#) = 25 °C
 - [C01192/1](#) = 1000 Ω
- Interpolation point ❷
 - [C01191/2](#) = 150 °C
 - [C01192/2](#) = 2225 Ω



Note!

- If a motor is selected from the motor catalogue, parameters [C01190](#), [C01191](#), and [C01192](#) are overwritten!
- If the controller measures a resistance below 122 Ω, this is interpreted as a sensor error and a temperature of 255 °C is output.

The following applies from software version V4.0:

- Sometimes a short circuit is a desired state (e.g. temperature contact closed below 140 °C). For this purpose, the interpolation point 1 ([C01191/1](#)) must be below 122 Ω to prevent the triggering of sensor errors. In this case the temperature continues to be calculated.

5.9.3.2 Motor temperature monitoring (PTC)

For detecting and monitoring of the motor temperature, a PTC thermistor (DIN 44081/DIN 44082) or a thermal contact (NC contact) can be connected to the terminals X106/T1 and X106/T2.



Stop!

- This monitoring is only active if the controller is supplied via the line side, i.e. if the DC-bus voltage (U_z) > undervoltage threshold (LU).
- The controller can only evaluate one PTC thermistor!
Do not connect several PTC thermistors in series or parallel.
- If several motors are operated on one controller, use thermal contacts (NC contacts) connected in series.
- To achieve full motor protection, an additional temperature monitoring with separate evaluation must be installed.



Note!

- In the Lenze setting ([C00585](#) = "0: No response"), motor temperature monitoring is deactivated!
- Lenze three-phase AC motors are provided with a thermal contact on delivery.

- The monitoring responds from a resistance value of 1.6 k Ω at connections X106/T1 and X106/T2, see functional test below.
- If the monitoring responds:
 - The error response set in [C00585](#) is activated (Lenze setting: "No response").
 - the error message "PTC has triggered" (0x0077000f) is entered into the logbook of the controller.
 - the status output *MI_bMotorOverloadWarning* is set to TRUE.



Tip!

We recommend to always activate the PTC input when using motors which are equipped with PTC thermistors or thermostats. This prevents the motor from being destroyed by overheating.

Functional test

Connect a fixed resistor to the PTC input:

- $R > 4 \text{ k}\Omega$: Fault message must be activated.
- $R < 1 \text{ k}\Omega$: Fault message must not be activated.

5.9.3.3 Temperature monitoring of a second motor

[This function is available from software version V7.0!](#)

From software version V7.0 onwards, two motor temperature sensors can be evaluated simultaneously via the two encoder inputs X7 and X8 when two motor are used (e.g. double motor for a storage and retrieval unit). For this purpose, the selection "X7 and X8 in parallel" must be set as feedback system for the motor temperature in [C01193](#).

- In this case, always the higher temperature of the two detected temperatures is displayed as the current motor temperature on the **Diagnostics** tab and in [C00063](#).
- Moreover, the following display parameters are available from software version V6.0 onwards:
 - [C01200/1](#): Motor temperature via X7
 - [C01200/2](#): Motor temperature via X8
- If one of the two detected temperatures exceeds the limit value set in [C00121](#), the response set in [C00584](#) is activated as advance warning.
 - In the Lenze setting the "Warning" response occurs if one of the two winding temperature exceeds 120 °C.
- As soon as one of the two detected temperatures exceeds the fixed limit value of 150 °C, the response set in [C00583](#) is activated (default setting: "Fault").
- If an open circuit is detected in one of the two motor temperature sensors, the response set in [C00594](#) (default setting: "Fault") is activated.
- It is not possible to set different responses for the two temperature monitoring modes.
- For the motor model in the controller, the mean value of both detected temperatures is used.

Related topics:

- ▶ [Brake control](#) ▶ [Control of two motor holding brakes](#) (📄 556)

5.9.4 Motor phase failure monitoring

5.9.4.1 Monitoring of the individual motor phases during operation

Failure of one motor phase during operation

If a current-carrying motor phase (U, V, W) fails during operation, the response set in [C00597](#) is executed (Lenze setting: "No response") if two conditions are fulfilled:

- Condition 1: Monitoring is activated

To safely detect a motor phase failure, a certain motor current must flow for the current sensor system.

- Monitoring will therefore only be activated if, in the case of servo control the setpoint of the motor current, and in the case of sensorless vector control or V/f control the actual value motor current (display in [C00054](#)) has exceeded a certain current value.
- The current value for the activation can be set in [C00599](#) in [%] with regard to the maximum device current (display in [C00789](#)).
- Condition 2: A specific commutation angle was covered without the detection of a current flow.

In this case monitoring works according to the principle of checking for each motor phase that a current flows depending on the commutation angle.

- Monitoring responds if a rotating field is output and hence a specific commutation angle (approx. 150°, electric) is covered without the current having exceeded a (non-parameterisable) threshold that depends on the device power.



Note!

- In case of sensorless vector control or V/f control, the safe detection of a motor phase failure is only carried out if the actual current has exceeded the 3.5-fold value of the threshold parameterised in [C00599](#).
- The dependence on the commutation angle also causes a dependence on the motor type used:
 - The commutation angle and the angle at the shaft (number of pole pairs) of a synchronous machine are proportional. This makes it possible to predict which shaft angle is maximally covered in case of error.
 - An asynchronous machine has an additional slip between the commutation angle and the angle on the shaft. This results in a load dependency due to which it is impossible to predict the maximally covered shaft angle in the event of a fault. In certain applications (e.g. hoists during lowering operation at non-zero speeds) it may be possible that a rotating field is no longer applied. Instead, a DC current flows. In this case, condition 2 is no longer met.

Failure of multiple motor phases during operation

This function is available from software version V10.0!

The following operating modes enable the detection of multiple motor phases during operation:

- VFCplus: V/f control closed loop
- SLVC: sensorless vector control

The monitoring for failure of multiple motor phases is *active* if

1. [C00597](#) is set to a response other than "No response" (Lenze setting) and
2. the motor voltage exceeds the threshold value parameterised in [C02867](#).

The "Motor disconnected" fault message is issued if the motor current is lower than the device-dependent threshold value for > 20 ms.

The monitoring for failure of multiple motor phases can be *deactivated* if a value of 1000.0 V is parameterised in [C02867](#).

5.9.4.2 Checking the individual motor phases before operation is started

This function is available from software version V5.0!

From software version V5.0 a check via test signal application has been added. It injects a current into the machine before the actual operation is started, by means of which both a motor phase failure and the existence of the motor are checked. Only after the check has been carried out successfully, the actual operation is continued.

- The setpoint current amplitude corresponds to the lower of the two following values:

$$50\% \cdot \sqrt{2} \cdot \text{Rated device current}$$

or

$$50\% \cdot \sqrt{2} \cdot \text{Rated motor current}$$

- The test signal application is activated directly after controller enable if the following conditions are fulfilled:
 - In [C00597](#) a response other than "No response" is set.
 - No test mode is activated ([C00398](#) = 0).
 - No identification procedure is active (by device command [C00002](#) = "51", "52", "71" or "72").
- The check actuates the response set in [C00597](#) if one or more motor phase currents have not reached a certain threshold value within 5 ms after controller enable.
 - The threshold value depends on the device power and cannot be parameterised.
 - If only one motor phase current does not reach the threshold value, "Motor phase U/V/W not available" is entered in the logbook.
 - If several motor phases do not reach the threshold value, the motor is considered as not connected, and "Motor not connected" is entered in the logbook.
- The check is completed successfully if all three motor phase currents have exceeded the threshold value. Then the actual operation is continued immediately.



Note!

- As the check is cancelled immediately if all three motor phase currents have exceeded the threshold value, the setpoint current usually is not achieved.
- In order to be able to achieve the threshold value used for the check, the rated motor current must at least be 10 % of the maximum device current (display in [C00789](#)).
- This monitoring is independent of the further rotation of the commutation angle.

5.9.4.3 Limits of motor phase failure monitoring

Motor phase failure monitoring can be activated for both synchronous and asynchronous motors. However, it is possible that a current flow cannot be detected for sure in the case of certain operating statuses of correctly connected synchronous motors. Hence, a fault is triggered.

The following table provides an overview:

Operating status		Synchronous motor	Asynchronous motor
Check of the motor phases <u>prior to operation</u>		ž	ž
Check of the motor phases <u>during operation</u>			
• $I_q < C00599$	at standstill	<input type="checkbox"/>	<input checked="" type="checkbox"/>
	when motor is rotating	<input type="checkbox"/>	<input checked="" type="checkbox"/>
• $I_q \geq C00599$	at standstill	<input type="checkbox"/>	<input checked="" type="checkbox"/>
	when motor is rotating	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Explanation	
<input checked="" type="checkbox"/>	Phase failure is detected for sure.
<input type="checkbox"/>	Phase failure detection may trip without a fault pending.
I_q	Torque-forming current component

Special case: Hoist

The special case "Hoist" is already referred to in the chapter

▶ [Monitoring of the individual motor phases during operation](#) (📖 229)

Motor phase failure monitoring may trigger a fault message in a hoist if the applied asynchronous motor reaches the following working point:

- The hoist moves downwards, i.e. the motor is in generator mode.
- The slip frequency equals the field frequency in terms of amount. Both frequencies mutually neutralise themselves due to their opposite effective directions.

5.9.5 Maximum current monitoring

The ultimate motor current I_{ULT} to be parameterised in [C00620](#) is a limit value to protect the motor from destruction or influence of the rated data.

- This limit value must not be travelled cyclically in the drive process.
- The maximum current parameterisable in [C00022](#) should have a sufficient distance from this limit value.
- If the instantaneous value of the motor current exceeds the limit value set in [C00620](#) the response set in [C00619](#) is executed for motor protection (Lenze setting: Fault).



Note!


When you select a Lenze motor from the catalogue and transfer the plant parameters of the motor to the controller, the setting in [C00620](#) is automatically adjusted to the selected motor.

5 Motor interface

5.10 Internal interfaces | "LS_MotorInterface" system block

5.10 Internal interfaces | "LS_MotorInterface" system block

The **LS_MotorInterface** system block provides the internal interfaces to the driving machine, consisting of the phase controller, speed controller, and motor control in the function block editor.



Note!

All input and output signals of the motor interface directly refer to the motor!

Inputs

Identifier DIS code data type	Information/possible settings
MI_dnPosCtrlAdaptLoad_n C02568/1 DINT	Dynamic change of the proportional gain V_p of the position controller during operation <ul style="list-style-type: none"> For software versions lower than V5.0 the following applies: Internal limitation to 10 ... 200 % From software version V5.0 the following applies: Internal limitation to 0 ... 200 %
MI_dnPosCtrlAdaptMotor_n C02568/2 DINT	Dynamic change of the proportional gain V_p of the phase controller during operation <ul style="list-style-type: none"> For software versions lower than V5.0 the following applies: Internal limitation to 10 ... 200 % From software version V5.0 the following applies: Internal limitation to 0 ... 200 %
MI_dnSpeedCtrlAdapt_n C02568/3 DINT	Dynamic change of the proportional gain V_p of the speed controller during operation <ul style="list-style-type: none"> If the input is assigned, the following applies: $V_p = MI_dnSpeedCtrlAdapt_n [\%] * C00070$ If the input is not assigned, the following applies: $V_p = 100 \% * C00070 = C00070$ Internal limitation to 10 ... 200 % ► Optimising the speed controller (150)
MI_bResetSpeedCtrlIntegrator C02569/2 BOOL	Reset integral action component in the speed controller TRUE Integral action component is reset to "0".
MI_dnTorqueHighLimit_n C02568/4 DINT MI_dnTorqueLowLimit_n C02568/5 DINT	Upper/lower limit value for correcting variable of the speed controller and total torque setpoint <ul style="list-style-type: none"> These two inputs serve to select an external torque limitation. If the motor torque reaches the selected limits, the drive can no longer follow the speed setpoint! If the torque limitation is active, the output <i>MI_bTorqueSetpointLimited</i> is set to TRUE. 100 % \equiv C00057/2 Only a positive torque is permissible as upper limit value. Only a negative torque is permissible as lower limit value. The motor mounting position (C02527) defines the assignment to the limitation inputs of the motor control. The internally effective torque limit values are displayed in C02559/1...2.
MI_dnFluxSetpoint_n C02568/7 DINT	Setpoint for the field controller
MI_dnInertiaAdapt_n C02568/8 DINT	Adaptation of the moment of inertia in [%] <ul style="list-style-type: none"> If input is not assigned = 100 % Internal limitation to 0 ... 200 %
MI_dnBoostSet_n C02568/9 DINT From V3.0	Boost voltage <ul style="list-style-type: none"> 100 % \equiv 1000 V
MI_bFlyingSyncBlocked C02569/16 BOOL From V3.0	Block flying restart ► Flying restart function (212)
	FALSE Flying restart function is active
	TRUE Flying restart process is blocked.

Identifier DIS code data type	Information/possible settings
MI_dnTorqueAdd_n C02568/10 DINT From V8.0	<p>Additional torque feedforward control value in [%]</p> <p>This input serves to provide an additional torque setpoint. In this way, you can provide an additional torque for the basic functions manual jog, positioning and homing besides the acceleration feedforward control.</p> <ul style="list-style-type: none"> • 100 % = motor reference torque <p>If the controller is enabled, the torque setpoints at this input have a direct effect on the drive!</p> <p>The user has to</p> <ul style="list-style-type: none"> • apply the appropriate setpoint for every state of the drive. • avoid setpoint step-changes.
	- 200 %
	+ 200 %

Outputs

Identifier DIS code data type	Value/meaning
MI_dwControlMode DWORD	<p>Active control structure of the motor control</p> <ul style="list-style-type: none"> • Displayed value is bit-coded:
	Bit 0 Encoderless motor control
	Bit 1 Position control (Setpoint from setpoint position)
	Bit 2 Position control (Setpoint from integrated setpoint speed)
	Bit 3 closed-loop speed control
	Bit 4 Closed-loop torque control
MI_bMotorOrientationInverse BOOL	<p>Parameterised motor mounting position</p>
	FALSE Motor mounting position in the same direction, setpoints are not defined.
	TRUE Motor mounting position in the opposite direction, setpoints are reversed.
MI_dwReferenceSpeed DWORD	Parameterised motor reference speed (C00011) in [rpm]
MI_dwReferenceTorque DWORD	<p>Reachable motor torque with I_{max_device} (C00022) in [mNm]</p> <ul style="list-style-type: none"> • 1000 mNm \equiv 1 Nm • Display in C00057/2 in [Nm]
MI_bLimitationActive C02569/3 BOOL	<p>Status signal "Internal limitation active"</p> <ul style="list-style-type: none"> • Group signal for all limitation messages.
	TRUE One of the internal limitations is active.
MI_bPosCtrlLimited C02569/4 BOOL	<p>Status signal "Phase/position controller at the limit"</p>
	TRUE The limitation of the phase and/or position controller is active.
MI_bSpeedSetPointLimited C02569/5 BOOL	<p>Status signal "Resulting speed setpoint at the limit"</p>
	TRUE The resulting speed setpoint is limited to the limit values parameterised in C00909/1 and C00909/2 .
MI_dnSpeedSetpoint_n DINT	<p>Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [%]</p> <ul style="list-style-type: none"> • After limitation by the upper speed limit value (C00909/1) and lower speed limit value (C00909/2). • 100 % \equiv Motor reference speed (C00011)
MI_dnSpeedSetpoint_s DINT	<p>Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [rpm]</p> <ul style="list-style-type: none"> • After limitation by the upper speed limit value (C00909/1) and lower speed limit value (C00909/2).

Identifier <small>DIS code data type</small>	Value/meaning
MI_bSpeedFollowingError <small>C02569/10 BOOL</small>	Status signal "Impermissible speed control deviation"
	TRUE Speed control deviation is higher than the window set in C00576 .
MI_bSpeedCtrlLimited <small>C02569/6 BOOL</small>	Status signal "Speed controller at the limit"
	TRUE The speed controller limitation is active.
MI_bTorqueSetpointLimited <small>C02569/7 BOOL</small>	Status signal "Total torque setpoint at the limit"
	TRUE The total torque setpoint is limited.
MI_dnTorqueSetpoint_n <small>DINT</small>	Current torque setpoint from speed control and torque feedforward control or direct setpoint selection <ul style="list-style-type: none"> • After limitation by <i>MI_dnTorqueLimit_n</i>. • 100 % = C00057/2
MI_dnFilteredTorqueSetpoint_n <small>DINT</small>	Filtered torque setpoint (after jerk limitation and band-stop filters) <ul style="list-style-type: none"> • 100 % = C00057/2
MI_bCurrentSetpointLimited <small>C02569/8 BOOL</small>	Status signal "Setpoint for current controller at the limit"
	TRUE The setpoint for the current controller is limited to I_{\max_device} (C00022).
MI_bMotorOverloadWarning <small>C02569/11 BOOL</small>	Status signal "Motor overload" <ul style="list-style-type: none"> • Group signal for warning signals from temperature monitoring (KTY, PTC, thermal switch) or I^2xt monitoring.
	TRUE One of the monitoring modes for motor overload protection is active.
MI_bSpeedBelowThresholdC19 <small>C02569/9 BOOL</small>	Status signal "Standstill reached"
	TRUE The current speed is below the threshold set in C00019 .
MI_dnActualMotorCurrent_n <small>DINT</small>	Actual motor current <ul style="list-style-type: none"> • 100 % = I_{\max_device} (C00789) • Display in C00780 in [A]
MI_dnActualMotorVoltage_n <small>DINT</small>	Current motor voltage <ul style="list-style-type: none"> • 100 % = 1000 V • Display in C00783 in [V]
MI_dnActualMotorTorque_n <small>DINT</small>	Current motor torque <ul style="list-style-type: none"> • 100 % = C00057/2 • Display in C00774 in [Nm]
MI_dnActualMotorSpeed_n <small>DINT</small>	Current speed of the motor shaft in [%] <ul style="list-style-type: none"> • 100 % = Motor reference speed (C00011)
MI_dnActualMotorSpeed_s <small>DINT</small>	Current speed of the motor shaft in [rpm] <ul style="list-style-type: none"> • Display in C00772
MI_dnActualMotorPos_p <small>DINT</small>	Current position of the motor shaft in [increments] <ul style="list-style-type: none"> • Display in C00770
MI_dnActualDCBusVoltage_n <small>DINT</small>	Current DC-bus voltage <ul style="list-style-type: none"> • 100 % = 1000 V
MI_dnThermalLoadDevice_n <small>DINT</small>	Thermal device utilisation in [%] <ul style="list-style-type: none"> • Current result of the Ixt calculation. • Display in C00064 ▶ Monitoring of the device utilisation (□ 111)
MI_dnThermalLoadMotor_n <small>DINT</small>	Thermal motor utilisation in [%] <ul style="list-style-type: none"> • Current result of the I^2xt calculation. • Display in C00066 ▶ Motor monitoring (I^2xt) (□ 218)
MI_dnActualMotorFreq_s <small>DINT</small> <small>From V3.0</small>	Current motor frequency in [Hz] The motor frequency corresponds to the field frequency [Hz]. Field frequency [Hz] = motor speed × number of motor pole pairs

Identifier DIS code data type	Value/meaning
MI_dnActualFlux_n DINT From V3.0	Actual flux value
MI_bFlyingSyncBusy C02569/13 BOOL From V3.0	"Flying restart function active" status signal ▶ Flying restart function (□ 212) TRUE Flying restart function is active
MI_bClampsActive C02569/14 BOOL From V3.0	Status signal "Clamping is active" TRUE Clamping is active.
MI_bMagnetisationFinished C02569/15 BOOL From V3.0	Status signal "Motor magnetisation is completed" Note: This bit is <u>only</u> supported in the SLVC control mode (sensorless vector control). TRUE Motor magnetisation is completed.

6 Encoder evaluation

This chapter contains information on how to use feedback systems for the motor control.



Danger!

If the encoder/resolver is used as motor encoder:
In case of error, safe operation of the motor is no longer guaranteed!

When servo control is used:

- For the (open circuit) monitoring of the encoder/resolver for reasons of safety always the "Fault" response (Lenze setting) should be set!

When V/f control is used:

- For this type of motor control, the drive basically is to coast down after an encoder failure and may not stop, therefore the "Warning" response is to be set for the (open circuit) monitoring in this case!

Parameters for the (open circuit) monitoring:

- [C00580](#): Response to open circuit of encoder
- [C00586](#): Response to open circuit of resolver
- [C00601](#): Response to communication error of encoder



Note!

The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched.

With regard to their position resolution, higher-level applications are based on the resolution of the encoder which is activated for position control.

Behaviour of the home position after mains switching

If the home position/information is also to be available after mains switching, the setting [C02652](#) = "1: Received" is required.

- Another condition for keeping the home position/information after mains switching is the compliance with the maximum permissible angle of rotation of the encoder, which can be set in [C02653](#).
- When resolvers or single-turn absolute value encoders are used and the mains is switched off (24 V supply off), the encoder may only be moved by ½ revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.



Note!

A digital position encoder connected to the "LS_Feedback" system block must have a position resolution of exactly 16 bits if a safety module SM301 is used together with the safe speed detection.


See also: [▶ Parameterising motor encoder \(□ 129\)](#)

6 Encoder evaluation

6.1 Internal interfaces | "LS_Feedback" system block

6.1 Internal interfaces | "LS_Feedback" system block

The **LS_Feedback** system block provides the internal interfaces for the basic function "Encoder evaluation" in the function block editor.



Inputs

Identifier	Data type	Information/possible settings		
FDB_dnPosOffset_p	DINT	Offset for position setpoint and actual position in [increments]		
FDB_dnActPosIn_p	DINT	External actual position in [increments] <ul style="list-style-type: none"> For the selection of an external actual position with a corresponding position control. ▶ Use of an external position encoder (242)		
FDB_bResetPosFollowingError	BOOL	Input for deleting the following error <table border="1"> <tr> <td>True</td> <td>The position setpoint is equated with the actual position value.</td> </tr> </table>	True	The position setpoint is equated with the actual position value.
True	The position setpoint is equated with the actual position value.			

Outputs

Identifier	Value/meaning		
FDB_dnActualPos_p	Current position of the position encoder in [increments]		
FDB_dnActualSpeed_s	Current speed of the position encoder in [rpm]		
FDB_dnPosFollowingError_p	Current following error in [increments]		
FDB_dnSetPos_p	Set position calculated by active basic drive function in [increments] <ul style="list-style-type: none"> Considering the motor mounting position. In the case of an active speed or torque control (instead of position control) the actual position (<i>FDB_dnActualPos_p</i>) is shown at this output. 		
FDB_dnSetSpeed_s	Setpoint speed calculated by active basic drive function in [rpm] <ul style="list-style-type: none"> Considering the motor mounting position. 		
FDB_bResolverError	Status signal "Resolver error" <table border="1"> <tr> <td>TRUE</td> <td>A resolver error (e.g. open circuit) has occurred.</td> </tr> </table>	TRUE	A resolver error (e.g. open circuit) has occurred.
TRUE	A resolver error (e.g. open circuit) has occurred.		
FDB_bSinCosSignalError	Status signal "sine/cosine encoder error" <table border="1"> <tr> <td>TRUE</td> <td>A sine/cosine encoder error has occurred.</td> </tr> </table>	TRUE	A sine/cosine encoder error has occurred.
TRUE	A sine/cosine encoder error has occurred.		

6

Encoder evaluation

6.1

Internal interfaces | "LS_Feedback" system block

Identifier <small>DIS code data type</small>	Value/meaning
FDB_bEncoderComError <small>C02579/3 BOOL</small>	Status signal "Encoder communication error" TRUE An encoder communication error has occurred.
FDB_dnSetAcc_x <small>From V7.0</small> <small>DINT</small>	Setpoint acceleration calculated by active basic function <ul style="list-style-type: none"> • Considering the motor mounting position. • For the basic functions Stop, Manual jog, Homing and Positioning, the internal acceleration resulting from the profile generation is output. • For the basic functions Quick stop, Position follower and Speed follower, the acceleration from the differentiated setpoint speed is determined. C02562 serves to filter the determined acceleration. • With an active torque control or in a non-controlled operation (function states "Controller not ready" and "Error"), the value "0" is output.

6 Encoder evaluation

6.1 Internal interfaces | "LS_Feedback" system block

6.1.1 Use of an external position encoder

The *FDB_dnActPosIn_p* input serves to evaluate an external encoder (CAN, SSI, Profibus) for the position control.

- Via this input, a current actual position of an external encoder in [increments] can be directly transferred to the encoder evaluation.



How to activate the use of the external actual position:

On the **Application parameters**

tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:

1. Select the "Position controller active" setting in the **Position control structure** list field ([C02570](#)), so that the position encoder is evaluated.
2. Set "From application" in the **Position encoder selection** list field ([C00490](#)).




Note!

- Encoder inversion and offset selection *FDB_dnPositionOffset_p* also affect the external actual position.
- If the use of the external actual position preset via *FDB_dnActPosIn_p* is activated, the "Home position known" status (*HM_bHomePosAvailable* = TRUE) is automatically set and homing with the basic function "Homing" cannot be activated anymore.
- If the traversing range ([C02528](#)) is set to "Modulo", the external actual position also has to be defined as modulo (0 ... cycle-1).

6 Encoder evaluation

6.2 Signal flow

6.2 Signal flow



[6-1] Signal flow - encoder evaluation

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (585)

No.	Variable of the motor control	Meaning
(1)	Position.dnActualLoadPos	Actual position
(2)	Position.dnActualMotorPos	Current motor position
(3)	Speed.dnActualMotorSpeed	Current motor speed
(4)	Speed.dnActualEncoderSpeed	Current encoder speed
(5)	Speed.dnActualResolverSpeed	Current resolver speed

6.3 Parameter setting

Short overview of parameters for the encoder evaluation:

Parameters	Info	Lenze setting	
		Value	Unit
C00058/1	Resolver pole position	-90.0	°
C00058/2	Rotor displ. angle encoder	0.0	°
C00058/3	Module pole position	0.0	°
C00080	Number of resolver pole pairs	1	
C00416	Resolver error correction	0	
C00417	Dynamics of the resolver evaluation	100	%
C00418	Activate resolver error compensation	Deactivated	
C00420	Number of encoder increments	512	
C00421	Encoder voltage	5.0	V
C00422	Encoder type	Incremental encoder (TTL signal)	
C00423	SSI encoder: Bit rate	400	kbps
C00424	SSI encoder: Data word length	25	Bit
C00427	TTL encoder signal evaluation	4x evaluation (A, B)	
C00435/1...8	SSI encoder: Partword starting position	0	
C00436/1	SSI encoder: partword length (partword 1)	31	
C00436/2...8	SSI encoder: partword length (partwords 2...8)	0	
C00437/1...8	SSI encoder: partword coding	Binary coded	
C00490	Position encoder selection	Motor encoder	
C00495	Motor encoder selection	Resolver X7	
C00497	Speed act. val. time const.	2.0	ms
C00579	Resp. to speed monitoring	Off	
C00580	Resp. to encoder open circuit	Error	
C00586	Resp. to resolver open circuit	Error	
C00601	Resp. to encoder fault	Error	
C00621	Resp. to angular drift of encoder	No response	
C02527	Motor mounting direction	Motor rotating CW	
C02529	Position encoder mounting direction	Encoder rotating CW	
C02570	Position control structure	Phase controller is active	
C02572	Speed setpoint (enc. eval.)	-	Unit/s
C02573	Position setpoint (enc. eval.)	-	Unit
C02574	Actual speed (encoder eval.)	-	Unit/s
C02575	Actual position (enc. eval.)	-	Unit
C02576	Following error	-	Unit
C02577	External actual position	-	Unit
C02578	Offset actual pos. value/setp.	-	Unit
C02760	Activate Encoder	Deactivated	
C02761	Resolution Multiturn	-	Rev.
C02762	Encoder position	-	Steps.
C02763	Encoder position	-	Rev.
C02764	Encoder speed	-	rpm
C02765	ENC_bError	-	
C02862/1	Resolver: cos gain	100	%

Greyed out = display parameter

6 Encoder evaluation

6.3 Parameter setting

Parameters	Info	Lenze setting	
		Value	Unit
C02862/1	Resolver: sine gain	100	%
C02863	Resolver: Angle correction	0	


Greyed out = display parameter



How to get to the dialog for setting the encoder evaluation parameters:

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Select the **Application parameters** tab from the *Workspace*.
3. Click the button **All basic functions** in the *Overview* dialog level.
4. Click the button **Encoder evaluation** in the dialog level *Overview* → *All basic functions*.

Parameterisation dialog in the »Engineer«



See also: [▶ Parameterising motor encoder \(129\)](#)

6.3.1 Controller configuration

The device interfaces for the encoder on the motor side and, if available, on the load side are directly assigned to the corresponding control according to the structure of the position control selected ([C02570](#)):

	Phase control (Lenze setting)	position control
Cycle time:	250 µs	Application-dependent
Dead time:	Smaller dead time in the actual value channel	Same dead time for position setpoint and actual position
Use:	In positioning technology and single-axis applications or if only one encoder is used.	In multi-axis applications or if a position encoder is used in addition to the motor encoder.

- If only an encoder on the motor side is available, this "motor encoder" provides the actual value signals for the phase/position control and the speed control.
 - In this case both the angle control and the position control can be selected.
 - When selecting the position control, make sure that the position encoder selection "10: Motor encoder (C00495)" is set in [C00490](#). With this selection, the mounting position and the resulting gearbox factor are already considered.
 - The motor encoder supports the secondary servo control irrespective of the use for position and speed control (commutation).
- If an additional encoder is available on the load side, this "position encoder" only supports the position control and [C02570](#) accordingly has to be set to "Position controller active", so that the position encoder is evaluated.
 - The used position encoder must be set in [C00490](#).
 - The position encoder mounting direction must be set in [C02529](#).
 - The starting position of the position encoder can be set via the basic function "Homing".



Note!

When the basic function "Quick stop" is activated, the controller configuration is always switched over to angle control internally, irrespective of the setting in [C02570](#).

- If the basic function "Quick stop" is to be used, the gain of the phase controller ([C00254](#)) must also be set correctly for the "Position control" controller configuration.

For the technology applications for the interconnection via the "Electrical shaft", the controller configuration is set to position control in the default setting.

6 Encoder evaluation

6.3 Parameter setting

From software version V7.0 onwards, the selection "3: Position controller active" is available in [C02570](#).

- In contrast to the already existing selection "2: Position controller active (<= FW V5.xx)", this selection considers the gearbox factor.
- Further explanations on this can be obtained from the following table:


C02570 = 2: Position controller active (<= FW V5.xx)	C02570 = 3: Position controller active
When the separate position encoder at the output end is used, the reference speed to the tool is assumed. This causes the acceleration and deceleration times not to refer to the motor but to the encoder. In order to re-establish the motor reference, the desired acceleration time of the corresponding function must be multiplied by the resulting gearbox factor.	When the separate position encoder at the output end is used, the reference speed is referred to the motor. Thus, all acceleration and deceleration times are calculated with regard to the reference speed at the motor.
Example: <ul style="list-style-type: none">• Motor reference speed (C00011) = 3000 rpm• Resulting gearbox factor = 10• Acceleration time = 1 s With 10 % setpoint selection:	
<ul style="list-style-type: none">• Motor speed = 100 % (3000 rpm)• Tool speed = 300 rpm• Acceleration time up to 10 % setpoint selection (100 % motor speed) = 0.1 s	<ul style="list-style-type: none">• Motor speed = 10 % (300 rpm)• Tool speed = 30 rpm• Acceleration time up to 10 % setpoint selection (10 % motor speed) = 0.1 s

6 Encoder evaluation

6.3 Parameter setting

6.3.2 System with motor encoder

No encoder is installed on the load side. The motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and are converted with regard to the load side.



[6-2] Schematic diagram - feedback with position encoder = motor encoder


The actual position and actual speed values on the machine side result from the conversion via the gearbox factor on the motor side ([C02520/C02521](#)) and the feed constant ([C02524](#)).

See also:

- ▶ [Gearbox ratio](#) (□ 34)
- ▶ [Feed constant](#) (□ 39)

6.3.3 System with motor encoder and position encoder

The optional position encoder is used as a feedback for the position control and transmits the position of slide or drive roll to the controller.



[6-3] Schematic diagram - feedback with separate position encoder

In this case, the actual position and actual speed values on the machine side result from the conversion of the position encoder position via the resulting gearbox factor (ratio of the motor speed to the position encoder speed; display in [C02531/3](#)) and the feed constant ([C02524](#)).



How to activate the use of a separate position encoder:

On the **Application parameters**

tab in the dialog level *Overview* → *Drive interface* → *Machine parameters*:

1. Select the "Position controller active" setting in the **Position control structure** list field ([C02570](#)), so that the position encoder is evaluated.
2. Select the position encoder available in the **Position encoder selection** list field ([C00490](#)).
3. Select the gearbox ratio of the position encoder (ratio of load speed to encoder speed) as a quotient (numerator/denominator) which results from the resulting teeth number:
 - Enter numerator in the input field **Gearbox fact. num.: Pos. enc.** ([C02522](#)).
 - Enter denominator in the input field **Gearbox fact. denom.: Pos. enc.** ([C02523](#)).
4. If required, adapt the position encoder mounting direction via the **Position encoder mounting direction** list field ([C02529](#)). The position encoder mounting direction is preset to "Encoder rotating CW".



Tip!

In [C02531/2](#) the gearbox factor is displayed in decimal format.

Important reference variables converted to the load side:

- Motor reference speed ([C00011](#)) → Load reference speed ([C02542](#))
- Reference torque ([C00057/2](#)) → Load reference torque ([C02543](#))

If a position encoder is used as well as the motor encoder, it is essential that position control is used instead of angle control ([C02570](#) = 2 or 3).

Rotative encoders as well as linear distance measuring devices can be used as position encoders.

The feedback from position encoders (SSI-, EnDat-, TTL-, Sin/Cos-, Hiperface encoder) is transferred via encoder input X8, with the exception of fieldbus encoders.

If a fieldbus encoder is used, the fieldbus interface is used for position feedback.

The actual position value is passed on to the position controller via the system block available for

encoder evaluation **LS_Feedback**. For this purpose, the actual position value must be connected to the input *FDB_dnActPosIn_p*.

**Note!**

The use of an SSI encoder is a special case:

- Position feedback takes place via encoder input X8 as is the case with most position encoders.
- Processing of the actual position value is carried out in the same way as in the case of a fieldbus encoder. The actual position is passed on to the position controller via the system block available for encoder evaluation **LS_Feedback**. For this purpose, the actual position value must be connected to the input *FDB_dnActPosIn_p*.

6.3.4 Position feedback with a linear distance measuring device

This function extension is available from software version V4.0!

Linear distance measuring devices (e.g. with Hiperface® or EnDat interface) are only used for additional position feedback in the case of servo-controlled drives. For speed and current control, a motor encoder is always necessary.

For applications with low requirements regarding dynamic response and speed accuracy, the use of sensorless V/F control (VFCplus) and position feedback for position control is possible.

6.3.4.1 Conversion from linear to rotative encoder variables

Like the signals of rotative position encoders, the signals of linear distance measuring devices are read in at encoder input X8. The actual position value of these usually optical encoders is thus directly available for position control. Additional block interconnection is not necessary.

Evaluation at encoder input X8 is designed for rotary encoders. In order to adapt the linear system, conversion to (notional) rotative values, which have to be entered in the code, is necessary.

Conversion for the number of encoder increments in [C00420](#):

In the case of linear distance measurement devices, the encoder resolution is usually indicated in the form of graduations in [μm] or as a number of increments per millimetre [inc/mm].

The following rule of thumb can be used to determine the number of encoder increments [C00420](#):

$$\text{Number of encoder increments} = \frac{\text{Feed constant [units/rev]}}{\text{Encoder graduation [units]}}$$
$$\text{C00420} = \text{INT number of encoder increments} = \frac{\text{C02524}}{\text{Encoder graduation}}$$

[6-4] Determination of the number of encoder increments of linear distance measuring devices

The integer value (INT = integer part of the calculation) must be entered in [C00420](#). The resulting rounding-off error is corrected by means of the position encoder gearbox factor ([C02522](#) / [C02523](#)) in the machine parameters.

See ▶ [Determination of the position encoder gearbox factor of linear distance measuring devices](#)

The resulting maximum position which can be shown can be checked in [C02539](#).

The maximum speed that can be shown is indicated in [C02540](#).

If the necessary speeds and positions for the application can no longer be shown, [C00420](#) can be enlarged. The internal resolution is thus decreased.

6 Encoder evaluation

6.3 Parameter setting

Calculation of the position encoder gearbox factor [C02522](#) and [C02523](#)

Please note that, when the number of encoder increments in the numerator of the following formula is indicated, the value with decimal places must be given whereas, in the denominator, the integer (INT = integer) is used for purposes of calculation:

$$n \text{ encoder - gearbox factor} = \frac{\text{Number of encoder increments (incl. decimal)}}{\text{Number of encoder increments (integer)}}$$


$$\frac{84823}{84820} = \frac{\text{Number of encoder increments (incl. decimal plac)}}{C00420}$$

[6-5] Determination of the position encoder gearbox factor of linear distance measuring devices

Example: Position encoder feedback with a laser distance measuring device

The current position of a positioning unit is detected with a laser distance measuring device (e.g. »DME5000«) with a Hiperface® interface. A graduation of 0.1 mm has been parameterised in the distance measuring device.

The positioning unit is moved by 848.23 mm in an axial direction for each revolution of the slip-free drive roll. The current motor speed is detected by a resolver.



[6-6] Schematic diagram of feedback with a laser distance measuring device

Short overview of the parameters:

Parameters	Info	Lenze setting	
		Value	Unit
C00420	Number of encoder increments	8482	
C00422	Encoder type	Absolute value encoder (Hiperface)	
C00490	Position encoder selection	Encoder on X8	
C00495	Motor encoder selection	Resolver on X7	
C02522	Gearbox factor numerator: position encoder	84823	-
C02523	Gearbox factor denominator: position encoder	84820	
C02524	Feed constant	848.23	mm
C02570	Position control structure	Position controller is active	

See also: [▶ Feed constant \(39\)](#)

6.3.5 Adaptation of the resolver evaluation dynamics

This function extension is available from software version V5.0 onwards!

The resolver evaluation of the controller is adapted to the resolver types mounted in Lenze motors and offers a good compromise between the dynamic performance and interference suppression. If the resolver is used as a speed feedback system, the dynamic performance of the resolver evaluation determines, among other things, the maximum speed controller gain by means of which stable operation is possible.

In a system with an EMC-compliant structure (low interference), you can increase the dynamic performance of the resolver evaluation in [C00417](#) without a loss in quality in the speed signal. By increasing [C00417](#), the evaluation is rendered more dynamic, and thus the speed controller gain V_p ([C00070](#)) is also increased without leaving the stable operating range.

The acceleration of the evaluation depends on the cable length, the resolver, and the quality of the electrical shielding. In many cases, a setting of [C00417](#) = 300 % is possible which can double the speed controller gain. The higher gain in the speed controller may reduce following errors.

When a resolver with a number of pole pairs > 1 ([C00080](#) > 1) is used, it may be necessary to increase the dynamics of the resolver evaluation [C00417](#). The following rule of thumb applies for the parameterisation:

$$C00417 = 100\% \times \text{Value in } C00080$$

If an SM301 safety module is used to monitor the equipment, a parameterised value in [C00417](#) of $> 500\%$ can cause incorrect triggering of the safety module. A value which is too high must be decreased in order to eliminate incorrect triggering.

See also:

- ▶ Servo control (SC): [Optimising the speed controller](#) (□ 150)
- ▶ Sensorless vector control (SLVC): [Optimising the speed controller](#) (□ 177)

6.3.6 Parameterisation of an unknown Hiperface® encoder

This function extension is available from software version V11.0!

Application: A Hiperface® encoder is to be used with the controller, the current firmware of which has not (yet) been stored permanently.



How to parameterise a Hiperface® encoder unknown to the controller:

1. Determine the type code of the encoder.
 - If the encoder has already been connected and read out, the type code is indicated in [C00413](#).
 - Alternatively, the type code can be obtained from the manufacturer or gathered from the documentation for the encoder.
2. Set the type code of the encoder in [C00414](#).
 - Please observe that the decimal format has to be used for the setting. The type codes provided by the manufacturer, however, are in the hexadecimal format.
3. If a multi-turn encoder is used, set the number of displayable resolutions in [C00415](#).
 - This value can also be gathered from the documentation for the encoder.
4. Set the number of encoder increments in [C00420](#).
 - This point must be executed last since it initiates a renewed readout of the encoder.

6.3.7 Parameterisation of a Hiperface® encoder with increased initialisation time

This function extension is available from software version V11.0!

Application: A Hiperface® encoder is to be used at the controller which has an initialisation time that differs from the Hiperface specification. This applies to e.g. the absolute value encoders of the types SEK37, SEL37, SEK52 and SEL52 of the Sick company.

In case of Hiperface® encoders with increased initialisation time, an error message occurs after switching on the controller [0x007b001a](#) ("absolute value encoder: communication error"). This error can be acknowledged but occurs again after every switch-on.

In order to avoid the error message, it is possible to consider the increased initialisation time of the encoder in [C00412](#).

For the absolute value encoders of the types SEK37, SEL37, SEK52 and SEL52 of the Sick company, the required initialisation time in [C00412](#) is = 1200 ms.

The initialisation time required for each case can be obtained from the respective absolute value encoder data sheet.

6.3.8 Use of an SSI encoder at X8

This function extension is available from software version V5.0 onwards!

From software version V5.0 all encoders at X8 using the Stegmann SSI protocol are supported.

- Supported bit rates for the SSI communication: 150 ... 1000 kbits
- Supported data word widths: 1 ... 31 bits (effective)
- Supported output code of the SSI encoder: Gray or binary
- The SSI encoder can be used as position encoder or master encoder with a minimum cycle time of 1 ms.
- The SSI encoder can be supplied via X8 up to a maximum voltage of 12 V and a maximum current of 0.25 A.
- The SSI data words received are provided to the application via the [LS SsiEncoderX8](#) system block for further processing within the function block editor.



Note!

The [LS SsiEncoderX8](#) SB is only provided within controllers with a MM3xx or MM4xx memory module.



How to parameterise the SSI encoder at X8:

1. Set the supply voltage of the SSI encoder used in [C00421](#).
2. Set the selection "4: SSI encoder" as encoder type in [C00422](#).
3. Set the bit rate for SSI communication in [C00423](#).
 - For SSI protocols, the permissible baud rate is reduced if the cable length is increased. A safe bit rate must be set, depending on the length of the used encoder cable and the electromagnetic interference level.
 - Lenze setting: 400 kbits (for encoder cables with a length of up to \approx 50 meters)
4. Set the data word width in [C00424](#), i. e. the number of data bits that is used for the transmission of a complete SSI data packet.
 - Lenze setting: 25 bits (Stegmann multiturn SSI encoder)
5. Optionally: Split the SSI data word received into partwords and connect a data conversion from Gray into binary code, which may be required (see the following subchapters).


6.3.8.1 "LS_SsiEncoderX8" system block

The **LS_SsiEncoderX8** system block provides the SSI data words received to the application for further processing in the function block editor.



Note!

- The **LS_SsiEncoderX8** SB is only provided within controllers with a MM3xx or MM4xx memory module.
- If a position is transmitted in the SSI data word, it is output in an unchanged manner with regard to the position format by the **LS_SsiEncoderX8** SB. For a use of the SSI encoder as position encoder the position has to be converted into the 9400 format afterwards by means of the **L_EsEncoderConv** FB.



Outputs

Identifier	Data type	Value/meaning
SSI_dwDataword_1	DWORD	SSI partword 1 • In the Lenze setting the complete SSI data word received is shown at this output without a conversion of the data format.
SSI_dwDataword_2 ... SSI_dwDataword_8	DWORD	SSI partwords 2 ... 8 • In the Lenze setting these outputs are deactivated. ▶ Dividing the SSI data word into partwords (257)

Gray-binary conversion

If an SSI encoder with Gray coding is used, a data conversion of Gray-to-binary code can be connected in **C00437/1...8** individually for each output of the **LS_SsiEncoderX8** SB, and thus for each partword.

- In the Lenze setting "Binary coded" there is no conversion, i. e. an SSI encoder with binary coding is expected.

6 Encoder evaluation

6.3 Parameter setting


6.3.8.2 Dividing the SSI data word into partwords

The [LS_SsiEncoderX8](#) SB can be configured so that it splits up the SSI data word received by the encoder interface into several partwords.

- A separation into partwords is reasonable if the SSI data word also contains other data (like for instance fault or status information) in addition to the position.
- The max. 8 possible partwords are fixedly assigned to the outputs *SSI_dwDataword_1* ... *SSI_dwDataword_8*.
- The partwords are configured via the following parameters:


Parameters	Info
C00435/1...8	Starting position for partwords 1 ... 8 In order to be able to display the individual components of the SSI data word received at different outputs, this code serves to specify the bit position with which the partword for the respective output starts for the eight possible outputs of the LS_SsiEncoderX8 SB . Subcode 1 is fixedly assigned to the first output, subcode 2 to the second output, etc.
C00436/1...8	Length of the partwords 1 ... 8 Apart from the position of the first bit, also the bit length of each partword is important for the separation. A length of zero means that no partword is to be shown at the corresponding output (output = 0). Here also subcode 1 is fixedly assigned to the first output, subcode 2 to the second output, etc.

- In the Lenze setting the complete SSI data word received is shown at the output *SSI_dwDataword_1*:



[6-7] Example 1: Lenze setting

- The following example shows the parameterisation required to split up the SSI data word received into three partwords (here status information, error bit, and position information):



[6-8] Example 2: Splitting up the SSI data word received into three partwords

6.3.8.3 Linear distance measuring devices with SSI protocol

Linear distance measuring devices provide the position directly in a physical unit of length (e.g. [mm]). An incremental position must be sent to the position controller via the system block

LS_Feedback. The reference of this incremental position corresponds to a value of 65536 (Lenze setting: [C00100](#) = 16) in the case of a revolution at the output end.

The necessary conversion of the position value can be carried out by means of the block **L_EsEncoderConv**. The block **L_EsEncoderConv** is designed for rotary encoders. Conversion to (notional) rotative values is therefore necessary for the adaptation of linear distance measuring devices. The results of the conversion must be entered in the code.

Conversion for the number of encoder increments in C05273:

In the case of linear distance measurement devices, the encoder resolution is usually indicated in the form of graduations in [μm] or as a number of increments per millimetre [*inc/mm*].

The following rule of thumb can be used to determine the number of encoder increments C05273:

$$\text{Number of encoder increments} = \frac{\text{Feed constant [units/rev]}}{\text{Encoder graduation [units]}}$$

$$\text{C05273} = \text{INT number of encoder increments} = \frac{\text{C02524}}{\text{Encoder graduation}}$$

[6-9] Determination of the number of encoder increments of linear distance measuring devices with SSI protocol

The integer (INT = integer part of the calculation) must be entered in C05273. The resulting rounding-off error is corrected by means of the position encoder gearbox factor ([C02522](#) / [C02523](#)) in the machine parameters.

▶ [Determination of the position encoder gearbox factor of linear distance measuring devices with SSI protocol](#)

The resulting maximum position which can be shown can be checked in [C02539](#).

The maximum speed that can be shown is indicated in [C02540](#).

If the necessary speeds and positions for the application can no longer be shown, C05273 can be enlarged. The internal resolution is thus decreased.

Calculation of the position encoder gearbox factor [C02522](#) and [C02523](#)

Please note that, when the number of encoder increments in the numerator of the following formula is indicated, the value with decimal places must be given whereas, in the denominator, the integer (INT = integer) is used for purposes of calculation:

$$\text{n encoder - gearbox factor} = \frac{\text{Number of encoder increments (incl. decimal)}}{\text{Number of encoder increments (integer)}}$$

$$\frac{\text{!522}}{\text{!523}} = \frac{\text{Number of encoder increments (incl. decimal plac)}}{\text{C05273}}$$

[6-10] Determination of the position encoder gearbox factor of linear distance measuring devices with SSI protocol


Example: Position encoder feedback with an SSI linear distance measuring device

The current position of a positioning unit is detected with a laser distance measuring device (e.g. »DME5000«) with an SSI interface. A graduation of 0.1 mm has been parameterised in the linear distance measuring device.

The positioning unit is moved by 848.23 mm in an axial direction for each revolution of the slip-free drive roll. The current motor speed is detected by a resolver.

A position offset of 100 mm must be taken into account due to installation of the distance measuring device and the reflector.

The lower 24 bits of the SSI data word contain information coded in Gray.




[6-11] Schematic diagram of feedback with laser distance measuring device DME5000

The Multiturn resolution (C05274) that is set must allow the entire traversing range of the application to be represented and must also ensure that the display limit in the 9400 device is not exceeded.

- Minimum Multiturn resolution.
 $C05274 = \text{Maximum traversing range} / \text{feed constant} = 59$
- Maximum Multiturn resolution
 $C05274 = 2^{31}-1 / \text{resolution of Singleturn} = 253181$

Required FB interconnection



Short overview of the parameters:

Parameters	Info	Lenze setting	
		Value	Unit
C00422	Encoder type	SSI encoder	
C00423	SSI encoder: Bit rate	400	kbps
C00424	SSI encoder: Data word length	24	Bit
C00435/1	SSI enc.: Partword 1 start	0	
C00436/1	SSI enc.: Partword 1 length	24	
C00437/1	SSI enc.: Partword 1 coding	gray coded	
C00490	Position encoder selection	Encoder on X8	
C00495	Motor encoder selection	Resolver on X7	
C02522	Gearbox factor numerator: position encoder	84823	
C02523	Gearbox factor denominator: position encoder	84820	
C02524	Feed constant	848.23	mm
C02570	Position control structure	Position controller is active	
C04276	Position offset at <i>FDB_dnPosOffset_p</i>	100	mm
C05271	32-bit encoder signal		
C005273	Single turn resolution	8482	Steps/rev
C05274	Resolution Multiturn	60	Rev

6.3.9 Rotative encoder with SSI protocol

In accordance with the parameterisation of the system block **LS_SsiEncoderX8**, the position information of the encoder is available in a partword and only has to be sent to the position controller via the SB **LS_Feedback**.

In accordance with the Lenze setting of the position encoder gearbox factor ([C02522](#) = 1, [C02523](#) 1 = 1), it is expected that one encoder revolution corresponds to one rotation at the output end, i.e. to a feed rate in accordance with the feed constant [C02524](#).


The position information from the SSI data word is converted to the internal scale with the function block **L_EsEncoderConv**, with which a certain machine position can be set as the reference/starting position. The parameterisation of the block makes it possible for the position to be reconstructed after mains switching. This is necessary if the absolute encoder display range of e.g. 4096 revolutions has been left.

Example: Material feed with length measurement by means of measuring wheel and SSI encoder

The current position of the material of a feed unit is detected with a rotative SSI encoder. One encoder revolution corresponds to one revolution of the measuring wheel (400 mm).


Every time the slip-free drive roll revolves, the material is moved 1200 mm in an axial direction. The current motor speed is detected by a resolver.

The lower 24 bits of the SSI data word contain the position information coded in Gray. The SSI encoder supplies 4096 gradations per revolution and has an absolute display range of 4096 revolutions.



[6-12] Schematic diagram of feedback with laser distance measuring device DME5000

Required FB interconnection



Short overview of the parameters:

Parameters	Info	Lenze setting	
		Value	Unit
C00422	Encoder type	SSI encoder	
C00423	SSI encoder: Bit rate	400	kbps
C00424	SSI encoder: Data word length	24	Bit
C00435/1	SSI enc.: Partword 1 start	0	
C00436/1	SSI enc.: Partword 1 length	24	
C00437/1	SSI enc.: Partword 1 coding	gray coded	
C00490	Position encoder selection	Encoder on X8	
C00495	Motor encoder selection	Resolver on X7	
C02522	Gearbox factor numerator: position encoder	1200	
C02523	Gearbox factor denominator: position encoder	400	
C02524	Feed constant	1200	mm
C02570	Position control structure	Position controller is active	
C05271	Encoder evaluation	32-bit encoder signal	
C05272	Encoder mounting position	Left	
C05273	Single turn resolution	4096	Steps/rev
C05274	Resolution Multiturn	4096	Rev

6.3.10 Provision of the encoder signal of input X8

This function extension is available from software version V7.0!

The **LS_EncoderX8** system block serves to provide the encoder signal of input X8 to the application, independent of the selected feedback system for the motor encoder and position encoder.

Application cases:

- High-resolution speed encoder as master encoder /value, correcting signal, ...
- Absolute value encoder for length measurements
- Display of the absolute encoder value without considering an offset




Note!

For SSL encoders, the **LS_SsiEncoderX8** system block must be used. ▶ [Use of an SSI encoder at X8 \(📄 255\)](#)

6.3.10.1 System block "LS_EncoderX8"

The **LS_EncoderX8** system block provides the input X8 to the application in the function block editor.



Outputs

Identifier <small>DIS code data type</small>	Value/meaning		
ENC_dnEncoderOut1 C02762 DINT	Display of the current encoder position (steps) within one revolution • 1 revolution $\equiv 2^{32}$ bits Note: In order to convert the encoder information/position into a position_p in the internal measuring system, connect both outputs <i>ENC_dnEncoderOut1</i> and <i>ENC_dnEncoderOut2</i> with the inputs <i>dnEncoderIn</i> and <i>dnEncoderIn2</i> of the FB L_EsEncoderConv . A storage with mains failure protection of the position signal is also processed via this FB.		
ENC_dnEncoderOut2 C02763 DINT	Display of all revolutions of the encoder (only with Multiturn) • After the max. presentable revolutions have been reached, the value jumps back to "0". • C02761 shows the max. presentable revolutions of the MultiTurn encoder (encoder-dependent). • In case of SingleTurn, the value "0" is always output.		
ENC_dnActualSpeed_s C02764 DINT	Current encoder speed in [rpm]		
ENC_bError C02765 BOOL	Status signal "Encoder error" <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>TRUE</td> <td>An encoder error has occurred.</td> </tr> </table>	TRUE	An encoder error has occurred.
TRUE	An encoder error has occurred.		

6.3.10.2 Activate evaluation

[C02760](#) serves to activate the evaluation of the encoder signal of input X8.

- When the evaluation is activated, the encoder parameterised in [C00422](#) is read in.
 - At the same time, the monitoring functions are active. If no encoder is available, the corresponding monitoring functions are triggered.
- When the evaluation is deactivated, the outputs of the system block are reset.
 - Monitoring is deactivated depending on the position encoder selection ([C00490](#)) and the motor encoder selection ([C00495](#)).

Monitoring

The monitoring functions depend on the encoder type selected in [C00422](#) and do not differ from the existing monitoring functions:

- Open circuit of encoder (response: [C00580](#))
- [Encoder angular drift monitoring](#) (📖 267)
- Encoder communication error (*FDB_bEncoderComError*; response: [C00601](#))
- Sine/cosine encoder error (*FDB_bSinCosSignalError*)
- Group signal for errors as process data (*ENC_bError*)

Conditioning of the encoder signal

- The encoder signal is conditioned to a position (including a storage with mains failure protection) within the application using the FB **L_EsEncoderConv**:
 - Interconnection of the *ENC_dnEncoderOut1* output signal with the *dnEncoderIn* input of the FB **L_EsEncoderConv**.
 - Interconnection of the *ENC_dnEncoderOut2* output signal with the *dnEncoderIn2* input of the FB **L_EsEncoderConv**.
 - Additional parameter setting of the FB **L_EsEncoderConv**:
 - Mode selection: Cxxxxx = 1
 - Number of revolutions transmitted from [C02761](#)
 - The (optional) reconstruction of the position after mains switching is also made by the FB **L_EsEncoderConv**.
- In contrast, the conditioning of the encoder signal to a speed is directly made in the [LS_EncoderX8](#) system block.
 - The current encoder speed is provided at the *ENC_dnActualSpeed_s* output in [rpm] (display parameter: [C02764](#)).
- TouchProbe function is not supported (continues to be only available for motor and position encoders).
- If the encoder at X8 is simultaneously used as motor or position encoder, the "raw value" of the encoder is continued to be output.

Display parameter

Parameters	Info	Lenze setting	
		Value	Unit
C02761	Resolution Multiturn	-	Rev.
C02762	Encoder position: Steps within one revolution	-	Steps
C02763	Encoder rev: Number of revolutions	-	Rev.
Greyed out = display parameter			

6 Encoder evaluation

6.3 Parameter setting

Parameters	Info	Lenze setting	
		Value	Unit
C02764	Encoder speed	-	rpm
C02765	Encoder error	-	

Greyed out = display parameter

6.3.11 Resolver error compensation

This function extension is available from software version V7.0!

Resolver errors typically occur in form of the 1st and 2nd harmonic. They have two different causes:

1. The inductances of the sine and cosine track of the resolver have slightly different values.
2. Sine and cosine track do not magnetise orthogonally to each other.

Resolver errors due to cause 1 can be corrected by adjusting the gains of the digital/analog converters which feed the resolver tracks. In the Lenze setting, the gains of both resolver tracks are preset with identical values.

Resolver errors due to cause 2 can be compensated for by a slight correction of the angle via which both resolver tracks are fed relative to one another.

By executing the device command [C00002](#) = "59: Resolver error identification", the gain of the digital/analog converter for feeding the resolver and the angle which serves to feed the two resolver tracks relatively to each other are corrected so that the resolver error is minimised.

- A precondition for the execution of the device command is that the machine is in speed-controlled operation (servo control). The speed amount during the identification must be constant and higher than 500 rpm.
- After the resolver error identification has been executed successfully, the resolver error compensation is activated automatically ([C00418](#) = "1: Activated"). Now the resolver operates with the following resolver error parameters which have been identified during the procedure:

Parameters	Info	Lenze setting	
		Value	Unit
C02862/1	Resolver: cos gain	100	%
C02862/1	Resolver: sine gain	100	%
C02863	Resolver: Angle correction	0	

- The detected gain can take values between 0 ...100 %.
 - With a setting of 0 %, the gain of the corresponding resolver track is only 95 % of the default setting.
 - With a sensible resolver error compensation only one of the two gains is adapted. The other remains at 100 %.
- For a permanent acceptance of the identified resolver error parameters, the parameter set must be saved ([C00002](#) = "11: Save start parameters").
- When the resolver error compensation is deactivated ([C00418](#) = "0: Deactivated"), the resolver operates with the Lenze setting again. The identified resolver error parameters remain stored.

The resolver error identification can fail due to the following:

- Wrong control mode is active (no servo control)
- Error or fault is active
- Another identification is active
- The speed is too low (< 500 rpm)
- Time-out while the algorithm is processed

6.3.12 Encoder angular drift monitoring

The optional encoder angular drift monitoring monitors a potential deviation between the actual encoder angle and the angle calculated by the counting of increments in the encoder evaluation.



The encoder angular drift monitoring is activated by parameterising an error response that is not "0: No response" in [C00621](#).

If a deviation higher than 45° (electrical) is recognised when monitoring is activated:

- The error message "Encoder monitoring: pulse deviation detected" is entered in the logbook of the controller.
- The error response parameterised in [C00621](#) is triggered.
- The "Reference known" status of the "Homing" basic drive function is reset (if this status was set before)



Tip!

A deviation may occur, for instance, by incorrect parameter setting of the encoder increments, by lines in the form of interferences caused by EMC or loss of lines caused by EMC.

The encoder angular drift monitoring for encoders with and without absolute information is implemented by two different principles which are explained in detail in the following subchapters.

6.3.12.1 Angular drift monitoring for encoders without absolute information

When an encoder without absolute information is used, the number of increments between two zero pulses (one revolution) is monitored. This value must equal the encoder increments set in [C00420](#).



Note!

After mains switching, monitoring is only active after second incoming zero pulse since the first line difference to be used can only be calculated with the second and first zero pulse.

When the motor (and thus the encoder) is replaced, it is very likely that a angular drift error occurs within the first revolution after acknowledging the encoder error since the monitoring function cannot recognise that the encoder has been replaced.

6.3.12.2 Angular drift monitoring for encoders with absolute information

For an encoder with absolute information, cyclical communication with the encoder takes place and the angle is read out digitally. This angle is compared to the angle from the encoder evaluation.



Note!

If monitoring is deactivated ([C00621](#) = "0: No response"), there is no cyclic communication with the encoder, and therefore no communication errors with the encoder can occur.

If monitoring is activated, it is only executed for speeds lower than 100 rpm due to runtimes for communication.

- If increments get lost at higher speeds, this deviation can only be recognised when the speed falls below 100 rpm for at least 80 ms.

After each detected encoder angular drift error, a renewed read-out of the position is tripped automatically and this angle is written into the encoder evaluation. This makes it possible to acknowledge the error. In case of synchronous machines, the pole position is corrected simultaneously.

7 Braking operation

The 9400 HighLine controller as single-axis controller (single drive) is provided with an integrated brake transistor.

- The required brake resistor must be connected externally (see Mounting Instructions/Hardware Manual).
- The rated values for the internal brake transistor are given in the Hardware Manual in the chapter "Rated data".



Stop!

If the brake resistor actually connected is smaller than the brake transistor parameterised, the brake chopper can be destroyed!

The brake resistor can be thermally overloaded. Carry out protective measures suitable for the installation, e.g.:

- Parameterisation of an error response in [C00574](#) and evaluation of the parameterised error message within the application or within the machine control. ▶ [I2t utilisation - brake resistor](#) (p. 273)
- External interconnection using the thermal contact on the brake resistor (e.g. supply interruption via the mains contactor and activation of the mechanical brakes).



Note!

The brake chopper control is also guaranteed if, for example, the application stands still or the 24-V supply is not connected and the controller is only fed by the DC bus.

7 Braking operation

7.1 Parameter setting

7.1 Parameter setting

Short overview: Parameters for braking operation

Parameters	Info	Lenze setting	
		Value	Unit
C00129	Brake resistance value	180.0	Ohm
C00130	Rated brake resistor power	5600	W
C00131	Thermal capacity - brake resistor	485	kWs
C00133	Ref.: Brake chopper utilisation	Minimum resistance (C00134)	
C00134	Min. brake resistance	-	Ohm
C00137	Brake transistor utilisation	-	%
C00138	Brake resistor utilisation	-	%
C00173	Mains voltage	400/415 V	
C00181	Reduced brake chopper threshold	0	V
C00569	Resp. brake trans. ixt > C00570	Warning	
C00570	Warning thres. brake transistor	90	%
C00571	Resp. brake res. i2t > C00572	Warning	
C00572	Warning thres. brake resistor	90	%
C00573	Resp. to brake transistor overload	No response	
C00574	Resp. to brake resist. overtemp.	No response	
C00600	Resp. to DC bus overvoltage	Fault	

Greyed out = display parameter

7.1.1 Setting the voltage threshold for braking operation

The voltage threshold for braking operation is set via [C00173](#) (mains voltage) and [C00181](#) (reduced brake chopper threshold). If the brake chopper threshold in the DC bus is exceeded, the brake transistor is switched on.

Mains voltage selected in C00173	Effective brake chopper threshold
230 V	390 V - value in C00181 (0 ... 100 V)
400/415 V	725 V - value in C00181 (0 ... 100 V)
460/480 V	765 V - value in C00181 (0 ... 100 V)
500 V	790 V - value in C00181 (0 ... 100 V)

7 Braking operation

7.2 Monitoring

7.2 Monitoring

7.2.1 Overcurrent protection

The brake chopper hardware is monitored with regard to overcurrent (short circuit or earth fault).



Note!

The monitoring with regard to overcurrent can only be triggered if a braking current is actually available. It is not possible to carry out a test in idle state (without connected brake resistor).

- If monitoring responds:
 - The brake chopper is switched off immediately.
 - The "Fault" response is activated.
 - The "Brake transistor: overcurrent" error message is entered into the logbook of the controller.



Note!

The error can only be acknowledged after 2 seconds at the earliest to resume the braking operation.



Tip!

In addition to the overcurrent protection the controller is provided with two further monitoring functions for the braking operation, which are also activated if no brake resistor is connected at all (testing mode for checking the parameterisation):

▶ [Ixt utilisation - brake transistor](#) (📖 272)

▶ [I2t utilisation - brake resistor](#) (📖 273)


7.2.2 Ixt utilisation - brake transistor

The controller is provided with a monitoring function for the Ixt utilisation of the internal brake transistor.



Note!

The braking operation will never be switched off by this monitoring function.



[7-1] Signal flow of Ixt utilisation - brake chopper

- Monitoring is based on a mathematical model which calculates the braking current from the current DC-bus voltage and the brake resistance parameterised.
 - Hence, monitoring can be activated although no brake resistor is connected and can therefore also be used for a testing mode to check the parameterisation.
- During the calculation the thermal utilisation of the brake transistor is taken into consideration by the use of an accordingly adapted time constant.
- In [C00133](#) it can be selected whether the minimum brake resistance (display in [C00134](#)) which depends on the network setting in [C00173](#)) or the brake resistor value parameterised in [C00129](#) is to be used as a reference for calculating the utilisation.
- [C00137](#) displays the calculated utilisation of the brake transistor in [%].
 - A 100 % utilisation corresponds to the continuous braking power which is provided by the integrated brake chopper at a DC-bus voltage of 790 V (or 390 V at a mains voltage of 230 V).
 - The maximum braking power (assuming that the utilisation starts at 0 %) can be provided for a time period depending on the device.
 - The calculated utilisation is provided as oscilloscope signal *Common.dnIxtBrakeChopper* to check the braking operation while the system is running (scaling: $2^{30} \equiv 100\%$).
- If the utilisation exceeds the advance warning threshold set in [C00570](#), "Brake chopper: Ixt > C00570" is entered in the logbook and the response set in [C00569](#) (default setting: "Warning") is activated.
- When the utilisation reaches the limit value (100 %):
 - The activation of the brake chopper is reset to the permanently permissible mark-to space ratio (taking the parameterised brake resistance into consideration). (The brake chopper is activated with 4 kHz, which means that it can be switched on/off at minimum intervals of 250 µs.)
 - The response set in [C00573](#) (default setting: "No response") is activated with the corresponding effects on the state machine and the inverter.

**Note!**


If the DC-bus voltage exceeds the overvoltage threshold due to a too high braking energy, the monitoring function for overvoltage in the DC bus responds. ▶ [Overvoltage in the DC bus](#) (□ 275)

7.2.3 I2t utilisation - brake resistor

The controller is provided with a monitoring function of the I²t utilisation of the brake resistor which is proportional to the converted braking power.

**Note!**

The braking operation will never be switched off by this monitoring function.



[7-2] Signal flow - I2t utilisation - brake resistor

- The monitoring function is based on the mathematical model which calculates the braking current from the current DC-bus voltage and the brake resistance parameterised in [C00129](#).
 - Hence, monitoring can be activated although no brake resistor is connected and can therefore also be used for a testing mode to check the parameterisation.
- The calculation considers the thermal utilisation of the brake resistor based on the following parameters:
 - Resistance value ([C00129](#))
 - Continuous power ([C00130](#))
 - Thermal capacity ([C00131](#))
- [C00138](#) displays the calculated utilisation of the brake resistor in [%].
 - A 100 % utilisation corresponds to the continuous power of the brake resistor which results at the maximum permissible temperature limit of the brake resistor.
 - The calculated utilisation is provided as oscilloscope signal *Common.dnI2tBrakeResistor* to check the braking operation while the system is running (scaling: $2^{30} \equiv 100\%$).
- If the utilisation exceeds the advance warning threshold set in [C00572](#), "Brake resistor: I2t > C00572" is entered in the logbook and the response set in [C00571](#) (default setting: "Warning") is activated.

-
- When the utilisation reaches the limit value (100 %):
 - The response set in [C00574](#) (default setting: "No response") is activated with the corresponding effects on the state machine and the inverter.
 - **Only applies to software versions lower than V3.0:**

The activation of the brake chopper is reset to the permanently permissible mark-to space ratio (taking the parameterised brake resistance into consideration). (The brake chopper is activated with 4 kHz, which means that it can be switched on/off at minimum intervals of 250 µs.)



Stop!

The brake resistor can be thermally overloaded. Carry out protective measures suitable for the installation, e.g.:

- Parameterisation of an error response in [C00574](#) and evaluation of the parameterised error message within the application or within the machine control system.
- External interconnection using the thermal contact on the brake resistor (e.g. supply interruption via the mains contactor and activation of the mechanical brakes).



Note!

If the system is dimensioned correctly, this monitoring function should not respond. If individual rated data of the actually connected brake resistor are not known, they have to be determined "empirically".

7.2.4 Overvoltage in the DC bus

If, due to a too high braking energy, the DC-bus voltage exceeds the overvoltage threshold which results from the mains voltage setting in [C00173](#), the "Overvoltage in the DC bus" error message is output and the response set in [C00600](#) is activated (default setting: "Trouble").



Note!

For hoist applications, the "Fault" response should be selected in [C00600](#) (in combination with an emergency stop via mechanical brakes).

8 I/O terminals

8.1 Overview

8 I/O terminals






This chapter provides information about options for parameter setting and configuration of the controller input and output terminals.



Tip!

Information on wiring the terminals can be found in the Mounting Instructions for the controller!

8.1 Overview

Front view	Terminal assignment	Info
	X2 	▶ "State bus" monitoring function (📖 286)
	X3 	▶ Analog inputs (📖 277) ▶ Analog outputs (📖 280)
	X4 	▶ Digital outputs (📖 284)
	X5 	▶ Digital inputs (📖 282) ▶ Touch probe detection (📖 288)

8 I/O terminals


8.2 Analog inputs

8.2 Analog inputs

The controller has two analog inputs that can be used to detect differential voltage signals in the range of ± 10 V, e.g. analog speed setpoint selections or the voltage signals of an external sensor (temperature, pressure, etc.).

- Optionally, analog input 1 can also be used to detect current setpoints.

8.2.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X3/A1- X3/A1+	Differential voltage input 1 (no jumper between A1R and A1-)	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Scaling: If C00034 = "0": ± 10 V $\equiv \pm 2^{30}$
		Conversion rate: 1 kHz
	Current input (jumper between A1R and A1-)	Level: -20 mA ... +20 mA
		Resolution: 10 bits + sign
X3/A2- X3/A2+	Differential voltage input 2	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Scaling: ± 10 V $\equiv \pm 2^{30}$
		Conversion rate: 1 kHz

8.2.2 Parameter setting

Short overview of parameters for the analog inputs:

Parameters	Info
C00034	Config. analog input 1
C00598	Resp. to open circuit AIN1
C02730/1	Analog input 1: Gain
C02730/2	Analog input 2: Gain
C02731/1	Analog input 1: Offset
C02731/2	Analog input 2: Offset
C02732/1	Analog input 1: Dead band
C02732/2	Analog input 2: Dead band
C02800/1	Analog input 1: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)
C02800/2	Analog input 2: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)
Greyed out = display parameter	

8.2.3 Reconfiguring analog input 1 into current input

By means of the following two steps, analog input 1 can be reconfigured into a current input:

1. Bridge the terminals A1R and A1- at terminal strip X3 by means of wiring.
2. Select the corresponding current loop under [C00034](#).



Tip!

Like this you can implement a 4 ...20 mA current loop, e.g. for speed setpoint selection.

Open-circuit monitoring


Under [C00598](#) you can set an error response to open circuit for the 4 ...20 mA current loop.

8 I/O terminals

8.2 Analog inputs

8.2.4 "LS_AnalogInput" system block

The LS_AnalogInput system block displays the analog inputs in the function block editor.



Output	Data type	Value/meaning
AIN1_dnIn_n	DINT	Analog input 1 <ul style="list-style-type: none"> Scaling: <ul style="list-style-type: none"> $\pm 2^{30} \equiv \pm 10 \text{ V}$ for use as a voltage input $\pm 2^{30} \equiv \pm 20 \text{ mA}$ for use as a current input
AIN2_dnIn_n	DINT	Analog input 2 <ul style="list-style-type: none"> Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$
AIN1_bCurrentError	BOOL	Status signal "Current input error" <ul style="list-style-type: none"> Only when analog input 1 is used as current input. Application: Cable-breakage monitoring of the 4 ...20 mA circuit.
		TRUE $ I_{AIN1} < 2 \text{ mA}$

8.3 Analog outputs

The controller has two analog outputs that can be used to output internal analog signals as voltage signals, e.g. for the control of analog indicating instruments or as a setpoint for slave drives.



Note!


Initialisation behaviour:

- After mains switching until the application is started, the analog outputs remain on 0 V.

Exception handling:

- In the case of a critical exception within the application (e. g. reset), the analog outputs are set to 0 V.

8.3.1 Terminal assignment/electrical data



Terminal	Use	Electrical data	
X3/AO1	Voltage output 1	Level:	-10 V ... +10 V (max. 2 mA)
		Resolution:	11 bits + sign
		Scaling:	$\pm 2^{30} \equiv \pm 10$ V
		Conversion rate:	1 kHz
X3/AO2	Voltage output 2	Level:	-10 V ... +10 V (max. 2 mA)
		Resolution:	11 bits + sign
		Scaling:	$\pm 2^{30} \equiv \pm 10$ V
		Conversion rate:	1 kHz
X3/GA	Reference potential (analog ground)		

8 I/O terminals

8.3 Analog outputs


8.3.2 Parameter setting

Short overview of parameters for the analog outputs:

Parameters	Info
C02733/1	Analog output 1: Gain
C02733/2	Analog output 2: Gain
C02734/1	Analog output 1: Offset
C02734/2	Analog output 2: Offset
C02801/1	Analog output 1: Output signal
C02801/2	Analog output 2: Output signal
Greyed out = display parameter	

8.3.3 "LS_AnalogOutput" system block

In the function block editor the **LS_AnalogOutput** system block provides the interface to the analog outputs.



Input	Data type	Information/possible settings
AOUT1_dnOut_n	DINT	Analog output 1 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$
AOUT2_dnOut_n	DINT	Analog output 2 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$

8 I/O terminals


8.4 Digital inputs

8.4 Digital inputs

The controller is provided with eight freely configurable digital inputs.

- All digital inputs can be used for touch probe. ▶ [Touch probe detection](#) (📖 288)
- The control input RFR of terminal strip X5 for controller enable is fixedly connected to the device control.

8.4.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X5/D11 X5/D18	Digital input 1 ... 8	LOW level: 0 ... +5 V
		HIGH level: +15 ... +30 V
		Input current: 8 mA per input (at 24 V)
		Electric strength of external voltage: Max. ±30 V
		Conversion rate: 1 kHz
X5/RFR	Controller enable	See digital inputs
X5/GI	Reference potential (digital ground)	

8.4.2 Parameter setting


Short overview of parameters for the digital inputs:

Parameters	Info
C00114	Digital input x - terminal pol.
C00443	Status: Digital inputs
C02803	Status word: Digital inputs
C02830	Digital inputs: Delay time

Greyed out = display parameter

8.4.3 "LS_DigitalInput" system block

The **LS_DigitalInput** system block displays the digital inputs and the status of the state bus in the function block editor.



Output	Value/meaning
DIGIN_bCInh <small>C00443/9 BOOL</small>	Status signal "Controller inhibit" <ul style="list-style-type: none"> The control input RFR (X5/pin 9) for setting/deactivating controller inhibit is fixedly connected to the device control (DCTRL) via an inverter.
DIGIN_bIn1 ... DIGIN_bIn8 <small>C00443/1 BOOL</small> <small>C00443/8 BOOL</small>	Digital input 1 ... 8
DIGIN_bStateBusIn <small>C00443/12 BOOL</small>	State bus status <ul style="list-style-type: none"> "State bus" monitoring function (286)
	TRUE A node connected to the state bus has set the state bus to LOW level and the "Error" state has been set. <ul style="list-style-type: none"> The "Error" state is also set if a node connected to the state bus is not supplied with voltage.

8 I/O terminals

8.5 Digital outputs

8.5 Digital outputs

The controller is provided with four freely configurable digital outputs.



Note!


Initialisation behaviour:

- After mains switching until the application is started, the digital outputs remain on FALSE.

Exception handling:

- In the case of a critical exception within the application (e. g. reset), the digital outputs are set to FALSE, taking the terminal polarity parameterised in [C00118](#) into consideration.

8.5.1 Terminal assignment/electrical data



Terminal	Use	Electrical data	
X4/DO1 ... X4/DO4	Digital output 1 ... 4	LOW level:	0 ... +5 V
		HIGH level:	+15 ... +30 V
		Output current:	max. 50 mA per output (external resistance > 480 Ω at 24 V)
		Conversion rate:	1 kHz
X4/240	External 24 V voltage supply for the digital outputs		
X4/GO	Reference potential (digital ground)		

8.5.2 Parameter setting

Short overview of parameters for the digital outputs:


Parameters	Info
C00118	Digital output x - terminal pol.
C00444	Status: Digital outputs
C02802	Status word: Digital outputs
Greyed out = display parameter	

8 I/O terminals

8.5 Digital outputs

8.5.3 "LS_DigitalOutput" system block


In the function block editor the **LS_DigitalOutput** system block provides the interface to the digital outputs, the state bus, and the yellow user LED at the front of the controller.



Input DIS code data type	Information/possible settings
DIGOUT_bOut1 C00444/1 BOOL ... DIGOUT_bOut4 C00444/4 BOOL	Digital output 1 ... 4
DIGOUT_bStateBusOut C00444/18 BOOL	Setting the state bus to the "Error" state ▶ "State bus" monitoring function (📖 286)
DIGOUT_bUserLED C00444/9 BOOL	Control of yellow user LED on the front of the controller
	TRUE LED on

8.6 "State bus" monitoring function

The state bus is a bus system that is solely designed for Lenze controllers, via which up to 20 controllers can be connected to each other, and by means of which the function of a "release cord" can be simulated:



[8-1] Schematic diagram: Networking via state bus

- The state bus only knows the states "OK" and "Error".
- The state bus is a bus with multi-master capability, i.e. each node connected to the state bus can set the state bus to the "Error" state by setting it to LOW level.
- In the "Error" status, all nodes start their adjustable response, e.g. synchronised braking of the drive system.
- The "Error" state is also set if a node connected to the state bus is not supplied with voltage.




Note!

Exception handling:

- In the case of a critical exception within the application (e. g. reset), the "release cord" is not triggered, the state bus remains in the "OK" status.


8.6.1 Detecting the current state

Via the output *DIGIN_bStateBusIn* of the [LS_DigitalInput](#) system block, the current status of the state bus can be queried. In case of error the output *DIGIN_bStateBusIn* is set to TRUE.



8.6.2 Setting the state bus to the "Error" state

If the input *DIGOUT_bStateBusOut* of the [LS_DigitalOutput](#) system block is set to TRUE, the state bus is set to "Error" and all connected nodes start their pre-programmed response.



8.7 Touch probe detection

A "touch probe" is an event that, for instance, can be triggered edge-controlled via a digital input in order to detect a (quickly changing) actual value at the time of triggering and process it in the program.

Overview of the touch probe channels


For the touch probe detection 12 touch probe channels are provided, which can be configured independently of each other:

Touch probe channel	Activating event	System block
1	Edge change at digital input 1	LS_TouchProbe1...8 (📖 291)
2	Edge change at digital input 2	
3	Edge change at digital input 3	
4	Edge change at digital input 4	
5	Edge change at digital input 5	
6	Edge change at digital input 6	
7	Edge change at digital input 7	
8	Edge change at digital input 8	
9	Motor encoder zero pulse	LS_TouchProbeMotor (📖 292)
10	Position encoder zero pulse	LS_TouchProbeLoad (📖 292)
11	DFIN zero pulse	LS_TouchProbeDFIN
12	DFOUT zero pulse	LS_TouchProbeDFOUT

- Each touch probe channel is assigned to a system block which provides the application with a scaled time stamp.
- The time stamp refers to the sampling time of the encoder signals and outputs the difference with regard to the touch probe event.

Further processing of the touch probe

For further processing of the touch probe event the time stamp is to be transmitted to an instance of the **L_SdTouchProbe** FB:




[8-2] Transfer of the time stamp to the **L_SdTouchProbe** FB

- The **L_SdTouchProbe** FB takes over the interpolation of the input signal on the basis of the time stamp and outputs the interpolated value and the difference to the last input signal.

8.7.1 Actual value interpolation (principle)

If a touch probe is detected, the (remaining) time until the following task cycle is determined and from this a time stamp is generated. On the basis of this time stamp, the **L_SdTouchProbe** FB can


then carry out a linear interpolation between the two actual position interpolation points; the result is the precise actual position at the time of the physical touch probe event.



[8-3] Actual value determination through linear interpolation (principle)

8.7.2 Dead time compensation

For dead time compensation during the detection of the touch probe event, it is possible to select a delay time (*Touch probe delay*) in [C02810](#) for each touch probe channel, which will be considered in the touch probe calculation.




[8-4] Dead time compensation (principle)

- The filtering of the digital inputs has an impact on the electrical detection of the touch probe, i. e. the delay time for the digital inputs set in [C02830](#) has to be taken into consideration within the delay time [C02810](#).
- For the optional digital frequency input/output the setting of the delay times is effected via separate parameters:
 - C13021 or C14021: TP delay time - digital frequency input.
 - C13061 or C14061: TP delay time - digital frequency output.

8.7.3 "LS_TouchProbe1...8" system block

In the function block editor the **LS_TouchProbe1 ... LS_TouchProbe8** system blocks display the touch probe channels 1 ... 8 which are assigned to the digital inputs **DI1 ... DI8**.




Input	Data type	Value/meaning
TPx_bEnablePosEdge	BOOL	Enable response to positive edge Note: <ul style="list-style-type: none"> If several positive edges occur within the basic cycle time (HighLine: 1 ms), only the first positive edge initiates the touch probe event and no status signal "touch probe(s) lost" is generated.
		TRUE A touch probe event is activated by a positive edge at the digital input DIx.
TPx_bEnableNegEdge	BOOL	Enable response to negative edge Note: <ul style="list-style-type: none"> If several negative edges occur within the basic cycle time (HighLine: 1 ms), only the first negative edge initiates the touch probe event. If a positive and negative edge occur within the basic cycle time (1 ms), and if the response to both edges is enabled, only the positive edge initiates the touch probe event. In both cases no status signal "touch probe(s) lost" is generated.
		TRUE A touch probe event is activated by a negative edge at the digital input DIx.

Output	Data type	Value/meaning
TPx_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB. <ul style="list-style-type: none"> 1 ms \equiv 20 bits
TPx_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> State is only set for one task cycle.
		TRUE Touch probe event has been activated.
TPx_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> State is only set for one task cycle.
		TRUE More than one touch probe event was actuated within the task runtime. The time stamp that is output only refers to the first touch probe event.
TPx_bNegativeEdge	BOOL	Status signal "Negative edge detected" <ul style="list-style-type: none"> State is only set for one task cycle.
		TRUE A negative edge has been detected at the digital input DIx.

8.7.4 "LS_TouchProbeMotor" system block


In the function block editor the **LS_TouchProbeMotor** system block represents the touch probe channel that is assigned to the motor encoder zero pulse.



Output	Data type	Value/meaning
TPM_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB.
TPM_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" • State is only set for one task cycle.
		TRUE Touch probe event has been activated.
TPM_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" • State is only set for one task cycle.
		TRUE More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.

8.7.5 "LS_TouchProbeLoad" system block

In the function block editor the **LS_TouchProbeLoad** system block represents the touch probe channel that is assigned to the position encoder zero pulse.




Output	Data type	Value/meaning
TPL_dnTouchProbeTimeLag	DINT	Scaled time stamp for further processing of the touch probe event with the L_SdTouchProbe FB.
TPL_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" • State is only set for one task cycle.
		TRUE Touch probe event has been activated.
TPL_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" • State is only set for one task cycle.
		TRUE More than one touch probe event was actuated within the task runtime and therefore could not be detected anymore.


8.8 Configure exception handling of the outputs

From »Engineer« version 2.10 onwards, the function block editor for the controller can also be used to configure the behaviour of the analog and digital outputs and that of the brake control and the output ports after a task overflow in order to adapt it to the respective application.



How to configure the exception handling:

1. Go to the *Project view* of the »Engineer« and select the 9400 HighLine controller.
2. Change to the **FB-Editor** tab in the *Workspace*.
3. Click on the  icon in the *FB editor toolbar* to open the *Configure exception handling* dialog box:



- On the **FB TaskOverrun** tab the behaviour of the controller outputs and that of the output ports defined in the application in the case of a task overflow can be configured.
 - On the **FB System Events** tab, the behaviour of the outputs of the drive controller and the application is only displayed and cannot be configured.
4. Carry out the desired configuration.
 - Each output can be configured individually. A free value can be set for the analog outputs (-200.00 ... 200.00 %).
 - If you select an output port in the "Ports" area on the right, all application variables for this output port are shown in the table below. In the "Value" column a value can be set for each application variable to which it is to be set if an event occurs can be specified.
 - If a value has been set for at least one application variable, the status "Exceptional behaviour parameterised" is shown for the corresponding output port.
 - If the **Restore standard settings** button is clicked, the default setting for task overflow is restored. In this case, all output terminals would be set to LOW level or 0 V in the event of a task overflow and the output ports would retain their last value.
 5. Click **OK** to accept the configuration and close the dialog box.

**Danger!**

In case a task overflow occurs, the brake can be configured to "open". This setting should be used with caution as the brake is then forcibly opened and does not close even if the drive controller is inhibited!

**Note!**

- To render the changes effective within the controller, the project has to be updated, and the changed application has to be transferred to the controller.
- During the reset or download of an application, all output signals are set to LOW level or 0 V for a short time (the state bus, in contrast, is set to HIGH level due to hardware inversion).

See also:

▶ [Behaviour after task overflow](#) (📖 109)

9 "CAN on board" system bus

The controller has an integrated CANopen system bus interface ("CAN on board") which is used to exchange i.a. process data and parameter values between the nodes. Furthermore, other modules can be connected via this interface such as decentralised terminals, operator and input devices (HMIs), as well as external controls and host systems.

The interface transfers CAN objects following the CANopen communication profile (CiA DS301, version 4.02) developed by the umbrella organisation of CiA (CAN in Automation) in conformity with the CAL (CAN Application Layer).



Tip!

- The parameters relevant for the CANopen system bus interface are assigned to different subcategories in the parameter list in »Engineer« and in the keypad in the **CAN** category.
- Information on CAN communication modules and CANopen system bus interfaces of other Lenze devices is provided in the "CAN" communication manual in the Lenze library.

9.1 General information

For many years the system bus (CAN) based on the CANopen communication profile has been integrated in Lenze controllers. Due to the lower number of data objects available, the functionality and compatibility of the old system bus are lower as compared with CANopen. For parameter setting, two parameter data channels are always available to the user while CANopen provides only one active parameter data channel (along with the possibility to establish further channels).

The system bus (CANopen) of the Servo Drives 9400 has been developed from the system bus (CAN) of the controller of the 9300 series with the following properties:

- Full compatibility according to CANopen DS301 V4.02.
- Support of the NMT master/slave function "Node Guarding" (DS301 V4.02).
- Support of the "Heartbeat" NMT slave function (DS301, V4.02).
- There are no restrictions regarding the selection of the node addresses.
- Number of parameterisable server and client SDO channels:
 - max. 10 channels with 1 ... 8 bytes
- Number of parameterisable PDO channels:
 - max. 4 Transmit-PDOs (TPDOs) with 1 ... 8 bytes
 - max. 4 Receive-PDOs (RPDOs) with 1 ... 8 bytes
- All PDO channels are functionally equivalent.
- Monitoring of the RPDOs for data reception
- Telegram counters for SDOs and PDOs
- Bus status diagnostics
- Boot-up telegram generation
- Emergency telegram generation
- Reset node telegram generation (in case of master configuration)
- Sync telegram generation and response to sync telegrams:
 - Data transmission/reception
 - Device-internal time base synchronisation
- Abort codes
- All CAN on board functions can be parameterised via codes
- Object directory (all mandatory functions, optional functions, indexes)

9 "CAN on board" system bus

9.1 General information

9.1.1 General data and application conditions

Department	Values
Communication profile	CANopen (DS301 V4.02)
Communication medium	DIN ISO 11898
Network topology	Line closed on both sides (e.g. termination by Sub-D plug, type EWZ0046)
Node addresses that can be set	1 ... 127 • Adjustable via DIP switch on the memory module (exception: memory module MM1xx) or via code C00350 .
Max. number of nodes	127
Baud rate	10, 20, 50, 125, 250, 500, 800, 1000 kbit/s or automatic recognition • Adjustable via DIP switch on the memory module (exception: memory module MM1xx) or via code C00351 .
Process data	• max. 4 TPDOs with 1 ... 8 bytes • max. 4 RPDOs with 1 ... 8 bytes
Parameter data	Max. 10 client and server SDO channels with 1 ... 8 bytes
Transfer mode for TPDOs	• With change of data • Time-controlled, 1 to x ms • After the reception of 1 to 240 sync telegrams

9.1.2 Supported protocols

Category	Protocol
Standard PDO protocols	PDO write PDO read
SDO protocols	SDO download SDO download initiate SDO download segment
	SDO upload SDO upload initiate SDO upload segment
	SDO abort transfer
	SDO block download SDO block download initiate SDO block download end
	SDO block upload SDO block upload initiate SDO block upload end
NMT protocols	Start remote node (master and slave)
	Stop remote node (slave)
	Enter pre-operational (slave)
	Reset node (slave and local device)
	Reset communication (slave)
Monitoring protocols	Node guarding (master and slave)
	Heartbeat (heartbeat producer and heartbeat consumer)

9.1.3 Communication time

The communication time is the time between the start of a request and the arrival of the corresponding response.

**Tip!**

The communication times in the CAN network depend on the

- processing time in the device
- telegram run time (baud rate / telegram length)
- bus load (especially if the bus is loaded with PDOs and SDOs at a low baud rate.)

Servo Drives 9400 processing time

There are no interdependencies between parameter data and process data.


- Parameter data:
 - For controller-internal parameters: approx. 30 ms ± 20 ms tolerance (typically)
 - For some codes the processing time can be longer.
- Process data are transported in real time.

9 "CAN on board" system bus

9.2 Possible settings by DIP switch

9.2 Possible settings by DIP switch

The DIP switches on the front of the memory serve to set the baud rate and the node address.



[9-1] DIP switch

9.2.1 Setting the node address

The node address can be set via code [C00350](#) or with the DIP switches 1 to 64.

- The labelling on the housing corresponds to the values of the individual DIP switches for determining the node address.
- Valid address range: 1 ... 127



Note!

- The addresses of the nodes must differ from each other.
- All twelve DIP switches = OFF (Lenze setting):
 - At switching on, the settings under code [C00350](#) (node address) and [C00351](#) (baud rate) will become active.
- Switch the voltage supply of the standard device off and then on again to activate altered settings.

Example: Setting of the node address 23

DIP switch	64	32	16	8	4	2	1
Switch position	OFF	OFF	ON	OFF	ON	ON	ON
Value	0	0	16	0	4	2	1
Node address	= Sum of the values = 16 + 4 + 2 + 1 = 23						



Tip!

The node address resulting from the setting of the DIP switches at the last mains switching is displayed in [C00349/1](#).

9.2.2 Setting the baud rate

The baud rate can be set via code [C00351](#) or with the DIP switches a to d:

d	Switch positions			Baud rate
	c	b	a	
OFF	ON	ON	OFF	10 kbps
OFF	ON	OFF	ON	20 kbps
OFF	OFF	ON	ON	50 kbps
OFF	OFF	ON	OFF	125 kbps
OFF	OFF	OFF	ON	250 kbps
OFF	OFF	OFF	OFF	500 kbps
ON	ON	ON	OFF	800 kbps
OFF	ON	OFF	OFF	1 Mbps
OFF	ON	ON	ON	Automatic recognition



Note!

Switch the voltage supply of the standard device off and then on again to activate altered settings.



Tip!

The baud rate resulting from the setting of the DIP switches at the last mains switching is displayed in [C00349/2](#).

9 "CAN on board" system bus

9.3 LED status displays for the system bus







9.3 LED status displays for the system bus

Both upper LEDs "CAN-RUN" and "CAN-ERR" on the front of the controller inform about the CANopen state and report CANopen errors.



[9-2] LED status displays CAN-RUN and CAN-ERR


The meaning can be seen from the table below:

LED status display		Meaning	
CAN-RUN	CAN-ERR	CANopen state	CANopen error
Only CAN-ERR is on 		-	Bus off
CAN-RUN and CAN-ERR jitter 		Automatic detection of the baud rate is active.	
CAN-RUN is blinking every 0.2 seconds CAN-ERR is off 		Pre-Operational	-
CAN-RUN is blinking every 0.2 seconds CAN-ERR 1 x blinking, 1 s off 			Warning Limit reached
CAN-RUN is blinking every 0.2 seconds CAN-ERR 2 x blinking, 1 s off 			Node Guard Event
Only CAN-RUN is on 		Operational	-
CAN-RUN on CAN-ERR 1 x blinking, 1 s off 			Warning Limit reached
CAN-RUN on CAN-ERR 2 x blinking, 1 s off 			Node Guard Event
CAN-RUN on CAN-ERR 3 x blinking, 1 s off 			Sync Message Error
CAN-RUN is blinking every 1 second CAN-ERR is off 		Stopped	-
CAN-RUN is blinking every 1 second CAN-ERR 1 x blinking, 1 s off 			Warning Limit reached
CAN-RUN is blinking every 1 second CAN-ERR 2 x blinking, 1 s off 			Node Guard Event

9 "CAN on board" system bus

9.4 Structure of the CAN data telegram

9.4 Structure of the CAN data telegram



[9-3] Basic structure of the CAN telegram

The following subchapters provide a detailed description of the identifier and the user data. The other signals refer to the transfer characteristics of the CAN telegram whose description is not included in the scope of this documentation.



Tip!

Please visit the homepage of the CAN user organisation CiA (CAN in automation) for further information:

<http://www.can-cia.org>

9.4.1 Identifier

The principle of the CAN communication is based on a message-oriented data exchange between a transmitter and many receivers. All nodes can transmit and receive quasi-simultaneously.

The identifier, also called COB-ID (abbr. for communication object identifier), is used to control which node is to receive a transmitted message. In addition to the addressing, the identifier contains information on the priority of the message and the type of user data.

The identifier consists of a basic identifier and the node address of the node to be addressed:

Identifier (COB-ID) = basic identifier + node address (node ID)

Exception: The identifier for process data/heartbeat/emergency objects as well as network management and sync telegrams is freely assigned by the user (either manually or automatically by the network configurator), or is permanently assigned.

Node address (node ID)

Every node of the system bus network must be assigned to a node address (also called node ID) within the valid address range (1 ... 127) for unambiguous identification.

- Assigning a node address more than once within a network is impermissible.
- The own node address can be configured via the DIP switch of the memory module (exception: MM1xx memory module) or via code [C00350](#). ▶ [Setting the node address](#) (📖 299)

Identifier assignment

The system bus is message-oriented instead of node-oriented. Every message has an unambiguous identification, the identifier. For CANopen, node-oriented transfer is achieved by the fact that every message has only one transmitter.

- The basic identifiers for network management (NMT) and sync as well as the basic SDO channel (SDO1) are defined in the CANopen protocol and cannot be changed.
- The basic identifiers of the PDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02 and can be changed via parameters/indexes, if required. ▶ [Identifiers of the process data objects](#) (📖 310)

Object	Direction		Basic identifier	
	from device	to device	dec	hex
Network management (NMT)			0	0
Sync			128	80
Emergency	●		128	80
PDO1 (process data channel 1)	TPDO1	●	384	180
	RPDO1		512	200
PDO2 (Process data channel 2)	TPDO2	●	640	280
	RPDO2		768	300
PDO3 (Process data channel 3)	TPDO3	●	896	380
	RPDO3		1024	400
PDO4 (Process data channel 4)	TPDO4	●	1152	480
	RPDO4		1280	500
SDO1 (Basic SDO channel)	●		1408	580
		●	1536	600
SDO2 ... SDO10 (parameter data channel 2 ... 10)	●		1472	5C0
		●	1600	640
Node guarding, heartbeat	●		1792	700

9.4.2 User data

All nodes communicate by exchanging data telegrams via the system bus. The user data area of the CAN telegram either contains network management data or parameter data or process data:

Network management data

(NMT data)

- Control information on start, stop, reset, etc. of communication to specific nodes or to all nodes of the CAN network.

Process data

(PDOs – process data objects)

- Process data are transferred via the process data channel.
- Process data can be used to control the controller.
- Process data are not saved to the controller.
- Process data are transmitted between host system and nodes to ensure continuous exchange of current input and output data.
- Process data usually are unscaled/scalable raw data.
- Process data are, for instance, setpoints and actual values.

Parameter data

(SDOs – service data objects)

- Parameter data are the CANopen indexes or, in case of Lenze devices, the codes.
- Parameters are set, for instance, when the system is initially adjusted during commissioning or when the material of the production machine is changed.
- Parameter data are transmitted as SDOs via the parameter data channel. They are acknowledged by the receiver, i.e. the transmitter gets a feedback about the transmission being successful or not.
- The parameter data channel enables access to all Lenze codes and CANopen indexes.
- Parameter changes are automatically saved to the controller until mains switching.
- In general, the parameter transfer is not time-critical.
- Parameter data are, for instance, operating parameters, diagnostic information, and motor data.

9.5 Communication phases/network management

Regarding communication via the system bus, the controller distinguishes between the following statuses:

State	Explanation
"Initialisation" (Initialisation)	After switch-on, an initialisation run is carried out. <ul style="list-style-type: none"> • During this phase, the controller is not involved in the data exchange via the bus. • The standard values are re-written to all CAN-relevant parameters. • After initialisation is completed, the controller is automatically set to the "Pre-Operational" status.
"Pre-Operational" (before being ready for operation)	Parameter data can be received, process data are ignored.
"Operational" (ready for operation)	Parameter data and process data can be received!
"Stopped" (stopped)	Only network management telegrams can be received.


Communication object	Initialisation	Pre-Operational	Operational	Stopped
PDO			●	
SDO		●	●	
Sync		●	●	
Emergency		●	●	
Boot-up	●			
Network management (NMT)		●	●	●





Tip!

Part of the initialisation or the entire initialisation can be carried out anew in every status by transferring the corresponding network management telegrams.

9.5.1 State transitions




[9-4] NMT status transitions in the CAN network

Transition	NMT command	Status after change	Effects on process/parameter data after status change
(1)	-	Initialisation	Initialisation starts automatically when the mains is switched on. <ul style="list-style-type: none"> • During initialisation, the controller is not involved in the data exchange. • After the initialisation is completed, the node sends a boot-up message with an individual identifier and automatically changes to the "pre-operational" status.
(2)	-	Pre-Operational	In this phase, the master determines the way in which the node(s) takes/take part in communication.
	From here, the master changes the statuses for the entire network. <ul style="list-style-type: none"> • A target address included in the NMT command defines the receiver(s). • If the 9400 controller has been configured as CAN master, the state automatically changes to "Operational" after the waiting time has expired (C00378) and the NMT command 0x0100 ("Start Remote Node") is sent to all nodes. • Data can only be exchanged via process data objects if the status is "Operational"! 		
(3), (6)	0x01 xx Start remote node	Operational	Network management/sync/emergency telegrams as well as process data (PDO) and parameter data (SDO) are active. Optional: When the status is changed, event and time-controlled process data (PDOs) are transmitted once.
(4), (7)	0x80 xx Enter Pre-Operational	Pre-Operational	Network management/sync/emergency telegrams and parameter data (SDO) are active.
(5), (8)	0x02 xx Stop remote node	Stopped	Only network management telegrams can be received.
(9), (10), (11)	0x81 xx Reset node	Initialisation	All CAN-relevant parameters (CiA DS 301) are initialised with the saved values.
(12), (13), (14)	0x82 xx Reset communication		All CAN-relevant parameters (CiA DS 301) are initialised with the saved values.
	Meaning of the node address in the NMT command: <ul style="list-style-type: none"> • xx = 0x00: If this assignment is selected, the telegram addresses all nodes (broadcast telegram). The status of all nodes can be changed at the same time. • xx = Node ID: If a node address is specified, only the status of the node with the corresponding address changes. 		

9.5.2 Network management telegram (NMT)

The telegram for the network management contains identifier "0" and the command included in the user data which consists of the command byte and the node address:



[9-5] Network management telegram for changing over the communication phases

Command specifier (cs)		NMT command
dec	hex	
1	0x01	Start remote node
2	0x02	Stop remote node
128	0x80	Enter Pre-Operational
129	0x81	Reset node
130	0x82	Reset communication

The communication phases are changed over by a node, the CAN master, for the entire network. The CAN master can also be a controller. ▶ [Parameterising the controller as CAN master](#) (📖 308)

Example:

Data can only be exchanged via process data objects if the status is "Operational". If the CAN master is supposed to switch all nodes connected to the bus from the "Pre-Operational" communication status to the "Operational" communication status, the identifier and user data in the transmission telegram must be set as follows:

- Identifier: 0x00 (network management)
- User data: 0x0100 ("Start remote node" NMT command to all nodes)

9.5.3 Parameterising the controller as CAN master

If the initialisation of the system bus and the associated status change from "Pre-Operational" to "Operational" is not effected by a superimposed host system, the controller can instead be defined to be a "quasi" master to execute this task.

The controller is configured as CAN master in [C00352](#).

- Being the CAN master, the controller sets all nodes connected to the bus (broadcast telegram) to the "Operational" communication status with the "Start remote node" NMT telegram. Only in this communication status, data can be exchanged via process data objects.
- In [C00378](#), you can set a delay time which must elapse after power-up before the controller applies the "Start Remote Node" NMT telegram to the bus.

Parameters	Info	Lenze setting	
		Value	Unit
C00352	CAN slave/master	slave	
C00378	CAN delay boot-up - Operational	3000	ms



Note!

The changes of the master/slave operation in [C00352](#) will not be activated until

- another mains switching of the controller

or

- the "Reset node" or "Reset communication" NMT telegram has been transmitted to the controller.


As an alternative to the "Reset Node" NMT telegram, the device command [C00002](#) = "91: CAN on board: Reset Node" can be used to reinitialise the CAN-specific device parameters.



Tip!

Master functionality is only required during the initialisation phase of the drive system.

9.6 Process data transfer



[9-6] PDO data transfer from / to the higher-level host system

For the transfer of process data, four separated process data channels (PDO1 ... PDO4) are available.

Definitions

- Process data telegrams between the host system and the devices are distinguished in terms of direction as follows:
 - Process data telegrams to the device (RPDO)
 - Process data telegrams from the device (TPDO)
- The CANopen process data objects are designated as seen from the node's view:
 - Receive PDOs (RPDOx): Process data object received by a node
 - Transmit PDOs (TPDOx): Process data object sent by a node



Note!

Data can only be exchanged via process data objects if the status is "Operational"!

▶ [Communication phases/network management](#) (📖 305)

9.6.1 Identifiers of the process data objects

The identifiers for the process data objects PDO1 ... PDO4 in the Lenze setting result from the basic identifier and the node address set in [C00350](#).

Identifier (COB-ID) = basic identifier + node address (node ID)

- The basic identifiers of the PDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02.
- The identifiers for the PDOs can be set individually via the Lenze codes and CANopen indexes listed in the following table. Thus, you can also set an identifier independent of the node address for certain PDOs.

Process data object	Basic identifier		Individual setting	
	dec	hex	Lenze code	CANopen index
PDO1				
RPDO1	512	0x200	C00321/1	I-1400/1
TPDO1	384	0x180	C00320/1	I-1800/1
PDO2				
RPDO2	768	0x300	C00321/2	I-1401/1
TPDO2	640	0x280	C00320/2	I-1801/1
PDO3				
RPDO3	1024	0x400	C00321/3	I-1402/1
TPDO3	896	0x380	C00320/3	I-1802/1
PDO4				
RPDO4	1280	0x500	C00321/4	I-1403/1
TPDO4	1152	0x480	C00320/4	I-1803/1



Note!

After the node address ([C00350](#)) has changed and a subsequent CAN reset node, the identifiers which result from the corresponding basic identifiers and the set node address are automatically set again in the subcodes of [C00320](#) and [C00321](#).



Tip!

The "Predefined Connection Set" can be re-established anytime using the following device commands ([C00002](#)):

- "93: CAN on board: Pred.Connect.Set" for CAN on board
- "94: CAN module: Pred.Connect.Set" for E94AYCCA communication module

9.6.2 Transmission type

The process data objects are transmitted in an event-controlled or time-controlled way.

- **Event-controlled:** The PDO is sent if a special device-internal event has occurred, for instance, when the data contents of the TPDO have changed or when a transmission cycle time has elapsed.
- **Synchronous:** A TPDO (or RPDO) is transmitted (or received) after the device has received a sync telegram (with identifier 0x80).
- **Cyclically:** The PDOs are transmitted in fixed time intervals after the transmission cycle time has elapsed.

The table shows that combinations of logic operations (AND, OR) are also possible between the different transmission modes:

Transmission type	PDO transmission			Logic operation
	cyclic	synchronous	event-controlled	
0		●	●	AND
1 ... 240		●		-
254, 255	●		●	OR

Transmission type	Description
0	The PDO is transmitted on an event-controlled basis with every sync (e.g. when a bit change occurs in the PDO).
1 ... 240	SYNC (with response) <ul style="list-style-type: none"> • Selection n = 1: The PDO is transmitted with <u>every</u> sync. • Selection 1 < n ≤ 240: The PDO is transmitted with <u>every n-th</u> sync.
254, 255	Event-controlled (with mask) with cyclic overlay If this value is entered, the PDO transmission is event-controlled <u>or</u> cyclic. (Note: The values "254" and "255" have the same meaning). For cyclic overlay, a cycle time must be set for the respective PDO. In this case, cyclic transmission takes place in addition to event-controlled transmission (e.g. through a bit change in the PDO).

The communication parameters such as the transmission mode and cycle time can be set freely for every PDO and independently of the settings of other PDOs:

Parameters	Info	Lenze setting	
		Value	Unit
C00322/1...4	CAN TPDOx Tx mode	254	
C00323/1...4	CAN RPDOx Rx mode	254	
C00324/1...4	CAN TPDOx delay time	0	1/10 ms
C00356/1...4	CAN TPDOx cycle time	0	ms



Tip!

The setting can also be carried out via the following CANopen objects:

- [I-1400](#) ... [I-1403](#): Communication parameters for RPDO1 ... RPDO4
- [I-1800](#) ... [I-1803](#): Communication parameters for TPDO1 ... TPDO4

9.6.3 Masking of the TPDOs for event control

For TPDO1 ... TPDO4, a mask can be parameterised for every byte. In case of the event-controlled transmission of a PDO, only the masked bits are used for the event control.

- Mask "0x0" means that no bit of the corresponding byte actuates the transmission.
- Mask "0xff" means that every bit of the corresponding byte can actuate the transmission.

Short overview: Parameters for masking the TPDOs

Parameters	Info	Lenze setting	
C00311/1...8	CAN TPDO1 mask byte x	0x00	
C00312/1...8	CAN TPDO2 mask byte x	0x00	
C00313/1...8	CAN TPDO3 mask byte x	0x00	
C00314/1...8	CAN TPDO4 mask byte x	0x00	

9.6.4 Monitoring of the RPDOs for data reception

For RPDO1 ... RPDO4 each, a monitoring time can be parameterised within which the RPDO must arrive. If the RPDO is not received within the monitoring time or not with the configured sync, the response parameterised for each RPDO takes place.

Short overview: Parameters for RPDO monitoring


Parameters	Info	Lenze setting	
		Value	Unit
C00357/1...4	CAN RPDOx monitoring time	3000	ms
C00591/1...4	Resp. to CAN RPDOx error	No response	

9.6.5 Synchronisation of PDOs via sync telegram

During cyclic transmission, one or more PDOs are transmitted/received in fixed time intervals. An additional specific telegram, the so-called sync telegram, is used for synchronising cyclic process data.

- The sync telegram is the trigger point for the transmission of process data from the slaves to the master and for the acceptance of process data from the master in the slaves.
- For sync-controlled process data processing, the sync telegram must be generated accordingly.
- The response to a sync telegram is determined by the transmission type selected.
 - ▶ [Transmission type](#) (311)

Basic workflow



[9-7] Sync telegram

- After the sync telegram has been received, the slaves transmit the synchronous process data to the master (TPDOs). The master reads them as process input data.
- When the transmission process is completed, the slaves receive (RPDOs) the process output data (of the master).
 - All other telegrams (e.g. parameters or event-controlled process data) are accepted acyclically by the slaves after the transmission is completed.
 - Illustration [9-7] does not include acyclic data. However, they need to be considered when dimensioning the cycle time.
- The data are accepted in the slave with the next sync telegram if the Rx mode is set to 1 ... 240. If the Rx mode is 254 or 255, the data are accepted in the next device cycle, irrespective of the sync telegram.

9.6.5.1 Parameter setting

Short overview: Parameters for the synchronisation via sync telegram

Parameters	Info	Lenze setting		Assignment	
		Value	Unit	Sync master	Sync slave
C00367	CAN SYNC Rx identifier	128			●
C00368	CAN SYNC Tx identifier	128		●	
C00369/1	CAN sync transmission cycle time	0	ms	●	
C01120	Sync source	Off			●
C01121	Sync cycle time For synchronisation via the system bus, only integer multiples of 1000 µs should be set.	1000	µs		●
C01122	Sync phase position	400	µs		●
C01123	Sync tolerance	0	µs		●
C01124	Sync PLL increment	109	ns		●
C01130	Sync application cycle	1000	µs		●



Note!

The following codes are ineffective if the servo inverter is synchronised via a communication module:

- [C01121](#)
- [C01122](#)
- [C01123](#)
- [C01124](#)

Sync source

[C01120](#) is used to select the source of the synchronisation signals. Basically, only one source can synchronise the node.

Sync cycle time

Time interval at which the internal phase-locking loop (PLL) expects the synchronisation signals.

The sync cycle time must be set in [C01121](#), matching the cycle of the synchronisation source selected in [C01120](#).

- Example 1:
For the system bus the interval between two synchronisation signals has been set with 2 ms. If the system bus is to be used as synchronisation source, a sync cycle time of 2000 µs must be set in [C01121](#).
- Example 2:
The cycle time of the application task running in the user application must also comply exactly with the sync cycle time.
Therefore, the following constellation can not be implemented:
 - Cycle time of the application task: 2 ms
 - Sync cycle time: 4 ms

Sync phase position

The phase position defines the zero point of time for the application relating to the synchronisation signal (bus cycle). Since PDO processing is integrated in the system part of the application, the instant of the PDO acceptance also changes if the phase position is changed.

- If 0 is set, the application is started together with the synchronisation signal.
- If a value > 0 is set, the application starts by the set time interval before the synchronisation signal arrives (the phase position acts negatively).

Example: If the phase position is set to 400 µs, the system part of the application starts 400 µs before the synchronisation signal arrives.



Note!

From software version V3.0:

The effect of the sync phase position can be affected by the application cycle set in [C01130](#). For the Lenze setting of [C01130](#) the behaviour remains as before.

Sync tolerance

Time slot for monitoring the synchronisation signal via the system block **LS_SyncInput**. ▶ [System block "LS_SyncInput"](#) (367)

- If the last synchronisation signal has been within this time slot around the expected value, the *SYNC_bSyncInsideWindow* output of the **LS_SyncInput** system block is set to TRUE.
- This setting does not affect the synchronisation process.

Sync PLL increment

If the cycle times of the synchronisation signal and the phase-locking loop (PLL) differ from each other, the setting in [C01124](#) defines the increment with which the phase-locking loop can be readjusted.

- The recommended reset time for the system bus as synchronisation source with regard to occurring deviations is 109 ns (Lenze setting).

Sync application cycle

This parameter influences the effect of the sync phase position ([C01122](#)) with regard to the instant of acceptance of the synchronous PDOs by the application or the instant of transmission of the synchronous PDOs to the system bus.

The following applies to software versions lower than V3.0:

- The sync application cycle is fixedly set to 1000 µs.
- The resulting PDO delay can be calculated with the following formula taking into consideration an internal processing time of 150 s:

$$\text{PDO delay} = (\text{sync cycle time} - \text{sync phase position} + 150 \mu\text{s}) \text{ modulo } 1000$$

The following applies from software version V3.0:

- The sync application cycle can be set in [C01130](#). The value set is automatically rounded down to full 1000 µs.
- The resulting PDO delay can be calculated with the following formula, taking an internal processing time of 150 s into consideration:

$$\text{PDO delay} = (\text{sync cycle time} - \text{sync phase position} + 150 \mu\text{s}) \text{ modulo } \text{C01130}$$







Note!

If the sync application cycle in [C01130](#) is set higher than the sync cycle time ([C01121](#)), the response is undefined. The same applies if the sync phase position ([C01122](#)) is set higher than the sync cycle time ([C01121](#)).


Usually, no synchronous PDOs are then applied to the system bus anymore.

9.6.5.2 Effect of C01130 on the sync phase position





9.7 Parameter data transfer



[9-8] Parameter data transfer via the available parameter data channels

Parameters are values stored in codes on Lenze controllers.

Ten separate parameter data channels are available for parameter setting, enabling the simultaneous connection of several devices for configuration.

Parameter data are transmitted via the system bus as SDOs ("Service Data Objects") and acknowledged by the receiver. The SDO enables read and write access to the object directory. Indexes (e.g. [I-1000](#)) ensure access to parameters and functions included in the object directory. To transfer SDOs, the information contained in the user data must comply with the CAN-SDO protocol.

9.7.1 Identifiers of the parameter data objects

The identifiers for the parameter data objects SDO1 ... SDO10 in the Lenze setting result from the basic identifier and the node address set in [C00350](#).

Identifier (COB-ID) = basic identifier + node address (node ID)

- The basic identifiers of the SDOs are preset in the Lenze setting according to the "Predefined Connection Set" of DS301 V4.02.

Parameter data object	Direction		Basic identifier	
	from device	to device	dec	hex
SDO1 (Parameter data channel 1)	●		1408	580
		●	1536	600
SDO2 ... 10 (parameter data channel 2 ... 10)	●	●	deactivated	
Node guarding, heartbeat	●		1792	700
Boot-up	●		1792	700



Note!

Please observe that the parameter data channels 2 ... 10 are deactivated in the Lenze setting.

The procedure for activating these parameter data channels is explained in the description of parameters [C00372](#) and [C00373](#) and the description for the implemented CAN object [I-1201](#). ▶ [Example](#) (📖 355)

9.7.2 User data

Structure of the user data of the parameter data telegram

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	LOW byte	HIGH byte		LOW word		HIGH word	
				LOW byte	HIGH byte	LOW byte	HIGH byte



Note!

For the user data, the Motorola format is used.

▶ [Parameter data telegram examples](#) (📖 325)

The following subchapters provide detailed information on user data.

9.7.2.1 Command

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	LOW byte	HIGH byte		LOW word		HIGH word	
				LOW byte	HIGH byte	LOW byte	HIGH byte

The following commands can be transmitted or received for writing and reading the parameters:

Command	1st byte		Data length	Info
	hex	dec		
Write request	0x23	35	4 bytes	Writing of a parameter to the controller.
	0x2B	43	2 bytes	
	0x2F	47	1 byte	
	0x21	33	Block	
Write response	0x60	96	4 bytes	Controller acknowledges a write request.
Read request	0x40	64	4 bytes	Reading of a parameter from the controller.
Read response	0x43	67	4 bytes	Controller's response to a read request with the current parameter value.
	0x4B	75	2 bytes	
	0x4F	79	1 byte	
	0x41	65	Block	
Error response	0x80	128	4 bytes	Response from the controller when the read/write request could not be executed correctly. ▶ Error messages (322)

More precisely, the command byte comprises the following information:

Command	1st byte							
	Command specifier (cs)			Toggle (t)	Length*		E	s
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Write request	0	0	1	0	0/1	0/1	1	1
Write response	0	1	1	0	0	0	0	0
Read request	0	1	0	0	0	0	0	0
Read response	0	1	0	0	0/1	0/1	1	1
Error response	1	0	0	0	0	0	0	0

*Bit coding of the length: 00 = 4 bytes, 01 = 3 bytes, 10 = 2 bytes, 11 = 1 byte
e: expedited (shortened block service)
s: segmented (normal block service)



Tip!

More commands are defined in CANopen specification DS301, V4.02 (e.g. segmented transfer).

9.7.2.2 Addressing by means of index and subindex

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	LOW byte	HIGH byte		LOW word		HIGH word	
				LOW byte	HIGH byte	LOW byte	HIGH byte

A parameter (a Lenze code) is addressed as per the following formula:
Index = 24575 - (Lenze code number)

Example

The [C00011](#) parameter (motor reference speed) is to be addressed.

Calculation:

- Index:
 - Decimal: $24575 - 11 = 24564$
 - Hexadecimal: $0x5FFF - 0xB = 0x5FF4$
- Subindex: 0x00 (subindex 0 since the parameter does not have any subcodes)

Entries:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	0xF4	0x5F	0x00				

9.7.2.3 Data 1 ... Data 4

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
	LOW byte	HIGH byte		LOW word		HIGH word	
				LOW byte	HIGH byte	LOW byte	HIGH byte

Maximally 4 bytes are available for parameter value entries. Depending on the data format, they are assigned as follows:

5th byte	6. byte	7th byte	8th byte
Parameter value (1 byte)	0x00	0x00	0x00
Parameter value (2 bytes)		0x00	0x00
LOW byte	HIGH byte		
Parameter value (4 bytes)			
LOW word		HIGH word	
LOW byte	HIGH byte	LOW byte	HIGH byte

**Note!**

The "Factor" column of the [Table of attributes](#) contains a so-called scaling factor for all Lenze parameters. The scaling factor is relevant to the transfer of parameter values which have one or more decimal positions in the parameter list.

If the scaling factor is > 1, the value must be multiplied by the indicated scaling factor prior to transmission to be able to transfer the value as an integer. At the SDO client end, the integer must be divided by the scaling factor to obtain the original value including decimal positions again.

Example

For a code with the scaling factor "100" and the data format U32 the value "123.45" is to be transmitted.

Calculation:

- Value to be transmitted = scaling factor x value
- Data (1...4) = 100 x 123.45 = 12345 (0x00 00 30 39)

Entries:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
				0x39	0x30	0x00	0x00

9.7.2.4 Error messages

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Error code			
0x80 (128)	LOW byte	HIGH byte		LOW word		HIGH word	
				LOW byte	HIGH byte	LOW byte	HIGH byte

In the event of an error, the addressed node generates a telegram with the "Error response" (0x80) command.

- The telegram includes the index and subindex of the code where the error occurred.
- The error code is entered in bytes 5 ... 8.
 - The error codes are standardised according to DS301, V4.02.
 - The representation of the error codes is provided in reverse read direction (see example below).

Example

Representation of error code "0x06 04 00 41" in bytes 5 ... 8:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Error code			
				0x41	0x00	0x04	0x06

Meaning of the error codes

Error code	Explanation
0x0503 0000	Toggle bit not changed.
0x0504 0000	SDO protocol expired.
0x0504 0001	Invalid or unknown client/server command specifier.
0x0504 0002	Invalid block size (block mode only).
0x0504 0003	Invalid processing number (block mode only).
0x0504 0004	CRC error (block mode only).
0x0504 0005	Memory does not suffice.
0x0601 0000	Object access not supported.
0x0601 0001	Attempted read access to a writable only object.
0x0601 0002	Attempted write access to a readable only object.
0x0602 0000	Object not listed in object directory.
0x0604 0041	Object not mapped to PDO.
0x0604 0042	Number and length of objects to be transferred longer than PDO length.
0x0604 0043	General parameter incompatibility.
0x0604 0047	General internal device incompatibility.
0x0606 0000	Access denied because of hardware error.
0x0607 0010	Unsuitable data type (unsuitable service parameter length).
0x0607 0012	Unsuitable data type (service parameter length exceeded).
0x0607 0013	Unsuitable data type (service parameter length too short).
0x0609 0011	Subindex does not exist.
0x0609 0030	Parameter value range exceeded.
0x0609 0031	Parameter values too high.
0x0609 0032	Parameter values too low.
0x0609 0036	Maximum value falls below minimum value.
0x0800 0000	General error.
0x0800 0020	Data cannot be transferred or saved for application.
0x0800 0021	Data cannot be transferred or saved for application due to local control.
0x0800 0022	Data cannot be transferred or saved for application due to current device status.
0x0800 0023	Dynamic generation of object directory failed or no object directory available (e.g. object directory generated from file, generation not possible because of a file error).

9 "CAN on board" system bus

9.7 Parameter data transfer

9.7.3 Parameter data telegram examples

9.7.3.1 Read parameters

Task: The heatsink temperature of 43 °C (code [C00061](#), data format INTEGER32, scaling factor 1) is to be read from the controller with node address 5.

Telegram to drive

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0605	0x40	0xC2	0x5F	0x00	0x00	0x00	0x00	0x00

Explanations on the telegram to the drive	
Identifier	= 1536 + node address = 1536 + 5 = 1541 = 0x0605 (1536 = SDO1 basic identifier to the controller)
Command	= 0x40 = "Read request" (read request of a parameter from the controller)
Index	= 24575 - code number = 24575 - 61 = 24514 = 0x5FC2
Subindex	= 0 (code C00061 does not have any subcodes)

Response telegram from drive (if data have been correctly transmitted)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0585	0x43	0xC2	0x5F	0x00	0x2B	0x00	0x00	0x00

Explanations on the telegram from the drive	
Identifier	= 1408 + node address = 1408 + 5 = 1413 = 0x0585 (1408 = SDO1 basic identifier from the controller)
Command	= 0x43 = "Read Response" (response to read request with current value)
Index	as in telegram to the drive
Subindex	
Data 1 ... 4	= 0x0000002B = 43 [°C]

9.7.3.2 Write parameters

Task: The rated current of the connected motor with $I_{rated} = 10.2 \text{ A}$ (code [C00088](#)) is to be entered in the controller.

Telegram to drive

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0602	0x23	0xA7	0x5F	0x00	0x66	0x00	0x00	0x00

Explanations on the telegram to the drive	
Identifier	= 1536 + node address = 1536 + 2 = 1538 = 0x0602 (1536 = SDO1 basic identifier to the controller)
Command	= 0x23 = "Write request" (write request of a parameter to the controller)
Index	= 24575 - code number = 24575 - 88 = 24487 = 0x5FA7
Subindex	= 0 (code C00088 does not have any subcodes)
Data 1 ... 4	= 10,2 x 10 = 102 = 0x00000066 (Value for motor current, data type U32; display factor 1/10)

Response telegram from drive (if data have been correctly transmitted)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x0582	0x60	0xA7	0x5F	0x00	0x00	0x00	0x00	0x00

Explanations on the telegram from the drive	
Identifier	= 1408 + node address = 1408 + 2 = 1410 = 0x0582 (1408 = SDO1 basic identifier from the controller)
Command	= 0x60 = "Write response" (Acknowledgement of the write access from the controller)
Index	as in telegram to the drive
Subindex	

9.7.3.3 Read block parameters

Task: The firmware version (code [C00099](#)) is to be read from the parameter set of the controller with node address "12". The firmware version has a length of 11 ASCII characters which are transmitted as a block parameter. Depending on the block, the data width from the 2nd to 8th byte is assigned within the user data.

Telegram 1 to the drive: Read request

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x060C	0x40	0x9C	0x5F	0x00	0x00	0x00	0x00	0x00

Explanations on the telegram to the drive	
Identifier	= 1536 + node address = 1536 + 12 = 1548 = 0x060C (1536 = SDO1 basic identifier to the controller)
Command	= 0x40 = "Read request" (read request of a parameter from the controller)
Index	= 24575 - code number = 24575 - 99 = 24476 = 0x5F9C
Subindex	= 0 (code C00099 does not have any subcodes)

Response telegram 1 from the drive: Indication of the block length (11 characters)

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x058C	0x41	0x9C	0x5F	0x00	0x0B	0x00	0x00	0x00

Explanations on the telegram from the drive	
Identifier	= 1408 + node address = 1408 + 12 = 1420 = 0x058C (1408 = SDO1 basic identifier from the controller)
Command	= 0x41 = "Read response" (response is block telegram)
Index	as in telegram to the drive
Subindex	
Data 1 ... 4	= 0x0000000B = data length of 11 characters in the ASCII format

Telegram 2 to the drive: Request of the 1st data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x060C	0x60	0x00	0x00	0x00	0x00	0x00	0x00	0x00

Explanations on the telegram to the drive	
Command	= 0x60 = "Read segment request" (request: read data block) <ul style="list-style-type: none"> • Bit 4 = 0 (toggle bit)
	Influence of the toggle bit on the request command The blocks are toggled one after another, i.e. the request is made with the "0x60" (= 0110*0000 _{bin}) command, then with the "0x70" (= 0111*0000 _{bin}) command, and then again with the "0x60" command, etc. * Toggle bit

Response telegram 2 from the drive: Transmission of the 1st data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x058C	0x00	0x30	0x31	0x2E	0x30	0x30	0x2E	0x30
		0 _{asc}	1 _{asc}	·asc	0 _{asc}	0 _{asc}	·asc	0 _{asc}

Explanations on the telegram to the drive	
Command	= 0x00 = 00000000 _{bin} <ul style="list-style-type: none"> • Bit 4 = 0 (toggle bit)
	Influence of the toggle bit on the transmission command <ul style="list-style-type: none"> • The 1st response of the controller in the command byte is "0x0000*0000_{bin}" if bytes 2 ... 8 are completely filled with data and other telegrams are following. • The 2nd response of the controller in the command byte is "0x0001*0000_{bin}" if bytes 2 ... 8 are completely filled with data and other telegrams are following, etc. * Toggle bit
Data 1 ... 7	= "01.00.0" (ASCII representation)

Telegram 3 to the drive: Request of the 2nd data block

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x060C	0x70	0x00	0x00	0x00	0x00	0x00	0x00	0x00

Explanations on telegram 3 to the drive	
Command	= 0x70 = "Read segment request" (request: read data block) • Bit 4 = 1 (toggle bit)

Response telegram 3 from the drive: Transmission of the 2nd data block including end identifier

Identifier	User data							
	1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
	Command	Data 1	Data 2	Data 3	Data 4	Data 5	Data 6	Data 7
0x058C	0x17	0x30	0x2E	0x30	0x30	0x00	0x00	0x00
		0 _{asc}	·asc	0 _{asc}	0 _{asc}	-	-	-

Explanations on telegram 3 from the drive	
Command	= 0x17 = 00010111 _{bin} : • Bit 0 = 1 (end of transmission) • Bit 1 ... bit 3 = 011 _{bin} (3 bytes do not contain any data) • Bit 4 = 1 (toggle bit)
	Influence of the final bit and the residual data length on the transmission command • The end of transmission is signalled via the set final bit 0. • Bits 1 ... 3 reveal the number of bytes that do not contain any data anymore. * Toggle bit
Data 1 ... 7	= "0.00" (ASCII representation) The result of the data block transmission is: "01.00.00.00"

9.8 Diagnostics

The display parameters listed in the following table serve to request current information on the system bus for diagnostic purposes, e.g. using the keypad, via a bus system, or using »Engineer« (when an online connection has been established to the controller).

- The »Engineer« parameter list and the keypad contain these parameters in the category **CAN → CAN management**.
- A detailed description of these parameters can be found in the chapter "[Parameter reference](#)".
([□ 724](#))


Parameters	Display
C00345	CAN error
C00359	CAN status
C00360/1	CAN stuffing bit error counter
C00360/2	CAN format error counter
C00360/3	CAN acknow. error counter
C00360/4	CAN bit 1 error counter
C00360/5	CAN bit 0 error counter
C00360/6	CAN CRC error counter
C00360/7	CAN Tx telegram counter
C00360/8	CAN Rx telegram counter
C00361/1	CAN bus load: Current node load in Tx direction
C00361/2	CAN bus load: Current node load in Rx direction
C00361/3	CAN bus load: Current node load of faulty telegrams
C00361/4	CAN bus load: Node peak load in Tx direction
C00361/5	CAN bus load: Node peak load in Rx direction
C00361/6	CAN bus load: Node peak load of faulty telegrams
C00390	CAN error register (DS301V402)

9.9 Monitoring

9.9.1 Node guarding protocol

In a CAN network, the node guarding protocol serves to monitor the connection between the NMT master and the NMT slave(s). If the controller was parameterised as NMT master, it can monitor up to 32 NMT slaves.

Basic workflow



[9-9] Node guarding protocol

1. The NMT master within cyclic time intervals sends a data telegram to the NMT slave, which is referred to as "Remote Transmission Request" (RTR).
2. The NMT slave then returns a response telegram ("Response") to the NMT master.

9.9.1.1 Telegram structure

RTR telegram

- The RTR telegram from the NMT master has the following identifiers:
Identifier (COB-ID) = 1792 + node address of the NMT slave
- The RTR telegram does not contain any user data.
- The RTR bit in the arbitration field of the RTR telegram is set to the valency LOW (dominant level).

Response message

- The response telegram from the requested NMT slave has the same identifier as the RTR telegram received by the NMT master.
- The user data (1 byte) contains the NMT slave status and the toggle bit (see the following description).

NMT slave state (s)

NMT slave status		Data								
Communication status	Decimal value (s)	(t)	NMT slave state (s)							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
Stopped	4	0/1	0	0	0	0	0	1	0	0
Operational	5	0/1	0	0	0	0	0	1	0	1
Pre-Operational	127	0/1	1	1	1	1	1	1	1	1

Toggle bit (t)

- The toggle bit (t) in the response telegram has the value "0" when the node guarding protocol is activated for the first time.
- The toggle bit (t) must change its value with each response.



Note!

The toggle bit is monitored by the NMT master.

If a telegram is received with a toggle bit value that has not changed compared to the previously received telegram, it will be treated as if it were not received, i.e. the monitoring time is not reset and elapses further.

The toggle bit can only be reset to the value "0" by the "Reset Communication" telegram of the NMT master.

9.9.1.2 Parameter setting

Short overview of parameters for the "Node Guarding" monitoring function:

Parameters	Info	Lenze setting		Assignment	
		Value	Unit	master	slave
C00382	CAN guard time	0	ms		●
C00383	CAN life time factor	0			●
C00386/1...32	CAN node guarding	0x00000000		●	
C00387	CAN Node Guarding Activity	-		●	
C00388/1...32	CAN node guarding status	-		●	
C00612/1...32	Resp. to CAN node guarding error	No response		●	
C00614	Resp. to CAN life guarding error	No response			●
C00625	CAN behaviour in case of fault	Pre-operational state		●	●

Greyed out = display parameter

Guard time

The time interval with which the NMT master transmits the RTR telegram is the guard time.

- For each NMT slave to be monitored an individual time interval can be set.
- The RTR telegram prompts the NMT slave to send its current status.

Node life time

The node life time is the product of the guard time and the life time factor:

node life time = guard time x life time factor

- "Life time factor" and "Guard time" have to be known to the NMT master. For this, the values from the NMT slave are read at each reboot, or defined values are sent to the NMT slave at each reboot.
- It is possible to select a different "node life time" for each NMT slave to be monitored.

OK status

The status of the connection is ok (OK status) if within the "Node life time"

- the NMT slave has received an RTR telegram from the NMT master and
- the NMT master has received a correct response from the requested NMT slave.

In the OK status the monitoring times for the NMT master and the NMT slave are reset and the node guarding protocol is continued.

Life guarding event

The "life guarding event" is triggered in the NMT slave if the slave has not received an RTR telegram from the NMT master within the node life time:

- In the Lenze setting, the NMT slave changes from the "Operational" communication status into the "Pre-Operational" communication status.
 - [C00625](#) or the [I-1029](#) object serve to set a status change.
- The NMT master receives an emergency telegram containing emergency error code 0x8130.
- The response parameterised in [C00614](#) takes place (Lenze setting: "No response").



Note!

The "Life Guarding Event" can only be triggered in the NMT slave if at least one RTR telegram has been received successfully from the NMT master.

Node guarding event

The "node guarding event" is triggered in the NMT master if the master has not received any response to its RTR telegram from the requested NMT slave within the node life time or if the toggle bit in the response telegram has not changed within the node life time.

- In the Lenze setting, the NMT master changes from the "Operational" communication status into the "Pre-Operational" communication status.
 - [C00625](#) or the [I-1029](#) object serve to set a status change.
- The response parameterised in [C00612/1...32](#) takes place (Lenze setting: "No response"). The response in the NMT master can be set individually for each monitored node.



Note!

The "Node Guarding Event" can only be triggered in the NMT master if at least one response has been received successfully from the requested NMT slave.

9.9.1.3 Commissioning example

Task

A 9400 controller configured as NMT master (node 1) is to monitor another 9400 controller (node 2).

- The node guarding telegram is to be transmitted from the NMT master to the NMT slave in intervals of 1 s:
 - Guard time = 1000 ms
- The node life time is to amount to 5 seconds:
 - Node life time = guard time (1000 ms) x life time factor (5)
- If an error occurs, an error response is to be activated both in the NMT master and the NMT slave.

Parameter setting of the NMT master (node 1)

1. Set heartbeat producer time ([C00381](#)) to 0 ms to deactivate the heartbeat monitoring (node guarding and heartbeat must not be used simultaneously in a CANopen device).
2. Configure controller as NMT master: Set [C00352](#) = "1: Master".
3. Set guard time ([C00382](#)) to 0 ms (slave parameter).
4. Set life time factor ([C00383](#)) to 0 (slave parameter).
5. Configure monitoring for the node guarding in [C00386](#).
 - The value to be entered into a free subcode (1 ... 32) is "0x050203E8". It consists of the following:

Bit 31 ... bit 24 Life time factor	Bit 23 ... Bit 16 Node address of slave	Bit 15 ... Bit 0 Guard time
0x05	0x02	1000 [ms] = 0x03E8

6. Go to [C00612/1...32](#) and set the response required for the monitoring functions parameterised in [C00386/1...32](#) which are to take place in case of a "Node Guarding Event" in the NMT master.



Tip!

- [C00387](#) displays the activity of every monitoring function parameterised in [C00386/1...32](#) in a bit-coded form.
- [C00388/1...32](#) displays the node guarding status of the monitored NMT slaves.
- [C00625](#) serves to set which status change is to occur in the NMT master in case of a "Node Guarding Event".

Parameterise NMT slave (node 2)

1. Accept the settings made in the NMT master in [C00386](#) of the life time factor and the guard time for the NMTslave:
 - Set guard time ([C00382](#)) to 1000 ms.
 - Set life time factor ([C00383](#)) to 5.
2. Go to [C00614](#) and set the response required in case of a "Life Guarding Event" in the NMT slave.

**Tip!**

[C00625](#) serves to set which status change is to occur in case of a "Life Guarding Event" in the NMT slave.

Node guarding telegrams

- Remote Transmission Request:
The RTR telegram from the NMT master has the following identifiers:
Identifier (COB-ID) = 1792 + node address of slave = 1792 + 2 = 1794 = 0x702
- Remote Transmission Response:
The response telegram from the NMT slave has the same identifier and the "Operational" NMT status in the user data (s = 5). ▶ [Telegram structure](#) (📖 332)

9.9.2 Heartbeat protocol


The heartbeat protocol can be used optionally to the node guarding protocol for monitoring nodes within a CAN network. Unlike the node guarding, this monitoring does not require a polling by means of an RTR telegram (Remote Transmission Request) from the NMT master.



Note!

Heartbeat and node guarding protocols must not be used simultaneously in a CANopen device. If the heartbeat producer time is set > 0 ms, the heartbeat protocol is used.

Basic workflow



[9-10] Heartbeat protocol

1. A heartbeat producer cyclically transmits a so-called heartbeat telegram to one or more consumers.
2. The consumer(s) monitor the heartbeat telegram for arrival on a regular basis.

9.9.2.1 Telegram structure

- The heartbeat telegram of the producer has the following identifier:
Identifier (COB-ID) = 1792 + producer's node address
- The user data (1 byte) contain the status (s) of the producer:

Heartbeat producer status		Data								
Communication status	Decimal value (s)	(r)	Producer status (s)							
		Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
Boot-up	0	0	0	0	0	0	0	0	0	0
Stopped	4	0	0	0	0	0	1	0	0	0
Operational	5	0	0	0	0	0	1	0	1	1
Pre-Operational	127	0	1	1	1	1	1	1	1	1

9.9.2.2 Parameter setting

Short overview of the parameters for the "Heartbeat" monitoring function:

Parameters	Info	Lenze setting		Assignment	
		Value	Unit	Consumer	Producer
C00346	CAN heartbeat activity	-		●	
C00347/1...32	CAN heartbeat status	-		●	
C00381	CAN Heartbeat producer time	0	ms		●
C00385/1...32	CAN heartbeat consumer time	0x00000000		●	
C00613/1...32	Resp. to CAN Heartbeat error	No response		●	
C00625	CAN behaviour in case of fault	Pre-operational state		●	●

Greyed out = display parameter

Heartbeat producer time

Time interval for the transmission of the heartbeat telegram to the consumer(s).

- Parameterisable in [C00381](#) or via object [I-1017](#). The parameterised time is rounded down to an integer multiple of 5 ms.
- The heartbeat telegram is sent automatically as soon as a time > 0 ms is set.



Note!

Heartbeat and node guarding protocols must not be used simultaneously in a CANopen device. If the heartbeat producer time is set > 0 ms, the heartbeat protocol is used.

Heartbeat consumer time

Monitoring time for the nodes (producers) to be monitored.

- Can be parameterised in [C00385/1...32](#) or via the object [I-1016](#).
- The parameterised time is rounded down to an integer multiple of 5 ms and must have a greater value than the heartbeat producer time of the node to be monitored.
- A consumer can monitor up to 32 producers.

Heartbeat event

The "Heartbeat event" is activated in the consumer if it does not receive any heartbeat telegram from the producer within the heartbeat consumer time:

- In the Lenze setting, the consumer changes from the "Operational" communication status into the "Pre-Operational" communication status.
 - [C00625](#) or the [I-1029](#) object serve to set a status change.
- The NMT master receives an emergency telegram containing emergency error code 0x8130.
- The response parameterised in [C00613/1...32](#) for the corresponding producer takes place (Lenze setting: "No response").



Note!

The heartbeat monitoring will not start until the first heartbeat telegram of a monitored producer has been received successfully and the "Pre-Operational" NMT status has been assumed.

The boot-up telegram counts as the first heartbeat telegram.

9.9.2.3 Commissioning example

Task

A 9400 controller (node 2) configured as a heartbeat consumer is to monitor another 9400 controller (Heartbeat Producer; node 1).

- The heartbeat producer is to transmit a heartbeat telegram to the heartbeat consumer every 10 ms.
- The heartbeat consumer monitors the heartbeat telegram for arrival. A response is to be activated in the event of an error.

Parameterising the heartbeat producer (node 1)

1. Set the heartbeat producer time ([C00381](#)) to 10 ms.

Parameterising the heartbeat consumer (node 2)

1. Configure monitoring for the heartbeat in [C00385](#).
 - Note: The heartbeat consumer time must be greater than the heartbeat producer time of the node to be monitored set in [C00381](#).
 - The value to be entered into a free subcode (1 ... 32) is "0x0001000F". It consists of the following:

Bit 31 ... bit 24 Reserved	Bit 23 ... Bit 16 Node address of the producer	Bit 15 ... Bit 0 Heartbeat consumer time (integer multiple of 5 ms)
0x00	0x01	15 [ms] = 0x000F

2. Go to [C00613/1...32](#) and set the response required for the monitoring functions parameterised in [C00385/1...32](#) which are to take place in case of a "Heartbeat Event" in the consumer.



Tip!

- [C00346](#) displays the activity of every monitoring function parameterised in [C00385/1...32](#) in a bit-coded form.
- [C00347/1...32](#) displays the node guarding status of the monitored NMT slaves.
- [C00625](#) serves to set which status change is to occur in case of a "Heartbeat Event".

Heartbeat telegram

- The heartbeat telegram of the producer has the following identifier:
Identifier (COB-ID) = 1792 + producer's node address = 1792 + 1 = 1793 = 0x701

9.9.3 Emergency telegram

If the error status changes because an internal device error occurs or has been eliminated, the NMT master receives an emergency telegram once with the following structure:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Emergency error codes		Error register	Manufacturer-specific error message				
LOW byte	HIGH byte	I-1001	0x00 (Reserved)	LOW word		HIGH word	
See table below				LOW byte	HIGH byte	LOW byte	HIGH byte
			<ul style="list-style-type: none"> • With emergency error code 0x1000: Lenze error number (displayed value in C00168) • All other emergency error codes have a value of "0" here. 				

Emergency error codes	Error register	Cause
0x0000	0xXX	One of several errors eliminated
	0x00	One error has been eliminated (error-free status afterwards)
0x1000	0x01	Generic error <ul style="list-style-type: none"> • In the standard device, an error has occurred with the error response "Fault", "Trouble", "Quick stop by trouble", "Warning", "Warning locked" or "System fault". • Error message is the Lenze error number (C00168). • For error cause see fault error description (C00166).
0x3100	0x01	Supply voltage of standard device faulty or failed
0x8100	0x11	Communication error (warning)
0x8130	0x11	Life guarding error or heartbeat error
0x8150	0x11	Collision of identifiers (COB-IDs): An identifier parameterised for reception is also used for transmission.
0x8210	0x11	PDO length shorter than expected
0x8220	0x11	PDO length greater than expected
0x8700	0x11	Monitoring of the sync telegram

Example

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Emergency error codes		Error register	Manufacturer-specific error message				
0x00	0x10	0x01	0x00 (Reserved)	0x1B	0x00	0x7B	0x00
Generic error				Lenze error message 0x007b001b: Encoder wire breakage. ▶ Error messages of the operating system Corresponding error-free message: Value "0x00000000"			



Tip!

A detailed description can be found in CAN specification DS301, V4.02.

9.10 CANopen objects implemented

Lenze devices can be parameterised with both Lenze codes and manufacturer-independent "CANopen objects". Fully CANopen-compliant communication can only be achieved by exclusively using CANopen objects for the parameterisation. The CANopen objects described in this chapter are defined in the DS301 V4.02 CAN specification.

Many CANopen objects can be mapped on Lenze codes. The following table lists the related Lenze codes in the column "Relationship to Lenze codes".



Note!

Some of the terms used here derive from the CANopen protocol.

Overview of CANopen indices and their relationship to Lenze codes

CANopen object			Relationship to Lenze code
Index	Subindex	Name	
I-1000	0	Device type	-
I-1001	0	Error register	C00390
I-1003	Predefined error field		
	0	Number of errors	-
	1 ... 10	Standard error field	-
I-1005	0	COB-ID SYNC message	C00367
			C00368
I-1006	0	Communication cycle period	C00369
I-100C	0	Guard time	C00382
I-100D	0	Life time factor	C00383
I-1010	Store parameters		
	0	Highest subindex supported	-
	1	Save All Parameters	-
I-1011	Restore default parameters		
	0	Highest subindex supported	-
	1	restore all default parameters	-
I-1014	0	COB-ID EMCY	C00391
I-1015	0	Inhibit time EMCY	C00392
I-1016	Consumer heartbeat time		
	0	Highest subindex supported	-
	1 ... 32	Consumer heartbeat time	C00385/1...32
I-1017	0	Producer heartbeat time	C00381
I-1018	Identity object		
	0	Highest subindex supported	-
	1	Vendor ID	-
	2	Product code	-
	3	Revision number	-
	4	Serial number	-

CANopen object			Relationship to Lenze code
Index	Subindex	Name	
I-1029	Error behaviour		
	0	Highest subindex supported	-
	1	Communication error	C00625
I-1200	SDO1 server parameter		
	0	Highest subindex supported	-
	1	COB-ID client → server (rx)	C00372/1
I-1201 ... I-1209	SDO2 ... SDO10 server parameter		
	0	Highest subindex supported	-
	1	COB-ID client → server (rx)	C00372/2...10
	2	COB-ID server → client (tx)	C00373/2...10
I-1400 ... I-1403	RPDO1 ... RPDO4 communication parameter		
	0	Highest subindex supported	-
	1	COB-ID used by RPDO	C00321/1...4
	2	Transmission type	C00323/1...4
	3	Inhibit time	-
	4	Compatibility entry	-
I-1600 ... I-1603	RPDO1 ... RPDO4 mapping parameter		
	0	Number of mapped application objects in PDO	-
	1 ... 8	Application object 1 ... 8	-
I-1800 ... I-1803	TPDO1 ... TDDO4 communication parameter		
	0	Highest subindex supported	-
	1	COB-ID used by TPDO	C00320/1...4
	2	Transmission type	C00322/1...4
	3	Inhibit time	C00324/1...4
	4	Reserved	-
I-1A00 ... I-1A03	TPDO1 ... TDDO4 mapping parameter		
	0	Number of mapped application objects in PDO	-
	1 ... 8	Application object 1 ... 8	-

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1000

I-1000

Index I-1000	Name: Device type				
Subindex	Default setting	Display range (min. value unit max. value)		Access	Data type
0: Device type	0	0		4294967295	ro U32

The CANopen index I-1000 specifies the profile for this device. Furthermore, additional information defined in the device profile itself can be stored here.

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
HIGH word		LOW word	
HIGH byte	LOW byte	HIGH byte	LOW byte
Additional information		ECAT: Device Profile Number	

[9-11] Data frame assignment

I-1001

Index: I-1001	Name: Error register				
Subindex	Default setting	Display range (min. value unit max. value)		Access	Data type
0: Error register	-	0		255	ro U8

Error register

- This object is related to the Lenze code [C00390](#).
- The error status in the data byte (U8) is bit coded (see the following table). Currently only bit 0 and bit 4 in the data byte contain the corresponding information.

Bit	Meaning if bit is set:
Bit 0	Generic error
Bit 1	Current error (not used)
Bit 2	Voltage error (not used)
Bit 3	Temperature error (not used)
Bit 4	Communication error
Bit 5	Device profile spec. error (not used)
Bit 6	Reserved
Bit 7	Manufacturer-specific error (not used)

I-1003

Index: I-1003	Name: Predefined error field					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of errors	0	0		255	rw	U8
1 ... 10: Standard error field	-	0		4294967295	ro	U32

Error history

This object indicates that an error has occurred in the module and in the standard device.

Subindex	Meaning
0	Number of saved error messages
1 ... 10	Display of the error list The error messages (U32) consist of a 16-bit error code and a manufacturer-specific information field comprising 16 bits.

**Note!**

The values in the "standard error field" under subindex 1 ... 10 will be deleted if the subindex "number of recorded errors" is overwritten with the value "0".

Emergency error codes	Cause	Entry in the error register (I-1001)
0x0000	One of several errors eliminated	0xXX
	Elimination of one single error (afterwards no more errors)	0x00
0x1000	Standard device is in error status (error response "fault", "message", "warning", "error", "quick stop by trouble", or "system error")	0x01
0x3100	Supply voltage of standard device faulty or failed	0x01
0x8100	Communication error (warning)	0x11
0x8130	Life guard error or heartbeat error	0x11
0x8150	Collision of COB-IDs: An ID parameterised for reception is also used for transmission.	0x11
0x8210	PDO length shorter than expected	0x11
0x8220	PDO length greater than expected	0x11
0x8700	Monitoring of the sync telegram	0x11

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1005

I-1005

Index: I-1005	Name: COB-ID SYNC message					
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type	
0: COB-ID SYNC message	0x0000 0080 or 0x8000 0080	0		4294967295	rw	U32

This object can be used to activate the generation of sync telegrams and to write the identifier value.

- This object is related to the Lenze codes [C00367](#) and [C00368](#).

Creating sync telegrams

To create sync telegrams, bit 30 (see below) must be set to "1". The interval of the sync telegrams can be set with the object [I-1006](#).

Writing identifiers

To receive PDOs, the value 0x80 must be entered in the 11-bit identifier in the Lenze setting (and according to CANopen specification) . This means that all modules are by default set to the same sync telegram.

- If sync telegrams are only to be received by certain communication modules, their identifiers can be entered with values up to and including 0x07FF.
- The identifier can only be changed if the communication module does not send any sync telegrams (bit 30 = "0").
- How to change the identifier:
 - Deactivate identifier (set bit 30 to "0").
 - Change identifier.
 - Activate identifier (set bit 30 to "1").

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
x	0/1	Extended identifier*				11-bit identifier	
* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".							

[9-12] Data frame assignment

I-1006

Index: I-1006	Name: Communication cycle period				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Communication cycle period	0 µs	0	µs	65535000	rw U32

Setting the sync telegram cycle time.

- The cycle time can be selected as "1000" or as an integer multiple of it.
- If "0 µs" is set (Lenze setting), no sync telegrams are created.
- This object is related to the Lenze code [C00369](#).

I-100C

Index: I-100C	Name: Guard time				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Guard time	0 ms	0	ms	65535	rw U16

Monitoring time for node guarding. ▶ [Node guarding protocol](#) (331)

- Time within the NMT slave expects the RTRs from the NMTmaster.
- The node life time is the product of the guard time and the life time factor:
Node Life Time = Guard Time (I-100C) x Life Time Factor (I-100D)
- The "life guarding event" occurs in the NMT slave if the slave has not been triggered by the NMT master through an RTR within the node life time.
- With "0 ms" (Lenze setting), monitoring is not supported by the slave.
- This object is related to the Lenze code [C00382](#).

I-100D

Index: I-100D	Name: Life time factor				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Life time factor	0	0		255	rw U8

Life Time Factor for node guarding. ▶ [Node guarding protocol](#) (331)

- The node life time is the product of the guard time and the life time factor:
Node Life Time = Guard Time (I-100C) x Life Time Factor (I-100D)
- The "life guarding event" occurs in the NMT slave if the slave has not been triggered by the NMT master through an RTR within the node life time.
- With "0" (Lenze setting), monitoring is not supported by the slave.
- This object is related to the Lenze code [C00383](#).

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1010

I-1010

Index: I-1010	Name: Store parameters				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: highest subindex supported	1	- (read access only)		ro	U32
1: Save all parameters	-	0	4294967295	rw	U32

Save parameters with mains failure protection.

- Corresponds to device command [C00002](#) = "11: Save start parameters".
- This command serves to save the current parameter settings of the active application with mains failure protection in the memory module of the controller.

Subindex	Meaning	
	Read	Write
0	Max. supported subindex: 1	- (A write attempt triggers the error message 0x06010002.)
1	Reading memory functions of all parameters.	Save parameters with mains failure protection.

Read subindex 1

8th byte	7th byte	6. byte	5th byte	
Data 4	Data 3	Data 2	Data 1	
Bit 31 ... bit 2			Bit 1	Bit 0
0			0/1	0/1

[9-13] Assignment of the data telegram (read access)

Bit	Meaning	
Bit 0	0	No saving of parameters on command.
	1	Saving of parameters on command (Lenze).
Bit 1	0	No automatic saving of parameters (Lenze).
	1	Automatic saving of parameters.

Write subindex 1

In addition to the index and subindex, the telegram data must also include the "save" signature (ASCII characters; ISO 8859) so that the parameters are stored.

- A response according to the DS301 V4.02 specification occurs while writing with a wrong identifier.

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
"e" = 0x65	"v" = 0x76	"a" = 0x61	"s" = 0x73

[9-14] Assignment of the data telegram (write access)

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1011

I-1011

Index: I-1011	Name: Restore default parameters				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: highest subindex supported	1	- (read access only)		ro	U32
1: restore all default parameters	-	0	4294967295	rw	U32

Load Lenze setting.

- Corresponds to the device command [C00002](#) = "0: Load Lenze setting".
- This command serves to reset the parameters of the active application to the Lenze setting which is stored in the firmware.

Subindex	Meaning	
	Read	Write
0	Max. supported subindex: 1	- (A write attempt triggers the error message 0x06010002.)
1	Loading of all parameters possible.	Load Lenze setting.

Read subindex 1

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 1			Bit 0
0			0/1

[9-15] Assignment of the data telegram (read)

Bit	setting
Bit 0	0 Parameters cannot be loaded.
	1 Parameters can be loaded (Lenze).

Write subindex 1

In addition to the index and subindex, the telegram data must include the "load" signature (ASCII characters; ISO 8859) so that the Lenze setting can be loaded.

- A response according to the DS301 V4.02 specification occurs while writing with a wrong identifier.

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
"d" = 0x64	"a" = 0x61	"o" = 0x6F	"l" = 0x6C

[9-16] Assignment of the data telegram (write)

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1014

I-1014

Index: I-1014	Name: COB-ID EMCY				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: COB-ID EMCY	0x80 + node ID	0		4294967295	rw U32

If a communication error or an internal error of the communication module or the controller occurs or is acknowledged (e. g. "trouble"), an error message is sent via the system bus. For each error, the telegram is interrupted once. By means of bit 31 this function can be activated or deactivated.

- This object is related to the Lenze code [C00391](#).

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0	Extended identifier*				11-bit identifier	
* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".							

[9-17] Data frame assignment

Bit	setting	
Bit 31	0	Emergency object is valid.
	1	Emergency object is invalid.



Note!

The identifier can only be changed in the "emergency object invalid" status (bit 31 = 1).

I-1015

Index: I-1015	Name: Inhibit time EMCY				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: inhibit time EMCY	0	0	0.1 ms	65535	rw U32

Time which must elapse after an error message ([I-1014](#)) has been transmitted before further error messages can be sent via the bus.

- The entered value multiplied by "0.1" gives the delay time in [ms]. The values are automatically rounded up to whole values in [ms].
- This object is related to the Lenze code [C00392](#).

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1016

I-1016

Index: I-1016	Name: Consumer heartbeat time					
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type	
0: Highest subindex supported	32	- (read access only)		ro	U32	
1 ... 32: consumer heartbeat time	0	0		4294967295	rw	U32

Monitoring time for the nodes 1 ... 32 to be monitored via heartbeat. ▶ [Heartbeat protocol \(📖 337\)](#)

- The parameterised time is rounded down to an integer multiple of 5 ms and must have a greater value than the heartbeat producer time of the node to be monitored.

Subindex	Meaning	Lenze code
0	Number of nodes to be monitored	
1 ... 32	Node-ID and heartbeat time of the node 1 ... 32 to be monitored	C00385/1...32

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 24	Bit 23 ... Bit 16	Bit 15 ... Bit 0	
0 (Reserved)	Node ID	Heartbeat time in [ms]	

[9-18] Data frame assignment

I-1017

Index: I-1017	Name: Producer heartbeat time					
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type	
0: Producer heartbeat time	0	0	ms	65535	rw	U32

Time interval for the transmission of the heartbeat telegram to one or several consumers. ▶ [Heartbeat protocol \(📖 337\)](#)

- The parameterised time is rounded down to an integer multiple of 5 ms.
- The heartbeat telegram is automatically sent as soon as a time > 0 ms is entered. In this case, the "node guarding" monitoring function is deactivated.
- This object is related to the Lenze code [C00381](#).

I-1018

Index: I-1018	Name: Identity object					
Subindex	Default setting	Display range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	see below	0		4294967295	ro	U32
1: Vendor ID						
2: Product code						
3: Revision number						
4: Serial number						

Subindex	Meaning						
1	Manufacturer's identification number <ul style="list-style-type: none"> The identification number allocated to Lenze by the organisation "CAN in Automation e. V." is "0x0000003B". 						
2	Product code <table border="1"> <tr> <td>0x94001</td> <td>9400 StateLine</td> </tr> <tr> <td>0x94002</td> <td>9400 HighLine / ServoPLC</td> </tr> <tr> <td>0x94004</td> <td>9400 regenerative power supply module</td> </tr> </table>	0x94001	9400 StateLine	0x94002	9400 HighLine / ServoPLC	0x94004	9400 regenerative power supply module
0x94001	9400 StateLine						
0x94002	9400 HighLine / ServoPLC						
0x94004	9400 regenerative power supply module						
3	Main and subversion of firmware						
4	Serial number						

I-1029

Index: I-1029	Name: Error behaviour					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	1	- (read access only)			ro	U8
1: Communication error	0	0		2	rw	U8

This object serves to set the communication status to which the controller is to change after a bus off, a node/life guarding event or a heartbeat event.

Subindex	Meaning	Lenze code						
1	Status change after bus off, node/life guarding event or heartbeat event: <table border="1"> <tr> <td>0</td> <td>State change from "Operational" to "Pre-operational"</td> </tr> <tr> <td>1</td> <td>No state change</td> </tr> <tr> <td>2</td> <td>State change to "Stopped"</td> </tr> </table>	0	State change from "Operational" to "Pre-operational"	1	No state change	2	State change to "Stopped"	C00625
0	State change from "Operational" to "Pre-operational"							
1	No state change							
2	State change to "Stopped"							

I-1200

Index: I-1200	Name: SDO1 server parameter					
Subindex	Default setting	Display range (min. value unit max. value)		Access	Data type	
0: Highest subindex supported	2	2		2	ro	U8
1: COB-ID client -> server (rx)	node ID + 0x600	0		4294967295	ro	U32
2: COB-ID server -> client (tx)	node ID + 0x580	0		4294967295	ro	U32

Identifiers for SDO server channel 1 (basic SDO channel).

- According to DS301 V4.02, the basic SDO channel can neither be changed nor deactivated.

Subindex	Meaning
1	Specification of receive identifier <ul style="list-style-type: none"> • For SDO server channel 1: node address (C00350) + 0x600
2	Specification of send identifier <ul style="list-style-type: none"> • For SDO server channel 1: node address (C00350) + 0x580

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0	0	Extended identifier*				11-bit identifier	

* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".

[9-19] Data frame assignment

I-1201

Index: I-1201	Name: SDO2 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0		4294967295	rw U32
2: COB-ID server -> client (tx)	0x80000000	0		4294967295	rw U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Identifiers for SDO server channel 2.

- The SDO server parameter is only valid, if bit 31 is set to "0" for both transmission directions (subindex 1 and 2).
- In the Lenze setting, the SDO server channels 2 ... 10 are deactivated (bit 31 = "1").
- The identifier can only be changed if the SDO is invalid (bit 31 = "1").

Subindex	Meaning
1	Specification of receive identifier
2	Specification of send identifier
3	Node address of the client

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0	Extended identifier*				11-bit identifier	

* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".

[9-20] Data frame assignment

Bit	setting	
Bit 31	0	SDO is valid.
	1	SDO is invalid.

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").

Example

Parameter data channel 2 of the controller with node address 4 shall be activated.

- For this purpose, bit 31 in the subindexes 1 and 2 of the [I-1201](#) object must be set to the value "0" (≡ "SDO valid").
- The master must send the two "write request" commands to the nodes via the basic SDO channel.

Identifier calculation

- Identifier (COB-ID) = basic identifier + node address (node ID)
- Basic identifier SDO2 from master to drive: 1600 (0x640)
→ Identifier = 0x640 + 0x4 = 0x644
- Basic identifier SDO2 from drive to master: 1472 (0x5C0)
→ Identifier = 0x5C0 + 0x4 = 0x5C4

Resulting data (data 1 ... data 4)

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0	0	Extended identifier = 0				11-bit identifier = 0x644	
0x00		0x00		0x06		0x44	

[9-21] Data telegram assignment for subindex 1

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0	0	Extended identifier = 0				11-bit identifier = 0x5C4	
0x00		0x00		0x05		0xC4	

[9-22] Data telegram assignment for subindex 2

User data assignment

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x23	0x01	0x12	0x01	0x44	0x06	0x00	0x00

[9-23] User data assignment for writing to subindex 1

1st byte	2nd byte	3rd byte	4th byte	5th byte	6. byte	7th byte	8th byte
Command	Index		Subindex	Data 1	Data 2	Data 3	Data 4
0x23	0x01	0x12	0x02	0xC4	0x05	0x00	0x00

[9-24] User data assignment for writing to subindex 2

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1202

I-1202

Index: I-1202	Name: SDO3 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 3. For description see object [I-1201](#).

I-1203

Index: I-1203	Name: SDO4 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 4. For description see object [I-1201](#).

I-1204

Index: I-1204	Name: SDO5 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 5. For description see object [I-1201](#).

I-1205

Index: I-1205	Name: SDO6 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 6. For description see object [I-1201](#).

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1206

I-1206

Index: I-1206	Name: SDO7 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 7. For description see object [I-1201](#).

I-1207

Index: I-1207	Name: SDO8 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 8. For description see object [I-1201](#).

I-1208

Index: I-1208	Name: SDO9 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 9. For description see object [I-1201](#).

I-1209

Index: I-1209	Name: SDO10 server parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	3	- (read access only)		ro	U8
1: COB-ID client -> server (rx)	0x80000000	0	4294967295	rw	U32
2: COB-ID server -> client (tx)	0x80000000	0	4294967295	rw	U32
3: Node-ID of the SDO client	1 ... 127	- (read access only)		ro	U32

Setting of the identifiers for the SDO server channel 10. For description see object [I-1201](#).

I-1400

Index: I-1400	Name: RPDO1 communication parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	5	- (read access only)			ro	U8
1: COB-ID used by RPDO	0x200 + node ID	0		4294967295	rw	U32
2: Transmission type	254	0		255	rw	U8
3: Inhibit time	-	- (not used for RPDOs)			rw	U16
4: Compatibility entry	-	- (reserved, read or write access leads to error message 0x06090011)			rw	U8
5: Event timer	-	- (not used for RPDOs)			rw	U16

Communication parameter for receiving process data via RPDO1

Subindex	Meaning	Lenze code
1	RPDO1 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x200 + node ID	C00321/1
2	RPDO Transmission type according to DS301 V4.02 ▶ Transmission type (☰ 311)	C00323/1

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0/1	Extended identifier*				11-bit identifier	
* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".							

[9-25] Data frame assignment

Bit	setting	
Bit 30	0	RTR to this PDO possible (cannot be set).
	1	RTR to this PDO not possible (Lenze).
Bit 31	0	PDO active
	1	PDO inactive

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").

I-1401

Index: I-1401		Name: RPDO2 communication parameter			
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	5	- (read access only)		ro	U8
1: COB-ID used by RPDO	0x300 + node ID	0		4294967295	rw U32
2: Transmission type	254	0		255	rw U8
3: Inhibit time	-	- (not used for RPDOs)		rw	U16
4: Compatibility entry	-	- (reserved, read or write access leads to error message 0x06090011)		rw	U8
5: Event timer	-	- (not used for RPDOs)		rw	U16

Communication parameter for receiving process data via RPDO2

Subindex	Meaning	Lenze code
1	RPDO2 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x300 + node ID	C00321/2
2	RPDO Transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00323/2

- For assignment of the data telegram see object [I-1400](#).

I-1402

Index: I-1402		Name: RPDO3 communication parameter			
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	5	- (read access only)		ro	U8
1: COB-ID used by RPDO	0x400 + node ID	0		4294967295	rw U32
2: Transmission type	254	0		255	rw U8
3: Inhibit time	-	- (not used for RPDOs)		rw	U16
4: Compatibility entry	-	- (reserved, read or write access leads to error message 0x06090011)		rw	U8
5: Event timer	-	- (not used for RPDOs)		rw	U16

Communication parameter for receiving process data via RPDO3

Subindex	Meaning	Lenze code
1	RPDO3 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x400 + node ID	C00321/3
2	RPDO Transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00323/3

- For assignment of the data telegram see object [I-1400](#).

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1403

I-1403

Index: I-1403		Name: RPDO4 communication parameter				
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	5	- (read access only)			ro	U8
1: COB-ID used by RPDO	0x500 + node ID	0		4294967295	rw	U32
2: Transmission type	254	0		255	rw	U8
3: Inhibit time	-	- (not used for RPDOs)			rw	U16
4: Compatibility entry	-	- (reserved, read or write access leads to error message 0x06090011)			rw	U8
5: Event timer	-	- (not used for RPDOs)			rw	U16

Communication parameter for receiving process data via RPDO4

Subindex	Meaning	Lenze code
1	Identifier RPDO4 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x500 + node ID	C00321/4
2	RPDO Transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00323/4

- For assignment of the data telegram see object [I-1400](#).

I-1600

Index: I-1600		Name: RPDO1 mapping parameter				
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1600 serves to receive parameter data as RPDO1.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO1

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 16		Bit 15 ... bit 8	Bit 7 ... bit 0
Index		Subindex	Length

[9-26] Data frame assignment

IEC 61131 process data words are mapped. Only whole bytes can be mapped (the granularity of the mapping entries is one byte).

I-1601

Index: I-1601	Name: RPDO2 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1601 serves to receive parameter data as RPDO2.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO2

- For data telegram assignment, see object [I-1600](#).

I-1602

Index: I-1602	Name: RPDO3 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1602 serves to receive parameter data as RPDO3.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO3

- For data telegram assignment, see object [I-1600](#).

I-1603

Index: I-1603	Name: RPDO4 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1603 serves to receive parameter data as RPDO4.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO4

- For data telegram assignment, see object [I-1600](#).

I-1800

Index: I-1800	Name: TPDO1 communication parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	5	- (read access only)			ro	U8
1: COB-ID used by TPDO	0x180 + node ID	0		4294967295	rw	U32
2: Transmission type	254	0		255	rw	U8
3: Inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: Reserved	-	- (reserved, read or write access leads to error message 0x06090011)			rw	U8
5: Event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for sending process data via TPDO1

Subindex	Meaning	Lenze code
1	TPDO1 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x180 + node ID	C00320/1
2	TPDO transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00322/1
3	Minimum time between sending two identical TPDOs (see DS301 V4.02).	C00324/1
5	Cycle time for PDO transmission with transmission type "254".	C00356/1

8th byte		7th byte		6. byte		5th byte	
Data 4		Data 3		Data 2		Data 1	
Bit 31	Bit 30	Bit 29 ... bit 11				Bit 10 ... bit 0	
0/1	0/1	Extended identifier*				11-bit identifier	
* The extended identifier is not supported. Bit 11 ... bit 29 must be set to "0".							

[9-27] Data frame assignment

Bit	setting
Bit 30	0 RTR to this PDO possible (Lenze).
	1 RTR to this PDO not possible (not adjustable)
Bit 31	0 PDO active
	1 PDO inactive

How to change the identifier:

1. Deactivate identifier (set bit 31 to "1").
2. Change identifier.
3. Activate identifier (set bit 31 to "0").

Subindex 3 - inhibit time

The delay time can only be changed if the PDO is inactive (subindex 1, bit 31 = 1). The entered value multiplied by 0.1 results in the delay time in [ms]. The calculated delay time is always rounded down to an integer value.

Example:

- Entered value: 26
- Calculated time = $26 * 0.1 \text{ [ms]} = 2.6 \text{ [ms]} \rightarrow \text{delay time} = 2 \text{ [ms]}$

I-1801

Index:	Name:					
I-1801	TPDO2 communication parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Highest subindex supported	5	- (read access only)			ro	U8
1: COB-ID used by TPDO	0x280 + node ID	0		4294967295	rw	U32
2: Transmission type	254	0		255	rw	U8
3: Inhibit time	0 ms	0	0.1 ms	65535	rw	U16
4: Reserved	-	- (reserved, read or write access leads to error message 0x06090011)			rw	U8
5: Event timer	0 ms	0	ms	65535	rw	U16

Communication parameter for sending process data via TPDO2

Subindex	Meaning	Lenze code
1	TPDO2 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x280 + node ID	C00320/2
2	TPDO transmission type according to DS301 V4.02 ▶ Transmission type (☐ 311)	C00322/2
3	Minimum time between sending two identical TPDOs (see DS301 V4.02).	C00324/2
5	Cycle time for PDO transmission with transmission type "254".	C00356/2

- For assignment of the data telegram see object [I-1800](#).

I-1802

Index: I-1802	Name: TPDO3 communication parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	5	- (read access only)		ro	U8
1: COB-ID used by TPDO	0x380 + node ID	0	4294967295	rw	U32
2: Transmission type	254	0	255	rw	U8
3: Inhibit time	0 ms	0	0.1 ms 65535	rw	U16
4: Reserved	-	- (reserved, read or write access leads to error message 0x06090011)		rw	U8
5: Event timer	0 ms	0	ms 65535	rw	U16

Communication parameter for sending process data via TPDO3

Subindex	Meaning	Lenze code
1	TPDO3 identifier • The basic setting is according to the "Predefined Connection Set": Identifier = 0x380 + node ID	C00320/3
2	TPDO transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00322/3
3	Minimum time between sending two identical TPDOs (see DS301 V4.02).	C00324/3
5	Cycle time for PDO transmission with transmission type "254".	C00356/3

- For assignment of the data telegram see object [I-1800](#).

I-1803

Index: I-1803	Name: TPDO4 communication parameter				
Subindex	Default setting	Setting range (min. value unit max. value)		Access	Data type
0: Highest subindex supported	5	- (read access only)		ro	U8
1: COB-ID used by TPDO	0x480 + node ID	0	4294967295	rw	U32
2: Transmission type	254	0	255	rw	U8
3: Inhibit time	0 ms	0	0.1 ms 65535	rw	U16
4: Reserved	-	- (reserved, read or write access leads to error message 0x06090011)		rw	U8
5: Event timer	0 ms	0	ms 65535	rw	U16

Communication parameter for sending process data via TPDO4

Subindex	Meaning	Lenze code
1	Identifier TPDO4 • The basic setting is according to the "Predefined Connection Set": Identifier = 0x480 + node ID	C00320/4
2	TPDO transmission type according to DS301 V4.02 ▶ Transmission type (□ 311)	C00322/4
3	Minimum time between sending two identical TPDOs (see DS301 V4.02).	C00324/4
5	Cycle time for PDO transmission with transmission type "254".	C00356/4

- For assignment of the data telegram see object [I-1800](#).

9 "CAN on board" system bus

9.10 CANopen objects implemented | I-1A00

I-1A00

Index: I-1A00	Name: TPDO1 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A00 serves to send parameter data as TPDO1.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entry 1 ... 8 for TPDO1

8th byte	7th byte	6. byte	5th byte
Data 4	Data 3	Data 2	Data 1
Bit 31 ... bit 16		Bit 15 ... bit 8	
Index		Subindex	Length

[9-28] Data frame assignment

IEC 61131 process data words are mapped. Only whole bytes can be mapped (the granularity of the mapping entries is one byte).

I-1A01

Index: I-1A01	Name: TPDO2 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A01 serves to send parameter data as TPDO2.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO2

- For assignment of the data telegram see object [I-1A00](#).

I-1A02

Index: I-1A02	Name: TPDO3 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32

The object I-1A02 serves to send parameter data as TPDO3.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for RPDO4

- For assignment of the data telegram see object [I-1A00](#).

I-1A03

Index: I-1A03	Name: TPDO4 mapping parameter					
Subindex	Default setting	Setting range (min. value unit max. value)			Access	Data type
0: Number of mapped application objects in PDO	0	0		8	rw	U8
1 ... 8: application object 1 ... 8	0	0		4294967295	rw	U32


The object I-1A03 serves to send parameter data as TPDO4.

Subindex	Meaning
0	Number of mapped objects
1 ... 8	Mapping entries 1 ... 8 for TPDO4

- For assignment of the data telegram see object [I-1A00](#).

9.11 System block "LS_SyncInput"

The **LS_SyncInput** system block provides status information in the function block editor about the sync telegram received via the system block.



Outputs

Identifier	Data type	Value/meaning																										
SYNC_wSyncCycleTime	WORD	Sync cycle time in [µs] • Time with which the internal phase-locking loop (PLL) expects the synchronisation signals. The time must be set in C01121 in accordance with the cycle of the synchronisation source selected in C01120 .																										
SYNC_wSource	WORD	Synchronisation source selected in C01120 : <table border="1"> <tr><td>0</td><td>Off</td></tr> <tr><td>1</td><td>CAN on board</td></tr> <tr><td>2</td><td>CAN module</td></tr> <tr><td>4</td><td>Module in MXI1</td></tr> <tr><td>5</td><td>Module in MXI2</td></tr> <tr><td>6</td><td>Digital input 1</td></tr> <tr><td>7</td><td>Digital input 2</td></tr> <tr><td>8</td><td>Digital input 3</td></tr> <tr><td>9</td><td>Digital input 4</td></tr> <tr><td>10</td><td>Digital input 5</td></tr> <tr><td>11</td><td>Digital input 6</td></tr> <tr><td>12</td><td>Digital input 7</td></tr> <tr><td>13</td><td>Digital input 8</td></tr> </table>	0	Off	1	CAN on board	2	CAN module	4	Module in MXI1	5	Module in MXI2	6	Digital input 1	7	Digital input 2	8	Digital input 3	9	Digital input 4	10	Digital input 5	11	Digital input 6	12	Digital input 7	13	Digital input 8
0	Off																											
1	CAN on board																											
2	CAN module																											
4	Module in MXI1																											
5	Module in MXI2																											
6	Digital input 1																											
7	Digital input 2																											
8	Digital input 3																											
9	Digital input 4																											
10	Digital input 5																											
11	Digital input 6																											
12	Digital input 7																											
13	Digital input 8																											
SYNC_nSyncDeviation	INT	Deviation of the synchronisation signal in [increments] • ±16000 increments ≅ ±1 ms																										
SYNC_bSyncInsideWindow	BOOL	Status signal "Synchronisation signal within time slot" Note! If you use this signal in the application, observe the change in behaviour from software version V7.= onwards described in the following subchapter! ▶ Behaviour of the status signal bSyncInsideWindow (□ 368) <table border="1"> <tr> <td>TRUE</td> <td>The last synchronisation signal has been around the expected value within the time slot parameterised in C01123.</td> </tr> </table>	TRUE	The last synchronisation signal has been around the expected value within the time slot parameterised in C01123 .																								
TRUE	The last synchronisation signal has been around the expected value within the time slot parameterised in C01123 .																											
SYNC_bSyncSignalReceived	BOOL	Status signal "Receive synchronisation signal" <table border="1"> <tr> <td>TRUE</td> <td>Synchronisation signal has been received.</td> </tr> </table>	TRUE	Synchronisation signal has been received.																								
TRUE	Synchronisation signal has been received.																											
SYNC_bProcessDataExpected	BOOL	Status signal "Synchronous PDO expected" <table border="1"> <tr> <td>TRUE</td> <td>Synchronous PDO is expected</td> </tr> </table>	TRUE	Synchronous PDO is expected																								
TRUE	Synchronous PDO is expected																											

Identifier	Data type	Value/meaning
SYNC_bProcessDataInvalid	BOOL	Status signal "Synchronous PDO invalid"
		TRUE Synchronous PDO is invalid.

▶ [Synchronisation of PDOs via sync telegram](#) (☞ 313)

9.11.1 Behaviour of the status signal `bSyncInsideWindow`

[C01123](#) serves to set a time slot for monitoring the synchronisation signal. If the synchronisation signal received via the bus is in this time slot (around the expected time of the synchronisation signal), the `bSyncInsideWindow` output is set to TRUE.

Up to and including software version V6.0 the following applies:

Due to an error in the implementation, the phase position set in [C01122](#) is included in the calculation of the time slot. The time slot effective for monitoring around the expected time of the synchronisation signal is thus increased by the amount of the set phase position.

Example:

- Sync phase position ([C01122](#)) = 400 µs
- Sync tolerance ([C01123](#)) = 20 µs

→ The time slot for monitoring has a size of 420 µs!

The following applies from software version V7.0 onwards:

The faulty inclusion of the phase position set in [C01122](#) into the calculation of the time slot has been removed. The time slot for monitoring the synchronisation signal only corresponds to the sync tolerance set in [C01123](#).

Example:

- Sync phase position ([C01122](#)) = 400 µs
- Sync tolerance ([C01123](#)) = 20 µs

→ The time slot for monitoring has a size of 20 µs!

Feedbacks and their remedies

If the `bSyncInsideWindow` status signal is used in existing systems, this remedy reduces the monitoring window by the amount of the phase position if it is non-zero. This may cause an unwanted activation of the monitoring of the synchronisation signal programmed by the user.

Remedy: When the syn tolerance is increased ([C01123](#)) by the amount of the phase position set in [C01122](#), the compatible state is restored.

10 Safety engineering

The controller can be equipped with a safety module. The individual safety module types have a different range of functions to optimally meet different requirements.

"Integrated safety" stands for application-oriented safety functions that can be used on machines for the protection of persons and machines.

The motion functions are furthermore executed by the controller. The safety modules monitor the reliable compliance with limit values and provide safe inputs and outputs. If limit values are exceeded, the safety modules start control functions for the fault scenario in accordance with EN 60204-1 directly in the controller.

The safety functions are suitable for applications according to IEC 61508 to SIL 3 and, depending on the module, achieve the requirements of the EN ISO 13849-1 up to control category 4 and performance level (PL) "e".



Note!

For detailed information about the integrated safety technology, please see the manual for the safety module.

10.1 Integration into the application

If a safety function is requested, the safety engineering activates a corresponding safe monitoring function. The standstill function, however, is only executed directly if the "Safe torque off" function (STO) is activated. For the other safety functions, an action of the controller is required, which is safely monitored. The implementation of the corresponding action (e.g. braking, braking to standstill, holding of the standstill position) must be carried out by the application.

"LS_SafetyModuleInterface" system block

For the transmission of the control and status information from the safety module to the application, the **LS_SafetyModuleInterface** system block is provided in the function block editor of the »Engineer«. [\(□ 371\)](#)

"LS_Limiter" system block/basic function "Limiter"

Furthermore the **LS_Limiter** system block which contains the basic function "[Limiter](#)" is provided in the function block editor for the connection of safety engineering to the application. [\(□ 506\)](#)

For one thing, the basic function "Limiter" provides a parameterisation interface in »Engineer« for a comfortable setting of limit positions, limited speeds, and limit values, and for another it enables the drive to be braked specifically **after request** through the safety module.

Basic workflow

1. Activation of the safety function on the safety module (e. g. SS1 - safe stop 1).
→ Monitoring starts.
2. The safety module informs the controller via a control word that the safety function has been activated.
3. The application evaluates the control word and starts the required motion sequence (e.g. braking).



Note!

If communication to the controller is interrupted, e.g. by switching off the controller, the safety module responds as follows:

- Fault stop with STO is activated.
- "Warning" error message is transmitted.
- The LED "ME" is blinking.

The required error acknowledgement (AIE) is possible via terminal or safety bus.

10.2 Selecting the required safety module



Note!

With online communication via a bus system, there is the possibility that several users access the same drive at the same time and edit the safe parameter set.

After transferring the safe parameters, it must be checked whether the check sums (CRC) of the parameter set, memory module, and the safety module comply with each other in the *Safe Transfer* dialog box.

Access to the safety parameters by several users is currently technically unavoidable; therefore, organisational measures are required to ensure the consistency of the safety parameters.


The safety module expected by the application and the controller is selected in [C00214](#).

- In »Engineer« this setting is carried out automatically by assigning the device modules to the controller, i.e. »Engineer« automatically sets [C00214](#) according to the safety module selected.
- If the safety module set in [C00214](#) does not comply with the plugged-in safety module type, an error (fault) is triggered. The error can only be eliminated by mains switching.

Parameter Name: C00214 Required safety module		Data type: UNSIGNED_8 Index: 24361 _d = 5F29 _h
Setting of the expected safety module		
Selection list		
1	SM0	
2	SM100	
4	SM300	
5	SM301	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

10.3 System block "LS_SafetyModuleInterface"

The **LS_SafetyModuleInterface** system block is the interface to the safety module in the function block editor.



Outputs

Identifier	Data type	Value/meaning
SMI_dnState	DINT	Bit coded status information from the safety module ▶ Status information (□ 373)
SMI_dnIoState	DINT	Bit coded I/O status information from the safety module ▶ I/O status information (□ 374)
SMI_dwControl	DWORD	Bit coded control information from the safety module ▶ Control information (□ 374)
SMI_bPowerStageEnable	BOOL	Status signal "Inverter enable"
		TRUE Inverter is enabled by the safety module.
SMI_byModuleId	BYTE	ID of the safety module available in the controller

10.3.1 Status information

Via the bit-coded status signal *SMI_dnState* of the **LS_SafetyModuleInterface** SB, the SM3xx safety module transmits the status of safety functions to the application.

- Which bits are supported depends on the safety module used.


Bit coding of the status signal SMI_dnState		
Bit	Name	Meaning
0	STO	"Safe torque off (STO)" function is active. • The drive is safely switched to torqueless operation.
3	EC_STO	Error stop category 0: "Safe torque off (STO)" function is active.
4	EC_SS1	Error stop category 1: "Safe stop 1 (SS1)" function is active.
5	EC_SS2	Error stop category 2: "Safe stop 2 (SS2)" function is active.
8	SLS1 observed	Safely limited speed 1 is activated and complied with.
9	SLS2 observed	Safely limited speed 2 is activated and complied with.
10	SLS3 observed	Safely limited speed 3 is activated and complied with.
11	SLS4 observed	Safely limited speed 4 is activated and complied with.
12	SDIpos observed	Safe positive direction of rotation (SDIpos) is activated and complied with.
13	SDIneg observed	Safe negative direction of rotation (SDIneg) is activated and complied with.
14	Error active	SM3xx safety module has the error status (trouble or warning).

Bits not listed are reserved for future extensions!



Tip!

For decoding the status signal into individual boolean status signals, simply connect the *SMI_dnState* output to the **L_DevSMStateDecoder** FB which is available in the function library from V2.0.



[10-1] Example: Decoding of the *SMI_dnState* status signal into individual boolean status signals

10.3.2 I/O status information

Via the bit coded status signal *SMI_dnIoState* of the **LS_SafetyModuleInterface** SB, the SM3xx safety module transmits the status of the safe inputs and outputs to the application.

- Which bits are supported depends on the safety module used.


Bit coding of the SMI_dnIoState status signal		
Bit	Name	Meaning
0	SD-In1	Sensor input 1 in ON state.
1	SD-In2	Sensor input 2 in ON state.
2	SD-In3	Sensor input 3 in the ON state.
3	SD-In4	Sensor input 4 in the ON state.
5	AIS	Restart acknowledgement via terminal effected (negative edge: 1↘0).
6	AIE	Error acknowledgement via terminal effected (negative edge: 1↘0).
8	PS_AIS	Restart acknowledgement via safety bus effected (positive edge: 0↗1)
9	PS_AIE	Error acknowledgement via safety bus effected (positive edge: 0↗1)
12	SD-Out1	Safe output 1 (feedback output) in the ON state.

Bits not listed are reserved for future extensions!



Tip!

For decoding the status signal into individual boolean status signals, simply connect the *SMI_dnIoState* output to the **L_DevSMStateDecoderIO** FB which is available in the function library from V2.0.



[10-2] Example: Decoding of the SMI_dnIoState status signal into individual boolean status signals

10.3.3 Control information

Via the bit coded control signal *SMI_dwControl* of the **LS_SafetyModuleInterface** SB, the SM3xx safety module transmits information on safety functions requested, or on active safety functions to the application.

- Several safety functions can be requested/active at the same time.
- Which bits are supported depends on the safety module used.

Bit coding of the control signal <i>SMI_dwControl</i>		
Bit	Name	Meaning
1	SS1 active	"Safe stop 1 (SS1)" function is active. • After the parameterised stopping time has elapsed, bit 0 of the status signal <i>SMI_dnState</i> (STO active) is set.
2	SS2 active	"Safe stop 2 (SS2)" function is active. • After the parameterised stopping time has elapsed, bit 16 (SOS monitored) is set.
3	SLS1 active	"Safely limited speed 1 (SLS1)" function is active. • After the parameterised braking time <i>Nlim3</i> has elapsed, bit 8 of the status signal <i>SMI_dnState</i> (SLS1 monitored) is set additionally.
4	SLS2 active	"Safely limited speed 2 (SLS2)" function is active. • After the parameterised braking time <i>Nlim2</i> has elapsed, bit 9 of the status signal <i>SMI_dnState</i> (SLS2 monitored) is set additionally.
5	SLS3 active	"Safely limited speed 3 (SLS3)" function is active. • After the parameterised braking time <i>Nlim3</i> has elapsed, bit 10 of the status signal <i>SMI_dnState</i> (SLS3 monitored) is set additionally.
6	SLS4 active	"Safely limited speed 4 (SLS4)" function is active. • After the parameterised braking time has elapsed, bit 11 of the status signal <i>SMI_dnState</i> (SLS4 monitored) is additionally set.
7	SDIpos active	"Safe positive direction of rotation (SDIpos)" function is active. • After the parameterised SDI delay time has elapsed, bit 12 of the status signal <i>SMI_dnState</i> (SDIpos monitored) is set additionally.
8	SDIneg active	"Safe negative direction of rotation (SDIneg)" function is active. • After the parameterised SDI delay time has elapsed, bit 13 of the status signal <i>SMI_dnState</i> (SDIneg monitored) is set additionally.
9	ES active	"Confirm button (ES)" function for motion functions in special operation is active.
10	SLI active	"Safely limited increment (SLI)" function is active.
11	OMS	"Operation mode selector (OMS)" function for special operation has been requested.
16	SOS active	"Safe operating stop (SOS)" function is active. • The safe operating stop is monitored. • The function becomes active after the "Safe stop 2 (SS2)" function has been executed.
23	SSE active	Emergency stop function (SSE) is active. • At the end of the function, bit 1 (SS1 active) or bit 0 of the status signal <i>SMI_dnState</i> (STO active) is set according to the emergency stop function parameterised.
29	OMS active	Special operation is active.

Bits not listed are reserved for future extensions!



Note!


To effect the corresponding action (e.g. braking to standstill, holding the standstill position), the application engineer has to provide an appropriate interconnection in the application.

- To integrate the basic function "Limiter", the output *SMI_dwControl* is to be connected to the input *LIM_dwControl* of the **LS_Limiter** system block.



Tip!

For decoding/coding the control signal, the function blocks **L_DevSMControlDecoder** and **L_DevSMControlEncoder** are available in the function library from V2.0.



[10-3] Example: Decoding of the `SMI_dwControl` control signal into individual boolean control signals

11 Basic drive functions

In this chapter the basic (drive) functions of the "Servo Drives 9400" are described, to which the active application can access via defined, internal interfaces, and which can be carried out in the following way, depending on the controller type (StateLine or HighLine) and the Motion Control licence available:

Parameter setting by means of »Engineer« or keypad

In each licence level the basic functions can be parameterised in »Engineer« via a corresponding dialog or alternatively via the keypad.

In the case of the 9400 StateLine (licence level Motion Control StateLevel), the interconnection of the internal interfaces is defined by the technology application selected.

Configuration in the »Engineer« function block editor

»Engineer« additionally provides the graphic function block editor for the 9400 HighLine which can be used to reconfigure and extend the application interconnection by individual functions using the function library.

Programming according to IEC 61131-3 in »PLC Designer«*

For the 9400 HighLine with the licence level Motion Control PLC the basic functions are also provided as separate system blocks in »PLC Designer«, which, if required, can be integrated in the control configuration, and which then can be accessed from the IEC 61131-3 program via the corresponding system variables.

* In preparation!


11 Basic drive functions

11.1 General information

11.1 General information

11.1.1 Internal state machine

The execution of the different basic functions is internally controlled by a state machine which can adopt the following "function states":



[11-1] Function states of the state machine "Basic functions"

The state machine ensures that:


- one basic function at a time adopts the control of the drive.
- only the basic function with the highest priority (= smallest number) is executed if several basic functions are activated at the same time. ▶ [Priorities](#) (383)
- the drive always has a defined state both in case of error and in normal operation.

**Note!**

The basic functions "[Limiter](#)" and "[Brake control](#)" run autonomously, but are able to control the state machine to a certain function state, if required.

The function states are not to be confused with the device states ("Operation", "Fault active", "Device is switched on", etc.) of the controller. ▶ [Device states](#) (100)

From software version V7.0 onwards, the basic functions "[Manual jog, encoderless](#)" and "[Pole position identification](#)" are additionally available for the setting-up operation. Both basic functions can only be requested when the controller is inhibited and with the "Controller not ready" function state:



[11-2] Sequence diagram for basic functions "[Manual jog, encoderless](#)" and "[Pole position identification](#)"

11.1.2 Function states

**Tip!**

In [C02530](#) the currently active function state is displayed.

"Initialisation" state

If the controller has completed the device initialisation, the function state "Initialisation" is passed through automatically.

- In the "Initialisation" function state, the process data required for processing the basic functions are initialised.
- The monitoring functions are not active yet.
- The basic functions are not yet processed (e.g. brake control) and cannot yet be parameterised or activated either.
- If the initialisation of the basic functions is completed and no fault is available, a change-over to the basic state "Drive at standstill" is automatically effected.

State "Controller not ready"

In this function state the pulse inhibit is set in the controller, which means that the power output stages are high-resistance and the drive cannot be controlled.

State "Manual jog, encoderless active"

From software version V7.0 onwards, the drive can be controlled without feedback (encoderless) in this function state, e.g. for a setting-up operation or in the event of service when the feedback system fails. ▶ [Manual job, encoderless](#) (□ 412)

State "Identification of pole position active"

From software version V7.0 onwards, an identification of pole position can be executed in this function state in order to detect the pole position for the motor encoder that is currently activated in [C00495](#). ▶ [Pole position identification](#) (□ 575)

State "Drive at standstill"

This "basic state" is automatically adopted if no other state is active.

- The setpoints for speed and acceleration are set to "0".
- The drive is position-controlled.
- No error has occurred and quick stop is not active.
- Every basic function can be activated out of this state.

State "Drive is stopped"

This function state is automatically passed through when a basic function is deactivated.

- If the drive is not yet in the standstill state, it is decelerated to standstill via a parameterisable deceleration ramp.
- If a basic function is activated during the "stopping" process, this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
- If the drive is at standstill, a change-over to the basic state "Drive at standstill" is automatically effected.

State "Manual jog active"

In this function state, the drive can be operated manually clockwise or anti-clockwise ("Manual jog, encoderless"). ▶ [Manual jog](#) (☞ 400)

- If the home position is known to the controller, the software limit positions set and a potentially connected travel range limit switch are monitored.
- "Retracting" from an activated travel range limit switch is also possible.

State "Homing active"

In this function state the home position and the machine measuring system for the drive can be determined. ▶ [Homing](#) (☞ 421)

- The home position can be specified by an active homing or by reference setting.
- A redetermination of the home position is only required in case of recommissioning or in case of service (e.g. when drive components are exchanged) or after travel commands have been executed which reset the reference.

State "Positioning active"

In this function state all positioning types (absolute, relative, modulo, continuous, touch probe etc.) can be executed. ▶ [Positioning](#) (☞ 479)

- In the position-controlled mode, the drive executes a time-controlled point-to-point setpoint generation based on the defined motion profile.

State "Setpoint follower active"

In this function state the drive directly follows the defined setpoint.

- The setpoint can be optionally defined as speed, torque, or position via three separate basic functions:
 - [Speed follower](#) (☞ 496)
 - [Torque follower](#) (☞ 501)
 - [Position follower](#) (☞ 490)

State "Quick stop active"

This function state is active if quick stop has been activated by the user. ▶ [Quick stop](#) (📖 393)

- The drive is brought to standstill within the deceleration time parameterised, irrespective of the setpoint defined.
- If the quick stop is cancelled again by the user, a change-over to a setpoint-generating basic function (e. g. "Speed follower") is effected, if requested.

**Note!**

For the encoderless motor control types (from software version V3.0) the following applies:

The "Quick stop active" function state is also activated when DC-injection braking is executed.

**Tip!**

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "Diagnostics & fault analysis".

The source that activated quick stop is displayed bit-coded in [C00159](#).

"Error" status

This function state is active if a fault has occurred and the controller is in the "Fault active" or "Quick stop by trouble active" device state.

- The function state can only be abandoned by acknowledging the error if the error is removed.

11.1.3 Interrupting/replacing states

An active function state cannot be interrupted or replaced by the activation of another function state. However, the following exceptions apply:

- The "Initialisation" state replaces all other states.
- The "Fault" state can replace all other states except "Initialisation".
- The "Controller not ready" state can replace all other states except "Error" and "Initialisation".
- The "Quick stop active" state can replace all other states except "Initialisation", "Error" and "Controller not ready".

11 Basic drive functions

11.1 General information

11.1.4 Priorities

The function states are assigned to priorities so that, if several basic functions are activated at the same time, it is always changed to the function state with the highest priority:

Priority	Function state	Executable basic function
1	Initialisation	-
2	Error	-
3	Controller is not ready	-
4	Quick stop active	▶ Quick stop (☞ 393)
5	Manual jog active	▶ Manual jog (☞ 400)
6	Homing active	▶ Homing (☞ 421)
7	Positioning active	▶ Positioning (☞ 479)
8	Setpoint follower (position) active	▶ Position follower (☞ 490)
9	Setpoint follower (speed) active	▶ Speed follower (☞ 496)
10	Setpoint follower (torque) active	▶ Torque follower (☞ 501)
10	Brake check	▶ Brake control (☞ 521)
12	Drive is stopped	▶ Stop (☞ 389)
13	Manual jog, encoderless active	▶ Manual job, encoderless (☞ 412)
14	Pole position identification active	▶ Pole position identification (☞ 575)

1 = highest priority; 14 = lowest priority



Note!

The basic state "Drive at standstill" is automatically adopted if no other state is active.

11.1.5 Requesting control via a basic function

Enable input "bEnable"

The basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" and the three setpoint followers each possess an *bEnable* enable input, via which the control of the corresponding basic function can be requested.

- If no other basic function and no error status is active, a change-over to the corresponding function state is effected, and the basic function can be controlled now.
- If several enable inputs are set to TRUE at the same time, the change-over to the function state is effected with the highest priority.

Status outputs "bEnabled", "bActive" and "bDone"

If the basic function is enabled, the *bEnabled* status output of the basic function is set to TRUE and the corresponding drive motion can be started via the control inputs of the basic function.

- If the basic function is currently carrying out a drive movement, this is shown by a TRUE signal at the status output *bActive*.
- The basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)" are only provided with the status output *bEnabled*, as the drive directly follows the setpoint selection after being enabled.
- The basic functions "[Homing](#)" and "[Positioning](#)" are furthermore provided with a status output *bDone* showing that the drive movement started (Homing or positioning) has been completed.

Priority	Basic function	Status outputs		
		<i>bEnabled</i>	<i>bActive</i>	<i>bDone</i>
1	Manual jog	☑	☑	
2	Homing	☑	☑	☑
3	Positioning	☑	☑	☑
4	Speed follower	☑		
5	Torque follower	☑		
6	Position follower	☑		

Re-deactivating the enable of a basic function

When the *bEnable* enable input of the active basic function is reset to FALSE, the control inputs of the basic function are inhibited and the status outputs *bEnabled*, *bActive* and *bDone* are reset to FALSE.

- If the drive is not at standstill, it is brought to standstill within the deceleration time for [Stop](#) if no other basic function takes over the control of the drive. Here a change-over from the active function state via the function state "Drive is stopped" back to the basic state "Drive at standstill" is effected.
- When the enable input of another basic function is set to TRUE, this basic function adopts the control of the drive immediately.

11.1.6 Start acceleration/acceleration reduction when the basic function changes

In order to make the transitions during the changeover between the single basic functions as jerk-free as possible, i.e. preventing acceleration steps, the current setpoint acceleration is used as starting value for the new basic function (see the following table).

from	to						
	Position, speed or torque follower	Manual jog	Homing	Positioning	Error/controller not ready	Stop	Quick stop*
Position follower	0	A	A	A	0	A	0
Speed follower	0	A	A	A	0	A	0
Torque follower	0	0	0	0	0	0	0
Manual jog	0	-	B	B	0	B	0
Homing	0	B	-	B	0	B	0
Positioning	0	B	B	-	0	B	0
Error/controller not ready	0	0	0	0	-	0	0
Stop	0	B	B	B	0	-	0
Quick stop*	0	A	A	A	0	A	-

Legend:

0	The start acceleration is defined with "0", thus no acceleration reduction is required.
A	<ul style="list-style-type: none"> Acceleration value is generated from the differentiation and filtering (C02562) of the active setpoint speed. Jerk = Maximum value from transition jerk (defined via C02545) and jerk of the "new" profile data.
B	<ul style="list-style-type: none"> Acceleration value is taken from the setpoint generator (e.g. profile generator). Jerk = maximum value from the jerk of the "old" and "new" profile data.

* Also quick stop by trouble

Reduction of the start acceleration

Depending on the acceleration and S-ramp time parameterised in the basic function, the start acceleration is reduced.

The following applies for software versions lower than V7.0:

- The start acceleration is reduced with the maximum jerk of the old or new basic function. ▶ [Setting the S-ramp time](#) (□ 387)



Note!

Very low jerks cause very high speeds!

See also the following chapter "[Setting the S-ramp time](#)". (□ 387)

Since this behaviour is mostly not wanted or expected, the acceleration is reduced from software version V7.0 as described in the following section.

The following applies from software version V7.0 onwards:

- The start acceleration is reduced with the maximum jerk of the old or new basic function.

Transition of a profile-generating to a profile-generating basic function

The corresponding jerk results from the profile data:

$$\text{Jerk} = \frac{\text{Profile acceleration/deceleration}}{\text{S-ramp time}}$$

Transition of a non-profile-generating to a profile-generating basic function

- The jerk of the profile-generating basic function results from the profile data:

$$\text{Jerk} = \frac{\text{Profile acceleration/deceleration}}{\text{S-ramp time}}$$

- Since a non-profile-generating basic function has no defined jerk, a "transition jerk" is used which results from the reference acceleration and the reference S-ramp time parameterised in [C02545](#).

$$\text{Transition jerk} = \frac{\text{Reference acceleration}}{\text{Reference Jerktime}} = \frac{\text{C00011} / 1 \text{ ms}}{\text{C02545} \times 10}$$

- With a Lenze setting [C02545](#) = 0.001 s, a maximum jerk occurs, i.g. the start acceleration is reduced in one cycle (1 ms).
- The setting [C02545](#) = 0.000 s results in a compatible behaviour lower than V7.0.



Tip!

Profile-generating basic functions are:

"[Stop](#)", "[Manual jog](#)", "[Homing](#)", "[Positioning](#)"

Non-profile-generating basic functions are:

"[Quick stop](#)", "[Position follower](#)", "[Speed follower](#)", "[Torque follower](#)"

11 Basic drive functions

11.1 General information

11.1.7 Setting the S-ramp time

For path planning, various basic functions serve to build up or reduce the acceleration linearly. The motion profile causes less structural vibrations and the gearboxes are protected.

The smoothing (jerk) is calculated via the S-ramp time and the maximum acceleration permitted in the profile:

$$\text{Jerk} = \frac{\text{maximum acceleration}}{\text{S-ramp time}}$$

[11-3] Formula for calculating the jerk for acceleration and deceleration phases

S-ramp times can be set in the given parameters for the following basic functions:

Basic function	Parameter for S-ramp time
Stop	C02611
Quick stop	C00106
Manual jog	C02624
Homing	C02648
Positioning	The S-ramp time is defined via FB L_PosPositionerTable or FB L_PosProfileTable.




Stop!


When it is switched to another basic function, the start acceleration is reduced with the jerk of the new basic function. **A small jerk causes very high speeds!**

Remedy: Avoid unnecessarily long S-ramp times. Set the profile parameters of the different basic functions so that the jerk is roughly the same for all basic functions.

Examples



[11-4] Example 1: Point-to-point positioning from standstill without start acceleration



[11-5] Example 2: Point-to-point positioning from standstill with start acceleration

In the example 2, the slow reduction of the start acceleration results in very high speeds!

11.2 Stop

The standard stop (in the following called "stop") of the drive will be automatically activated by the internal state machine if a basic function is deactivated and the drive is not yet at standstill.

- The drive is decelerated to standstill along a parameterised deceleration ramp
 - While the drive is braked to standstill, the state machine is in the "Drive is stopped" function state.
 - If meanwhile another basic function is activated, this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
 - If the drive is at standstill, a change-over to the basic state "Drive at standstill" is automatically effected.
- An acceleration phase active at the time of activated stopping process is considered by the normal stop, i.e. the current acceleration is first lead to "0" with the parameterised S-ramp time before the real deceleration process starts.
- If the controller is enabled with the shaft coasting (controller inhibit and pulse inhibit are deactivated), the drive is lead to standstill from the current speed.



Stop!

The basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)" do not take over the control of the from the current speed, but immediately with the setpoint defined, which may cause a jerk!




Note!

- As the stop function takes into account the acceleration active at the moment of activation, the deceleration of the stop function should always be set greater than the deceleration of the active process in order to avoid a possible overshoot.
 - If the stop function is activated while the basic function "[Torque follower](#)" or the states "Controller inhibited" or "Error" are active, the drive is braked to standstill starting from the current speed and without taking into account the current acceleration.
- ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (📖 385)

11.2.1 Internal interfaces | "LS_Stop" system block

The **LS_Stop** system block provides the internal interfaces for the basic function "Stop" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Outputs


Identifier <small>DIS code data type</small>	Value/meaning
STP_dnState <small>C02616 DINT</small>	Status (bit coded) <ul style="list-style-type: none"> When the basic function is not active, all bits are set to "0". Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Drive is braked to standstill. <ul style="list-style-type: none"> The internal state machine is in the "Drive is stopped" function state.
	Bit 2 Drive is at standstill. <ul style="list-style-type: none"> The internal state machine is in the "Drive at standstill" function state.
	Bit 3 Deceleration phase is active.
	Bit 5 CCW rotation is active.
STP_bStopActive <small>C02617 BOOL</small>	Status signal "Stop is active"
	TRUE The drive is braked to standstill or is at standstill. <ul style="list-style-type: none"> The internal state machine is in the "Drive is stopped" or "Drive at standstill" function state.

11.2.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Stop*
- Short overview of parameters for standard stop :


Parameters	Info
C02610	Deceleration time for stop
C02611	S-ramp time for stop
C02612	Ref. for decel. time of stop

Parameter setting of stop




[11-6] Deceleration time referred to the motor reference speed

- The deceleration time for stop set in [C02610](#) refers to a speed variation from the motor reference speed ([C00011](#)) to standstill, i. e. the deceleration is constant.



[11-7] Deceleration time referred to the current speed

- When [C02612](#) is set = "1", the deceleration time refers to the current speed, i. e. the braking time is constant.




[11-8] S-shaped deceleration ramp through selection of a relative S-ramp time

- By entering an S-ramp time in [C02611](#), the deceleration ramp can be set in an S-shaped manner for purposes of jerk limitation; the total time until standstill is then extended by the S-ramp time set. ▶ [Setting the S-ramp time](#) (□ 387)
- Braking time at motor reference speed or [C02612](#) = "1":

$$C02610 [s] + C02611 [s]$$


11.2.3 Behaviour of the function (example)

In the following example the enable of manual jog is deactivated during an active manual jog. Then the drive is braked to standstill within the deceleration time ❶ set for stop.



[11-9] Example: Stop with reaching standstill

If the basic function "Manual Jog" is reactivated within the deceleration time ❶, this basic function takes over the control of the drive from the current speed and the function state "Drive is stopped" is abandoned immediately:



[11-10] Example: Stop without reaching standstill

11 Basic drive functions

11.3 Quick stop

11.3 Quick stop

In contrast to [Stop](#), the purpose of quick stop (QSP) is a stop in case of error. If quick stop is activated, the drive is brought to standstill within the deceleration time set irrespective of the setpoint that is preselected.



Note!

Through this, superimposed controls (e.g. synchronous or position control) may produce following errors. If several drives execute a coordinated motion, the quick stop function should only be used for the motion master (master drive) in order to maintain the coordination.

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (📖 385)




Tip!

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "[Diagnostics & fault analysis](#)". (📖 608)

The source that activated quick stop is displayed bit-coded in [C00159](#).

11.3.1 Internal interfaces | "LS_Quickstop" system block

The **LS_Quickstop** system block provides the internal interfaces for the basic function "Stop" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier DIS code data type	Information/possible settings		
QSP_bActivate1 C02619/1 BOOL	Activate quick stop <ul style="list-style-type: none"> The three inputs are linked via a logic OR gate. 		
QSP_bActivate2 C02619/2 BOOL		TRUE	If one of the three inputs is set to TRUE, a change-over to the "Quick stop active" function state is effected and the drive is brought to standstill within the deceleration time set for quick stop.
QSP_bActivate3 C02619/3 BOOL		TRUE↯FALSE	If all three inputs are reset to FALSE, a change-over to a setpoint-generating basic function (e. g. "Speed follower") via the "Drive is stopped" function state is effected.
QSP_bActivateDCBrake C02619/5 BOOL From V3.0	Activate DC-injection braking . (☰ 397) <ul style="list-style-type: none"> Only possible if V/f control or sensorless vector control is selected as motor control type in C00006! This input has a higher priority than the three inputs <i>QSP_bActivate1 ... 3</i>. 		
	TRUE	A change-over to the "Quick stop active" function state is effected and the drive is decelerated with the braking current set in C00974 .	
	TRUE↯FALSE	DC-injection braking is activated again. <ul style="list-style-type: none"> If flying restart is activated in C00990, a flying restart process is automatically started to determine the current motor speed. 	

Outputs


Identifier DIS code data type	Value/meaning
QSP_bActive C02619/4 BOOL	Status signal "Quick stop through application active" <ul style="list-style-type: none"> <i>QSP_bActive</i> is not set to TRUE if quick stop has been activated by another source, e. g. via device command or as an error response ("Quick stop by trouble").
	TRUE <ul style="list-style-type: none"> Quick stop has been requested via one of the three inputs <i>QSP_bActivate1 ... 3</i> and is active. - or - DC-injection braking has been requested via <i>QSP_bActivateDCBrake</i> and is active (only for motor control mode without encoder).

11.3.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Quick stop*
- Short overview of the parameters for quick stop:


Parameters	Info
C00105	Decel. time - quick stop
C00106	Quick stop S-ramp time
C00107	Reference for quick stop deceleration time

Parameter setting of quick stop




[11-11] Deceleration time referred to the motor reference speed

- The deceleration time for the quick stop function set in [C00105](#) refers to a speed variation from the motor reference speed ([C00011](#)) to standstill.



[11-12] Deceleration time referred to the current speed

- When [C00107](#) is set = "1", the deceleration time refers to the current speed.



[11-13] S-shaped deceleration ramp through selection of a relative S-ramp time

- By entering a relative S-ramp time in [C00106](#), the deceleration ramp can be set in an S-shaped manner for purposes of jerk limitation; the total time until standstill is then extended by the S-ramp time set. ▶ [Setting the S-ramp time](#) (387)

- Braking time at motor reference speed or [C00107](#) = "1":

$$C00105 + \frac{C00105 \cdot C00106 [\%]}{100 \%}$$



Tip!

After reaching standstill, the standstill position can be maintained while a torque is applied.

- For this purpose, select the phase controller gain in [C00254](#) > "0".
- With [C00254](#) > "0" the phase control is automatically activated after the standstill is reached.

11.3.3 Activate/deactivate quick stop

For activation/deactivation of quick stop by the application, the three inputs *QSP_bActivate1...3* are provided. ([📖 393](#))


- The three control inputs are linked via a logic OR gate, i.e. in order to activate quick stop, only one of the three inputs must be set to TRUE. To deactivate quick stop, though, all three inputs must be reset to FALSE.
- The control inputs can be linked with terminals (digital inputs) and/or process data in the function block editor.



Note!

In the standard technology applications the control input *QSP_bActivate1* is linked with the digital input DI1 in the Lenze setting.

Further options for activating quick stop

- Via device command "Activate quick stop" ([C00002](#) = "45"), e.g. via a corresponding SDO of a higher-level control, an HMI or »Engineer«.
- Via the  key at the keypad, unless the Lenze setting of [C00469](#) (assignment of the key) has been changed.
- Through the response "quick stop by trouble" parameterised for monitoring.

11.3.4 DC-injection braking

This function extension is available from software version V3.0!



Note!

DC-injection braking is only possible if V/f control or sensorless vector control is selected as motor control type in [C00006](#)!

Activate DC-injection braking

To activate DC-injection braking through the application, the *bActivateDCBrake* control input must be set to TRUE.


- A change-over to the "Quick stop active" function state is effected and DC-injection braking with the braking current set in [C00974](#) is carried out.

Flying restart process after cancelling DC injection braking

If the flying restart mode is activated in [C00990](#) and DC-injection braking is cancelled, a flying restart process is automatically started to determine the current motor speed if the following conditions are met:

- V/f control or sensorless vector control are selected as motor control in [C00006](#).
- The position control structure is set to "Phase controller is active" in [C02570](#).
- The *MI_bFlyingSyncBlocked* control input of the motor interface is not assigned or set to FALSE.
- The holding brake, if available, is not applied.

11.3.4.1 DC-injection braking and flying restart process




[11-14] Process example: speed follower is active → QSP_bActivateDCBrake is active → speed follower is active

- A. Initial situation: basic function "Speed follower" is enabled and active.
- B. *QSP_bActivateDCBrake* control input is set to TRUE through the application to activate DC-injection braking.
- C. DC-injection braking is executed with the braking current set in [C00974](#).
- D. *QSP_bActivateDCBrake* control input is reset to FALSE through the application to deactivate DC-injection braking.
- E. The flying restart process starts, i.e. the controller calculates the output frequency required for the momentary motor speed, then connects to the system, and accelerates the motor to the defined setpoint again.

11.3.4.2 DC-injection braking when quick stop is activated

If DC-injection braking is activated in [C00976](#) instead of quick stop, DC-injection braking is executed automatically when quick stop is activated.

- After activating quick stop, a change-over to the "Quick stop active" function state is effected, and for the quick stop deceleration time set in [C00105](#) a DC-injection braking process with the braking current set in [C00975](#) is carried out.
- After this time has elapsed, a change-over to the braking current parameterised in [C00974](#) is carried out and DC-injection braking is continued with this braking current.
- The DC-injection braking in this case is also carried out when the "Quick stop by trouble" error response is actuated; however, instead of the "Quick stop active" function state, the "Fault" function state is active, and the controller is in the "Quick stop by trouble active" device state.



[11-15] Process example: speed follower is active → quick stop activation → speed follower is active



Note!

The quick stop braking current in [C00975](#) has to be set so that the drive can be decelerated from the maximum operating speed to standstill within the deceleration time for quick stop set in [C00105](#)!

11.4 Manual jog

The basic function "Manual jog" serves to traverse the drive manually, e.g. to clean or exchange the tool.

- As an option, it is possible to change over to a second speed during traversing.
- "Retraction" of operated (travel range) limit switches is also supported. Only traversing in the corresponding retracting direction is then possible.



Danger!

During manual jogging, specially assigned profile parameters are active. If they have not been set correctly, the drive can engage in uncontrolled movement!



Stop!

In manual mode a travel range monitoring via limit switches and software limit positions is carried out via the basic function "[Limiter](#)". ([□ 506](#))

If no limit switches are connected and no software limit positions are set, and the reference is not known, the drive can travel into a mechanical barrier during manual mode and machine parts can be destroyed or damaged!



Note!

For manual jog setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) ([□ 385](#))

For the encoderless motor control types (from software version V3.0) the following applies:

If no position controller has been selected for position control in case of V/f control or sensorless vector control ([C02570](#) = "1: Phase controller is active"), the manual jog is only executed via the speed profile resulting from the manual jog parameters.

11.4.1 Internal interfaces | "LS_ManualJog" system block

The **LS_ManualJog** system block provides the internal interfaces for the basic function "Manual jog" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings			
MAN_bEnable C02639/1 BOOL	Request control of basic function			
	<table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Active manual jog is stopped, i. e. a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.	TRUE↔FALSE
TRUE	If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.			
TRUE↔FALSE	Active manual jog is stopped, i. e. a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.			
MAN_bJogPositive C02639/2 BOOL	▶ Manual jog in positive/negative direction (☞ 407)			
MAN_bJogNegative C02639/3 BOOL				
MAN_bActivateJogSpeed2 C02639/4 BOOL	Change over to speed 2 for manual jog			
	<table border="1"> <tr> <td>FALSE</td> <td>Speed 1 (C02620) active.</td> </tr> <tr> <td>TRUE</td> <td>Speed 2 (C02621) active.</td> </tr> </table>	FALSE	Speed 1 (C02620) active.	TRUE
FALSE	Speed 1 (C02620) active.			
TRUE	Speed 2 (C02621) active.			
MAN_bReleaseLimitSwitch C02639/5 BOOL	Retracting of an activated limit switch			
	<table border="1"> <tr> <td>TRUE</td> <td>Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.</td> </tr> </table>	TRUE	Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.	
TRUE	Retracting of the accordingly operated limit switch in the corresponding retracting direction until the limit switch is cleared again (no longer operated) and the drive is within the software limit positions again. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.			

Identifier DIS code data type	Information/possible settings		
MAN_dnSpeedOverride_n <small>From V5.0</small> C02637 DINT	Value for speed override <ul style="list-style-type: none"> • Percentage multiplier for the currently active speed (C02620 or C02621). • In the case of active manual jog, the speed override is always active and does not have to be activated separately. • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the speed parameterised in C02620 or C02621. • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are set to 0% internally and lead to the standstill of the drive. 		
MAN_bStepMode <small>From V5.0</small> C02639/8 BOOL	▶ Manual jog with step limitation (□ 408) <ul style="list-style-type: none"> • Only possible if the "Manual jog with intermediate stop" mode is not active. <table border="1" data-bbox="608 629 1441 667"> <tr> <td>TRUE</td> <td>Manual jog with step limitation active.</td> </tr> </table>	TRUE	Manual jog with step limitation active.
TRUE	Manual jog with step limitation active.		
MAN_bIntermediateStopMode <small>From V5.0</small> C02639/9 BOOL	▶ Manual jog with intermediate stop (□ 409) <ul style="list-style-type: none"> • This mode has a higher priority than the "Manual jog with step limitation" mode. <table border="1" data-bbox="608 734 1441 772"> <tr> <td>TRUE</td> <td>Manual jog with intermediate stop active.</td> </tr> </table>	TRUE	Manual jog with intermediate stop active.
TRUE	Manual jog with intermediate stop active.		
MAN_FBData <small>From V5.0</small>	Interface for the transfer of the function block instance data for determining the positions for intermediate stop <ul style="list-style-type: none"> • Connect this input to the output <i>FBData</i> of the function block instance of type L_PosPositionerTable or L_PosProfileTable. 		

Outputs

Identifier DIS code data type	Value/meaning
MAN_dnState C02638 DINT	Status (bit coded) <ul style="list-style-type: none"> • When the basic function is not enabled, all bits are set to "0". • Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Manual jog active.
	Bit 2 Manual jog is completed.
	Bit 3 Acceleration/deceleration phase is active.
	Bit 5 CCW rotation is active.
	Bit 15 Fault in basic function active (group signal).
	Bit 16 Stop by simultaneous selection of negative direction and retraction of limit switch.
	Bit 17 Stop by simultaneous selection of positive and negative direction.
	Bit 18 Stop by simultaneous selection of positive direction and retraction of limit switch.
	Bit 19 Speed override ≤1 % <ul style="list-style-type: none"> • This status is only available from software version V5.0.
	Bit 20 Speed 2 (C02621) active.
	Bit 21 Speed 1 (C02620) active.
	Bit 22 Stop by selection of positive direction and simultaneous activation of the positive software limit position or the positive limit switch.
	Bit 23 Stop by selection of negative direction and simultaneous activation of the negative software limit position or the negative limit switch.
	Bit 24 General abort process (ramp down of the speed setpoint) <ul style="list-style-type: none"> • Takes place e.g. when a manual direction initiator is released or due to an impermissible state (see bit 16, 17, 18, 22, 23).
	Bit 25 Stopping is active. <ul style="list-style-type: none"> • Basic function enabled for the first time but no manual jog has been requested/is active yet or current speed is higher than the manual jog speed.
Bit 26 Home position is not known. <ul style="list-style-type: none"> • This status is only available from software version V5.0. 	
Bit 27 No intermediate stop position available. <ul style="list-style-type: none"> • This status is only available from software version V5.0. 	
Bit 30 Profile generation error.	
MAN_bEnabled C02639/6 BOOL	Status signal "Basic function is enabled"
	TRUE Manual jog via the control inputs is possible. <ul style="list-style-type: none"> • The <i>MAN_bEnable</i> enable input is set to TRUE and the controller is in the "Manual jog active" function state.
MAN_bActive C02639/7 BOOL	Status signal "Basic function is active"
	TRUE Manual jog is active (the drive axis is moving).


11.4.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Manual jog*
- Short overview of the parameters for manual jog:

Parameters	Info
C02620	Manual jog: Speed 1
C02621	Manual jog: Speed 2
C02622	Manual jog: Acceleration
C02623	Manual jog: Deceleration
C02624	Manual jog: S-ramp time
C02625	Manual jog: Step distance
C02626/1...16	Manual jog: Index stop position
C02627/1...16	Manual jog: Selected stop position

Greyed out = display parameter

11.4.2.1 Smooth start and quick stop of the drive



[11-16] Example: Smooth start and quick stop




Tip!

A quick deceleration ([C02623](#)) reduces the time from letting go of the "Jog key" to the actual stop of the drive, so that the drive can thus be better positioned "by eye" and the desired stop position is not overtravelled.

- Different values for acceleration and deceleration can be set in [C02622/ C02623](#) in order to implement a smooth start and a quick stop of the drive.
- By entering a relative S-ramp time in [C02624](#) both ramps can be set in S-shape for jerk reduction. ▶ [Setting the S-ramp time](#) (□ 387)

11.4.2.2 Second speed



- By setting the input *MAN_bActivateJogSpeed2* to TRUE, a change-over to a second speed ([C02621](#)) can be carried out during the traversing process.

[11-17] Example: Change-over to second speed

11.4.3 Executing manual jogging

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "manual jog" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *MAN_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Manual jog active" function state is effected and manual jog can be carried out via the control inputs.
- A successful change to the function state "Manual jog active" is displayed by a TRUE signal at the *MAN_bEnabled* status output.

Deactivation

If the *MAN_bEnable* enable input is reset to FALSE, an active manual jog is reset, i.e. the control inputs for manual jog are inhibited and the drive is braked to standstill within the deceleration time for [Stop](#). ([📖 389](#))

- The status output *MAN_bEnabled* is reset to FALSE and a change-over from the active "Manual jog active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11.4.3.1 Manual jog in positive/negative direction

In the "Manual jog active" function state the drive can be traversed manually according to the following truth table via the control inputs:

MAN_bJogNegative	MAN_bJogPositive	MAN_bActivateJogSpeed2	Job title
FALSE	FALSE	-	Stop <ul style="list-style-type: none"> The drive is controlled to standstill at the set rate of deceleration.
FALSE	TRUE	FALSE	Manual jog <ul style="list-style-type: none"> In positive direction Using speed 1 (C02620)
		TRUE	Manual jog <ul style="list-style-type: none"> In positive direction Using speed 2 (C02621)
TRUE	FALSE	FALSE	Manual jog <ul style="list-style-type: none"> In negative direction Using speed 1 (C02620)
		TRUE	Manual jog <ul style="list-style-type: none"> In negative direction Using speed 2 (C02621)
TRUE	TRUE	-	When both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> The drive is controlled to standstill at the set rate of deceleration. If not both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> The drive continues to traverse in the direction that was selected first.



Note!

In the standard technology applications "Actuating drive – speed" and "Actuating drive – torque", in the Lenze setting the control inputs are linked to the following digital inputs:

- **DI6:** Activate manual mode
- **DI7:** Manual jog in positive direction
- **DI8:** Manual jog in negative direction

11.4.3.2 Manual jog with step limitation

This function extension is available from software version V5.0 onwards!

This mode can be activated via the control input *MAN_bStepMode*.

In the "Manual jog with step limitation" mode the drive traverses by the "step distance" parameterised in [C02625](#) if a direction is requested via the control inputs *MAN_bJogPositive*/*MAN_bJogNegative*. After traversing this distance, the drive stops.

- A new positive edge for the routing request causes a restart of the function or a reset of the distance counter, even if the drive is not at standstill yet.
- If the routing request is reset before the distance is reached, the drive stops immediately (with the deceleration set).



Note!

The two modes "Manual jog with step limitation" and "Manual jog with intermediate stop" cannot be active at the same time.

If there is a simultaneous request via the control inputs *MAN_bStepMode* and *MAN_bIntermediateStopMode*, only the "Manual jog with intermediate stop" mode is active. ▶ [Manual jog with intermediate stop](#) (📖 409)

11.4.3.3 Manual jog with intermediate stop

This function extension is available from software version V5.0 onwards!

This mode can be activated via the control input *MAN_bIntermediateStopMode*.

In the "Manual jog with intermediate stop" mode, in the case of a routing request via the control inputs *MAN_bJogPositive*/*MAN_bJogNegative* the drive traverses to the defined "Intermediate stop position" that is next in the corresponding direction.

MAN_bJogNegative	MAN_bJogPositive	Job title
FALSE	TRUE	Drive traverses from the current position to the next target in positive direction of the intermediate positions defined.
TRUE	FALSE	Drive traverses from the current position to the next target in negative direction of the intermediate positions defined.

- The drive stops on the intermediate position that is approached.
- If the routing request is reset before the intermediate position is reached, the drive stops immediately (with the deceleration set).
- After the drive has stopped on the intermediate position, it can only continue after a new positive edge for the routing request.
- If the drive is in the outmost intermediate position defined and a new routing request is effected, the drive stops.



Note!

Requirements for manual jog with intermediate stop:

- The home position is known (otherwise status bit 26 is set).
- At least one intermediate stop position is defined (otherwise status bit 27 is set).

Selection of the intermediate stop positions

The max. 16 intermediate stop positions are selected/defined via a function block instance of type **L_PosPositionerTable** or **L_PosProfileTable**.

- For the transfer of the intermediate stop positions the output *FBData* of the respective function block instance is to be connected to the input *MAN_FBData* of the **LS_ManualJog** SB.
- The positions defined by the function block instance, which are to be used as intermediate stop positions are selected via [C02626/1...16](#).
 - In connection with a function block instance of type **L_PosPositionerTable**:
In [C02626/x](#) the index [1...75] of the table position in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used.
 - In connection with a function block instance of type **L_PosProfileTable**:
In [C02626/x](#) the index [1...4] of the profile data set has to be specified, which contains the intermediate stop position x that is to be used.
- The positions selected are shown in [C02627/1...16](#).


11.4.3.4 Manual jog to limit position



Note!

Detailed information on travel range monitoring via limit switches and software limit positions can be found in the description of the basic function "[Limiter](#)". ([506](#))


Manual jog to software limit position



[11-18] Example: Manual jog to positive software limit position

- If the reference is known and the software limit positions are set, a positioning to the corresponding software limit position is carried out, if manual jog was not exited manually before by resetting *MAN_bJogNegative* or *MAN_bJogPositive*.
- The drive brakes with the deceleration set ([C02623](#)) to the position of the corresponding software limit position.

Manual jog to hardware limit position (limit switch)



[11-19] Example: Manual jog to positive limit switch

- When a limit switch is approached during manual jog, the drive is braked to standstill within the deceleration time set for the quick stop function.

See also:

- ▶ [Software limit positions](#) ([512](#))
- ▶ [Hardware limit positions \(limit switch\)](#) ([515](#))

11.4.3.5 Retracting of an activated limit switch

By setting *MAN_bReleaseLimitSwitch* to TRUE, retracting from an operated limit switch is possible. The traversing process in the corresponding retracting direction is carried out until the limit switch is no longer activated.

- If, while retracting, a direction is selected additionally via the control inputs *MAN_bJogPositive* or *MAN_bJogNegative* towards the retracting direction, the travel is continued even after the limit switch has been abandoned until *MAN_bJogPositive* or *MAN_bJogNegative* are reset to FALSE.
- If the direction opposite to the retracting direction is preselected instead, the drive stops, and a corresponding status is shown via the status output *MAN_dnState*.



Note!

Retracting from a limit switch is only possible if it is still activated, i. e. if the corresponding limit switch input of the limiter is still activated. Therefore ensure that if a limit switch is approached, its trigger mechanics is not "overtravelled", for instance by a too great mass or drive, so that by this the limit switch is no longer activated.



Tip!

An activated limit switch can also be exited again by manual jog in the retracting direction via the control input *MAN_bJogPositive* or *MAN_bJogNegative*.

See also: [▶ Hardware limit positions \(limit switch\) \(📖 515\)](#)

11 Basic drive functions

11.5 Manual job, encoderless

11.5 Manual job, encoderless

This function extension is available from software version V7.0!



Danger!

In this basic function, the extent of the useable operating modes of the holding brake is restricted. Only the following operating modes function:

- Directly with brake module ([C02580, selection 1](#)) and
- Direct switching externally ([C02580, selection 11](#))

The basic function "Manual jog (OL)", which is implemented in the motor control system of the drive controller, enables the user to operate the drive without control (i.e. "open loop", encoderless) and independently of the selected operating mode:

- If the motor is asynchronous, the speed depends on the load.
- A synchronous motor turns with a prescribed field frequency.



Stop!

It is only permissible to activate controlled operation of synchronous machines if the following parameters have been set correctly, in addition to correct assignment of the encoder image and the motor's rotating field:

- Motor control SC, "Servo control of sync motor" ([C00006, selection 1](#))
- Pole position of the motor encoder ([C00058](#))
- Motor data ([C00081 ... C00091](#))
- Active resolver feedback or encoder feedback as motor encoder ([C00420 ... C00422](#))

The basic function "Manual jog (OL)"

- is based on the I-rotation test mode and is especially suitable for the operation of synchronous motors. There is a corresponding dialog box in »Engineer«
- is not identical with sensorless operation of synchronous machines. In the basic function "Manual jog (OL)", neither parameters relevant to the motor model nor parameters relevant to the motor type are used
- can be activated and controlled by means of process data (system block inputs) or by accessing codes (e.g. via keypad).

Uses of "Manual job, encoderless"

- Test of hardware (e.g. connection system, rotating field and motor cables) during initial commissioning and during servicing
- Movement of the drive or machine to a service position in the event of defective encoder feedback
- Functional test of the discretely structured feedback system of a torque or linear motor.

11 Basic drive functions

11.5 Manual job, encoderless

- Support for [Pole position identification](#) (☰ 131) in the case of torque and linear motors by means of
 - movement to a machine position in which pole position identification can be carried out in a reproducible manner and
 - setting of the pole position angle with the "PL touch probe signal"

11.5.1 Parameter setting

- Parameterising dialog box in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Manual jog (OL)*
- Short overview of the parameters for manual jog, encoderless:

Parameters	Info	Lenze setting	
		Value	Unit
C02770/1	EnableManualMode	0: Deactivate	
C02770/2	JogPositive	0: Deactivate	
C02770/3	JogNegative	0: Deactivate	
C02770/4	ActivateDataBit1	0: Deactivate	
C02770/5	ActivateDataBit2	0: Deactivate	
C02771/1...4	Frequency • Field frequency f_d with which the current vector rotates.	1.0	Hz
C02772/1...4	Start angle	0.0	°
C02773/1...4	Current • R.m.s. value of the current vector which is injected with the parameterised frequency/starting angle. • 100 % $\equiv I_{\max_device}$ (C00022)	10.00	%
C02774/1...4	Acceleration time	1.000	s
C02775/1...4	Deceleration time	1.000	s
C02776/1...4	Max. activation time	1.000	s
C02779	Mol_SetpointCurrent	-	A
C02780	Mol_dnState	-	
C02781	ManualJogOpenLoop: Dig. signals	-	

Greyed out = display parameter



Stop!

At the frequency $f_d = 0$ Hz, the r.m.s. value increases to 141 % of the current parameterised in [C02773/x](#). As a result, the connected motor can be destroyed!


Remedy: Activation of a derating curve in i2xt monitoring or limitation of the parameterised current in [C02773/x](#) to 71 % of the rated motor current. ▶ [Motor monitoring \(\$I^2_{xt}\$ \)](#) (☰ 218)

11.5.2 Carrying out encoderless manual jogging

The procedure for using this basic function is described with reference to the signal characteristic shown below.

Please refer to the following chapters for more information

- ▶ [Prerequisites](#)
- ▶ [Activation / Deactivation](#)
- ▶ [Selection and contents of the profile parameter set](#)
- ▶ [Encoderless manual jogging in a positive/negative direction](#)



[11-20] Signal characteristic: activation/deactivation of basic function "manual jog (OL)"

11 Basic drive functions

11.5 Manual job, encoderless

11.5.2.1 Prerequisites

- Check and, if necessary, adjust the basic parameterisation:
 - Optimisation of the current controller in the case of non-Lenze motors or motors that are not included in the »Engineer« motor catalogue. ▶ [Optimise current controller](#) (☞ 181)
 - Parameterisation of motor monitoring corresponding to the existing motor with the monitoring response "Fault". ▶ [Motor monitoring \(I²xt\)](#) (☞ 218)
 - This function is especially important for monitoring the permissible r.m.s. current load on motors at $f_d = 0$ Hz.
 - Activation of maximum current monitoring with the monitoring response "Fault" in the case of non-Lenze motors or motor that are not included in the »Engineer« motor catalogue. ▶ [Maximum current monitoring](#) (☞ 233)
 - Activation of motor temperature monitoring via PTC and/or KTY. ▶ [Motor temperature monitoring](#) (☞ 225)
- The controller inhibit is active.
- The controller is in the "Controller not ready" state ▶ [Device states](#) (☞ 100).
- The basic function "Manual jog (OL)" is part of the active application; see ▶ [Internal interfaces | "LS_ManualJogOpenLoop" system block](#) (☞ 419).
- No other basic function is active.

11.5.2.2 Activation

In order to request the control via the basic function, the *MOL_bEnable* enable input in the application must be set to TRUE or [C02770/1](#) to "1".

- If no other basic function is active, a changeover to the function state "Manual jog, encoderless active" takes place and controlled traversing can be carried out by means of the control inputs or by writing values into [C02770/2...5](#).
- A successful changeover to the function state "Manual jog, encoderless active" is indicated by a TRUE signal at the status output *MOL_bEnabled*.

11.5.2.3 Deactivation




Stop!

Before the basic function is deactivated, the controller inhibit must be set. Otherwise, unsteady drive behaviour can occur when a changeover is made from the basic function "Manual jog, encoderless" to the basic function "Stop".

The basic function is deactivated by

- setting the input "MOL_bEnable" to FALSE or
- removing the checkmark (if there is one) in the »Engineer« dialog box entitled *Manual control (parameter set 1)*.



[11-21] Deactivation of the basic function "Manual jog, encoderless"

11.5.2.4 Selection and contents of the profile parameter set

For controlled traversing, four different profiles can be parameterised. The profile parameter set to be used is selected by means of the control inputs *MOL_bActivateDataBit1* [C02781/4](#) and *MOL_bActivateDataBit2* [C02781/5](#) or alternatively by means of the parameters [C02770/4](#) (*ActivateDataBit1*) and [C02770/5](#) (*ActivateDataBit2*):

<i>MOL_bActivateDataBit2</i> C02781/5	<i>MOL_bActivateDataBit1</i> C02781/4	Selected profile parameter set
FALSE	FALSE	Profile parameter set 1
FALSE	TRUE	Profile parameter set 2
TRUE	FALSE	Profile parameter set 3
TRUE	TRUE	Profile parameter set 4

Setpoint	Profile parameter set 1	Profile parameter set 2	Profile parameter set 3	Profile parameter set 4
Frequency	C02771/1	C02771/2	C02771/3	C02771/4
Start angle	C02772/1	C02772/2	C02772/3	C02772/4
Current	C02773/1	C02773/2	C02773/3	C02773/4
Acceleration time	C02774/1	C02774/2	C02774/3	C02774/4
Deceleration time	C02775/1	C02775/2	C02775/3	C02775/4
Max. activation time	C02776/1	C02776/2	C02776/3	C02776/4



Note!

The four profile parameter sets must be dealt with sequentially, i.e. a selected profile parameter set must first be completed with $f_d = 0$ Hz before a further profile parameter set can be activated.

- The signal characteristic in Fig. [\[11-20\]](#) (□ 414) shows that the drive must ramp down completely in the case of each parameter set before the next parameter set can be started.
- Lenze recommends to control the basic function in accordance with this signal characteristic.

11 Basic drive functions

11.5 Manual job, encoderless

11.5.2.5 Encoderless manual jogging in a positive/negative direction

In the function state "Manual jog, encoderless active", the drive can be traversed manually in accordance with the following truth table by means of the indicated control inputs:


MOL_bJogNegative C02770/3	MOL_bJogPositive C02770/2	Job title
FALSE	FALSE	Stop • The drive is braked to standstill with the deceleration time in (C02775/x) set for the selected profile.
FALSE	TRUE	Controlled traversing in positive direction • The drive is led to the setpoint frequency with the acceleration time (C02774/x) set for the selected profile (C02771/x) .
TRUE	FALSE	Controlled traversing in negative direction • The drive is led to the setpoint frequency with the acceleration time (C02774/x) set for the selected profile (C02771/x) .
TRUE	TRUE	When both inputs are set to TRUE at the same time: • The drive is braked to standstill with the deceleration time in (C02775/x) set for the selected profile. If not both inputs are set to TRUE at the same time: • The drive continues to traverse in the direction that was selected first.
		x = number (1...4) of the selected profile parameter set

11 Basic drive functions

11.5 Manual job, encoderless

11.5.3 Internal interfaces | "LS_ManualJogOpenLoop" system block

In the function block editor, the system block **LS_ManualJogOpenLoop** makes the internal interfaces to the basic function "Manual jog, encoderless" available.



Note!

For the basic function "Manual jog, encoderless", the system block must be integrated into the application task. When the FB editor is activated, the basic dialog boxes of the corresponding technology application in »Engineer« change.

In the dialog box entitled "All basic functions", the "Manual jog, encoderless" button is not shown until the project has been updated.

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings
MOL_bEnable C02781/1 BOOL	Request control of basic function <ul style="list-style-type: none"> Request is also possible via C02770/1.
	TRUE If no other basic function is active, a changeover to the function state "Manual jog, encoderless active" takes place and controlled traversing of the drive can be carried out by means of the control inputs
	TRUE↘FALSE Actively controlled traversing is ended, i.e. a changeover from the active function state "Manual jog, encoderless active" back to the basic state "Controller not ready" takes place.
MOL_bJogPositive C02781/2 BOOL	▶ Encoderless manual jogging in a positive/negative direction (418) <ul style="list-style-type: none"> Control is also possible via C02770/2 and C02770/3.
MOL_bJogNegative C02781/3 BOOL	
MOL_bActivateDataBit1 C02781/4 BOOL	▶ Selection and contents of the profile parameter set (417) <ul style="list-style-type: none"> Selection is also possible via C02770/4 and C02770/5.
MOL_bActivateDataBit2 C02781/5 BOOL	

Outputs

Identifier DIS code data type	Value/meaning
Mol_dnState C02780 DINT	Status (bit coded) <ul style="list-style-type: none"> When the basic function is not enabled, all bits are set to "0". Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Manual jog, encoderless active.
	Bit 2 Profile executed.
	Bit 16 Request for "Quick stop" (QSP) active
MOL_bEnabled C02781/6 BOOL	Status signal "Basic function is enabled"
	TRUE Controlled traversing via the control inputs is possible. <ul style="list-style-type: none"> The enable input <i>MOL_bEnable</i> has been set to TRUE and the controller is in the function state "Manual job, encoderless active".
MOL_bActive C02781/7 BOOL	Status signal "Basic function is active"
	TRUE Controlled traversing is active (the drive axis moves according to the defined profile).
MOL_bDone C02781/8 BOOL	Status signal "Max. activation time reached" <ul style="list-style-type: none"> The status signal indicates that the respective parameterised max. activation time has been reached. The counter of the max. activation time is reset every time there is a TRUE-FALSE edge at <i>MOL_bJogPositive</i>/<i>MOL_bJogNegative</i>. The setpoint frequency and therefore the rotating field at the motor terminals is generated within the acceleration time parameterised in C02774/1...4 for the selected profile and the drive movement starts accordingly. At the instant of "Max. activation time reached", the drive is still moving and ramping down within the deceleration time parameterised in C02775/1...4 for the selected profile is initiated.
	TRUE Controlled manual jogging is active <ul style="list-style-type: none"> The max. activation time parameterised for the selected profile in C02776/1...4 has expired. <i>MOL_bJogPositive</i> or <i>MOL_bJogNegative</i> is TRUE The setpoint frequency still corresponds to the setpoint frequency parameterised in C02771/1...4 for the selected profile.

11.6 Homing

With the basic function "Homing" the measuring system of the machine is transmitted to the controller within the travel range that is physically possible.

- The reference (e.g. zero position of the drive axis in the machine measuring system) can be defined by reference search or reference setting.
- In case of reference search, the drive travels according to the defined homing mode to detect the reference in the measuring system independently.
 - In the reference point, the home position parameterised in [C02642](#) is set as the current position. Afterwards, an absolute positioning to the target position parameterised in [C02643](#) takes place (if [C02641](#) = "0").
- If the reference is set in the homing mode "100: Set reference directly" or via the control input *HM_bLoadHomePos*, the drive can also be referenced manually if the motor is at standstill. The measuring system is set by means of the home position parameterised in [C02642](#) or applied at the input *HM_dnHomePos_p*.



Danger!

During homing, specially assigned profile parameters are active. If they have not been set correctly, the drive can engage in uncontrolled movement!



Note!

Normally homing is only required once during commissioning of systems for which the machine cycle can be represented in the display area of the encoder, e. g. if multiturn absolute value encoders or singleturn absolute value encoders/resolvers are used during the machine cycle on one motor revolution.

- The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched. ▶ [Behaviour of the home position after mains switching](#) (□ 426)
- A renewed reference setting is only required in case of a renewed commissioning or in case of service (e.g. when drive components are exchanged).
- When multipole resolvers ([C00080](#) > 1) are used, a renewed homing is required after mains switching due to the ambiguity of the evaluated position.

**Note!**

For homing, setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 385)

For the encoderless motor control types (from software version V3.0) the following applies:

The basic function "Homing" can only be activated for V/f control or sensorless vector control if the position controller has been selected for the position control (C02570 = "2: position controller active").

- The homing modes 14 & 15 are not permissible for the V/f control. If the selection is impermissible, the error message "Homing mode not allowed" is output.


For the encoderless motor control types (from software version V5.0) the following applies:

If the V/f control or sensorless vector control is selected, the basic function "Homing" can be activated, irrespective of the use of the position controller.

- If no position controller has been selected for the position control in case of V/f control or sensorless vector control (C02570 = "1: Phase controller is active"), homing is only carried out via the speed profile resulting from the homing parameters. Because of this, the target positions set will only "roughly" be reached.

11.6.1 Internal interfaces | "LS_Homing" system block

The **LS_Homing** system block provides the internal interfaces for the basic function "Homing" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings
HM_bEnable C02659/1 BOOL	Request control of basic function
	TRUE If no other basic function is active, a change-over to the "Homing active" function state is effected and homing can be carried out via the control inputs.
	TRUE↔FALSE An active reference search is stopped, i. e. a change-over from the active "Homing active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
HM_bActivateHoming C02659/2 BOOL	Start homing/set home position directly
	TRUE Reference search is started in the homing mode selected (C02640). In the homing mode "100: Set reference directly" no reference search is started, but the home position set in C02642 is directly accepted.
	TRUE↔FALSE Active reference search is completed/cancelled.
HM_bHomingMark C02659/3 BOOL	Input for reference switch
	TRUE Reference switch is activated.
HM_bLoadHomePos C02659/4 BOOL	Load home position
	FALSE↔TRUE The position applied to input <i>HM_dnHomePos_p</i> is accepted as home position.
HM_dnHomePos_p C02658 DINT	Home position in [increments] for acceptance with <i>HM_bLoadHomePos</i>

Identifier DIS code data type	Information/possible settings
HM_bResetHomePos C02659/5 BOOL	Reset the "Reference known" status FALSE → TRUE The internal "Home position known" status is reset. • The status outputs <i>HM_bDone</i> and <i>HM_bHomePosAvailable</i> are reset to FALSE.
HM_dnSpeedOverride_n C02655 DINT From V5.0	Value for speed override • Percentage multiplier for the currently active speed (C02644 or C02646). • In the case of active homing, the speed override is always active and does not have to be activated separately. • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the speed parameterised in C02644 or C02646 . • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are set to 0% internally and lead to the standstill of the drive.

Outputs

Identifier DIS code data type	Value/meaning
HM_dnState C02657 DINT	Status (bit coded) • When the basic function is not enabled, all bits are set to "0". • Bits which are not listed are not assigned with a status (always "0"). Bit 1 Reference search is active. Bit 2 Reference search is completed. Bit 3 Acceleration/deceleration phase is active. Bit 5 CCW rotation is active. Bit 7 Reference known. Bit 15 Fault in basic function active (group signal). Bit 16 Pre-switch-off (reference switch) has been detected. Bit 17 Touch probe/zero pulse has been detected. Bit 19 Speed override $\leq 1\%$ • This status is only available from software version V5.0. Bit 21 Profile data are limited by basic function "Limiter". Bit 22 Traversing direction is inhibited by basic function "Limiter". Bit 23 Abort by basic function "Limiter". Bit 25 Stopping is active. • Basic function is enabled for the first time but no referencing has been requested / is active yet or speed $\neq 0$. Bit 30 Profile generation error.
HM_bEnabled C02659/6 BOOL	Status signal "Basic function is enabled" TRUE Homing via the control inputs is possible. • The <i>HM_bEnable</i> enable input is set to TRUE and the controller is in the "Homing active" function state.
HM_bActive C02659/7 BOOL	Status signal "Basic function is active" TRUE Reference search is active (the drive axis is moving).
HM_bDone C02659/8 BOOL	Status signal "Basic function is ready" TRUE Reference search is completed. • Output is reset to FALSE when input <i>HM_bActivateHoming</i> is reset to FALSE.
HM_bHomePosAvailable C02659/9 BOOL	Status signal "Home position is known" TRUE The drive knows the home position.

11.6.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Homing*
- Short overview of the parameters for homing:

Parameters	Info
C02528	Traversing range
C02640	Homing mode
C02641	Action after detect Home position
C02642	Home position
C02643	Homing: target position
C02644	Homing: Speed 1
C02645	Homing: Acceleration 1
C02646	Homing: veloc. 2
C02647	Homing: acceleration 2
C02648	Homing: S-ramp time
C02649	Homing: Torque limit
C02650	Homing: Blocking time
C02651	Homing: TP configuration
C02652	Home pos. following mains switching
C02653	Max. rot. ang. aft. mns. swtch.
C02656	Actual position (homing)

11.6.2.1 Behaviour of the home position after mains switching

If the home position/information is also to be available after mains switching, the setting [C02652](#) = "1: Received" is required.

Another condition for keeping the home position/information after mains switching is the compliance with the maximum permissible angle of rotation of the encoder.

- The maximally permissible angle of rotation can be set in [C02653](#) in angular degree [°] with regard to the encoder shaft ($360^\circ \equiv$ one encoder shaft rotation).



Note!

Due to the internal numerical format and the resolution of one encoder revolution according to [C00100](#), the position may not be reconstructed over the complete encoder range!

- The possible number of revolutions can be calculated as follows:
Number of revolutions = $2^{(31 - C00100)}$
- Example: For a standard multiturn absolute value encoder with an absolute display area of 4096 revolutions (± 2048), a maximum position resolution of 20 bits per revolution can be used!

When resolvers or single-turn absolute value encoders are used and the mains is switched off (24 V supply off), the encoder may only be moved by $\frac{1}{2}$ revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.

When multipole resolvers ([C00080](#) > 1) are used, a renewed homing is required after mains switching due to the ambiguity of the evaluated position.

11.6.2.2 Homing mode

The zero position, also called reference, can be defined by a reference search or reference setting:

- In case of a reference search the drive travels according to a defined mode to detect the reference independently.
- In case of reference setting the reference is manually set when the drive has stopped.



Tip!

A reference search is mainly used in the case of continuously running systems, or if the traversing range or machine cycle of the drive cannot be represented in the display area of the encoder, e. g. if incremental encoders are used at the motor, or singleturn absolute value encoders or resolvers are used at the gearbox.

A reference is mainly set in systems/machines that bear the risk of collisions, or every time no homing can be executed (e.g. in case of a cross cutter having material in the machine).

- For reference setting, select the homing mode "100" in [C02640](#).
- For a reference search the homing modes 0..."15" are provided in [C02640](#).
 - For process descriptions see the chapter "[Overview of the Lenze homing modes](#)". ([432](#))
 - [From software version V3.0](#) according to the DS402 device profile, additionally the homing modes 1001"..."1035" are provided in [C02640](#). Process descriptions for these homing modes can be found in the chapter "[Overview of DS402 homing modes](#)". ([432](#))



Note!

Profile data switch-over

For the reference search, two profile data sets with different velocities and accelerations can be parameterised. Like this, the homing time can be reduced, and at the same time accuracy can be increased.

▶ [Profile data switch-over](#) ([429](#))

The process descriptions in the following chapters provide information on the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

▶ [Overview of the Lenze homing modes](#) ([432](#))

▶ [Overview of DS402 homing modes](#) ([445](#))

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



Note!

Drive behaviour after setting the reference

[From software version V4.0 onwards](#), [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position](#) ([428](#))

In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.

**Note!****Conditions for new homing**

A new homing must not be started if

- the drive is between a software and hardware limit position at the starting time and
- is to move towards the hardware limit position.

For the described case, the old homing must be reset first.

11.6.2.3 Home position & target position

When the home position is set during the reference search, the position detected in the machine measuring system corresponds to the value set in [C02642](#).

For software versions lower than V4.0 the following applies:

- Afterwards the drive travels to the target position set in [C02643](#).

The following applies from software version V4.0:

- The subsequent drive behaviour is determined by the mode parameterised in [C02641](#). See the below chapter "[Drive behaviour after setting the home position](#)".

11.6.2.4 Drive behaviour after setting the home position

This function extension is available from software version V4.0!

[C02641](#) can be used to select the drive behaviour after setting the home position.

Selection "0: Move absolute on Target position"

After setting the home position ([C02642](#)), the drive moves to the absolute target position set in [C02643](#).

This selection is the Lenze setting and corresponds to the behaviour known from the previous versions.

Selection "1: Move relative by Target position"

After setting the home position ([C02642](#)), the drive moves relatively by the target position set in [C02643](#).

Selection "2: Stop immediately"

After setting the home position ([C02642](#)), the drive stops immediately.

11.6.2.5 Profile data switch-over

For the reference search two profile data sets can be parameterised to reduce the homing time and increase the accuracy:

Profile data set 1		Profile data set 2	
C02644	Speed 1	C02646	Speed 2
C02645	Acceleration 1 (and deceleration 1)	C02647	Acceleration 2 (and deceleration 2)
C02648	S-ramp time (identical in the two profile data sets) ▶ Setting the S-ramp time (📖 387)	C02648	S-ramp time (identical in the two profile data sets) ▶ Setting the S-ramp time (📖 387)

- With the profile data set 1 first the limit switch/reference switch (depending on the mode selected) is quickly approached.
- After reversing on the limit switch/reference switch, the slower – but more accurate – approach of the encoder zero pulse/touch probe sensor and the positioning to the target position ([C02643](#)) are effected with profile data set 2.




Note!

The change-over to profile data set 2 is only effected if speed 2 ([C02646](#)) is set > "0"!

In the Lenze setting ([C02646](#) = "0") no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.

The process descriptions of the homing modes provide information about when the change-over to profile data set 2 takes place in the respective homing mode. ▶ [Overview of the Lenze homing modes](#) (📖 432)



Example: Procedure of mode 2:

- A. Movement in positive direction with profile data set 1.
- B. Reversing to positive travel range limit switch.
- C. Positive edge at *HM_bHomingMark* activates profile data set 2 for the further reference search.
- D. Negative edge at *HM_bHomingMark* enables home position detection.
- E. The following positive edge of the encoder zero pulse (MP) sets the reference.
- F. Drive has reached defined target position.

11.6.2.6 Homing to end stop

By selecting the homing modes 14 & 15, homing to end stop can be executed as follows:

1. The drive travels with reduced torque in positive direction (mode 14) or negative direction (mode 15).
2. When the drive hits an end stop so that the torque limit set in [C02649](#) is exceeded for the blocking time defined in [C02650](#), the reference is set.
 - If a reference offset is set, traversing takes place around this offset in a correctly signed manner.

▶ [Mode 14: positive direction to torque limit](#) (📖 443)

▶ [Mode 15: negative direction to torque limit](#) (📖 443)

11.6.2.7 Reference switch connection

For the homing modes with reference switch, the *HM_bHomingMark* control input must be connected to the digital input which is connected to the reference switch.

11.6.2.8 Touch probe interface configuration

The touch probe channel to be used for homing with touch probe detection in »Engineer« is selected on the **Application parameters** tab in the dialog level *Overview* → *All basic functions* → *Homing* → *TP interface*.

- The setting carried out in this parameterisation dialog directly affects the setting of [C02651](#) ("Homing: TP configuration") and vice versa.
- For directly setting [C02651](#) (e. g. by means of the keypad) the corresponding decimal values are listed for all configuration options in the following table:

Selection Touch probe channel	Touch probe response		
	Positive edge	Negative edge	Both edges
Digital input 1	1	2	3
Digital input 2	4	8	12
Digital input 3	16	32	48
Digital input 4	64	128	192
Digital input 5	256	512	768
Digital input 6	1024	2048	3072
Digital input 7	4096	8192	12288
Digital input 8	16384	32768	49152
Motor encoder zero pulse	65536		
Position encoder zero pulse	262144		

- Example: For selecting the touch probe channel "Digital input 1" and a response only to a negative edge, the decimal value "2" has to be set in [C02651](#).

11.6.3 Overview of the Lenze homing modes

In the following subchapters the procedures of homing modes 0 ... 15 are described, which can be selected in [C02640](#).

Homing mode C02640	Evaluated signals/sensors			Reference switch at <i>HM_bHomingMark</i>
	Touch probe sensor/ encoder zero pulse	Travel range limit switch		
		Negative limit switch	Positive limit switch	
0	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
1	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
4	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
5	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
8	<input checked="" type="checkbox"/>			
9	<input checked="" type="checkbox"/>			
10	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
12			<input checked="" type="checkbox"/>	
13		<input checked="" type="checkbox"/>		
14	Positive direction of rotation to torque limit.			
15	Negative direction of rotation to torque limit.			
100	Set reference directly.			

The switches/sensors are evaluated via the following internal interfaces:

Switch/sensor	Internal interface for digital input signal
Touch probe sensor	<i>DIGIN_bIn1 ... DIGIN_bIn8</i> • Alternatively the motor encoder or position encoder zero pulse can be evaluated. ▶ Touch probe interface configuration (431)
Positive travel range limit switch	<i>LIM_bLimitSwitchPositive</i> (basic function " Limiter ")
Negative travel range limit switch	<i>LIM_bLimitSwitchNegative</i> (basic function " Limiter ")
Reference switch	<i>HM_bHomingMark</i> (basic function " Homing ")



Note!

Profile data switch-over

For the reference search, two profile data sets with different velocities and accelerations can be parameterised. Like this, the homing time can be reduced, and at the same time accuracy can be increased.

▶ [Profile data switch-over](#) (429)

The following process descriptions give information about the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



Note!


Drive behaviour after setting the reference

From software version V4.0 onwards, [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position](#) (☰ 428)

In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.


Mode 0: pos. direction - via home mark - to TP



Procedure:

1. Movement in positive direction with profile data set 1.
2. Positive edge at *HM_bHomingMark* activates profile data set 2 for the further reference search.
3. Negative edge at *HM_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1: neg. direction - via home mark - to TP



Procedure:

1. Movement in negative direction with profile data set 1.
2. Positive edge at *HM_bHomingMark* activates profile data set 2 for the further reference search.
3. Negative edge at *HM_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 2: pos. direction - reversing to limit switch - via home mark - to TP



Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge at *HM_bHomingMark* activates profile data set 2 for the further reference search.
4. Negative edge at *HM_bHomingMark* enables home position detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 3: neg. direction - reversing to limit switch - via home mark - to TP




Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch.
3. Positive edge at *HM_bHomingMark* activates profile data set 2 for the further reference search.
4. Negative edge at *HM_bHomingMark* enables home position detection.
5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

11 Basic drive functions

11.6 Homing

Mode 4: pos. direction - reversing to home mark - to TP



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge at *HM_bHomingMark* and simultaneous activation of the profile data set 2 for further reference search.
3. Negative edge at *HM_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Negative edge at *HM_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 5: neg. direction - reversing to home mark - to TP



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge at *HM_bHomingMark* and simultaneous activation of the profile data set 2 for further reference search.
3. Negative edge at *HM_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in positive direction with profile data set 2.
2. Negative edge at *HM_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 8: positive direction to touch probe



Procedure:

1. Movement in positive direction with profile data set 1.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 9: negative direction to touch probe



Procedure:

1. Movement in negative direction with profile data set 1.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 10: pos. direction - reversing to limit switch - to TP



Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing when the edge of the positive travel range limit switch is positive and, at the same time, activation of profile data set 2 for continued reference searching.
3. The touch probe signal is evaluated while reversing the limit switch.
4. The following positive edge of the touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").




Note!

The touch probe detection is already activated after reversing to the travel range limit switch, i.e. the home position may be set to the travel range limit switch.

- We therefore recommend to set a target position ([C02643](#)) unequal to the home position ([C02642](#)), in order to reenble the activated limit switch. Otherwise, the positioning process to the target position may be aborted by the basic function "[Limiter](#)" (see status signal *HM_dnState*).
- We recommend the use of the DS402 homing methods 1 and 2 if the touch probe detection (especially the one of the motor zero pulse) is to be activated after the travel range switch has been left. ▶ [Overview of DS402 homing modes](#) ([445](#))

Mode 11: neg. direction - reversing to limit switch - to TP



Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing when the edge of the negative travel range limit switch is positive and, at the same time, activation of profile data set 2 for continued reference searching.
3. The touch probe signal is evaluated while reversing the limit switch.
4. The following positive edge of the touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").




Note!

The touch probe detection is already activated after reversing to the travel range limit switch, i.e. the home position may be set to the travel range limit switch.

- We therefore recommend to set a target position ([C02643](#)) unequal to the home position ([C02642](#)), in order to reenble the activated limit switch. Otherwise, the positioning process to the target position may be aborted by the basic function "[Limiter](#)" (see status signal *HM_dnState*).
- We recommend the use of the DS402 homing methods 1 and 2 if the touch probe detection (especially the one of the motor zero pulse) is to be activated after the travel range switch has been left. ▶ [Overview of DS402 homing modes](#) (445)

Mode 12: positive direction to limit switch



Procedure:


1. Movement in positive direction with profile data set 1.
2. Positive edge of the travel range limit switch sets reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").



Note!

The load machine can also leave the travel range limit switch. There follows a return to the home position that was set with the positive edge of the travel range limit switch.

- It is possible that, as a result, the machine will remain on an operated limit switch.
- Therefore it is recommended to set a target position ([C02643](#)) that is unequal to the home position ([C02642](#)) to release the activated limit switch again.

Mode 13: negative direction to limit switch
**Procedure:**

1. Movement in negative direction with profile data set 1.
2. Positive edge of the travel range limit switch sets reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

**Note!**

The load machine can also leave the travel range limit switch. There follows a return to the home position that was set with the positive edge of the travel range limit switch.

- It is possible that, as a result, the machine will remain on an operated limit switch.
- Therefore it is recommended to set a target position ([C02643](#)) that is unequal to the home position ([C02642](#)) to release the activated limit switch again.

Mode 14: positive direction to torque limit



Procedure:

1. Movement in positive direction with reduced torque and profile data set 1.
2. The reference is set if the two following conditions for the time set in [C02650](#) are fulfilled at the same time:
 - The current speed is lower than the threshold for standstill detection set in [C00019](#).
 - Current torque is greater than the torque limit set in [C02649](#) ("Homing to end stop").
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 15: negative direction to torque limit




Procedure:

1. Movement in negative direction with reduced torque and profile data set 1.
2. The reference is set if the two following conditions for the time set in [C02650](#) are fulfilled at the same time:
 - The current speed is lower than the threshold for standstill detection set in [C00019](#).
 - Current torque is greater than the torque limit set in [C02649](#) ("Homing to end stop").
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

11 Basic drive functions

11.6 Homing

Mode 100: Set reference directly



During the drive is at standstill, the measuring system is set by means of the home position parameterised in [C02642](#).

11.6.4 Overview of DS402 homing modes

This function extension is available from software version V3.0!

In addition to the homing modes described in the previous subchapter "[Overview of the Lenze homing modes](#)", from software version V3.0 also the homing modes described in the following can be selected for a homing in [C02640](#), according to the DS402 device profile.

DS402 homing method	Evaluated signals/sensors			Reference switch at <i>HM_bHomingMark</i>
	Touch probe sensor/ encoder zero pulse	Travel range limit switch		
		Negative limit switch	Positive limit switch	
01	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
02	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
03	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
04	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
05	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
06	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>
07	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
08	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
09	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
10	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
11	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
12	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
13	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
14	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
15	Reserved: no homing is executed.			
16	Reserved: no homing is executed.			
17		<input checked="" type="checkbox"/>		
18			<input checked="" type="checkbox"/>	
19				<input checked="" type="checkbox"/>
20				<input checked="" type="checkbox"/>
21				<input checked="" type="checkbox"/>
22				<input checked="" type="checkbox"/>
23			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
24			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
25			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
26			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
27		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
28		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
29		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
30		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
31	Reserved: no homing is executed.			
32	Reserved: no homing is executed.			
33	<input checked="" type="checkbox"/>			
34	<input checked="" type="checkbox"/>			
35	Direct reference setting.			

The switches/sensors are evaluated via the following internal interfaces:

Switch/sensor	Internal interface for digital input signal
Touch probe sensor	<i>DIGIN_bIn1 ... DIGIN_bIn8</i> <ul style="list-style-type: none"> Alternatively the motor encoder or position encoder zero pulse can be evaluated. ▶ Touch probe interface configuration (□ 431)
Positive travel range limit switch	<i>LIM_bLimitSwitchPositive</i> (basic function " Limiter ")
Negative travel range limit switch	<i>LIM_bLimitSwitchNegative</i> (basic function " Limiter ")
Reference switch	<i>HM_bHomingMark</i> (basic function " Homing ")



Note!

Profile data switch-over

For the reference search, two profile data sets with different velocities and accelerations can be parameterised. Like this, the homing time can be reduced, and at the same time accuracy can be increased.

▶ [Profile data switch-over \(□ 429\)](#)

The following process descriptions give information about the time the change-over to the profile data set 2 takes place in the corresponding homing mode.

If the speed 2 ([C02646](#)) is set to "0" (Lenze setting), no change-over to the profile data set 2 takes place and the reference search and positioning to the target position is only executed with the profile parameters of the profile data set 1.



Note!


Drive behaviour after setting the reference

From software version V4.0 onwards, [C02641](#) serves to parameterise the drive behaviour after setting the home position.

▶ [Drive behaviour after setting the home position \(□ 428\)](#)

In the Lenze setting ([C02641](#) = "0"), the drive traverses to the absolute target position set in [C02643](#) similarly to the behaviour known from the previous versions.


Mode 1001: DS402 homing method 01



Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch and change-over to profile data set 2.
3. Negative edge of the travel range limit switch activates touch probe recognition.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1002: DS402 homing method 02



Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch and change-over to profile data set 2.
3. Negative edge of the travel range limit switch activates touch probe recognition.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1003: DS402 homing method 03



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in positive direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
3. Negative edge of the reference switch activates touch probe recognition.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe recognition.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1004: DS402 homing method 04



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in positive direction with profile data set 1.
2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1005: DS402 homing method 05



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
3. Negative edge of the reference switch activates touch probe recognition.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in positive direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe recognition.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1006: DS402 homing method 06



Procedures:

Case 1:

Axis has not activated reference switch yet:


1. Movement in negative direction with profile data set 1.
2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2:

Axis is already positioned on reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1007: DS402 homing method 07



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. Negative edge of the reference switch activates touch probe recognition.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 3. Negative edge of the reference switch activates touch probe recognition.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


11 Basic drive functions

11.6 Homing

Case 3: Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Negative edge of the reference switch activates touch probe recognition.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1008: DS402 homing method 08



Procedures:

Case 1: Axis does not activate the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch.
3. Positive edge of the reference switch activates profile data set 2.
4. Reversing with negative edge of the reference switch.
5. Positive edge of the reference switch activates touch probe detection.
6. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
7. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Case 2: Axis first activates the reference switch while moving towards the limit switch:

1. Movement in positive direction with profile data set 1.
2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 3: Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. Positive edge of the reference switch activates touch probe detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1009: DS402 homing method 09



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. Reversing with negative edge of the reference switch.
 4. Positive edge of the reference switch activates touch probe detection.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. Positive edge of the reference switch activates touch probe detection.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1010: DS402 homing method 10



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 4. Negative edge of the reference switch activates touch probe recognition.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Negative edge of the reference switch activates touch probe recognition.
 3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. Negative edge of the reference switch activates touch probe recognition.
 3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1011: DS402 homing method 11



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. Negative edge of the reference switch activates touch probe recognition.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 3. Negative edge of the reference switch activates touch probe recognition.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. Negative edge of the reference switch activates touch probe recognition.
 3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1012: DS402 homing method 12



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. Reversing with negative edge of the reference switch.
 5. Positive edge of the reference switch activates touch probe detection.
 6. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 7. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
 3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. Positive edge of the reference switch activates touch probe detection.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1013: DS402 homing method 13



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Positive edge of the reference switch activates touch probe detection and change to profile data set 2.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. Reversing with negative edge of the reference switch.
 4. Positive edge of the reference switch activates touch probe detection.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. Positive edge of the reference switch activates touch probe detection.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1014: DS402 homing method 14



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 4. Negative edge of the reference switch activates touch probe recognition.
 5. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. Negative edge of the reference switch activates touch probe recognition.
 4. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. Negative edge of the reference switch activates touch probe recognition.
 3. The following positive edge of the encoder zero pulse/touch probe sensor sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

11 Basic drive functions

11.6 Homing


Mode 1015: DS402 homing method 15

Reserved: no homing is executed.

Mode 1016: DS402 homing method 16

Reserved: no homing is executed.


Mode 1017: DS402 homing method 17



Procedure:

1. Movement in negative direction with profile data set 1.
2. Reversing to negative travel range limit switch and change-over to profile data set 2.
3. The following negative edge of the travel range limit switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1018: DS402 homing method 18




Procedure:

1. Movement in positive direction with profile data set 1.
2. Reversing to positive travel range limit switch and change-over to profile data set 2.
3. The following negative edge of the travel range limit switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

11 Basic drive functions

11.6 Homing


Mode 1019: DS402 homing method 19



Procedures:

- Case 1: Axis has not activated reference switch yet:
1. Movement in positive direction with profile data set 1.
 2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 3. The following negative edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. The following negative edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1020: DS402 homing method 20



Procedures:


Case 1: Axis has not activated reference switch yet:

1. Movement in positive direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis is already positioned on reference switch:

1. Movement in negative direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1021: DS402 homing method 21



Procedures:


Case 1: Axis has not activated reference switch yet:

1. Movement in negative direction with profile data set 1.
2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
3. The following negative edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis is already positioned on reference switch:

1. Movement in positive direction with profile data set 2.
2. The following negative edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1022: DS402 homing method 22



Procedures:


Case 1: Axis has not activated reference switch yet:

1. Movement in negative direction with profile data set 1.
2. The following positive edge of the reference switch sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Case 2: Axis is already positioned on reference switch:

1. Movement in positive direction with profile data set 2.
2. Reversing with negative edge of the reference switch.
3. The following positive edge of the reference switch sets the reference.
4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1023: DS402 homing method 23



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. The following negative edge of the reference switch sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 3. The following negative edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. The following negative edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1024: DS402 homing method 24



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. Reversing with negative edge of the reference switch.
 5. The following positive edge of the reference switch sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. The following positive edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1025: DS402 homing method 25



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. The following positive edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis already stands on the reference switch:
1. Movement in positive direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1026: DS402 homing method 26



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Reversing to positive travel range limit switch.
 3. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 4. The following negative edge of the reference switch sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in positive direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. The following negative edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. The following negative edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1027: DS402 homing method 27



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. The following negative edge of the reference switch sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 3. The following negative edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. The following negative edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1028: DS402 homing method 28



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Positive edge of the reference switch activates profile data set 2.
 4. Reversing with negative edge of the reference switch.
 5. The following positive edge of the reference switch sets the reference.
 6. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. The following positive edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in positive direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1029: DS402 homing method 29



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. Reversing with negative edge of the reference switch.
 4. The following positive edge of the reference switch sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. Reversing with negative edge of the reference switch.
 3. The following positive edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1030: DS402 homing method 30



Procedures:

- Case 1: Axis does not activate the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Reversing to negative travel range limit switch.
 3. Reversing with positive edge of the reference switch and change-over to profile data set 2.
 4. The following negative edge of the reference switch sets the reference.
 5. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 2: Axis first activates the reference switch while moving towards the limit switch:
1. Movement in negative direction with profile data set 1.
 2. Positive edge of the reference switch activates profile data set 2.
 3. The following negative edge of the reference switch sets the reference.
 4. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").
- Case 3: Axis is already positioned on reference switch:
1. Movement in negative direction with profile data set 2.
 2. The following negative edge of the reference switch sets the reference.
 3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

11 Basic drive functions

11.6 Homing


Mode 1031: DS402 homing method 31

Reserved: no homing is executed.

Mode 1032: DS402 homing method 32

Reserved: no homing is executed.


Mode 1033: DS402 homing method 33



Procedure:

1. Movement in negative direction with profile data set 1 and activation of the touch probe recognition.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").


Mode 1034: DS402 homing method 34



Procedure:

1. Movement in positive direction with profile data set 1 and activation of the touch probe recognition.
2. The following positive edge of the touch probe sensor sets the reference.
3. Absolute positioning to target position ([C02643](#)) with profile data set 2 (if [C02641](#) = "0").

Mode 1035: DS402 homing method 35



Direct reference setting.

11.6.5 Execute homing

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "Homing" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *HM_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Homing active" function state is effected and homing can be carried out via the control inputs.
- A successful change to the "Homing active" function state is displayed by a TRUE signal at the *HM_bEnabled* status output.

Deactivation

When the *HM_bEnable* enable input is reset to FALSE, an active homing is stopped, i.e. the control inputs for homing are inhibited and the drive is braked to standstill within the deceleration time for stop.

- The status output *HM_bEnabled* is reset to FALSE and a change-over from the active "Homing active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11.6.5.1 Starting reference search/setting the reference directly

By setting the *HM_bActivateHoming* control input to TRUE, the reference search in the selected homing mode is started.

- During reference search, the *HM_bActive* status output is set to TRUE.
- By setting the status output *HM_bHomePosAvailable* to TRUE, it is already signalled during the reference search that the home position has been found. Depending on the homing mode selected, the drive traverses further on to the target position set in [C02643](#).
- When the reference search is completed, the *HM_bActive* status output is reset to FALSE and the *HM_bDone* status output is set to TRUE.



Note!

In the homing mode "100: Set reference directly" no reference search is started, but the home position set in [C02642](#) is directly accepted.

11.6.5.2 Loading home position via input

By setting the control input *HM_bLoadHomePos* to TRUE, the "Tool position" that is pending at input *HM_dnHomePos_p* is manually accepted as home position during the drive is at standstill. This is also possible if the controller is inhibited.

- The *HM_bDone* status output is set to TRUE for one cycle.
- The *HM_bHomePosAvailable* status output is set to TRUE.



Note!

For the encoderless motor control types (from software version V3.0) the following applies:

If V/f control or sensorless vector control has been selected, this function is only effective if the position controller has also been selected for the position control ([C02570](#) = "2: position controller active").

For the encoderless motor control types (from software version V5.0) the following applies:

If the V/f control or sensorless vector control is selected, this function can be activated irrespective of the use of the position controller.

11.6.5.3 Reset home position

By setting the control input *HM_bResetHomePos* to TRUE, the "Home position known" status can be reset.

- The status outputs *HM_bDone* and *HM_bHomePosAvailable* are reset to FALSE.



Note!

For the encoderless motor control types (from software version V3.0) the following applies:

If V/f control or sensorless vector control has been selected, this function is only effective if the position controller has also been selected for the position control (*C02570* = "2: position controller active").

For the encoderless motor control types (from software version V5.0) the following applies:

If the V/f control or sensorless vector control is selected, this function can be activated irrespective of the use of the position controller.

11.7 Positioning

The basic function "Positioning" provides the functions for executing the (travel) profiles and supports an "override" of speed and acceleration.

- A profile describes a motion request which can be implemented by this basic function into a rotary motion.
- A profile is described via the following profile parameters: Mode (type of positioning), position, speed, acceleration, deceleration, S-ramp time, final speed, standard sequence profile, TP sequence profile, TP window starting and end position and touch probe signal source(s).



Note!

For positioning, setpoint speeds greater than 30000 rpm are not possible. The speeds defined for these basic function are internally limited to 30000 rpm.

If the basic function is activated for a speed greater than 30000 rpm (e. g. if the basic function "Speed follower" is replaced), the internal limitation of the speed setpoint causes a speed step.


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 385)

For the encoderless motor control types (from software version V3.0) the following applies:

If no position controller has been selected for the position control in case of V/f control or sensorless vector control ([C02570](#) = "1: Phase controller is active"), positioning is only executed via the speed profile resulting from the profile parameters. Because of this, the target positions set will only "roughly" be reached.

11.7.1 Internal interfaces | "LS_Positioner" system block

The **LS_Positioner** system block provides the internal interfaces for the basic function "Positioning" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings
POS_bEnable <small>C02679/1 BOOL</small>	Request control of basic function
	TRUE If no other basic function is active, a change-over to the "Positioning active" function state is effected and positioning can be carried out via the control inputs. TRUE↔FALSE Active positioning is stopped, i. e. a change-over from the active "Positioning active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
POS_bStart <small>C02679/2 BOOL</small>	Start positioning
	FALSE↗TRUE The profile <i>POS_ProfileData</i> is executed. FALSE↗TRUE (once again) "Restart" <ul style="list-style-type: none"> • During an active positioning process, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart. • Distances of a relative positioning that have already been covered are <u>not</u> taken into consideration.

Identifier DIS code data type	Information/possible settings
POS_bAbort C02679/3 BOOL	Abort or interrupt positioning
	FALSE↗TRUE The current profile is not completed but braked to standstill with the deceleration defined in the profile data.
	TRUE A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is inhibited.
POS_bRestart C02679/4 BOOL	Continue interrupted positioning • Only possible if <i>POS_bAbort</i> has been reset from TRUE to FALSE.
	TRUE The positioning interrupted before via <i>POS_bAbort</i> is completed. • Distances of a relative positioning already covered are taken into account.
POS_ProfileData	Pointer to the profile to be executed in internal units (increments) • A profile linkage results from the fact that a pointer to the sequence profile is contained within the profile.
POS_bEnableOverride C02679/5 BOOL	Activate override
	TRUE Override of the speed, acceleration, and deceleration is active. • If the <i>POS_dnDecOverride_n</i> input is triggered with a very low value after the override function is activated, the drive decelerates correspondingly slow. The target position may be overtravelled.
POS_dnSpeedOverride_n C02677/1 DINT	Value for speed override • Percentage multiplier for the current profile parameter "Speed". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the speed defined in the profile. • For values $\leq 1\%$ the status bit 18 is set. • Values $\leq 0\%$ are set to 0% internally and lead to the standstill of the drive.
POS_dnAccOverride_n C02677/2 DINT	Value for acceleration override • Percentage multiplier for the current profile parameter "Acceleration". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the acceleration defined in the profile. • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are internally set to 0% ("no acceleration").
POS_dnDecOverride_n C02677/3 DINT From V5.0	Value for deceleration override • Percentage multiplier for the current profile parameter "Deceleration". • Changes are accepted in each cycle. • $2^{30} \equiv 100\%$ of the acceleration defined in the profile. • For values $\leq 1\%$ the status bit 19 is set. • Values $\leq 0\%$ are internally set to 0% ("no deceleration").
POS_bDisableTP C02679/6 BOOL	Deactivating touch probe positioning
	TRUE Detected touch probes are ignored. There is no automatic change-over to the TP sequence profile defined in the profile data.

Outputs

Identifier DIS code data type	Value/meaning			
POS_dnState C02675 DINT	Status (bit coded) <ul style="list-style-type: none"> When the basic function is not enabled, all bits are set to "0". Bits which are not listed are not assigned with a status (always "0"). 			
	Bit 1 Positioning active.			
	Bit 2 Positioning is completed (all profiles have been executed).			
	Bit 3 Acceleration/deceleration phase is active.			
	Bit 4 Actual position in the target <ul style="list-style-type: none"> The actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in C02670. 			
	Bit 5 CCW rotation is active.			
	Bit 6 Set position reached (in case of sequence profiles the drive continues to travel).			
	Bit 10 Zero crossing in the positioning mode "modulo".			
	Bit 11 Positioning cannot be continued.			
	Bit 12 Drive in the target (actual position <u>and</u> set position in the target). <ul style="list-style-type: none"> This status is available from software version V5.0. 			
	Bit 15 Fault in basic function active (group signal).			
	Bit 16 Positioning is aborted.			
	Bit 17 Reversing phase is active.			
	Bit 18 Speed override ≤1 %			
	Bit 19 Acceleration or deceleration override ≤ 1 %			
	Bit 20 Position is limited by basic function " Limiter ".			
	Bit 21 Profile data are limited by basic function " Limiter ".			
	Bit 22 Direction is inhibited by basic function " Limiter ".			
	Bit 23 Abort by basic function " Limiter ".			
	Bit 24 Home position is not known.			
	Bit 25 Stopping is active. <ul style="list-style-type: none"> Basic function is enabled for the first time but no positioning has been requested / is active yet. 			
	Bit 26 Cycle is not known.			
	Bit 27 Invalid positioning mode.			
	Bit 28 Invalid change of the positioning mode.			
	Bit 29 Profile data are not plausible or incorrect.			
	Bit 30 Profile generation error.			
	POS_bEnabled C02679/7 BOOL	Status signal "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>Positioning via the control inputs is possible. <ul style="list-style-type: none"> The <i>POS_bEnable</i> enable input is set to TRUE and the controller is in the "Positioning active" function state. </td> </tr> </table>	TRUE	Positioning via the control inputs is possible. <ul style="list-style-type: none"> The <i>POS_bEnable</i> enable input is set to TRUE and the controller is in the "Positioning active" function state.
	TRUE	Positioning via the control inputs is possible. <ul style="list-style-type: none"> The <i>POS_bEnable</i> enable input is set to TRUE and the controller is in the "Positioning active" function state. 		
	POS_bActive C02679/8 BOOL	Status signal "Basic function is active" <table border="1"> <tr> <td>TRUE</td> <td>Positioning is active (the drive axis is moving).</td> </tr> </table>	TRUE	Positioning is active (the drive axis is moving).
	TRUE	Positioning is active (the drive axis is moving).		
	POS_bDone C02679/9 BOOL	Status signal "Basic function is ready" <table border="1"> <tr> <td>TRUE</td> <td>Positioning is completed. <ul style="list-style-type: none"> The profile is executed and no sequence profile is defined. </td> </tr> </table>	TRUE	Positioning is completed. <ul style="list-style-type: none"> The profile is executed and no sequence profile is defined.
TRUE	Positioning is completed. <ul style="list-style-type: none"> The profile is executed and no sequence profile is defined. 			

Identifier DIS code data type	Value/meaning			
POS_bInTarget C02679/10 BOOL	Status signal "Setpoint has reached target position"			
	<table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> <tr> <td>TRUE</td> <td>The current position setpoint has reached the target position.</td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	TRUE
FALSE	Positioning is still active or has been aborted.			
TRUE	The current position setpoint has reached the target position.			
POS_bActPosInTarget C02679/11 BOOL	Status signal "Actual position in the target" <ul style="list-style-type: none"> In the case of sequence profiles, the target position of the last profile to be processed. ▶ Actual value-based evaluation "Target position reached" (□ 485) 			
	<table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> <tr> <td>TRUE</td> <td>The current actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in C02670.</td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	TRUE
FALSE	Positioning is still active or has been aborted.			
TRUE	The current actual position value of the drive has reached the target of the last profile to be traversed within the tolerance window set in C02670 .			
POS_bDriveInTarget C02679/12 BOOL From V5.0	Status signal "Drive in target" <ul style="list-style-type: none"> In the case of sequence profiles, the target position of the last profile to be processed. The status is also output when the basic function "Positioning" is deactivated. ▶ Actual value- and setpoint-based evaluation "Drive in the target" (□ 486) 			
	<table border="1"> <tr> <td>FALSE</td> <td>Positioning is still active or has been aborted.</td> </tr> </table>	FALSE	Positioning is still active or has been aborted.	
	FALSE	Positioning is still active or has been aborted.		
	<table border="1"> <tr> <td>FALSE↗TRUE</td> <td>The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in C02671. At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> In positioning processes with sequence profiles, the output will only be set to TRUE when the last profile has been processed. </td> </tr> </table>	FALSE↗TRUE	The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in C02671 . At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> In positioning processes with sequence profiles, the output will only be set to TRUE when the last profile has been processed. 	
	FALSE↗TRUE	The current actual position value of the drive has reached the target position within the profile to be traversed last within the tolerance window set in C02671 . At this time, the current position setpoint has already reached the target position. <ul style="list-style-type: none"> In positioning processes with sequence profiles, the output will only be set to TRUE when the last profile has been processed. 		
<table border="1"> <tr> <td>TRUE↘FALSE</td> <td>The current actual position value of the drive has exited the tolerance and hysteresis window set in C02671 and C02672 again after a positioning process has been completed.</td> </tr> </table>	TRUE↘FALSE	The current actual position value of the drive has exited the tolerance and hysteresis window set in C02671 and C02672 again after a positioning process has been completed.		
TRUE↘FALSE	The current actual position value of the drive has exited the tolerance and hysteresis window set in C02671 and C02672 again after a positioning process has been completed.			
<table border="1"> <tr> <td>FALSE↗TRUE (once again)</td> <td>If C02673 = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again. </td> </tr> <tr> <td></td> <td>If C02673 = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again. </td> </tr> </table>	FALSE↗TRUE (once again)	If C02673 = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again. 		If C02673 = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again.
FALSE↗TRUE (once again)	If C02673 = "1", a modulo evaluation is carried out in all cycles (Lenze setting): <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in an optional modulo cycle</u> again. 			
	If C02673 = "0", a modulo evaluation is only carried out in the modulo cycle of the target setpoint: <ul style="list-style-type: none"> The output is set to TRUE again if the current actual position value of the drive enters the tolerance and hysteresis window <u>in the same modulo cycle</u> again. 			
POS_dnSetPos_p C02678/1 DINT	Current position setpoint in [increments] <ul style="list-style-type: none"> Reference point is the home position. 			
POS_dnProfileTarget_p C02678/2 DINT	Target position of the current profile in [increments] <ul style="list-style-type: none"> Reference point is the home position. 			
POS_dnProfileSpeed_s C02676 DINT	Current setpoint speed of the current profile as speed in [rpm] <ul style="list-style-type: none"> Taking a speed override into consideration. 			
POS_dwActualProfileNumber C02674 DWORD	Profile number (1 100) of the current profile			

Identifier DIS code data type	Value/meaning
POS_dnSetPosRelative_p From V5.0 C02678/3 DINT	Current relative position setpoint of the current positioning in [increments] <ul style="list-style-type: none"> • The value is also output if the basic function "Positioning" is deactivated. • Reference point is the starting position of the current profile. • After a positioning process has been completed, the output keeps the last relative value of the setpoint profile. • The output is reset when a new positioning is started, or when the home position is set.
POS_dnActPosRelative_p From V5.0 C02678/4 DINT	Current relative actual position value of the current positioning in [increments] <ul style="list-style-type: none"> • The value is also output if the basic function "Positioning" is deactivated. • Reference point is the starting position of the current profile. • The output follows the current position even if the basic function "Positioning" is no longer active. • The output is reset when a new positioning is started, or when the home position is set.

11.7.1.1 Possibilities for the selection of the profile

For specifying as well as storing and managing (travel) profiles, the following function blocks are available:

Function block	Job title
L_PosPositionerTable	...serves to store and manage up to 100 (travel) profiles and to "Teach" positions, speeds, accelerations/decelerations and S-ramp times. <ul style="list-style-type: none"> • A further important task of this FB is the conversion of the table values according to the preselected scaling in the LS_DriveInterface SB.
L_PosProfileTable	...serves to store and manage up to four (travel) profiles and allows the "teaching" of target positions. <ul style="list-style-type: none"> • In contrast to the FB L_PosPositionerTable this FB does not use any variable tables but the data of the profile parameters are entered directly into the assigned codes. • The position at the input <i>dnExtPos_p</i> is used as target position as a further specific feature for the selection of profile no. 1.
L_PosProfileInterface	...provides a profile data set for the LS_Positioner SB.

Related topics:

- ▶ [Setting the S-ramp time](#) (📖 387)

11.7.2 Parameter setting

Setting parameters is not required for the basic function "Positioning".

- After activating the function, the profile is executed which has been transferred from the application to the basic function via the input *POS_ProfileData*.
- For profiles with touch probe positioning mode (residual path positioning) touch probe is detected implicitly.

Related topics:

- ▶ [Setting the S-ramp time](#) (📖 387)

11.7.2.1 Actual value-based evaluation "Target position reached"

An actual value-based evaluation on whether the drive has reached the target position can be carried out by means of the output *POS_bActPosInTarget* and parameterisation of [C02670](#).

- The output *POS_bActPosInTarget* is set to TRUE if the current actual position value of the drive has reached the target position of the profile to be traversed last within the tolerance window set in [C02670](#).
 - Hence, for sequence profiles the evaluation is only valid for the target position of the last profile.
- If [C02670](#) is set to "0" (Lenze setting), the evaluation is setpoint-based and the signal at the *POS_bActPosInTarget* output corresponds to the *POS_bDone* signal.



Tip!

In many cases the signal *POS_bActPosInTarget* only has to be evaluated if the setpoint has also reached the target position. This can for instance be implemented in the function block editor by a logic "AND" operation with the signal *POS_bDone*.

From software version V5.0 it is displayed whether the set position and the actual position are in the target via the output *POS_bDriveInTarget*. ▶ [Actual value- and setpoint-based evaluation "Drive in the target"](#) (📖 486)

11.7.2.2 Actual value- and setpoint-based evaluation "Drive in the target"

This function extension is available from software version V5.0 onwards!

An actual value- and setpoint-based evaluation on whether the drive is in the target can be carried out by means of the output *POS_bDriveInTarget* and parameterisation of [C02671](#), [C02672](#), and [C02673](#).

- The output *POS_bDriveInTarget* is set to TRUE if the current actual position value of the drive has reached the target position of the profile to be traversed last within the tolerance window set in [C02671](#).
 - At this time, the current setpoint value has already reached the target position, i. e. the actual position and set position are in the target.
 - In positioning processes with sequence profiles, the output will only be set to TRUE when the last profile has been processed.
- The output *POS_bDriveInTarget* is reset to FALSE if the current actual position value of the drive has exited the tolerance and hysteresis window set in [C02671](#) and [C02672](#) again after a positioning process has been completed.
- How the modulo evaluation is to be carried out if the actual position value enters the tolerance and hysteresis window again can be set in [C02673](#):
 - Modulo evaluation in all cycles (Lenze setting):
The output *POS_bDriveInTarget* is set to TRUE again if the current actual position value of the drive enters the tolerance window again in an optional modulo cycle.
 - Modulo evaluation only in the modulo cycle of the target setpoint:
The output *POS_bDriveInTarget* is set to TRUE again if the current actual position value of the drive enters the tolerance window again in the same modulo cycle.
- A new FALSE \rightarrow TRUE edge at the output *POS_bDriveInTarget* after a positioning process has been completed can for instance occur when the basic function is deactivated afterwards, and if the drive axis is skewed so that the tolerance and hysteresis window is exited and then the tolerance range is entered again.

Short overview of the parameters for the actual value- and setpoint-based evaluation:

Parameters	Info	Lenze setting	
		Value	Unit
C02671	Tolerance for target position	2.0000	Unit
C02672	Hysteresis for target position	1.0000	Unit
C02673	Activate DriveInTarget Modulo	All cycles	

11.7.3 Carrying out positioning

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "Positioning" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *POS_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Positioning active" function state is effected and positioning can be carried out via the control inputs.
- A successful change to the function state "Positioning active" is displayed by a TRUE signal at the *POS_bEnabled* status output.

Deactivation

When the *POS_bEnable* enable input is reset to FALSE, an active positioning is stopped, i.e. the control inputs for positioning are inhibited and the drive is braked to standstill within the deceleration time for stop.

- The status output *POS_bEnabled* is reset to FALSE and a change-over from the active "Positioning active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11.7.3.1 Start positioning

By setting the control input *POS_bStart* to TRUE, the positioning process is started.

- The (travel) profile that has been transferred to the basic function via the input *POS_ProfileData* is traversed.

11.7.3.2 Aborting/interrupting positioning

By setting the control input *POS_bAbort* to TRUE, the active positioning can be aborted or interrupted.

- The current profile is not completed but braked to standstill with the deceleration defined in the profile data.
- If the control input *POS_bAbort* remains on TRUE, a restart or the continuation of an interrupted positioning is inhibited.
- After resetting the control input *POS_bAbort* to FALSE, a restart or the continuation of an interrupted positioning process is possible again.

11.7.3.3 Continue interrupted positioning

By setting the control input *POS_bRestart* to TRUE, an interrupted positioning process can be continued if the control input *POS_bAbort* has been reset to FALSE before.

- Distances of a relative positioning already covered are taken into account.
- If the continuation of a positioning process via the input *POS_bRestart* is not possible, this is displayed via bit 11 of the status output *POS_dnState*.

The following applies to software versions lower than V3.0:

- If during an active or cancelled positioning process a change-over to the states "Quick stop active", "Drive is stopped", or "Drive at standstill" is effected, it is also possible to continue a positioning process via *POS_bRestart*, taking the distance that has already been covered into consideration.

The following applies from software version V3.0:

- If during an active or cancelled positioning process a change-over is effected (e. g. by activating a quick stop or inhibiting the controller), it is also possible to continue a positioning process via *POS_bRestart*, taking the distance that has already been covered into consideration.
- However, after a homing has been carried out again, or after the following machine parameters have been changed, a continuation of an interrupted positioning process via the control input *POS_bRestart* is no longer possible:
 - Encoder resolution ([C00100](#))
 - Position encoder selection ([C00490](#)), motor encoder selection ([C00495](#))
 - Gearbox factors ([C02520](#), [C02521](#), [C02522](#), [C02523](#))
 - Feed constant ([C02524](#))
 - Motor mounting direction ([C02527](#)), position encoder mounting direction ([C02529](#))
 - Traversing range ([C02528](#))
 - Cycle ([C02536](#)) for modulo traversing range
 - Position control structure ([C02570](#))

11.7.3.4 Activate override

An "Override" is the change of profile parameters and their acceptance during the positioning process.

- When the input *POS_bEnableOverride* is set to TRUE, a speed and acceleration override occurs according to the override values applied to the inputs *POS_dnSpeedOverride_n* and *POS_dnAccOverride_n*.
 - The override values represent percentage multipliers with regard to the current profile parameters for speed and acceleration.
 - For override values $\leq 1\%$ a status bit is set.
 - Override values $\leq 0\%$ are internally set to 0% .
 - Changes of the override values are accepted in each cycle.



Note!

The online change of speed and acceleration is in effect from the start of the profile until the deceleration phase begins. Changing the deceleration phase by means of an override is therefore not possible!

- In the case of an override value of 0% for the speed, the drive is brought to a standstill.
- In the case of an override value of 0% for the acceleration, acceleration does not take place any longer.

- From software version V5.0 also a deceleration override via the input *POS_dnDecOverride_n* can be carried out if the input *POS_bEnableOverride* is set to TRUE.

The deceleration override is effective:

- During the deceleration phase of a profile
- During an abort process
- In the case of a speed change-over from a high to a low speed within a profile (e. g. if the speed override is used)



Note!

If the override value for deceleration is 0% , there is no deceleration, i. e. the drive does not come to a standstill!

- If the input *POS_bEnableOverride* is reset to FALSE again, the speeds, accelerations, and decelerations are run again, which have been defined via the profile parameters. There is an immediate acceleration from the override speed to the speed set in the profile.

11.8 Position follower

This basic function is used as setpoint interface for position-controlled drives.

- The specified position setpoint can either refer to the encoder on the motor side or to the (position) encoder used additionally to detect the machine position. The selection of the encoder configuration serves to adapt the internal control structure accordingly.
- Instead of a position setpoint alternatively also a speed setpoint can be specified by an according selection in [C02680](#); the set position is then calculated by the integration of the speed setpoint on the basis of the current actual position (relative positioning).
- If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.
- The speed feedforward control can also be executed with the position setpoint by a corresponding selection in [C02681](#). Then, the speed is calculated by differentiation of the position setpoint.



Stop!

If a limit switch is approached by means of the basic function "Position follower" and by this a fault with the "Quick stop by trouble" response is activated, always a set/actual adjustment of the position has to be carried out before the fault is acknowledged, as otherwise an uncontrolled motor movement may result after the fault is acknowledged!

▶ [Hardware limit positions \(limit switch\)](#) (📖 515)



Note!


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (📖 385)

For the encoderless motor control types (from software version V3.0) the following applies:

The basic function "Position follower" can only be activated for V/f control or sensorless vector control if the position controller has been selected for the position control ([C02570](#) = "2: position controller active").

11.8.1 Internal interfaces | "LS_PositionFollower" system block

The **LS_PositionFollower** system block provides the internal interfaces for the basic function "Position follower" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!


Inputs

Identifier <small>DIS code data type</small>	Information/possible settings				
PF_bEnable C02689/1 BOOL	Request control of basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td>TRUE⇒FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.	TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Position follower active" function state is carried out, and the setpoints defined are accepted.				
TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Position follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				
PF_dnPositionSet_p C02688/1 DINT	Position setpoint in [increments]				
PF_dnSpeedAdd1_s C02686 DINT	Speed feedforward control value in [rpm]				
PF_dnSpeedAdd2_n C02687/1 DINT	Additional speed setpoint in [%] • 100 % ≙ Motor reference speed (C00011)				
PF_dnAccAdd_x C02685 DINT	Motor acceleration • For calculating the acceleration torque (for setting C00276 = "0"). • Selection as speed variation/time in [rpm/s]				
PF_dnTorqueAdd_n C02687/2 DINT	Additive torque feedforward control value in [%] • 100 % ≙ motor reference torque (display in C00057/2).				

Outputs

Identifier <small>DIS code data type</small>	Value/meaning		
PF_bEnabled C02689/2 BOOL	Status signal "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		

11.8.2 Signal flow



[11-22] Signal flow - position follower

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. ([📄 585](#))

No.	Variable of the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque feedforward control value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Position.dnActualLoadPos	Actual position
(4)	Position.dnPositionSetpoint	Position setpoint
(5)	Position.dnActualMotorPos	Current motor position
(6)	Position.dnContouringError	Following error
(7)	Speed.dnOutputPosCtrl	Output signal - phase controller
(8)	Speed.dnSpeedSetpoint	Speed setpoint
(9)	Speed.dnActualMotorSpeed	Current motor speed

11.8.3 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Position follower*
- Short overview of the parameters for the position follower:

Parameters	Info
C00050/1	Speed setpoint 1 [rpm]
C00070	Speed controller gain
C00071	Speed controller reset time
C00072	Speed controller rate time
C00273/1	Motor moment of inertia
C00273/2	Load moment of inertia
C00275	Signal source - speed setpoint
C00276	Signal source - torque setpoint
C00909/1	Upper speed limit value
C00909/2	Lower speed limit value
C02520	Gearbox factor numerator: Motor
C02521	Gearbox factor denom.: Motor
C02522	Gearbox factor num.: Pos. enc.
C02523	Gearbox fac. denom.: Pos. enc.
C02527	Motor mounting direction
C02550/1	Position setpoint interpolat.
C02550/2	Speed setpoint interpolation
C02550/3	Torque setpoint interpolation
C02553	Position controller gain
C02554	Position controller reset time
C02555	D component position controller
C02559	Internal torque limit
C02680	Source position setpoint
C02681	Source add. speed
Greyed out = display parameter	

11.8.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the setpoints which may be transferred from a slower task.

- [C02550/1](#) = "1": The motor control follows the position setpoint in interpolated steps.
- [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

11.8.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- [C02527](#) = "0": Clockwise rotating motor \equiv positive machine direction.
- [C02527](#) = "1": Counter-clockwise rotating motor \equiv positive machine direction.

11.8.4 Activating setpoint interface

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "Position follower" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *PF_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Position follower active" function state is carried out. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- A successful change to the "Position follower active" function state is displayed by a TRUE signal at the status output *PF_bEnabled*.



Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

Deactivation

When the *PF_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- The status output *PF_bEnabled* is reset to FALSE and a change-over from the active "Position follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11.9 Speed follower

This basic function is used as setpoint interface for speed-controlled drives.

- The motor control is switched over automatically to speed control with torque limitation.
- If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.




Note!

When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (385)

11.9.1 Internal interfaces | "LS_SpeedFollower" system block

The **LS_SpeedFollower** system block provides the internal interfaces for the basic function "Speed follower" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs


Identifier <small>DIS code data type</small>	Information/possible settings				
SF_bEnable C02695/1 BOOL	Request control of basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.	TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.
TRUE	If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the setpoints defined are accepted.				
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Speed follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.				
SF_dnSpeedSet_n C02694/1 DINT	Speed setpoint in [%] <ul style="list-style-type: none"> • 100 % ≙ Motor reference speed (C00011) 				
SF_dnSpeedAdd_s C02693 DINT	Additive speed setpoint in [rpm] <ul style="list-style-type: none"> • Without position control function. 				

Identifier DIS code data type	Information/possible settings
SF_dnAccAdd_x C02692 DINT	Motor acceleration <ul style="list-style-type: none"> • For calculating the acceleration torque (for setting C00276 = "0"). • Selection as speed variation/time in [rpm/s]
SF_dnTorqueAdd_n C02694/2 DINT	Additive torque feedforward control value in [%] <ul style="list-style-type: none"> • 100 % ≙ motor reference torque (display in C00057/2).

Outputs

Identifier DIS code data type	Value/meaning
SF_bEnabled C02695/2 BOOL	Status signal "Basic function is enabled"
	TRUE The defined setpoints are accepted.

11.9.2 Signal flow



[11-23] Signal flow - speed follower

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 585)

No.	Variable of the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque feedforward control value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Speed.dnTotalSpeedAdd	Additive speed setpoint
(4)	Speed.dnSpeedSetpoint	Speed setpoint
(5)	Speed.dnActualMotorSpeed	Current motor speed

11.9.3 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Speed follower*
- Short overview of the parameters for the speed follower:

Parameters	Info
C00050/1	Speed setpoint 1
C00070	Speed controller gain
C00071	Speed controller reset time
C00072	Speed controller rate time
C00273/1	Motor moment of inertia
C00273/2	Load moment of inertia
C00276	Signal source - torque setpoint
C00576	Speed monitoring window
C00579	Resp. to speed monitoring
C00909/1	Upper speed limit value
C00909/2	Lower speed limit value
C02520	Gearbox factor numerator: Motor
C02521	Gearbox factor denom.: Motor
C02522	Gearbox factor num.: Pos. enc.
C02523	Gearbox fac. denom.: Pos. enc.
C02527	Motor mounting direction
C02531/3	Effective gearbox factor (dec.)
C02550/2	Speed setpoint interpolation
C02550/3	Torque setpoint interpolation
C02570	Position control structure
C02559	Internal torque limit

Greyed out = display parameter

11.9.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

11.9.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- [C02527](#) = "0": Clockwise rotating motor ≡ positive machine direction.
- [C02527](#) = "1": Counter-clockwise rotating motor ≡ positive machine direction.

11.9.4 Activating setpoint interface

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "Speed follower" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *SF_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Speed follower active" function state is carried out, and the motor control is automatically switched over to speed control with torque limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- A successful change to the function state "Speed follower active" is displayed by a TRUE signal at the *SF_bEnabled* status output.



Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

Deactivation

When the *SF_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- The status output *SF_bEnabled* is reset to FALSE and a change-over from the active "Speed follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11.10 Torque follower

This basic function is used as setpoint interface for torque-controlled drives.

- The motor control is switched over automatically to torque control with speed limitation.
- If the direction of rotation of the motor has to be inverted due to the mounting position of the motor or the gearbox ratio available, the use of the control signals can be accordingly changed over by means of parameterisation.
- A stable speed limitation requires a minimum difference of the speed limit values of 50 rpm. If the defined speed limit values fall below this minimum difference, the internal lower speed limit value is lowered accordingly. The upper speed limit value remains unchanged. ▶ [Signal flow - torque follower](#) (□ 503)



Note!


When the basic function is activated, a start acceleration is considered. ▶ [Start acceleration/acceleration reduction when the basic function changes](#) (□ 385)

For the encoderless motor control types (from software version V3.0) the following applies:

The basic function "Torque follower" cannot be activated when the V/f control has been selected.

11.10.1 Internal interfaces | "LS_TorqueFollower" system block

The **LS_TorqueFollower** system block provides the internal interfaces for the basic function "Torque follower" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings			
TF_bEnable C02699/1 BOOL	Request control of basic function			
	<table border="0"> <tr> <td style="text-align: center;">TRUE</td> <td>If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.</td> </tr> <tr> <td style="text-align: center;">TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Torque follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.	TRUE↔FALSE
TRUE	If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the setpoints defined are accepted.			
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a change-over from the active function state "Torque follower active" via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.			
TF_dnTorqueSet_n C02698/1 DINT	Torque setpoint in [%] • 100 % ≙ motor reference torque (display in C00057/2).			
TF_dnSpeedHighLimit_n C02698/2 DINT	Upper speed limit value in [%] for speed limitation • For positive direction of motion. • 100 % ≙ Motor reference speed (C00011). • Negative values are limited internally to the value "0".			
TF_dnSpeedLowLimit_n C02698/3 DINT	Lower speed limit value in [%] for speed limitation • For negative direction of motion. • 100 % ≙ Motor reference speed (C00011). • Positive values are limited internally to the value "0".			


Outputs

Identifier <small>DIS code data type</small>	Value/meaning
TF_bEnabled C02699/2 BOOL	Status signal "Basic function is enabled"
	TRUE The defined setpoints are accepted.

11 Basic drive functions

11.10 Torque follower

11.10.2 Signal flow



[11-24] Signal flow - torque follower

Internal variables of the motor control (oscilloscope signals)

- The red numbers in brackets listed in the signal flow stand for internal variables of the motor control, which you can record by means of the [Oscilloscope](#) for purposes of diagnostics and documentation. (📖 585)

No.	Variable of the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Speed.dnActualMotorSpeed	Current motor speed

11 Basic drive functions

11.10 Torque follower

11.10.3 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Torque follower*
- Short overview of the parameters for the torque follower:

Parameters	Info
C00050/1	Speed setpoint 1
C00050/2	Speed setpoint 2
C00070	Speed controller gain
C00071	Speed controller reset time
C00909/1	Upper speed limit value
C00909/2	Lower speed limit value
C02527	Motor mounting direction
C02550/2	Speed setpoint interpolation
C02550/3	Torque setpoint interpolation
C02559	Internal torque limit

Greyed out = display parameter

11.10.3.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

11.10.3.2 Inversion of the direction of rotation

Depending on the motor mounting position, if required, the direction of rotation can be inverted:

- [C02527](#) = "0": Clockwise rotating motor ≡ positive machine direction.
- [C02527](#) = "1": Counter-clockwise rotating motor ≡ positive machine direction.

11.10.4 Activating setpoint interface

Prerequisites

- The controller is in the "Operation" device state.
- The basic function "Torque follower" is part of the active application.
- No other basic function is active.

Activation

To request the control via the basic function, the *TF_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Torque follower active" function state is carried out, and the motor control is automatically switched over to torque control with speed limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- A successful change to the function state "Torque follower active" is displayed by a TRUE signal at the *TF_bEnabled* status output.



Stop!

The basic function does not take over the control of the drive from the current speed, but immediately with the setpoint defined, which may cause a jerk!

Deactivation

When the *TF_bEnable* enable input is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- The status output *TF_bEnabled* is reset to FALSE and a change-over from the active "Torque follower active" function state via the "Drive is stopped" function state back to the basic state "Drive at standstill" is carried out.

11 Basic drive functions

11.11 Limiter

11.11 Limiter

The basic function "Limiter" monitors the travel range limits via limit switches and parameterised software limit positions and can lead the drive to defined limit ranges when being requested accordingly by the safety module.



Danger!

The safety is exclusively ensured by the safety module!

When the request for the safety function is cancelled, the drive can restarts automatically.

Ensure by external measures that the drive only starts after a confirmation (EN 60204).




Note!

In order to make it possible for the basic function "Limiter" to lead the drive to the limit ranges defined **after a corresponding request by the safety module**, before the limits set for the safety module have been reached and it shuts down the drive, the limits for the basic function "Limiter" have to be set lower than the limits of the safety module!

See also: [Safety engineering \(369\)](#)

11.11.1 Internal interfaces | "LS_Limiter" system block

The **LS_Limiter** system block provides the internal interfaces for the basic function "Limiter" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier DIS code data type	Information/possible settings
LIM_dwControl C02717 DWORD	Interface to the safety module (bit coded) <ul style="list-style-type: none"> • For a simple connection of the safety module to the application, the transmission of the currently valid safety requirement(s) is effected via this bit coded control signal. • It is also possible to make several requirements at the same time via the control signal, e.g. manual jog with limited increment and limited speed 2. • Bits not listed are reserved for future extensions!
Bit 0	Switched-off torque: request controller inhibit. <ul style="list-style-type: none"> • This bit is no longer supported by the control signal of the LS_SafetyModuleInterface system block.
Bit 1	Stop 1: request quick stop with subsequent controller inhibit.
Bit 2	Stop 2: request quick stop. <ul style="list-style-type: none"> • If the automatic brake operation is activated, the brake remains open at standstill.
Bit 3	Request limited speed 1. <ul style="list-style-type: none"> • Change of the traversing profile according to the parameters set for the limited speed 1 (C02708/1, C02710/1, C02711/1). • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 4	Request limited speed 2. <ul style="list-style-type: none"> • Change of the traversing profile according to the parameters set for the limited speed 2 (C02708/2, C02710/2, C02711/2). • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 5	Request limited speed 3. <ul style="list-style-type: none"> • Change of the traversing profile according to the parameters set for the limited speed 3 (C02708/3, C02710/3, C02711/3). • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 6	Request limited speed 4. <ul style="list-style-type: none"> • Change of the traversing profile according to the parameters set for the limited speed 4 (C02708/4, C02710/4, C02711/4). • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 7	Only permit positive direction of rotation. <ul style="list-style-type: none"> • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 8	Only permit negative direction of rotation. <ul style="list-style-type: none"> • Only effective for the basic functions "Manual jog", "Homing" and "Positioning".
Bit 10	Limited increment <ul style="list-style-type: none"> • Activate maximum distance set in C02713 as limited increment for the basic function "Manual jog".
Bit 12	Defined limit positions <ul style="list-style-type: none"> • Activate software limit positions set in C02701/1 and C02701/2.

Identifier DIS code data type	Information/possible settings	
LIM_bLimitSwitchPositive C02719/1 BOOL	Input for positive travel range limit switch	
	TRUE	Limit switch is activated.
LIM_bLimitSwitchNegative C02719/2 BOOL	Input for negative travel range limit switch	
	TRUE	Limit switch is activated.
LIM_bActivateLimitedSpeed 1 C02719/3 BOOL	Request limited speed 1 • If a setpoint follower is active, no limitation takes place, but an exceeding of the limit values is displayed via the output <i>LIM_dnState</i> .	
	TRUE	Request limited speed 1.

Outputs


Identifier DIS code data type	Value/meaning																																						
LIM_dnState C02718 DINT	Status word (bit coded) • Bits which are not listed are not assigned with a status (always "0"). <table border="1" data-bbox="606 456 1442 1666"> <tr> <td data-bbox="606 456 758 546">Bit 0</td> <td data-bbox="758 456 1442 546">Controller inhibit is initiated. (Safe torque off is requested; bit 0 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 546 758 636">Bit 1</td> <td data-bbox="758 546 1442 636">Quick stop is initiated. (Safe stop 1 is requested; bit 1 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 636 758 725">Bit 2</td> <td data-bbox="758 636 1442 725">Quick stop is initiated. (Safe stop 2 is requested; bit 2 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 725 758 815">Bit 3</td> <td data-bbox="758 725 1442 815">Profile change due to speed limitation. (Limited speed 1 is requested; bit 3 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 815 758 904">Bit 4</td> <td data-bbox="758 815 1442 904">Profile change due to speed limitation. (Limited speed 2 is requested; bit 4 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 904 758 994">Bit 5</td> <td data-bbox="758 904 1442 994">Profile change due to speed limitation. (Limited speed 3 is requested; bit 5 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 994 758 1084">Bit 6</td> <td data-bbox="758 994 1442 1084">Profile change due to speed limitation. (Limited speed 4 is requested; bit 6 of the <i>LIM_dwControl</i> control signal is set to "1".)</td> </tr> <tr> <td data-bbox="606 1084 758 1173">Bit 7</td> <td data-bbox="758 1084 1442 1173">Only positive direction of rotation is permissible. • When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.</td> </tr> <tr> <td data-bbox="606 1173 758 1263">Bit 8</td> <td data-bbox="758 1173 1442 1263">Only negative direction of rotation is permissible. • When the direction of rotation is positive while requesting "Only negative direction of rotation", the drive is braked to standstill.</td> </tr> <tr> <td data-bbox="606 1263 758 1308">Bit 10</td> <td data-bbox="758 1263 1442 1308">Increment in manual jog mode is limited.</td> </tr> <tr> <td data-bbox="606 1308 758 1352">Bit 12</td> <td data-bbox="758 1308 1442 1352">Limitation of the set position is active.</td> </tr> <tr> <td data-bbox="606 1352 758 1397">Bit 16</td> <td data-bbox="758 1352 1442 1397">Positive limit switch inhibits travel in positive direction.</td> </tr> <tr> <td data-bbox="606 1397 758 1442">Bit 17</td> <td data-bbox="758 1397 1442 1442">Negative limit switch inhibits travel in negative direction.</td> </tr> <tr> <td data-bbox="606 1442 758 1487">Bit 18</td> <td data-bbox="758 1442 1442 1487">Positive software limit position inhibits travel in positive direction.</td> </tr> <tr> <td data-bbox="606 1487 758 1532">Bit 19</td> <td data-bbox="758 1487 1442 1532">Negative software limit position inhibits travel in negative direction.</td> </tr> <tr> <td data-bbox="606 1532 758 1576">Bit 20</td> <td data-bbox="758 1532 1442 1576">Limitation of speed is active.</td> </tr> <tr> <td data-bbox="606 1576 758 1621">Bit 21</td> <td data-bbox="758 1576 1442 1621">Limitation of acceleration is active.</td> </tr> <tr> <td data-bbox="606 1621 758 1666">Bit 22</td> <td data-bbox="758 1621 1442 1666">Limitation of deceleration is active.</td> </tr> <tr> <td data-bbox="606 1666 758 1711">Bit 23</td> <td data-bbox="758 1666 1442 1711">Limitation of jerk is active (S-ramp time is increased).</td> </tr> </table>	Bit 0	Controller inhibit is initiated. (Safe torque off is requested; bit 0 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 1	Quick stop is initiated. (Safe stop 1 is requested; bit 1 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 2	Quick stop is initiated. (Safe stop 2 is requested; bit 2 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 3	Profile change due to speed limitation. (Limited speed 1 is requested; bit 3 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 4	Profile change due to speed limitation. (Limited speed 2 is requested; bit 4 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 5	Profile change due to speed limitation. (Limited speed 3 is requested; bit 5 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 6	Profile change due to speed limitation. (Limited speed 4 is requested; bit 6 of the <i>LIM_dwControl</i> control signal is set to "1".)	Bit 7	Only positive direction of rotation is permissible. • When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.	Bit 8	Only negative direction of rotation is permissible. • When the direction of rotation is positive while requesting "Only negative direction of rotation", the drive is braked to standstill.	Bit 10	Increment in manual jog mode is limited.	Bit 12	Limitation of the set position is active.	Bit 16	Positive limit switch inhibits travel in positive direction.	Bit 17	Negative limit switch inhibits travel in negative direction.	Bit 18	Positive software limit position inhibits travel in positive direction.	Bit 19	Negative software limit position inhibits travel in negative direction.	Bit 20	Limitation of speed is active.	Bit 21	Limitation of acceleration is active.	Bit 22	Limitation of deceleration is active.	Bit 23	Limitation of jerk is active (S-ramp time is increased).
Bit 0	Controller inhibit is initiated. (Safe torque off is requested; bit 0 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 1	Quick stop is initiated. (Safe stop 1 is requested; bit 1 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 2	Quick stop is initiated. (Safe stop 2 is requested; bit 2 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 3	Profile change due to speed limitation. (Limited speed 1 is requested; bit 3 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 4	Profile change due to speed limitation. (Limited speed 2 is requested; bit 4 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 5	Profile change due to speed limitation. (Limited speed 3 is requested; bit 5 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 6	Profile change due to speed limitation. (Limited speed 4 is requested; bit 6 of the <i>LIM_dwControl</i> control signal is set to "1".)																																						
Bit 7	Only positive direction of rotation is permissible. • When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.																																						
Bit 8	Only negative direction of rotation is permissible. • When the direction of rotation is positive while requesting "Only negative direction of rotation", the drive is braked to standstill.																																						
Bit 10	Increment in manual jog mode is limited.																																						
Bit 12	Limitation of the set position is active.																																						
Bit 16	Positive limit switch inhibits travel in positive direction.																																						
Bit 17	Negative limit switch inhibits travel in negative direction.																																						
Bit 18	Positive software limit position inhibits travel in positive direction.																																						
Bit 19	Negative software limit position inhibits travel in negative direction.																																						
Bit 20	Limitation of speed is active.																																						
Bit 21	Limitation of acceleration is active.																																						
Bit 22	Limitation of deceleration is active.																																						
Bit 23	Limitation of jerk is active (S-ramp time is increased).																																						
LIM_bLimitationActive C02715 BOOL	Status signal "Limitation is active" (group signal) <table border="1" data-bbox="606 1704 1442 1738"> <tr> <td data-bbox="606 1704 758 1738">TRUE</td> <td data-bbox="758 1704 1442 1738">A limitation is active.</td> </tr> </table>	TRUE	A limitation is active.																																				
TRUE	A limitation is active.																																						

11 Basic drive functions

11.11 Limiter

11.11.1.1 Interface to the safety module

For the simple connection of the safety module to the application, the transmission of the currently valid safety requirement(s) is effected in the form of a bit coded control signal via the following interface:



[11-25] Interface to connect the safety module to the basic function "Limiter"

- It is also possible to make several requirements at the same time via the control signal, e.g. manual jog with limited increment and limited speed 2.
- If no safety module is connected, the control signal can also be generated by means of a converter block (FB **L_DevSMControlEncoder**).

11.11.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Limiter*
- Short overview of the parameters for the limiter:

Parameters	Info
C02700	Software limit positions active
C02701/1	Positive software limit position
C02701/2	Negative software limit position
C02702	Limitations effective
C02703	Max. speed
C02704	Max. speed [rpm]
C02705	Max. acceleration
C02706	Min. S-ramp time
C02707	Permissible direction of rotation
C02708/1...4	Limited speed 1 4
C02709/1...4	Limited speed 1 4 (display in [rpm])
C02710/1...4	Dec. limited speed 1 4
C02711/1...4	S-ramp time limited speed 1 4
C02712/1...4	Dec. time limited speed 1 4
C02713	Max. distance manual control
C02714	Max. dist. manual control (display in [increments])
C02715	Limitation active (status display)
C02716/1	Resp. to rotation limitation
C02716/2	Resp. to SW lim. pos. exceeded
C02716/3	Resp. to max. value exceeded
C02720	Observation software limit positions

Greyed out = display parameter



Note!

The safety module has its own parameters.

Relevant to the basic function "Limiter" are the parameters of the safety modules for setting "Limited direction of rotation", "Speed with time limit" and "Limited increment (position)".

However, several other parameters of the safety module have no significance for the basic function "Limiter", e. g. the parameters for the configuration of the inputs of the safety module.

11.11.2.1 Software limit positions

The parameterisable limit positions serve to limit the traversing range by the software.



Note!

Software limit positions are only evaluated and monitored if the drive knows the home position and the software limit positions are active ([C02700](#) = "1").


- When the traversing range is limited ([C02528](#) = "1") and the software limit positions are not active, the range is limited by the software to the internal value range that can be maximally displayed ($\pm 2^{31}$ increments).
- For the "Modulo" traversing range ([C02528](#) = "2") the software limit positions are generally not effective.
- If the error response that can be set in [C02716/2](#) is deactivated or is only set to "Warning" or "Information", the software limit positions are not effective in an active manner for the basic functions "[Speed follower](#)", "[Torque follower](#)", and "[Position follower](#)"!
- After the software limit positions have been exceeded, it must be ensured before acknowledging a pending error that the setpoint applied to the SB `LS_PositionFollower` is not beyond the software limit positions.

From software version V4.0 onwards, the triggering behaviour of the software limit position monitoring can be parameterised in [C02720](#).

- If you want to maintain the device behaviour known from the previous versions, select "1: Based on set and actual value" in [C02720](#).

▶ [Triggering behaviour of software limit position monitoring](#) (□ 514)

- The positive software limit position is set in [C02701/1](#), and the negative software limit position is set in [C02701/2](#).
- If the software limit positions are active, travelling commands that would result in exiting from the permissible travel range can no longer be executed:




[11-26] Example: Traversing range limitation by means of software limit positions

11 Basic drive functions

11.11 Limiter

- If the drive is already outside the permissible travel range and the software limit positions have been activated, only travel commands that result in the drive moving back into the permissible travel range can be executed:



[11-27] Example: Permissible traversing direction if software limit positions active

- If the software limit positions are active and a software limit position is passed ("overtravel"):
 - The error response "quick stop by trouble" is carried out in the Lenze setting, i.e. the drive is braked to standstill within the deceleration time set for the quick stop function irrespective of the setpoint selection. The error response can be parameterised in [C02716/2](#).
 - The fault message "Pos. SW limit switch overtravelled" or "Neg. SW limit overtravelled" is entered in the logbook of the controller.
 - A corresponding status is output via the *LIM_dnState* output.
 - Depending on the parameterised fault response, the drive cannot traverse until the error has been acknowledged.

See also: [▶ Manual jog to limit position \(410\)](#)

11.11.2.2 Triggering behaviour of software limit position monitoring

This function extension is available from software version V4.0!

[C02720](#) can be used to select the triggering behaviour of the software limit position monitoring of non-position-controlled basic functions:

Selection "0: Based on set value"

From software version V4.0 onwards, this is the Lenze setting:

- If the basic functions "[Speed follower](#)" and "[Torque follower](#)" are used, the monitoring responds if the drive is outside the software limit positions and a command to travel in the "forbidden" direction is given (depending on the speed setpoint of the application).
- For all other non-position-controlled basic functions, the monitoring does not respond if a software limit position is exceeded.

Selection "1: Based on set and actual value"

This selection corresponds to the behaviour known from the previous versions (software versions < V4.0):

- For all non-position-controlled basic functions, the monitoring responds if the actual position exceeds a software limit position.
 - The monitoring also responds in the function states "Controller not ready" and "Error". This may cause the monitoring to trigger permanently if the drive traverses to a software limit position and controller inhibit is set subsequently because the actual position slightly changes around the software limit position.
- If the basic functions "[Speed follower](#)" and "[Torque follower](#)" are used, the monitoring also responds if the drive is outside the software limit positions and a command to travel in the "forbidden" direction is given (depending on the speed setpoint of the application).



Note!

If the position-controlled basic functions "[Manual jog](#)", "[Positioning](#)" and "[Position follower](#)" are used, the monitoring responds independently of the triggering behaviour parameterised in [C02720](#) if one of the following cases occurs:


- The setpoint position exceeds a software limit position.
- A travel command is given which would cause the drive to leave the permissible travel range.
- The drive is outside the software limit positions and a command to travel in the "forbidden" direction is given.

If the software limit position monitoring is triggered, the error response parameterised in [C02716/2](#) is carried out.

11.11.2.3 Hardware limit positions (limit switch)

Monitoring of the travel range limit by means of limit switches is effected via the inputs *LIM_bLimitSwitchPositive* and *LIM_bLimitSwitchNegative* of the **LS_Limiter** SB.

- The two inputs respond to the TRUE state and are to be connected to the corresponding digital inputs to which the limit switches are connected:



[11-28] Example: Connection of the travel range limit switches to the digital inputs DI3 & DI4

- If the limit switches are connected to decentralised terminals, the two inputs *LIM_bLimitSwitchPositive* and *LIM_bLimitSwitchNegative* can be connected to the decentralised terminal via a bus system (e. g. system bus).



Note!

If the digital inputs used for the connection of the limit switches are to be designed in a fail-safe manner (activation at LOW level), you simply change the terminal polarity of the corresponding digital inputs in [C00114](#).

- If one of the two monitoring inputs is set to TRUE:
 - The error response "quick stop by trouble" is carried out, i.e. the drive is braked to standstill within the deceleration time set for the quick stop function irrespective of the setpoint selection.
 - The fault message "Pos. SW limit switch has tripped" or "Neg. SW limit has tripped" is entered in the logbook of the controller.
 - A corresponding status is output via the *LIM_dnState* output.
 - The drive can only be traversed again after the error has been acknowledged.



Stop!

If a limit switch is approached by means of the basic function [Position follower](#) and by this a fault with the "Quick stop by trouble" response is activated, always a set/actual adjustment of the position has to be carried out before the fault is acknowledged, as otherwise an uncontrolled motor movement may result after the fault is acknowledged!

11 Basic drive functions

11.11 Limiter



Tip!

An activated limit switch can be retracted using the function "Retracting the limit switch". ▶ [Retracting of an activated limit switch](#) (📖 411)

See also: ▶ [Manual jog to limit position](#) (📖 410)

11.11.2.4 Limitations

Limit values for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameters	Info
C02703	Max. speed <ul style="list-style-type: none"> • Max. permissible speed that can be driven by the system. • This parameter depends, among other things, on the max. motor speed.
C02705	Max. acceleration <ul style="list-style-type: none"> • Max. permissible acceleration or deceleration for positioning processes. • This parameter depends, among other things, on the motor torque and moment of inertia of the entire mechanics which is driven during the positioning process.
C02706	Min. S-ramp time

- The parameters depend on the mechanics (e.g. the tool used).
- Usually the parameters must be changed when a tool is exchanged, e.g. by means of a recipe management of a superimposed control or via an HMI ("*Human Machine Interface*").



Note!

In order that the set limit values are effective, "1" must be selected in [C02702](#).

- Irrespective of this setting, basically, the speed setpoint is limited to the motor reference speed ([C00011](#))!

The limitations are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- In case of these basic functions only speed and acceleration are monitored.
- If the limit values for speed and acceleration are exceeded, the response parameterised in [C02716/3](#) is activated (Lenze setting: no response).
- **Background:** In the case of technology applications which are synchronised via an electrical shaft, the setpoint followers may not be limited, since synchronism would be lost by this. A possible consequence would be a collision of tools.

- If the limit values are switched effectively and a limit value that is set is exceeded:
 - The setpoints of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") are changed (limited).
 - The response parameterised in [C02716/3](#) (Lenze setting: "No response") is activated.
 - A corresponding error message is entered into the logbook of the controller.
 - A corresponding status is output via the *LIM_dnState* output.
 - The display parameter "Limitation active" ([C02715](#)) is set to "1: Activated".

11.11.2.5 Permissible direction of rotation

Via [C02707](#), or alternatively via the input *LIM_dwControl* (generally by the control word of the safety module) the permissible direction of rotation for the basic functions "[Manual jog](#)", "[Homing](#)", and "[Positioning](#)" can be restricted.



Note!

The restriction of the permissible direction of rotation is not actively effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- Only the response parameterised in [C02716/1](#) is executed.
(Lenze setting: "No response")
- If the permissible direction of rotation is restricted and a travel command in the inhibited direction of rotation is requested:
 - The movement of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") is cancelled.
 - The response parameterised in [C02716/1](#) (Lenze setting: "No response") is activated.
 - The fault message "Pos. direction of rotation was limited" or "Neg. direction of rotation was limited" is entered in the logbook of the controller.
 - A corresponding status is output via the *LIM_dnState* output.

11.11.2.6 Limited speed

"Limited speeds" for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameters	Info
C02708/1...4	Limited speed 1 4
C02710/1...4	Dec. limited speed 1 4
C02711/1...4	S-ramp time limited speed 1 4
C02712/1...4	Dec. time limited speed 1 4



Note!

The limited speeds are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- The request "Limited speed 1 ... 4" is effected via the input *LIM_dwControl*, generally by the control word of the safety module. If no safety module is available, the control word for the input *LIM_dwControl* can also be generated by means of an inverter.
- By means of the input *LIM_bActivateLimitedSpeed1* additionally the request of "Limited speed 1" can be effected, e. g. via a digital input that is connected to this input.
- If a limited speed is requested and the current speed exceeds the limited speed:
 - The setpoints of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") are changed (limited).
 - The response parameterised in [C02716/3](#) (Lenze setting: "No response") is activated.
 - The error message "Speed has been limited" is entered into the logbook of the controller.
 - A corresponding status is output via the *LIM_dnState* output.
 - The display parameter "Limitation active" ([C02715](#)) is set to "1: Activated".

Process example: "Manual jog"

1. Manual jog in positive direction is active and the manual speed is greater than the "Limited speed 1" set.
2. Via the control word of the safety module the "Limited speed 1" is requested.
3. The drive is decelerated to the "Limited speed 1" with the deceleration and S-ramp time set for the "Limited speed 1".
4. At the same time, a corresponding status is output via the *LIM_dnState* output.

Priorisation of the limited speeds

The following applies to software versions lower than V3.0:

If several limited speeds are requested at the same time, the parameters of the limited speed with the lowest number are used, i.e. the "Limited speed 1" has the highest priority.

The following applies from software version V3.0:

If several limited speeds are requested at the same time, the lowest speed with the greatest deceleration and the lowest S-ramp time is approached from the parameters of the requested limited speeds.

When activating the profile parameter limitations ([C2702](#) = TRUE), observe the following:

- The SLS deceleration is limited to maximally [C2705](#).
- The SLS jerk time can minimally correspond to the value of the minimum S-ramp ([C2706](#)).

11.11.2.7 Limited increment for manual jog

Via [C02713](#) the maximum permissible distance (limited increment) for the basic function "[Manual jog](#)" can be set.

- The request "Limited increment" is effected via the input *LIM_dwControl*, generally by the control word of the safety module. If no safety module is available, the control word for the input *LIM_dwControl* can also be generated by means of an inverter.
- In [C02714](#) the maximum permissible distance in [increments] is displayed.

11.12 Brake control

This basic function is used for a wear-free control and monitoring of a motor holding brake which in the simplest case is connected to the optionally available motor brake control module (accessories).

Alternatively, the motor holding brake can be controlled via a digital output and monitored via a digital input.

Intended use

Motor holding brakes are used to hold axes in the case of controller inhibit or pulse inhibit and in the "Mains OFF" system state. This is not only important for vertical axes, but for instance also for horizontal axes for which an uncontrolled movement can bring about diverse problems.

Examples:

- Loss of the reference information after mains OFF and further spinning of the drive.
- Collision with other moving machine parts.



Danger!

Please bear in mind that the motor holding brake is an important element of the safety concept of the entire machine. Thus maintain this system component with special care!



Stop!

Motor holding brakes at Lenze motors are not designed for braking during operation. The increased wear resulting from braking during operation may lead to an early destruction of the motor holding brake!



Please observe the notes in the hardware manual for mounting and electrical installation of the motor holding brake!

**Note!**

For the operation with the motor brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

For the encoderless motor control types (from software version V3.0) the following applies:

The operation of vertical drives/hoists is

- only supported up to 55 kW by the V/f control!
- not supported by the sensorless vector control!


When the V/f control or sensorless vector control are selected, standstill monitoring is always switched off.

11 Basic drive functions

11.12 Brake control

11.12.1 Internal interfaces | "LS_Brake" system block

The **LS_Brake** system block provides the internal interfaces for the basic function "Brake control" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier DIS code data type	Information/possible settings			
BRK_bReleaseBrake C02609/1 BOOL	Releasing/applying the brake in connection with the selected operating mode			
	<table border="1"> <tr> <td>FALSE</td> <td>Apply brake. • During automatic operation, the internal brake logic controls the brake.</td> </tr> <tr> <td>TRUE</td> <td>Release brake. • During automatic operation, the internal brake logic is deactivated and the brake is released. If the brake control has inhibited the controller, this inhibit is deactivated again.</td> </tr> </table>	FALSE	Apply brake. • During automatic operation, the internal brake logic controls the brake.	TRUE
FALSE	Apply brake. • During automatic operation, the internal brake logic controls the brake.			
TRUE	Release brake. • During automatic operation, the internal brake logic is deactivated and the brake is released. If the brake control has inhibited the controller, this inhibit is deactivated again.			
BRK_bStartingTorque2 C02609/2 BOOL	Selection of the torque feedforward control value • For the general use of the parameterisable starting torque as a feedforward control value, the setting C02588 = 0 is required. ▶ Torque feedforward control (□ 537)			
	<table border="1"> <tr> <td>FALSE</td> <td>Starting torque 1 (C02586) is active.</td> </tr> <tr> <td>TRUE</td> <td>Starting torque 2 (C02587) is active.</td> </tr> </table>	FALSE	Starting torque 1 (C02586) is active.	TRUE
FALSE	Starting torque 1 (C02586) is active.			
TRUE	Starting torque 2 (C02587) is active.			
BRK_bDisableStop C02609/10 BOOL	Prevent the brake from being applied in automatic operation • By this the drive remains position-controlled in the function states "Quick stop active", "Drive is stopped", and "Drive at standstill". • The input has no effect when the controller is inhibited.			
	<table border="1"> <tr> <td>TRUE</td> <td>The application of the brake in automatic operation is prevented.</td> </tr> </table>	TRUE	The application of the brake in automatic operation is prevented.	
TRUE	The application of the brake in automatic operation is prevented.			
BRK_dnTorqueAdd_n C02608 DINT	Additive torque value in [%] for torque feedforward control during start • 100 % = C00057/2 ▶ Torque feedforward control (□ 537) Note: The input is read out if the brake receives a release signal, e.g. when <i>BRK_bReleaseBrake</i> = TRUE.			
BRK_bBrakeApplied C02609/3 BOOL	Input for status detection via switching contacts at the brake • Activation of the input by setting C02583 = 1. ▶ Signal configuration (□ 528)			
	<table border="1"> <tr> <td>FALSE</td> <td>Status "Brake is released".</td> </tr> <tr> <td>TRUE</td> <td>Status "Brake is applied".</td> </tr> </table>	FALSE	Status "Brake is released".	TRUE
FALSE	Status "Brake is released".			
TRUE	Status "Brake is applied".			
BRK_bBrakeTest C02609/4 BOOL	Start/abort of the brake test ▶ Carrying out brake test (□ 554)			
	<table border="1"> <tr> <td>TRUE</td> <td>Carry out brake test</td> </tr> <tr> <td>TRUE↯FALSE</td> <td>Abort brake test (deactivate mode).</td> </tr> </table>	TRUE	Carry out brake test	TRUE↯FALSE
TRUE	Carry out brake test			
TRUE↯FALSE	Abort brake test (deactivate mode).			
BRK_bBrakeGrindIn C02609/5 BOOL	Start/abort of the brake grinding process ▶ Grinding the brake (□ 552)			
	<table border="1"> <tr> <td>TRUE</td> <td>Brake grinding.</td> </tr> <tr> <td>TRUE↯FALSE</td> <td>Abort grinding process (deactivate mode).</td> </tr> </table>	TRUE	Brake grinding.	TRUE↯FALSE
TRUE	Brake grinding.			
TRUE↯FALSE	Abort grinding process (deactivate mode).			

Outputs

Identifier DIS code data type	Value/meaning
BRK_dnState C02607 DINT	Status (bit coded) • Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Brake control is active.
	Bit 4 Motor brake control module is used.
	Bit 8 Brake status (internal status signal).
	Bit 9 Torque feedforward control is active.
	Bit 10 Controller inhibit by brake is active or set.
	Bit 15 Fault is active (collective message).
	Bit 16 State "Grinding the brake".
	Bit 17 State "Brake test".
	Bit 18 State "Direct control".
	Bit 19 State "Automatic control".
	Bit 20 Fault: External feedback.
	Bit 21 Fault: Position drift when brake is applied/checked.
	Bit 22 Error: Monitoring of motor brake control module
	Bit 23 Information: Brake activation via waiting time.
Bit 24 Information: Brake grinding process completed.	
Bit 25 Information: Brake test completed.	
Bit 26 Fault: Feedforward control torque could not be established within one second.	
Bit 27 Information: Current speed has fallen below the threshold for brake activation set in C02581 .	
BRK_bReleaseBrakeOut C02609/6 BOOL	Control signal for triggering an external brake/status signal for control state
	FALSE Apply brake.
	TRUE Release brake.
BRK_bBrakeReleased C02609/7 BOOL	Status signal of the brake control considering the closing and opening time of the brake
	FALSE Brake applied (after the brake application time has expired).
	TRUE Brake released (after the brake release time has expired).
BRK_bError C02609/8 BOOL	Status signal "Brake error"
	TRUE An error has been detected.
BRK_bClnhActive C02609/9 BOOL	Status signal "Controller inhibit"
	TRUE Controller inhibit has been set by brake control.

11.12.2 Parameter setting



Danger!

A faultless brake control function requires a correct setting of the different deceleration times in the following parameters!

If the delay times are set incorrectly, a faulty control of the motor holding brake may be caused!

In the case of the basic functions [Manual job, encoderless](#) (□ 412) and [Pole position identification](#) (□ 575), the number of available operating modes of the holding brake is limited. Please refer to the danger notes in the chapters indicated.

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Brake control*
- Short overview of parameters for brake control:

Parameters	Info
C02580	Brake operating mode
C02581	Threshold - brake activation
C02582	Brake resp. to pulse inhibit
C02583	Status input monitoring
C02585	Brake control polarity
C02586	Starting torque 1
C02587	Starting torque 2
C02588	Source of starting torque
C02589	Brake closing time
C02590	Brake opening time
C02591	Waiting time - status monitoring
C02593	Waiting time - brake activation
C02594	Test torque
C02595	Permissible angle of rotation
C02596	Grinding speed
C02597	Accel./decel. time - grinding
C02598	Grinding ON time
C02599	Grinding OFF time
C02600	Acceleration time feedf. control
C02601	Reference for acceleration time of brake
C02602	Source for feedf. control brake
C02603	Threshold 1 for opening brake
C02604	Threshold 2 for opening brake
C02605/1	Acceleration time - brake test
C02605/2	Duration of constant torque - brake test
C02605/3	Deceleration time - brake test
C02606	Minimum starting torque

11 Basic drive functions

11.12 Brake control

11.12.2.1 Operating mode

Various operating modes are available in [C02580](#) for different applications and tasks:

- [Mode 0: Brake control is switched off](#) (📖 542)
- [Mode 1/11: Direct control of the brake](#) (📖 543)
 - Without a specific logic or automatic system, can for instance be used to carry out a simple check on whether the brake switches correctly.
- [Mode 2/12: Automatic control of the brake](#) (📖 544)
 - The normal mode for the control of mech. holding brakes with and without holding torque precontrol.

Function extension from software version V3.0:

- [Mode 22: Automatic DC-injection braking](#) (📖 549)
 - DC-injection braking for V/f control and sensorless vector control.
-

11 Basic drive functions


11.12 Brake control

11.12.2.2 Signal configuration

The signal configuration of the control and status signals for the brake logic and monitoring function is executed via the parameters shown in the following signal flows.

Direct brake control


This triggering of the holding brake does not need the motor brake control module:



[11-29] Direct control of the motor holding brake

Triggering the brake via the motor brake control module E94AZHA0051


The design of the motor brake control module E94AZHA0051 enables the external control of the holding brake via an additional 3-pole terminal (X121).



[11-30] Signal configuration of the control and status signal with the motor brake control module E94AZHA0051

Triggering the brake via the motor brake control module E94AZHX0051

The motor brake control module E94AZHX0051 does **not** include an additional 3-pole terminal for the external control of the holding brake.



[11-31] Signal configuration of the control and status signal with the motor brake control module E84AZHX0051



Note!

If an electrically holding (self-releasing) motor holding brake is to be controlled instead of an electrically releasing (self-holding) motor holding brake, the corresponding control and status signals must be inverted!



Please observe the notes in the hardware manual for mounting and electrical installation of the motor holding brake!

Status monitoring by "Motor brake control module status"

(See signal path [E](#) in fig. [\[11-30\]](#))

- Indirect status detection of the brake function.
- Monitoring of the motor brake control module and the electrical brake circuit.


Status monitoring by "Brake function test"

(See signal path [B](#) in fig. [\[11-29\]](#) or [\[11-31\]](#))

- Direct function test of the complete brake circuit by microswitches at the brake.
- Wear control of the brake rotor.

11.12.2.3 Standstill monitoring

After the brake closing time and the waiting time for the status monitoring have elapsed, the standstill monitoring becomes active, i. e. the holding position is noted and compared to the permissible angle of rotation set in [C02595](#) (Lenze setting: 5°) when the brake is applied.



[11-32] Automatic monitoring of the holding position

- If the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#), although the brake is engaged:
 - The error message "Motor brake: Angular drift with closed brake too high" is entered into the logbook.
 - "Quick stop by trouble" is activated as error response to avoid a further rotation/acceleration of the drive.
 - The error output *BRK_bError* is set to TRUE for one task cycle.
 - The status "position drift when brake is applied" is displayed at the *BRK_dnState* status output via bit 21 for one task cycle.



Note!


The standstill monitoring can be switched off by the setting [C02595](#) = "0".

For the encoderless motor control types (from software version V3.0) the following applies:

If the V/f control or the sensorless vector control is selected, the standstill monitoring is generally switched off, irrespective of the setting in [C02595](#).

11.12.2.4 Speed watchdog

Brake activation through $N < N_{min}$



[11-33] Process of brake activation through $N < N_{min}$



Tip!

The value in [C02581](#) should be set to approx. 5 ... 20 % of the maximum speed to minimise the wear of the brake and also provide for an optimum braking behaviour by a low grinding of the brake.

- If the motor speed falls below the threshold for brake activation set in [C02581](#), the function "Close brake" is activated in the automatic operation (mode 2/12).
- Here only the absolute value of the motor speed is considered, the direction of rotation remains unconsidered.
- In manual operation (mode 1/11) [C02581](#) has no function.


Brake activation through time-out

If a waiting time for the brake activation > 0 s is set in [C02593](#), the time monitoring is active, i. e. the brake at the latest is activated for application after the waiting time has elapsed, even if the actual speed value is still above the threshold for the brake activation set in [C02581](#).



Note!

In the Lenze setting the time monitoring is not active ([C02593](#) = "0 s").



[11-34] Process of brake activation through time-out

- The waiting time starts to elapse if the speed setpoint has reached the threshold for the brake activation.
- If the speed setpoint is still above the threshold after the waiting time has elapsed:
 - The brake is automatically triggered to close in automatic operation (mode 2/12).
 - The "brake activation via waiting time" status is displayed at the *BRK_dnState* status output via bit 23.
 - The information "Motor brake: Automatically activated after waiting time has elapsed" is entered in the logbook.

11.12.2.5 Braking time characteristics


Application and release time



Danger!

A wrong setting of the closing and opening time can cause a wrong activation of the motor holding brake!

- When the closing time is set too low, the controller is inhibited and the drive gets torqueless before the motor holding brake is closed completely.



- Every mechanical motor holding brake has a construction-conditioned application and opening time which has to be taken into consideration by the brake control and which for this purpose has to be set in [C02589](#) and in [C02590](#).
- The information on the application and opening time of a Lenze-motor holding brake can be found in the corresponding Operating Instructions in the chapter "Technical data".
- If the application and release times are too long, this is uncritical in respect of safety but leads to unnecessarily long delays during cyclical braking processes.

[11-35] Definition of the application and release time with the example of the PM brake




Tip!

The application and release times do not only vary between the brake types but also depend on the basic conditions in the plant:

- Parameters of the hardware (cable length, temperature, level of supply voltage etc.)
- Contact elements used (motor brake control module or contactor at the digital output)
- Type of overvoltage limitation/suppressor circuit

For optimisation purposes, detect in individual cases the response times by measurement.

Motor magnetising time (only with asynchronous motor)



- When an asynchronous motor is used, first the magnetic field required for the holding torque is created (which is already available when a synchronous motor is used) after the controller inhibit is deactivated.
- The brake is only released if the actual torque has reached 90 % of the feedforward control torque.

[11-36] Considering the motor magnetising time taking the PM brake as an example

Waiting time for status monitoring


Every time the brake status changes, the waiting time set in [C02591](#) is awaited after the brake opening or brake closing time has elapsed, before the monitoring of the motor brake control module and the status input *BRK_bBrakeApplied* (if activated via [C02583](#)) and the standstill monitoring function are switched active again.

- During the "Closing the brake" process, a mechanical contact must signal the "brake closed" state after the waiting time has elapsed.
- During the "Releasing the brake" process, a mechanical contact must signal the "brake released" state after the waiting time has elapsed.



Tip!

The additional waiting time is based on the fact that during the state change of the brake also state changes with regard to the monitored signals within the brake logic can occur, e. g. by bouncing the microswitch on the brake, or activation of the short circuit threshold within the motor brake control module due to discharge current peaks when the brake voltage is switched on. These state changes result in the activation of the monitoring function, although no stationary fault is pending.



[11-37] Definition of the waiting time for status monitoring

- The waiting time in [C02591](#) must be set so that bouncing of a feedback contact and the transient response of the brake current monitoring will be suppressed completely.
- If no corresponding feedback takes place after the waiting time has elapsed:
 - The error output *BRK_bError* is set to TRUE until the next trigger attempt starts.
 - The error response "Quick stop by trouble" is activated.
 - The error message "Brake status error" is entered into the logbook.

11.12.2.6 Torque feedforward control

In automatic operation (mode 2/12) the brake control offers the possibility of precontrolling the required torque of the drive when the brake is released.



Note!


The torque is precontrolled for one second. During this time, the actual torque must have reached 90 % of the set torque, otherwise a fault is tripped!

The torque feedforward control is also supported for the V/f control (from software version V3.0).

Via [C02588](#) first the basic selection on whether a parameterised starting torque or the torque memorised during the last application process is to be used for the feedforward control.

With this setting, [C02606](#) serves to define an additional torque which is to be used for feedforward control. This is for instance reasonable for hoist drives, in order to avoid, for example, that, due to stalling, a counteracting standstill torque is saved.

Feedforward control with parameterised starting torque



[11-38] Feedforward control with parameterised starting torque

- When [C02588](#) = 0, a change-over between two starting torques is possible via input *BRK_bStartingTorque2*:
 - *BRK_bStartingTorque2* = FALSE: Starting torque 1 ([C02586](#)) is used.
 - *BRK_bStartingTorque2* = TRUE: Starting torque 2 ([C02587](#)) is used.

Application example:

A hoist drive is to be operated with different loads. Unfortunately we do not know when the load is available, but the starting direction (lifting or lowering) is known.

- In a no-load condition, the hoist drive needs a torque of 10 Nm. For holding the maximum load it needs a torque of 50 Nm.
- The change-over between lifting and lowering at start-up is done via the input *BRK_bStartingTorque2*.


- To ensure the correct direction at start-up, the speed controller is loaded with the following starting torques:

	Lifting	Lowering
Starting torque:	C02586 = 50 Nm	C02587 = 10 Nm

- This results in the following behaviour depending on load and direction:

	Lifting	Lowering
Behaviour at max. load:	Optimum behaviour	Start-up a bit fast, but correct direction (non-critical).
Behaviour without load:	Start-up a bit fast, but correct direction (non-critical).	Optimum behaviour

Feedforward control with memorised torque



- When [C02588](#) = 1, the starting torque is the setpoint which has been automatically memorised during the last closing process (falling below the speed threshold set in [C02581](#)).

[11-39] Feedforward control with parameterised starting torque




Note!

The greater the threshold for the brake activation set in [C02581](#), the greater the dynamic portion (e. g. the speed-dependent friction torque) in the memorised torque.

For the specific case that the load is altered while the motor holding brake is closed, a correction value for the torque feedforward control can be defined via the input *BRK_dnTorqueAdd_n* that is added to the memorised torque.

Further torque feedforward control options



[11-40] Feedforward control with parameterised starting torque

- Via the input *BRK_dnTorqueAdd_n* an additional feedforward control value can be defined.

Note:

The input is read out if the brake receives a release signal, e.g. when *BRK_bReleaseBrake* = TRUE.

Application example:

In the case of a hoist drive, the load is always known. For an optimum behaviour a torque proportional to the load and additionally 10 Nm as a constant feedforward control value should be loaded into the speed controller.

- As a constant feedforward control value the starting torque 1 is used ([C02586](#) = "10 Nm", [C02588](#) = "0", and *BRK_bStartingTorque2* = FALSE).
- Via the input *BRK_dnTorqueAdd_n* the torque is specified proportional to the load.

11.12.2.7 Torque feedforward control via ramp function


This function extension is available from software version V3.0!

The brake control additionally offers the possibility of establishing the required torque of the drive when the brake is released via a parameterisable ramp function.

Recruitments

1. Go to [C02600](#) and set the acceleration time for the feedforward control.
2. Go to [C02601](#) and select the reference for the acceleration time:
 - Selection "0: Motor reference value":
The acceleration time refers to the generation of the motor reference torque ([C00057/2](#)), i.e. the acceleration is constant.
 - Selection "1: Starting current value":
The acceleration time refers to the torque requested, i. e. the acceleration time is constant.

Procedure



[11-41] Sequence of torque feedforward control via ramp function

11.12.2.8 Speed feedforward control via ramp function for V/f control

This function extension is available from software version V3.0!

For the V/f control there is the possibility of carrying out a feedforward control by means of a speed which is generated via a parameterisable ramp.



Note!

The operation of vertical drives/hoists is only supported up to 55 kW by the V/f control!

Settings:

1. Go to [C02602](#) and set the selection "1: Speed" as source for the feedforward control.
2. Go to [C02603](#) to set the speed threshold from which on the brake is to be opened.
 - [C02604](#) can be used to parameterise a second speed threshold which can be activated by setting *BRK_bStartingTorque2* to TRUE.
3. Go to [C02600](#) and set the acceleration time for the feedforward control.
4. Go to [C02601](#) and set the reference for the acceleration time (0: Motor reference value, 1: Starting current value).

11.12.3 Mode 0: Brake control is switched off

If the mode 0 is selected in [C02580](#), the brake control is switched off.

- If a motor brake control module is available, it will not be triggered.
- The brake monitoring function is not active.
- A potential fault reported by the brake control is reset automatically.
- The output signals of the system block LS_Brake are reset:
 - *BRK_dnState* = 0
 - *BRK_bReleaseBrakeOut* = FALSE
 - *BRK_bBrakeReleased* = FALSE
 - *BRK_bError* = FALSE



Note!

In the Lenze setting, the mode 0 is preset to get into a safe state after the mains is switched on.

11.12.4 Mode 1/11: Direct control of the brake

If the mode 1 or 11 has been selected in [C02580](#), the brake is directly controlled via the input *BRK_bReleaseBrake*.



Tip!

Mode 1/11 can be used to easily check if the brake switches correctly.

- By the selection of the mode it is also defined in which way the brake is to be controlled:
 - Mode 1: Direct brake control via a motor brake control module.
 - Mode 11: Direct brake control via a digital output.



Note!

The digital outputs are not suitable for the "direct" control of a motor holding brake!

- The digital output used must be connected to a relay or power contactor which switches the brake supply.
- If a power contactor is used, the response and release time of the contactor contact is also added to the response and release time of the brake.

For the operation with the motor brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

- Setting the pulse inhibit or controller inhibit does not influence the output signal.
- After the brake has been activated and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- For the operation with a motor brake control module (mode 1) the desired polarity for controlling the brake can be set in [C02585](#).

11.12.5 Mode 2/12: Automatic control of the brake

If mode 2 or mode 12 is selected in [C02580](#), the brake is controlled automatically, i. e. if another basic function is activated, which results in a traversing of the drive, the brake is automatically opened and operation is enabled. If the corresponding basic function is deactivated again, the drive is stopped via the basic function "[Stop](#)" and the brake is automatically closed again if the speed setpoint and the actual speed value are below the speed threshold set in [C02581](#).



Tip!

The 2/12 mode is the usual mode to control the brake.

In this mode, the `BRK_bReleaseBrake` input should be set permanently to FALSE unless a manual release is required.

If `BRK_bReleaseBrake = TRUE`, the brake is released permanently and the automatic control cannot close the brake.

- By the selection of the mode it is also defined in which way the brake is to be controlled:
 - Mode 2: Current monitoring active, brake is automatically controlled via motor brake control module.
 - Mode 12: Current monitoring deactivated, brake is controlled via digital output. If a motor brake control module is installed, this will also be controlled.



Note!

The digital outputs are not suitable for the "direct" control of a motor holding brake!

- The digital output used must be connected to a relay or power contactor which switches the brake supply.
- If a power contactor is used, the response and release time of the contactor contact is also added to the response and release time of the brake.

For the operation with the motor brake control module:

- For single-axis controllers (Single Drive) the control (release) of the motor holding brake is only possible if both the DC-bus voltage and a 24-V supply voltage are available for the motor brake control!
- For multi-axis controllers (Multi Drive) the motor holding brake can also be released without a DC-bus voltage.

- The brake is also activated automatically if a quick stop is activated in the drive, e.g. via the basic function "[Quick stop](#)" or as a response to a fault and also in case of a controller inhibit and pulse inhibit. ▶ [Behaviour in case of pulse inhibit](#) (📖 545)
- By setting the input *BRK_bDisableStop* to TRUE, an application of the brake at standstill or during quick stop can be avoided; by this the drive remains position-controlled.
- After the brake has been activated automatically and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- For the operation with a motor brake control module (mode 2) the desired polarity for controlling the brake can be set in [C02585](#).

11.12.5.1 Behaviour in case of pulse inhibit

In case of pulse inhibit the brake is applied. This occurs according to the parameter setting in [C02582](#) either immediately (default setting) or delayed when the threshold set for brake activation is fallen below, which can be selected to protect the brake if high centrifugal masses occur.



Note!

Setting the pulse inhibit results causes the motor to coast down in a load-controlled manner until pulse enable is carried out again.

Pulse inhibit can be set in the enabled controller, e.g. due to a DC overvoltage, DC undervoltage or the "Safe torque off" request.



Stop!

Before setting the parameters of [C02582](#) it is important to assess the energy conditions of the machine.

The amount of energy stored in the machine can exceed the permissible switching energy of a motor holding brake at the time of pulse inhibit and can thus destroy the brake when being applied!

Activate the brake in any case

When [C02582](#) = "0", the brake is immediately triggered to close to prevent the mechanics from being damaged.

Only activate brake below threshold for brake activation

When [C02582](#) = "1", the brake remains released until the threshold set in [C02581](#) for brake activation has been reached to protect the brake from excessive wear.

- The braking action only takes place due to the friction in the load mechanics.
- Only when the motor speed has reached the threshold for brake activation, the brake will be closed.



Stop!

Do not set the threshold for brake activation in [C02581](#) too high to protect the motor holding brake from wear!



Note!

For the encoderless motor control types (from software version V3.0) the following applies:

If V/f control without encoder or sensorless vector control is selected, there is no speed information for the controller in the case of pulse inhibit, therefore the threshold set in [C02581](#) for the brake activation is not effective in this case.

In order to avoid that the motor holding brake is closed in case of pulse inhibit, a waiting time for the brake activation can be parameterised in [C02593](#). In case of pulse inhibit, the motor holding brake is then only triggered to close after this application time has elapsed. ▶ [Speed watchdog](#) (□ 532)

11.12.5.2 Process when brake is released

The following process occurs when a basic function is requested which causes the drive to traverse:

1. The controller inhibit is deactivated.
2. The magnetic field required for the holding torque is created in the motor (is already available when a synchronous machine is used).
3. The feedforward control torque is loaded into the speed controller.
4. If the actual torque has reached 90 % of the feedforward control torque:
 - The output *BRK_bReleaseBrakeOut* is set to TRUE for releasing the brake.
 - Monitoring of the motor brake control module is deactivated temporarily.
 - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
 - The brake opening time starts to elapse.
5. After the brake opening time has elapsed:
 - The output *BRK_bBrakeReleased* is set to TRUE.
 - The requested basic function is enabled.
6. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
 - Monitoring of the motor brake control module is active again.
 - Monitoring of the status input is active again (if switched active via [C02583](#)).

11.12.5.3 Process when brake is closed

The following process occurs if the enable of the requested basic function for traversing the drive is deactivated again:

1. The drive is brought to standstill via the basic function "[Stop](#)", or, where required, also via the basic function "[Quick stop](#)".
2. When speed setpoint and actual speed value have fallen below the speed threshold set in [C02581](#):
 - The output *BRK_bReleaseBrakeOut* is set to FALSE for closing the brake.
 - The current torque is saved, so that, if necessary, it can be used for feedforward control during the next start.
 - Monitoring of the motor brake control module is deactivated temporarily.
 - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
 - The brake application time starts to expire.
3. After the brake closing time has elapsed and the corresponding state change of the status signal:
 - The output *BRK_bBrakeReleased* is reset to FALSE.
 - Controller inhibit set.
4. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
 - Monitoring of the motor brake control module is active again.
 - Monitoring of the status input is active again (if switched active via [C02583](#)).
 - Standstill monitoring is activated. ▶ [Standstill monitoring](#) (□ 531)

11.12.6 Mode 22: Automatic DC-injection braking

This function extension is available from software version V3.0!



Note!

Automatic DC-injection braking is only possible if V/f control or sensorless vector control is selected as motor control type in [C00006](#)!


If mode 22 has been selected in [C02580](#), DC-injection braking is executed automatically if the current speed setpoint falls below the speed threshold set in [C02581](#).

- The automatic is only effective in the function states "Drive is stopped", "Drive at standstill", "Quick stop active", and "Fault".
- DC-injection braking is executed for the brake closing time set in [C02589](#) with the braking current set in [C00974](#).
- After the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".




Danger!

If the braking current is set too low, or the application time is too short, controller inhibit is set and the drive becomes torqueless before being completely braked to standstill by means of DC-injection braking!



[11-42] Example 1: Speed follower active → stopping active (stopping time > brake closing time) → speed follower active

- If a basic function is requested again before the brake closing time has elapsed, DC-injection braking is interrupted and - if activated in [C00990](#) – the flying restart process is started and the basic function is activated:



[11-43] Example 2: Speed follower active → stopping active (stopping time > brake closing time) → speed follower active


Automatic DC-injection braking when quick stop is activated

DC-injection braking is activated automatically if a quick stop is triggered in the drive, e.g. via the basic function "[Quick stop](#)" or as a response to an error.

- A change-over to the "Quick stop active" function state is effected, and for the quick stop deceleration time set in [C00105](#) a DC-injection braking process with the braking current set in [C00975](#) is carried out.
- After this time has elapsed, a change-over to the braking current parameterised in [C00974](#) is carried out and DC-injection braking is continued with this braking current.
- After the brake closing time set in [C02589](#) has also elapsed, the basic function "Brake control" automatically sets controller inhibit.
- The DC-injection braking in this case is also carried out when the "Quick stop by trouble" error response is actuated; however, instead of the "Quick stop active" function state, the "Fault" function state is active, and the controller is in the "Quick stop by trouble active" device state.

11 Basic drive functions

11.12 Brake control



[11-44] Process example: speed follower is active → quick stop activation → speed follower is active



Note!

The quick stop braking current in [C00975](#) has to be set so that the drive can be decelerated from the maximum operating speed to standstill within the deceleration time for quick stop set in [C00105](#)!

11.12.7 Grinding the brake

This function may be required after the brake has been replaced. The holding torque specified in the data sheet is only reached if the friction partners are ground in after mounting.



Stop!

If this function is activated, the drive is automatically accelerated to the grinding speed parameterised in [C02596](#).

- The axis must move freely without driving against the travel range limitations.
- The maximally permissible friction energy of the brake must not be exceeded (observe the specifications of the manufacturer)!

$$W_{\text{total}}[\text{J}] \sim M_{\text{K}}[\text{Nm}] \cdot \frac{2\pi}{60} \cdot N[\text{min}^{-1}] \cdot t_{\text{total}}[\text{s}]$$

[11-45] Formula for estimating the friction energy during grinding process

Prerequisites

In order to be able to activate the grinding of the brake, the following conditions must be fulfilled:

- The grinding speed in [C02596](#) is set higher than 0 rpm.
- The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.




Note!

When grinding the brake, ensure that the motor shaft can be kept at speed against the closed holding brake.

- For this purpose, make sure that the maximum torque of the motor control ([C00057/2](#)) is higher than the holding torque of the brake.

Procedure

If all requirements mentioned before have been met, the grinding process can be started by setting the input *BRK_bBrakeGrindIn* to TRUE.



- After the grinding speed has been reached, the friction partners in the brake are ground by a pulse-type control.
- After the brake has been closed and opened ten times, the direction of rotation changes and grinding in the opposite direction is carried out.
- By resetting the input *BRK_bBrakeGrindIn* to FALSE the grinding process can be aborted.

[11-46] Sequence of the grinding operation

11.12.8 Carrying out brake test

This function can be used to check the holding torque of the brake.



Tip!

You can carry out this test in regular intervals, e. g. to detect a defect or wear of the brake at an early stage.



Note!

Due to possible deviations in the torque generation, the test of the holding torque cannot determine the holding torque exactly!

- The generated motor torque can deviate up to $\pm 15\%$ from the default value depending on temperature.
- The test torque is internally limited to the value of the motor reference torque ([C00057/2](#)). A higher parameterisation of [C02594](#) is automatically limited to this value.


Prerequisites

In order to be able to activate the brake test, the following requirements have to be met:

- The test torque in [C02594](#) is set higher than 0 Nm.
- The permissible angle of rotation is set greater 0° in [C02595](#), thus standstill monitoring is active. ▶ [Standstill monitoring](#) (📖 531)
- The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.

Procedure

If all requirements mentioned before have been met, the brake test can be started by setting the input *BRK_bBrakeTest* to TRUE.



[11-47] Sequence of the brake test

- The specified test torque is created via a ramp generator with an acceleration time of 1 s and held max. 4 s.
 - By this the motor shaft tries to rotate while the brake is applied.
- By resetting the input *BRK_bBrakeTest* to FALSE the brake test can be aborted.

Error behaviour

If during the brake test the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#), although the brake is engaged:


- The brake test is cancelled immediately and "Quick stop by trouble" is activated as error response to avoid a further rotation/acceleration of the drive.
- The error message "Motor brake: Angular drift with closed brake too high" is entered into the logbook.
- The status "position drift when brake is applied" is displayed for one cycle at the *BRK_dnState* status output via bit 21 and the status "brake error" is displayed via bit 15.
- The *BRK_bError* output is set to TRUE for one task cycle.

11 Basic drive functions

11.12 Brake control

11.12.9 Control of two motor holding brakes

The technical implementation is based on the control of an external relay by a digital output. The relay contact then switches an external 24-V supply for both motor holding brakes:



[11-48] Interconnection example for controlling two motor holding brakes



Tip!

From software version V7.0 onwards, two motor temperature sensors can be evaluated simultaneously via the two encoder inputs X7 and X8 when two motor are used (e.g. double motor for a storage and retrieval unit).

► [Temperature monitoring of a second motor](#) (📖 228)

11 Basic drive functions

11.13 Cam data management

11.13 Cam data management

This function extension is available from software version V3.0!

The basic function "Cam data management" provides different functions for the systemwide management of the cam data available in the memory module for a cam application.

- Cam data are motion profiles/characteristics, cam tracks, and position marks.
- The cam data required can either be created using the »Cam Editor« and transmitted to the controller by means of »Engineer«, or they can be directly entered via the parameters of this basic drive function if cam data have already been downloaded.




Note!

For the use of cam data in the controller, the licence level Motion Control TopLevel is required!

11.13.1 "Online" tab for cam data management

After an interconnection has been created via the electrical shaft, it is shown in the *Project view* with the axes assigned:



If you select the axis representing the 9400 HighLine controller under the electrical shaft, the **Online** tab for cam data management is provided in the *Workspace*:

Info	
A	Cam-data-compatible <ul style="list-style-type: none"> This property is set automatically for the controller if the controller supports cam data (licence level Motion Control TopLevel required). Note: The checkmark must not be removed, as otherwise the assignment to the cam data is lost!
B	Cam data status <ul style="list-style-type: none"> The first green LED for instance is lit if the cam data file in the project is active. When an online connection to the controller has been established, also the status of the cam data available in the controller is shown.
C	Display of the current memory distribution for the cam data. ▶ Memory distribution (559)
D	Configuration of the access protection for the cam data. ▶ Access protection (560)
E	Possibility for quickly updating the cam data in the controller (without having to transfer the complete application). ▶ Regenerating the cam data file and transferring it to the controller (562)

11.13.1.1 Memory distribution

From software version V5.0 there are three different storage modes for the distribution of the cam data memory in the controller. The specification of the storage mode is effected automatically by the »Engineer« when the cam data file is generated.



Note!

For controllers with a software version lower than V5.0 the memory distribution always corresponds to storage mode 1 (see following table), i. e. the max. size of the cam data file is limited to 256 kBytes.

Storage modes 2 and 3 automatically provide a greater memory for an extensive amount of cam data, however, in return certain functions are no longer supported (e. g. changing cam data via parameterisation).

Memory distribution of the cam data	Display in [bytes]	Storage mode		
		1	2*	3*
Memory module	-	262144 bytes (256 kBytes)	524288 bytes (512 kBytes)	1048576 bytes (1024 kBytes)
Internal RAM for quick download	C02901/1	262144 bytes (256 kBytes)	0 bytes	0 bytes
Internal RAM for online change	C02901/2	131072 bytes (128 kBytes)	262144 bytes (256 kBytes)	0 bytes
Internal RAM for cam data	C02901/3	131072 bytes (128 kBytes)	262144 bytes (256 kBytes)	524288 bytes (512 kBytes)

* Only from software version V5.0

Functions supported	Storage mode		
	1	2*	3*
Changing cam data via parameterisation	●		
Quick download to the RAM	●		
Online change	●	●	
Device command " Load cam data "	●	●	●
Device command " Save cam data "	●		
Device command " Calculate cam data "	●	●	●
Device command " Calculate cam data checksum "	●		

* Only from software version V5.0

11.13.1.2 Access protection

If required, the cam data can be protected against unauthorised or unintentional change by means of a three-stage access protection concept:

Step 1: Access protection deactivated

- There is no access protection for the upload/download of new cam data and the change of cam data via parameters.

Step 2: Access protection via user password

- The user password must be entered for the upload/download of new cam data and the change of password-protected cam data via parameters.

Step 3: Linking the cam data to the serial number of the memory module

- The user password must be entered for the upload/download of new cam data and the change of password-protected cam data via parameters.
- In addition, the serial number of the memory module must comply with the serial number given in »Engineer« for the cam data.



Note!

The settings for the access protection are firmly defined for the existing cam data and cannot be changed.

For a change of the settings the cam data have to be updated in »Engineer« and then transferred to the controller. These two actions can be carried out on the **Online** tab via the buttons **Generate cam data file** and **Transfer cam data to the device**.

▶ [Regenerating the cam data file and transferring it to the controller](#) (📖 562)



How to define a password for the cam data:

1. Click the lower **Password** button (for new password).
 - The *Change password* dialog box appears:

The dialog box titled "Change password" has a blue header. The main area is light beige and contains the text "Please enter your password for locking Cam-data of the drive". Below this text are two input fields: "Password:" and "Enter password again:". At the bottom right of the dialog box are two buttons: "OK" and "Cancel".

2. Enter desired user password.
3. Click **OK** to accept the entry and close the dialog box.

**How to change an existing password:**

1. Click upper **Password** button (for existing password).
2. Enter the existing user password in the *Change password* dialog box.
3. Click **OK** to accept the entry and close the dialog box.
4. Click the lower **Password** button (for new password).
5. Enter the new user password in the *Change password* dialog box.
6. Click **OK** to accept the entry and close the dialog box.

**Tip!**

An existing access protection via user password can be cancelled again by carrying out the steps described before for changing the password and simply leaving blank the input field for the new password.

**How to link the cam data to the serial number of the memory module:**

Go to the **Serial number** input field and enter the serial number of the memory module.

- When an online connection to the controller has been established, you can read out the serial number of the memory module in the controller by clicking the **Read from device** button.

**Tip!**

The linkage of the cam data to the serial number of the memory module can be cancelled again by carrying out the steps described before and simply leaving blank the **Serial number** input field.

11.13.1.3 Regenerating the cam data file and transferring it to the controller

If you transfer the parameter set or the application from »Engineer« to the controller, the cam data are also transferred automatically to the controller.

To only regenerate the cam data file and transferring it to the controller, after the cam data have been changed in the »Cam Manager« or the settings have been changed for access protection, carry out the following steps:



How to update the cam data:

1. Click on the **Generate cam data file** button on the **Online** tab to regenerate the cam data file for the controller.
 - The cam data status shown and the information with regard to the memory distribution on the **Online** tab are updated. The green LED behind "In the project" is lit now, which means that the cam data file in the project is active:

Cam data status	Time stamp for data generation	Generated data volume for next transfer
In Project	23.10.2008 07:51:24	9 kbytes
In RAM		
Processing		5 kbytes
In memory module		


When an online connection has been established to the controller:

2. To transmit the cam data to the controller, click the **Download cam data** button.
 - The new/altered cam data are accepted in the controller according to the online change mode set. ▶ [Online change mode](#) (□ 567)
 - The green LED behind "In the memory module" is now lit as well, which means that the cam data file in the memory module is also active:

Cam data status	Time stamp for data generation	Generated data volume for next transfer
In Project	23.10.2008 07:51:24	0 kbytes
In RAM	23.10.2008 07:51:24	
Processing	23.10.2008 07:51:24	5 kbytes
In memory module	23.10.2008 07:51:24	

11.13.2 Internal interfaces | "LS_CamInterface" system block

The **LS_CamInterface** system block provides the internal interfaces for cam data management in the function block editor.



Inputs

Identifier <small>DIS code data type</small>	Information/possible settings		
CAM_dnProductNumber <small>DINT</small>	Product number <ul style="list-style-type: none"> The basic function manages the product number for all cam FBs within the application. The product number is displayed in the »Cam Manager« in squared brackets after the product name. If the product number is to be defined via parameter instead, a corresponding user code must be created in the application and connected with this input. The highest product number to be created is shown in C02908. 		
CAM_bActivateProduct <small>BOOL</small>	Activate product <ul style="list-style-type: none"> The change-over to another product is caused by an event which is generated from the application. <table border="1" style="width: 100%; margin-top: 5px;"> <tr> <td style="text-align: center;">TRUE</td> <td>The product with the product number at input <i>CAM_dnProductNumber</i> is activated.</td> </tr> </table>	TRUE	The product with the product number at input <i>CAM_dnProductNumber</i> is activated.
TRUE	The product with the product number at input <i>CAM_dnProductNumber</i> is activated.		
CAM_bActivateNewData <small>BOOL</small>	Reload cam data from the backup memory (controlled acceptance) <ul style="list-style-type: none"> Only possible if the online change mode "10: Manual Activation" is set in C02905. If the online change mode "16: Automatic activation with CINH" (Lenze setting) or "15: Automatic activation" is set in C02905, the new cam data are accepted immediately after a download and this input has no function. The current status of the data acceptance is shown in C02906. <table border="1" style="width: 100%; margin-top: 5px;"> <tr> <td style="text-align: center;">TRUE</td> <td>Reload cam data from the backup memory.</td> </tr> </table>	TRUE	Reload cam data from the backup memory.
TRUE	Reload cam data from the backup memory.		

Outputs

Identifier DIS code data type	Value/meaning	
CAM_dnActiveProduct C02909 DINT	Product number of the currently active product	
CAM_bDownloadBusy BOOL	Status signal "Download/data change active" • The current status of the data acceptance is shown in C02906 .	
	TRUE	Currently the cam data in the RAM of the controller are changed. • For instance, due to parameter set transfer, device command C00002 = "501: Load cam data" or change of the cam data via parameters.
	TRUE↔FALSE	Download/data change completed. • In order to detect if the download/ the data change has been completed correctly, the <i>CAM_bError</i> error output should also be evaluated.
CAM_bNewDataAvailable BOOL	Status signal "New cam data available"	
	TRUE	The internal recalculation of the new/changed cam data is completed and the cam data are ready for acceptance. • The time when the new/alterred cam data are accepted depends on the online change mode set in C02905 . ▶ Online change mode (567) • In the Lenze setting the new/alterred cam data are accepted automatically as soon as the controller inhibit is set within the controller. • If the online change mode "15: Automatic activation" is set in C02905 , the new/changed cam data are accepted immediately after the internal recalculation and the TRUE signal is only pending for one task cycle.
	TRUE↔FALSE	The new/changed cam data have been accepted.
CAM_bError BOOL	"Fault" status signal	
	TRUE	An error has occurred (group signal).

11.13.3 Parameter setting

Short overview of the parameters for cam data management:

Parameters	Info	Effective in storage mode		
		1	2*	3*
C00198	Axis number	●	●	●
C02900	User Password	●	●	●
C02901	Cam storage capacity	●	●	●
C02902	Time stamp of cam data	●	●	●
C02903	GUID cam data	●	●	●
C02905	Online change mode	●	●	
C02906	Online change status	●	●	●
C02908	Number of products	●	●	●
C02909	Active Product	●	●	●
C02910	Product designation	●	●	●
C02911	Product Choice	●	●	●
C02912	Number of products	●		
C02919	Number of curve tracks	●		
C02920	Cam Track Choice	●	●	●
C02921	Cam Track Type	●		
C02922	Number of Cam Data Points	●		
C02923	Cam Data Point Choice	●	●	●
C02924	Change Cam Data Point X	●		
C02925	Change Cam Data Point Y	●		
C02926	Torque feedforward control value	●		
C02927	Auto Inc Cam Data Points	●	●	●
C02939	Number of Cont Tracks	●		
C02940	Cont Track Choice	●	●	●
C02941	Cam type	●	●	●
C02942	Number of Cont Data Points	●		
C02943	Cont Data Point Choice	●	●	●
C02944	Cont Pos X0	●		
C02945	Cont Pos X1	●		
C02946	Cont Time	●		
C02959	Number of Position Tracks	●		
C02960	Pos Track Choice	●	●	●
C02962	Number of Pos Data Points	●		
C02963	Pos Data Point Choice	●	●	●
C02964	Change Pos Data Point X	●		
C02965	Change Pos Data Point Y	●		

Greyed out = display parameter
 * Storage modes 2 and 3 are only available from software version V5.0. Parameters that are not effective are set to zero.

11.13.3.1 Password entry

If a password has been defined for the cam data in »Engineer«, the defined user password must be entered once to execute the following actions:

- Download of new cam data during operation
→ Entry of the existing password in »Engineer«.
- Change of the cam data via parameter setting
→ Entry of the existing password in [C02900](#).
- Loading/saving of the cam data
→ entry of the existing password in [C02900](#).



Note!

From software version V4.0 onwards, you do not need to enter a possibly existing user password ([C02900](#)) if you want to save the cam data.



Tip!

The access protection for the cam data can be configured on the **Online** tab. ▶ ["Online" tab for cam data management](#) (📖 558)

Validity

The user password entered in [C02900](#) is maintained until the next download, mains switching, or until reset by the user (logout).

- You can "log out" deliberately by entering an invalid password into [C02900](#).

Behaviour in case of invalid entry

If the user password is entered incorrectly three times, the cam data are blocked. A correct entry resets the number of the failed attempts.

To remove the blocking of the cam data, there are two possibilities:

- A. Resetting the parameters to the Lenze setting via device command [C00002](#) = "0: Load Lenze setting".
 - When the Lenze setting is loaded, the cam data are deleted.
 - Afterwards the cam data can be transferred to the device again.
- B. Transfer complete application to the device again.
 - The application available and the cam data are deleted and all data are transferred to the device again.

11.13.3.2 Online change mode

During running operation, new cam data can be downloaded from »Engineer« to the controller if the controller is in storage mode 1 or 2.

- If the cam data are provided with an access protection, the user password has to be entered first.
 - ▶ [Access protection](#) (📖 560)
- The time when the new/altered cam data are accepted depends on the online change mode set in [C02905](#).



Note!


If the controller is in storage mode 3, the "Online change" function is deactivated:

- The online change mode set in [C02905](#) is ineffective.
- In [C02906](#) the status "999: Online change deactivated" is displayed.
- For the download of new cam data, controller inhibit is required.
- The cam data are accepted immediately after download.

▶ [Memory distribution](#) (📖 559)

Mode 16: Automatic activation with CINH

In the Lenze setting, the online change mode "Automatic activation with CINH" is set in [C02905](#), i.e. the new cam data are accepted automatically as soon as the controller is inhibited.




[11-49] Online change mode "Automatic activation with CINH"

Mode 15: Automatic activation

In the online change mode "Automatic activation", the new cam data are accepted directly after the internal recalculation of the data from the application unit [unit] into the internal unit [increments] has been completed.


- The controller does not need to be inhibited for acceptance.



[11-50] Online change mode "Automatic activation"

Mode 10: Manual activation

In the online change mode "Manual activation", the new cam data are accepted when the `CAM_bActivateNewData` control input is set to TRUE.



[11-51] Online change mode "Manual activation"

11.13.3.3 Changing cam data via parameterisation

If required, the cam data (motion profiles/characteristics, cams, and position markers) can be changed via corresponding parameters if the controller is in storage mode 1. Except for the last interpolation point, all interpolation points of an electronic cam can be changed via the parameter access.

- If the cam data are provided with an access protection, the user password has to be entered in [C02900](#) first. ▶ [Access protection](#) (□ 560)
- **From software version V4.0 onwards**, the time stamp of the cam data is updated if the cam data are changed by parameter setting. This enables, for instance, the »Engineer« to recognise that the cam data of the »Engineer« project and those of the controller differ.



Note!

If the controller is in storage mode 2 or 3, the cam data cannot be changed via parameterisation. All parameters for change are ineffective and set to zero. ▶ [Memory distribution](#) (□ 559)

If the cam data of the controller have been changed by parameter setting, the [C00002](#) = "504: Calculate Cam Checksum" device command has to be executed afterwards. ▶ [Calculate cam data checksum](#) (□ 95)

Then the cam data can be converted into the internal format with the "503: Calculate Cam Data" device command or saved on the memory module in a powerfail-proof manner with the "502: Save Cam Data" device command. ▶ [Calculate cam data](#) (□ 94) / ▶ [Save cam data](#) (□ 92)

From software version V4.0 onwards, the changed cam data and the parameters can be saved together on the memory module in a powerfail-proof manner with the [C00002](#) = "11: Save start parameters" device command. ▶ [Save start parameters](#) (□ 52)



How to change an interpolation point in a curve (motion profile or characteristic):

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02920](#) and set the track number of the curve track to be edited.

Tip!

In [C02921](#) the curve type, and in [C02922](#) the number of interpolation points of the curve selected is shown.

3. Set the interpolation point to be edited in [C02923](#).
4. Change the desired parameters of the selected grid point:
 - [C02924](#): x position
 - [C02925](#): y position
 - [C02926](#): Torque feedforward control value (only in case of a motion profile with feedforward control.)

**Tip!**

[C02927](#) serves to activate a grid point auto increment if several successive grid points are to be changed.

- When the grid point auto increment is activated, it is automatically incremented to the next grid point every time the y position is written into [C02925](#) so that the specification of the grid point to be changed in [C02923](#) is only required once.

**How to change several successive grid points (auto increment):**

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02920](#) and set the track number of the curve track to be edited.

Tip!

In [C02921](#) the curve type, and in [C02922](#) the number of interpolation points of the curve selected is shown.

3. Set selection "1: Activate" in [C02927](#) to activate the grid point auto increment.
4. Set the grid point from which on the grid point auto increment is to be started in [C02923](#).
5. Set the following parameters for the grid point set in [C02923](#) in the given order:
 - [C02924](#): x position
 - [C02926](#): Torque feedforward control value
(only in case of a motion profile with feedforward control.)
 - [C02925](#): y position

After the y position is written into [C02925](#) it is automatically incremented to the next grid point.

6. Set the parameters for the next grid point in the same order:
 - [C02924](#): x position
 - [C02926](#): Torque feedforward control value
(only in case of a motion profile with feedforward control.)
 - [C02925](#): y position
7. Repeat step 4 until all grid points are changed.

Note: Do not change more grid points than available (depending on the start grid point). Changing a non-available grid point causes an error message!

**How to change a cam:**

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02940](#) and set the track number of the cam track to be edited.

Tip!

The cam type is displayed in [C02941](#) and the number of cams of the selected cam data is displayed in [C02942](#).

3. Go to [C02943](#) and set the cam to be edited.
4. Change the desired parameters of the selected cam:
 - [C02944](#): Cam position X0
 - [C02945](#): Cam position X1
 - [C02946](#): Cont Time (for position/time cams)

**How to change a position mark:**

1. Go to [C02911](#) and set the product number of the product to be edited.
2. Go to [C02960](#) and set the track number of the position track to be edited.

Tip!

In [C02962](#) the number of the position marks of the position data selected is shown.


3. Set the position mark to be edited in [C02963](#).
4. Change the desired parameters of the selected position mark:
 - [C02964](#): x position
 - [C02965](#): y position

11.13.4 Product/track change-over

Product change-over

The change-over to another product number is effected for all cam FBs within the application via the basic function "Cam data management".

- The change-over is effected via the input *CAM_bActivateProduct* on the basis of an event that is generated from the application.
- By setting the input *CAM_bActivateProduct* to TRUE, the product is activated with the product number at input *CAM_dnProductNumber*.




[11-52] Principle: Product change-over

Track switch-over

The change-over to another curve track, cam track, or position track, however, is individually effected via the input *dnTrackNumber* at the respective cam function block.

- For the two FBs *L_CamProfiler* and *L_CamContactor* it can be parameterised whether the track change-over is to be effected in the next zero crossing of the x axis or immediately (Lenze setting: in the next zero crossing).



[11-53] Principle: Track change-over

11.13.5 Invalid cam data due to changed machine parameters

This function extension is available from software version V4.0!

If one or more machine parameters affecting the internal scaling of the cam data are changed, the message "Cam Data: Invalidated due to change of mechanical data" (error number [0x00b80034](#)) is entered into the logbook and the error response "Warning" occurs.

- The cam data are no longer valid and have to be recalculated.
- The warning is automatically reset if the [C00002](#) = "503: Calculate Cam Data" device command is executed. ▶ [Calculate cam data](#) (📖 94)

Machine parameters affecting the internal scaling of the cam data:

Parameters	Info
C00006	Selection of the motor control
C00100	Resolution of an encoder revolution
C02520 / C02521	Gearbox factor - motor (if motor = reference source)
C02522 / C02523	Gearbox factor - position encoder (if position encoder = reference source)
C02524	Feed constant
C02570	Position control structure

11.13.6 Behaviour after mains switching

After mains switching, the cam data are loaded from the memory module into the controller between loading and start of the application.



Note!

During the initialisation no check of the user password takes place, but a check of the serial number of the memory module is carried out, if this access protection has been activated by the user in »Cam Designer«. If the serial number specified and the serial number of the memory module do not match, the cam data are not loaded.

- The "Cam data: serial number" error message is entered in the logbook.
- The "Warning locked" error response occurs.

If a download of cam data that was carried out before mains switching was not completed correctly, the previous cam data – if available – are loaded by the memory module.

- The "Cam data restored" error message is entered into the logbook.
- The "Fault" error response occurs.
- After the error is reset (acknowledged), operation with the previous cam data is possible.

11 Basic drive functions

11.14 Pole position identification

11.14 Pole position identification

This function extension is available from software version V7.0!



Danger!

In this basic function, the extent of the useable operating modes of the holding brake is restricted. Only the following operating modes function:

- Directly with brake module ([C02580, selection 1](#)) and
- Direct switching externally ([C02580, selection 11](#))

The device commands "Identify pole position (360°)" and "Identify pole position (min. motion)" serve to execute an identification of pole position to detect the pole position to the motor encoder currently activated in [C00495](#).

From software version V7.0 onwards, the identification of pole position is additionally available as a basic function in the form of the [LS PolePositionIdentification](#) system block.



Note!


An identification of pole position is only required:

- For servo control with synchronous motor of a third-party manufacturer.
- For servo control with synchronous motor and use of incremental encoders (TTL or sin/cos encoders as well as multi-pole pair resolvers).
- After changes of the motor feedback system, e.g. encoder exchange.

Detailed information on the identification of pole position can be found in the subchapter "[Pole position identification](#)" for the motor interface. ([131](#))

11.14.1 Internal interfaces | System block "LS_PolePositionIdentification"

The **LS_PolePositionIdentification** system block provides the internal interfaces for the basic function "Pole position identification" in the function block editor.



Note!

Ensure that the system block is called in a cyclic application task.

Basically, projects which only contain an unsolicited task and no cyclic task are not permissible!

Inputs

Identifier <small>DIS code data type</small>	Information/possible settings			
PPI_bEnable C02789/1 BOOL	Request control of basic function			
	<table border="0"> <tr> <td style="text-align: center;">TRUE</td> <td>If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs.</td> </tr> <tr> <td style="text-align: center;">TRUE↘FALSE</td> <td>An active identification of pole position is stopped, i.e. a change-over from the active "Identification of pole position active" function state back to the "Controller not ready" basic state is effected.</td> </tr> </table>	TRUE	If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs.	TRUE↘FALSE
TRUE	If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs.			
TRUE↘FALSE	An active identification of pole position is stopped, i.e. a change-over from the active "Identification of pole position active" function state back to the "Controller not ready" basic state is effected.			
PPI_bStart C02789/2 BOOL	For starting pole position identification			
	FALSE↗TRUE Pole position identification is started in the mode selected in C02786 .			
PPI_bLoadPolePosition C02789/3 BOOL	For starting pole position identification			
	FALSE↗TRUE The pole position angle applied at <i>PPI_dnPolePosition</i> is accepted in C00058/x . • The subcode to be described of C00058 depends on the motor encoder selected in C00495 .			
PPI_dnPolePosition C02788 DINT	Pole position angle in [°] with one decimal position • Value range: -179.9 ... +179.9 °			
PPI_bResetPolePosition C02789/4 BOOL	For resetting status "Pole position known"			
	FALSE↗TRUE The status outputs <i>PPI_bDone</i> and <i>PPI_bPolePositionAvailable</i> are reset to FALSE.			

Outputs

Identifier DIS code data type	Value/meaning
Ppi_dnState C02787 DINT	Status (bit coded) <ul style="list-style-type: none"> • When the basic function is not enabled, all bits are set to "0". • Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Pole position identification active.
	Bit 2 Pole position identification completed.
	Bit 14 Pole position known.
PPI_bEnabled C02789/5 BOOL	Status signal "Basic function is enabled"
	TRUE Pole position identification via the control inputs is possible. <ul style="list-style-type: none"> • The <i>PPI_bEnable</i> enable input is set to TRUE and the controller is in the "Pole position identification active" function state.
PPI_bActive C02789/6 BOOL	Status signal "Basic function is active"
	TRUE Pole position identification is active. <ul style="list-style-type: none"> • Output is reset to FALSE if the <i>PPI_bStart</i> input is reset to FALSE, controller enable is deactivated, or an error has occurred.
PPI_bDone C02789/7 BOOL	Status signal "Basic function is ready"
	TRUE Pole position identification is completed. <ul style="list-style-type: none"> • Output is reset to FALSE when input <i>PPI_bStart</i> is reset to FALSE.
PPI_bError C02789/8 BOOL	"Fault" status signal
	TRUE An error has occurred (group signal).
PPI_bPolePositionAvailable BOOL	Status signal "Pole position is known"
	TRUE The drive knows the pole position. <ul style="list-style-type: none"> • The value written into C00058/x corresponds to the pole position (x depends on the motor encoder selected in C00422).

11 Basic drive functions

11.14 Pole position identification

11.14.2 Parameter setting

- Parameterisation dialog in »Engineer«: Tab **Application parameters** → Dialog level *Overview* → *All basic functions* → *Pole position identification*
- Short overview of parameters for pole position identification:

Parameters	Info
C02785	Activation of PPI
C02786	Mode of PPI
C02787	Ppi_dnState
C02788	PolePosition Setpoint
C02789	PolePositionIdentification: Dig. signals

Greyed out = display parameter

11.14.3 Execution of the pole position identification

Prerequisites

- The controller inhibit is active.
- The controller has the "Controller not ready" function state.
- The basic function "Pole position identification" is part of the active application.
- No other basic function is active.

Activate basic function

To request the control via the basic function, the *PPI_bEnable* enable input in the application must be set to TRUE.

- If no other basic function is active, a change-over to the "Identification of pole position active" function state is effected and an identification of pole position can be carried out via the control inputs.
- A successful change to the function state "Pole position identification active" is displayed by a TRUE signal at the *PPI_bEnabled* status output.

For starting pole position identification**Danger!**

The machine must not be braked or blocked during the pole position identification! For this reason, the pole position identification is not permitted for hanging loads!

During the pole position identification the rotor aligns itself. The motor shaft moves by max. one electrical revolution which causes the corresponding movement of the connected mechanical components!

**Stop!**

Check the correct parameterisation of the max. motor current monitoring ([C00619](#) and [C00620](#)) before carrying out the pole position identification to prevent the motor from being permanently damaged.

By setting the *PPI_bStart* control input to TRUE, the pole position identification is started in the mode selected in [C02786](#).

- The procedure starts with controller enable, if
 - a synchronous machine is selected,
 - no other identification is active,
 - no error has occurred, and
 - no test mode is activated.
- If one of the above conditions is not met, the procedure is cancelled and the corresponding device command status is indicated via *PPI_dnState*.

**Note!**


Detailed information on the identification of pole position can be found in the subchapter "[Pole position identification](#)" for the motor interface. ([131](#))

Deactivation


When the *PPI_bEnable* enable input is reset to FALSE, an active pole position identification is stopped.

- If the pole position identification is aborted, no change is made in [C00058/x](#).
- The *PPI_bEnabled* status output is reset to FALSE and a change-over from the active "Pole position identification active" function state back to the basic "Controller not ready" state is carried out".

11.14.4 Signal characteristics



[11-54] Signal characteristic 1: Normal procedure of the pole position identification



[11-55] Signal characteristic 2: Load pole position

11 Basic drive functions

11.14 Pole position identification



[11-56] Signal characteristic 3: Reset pole position

11.14.5 Deactivating a known pole position

The following describes the circumstances that cause a deactivation of an already known pole position by changing certain parameter settings. The pole position status *PPI_bPolePositionAvailable* changes from TRUE to FALSE due to the change.

Changing the type of motor control (C00006)

Initial situation	Parameter change
<ul style="list-style-type: none"> • <i>PPI_bPolePositionAvailable</i> = TRUE • Motor control (C00006) = <ul style="list-style-type: none"> • "2: SC: Servo control async. motor" or • "4: SLVC: Sensorless vector control" or • "6: VFCplus: V/f control" or • "7: VFCplus: V/f control" 	In C00006, the motor control "1: SC: Servo control sync. motor" is set.

Changing relevant motor data

Initial situation	Parameter change
<i>PPI_bPolePositionAvailable</i> = TRUE	One of the following parameters is changed: <ul style="list-style-type: none"> • Rated motor speed (C00087) • Rated motor frequency (C00089) • Rated motor voltage (C00090)

Changing relevant encoder data

Initial situation	Parameter change
<i>PPI_bPolePositionAvailable</i> = TRUE	One of the following parameters is changed: <ul style="list-style-type: none"> • Resolver - number of pole pairs (C00080) • Encoder - number of increments (C00420) • Encoder type (C00422) • TTL encoder signal evaluation (C00427) • Motor encoder selection (C00495)

Behaviour after mains ON

Initial situation 1	Behaviour after mains ON
<ul style="list-style-type: none"> • <i>PPI_bPolePositionAvailable</i> = TRUE • Motor control (C00006) = "1: SC: Servo control sync. motor" • Resolver - number of pole pairs (C00080) > 1 	<i>PPI_bPolePositionAvailable</i> is only reset to FALSE if: <ul style="list-style-type: none"> • Motor encoder selection (C00495) = "0: Resolver to X7" AND <ul style="list-style-type: none"> • The number of motor pole pairs are (C00059no integer multiple of the number of resolver pole pairs (C00080).

Initial situation 2	Behaviour after mains ON
<ul style="list-style-type: none"> • <i>PPI_bPolePositionAvailable</i> = TRUE • Motor control (C00006) = "1: SC: Servo control sync. motor" • Encoder type (C00422) = <ul style="list-style-type: none"> • "0: Incremental encoder (TTL signal)" or • "1: Sine/Cosine encoder" • Motor encoder selection (C00495) = "1: Encoder to X8" 	<i>PPI_bPolePositionAvailable</i> is reset to FALSE.

Behaviour after encoder error

Initial situation	Behaviour after encoder error
<ul style="list-style-type: none"> • <i>PPI_bPolePositionAvailable</i> = TRUE • Motor control (C00006) = "1: SC: Servo control sync. motor" • Encoder type (C00422) = <ul style="list-style-type: none"> • "0: Incremental encoder (TTL signal)" or • "1: Sine/Cosine encoder" or • "2: Absolute value encoder (Hiperface)" or • "3: Absolute value encoder (EnDat)" or • Motor encoder selection (C00495) = "1: Encoder to X8" 	<i>PPI_bPolePositionAvailable</i> is reset to FALSE.

Behaviour after resolver error

Initial situation	Behaviour after resolver error
<ul style="list-style-type: none"> • <i>PPI_bPolePositionAvailable</i> = TRUE • Motor control (C00006) = "1: SC: Servo control sync. motor" • The number of motor pole pairs are (C00059) no integer multiple of the number of resolver pole pairs (C00080). • Motor encoder selection (C00495) = "0: Resolver to X7" 	<i>PPI_bPolePositionAvailable</i> is reset to FALSE.

12 Oscilloscope

The oscilloscope function integrated in the Servo Drives 9400 HighLine can be used as support for commissioning, maintenance and troubleshooting. The oscilloscope function is operated via a user interface in the engineering tool.

Typical applications

- Graphic display of measured variable (e.g. speed setpoint, actual speed value and torque)
- Detection of process values without additional measuring instruments (e.g. oscilloscope, voltmeter and ammeter)
- Convenient documentation for fine tuning of control circuits or parameter changes of the Servo Drives 9400 HighLine

Special features

- Recording and saving measured values in the Servo Drives 9400 HighLine
- Simultaneous measuring on eight independent channels
- Measuring fast and slow signals by means of adjustable sample rate
- Triggering on channel, variable or system event
- Detecting measured values before and after the trigger event
- Transferring measured values to the Engineering PC for the purpose of graphic display and evaluation in the engineering tool
- The measured values represented in the form of curves can be optionally shown and hidden, represented in any colour or overlaid with the signal characteristic of other variables recorded.
- Cursor and zoom function for the measurement analysis
- Saving & loading oscilloscope configurations on the Engineering PC
- Export of measured values via the clipboard for further processing
- Linking channel values with arithmetic operations (addition, subtraction and multiplication)
- Simple signal analysis by frequency transformation of time signals with FFT ("Fast Fourier Transformation").

12.1 Functional description

When an online connection to the Servo Drives 9400 HighLine has been established, use the oscilloscope user interface of the engineering tool to set the trigger condition and the sample rate and select the signal sources to be recorded. Here, "signal sources" are the internal output signals of the function, system, application and port blocks.

The values are validated after each input acknowledgement by the "Return" key. If the check shows invalid settings, the oscilloscope triggers an error.

With an online connection, the measured values contained in the Servo Drives 9400 HighLine are transferred to the engineering tool and graphically presented on the oscilloscope user interface as soon as the measurement has been completed.

12.2 Technical data

Oscilloscope function of Servo Drives 9400 HighLine	
Number of channels	1 ... 8
Depth of the measured value memory	Max. 16384 measured values, depending on the number of channels and the size of the variables to be recorded.
Data width of a channel	1 ... 4 bytes, corresponding to the size of the variables to be recorded
Sampling rate	1 ms or a multiple of it. Increased sampling rates of 62.5 µs or 250 µs are possible.
Max. time base	8 channels 32 bits each ≙ 26 hours
Max. recording time	8 channels 32 bits each ≙ 10 days
Memory capacity	32768 bytes
Trigger level	Corresponding to the value range of the signal sources to be triggered
Trigger selection	Immediate triggering, rising/falling edge, signal change
Trigger delay	-100 % ... +400 %
Trigger source	Channel 1 ... 8: <ul style="list-style-type: none"> • Any application variable • Motor control variables • System events • Internal variables

12.3 Operation

This chapter informs you step by step on how to record signal characteristics of variables in the Servo Drives 9400 HighLine using the oscilloscope and then present, analyse, document and process them in the oscilloscope.

**Note!**

The configuration of the oscilloscope and the start of recording are only possible when an online connection has been established to the Servo Drives 9400 HighLine.

12.3.1 User interface

The oscilloscope user interface is available in the following Lenze engineering tools:


<input checked="" type="checkbox"/> »Engineer« from version 2.16	<input type="checkbox"/> »PLC Designer«	<input checked="" type="checkbox"/> »EASY Starter« from version 1.9
--	---	---



How to go to the oscilloscope user interface:













1. Go to the *Project view* and select the Servo Drives 9400 HighLine.
2. Select the **Oscilloscope** tab from the *Workspace*.

The oscilloscope user interface contains the following control and function elements:



- | | |
|--|--|
| <ul style="list-style-type: none"> A Oscilloscope toolbar B Oscillogram selection C Channel list <ul style="list-style-type: none"> ▶ Selecting the signal sources to be recorded D Status bar E Recruitment | <ul style="list-style-type: none"> F Last settings G Import settings from a loaded oscillogram or an oscillogram file H Trigger settings I Input fields for <ul style="list-style-type: none"> ▶ Selecting the recording time/sample rate J Start recording / stop <ul style="list-style-type: none"> : Input field for comments |
|--|--|

Oscilloscope toolbar

Symbol	Job title
	Loading the oscillogram file (📖 601)
	Upload recorded oscillogram from device <ul style="list-style-type: none"> • Transmit values from the measured value memory of the Servo Drives 9400 HighLine to the Engineering PC. • Only possible when an online connection has been established to the Servo Drives 9400 HighLine.
	Saving the oscillogram in a file (📖 600)
	Copy to clipboard: Copy as text Copy as picture Copy as table Copy as raw value <ul style="list-style-type: none"> • For documentation purposes, it is possible to copy the measured value of an oscilloscope as a table or, alternatively, the oscilloscope user interface as a picture, to the clipboard for use in other programs.
	Printer settings Print view Print
	Activate zoom function ▶ Adjusting the representation (📖 596)
	Show cursor
	Automatically scale vertically <ul style="list-style-type: none"> • Set all Y positions to zero • Arrange all curves above one another: The Y positions are evenly distributed over the entire vertical range.
	Activate zoom function ▶ Adjusting the representation (📖 596)
	Start recording (📖 595) <ul style="list-style-type: none"> • Transfer settings to the device • Activate trigger
	Stop recording
	Oscilloscope settings <ul style="list-style-type: none"> • Cyclic recording of oscillograms • Always load oscillograms after recording is completed without a query

12.3.2 Selecting the signal sources to be recorded

The oscilloscope supports up to eight channels. Thus, the **channel list** can record maximally eight signal sources.

Use the **channel list** to configure the signal sources to be recorded:

Ch	On	Inv	Name	Context	yPos I	yPos II	▲ ΔyPos	Unit	AS	1/Div	Offset	Position
1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voltage.dnActualMotorVoltage					V	<input checked="" type="checkbox"/>	100	0	0
2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voltage.dnMotorVoltageLimit					V	<input checked="" type="checkbox"/>	100	0	0
3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Current.dnActualDirectCurrent					A	<input checked="" type="checkbox"/>	100	0	0
4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Torque.dnActualMotorTorque					Nm	<input checked="" type="checkbox"/>	100	0	0
5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Speed.dnActualMotorSpeed					rpm	<input checked="" type="checkbox"/>	100	0	0
6	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Speed.dnOutputPosCtrlMotor					rpm	<input checked="" type="checkbox"/>	100	0	0
7	<input type="checkbox"/>	<input type="checkbox"/>							<input type="checkbox"/>			
8	<input type="checkbox"/>	<input type="checkbox"/>							<input type="checkbox"/>			

Designation	Meaning
-	Curve colour for representation in the oscillogram • A double-click on the colour area of the channel serves to set a user-defined colour.
Ch	Channel number
To	Cam visible / invisible
Inv	Inversion yes / no
Name	Name of the signal source
Context	Channel representation with task reference • Channel representation with task selection: • If the selected task is active at the time of recording, the value is taken from the input image of the selected task. • If the selected task is not active at the time of recording, an invalid value is recorded. There will be a gap in the graph. • Channel representation without task selection: • The current value of the variables is used without task reference at the time of recording.
yPos I	y position of cursor I
yPos II	y position of cursor II
ΔyPos	Difference of the y positions of both cursors • Difference = yPos II - yPos I
Unit	Unit of the signal source
AS	Select/deselect channel for automatic scaling
1/Div	Vertical scaling factor
Offset	Offset value • The offset value is subtracted from the recorded raw value before scaling is executed. This serves, for instance, to make very slight value fluctuations visible within one constantly very high recording value (e.g. harmonics with low amplitude).
Position	Position value • The position value determines the vertical position of the zero point of the y axis of a curve with regard to the vertical curve scale (- 5 ... + 5).

**How to select a signal source for recording:**

1. Double-click a non-assigned line in the **channel list** to open the *Select signal source* dialog box.
 - Double-clicking an already pre-assigned selection enables you to assign it with another signal source.
2. Select a new variable in the *Select signal source* dialog box.
3. Click the **OK** button.
 - The dialog box is closed and the selection is accepted.

**How to delete a selection:**

1. Go to the **channel list** and click the signal source to be removed.
2. Right-click the *context menu* to open it.
3. Select the **Delete signal source** command in the *context menu*.

You can add so many signal sources for the recording until all eight channels are assigned.


12.3.3 Selecting the recording time/sample rate



How to select the recording time and the sample rate:

1. Select the desired time base from the **time base** list field.
 - The current time base setting multiplied by ten results in the recording time.
 - Since the measured data memory of the Servo Drives 9400 HighLine has a limited capacity, usually a compromise is made between sample rate and recording time.
2. Enter the desired sampling rate in [ms] in the **sampling rate** input field.

Pressing the " ..." button next to the **Sampling rate** input field opens the *Sampling rate* dialog box. Here, you can also select the option **Increased sampling rate**:



Note!

When the option **Increased sampling rate** is selected, only integer multiples of $1/(\text{sampling rate in ms})$ are detected by the system.

- Since a complete representation in the oscillogram ($10 * 1/(\text{sampling rate in ms}) * (\text{horizontal resolution in ms/Div})$) requires + 1 measured values, but due to system-dependent reasons only integer multiples of $(1 / (\text{sampling rate in ms}))$ can be recorded, 1 ... 3 measured values may be missing at the left or right edges of the oscillogram. The displayed curve then ends before the end or starts after the start of the oscillogram.
- The curve that is recorded is not extended or compressed.

12.3.4 Selecting the trigger condition

Use the trigger condition to define when recording should start in the Servo Drives 9400 HighLine. The oscilloscope offers various trigger conditions for controlling how the measured values are recorded.



If the **Last settings** tab is in the foreground, click the **Settings** tab to show the input fields for configuring the trigger condition. The **Settings** tab contains the **Import settings** button for importing settings from a loaded oscillogram.


setting	Job title
Signal source	Selection of the trigger source
Variable	Selection of an application variable or a motor control variable as signal source
Channel	The oscilloscope triggers on a channel configured in the channel list .
System event	The following system events serve as trigger source: <ul style="list-style-type: none"> • Fault • Warning • Error • Quick stop by trouble • Any system event
Direct trigger	No trigger condition. Recording commences as soon as you press the Start recording button, if Activate trigger has been activated in the dropdown menu.
Value	Value from which on triggering is activated.
Deceleration	Time delay between recording and trigger event. Unit: [%]
Trigger delay	To detect signals that occur before the trigger event (e.g. values responsible for causing the event), enter a negative delay time. <div style="text-align: center;"> </div> <p>In the oscillograph, the trigger time is marked by a dotted line. If you set a negative trigger delay, make sure that the recording memory contains the required values at the time of the trigger event. To ensure this, the settings must be transferred to the device far enough in advance of the trigger event.</p> <p>To detect signals that occur a certain time after the trigger event, enter a positive delay time.</p> <div style="text-align: center;"> </div>


setting	Job title
Edge	Three trigger types are available:
Positive edge	First, the selected trigger value must be fallen below and then exceeded in order that the trigger is activated.
Negative edge	First, the selected trigger value must be exceeded and then fallen below in order that the trigger is activated.
Change	For triggering on a Boolean signal source: <ul style="list-style-type: none">• Trigger activation requires a state change. For triggering on a different signal source: <ul style="list-style-type: none">• The current value must be different than the last value in order that the trigger is activated.

12.3.5 Start recording

The following options are available in the dropdown menu:

- **Transfer settings to the device**
 - All oscilloscope settings are written to the device.
- **Activate trigger**
 - Actual recording from the device is only enabled if this option is activated.
 - The **Oscilloscope** tab displays the recording.

When you press the **Start recording**  button, only the actions that have been activated in the dropdown menu (signalled by a checkmark) will be executed.

- With the engineering tool default setting, both options are active. When you press the **Start recording**  button, both actions will be executed one after the other.
- There is always at least one active option.

Start recording after the trigger or scan settings are changed

If the trigger or scan settings have been changed on the **Oscilloscope** tab, an exclamation mark will appear on the **Start recording** button:




After the configuration has been changed, it is transferred to the device by opening the dropdown menu and activating **Transfer settings to the device**.

12.3.6 Cyclic recording



How to record oscillogram cyclically:

1. Click the  icon in the *oscilloscope toolbar* to open the **Oscilloscope settings** dialog box [▶ Oscilloscope toolbar](#) (📖 589).
2. In order that the recording process is restarted automatically after the upload of an oscillogram, set the checkmark accordingly.
 - Cyclic recording is only possible for time base values ≥ 500 ms.


For monitoring certain situations, this serves, for instance, to obtain the increased view of the interesting part of a characteristic even after the cyclic update, as originally zoomed.








12.3.7 Adjusting the representation

After the variable values have been recorded and the oscillogram has been transferred to the PC, it is visualised. If required, the representation can now be adjusted by using the zoom or the automatic scaling function.

Zoom function



Go to the *oscilloscope toolbar* and click the  icon to activate the zoom function
 ▶ [Oscilloscope toolbar](#) (📖 589)


Zoom function	Procedure	
Zoom selection		Hold down the left mouse button and draw the oscillogram section to be zoomed:  <ul style="list-style-type: none"> • While being drawn, the selection is shown with a frame. • When the left mouse button is released, the selection is zoomed in the oscillogram.
Horizontal stretching		Hold down the left mouse button and move the mouse pointer on the horizontal scale to the left to stretch the shown selection from the right edge.
		Hold down the right mouse button and move the mouse pointer on the horizontal scale to the right to stretch the shown selection from the left edge.
Moving the mouse pointer in opposite direction continuously reduces the stretching.		
Vertical stretching		Hold down the left mouse button and move the mouse pointer on the vertical scale to the bottom to stretch the shown selection from the top.
		Hold down the right mouse button and move the mouse pointer on the vertical scale to the top to stretch the shown selection from the bottom.
Moving the mouse pointer in opposite direction continuously reduces the stretching.		
Return to original representation		Click the right mouse button in the oscillogram to return step by step to the original representation.


Automatic scaling function

Use the automatic scaling function to automatically scale and reposition the representation of selectable signal characteristics in the oscillogram and reset the offset to "0".



How to carry out automatic scaling:

1. Activate the automatic scaling for each channel in the **channel list** by a checkmark in the "AS" column.
2. Go to the *oscilloscope toolbar* and click the  icon to activate the automatic scaling function for the activated channels.

3. Click the **OK** button.
 - The dialog box is closed and the selected channels/signal sources are scaled automatically.
4. Go to the *oscilloscope toolbar* and click the arrow next to the  symbol to set all the displayed curves to the Y position "0". This way, the curves are displayed "above one another".



How to carry out scaling manually per channel:

1. Go to the **Channel list** and click the entry to be changed in the "Unit" column (double-clicking an empty line has no effect.)
 - The dialog for entering the scaling opens which, as can be seen here in the example, allows for the entry of the lower and upper limit and the unit:

2. Enter the lower limit, the upper limit and the unit.
 - On the right side, any scaling values can be entered as upper and lower limit.
 - On the left side of the dialog, the limits of the data type of the recorded value are displayed.
3. Click the **OK** button.
 - The dialog box is closed.

There are variables the scaling of which depends on a parameter setting at the recording time (e.g. [C00100](#)). For these variables, the "Update scaling after oscillogram upload" option can be selected in the "Scaling" dialog.

If this option is active (box checked), the scaling settings "lower limit" and "upper limit" are automatically reset in the device according to the respective parameter value (e.g. [C00100](#)) each time an oscillogram is uploaded.



The option is automatically deactivated as soon as a value has been entered manually into the "lower limit" or "upper limit" field - the box is unchecked in the option.

12.3.8 Cursor function: Reading individual measured values

In addition to the zoom and scaling function, the oscilloscope offers a "cursor function" that can be used to display individual measured values of a selectable channel or the difference between two measured values.



How to use the cursor function:

1. Go to the *oscilloscope toolbar* and click the  icon to activate the cursor function.
 - Another  button is then shown which enables the centering of two independent and movable measuring lines.
 - The status bar displays the position of both measuring lines and the difference between them.
2. Select the channel for which individual measured values are to be indicated from the **Channel** list field.
3. Hold down the left mouse button and drag the red vertical measuring line to the desired position.
 - The active measuring line is represented by a continuous line, the inactive measuring line is represented by a dashed line.
 - If you click the inactive measuring line, it automatically becomes active.
 - The value measured at the position of the active measuring line is indicated in the value group box.
 - The difference between the values measured at the two measuring lines is indicated in the Differential value group field.
 - Comparing peak values: Several values displayed in the oscillogram can be compared by means of a horizontal measuring line. This measuring line is automatically generated based on the current cursor position and thus cannot be moved separately.

12.3.9 Last settings

All information included in the **Last settings** tab refer to the oscillogram loaded into the device:

Last settings	
Uploaded from device	
-	
Trigger	
Signal source	
-	
Value	
-	
Edge	Delay
-	-
Scan	
Sample rate	Time base
-	-

The contents cannot be changed.

12.4 Managing oscillograms (measured data records)

If several oscillograms are loaded in the oscilloscope at the same time, the oscillogram to be displayed is selected via the corresponding tab below the toolbar. In general, the following oscillograms are to be distinguished:

Device oscillogram

The device oscillogram is the only oscillogram which can be used to establish a connection to the target system to carry out an oscilloscope measurement.

MERGE oscillogram

If two or more oscillograms are loaded in the oscilloscope, a "MERGE" tab is available.

- In the merge tab, several characteristics from the currently loaded data records can be overlaid, e.g. to compare signal characteristics from different recordings. ▶ [Overlay function](#) (📖 603)

Loaded oscillogram

An oscillogram loaded from a file.

12.4.1 Commenting the oscillogram

The **Comments** text field serves to enter a comment on the selected oscillogram.

- If you execute the [Saving the oscillogram in a file](#) command, the comment is saved together with the oscillogram in the file.

12.4.2 Saving the oscillogram in a file

After the signal sources to be recorded have been selected and the required settings have been entered, you can save the configuration and recording, if already executed, for future use in the project or export them to a file.




Note!

The reuse of a saved configuration is only reasonable for devices of the same type, as otherwise due to a scaling of the oscilloscope channels that is not adapted, incorrect values are displayed!



How to save an oscillogram in the project:

1. Click the  icon in the *oscilloscope toolbar*.
 - The *Open oscillogram file* dialog box is displayed.
2. Specify a file name in the **File name** input field.
3. Click the **Filing in the project** button.
 - The dialog box is closed and the current oscillogram is filed in the project.




Note!

The oscillogram is only saved if the entire project is saved!



How to save an oscillogram as external file:

1. Click the  icon in the *oscilloscope toolbar*.
 - The *Open oscillogram file* dialog box is displayed.
2. Press the **Save as external file ...** button.
 - A new window opens in which the directory and the file name for the oscillogram to be saved have to be specified.
3. Click the **Save** button.
 - The dialog box is closed and the current oscillogram is saved.

12.4.3 Loading the oscillogram file

Configurations/oscillograms already saved can be reloaded into the oscilloscope any time, e.g. for the overlay function.




Note!

The reuse of a saved configuration is only possible for devices of the same type, as otherwise due to a scaling of the oscilloscope channels that is not adapted, incorrect values are displayed!




How to load an oscillogram file from the project:

1. Click the  icon in the *oscilloscope toolbar*.
 - The *Load oscillogram file* dialog box appears.
2. Select the file to be loaded from the upper list field.
3. Click the **OK** button.
 - The dialog box is closed and the oscillogram file is accepted.



How to load an oscillogram file from an external file:

1. Click the  icon in the *oscilloscope toolbar*.
 - The *Load oscillogram file* dialog box appears.
2. Press the **Load from external file...** button.
 - A new window opens in which the directory and the file name for the oscillogram file to be loaded have to be selected.
3. Click **Open**.
 - The dialog box is closed and the oscillogram file is loaded.
 - The oscillogram is displayed on an additionally appearing tab.
 - If the configuration to be loaded contains signal sources that are no longer available in the device, these variables are automatically removed from the configuration.

12.4.4 Importing settings from another loaded oscillogram

Pressing the **Import settings** button opens a dialog box containing the following possible settings:

- Select an oscillogram for importing the settings
 - By default, the settings from the oscillograms currently loaded in the oscilloscope are provided.
- Select the oscillogram file of the project to import the settings

This setting is only available for the »Engineer« from version 2.16 onwards!

 - One or several oscillogram files saved in the project (*.los) are provided. Their file name and the time of upload from the device are given.
- Import oscillogram settings from oscillogram file
 - You can navigate to the respective oscillogram file on the file level of the PC by pressing the "..." button under this menu item.

12.4.5 Overlay function


The overlay function serves to lay several characteristics from the currently loaded oscillogram files on top of each other, e.g. to compare signal characteristics from different recordings.


- If two or more oscillograms are loaded in the oscilloscope, e.g. the device oscillogram and an oscillogram previously saved in the project, a "MERGE" tab is available.
- If the MERGE tab is selected, the desired characteristics to be overload or compared can be selected from the loaded files in the **channel list**.
- If a device oscillogram is used in the merge tab, an update is carried out in the MERGE oscillogram in case of a renewed recording.
- Removing signal sources from the device oscillogram causes the characteristics in the MERGE oscillogram to be deleted.

12.4.6 Deleting an oscillogram file saved in the project



How to delete an oscillogram file saved in the project:

1. Click the  icon in the *oscilloscope toolbar*.
 - The *Load oscillogram file* dialog box appears.



2. Select one or several oscillogram files from the upper list field.
3. Press the **Delete selected file...** button.
 - The selected file(s) is/are deleted and the dialog box is closed.

12.5 Variables of the motor control (oscilloscope signals)

The system variables of the internal motor control listed in the following table can be recorded with the oscilloscope for diagnostic and documentation purposes.



Note!

In comparison to all other variable values, the system variables of the internal motor control have a cycle offset of 2 ... 3 ms!



Tip!

The exact position of a variable in the motor control can be obtained from the corresponding signal flow.

Variable of the motor control	Meaning
▶ Signal flow - servo control for synchronous motor (162) ▶ Signal flow - servo control for asynchronous motor (164)	
Common.dnActualFlux	Actual flux value
Common.dnFluxSet	Flux setpoint
Current.dnActualCurrentPhaseU	Actual motor current (phase U)
Current.dnActualCurrentPhaseV	Actual motor current (phase V)
Current.dnActualCurrentPhaseW	Actual motor current (phase W)
Current.dnActualDirectCurrent	Actual D current
Current.dnActualQuadratureCurrent	Actual Q current
Current.dnDirectCurrentSet	D current setpoint
Current.dnQuadratureCurrentSet	Q current setpoint
Torque.dnActualMotorTorque	Actual torque
Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter 2 input
Voltage.dnActualDCBusVoltage	Current DC-bus voltage
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnOutputQuadratureCurrentCtrl	Q-output voltage of the current controller
Voltage.dnOutputDirectCurrentCtrl	D-output voltage of the current controller
Voltage.dnDirectVoltage	D voltage
Voltage.dnQuadratureVoltage	Q voltage

Variable of the motor control	Meaning
▶ Signal flow - sensorless vector control (📖 183)	
Common.dnActualFlux	Actual flux value
Current.dnActualDirectCurrent	Actual D current
Current.dnActualQuadratureCurrent	Actual Q current
Current.dnDirectCurrentSet	D current setpoint
Current.dnQuadratureCurrentSet	Q current setpoint
Frequency.dnActualRotatingFieldFrequency	Current field frequency
Frequency.dnActualSlipFrequency	Actual slip frequency
Speed.dnActualMotorSpeed	Actual speed value
Torque.dnTorqueSetpoint	Torque setpoint
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnDirectVoltage	D voltage
Voltage.dnQuadratureVoltage	Q voltage
▶ Signal flow - V/f control (📖 199)	
▶ Signal flow for closed loop V/f control (📖 201)	
Current.Current.dnActualMotorCurrent	Actual motor current
Current.dnActualQuadratureCurrent	Actual Q current
Frequency.dnActualRotatingFieldFrequency	Current field frequency
Frequency.dnActualSlipFrequency	Actual slip frequency
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnSpeedSetpoint	Speed setpoint
Voltage.dnActualMotorVoltage	Current motor voltage
Voltage.dnOutputDirectCurrentCtrl	D voltage
Voltage.dnOutputQuadratureVoltage	Q voltage
▶ Signal flow - encoder evaluation (📖 243)	
Position.dnActualLoadPos	Actual position
Position.dnActualMotorPos	Current motor position
Speed.dnActualEncoderSpeed	Current encoder speed
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnActualResolverSpeed	Current resolver speed
▶ Signal flow - position follower (📖 492)	
Position.dnActualLoadPos	Actual position
Position.dnActualMotorPos	Current motor position
Position.dnContouringError	Following error
Position.dnPositionSetpoint	Position setpoint
Speed.dnActualMotorSpeed	Current motor speed
Speed.dnOutputPosCtrl	Output signal - phase controller
Speed.dnSpeedSetpoint	Speed setpoint
Torque.dnTorqueSetpoint	Torque setpoint
Torque.dnTotalTorqueAdd	Additive torque feedforward control value

Variable of the motor control		Meaning
▶ Signal flow - speed follower (📖 498)		
	Speed.dnActualMotorSpeed	Current motor speed
	Speed.dnSpeedSetpoint	Speed setpoint
	Speed.dnTotalSpeedAdd	Additive speed setpoint
	Torque.dnTorqueSetpoint	Torque setpoint
	Torque.dnTotalTorqueAdd	Additive torque feedforward control value
▶ Signal flow - torque follower (📖 503)		
	Speed.dnActualMotorSpeed	Current motor speed
	Speed.dnSpeedSetpoint	Speed setpoint


13 Diagnostics & fault analysis

13.1 LED status display

13 Diagnostics & fault analysis

13.1 LED status display

Information on some operating states can be quickly obtained via LED displays:




[13-1] LED display on the controller front panel

Labelling	Colour	Description
CAN-RUN	green	CAN bus ok
CAN-ERR	red	CAN bus error
DRIVE READY	green	Standard device ready for operation
DRIVE ERROR	red	Warning/trouble/fault
24 V	green	24-V supply voltage ok
USER	yellow	Message parameterised by the application

13.1.1 LED status displays for the device state

The control of the two LEDs "DRIVE READY" and "DRIVE ERROR" in the middle of the controller's front panel depends on the device state. ▶ [Device states](#) (100)



[13-2] DRIVE READY and DRIVE ERROR LED status displays

The meaning can be seen from the table below:


DRIVE READY	DRIVE ERROR	Meaning
OFF	OFF	"Initialisation active" state
	OFF	"Safe torque off active" state Observe LED on the safety module!
	OFF	"Device is ready to switch on" state
	OFF	"Device is switched on" state
	OFF	"Operation" state
 		"Warning active" or "Warning locked active" The controller is ready to switch on, switched on or the operation is enabled and a warning is indicated.
		"Quick stop by trouble active" state
OFF		"Trouble active" state
OFF		"Fault active" state
OFF		"System fault active" state
Legend		
Meaning of the symbols used to describe the LED states:		
	LED is flashing once approx. every 3 seconds (<i>slow flash</i>)	
	LED is flashing twice approx. every 1.25 seconds (<i>flash</i>)	
	LED is flashing twice approx. every 1.25 seconds (<i>double flash</i>)	
	LED is blinking every second	
	LED is permanently on	

13.2 Drive diagnostics with the »Engineer«


When an online connection to the controller has been established, the connected controller can be diagnosed and relevant actual controller states can be displayed in a clearly arranged visualisation using the »Engineer«.






How to diagnose a drive with the »Engineer«:

1. Select the 9400 HighLine controller to be diagnosed in the *Project view*.
2. Click the  icon or select the **Online→Go online** command to build up an online connection with the controller.
3. Select the **Diagnostics** tab.


With an online connection, the **Diagnostics** tab displays current status information about the controller:



Button	Job title
	Acknowledge error message (if the error cause has been eliminated).
	Reading out logbook entries (📖 615)
	A Display details of the current error.
	B Display all active sources of a controller inhibit.
	C Display all active sources of a quick stop.

13.3 Drive diagnostics via keypad/bus system

Keypad display of the controller status



- If the keypad on the front of the controller is connected to the diagnostic interface X6, the status of the controller is shown via different icons on the LCD display in the area ❶.

Symbol	Meaning	Note
RDY	Controller is ready for operation.	
RUN	Controller is enabled.	
STP	Application in the controller is stopped.	
QSP	Quick stop active	
CINH	Controller is inhibited.	The power outputs are inhibited.
OFF	Controller is ready to start.	
Mmax	Speed controller 1 at the limit.	The drive is torque-controlled.
I_{max}	Set current limit has been exceeded in motor or generator mode.	
IMP	Pulse inhibit active	The power outputs are inhibited.
ISFLT	System fault active	
IFLT	Fault active	
ITRB	Trouble active	
ITQSP	Quick stop by trouble active	
WRN	Warning is active	

Display parameters

The parameters listed in the following tables serve to query current states and actual values of the controller for diagnostic purposes, e.g. by using the keypad, a bus system or the »Engineer« (with an online connection to the controller).

- These parameters are listed in the »Engineer« parameter list and the keypad in the **Diagnostics** category.
- A detailed description of these parameters can be found in the chapter "[Parameter reference](#)". (724)

Parameters	Display
C00183	Device status
C00166	Error description
C00168	Error number
C00051	Actual speed value [min-1]
C00052	Motor voltage
C00054	Motor current

Parameters	Display
C00057/1	Maximum torque
C00057/2	Motor reference torque
C00059	Motor - number of pole pairs
C00060	Motor pole angle
C00061	Heatsink temperature
C00062	Interior temperature
C00063	Motor temperature
C00064	Device utilisation (Ixt) during the last 180 seconds
C00065	Ext. 24-V voltage
C00066	Thermal motor load ($I^2 \cdot t$)
C00068	Capacitor temperature
C00069	CPU temperature
C00178	Time the controller was enabled (elapsed-hour meter)
C00179	Power-up time (power-on time meter)
C00186	ENP: Identified motor type

Identification data

The parameters listed in the following table, which in the »Engineer« parameter list and in the keypad are classified in the category **Identification** → **Controller**, serve to display the identification data of the controller:

Parameters	Display
C00099	Firmware version
C00200	Firmware product type
C00201	Firmware compilation date
C00203/1...9	HW product types
C00204/1...9	HW serial numbers
C00205/1...6	HW descriptions
C00206/1...6	HW manufacturing data
C00208/1...6	HW manufacturer
C00209/1...6	HW countries of origin
C00210/1...6	HW versions
C02113	Program name

13.4 Logbook

The integrated logbook function of the controller chronologically logs important events within the system and plays an important role for troubleshooting and controller diagnostics.

Events that can be logged

The following events can be logged in the logbook:

- [Error messages of the operating system](#) (☞ 620)
- Error messages generated by the application
- Controller enable
- Starting / stopping the application
- Loading/saving of parameter sets, loading of the Lenze setting
- Transmitting an application or firmware to the controller
- Switching the controller on/off
- Formatting the file system



Tip!

Use a parameterisable filter to exclude certain events from logbook entry. ▶ [Filtering logbook entries](#) (☞ 614)

Information saved

For each event, the following information is saved in the logbook:

- Type of response to the event (e.g. fault, warning or information)
- Event
- Value of power-on time meter
- Date/time (for memory module with real-time clock)
- Module that activated the event (A = application; S = system).


Memory depth

The number of possible logbook entries depends on the memory module used:

- MM1xx, MM2xx: 7 entries
- MM3xx, MM4xx: 439 entries

13.4.1 Functional description

The structure of the logbook corresponds to a ring buffer:



[13-3] Ring buffer structure

- As long as free logbook memory is available, the entry is placed in the next free position within the memory (A).
- If all memory units are assigned, the oldest entry (B) is deleted for a new entry.
- The newest entries will always remain available.

13.4.2 Filtering logbook entries

The logbook enters new entries in the ring buffer after they have passed through a parameterisable filter. By means of this filter you can exclude events with a specific error response (trouble, warning, information, etc.) from being entered in the logbook.



Note!

Events with the "No response" setting are not entered into the logbook.

The filter is parameterised in [C00169](#) by means of a bit mask. A set bit inhibits the entry of the corresponding event in the logbook.

- From software version V5.0 the option that identical consecutive entries ("Multiple entries") into the logbook are suppressed can be additionally activated via bit 0. Then only the time stamp of the last (latest) entry and the number of times the same event has occurred successively are saved.



Bit	Filter	Lenze setting
0	No multiple entries	0 ≙ filter inactive
1	Error	0 ≙ filter inactive
2	Fault	0 ≙ filter inactive
3	Quick stop by trouble	0 ≙ filter inactive
4	Warning locked	0 ≙ filter inactive
5	Warning	0 ≙ filter inactive
6	Information	0 ≙ filter inactive

13.4.3 Reading out logbook entries


With an online connection, the existing logbook entries can easily be displayed in the »Engineer«.



How to display logbook entries in the »Engineer«:

1. Go to the *Project view* and select the 9400 HighLine controller the logbook entries of which are to be read out.
2. Click the  icon or select the **Online→Go online** command to build up an online connection with the controller.
3. Select the **Diagnostics** tab from the *Workspace*.
4. Click the  symbol in the *diagnostics toolbar* to open the *Logbook* dialog box.

The *Logbook* dialog box displays all logbook entries available in the device. You can filter the entries displayed systematically by selecting or defining filter criteria.



Button	Job title
Export...	Exporting logbook entries to a file (📄 616)
Storing in the project	Storing logbook entries in the project. Logbook entries stored in the project are also displayed if there is no online connection to the controller (e.g. for service and documentation purposes).
Deleting in the device	Delete all logbook entries available in the device.

13.4.4 Exporting logbook entries to a file



How to export the logbook entries to a file:

1. Click **Export...** in the *Logbook* dialog box.
 - The *Export logbook* dialog box is displayed.
2. Specify the folder, file name, and file type for the file.
3. Click the **Save** button to export the logbook entries into the given file.
 - Hidden logbook entries are not exported, i.e. the filter criteria specified are accounted for during the export.
 - The logbook entries are written to the file in the form of a semicolon separated list.







Example

```
Type;event;error number;number;power-on time meter;internal clock;module
Fault;motor:overtemperature;611778563;1;16243:36:56;01.01.1970 00:00;temperature monitoring
Fault;motor:thermal detector is defective;611778572;1;16243:36:56;01.01.1970 00:00;temperature
monitoring
Fault;resolver: open circuit;612040728;1;16243:36:55;01.01.1970 00:00;motor control
```


13.5 Monitoring

The controller is provided with various monitoring functions which protect the drive against impermissible operating conditions.

- If a monitoring function responds,
 - an entry will be made into the [Logbook](#) of the controller,
 - the response (quick stop by trouble, warning, fault, etc.) selected for this monitoring function is activated,
 - the status of the internal device control changes according to the selected response, controller inhibit is set, and the "DRIVE ERROR" LED on the front of the controller goes on:

Response	Logbook entry	Display in C00168	Pulse inhibit	Inverter disable	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Information	<input checked="" type="checkbox"/>					OFF
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Error	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
System fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	



Danger!

If automatic restart is enabled ([C00142](#) = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or request for "Safe torque off active" has been eliminated!

▶ [Automatic restart after mains connection/trouble...](#) (📖 107)

See also:

- ▶ [Device states](#) (📖 100)
- ▶ [LED status displays for the device state](#) (📖 609)

13.5.1 Setting the error response

If a monitoring function responds, the response set for this monitoring function (quick stop by trouble, warning, fault, etc.) is triggered.

- For many monitoring functions the response can be individually parameterised via parameters.

	C	S	Name	Value	Unit
	580	0	Resp. to encoder open circuit	Error	
	581	0	Resp. to external fault	1: Error	
	582	0	Resp. to heatsink temp. > C00122	0: No response	
	583	0	Resp. to motor overtemp. KTY	1: Error	
	584	0	Resp. to motor temp. > C00121	2: Fault	
	585	0	Resp. to motor overtemp. PTC	3: Quick stop by trouble	
	586	0	Resp. to resolver open circuit	4: Warning locked	
	586	0	Resp. to resolver open circuit	5: Warning	
	587	0	Status - fan control	6: Info	
				0x00	



Tip!

The table in the chapter "[Short overview \(A-Z\)](#)" contains the error messages for which the response can be set. (626)

Warning thresholds

Some of the monitoring functions are activated if a defined warning threshold (e.g. temperature) has been exceeded.

- The corresponding preset threshold values can be changed via the following parameters:

Parameters	Info
C00120	Motor overload protection (I ² t)
C00121	Motor temp. warning threshold
C00122	Heatsink temp. warn. threshold
C00123	Device utilisation warning threshold
C00126	CPU temp. warning threshold
C00127	Mot. overload warning threshold
C00128	Thermal time constant of motor
C00174	Undervoltage (LU) threshold
C00570	Warning thres. brake transistor
C00572	Warning thres. brake resistor
C00576	Speed monitoring tolerance
C00596	Threshold max. speed reached
C00599	Motor phase failure threshold
C00620	Max. motor current threshold

13.6 Maloperation of the drive

The motor does not rotate.

Cause	Remedy
DC-bus voltage is too low.	Check mains voltage.
Controller is inhibited.	Deactivate controller inhibit (can be set by several sources).
Motor holding brake is not released.	Release motor holding brake.
Quick stop is active	Deactivate quick stop
Setpoint = 0	Select setpoint.

With a positive speed setpoint selection, the motor rotates counter-clockwise instead of clockwise (when looking at the motor shaft).

Cause	Remedy
Feedback system is not connected in correct phase relation.	Connect feedback system in correct phase relation.

The maximum current (C00022) flows and the motor does not rotate according to the defined speed setpoint.

Cause	Remedy
Two motor phases are interchanged, i.e. an anti-clockwise rotating field is applied to the motor.	<p>Carry out the following steps for verification:</p> <ol style="list-style-type: none"> 1. Ensure that the motor shaft is not blocked and can rotate freely without damaging the system. 2. Activate the "U-rotation test mode" for the motor control (C00398 = "1"). <ul style="list-style-type: none"> • In this test mode a voltage phasor with the frequency set in C00399/1 and the amplitude from the linear characteristic of rated voltage and rated frequency is applied to the machine, which corresponds to a clockwise rotating field. • ⚠ Danger! When the test mode is active, the parameterisable error response "Quick stop by trouble" has no effect! If the test mode is active and a monitoring function responds with this error response, <u>no</u> quick stop is executed but the motor continues to rotate with the frequency set for the test mode! 3. Increase the frequency step by step for the test mode in C00399/1 until the motor shaft starts to rotate. <ul style="list-style-type: none"> • If the motor shaft does not rotate, check the electrical connection. 4. While the motor shaft is rotating, check whether it rotates clockwise when looking at the A end shield. If not, two motor phases are interchanged. 5. Additionally check whether the actual speed value shown in C00051 is positive and whether it corresponds to the defined frequency, taking the number of pole pairs of the machine into consideration (C00059). If this is not the case, the connection and the parameter setting of the feedback system are to be checked. 6. Deactivate the test mode for the motor control again (C00398 = "0").

13 Diagnostics & fault analysis

13.7 Error messages of the operating system

13.7 Error messages of the operating system

This chapter describes all error messages of the controller operating system and possible causes & remedies.




Tip!

Each error message is also saved to the logbook in chronological order. ▶ [Logbook](#) (📖 613)

13.7.1 Structure of the error number (bit coding)

If an error occurs in the controller, a 32-bit value will be saved in decimal format in the internal history buffer ([C00168](#)), which contains the following information:




[13-4] Structure of the error number



Tip!

If you go to the **Diagnostics** tab and click the button to the right of the **Error description** display parameter, you will be shown all details on the current error in a separate dialog box.



13.7.1.1 Response



Bit 31	Bit 30	Bit 29	Response
0	0	0	0: No Response
0	0	1	1: Error
0	1	0	2: Trouble
0	1	1	3: Quick stop by trouble
1	0	0	4: Warning locked
1	0	1	5: Warning
1	1	0	6: Information
1	1	1	7: System fault

The state of the internal device control changes according to the selected response to an error, controller inhibit is set, and the "DRIVE ERROR" LED on the front of the controller goes on:

Response	Logbook entry	Display in C00168	Pulse inhibit	Inverter disable	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Information	<input checked="" type="checkbox"/>					OFF
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Error	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
System fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	


13.7.1.2 Instance ID



The instance ID is dynamically assigned by the operating system.

Bit 28	Bit 27	Bit 26	Meaning
0	0	0	Instance ID 0
0	0	1	Instance ID 1
0	1	0	Instance ID 2
0	1	1	Instance ID 3
1	0	0	Instance ID 4
1	0	1	Instance ID 5
1	1	0	Instance ID 6
1	1	1	Instance ID 7

13.7.1.3 Module ID




Use the module ID to identify the module in which the error has occurred.

Module ID		Module
hex	decimal	
0x0065	101	Logbook module
0x0068	104	Module recognition
0x0069	105	Error check of the program memory for runtime
0x006a	106	Runtime environment for IEC 61131-3 programs
0x006e	110	Supply voltage monitoring
0x006f	111	24-V supply voltage monitoring
0x0072	114	Service register
0x0075	117	Drive control
0x0077	119	Temperature monitoring
0x0078	120	Analog signal monitoring
0x0079	121	Motor data interface
0x007a	122	Processing the digital inputs/outputs
0x007b	123	Motor control
0x007c	124	Device command module (C00002)
0x007d	125	Processing the analog inputs/outputs
0x007f	127	Interface to the intelligent communication module
0x0083	131	"CAN on board": CAN-Dispatcher
0x0084	132	"CAN on board": CAN-NMT-Handler
0x0085	133	"CAN on board": CAN-Emergency-Handler
0x0086	134	"CAN on board": CAN-NMT-Master
0x0087	135	"CAN on board": CAN-PDO-Handler
0x0088	136	"CAN on board": CAN-SDO-Server
0x0089	137	"CAN on board": CAN-SDO-Client
0x008c	140	Application project manager
0x008e	142	Communication interface for internal communication
0x0090	144	Parameter manager
0x0091	145	Lenze runtime system
0x0092	146	Interface to the safety module
0x0093	147	Sync signal generation
0x0099	153	Extension module - digital frequency in MXI1
0x009d	157	CAN module in MXI1: CAN-Dispatcher
0x009e	158	CAN module in MXI1: CAN-NMT-Handler
0x009f	159	CAN module in MXI1: CAN-Emergency-Handler
0x00a0	160	CAN module in MXI1: CAN-NMT-Master
0x00a1	161	CAN module in MXI1: CAN-PDO-Handler
0x00a2	162	CAN module in MXI1: CAN-SDO-Server
0x00a3	163	CAN module in MXI1: CAN-SDO-Client
0x00aa	170	Extension module - digital frequency in MXI2

Module ID		Module
hex	decimal	
0x00ac	172	CAN module in MXI2: CAN-Dispatcher
0x00ad	173	CAN module in MXI2: CAN-NMT-Handler
0x00ae	174	CAN module in MXI2: CAN-Emergency-Handler
0x00af	175	CAN module in MXI2: CAN-NMT-Master
0x00b0	176	CAN module in MXI2: CAN-PDO-Handler
0x00b1	177	CAN module in MXI2: CAN-SDO-Server
0x00b2	178	CAN module in MXI2: CAN-SDO-Client
0x00b8	184	Basic drive functions
0x00c8	200	Intelligent communication module
0x012f	303	Safety module SM300/SM301
0x3ac	940	Servodrive function library
0x3ad	941	Linedrive function library
0x3ae	942	Positioning function library
0x3af	943	Cam function library
0x3b0	944	Toolbox function library
0x3b1	945	Device9400 function library
0x3b2	946	Dataconversion function library
0x3b3	947	Electricalshaft function library
0x3b4	948	CIA402 function library

13.7.1.4 Error ID




16-bit value (0 ... 65535_{dec}) for error identification.

13.7.1.5 Example for bit coding of the error number

C00168 displays the error number "1148911631".

- This decimal value corresponds to the following bit sequence:



Assignment	Information	Meaning in the example
	Response	2: Trouble
	Instance ID	1: Instance ID 1
	Module ID	Module ID 123 (0x007b): Motor control
	Error ID	Error ID 15 (0x000f) for motor control: Undervoltage in the DC bus

- Error number "1148911631" thus means:
The "DC-bus undervoltage" error with the response "Trouble" occurred in the "motor control" module with the instance ID 1.

13.7.2 Reset error message

An error message with the response "Fault", "Quick stop by trouble", or "Warning locked" must be reset (acknowledged) explicitly after the cause of error has been eliminated.



To reset (acknowledge) a pending error message, execute the device command [C00002](#) = "43: Reset error".



Tip!

When an online connection to the controller has been established, use the **Diagnostics** tab of »Engineer« and click **Reset error** to reset a pending error message.

13.7.3 Short overview (A-Z)

The following table contains all error messages of the controller operating system in alphabetical order with the preset error response and - if available – the parameter for setting the error response.



Tip!

If you click on the cross-reference in the first column, you get to the detailed description of the corresponding error response in the following chapter "[Cause & possible remedies](#)".
([634](#))



Note!

Error message "Unknown error"

If the "Unknown error xxxx" error message is indicated in the logbook or in [C00166](#), the reason for the missing plain text is that the error texts required have not been downloaded to the controller during the application download.

- This, for instance, is the case if a device module plugged into the controller has not been included in the Engineer project.
- Remedy: Include the device module, recompile and download the project.

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x0090000c	9437196	Disconnection in the case of par. storage	Error	-
0x007b001a	8060954	Absolute value encoder: Communication error	Error	-
0x006a0000	6946816	General error in the application	Error	-
0x007d0000	8192000	Analog input 1: master current < 4 mA	Error	C00598
0x00750001	7667713	Controller is enabled	Information	-
0x00750003	7667715	Controller in STO state	Information	-
0x007b0047	8060999	Controller: Clamp operation	Information	-
0x00750005	7667717	Controller: Pulse inhibit is active	Information	-
0x007b0035	8060981	Controller: Overload during acceleration phases	Error	-
0x006a0004	6946820	ApplicationTask: Overflow	Error	C02111
0x006a0013	6946835	Application has started	Information	-
0x006a000e	6946830	Application has stopped	Information	-
0x006a0014	6946836	Application has stopped	Information	-
0x008c000c	9175052	Application and device are incompatible	Error	-
0x006a0010	6946832	Faulty application parameter	Error	-
0x007b003f	8060991	A mains phase has failed	Error	-
0x007b002d	8060973	Failure of motor phase U	No response	C00597
0x007b002e	8060974	Failure of motor phase V	No response	C00597
0x007b002f	8060975	Failure of motor phase W	No response	C00597
0x00b8000c	12058636	Acceleration has been limited	Information	C02716/3
0x00910012	9502738	Block function in wrong MEC task	Error	-
0x006a000f	6946831	Breakpoint reached	Information	-
0x007b0040	8060992	Brake chopper: Ixt > C00570	Warning	C00569
0x007b001c	8060956	Brake transistor: Ixt overload	No response	C00573
0x007b0021	8060961	Brake transistor: Overcurrent	Error	-
0x007b0041	8060993	Brake resistor: I2t > C00572	Warning	C00571
0x007b001d	8060957	Brake resistor: I³xt overload	Information	-
0x00b80014	12058644	Cam Data is corrupted	Warning locked	-
0x00b80016	12058646	Cam Data locked due to wrong password	Warning locked	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x00b80017	12058647	Cam Data locked due to wrong security key	Warning locked	-
0x00b80015	12058645	Cam Data restored	Error	-
0x00b80013	12058643	Cam data: serial number MM does not match	Warning locked	-
0x00b80034	12058676	Cam Data: Invalidated (due to change of mechanical data)	Warning	-
0x00b80035	12058677	Cam Data: Invalid product number	Information	-
0x00870008	8847368	CAN on board PDO manager: faulty configuration	Warning locked	-
0x00870000	8847360	CAN on board RPDO1: Telegram not received or faulty	No response	C00591/1
0x00870001	8847361	CAN on board RPDO2: Telegram not received or faulty	No response	C00591/2
0x00870002	8847362	CAN on board RPDO3: Telegram not received or faulty	No response	C00591/3
0x00870003	8847363	CAN on board RPDO4: Telegram not received or faulty	No response	C00591/4
0x00890000	8978432	CAN on board SDO client: Faulty configuration	Warning locked	-
0x00880000	8912896	CAN on board SDO server: Faulty configuration	Warning locked	-
0x00830002	8585218	CAN on board: Basic configuration invalid	Warning locked	-
0x00830000	8585216	CAN on board: Bus off	No response	C00595
0x00850000	8716288	CAN on board: Faulty emergency configuration	Warning locked	-
0x00840000	8650752	CAN on board: Heartbeat error index 1 ... 32	No response	C00613/1...32
0x00840020	8650784	CAN on board: Lifeguarding error	No response	C00614
0x00860020	8781856	CAN on board: Faulty NMT master configuration	Warning locked	-
0x00840021	8650785	CAN on board: Faulty NMT slave configuration	Warning locked	-
0x00860000	8781824	CAN on board: Node guarding error 1 ... 32	No response	C00612/1...32
0x00830001	8585217	CAN on board: Invalid node address 0	Warning	-
0x00a10008	10551304	CAN module (MXI1) PDO manager: Faulty configuration	Warning locked	-
0x00a10000	10551296	CAN module (MXI1) RPDO1: Telegram not received or faulty	No response	C13591/1
0x00a10001	10551297	CAN module (MXI1) RPDO2: Telegram not received or faulty	No response	C13591/2
0x00a10002	10551298	CAN module (MXI1) RPDO3: Telegram not received or faulty	No response	C13591/3
0x00a10003	10551299	CAN module (MXI1) RPDO4: Telegram not received or faulty	No response	C13591/4
0x00a10004	10551300	CAN module (MXI1) RPDO5: Telegram not received or faulty	No response	C13591/5
0x00a10005	10551301	CAN module (MXI1) RPDO6: Telegram not received or faulty	No response	C13591/6
0x00a10006	10551302	CAN module (MXI1) RPDO7: Telegram not received or faulty	No response	C13591/7
0x00a10007	10551303	CAN module (MXI1) RPDO8: Telegram not received or faulty	No response	C13591/8
0x00a30000	10682368	CAN module (MXI1) SDO client: faulty configuration	Warning locked	-
0x00a20000	10616832	CAN module (MXI1) SDO server: faulty configuration	Warning locked	-
0x009d0000	10289152	CAN module (MXI1): Bus off	Information	C13595
0x009f0000	10420224	Can module (MXI1): Faulty emergency configuration	Warning locked	-
0x009e0021	10354721	CAN module (MXI1): Faulty NMT slave configuration	Warning locked	-
0x009d0002	10289154	CAN module (MXI1): Basic configuration invalid	Warning locked	-
0x009e0000	10354688	CAN module (MXI1): Heartbeat error index 1 ... 32	No response	C13613/1...32
0x009e0020	10354720	CAN module (MXI1): Lifeguarding error	No response	C13614
0x00a00020	10485792	CAN module (MXI1): Faulty NMT master configuration	Warning locked	-
0x00a00000	10485760	CAN module (MXI1): node guarding error 1 ... 32	No response	C13612/1...32
0x009d0001	10289153	CAN module (MXI1): Invalid node address 0	Warning	-
0x00b00008	11534344	CAN module (MXI2) PDO manager: Faulty configuration	Warning locked	-
0x00b00000	11534336	CAN module (MXI2) RPDO1: Telegram not received or faulty	No response	C14591/1
0x00b00001	11534337	CAN module (MXI2) RPDO2: Telegram not received or faulty	No response	C14591/2
0x00b00002	11534338	CAN module (MXI2) RPDO3: Telegram not received or faulty	No response	C14591/3
0x00b00003	11534339	CAN module (MXI2) RPDO4: Telegram not received or faulty	No response	C14591/4
0x00b00004	11534340	CAN module (MXI2) RPDO5: Telegram not received or faulty	No response	C14591/5
0x00b00005	11534341	CAN module (MXI2) RPDO6: Telegram not received or faulty	No response	C14591/6
0x00b00006	11534342	CAN module (MXI2) RPDO7: Telegram not received or faulty	No response	C14591/7
0x00b00007	11534343	CAN module (MXI2) RPDO8: Telegram not received or faulty	No response	C14591/8
0x00b20000	11665408	CAN module (MXI2) SDO client: faulty configuration	Warning locked	-
0x00b10000	11599872	CAN module (MXI2) SDO server: faulty configuration	Warning locked	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x00ac0000	11272192	CAN module (MXI2): Bus off	Information	C14595
0x00ae0000	11403264	Can module (MXI2): Faulty emergency configuration	Warning locked	-
0x00ac0002	11272194	CAN module (MXI2): Basic configuration invalid	Warning locked	-
0x00ad0000	11337728	CAN module (MXI2): Heartbeat error index 1 ... 32	No response	C14613/1...32
0x00ad0020	11337760	CAN module (MXI2): Lifeguarding error	No response	C14614
0x00af0020	11468832	CAN module (MXI2): NMT master configuration incomplete	Warning locked	-
0x00ad0021	11337761	CAN module (MXI2): NMT slave configuration incomplete	Warning locked	-
0x00af0000	11468800	CAN module (MXI2): Node guarding error 1 ... 32	No response	C14612/1...32
0x00ac0001	11272193	CAN module (MXI2): Invalid node address 0	Warning	-
0x00900008	9437192	Code number duplicated	Warning locked	-
0x00690000	6881280	Code refresh	System fault	-
0x008c001a	9175066	ConnectTable active	Information	-
0x00770008	7798792	CPU: Temperature > C00126	No response	C00589
0x0077000e	7798798	CPU: thermal detector is defective	Error	C00588
0x00770009	7798793	CPU: Overtemperature	Warning	-
0x008c0002	9175042	File DeviceCFG.dat is defective	Error	-
0x008c0005	9175045	File DeviceCFG.dat is missing	Error	-
0x008c0008	9175048	File DeviceCFG.dat is invalid	Error	-
0x008c0001	9175041	File ProjectList.dat is defective	Error	-
0x008c0004	9175044	File ProjectList.dat is missing	Error	-
0x008c0007	9175047	File ProjectList.dat is invalid	Error	-
0x008c0000	9175040	File ProjectSelection.dat is defective	Error	-
0x008c0003	9175043	File ProjectSelection.dat is missing	Error	-
0x008c0006	9175046	File ProjectSelection.dat is invalid	Error	-
0x00990003	10027011	DFIN (MXI1): Signal error enable/lamp control	Warning	C13041
0x00990000	10027008	DFIN (MXI1): Track error A-/A	Error	C13040
0x00990001	10027009	DFIN (MXI1): Track error B-/B	Error	C13040
0x00990002	10027010	DFIN (MXI1): Track error Z-/Z	Error	C13040
0x00990004	10027012	DFIN (MXI1): Supply cannot be corrected anymore	Warning	C13042
0x00aa0003	11141123	DFIN (MXI2): Signal error enable/lamp control	Warning	C14041
0x00aa0000	11141120	DFIN (MXI2): Track error A-/A	Error	C14040
0x00aa0001	11141121	DFIN (MXI2): Track error B-/B	Error	C14040
0x00aa0002	11141122	DFIN (MXI2): Track error Z-/Z	Error	C14040
0x00aa0004	11141124	DFIN (MXI2): Supply cannot be corrected anymore	Warning	C14042
0x00990005	10027013	DFOUT (MXI1): Maximum frequency reached	Warning	C13080
0x00aa0005	11141125	DFOUT (MXI2): Maximum frequency reached	Warning	C14080
0x006a0011	6946833	Division by zero	Error	-
0x006a0001	6946817	Faulty program download	Error	-
0x007b0012	8060946	Actual speed value outside tolerance (C00576)	No response	C00579
0x00680022	6815778	Real-time clock is defective	Warning locked	-
0x00680024	6815780	Real-time clock: No battery, time lost	Warning locked	-
0x00680023	6815779	Real-time clock: Change battery	Warning locked	-
0x007b0039	8060985	Electronic nameplate: Data outside parameter limits	Information	-
0x007b0030	8060976	Electronic nameplate: Data loaded	Information	-
0x0078000a	7864330	Electronic nameplate: Data are incompatible	Information	-
0x007b0032	8060978	Electronic nameplate: Encoder protocol unknown	Information	-
0x007b0033	8060979	Electronic nameplate: Encoder signal unknown	Information	-
0x0068001b	6815771	Electronic nameplate: Communication error	Warning	-
0x007b0031	8060977	Electronic nameplate: Not found	Information	-
0x0068001d	6815773	Electronic nameplate: Checksum error	Warning	-
0x007b001b	8060955	Encoder: Open circuit	Error	C00580
0x007b002c	8060972	EnDat encoder: Battery empty	Information	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x007b004f	8061007	EnDat encoder: Command error	Information	-
0x007b0026	8060966	EnDat encoder: Lamp error	Information	-
0x007b0050	8061008	EnDat encoder: Initial position error	Information	-
0x007b0028	8060968	EnDat encoder: Position error	Information	-
0x007b0027	8060967	EnDat encoder: Signal error	Information	-
0x007b0029	8060969	EnDat encoder: Overvoltage	Information	-
0x007b002b	8060971	EnDat encoder: Overcurrent	Information	-
0x007b004e	8061006	EnDat encoder: Transmission error	Information	-
0x007b002a	8060970	EnDat encoder: Undervoltage	Information	-
0x007b0011	8060945	Earth fault detected	Error	-
0x008c000b	9175051	Required license missing	Error	-
0x00750000	7667712	External error	Error	C00581
0x00680013	6815763	Incorrect safety module	System fault	-
0x00680012	6815762	Incorrect memory module	System fault	-
0x006a0002	6946818	Error during the update of inputs and outputs	Error	-
0x006a0017	6946839	Error in control configuration	System fault	-
0x00910011	9502737	Error during initialisation	System fault	-
0x0068001e	6815774	Firmware incompatible to control card	System fault	-
0x0068001a	6815770	Firmware has been changed	Information	-
0x007b003e	8060990	Encoder monitoring: Pulse deviation detected	No response	C00621
0x00780001	7864321	Device utilisation lxt > 100 %	Error	-
0x00780000	7864320	Device utilisation lxt > C00123	Warning	C00604
0x00790000	7929856	Incorrect device command transfer	System fault	-
0x00770011	7798801	Inside the device: fan is defective	Error	C00611
0x0077000b	7798795	Inside the device: thermal detector is defective	Error	C00588
0x00b8000b	12058635	Speed has been limited	Information	C02716/3
0x00910003	9502723	Heartbeat not periodic	System fault	-
0x007b003b	8060987	Hiperface encoder: Command error	Information	-
0x007b003c	8060988	Hiperface encoder: Unknown encoder	Information	-
0x007b003d	8060989	Hiperface encoder: Initial position error	Information	-
0x007b003a	8060986	Hiperface encoder: Transmission error	Information	-
0x006a0006	6946822	IdleTask: Overflow	Error	-
0x00b8001a	12058650	Int. overflow C02620 (manual jog: speed 1)	Error	-
0x00b8001b	12058651	Int. overflow C02621 (manual jog: speed 2)	Error	-
0x00b8001c	12058652	Int. overflow C02622 (manual jog: acc.)	Error	-
0x00b8001d	12058653	Int. overflow C02623 (manual jog: dec.)	Error	-
0x00b8002d	12058669	Int. overflow C02642 (home position)	Error	-
0x00b8002e	12058670	Int. overflow C02643 (homing: target position)	Error	-
0x00b8002f	12058671	Int. overflow C02644 (homing: speed 1)	Error	-
0x00b80030	12058672	Int. overflow C02645 (homing: acceleration 1)	Error	-
0x00b80031	12058673	Int. overflow C02646 (homing: speed 2)	Error	-
0x00b80032	12058674	Int. overflow C02647 (homing: acceleration 2)	Error	-
0x00b80033	12058675	Int. overflow C02670 (positioner: tol. for target position)	Error	-
0x00b80020	12058656	Int. overflow C02701/1 (positive software limit pos.)	Error	-
0x00b80021	12058657	Int. overflow C02701/2 (negative software limit pos.)	Error	-
0x00b80022	12058658	Int. overflow C02703 (maximum speed)	Error	-
0x00b80023	12058659	Int. overflow C02705 (maximum acceleration)	Error	-
0x00b80028	12058664	Int. overflow C02708/1 (decel. limited speed 1)	Error	-
0x00b80024	12058660	Int. overflow C02708/1 (limited speed 1)	Error	-
0x00b80029	12058665	Int. overflow C02708/2 (decel. limited speed 2)	Error	-
0x00b80025	12058661	Int. overflow C02708/2 (limited speed 2)	Error	-
0x00b8002a	12058666	Int. overflow C02708/3 (decel. limited speed 3)	Error	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x00b80026	12058662	Int. overflow C02708/3 (limited speed 3)	Error	-
0x00b8002b	12058667	Int. overflow C02708/4 (decel. limited speed 4)	Error	-
0x00b80027	12058663	Int. overflow C02708/4 (limited speed 4)	Error	-
0x00b8002c	12058668	Int. overflow C02713 (max. dist. manual control)	Error	-
0x008c001d	9175069	Internal error (CRC application)	Error	-
0x00690009	6881289	Internal error (event mechanism)	System fault	-
0x0069000a	6881290	Internal error (event mechanism)	System fault	-
0x00690002	6881282	Internal error (LDS instance data)	System fault	-
0x00690003	6881283	Internal error (LDS tasks)	System fault	-
0x0069000d	6881293	Internal error (file system lifetime)	Warning	-
0x00690007	6881287	Internal error (message queue)	System fault	-
0x00690006	6881286	Internal error (message memory)	System fault	-
0x00690008	6881288	Internal error (name database)	System fault	-
0x0069000b	6881291	Internal error (semaphores)	System fault	-
0x0069000c	6881292	Internal error (semaphores)	System fault	-
0x00690001	6881281	Internal error (memory area - logbook)	System fault	-
0x00690004	6881284	Internal error (memory blocks)	System fault	-
0x00690005	6881285	Internal error (task queue)	System fault	-
0x00910004	9502724	Internal error: See C00180	System fault	-
0x00910005	9502725	Internal error: See C00180	System fault	-
0x00910006	9502726	Internal error: See C00180	System fault	-
0x00910008	9502728	Internal error: See C00180	Error	-
0x00910009	9502729	Internal error: See C00180	Error	-
0x007b0034	8060980	Internal communication error (DMA)	System fault	-
0x007b0014	8060948	Internal communication error (host MCTRL)	System fault	-
0x007b0036	8060982	Internal communication error (MCTRL host)	System fault	-
0x00910002	9502722	No heartbeat signal detected	System fault	-
0x0090000a	9437194	No parameters for module in MXI1	Error	C00615/2
0x0090000b	9437195	No parameters for module in MXI2	Error	C00615/3
0x00680019	6815769	Combination MXI1/MXI2 not possible	System fault	-
0x0068001f	6815775	Combination of memory module/device not possible	System fault	-
0x00680020	6815776	Combination of module in MXI1/device not possible	System fault	-
0x00680021	6815777	Combination of module in MXI2/device not possible	System fault	-
0x007f0003	8323075	Communication with module in MXI1 interrupted	Information	-
0x007f0004	8323076	Communication with module in MXI2 interrupted	Information	-
0x00920001	9568257	Communication with safety module interrupted	Information	-
0x007f0002	8323074	Communication error between device and device module	No response	C01501
0x0091000e	9502734	Communication task: standstill > 3 s	Error	C01230
0x00770010	7798800	Heatsink: fan is defective	Error	C00610
0x00770000	7798784	Heatsink: temperature > C00122	Warning	C00582
0x0077000a	7798794	Heatsink: thermal detector is defective	Error	C00588
0x00770001	7798785	Heatsink: Overtemperature	Error	-
0x007b0023	8060963	Load encoder: Module selected in C00490 is not available	Error	-
0x006a000d	6946829	Run-time error	Error	-
0x0068000f	6815759	Power section incompatible	System fault	-
0x00680001	6815745	Power section is defective	System fault	-
0x00680009	6815753	Power section is defective	System fault	-
0x007b0042	8060994	Power section is defective	System fault	-
0x00680014	6815764	Power section has been changed	Information or warning locked if the hardware type has also changed.	-
0x00900001	9437185	Lenze setting loaded	Information	-
0x00900004	9437188	Loading of Lenze setting failed	Error	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x00720000	7471104	Read error service register	Error	-
0x00650001	6619137	Logbook: Reset (read error)	Information	-
0x00650002	6619138	Logbook: Reset (version error)	Information	-
0x00650000	6619136	Logbook: Overflow	Information	-
0x00b80010	12058640	Maximum speed exceeded	Information	C02716/3
0x00b80011	12058641	Maximum acceleration exceeded	Information	C02716/3
0x007b004c	8061004	Motor disconnected	No response	C00597
0x007b0007	8060935	Motor: rated current < rated magnetisation current	Information	-
0x007b0002	8060930	Motor: Calculated mutual inductance unrealistic	Information	-
0x007b000a	8060938	Motor: Calculated mutual inductance unrealistic	Information	-
0x007b0001	8060929	Motor: Calculated motor impedance unrealistic	Information	-
0x007b000c	8060940	Motor: Calculated rotor time constant unrealistic	Information	-
0x007b0019	8060953	Motor: Calculated leakage inductance unrealistic	Information	-
0x007b000b	8060939	Motor: Calculated e.m.f. factor unrealistic	Information	-
0x007b000d	8060941	Motor: Calculated flux factor unrealistic	Information	-
0x007b0009	8060937	Motor: Calculated rotor resistance unrealistic	Information	-
0x007b0020	8060960	Motor: actual speed > C00596	Error	C00607
0x007b0006	8060934	Motor: Device current too low for rated magnetisation	Information	-
0x007b0004	8060932	Motor: Phase resistance too high	Information	-
0x0077000f	7798799	Motor: PTC has triggered	No response	C00585
0x007b001e	8060958	Motor: actual current > C00620	Error	C00619
0x00770002	7798786	Motor: temperature > C00121	Warning	C00584
0x0077000c	7798796	Motor: thermal detector is defective	Error	C00594
0x00770003	7798787	Motor: Overtemperature	Error	C00583
0x00780003	7864323	Motor load I*xt > C00120	Error	-
0x00780002	7864322	Motor load I*xt > C00127	Warning	C00606
0x00b80004	12058628	Motor brake: Autom. activated after waiting time has elapsed	Information	-
0x00b80005	12058629	Motor brake: Status monitoring error	Quick stop by trouble	-
0x00b80003	12058627	Motor brake: Angular drift with closed brake too high	Quick stop by trouble	-
0x007b0003	8060931	Motor data are inconsistent	Information	-
0x007b0017	8060951	Motor data are inconsistent	Information	-
0x007b0024	8060964	Motor encoder: Module selected in C00495 is not available	Error	-
0x007b0038	8060984	Motor parameter identification cancelled	Error	-
0x007b0013	8060947	Motor control: Task overflow	System fault	-
0x007b0025	8060965	Motor temperature: Module selected in C01193 is not available	Error	-
0x008c0017	9175063	MXI1: CAN module is missing or incompatible	Error	C00615/2
0x008c0011	9175057	MXI1: Ethernet module is missing or incompatible	Error	C00615/2
0x00680010	6815760	MXI1: Wrong module	System fault	-
0x008c0015	9175061	MXI1: ICM module is missing or incompatible	Error	C00615/2
0x008c0013	9175059	MXI1: Digital frequency module is missing or incompatible	Error	C00615/2
0x008c000d	9175053	MXI1: Module is missing or incompatible	Error	-
0x0068000a	6815754	MXI1: Module is defective or missing	Error	-
0x00680004	6815748	MXI1: Module changed during operation	Warning locked	-
0x00680015	6815765	MXI1: Module has been changed	Information or warning locked if the hardware type has also changed.	-
0x008c000f	9175055	MXI1: PROFIBUS module is missing or incompatible	Error	C00615/2
0x008c0018	9175064	MXI2: CAN module is missing or incompatible	Error	C00615/3
0x008c0012	9175058	MXI2: Ethernet module is missing or incompatible	Error	C00615/3
0x00680011	6815761	MXI2: Wrong module	System fault	-
0x008c0016	9175062	MXI2: ICM module is missing or incompatible	Error	C00615/3
0x008c0014	9175060	MXI2: Digital frequency module is missing or incompatible	Error	C00615/3
0x008c000e	9175054	MXI2: Module is missing or incompatible	Error	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x0068000b	6815755	MXI2: Module is defective or missing	System fault	-
0x00680005	6815749	MXI2: Module changed during operation	Warning locked	-
0x00680016	6815766	MXI2: Module has been changed	Information or warning locked if the hardware type has also changed.	-
0x008c0010	9175056	MXI2: PROFIBUS module is missing or incompatible	Error	C00615/3
0x00b8000a	12058634	Negative direction of rotation limited	Information	C02716/1
0x00b80002	12058626	Negative limit switch has triggered	Quick stop by trouble	-
0x00b80008	12058632	Negative software limit switch overtravelled	Quick stop by trouble	C02716/2
0x00910001	9502721	Mains voltage is switched off	Information	-
0x00910000	9502720	Mains voltage is switched on	Information	-
0x006a0003	6946819	New applications loaded	Information	-
0x00900006	9437190	Saving of parameters failed	Error	-
0x00900000	9437184	Parameter set faulty	Error	-
0x00900003	9437187	Parameter set loaded	Information	-
0x00900002	9437186	Parameter set saved	Information	-
0x00900005	9437189	Parameter set restored	Error	-
0x00900009	9437193	Parameter set: type of standard device has been changed	Information	-
0x00900007	9437191	Parameter set: Version conflict	Error	-
0x006a0015	6946837	PDO mapping (MXI1): Faulty configuration	Error	-
0x006a0016	6946838	PDO mapping (MXI2): Faulty configuration	Error	-
0x007b004a	8061002	Pole position identification cancelled	Error	C00640
0x00910010	9502736	Position value faulty	Error	-
0x00b8000f	12058639	Position target outside the software limit positions	Quick stop by trouble	C02716/2
0x00b80009	12058633	Positive direction of rotation limited	Information	C02716/1
0x00b80001	12058625	Positive limit switch has triggered	Quick stop by trouble	-
0x00b80007	12058631	Positive software limit switch overtravelled	Quick stop by trouble	C02716/2
0x008c0009	9175049	Project not loaded	Error	-
0x008c000a	9175050	Project not available	Error	-
0x00b80019	12058649	Homing mode not allowed	Error	-
0x007b001f	8060959	Resolver: Calculated acceleration unrealistic	Information	-
0x007b0018	8060952	Resolver: Open circuit	Error	-
0x006a001a	6946842	Retain memory of the application faulty	Error	-
0x00b8000e	12058638	Jerk has been limited	Information	C02716/3
0x00680003	6815747	Safety module is defective or missing	System fault	-
0x0068000d	6815757	Safety module is defective or missing	System fault	-
0x00680007	6815751	Safety module has been removed	System fault	-
0x00680018	6815768	Safety module has been changed	Information or warning locked if the hardware type has also changed.	-
0x00920000	9568256	Safety module: Incompatible with setting in C00214	System fault	-
0x00650003	6619139	Memory module missing	Information	-
0x00680002	6815746	Memory module is defective or missing	Error	-
0x0068000c	6815756	Memory module is defective or missing	System fault	-
0x00680006	6815750	Memory module has been removed	System fault	-
0x00680017	6815767	Memory module has been changed	Information or warning locked if the hardware type has also changed.	-
0x0068001c	6815772	Memory module: Faulty file system	Error	-
0x007c0000	8126464	Memory module: file system has been formatted	Information	-
0x007c0001	8126465	Memory module: File system has been restored	Information	-
0x008c001e	9175070	Storage capacity for user parameters exceeded	Error	-
0x00b80000	12058624	PLC configuration invalid	Error	-
0x007d0001	8192001	PLC configuration invalid	Error	-

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x007b0037	8060983	PLC configuration invalid	Error	-
0x00750006	7667718	PLC configuration invalid	Error	-
0x0068000e	6815758	Control card incompatible	System fault	-
0x00680000	6815744	Control card is defective	System fault	-
0x00680008	6815752	Control card is defective	System fault	-
0x00780008	7864328	Control card is defective (UB18 neg.)	System fault	-
0x00780004	7864324	Control card is defective (UB24)	System fault	-
0x00780006	7864326	Control card is defective (UB8)	System fault	-
0x00780007	7864327	Control card is defective (VCC15 neg.)	System fault	-
0x00780005	7864325	Control card is defective (VCC15)	System fault	-
0x00780009	7864329	Control card is defective (VCC5)	System fault	-
0x006f0000	7274496	Control card: Supply voltage (24 V DC) too low	Fault	-
0x0091000a	9502730	System task 1: Task overflow	System fault	-
0x0091000b	9502731	System task 2: Task overflow	Information	-
0x0091000c	9502732	System task 3: Task overflow	System fault	-
0x0091000d	9502733	System task: Task overflow	Error	-
0x00b80012	12058642	Time-out torque feedforward control brake	Quick stop by trouble	-
0x007b0010	8060944	Overcurrent detected	Error	-
0x006a0005	6946821	UserTask: Overflow	Error	C02111
0x00790002	7929858	Violation of time slice	Error	-
0x00b8000d	12058637	Deceleration has been limited	Information	C02716/3
0x006a001b	6946843	Watchdog cycle is greater than task cycle	Error	-
0x006a0012	6946834	Pointer access in impermissible memory area	Error	-
0x00790001	7929857	Time error - controller interface	System fault	-
0x0077000d	7798797	DC-bus capacitor: thermal detector is defective	Error	C00588
0x007b000e	8060942	DC-bus overvoltage	Fault	C00600
0x007b000f	8060943	DC-bus undervoltage	Fault	-
0x0091000f	9502735	Cyclical task: standstill > 60 s	Information	-

13.7.4 Cause & possible remedies

This chapter contains all error messages of the controller operating system in numerical order of the error numbers. The list provides detailed information on the response to the error message as well as information on the cause & possible remedies.



Tip!

A list of all error messages of the controller operating system in alphabetical order can be found in the previous chapter "[Short overview \(A-Z\)](#)". (📖 626)



Note!

Error message "Unknown error"

If the "Unknown error xxxx" error message is indicated in the logbook or in [C00166](#), the reason for the missing plain text is that the error texts required have not been downloaded to the controller during the application download.

- This, for instance, is the case if a device module plugged into the controller has not been included in the Engineer project.
- Remedy: Include the device module, recompile and download the project.

Logbook: Overflow [0x00650000]

Module ID (decimal)	Error ID (decimal)
101: Logbook module	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Too many events/faults have occurred in a very short time. It was therefore not possible to list all of them in the logbook.	Check whether application generates too many error messages.

Logbook: Reset (read error) [0x00650001]

Module ID (decimal)	Error ID (decimal)
101: Logbook module	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The logbook has been reset due to a read error..	-(is irreversible)

Logbook: Reset (version error) [0x00650002]

Module ID (decimal)	Error ID (decimal)
101: Logbook module	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The logbook has been reset due to a version conflict.	-(is irreversible)

Memory module is missing [0x00650003]

Module ID (decimal)	Error ID (decimal)
101: Logbook module	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Memory module is defective or not available.	Use a different memory module.

Control card is defect [0x00680000]

Module ID (decimal)	Error ID (decimal)
104: Module identification	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the control card.	Mains switching <ul style="list-style-type: none"> • Please contact Lenze if the error occurs again.

Power section is defect [0x00680001]

Module ID (decimal)	Error ID (decimal)
104: Module identification	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the power section.	Mains switching <ul style="list-style-type: none"> • Please contact Lenze if the error occurs again.

Memory module is defect or missing [0x00680002]

Module ID (decimal)	Error ID (decimal)
104: Module identification	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the memory module.	Mains switching <ul style="list-style-type: none"> • If the error occurs again: Switch off the controller, remove memory module and plug in again, switch on the controller again. • If the error still occurs: Switch off controller and use a different memory module.

Safety module is defect or missing [0x00680003]

Module ID (decimal)	Error ID (decimal)
104: Module identification	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the safety module.	Mains switching <ul style="list-style-type: none"> • If the error occurs again: Switch off the controller, remove safety module and plug in again, switch on the controller again. • If the error still occurs: Switch off controller and use a different safety module.

MXI1: Module changed during operation [0x00680004]

Module ID (decimal)	Error ID (decimal)
104: Module identification	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
It was tried to plug an extension module into module slot MXI1, which is not "Hot-plug"-able.	Plug in valid module and switch on mains. <ul style="list-style-type: none"> • Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.

MXI2: Module changed during operation [0x00680005]

Module ID (decimal)	Error ID (decimal)
104: Module identification	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
It was tried to plug an extension module into module slot MXI2, which is not "Hot-plug"-able.	Plug in valid module and switch on mains. <ul style="list-style-type: none"> • Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.

Memory module has been removed [0x00680006]

Module ID (decimal)	Error ID (decimal)
104: Module identification	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
You have tried to remove or change the memory module during operation.	Switch off the controller, plug in memory module and switch on the controller again. <ul style="list-style-type: none"> • If the error occurs again, the memory module is defective and must be replaced.

Safety module has been removed [0x00680007]

Module ID (decimal)	Error ID (decimal)
104: Module identification	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
You have tried to remove or change the safety module during operation.	Switch off the controller, plug in safety module and switch on the controller again. <ul style="list-style-type: none"> • If the error occurs again, the safety module is defective and must be replaced.

Control card is defect [0x00680008]

Module ID (decimal)	Error ID (decimal)
104: Module identification	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the control card.	Please contact Lenze.

Power section is defect [0x00680009]

Module ID (decimal)	Error ID (decimal)
104: Module identification	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the power section.	Please contact Lenze.

MX11: Module is defect or missing [0x0068000a]

Module ID (decimal)	Error ID (decimal)
104: Module identification	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the extension module in module slot MX11.	<ul style="list-style-type: none"> • Use a different extension module. • Please contact Lenze.

MX12: Module is defect or missing [0x0068000b]

Module ID (decimal)	Error ID (decimal)
104: Module identification	11
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the extension module in module slot MX12.	<ul style="list-style-type: none"> • Use a different extension module. • Please contact Lenze.

Memory module is defect or missing [0x0068000c]

Module ID (decimal)	Error ID (decimal)
104: Module identification	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the memory module.	<ul style="list-style-type: none"> • Use a different memory module. • Please contact Lenze.

Safety module is defect or missing [0x0068000d]

Module ID (decimal)	Error ID (decimal)
104: Module identification	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Operating system could not identify the safety module.	<ul style="list-style-type: none"> • Use a different safety module. • Please contact Lenze.

Control card incompatible [0x0068000e]

Module ID (decimal)	Error ID (decimal)
104: Module identification	14
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The control card is not supported by the operating system.	Please contact Lenze.

Power section incompatible [0x0068000f]

Module ID (decimal)	Error ID (decimal)
104: Module identification	15
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The power section is not supported by the operating system.	Please contact Lenze.

MXI1: Wrong module [0x00680010]

Module ID (decimal)	Error ID (decimal)
104: Module identification	16
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI1 is not supported by the operating system.	<ul style="list-style-type: none"> • Use a different module. • Please contact Lenze.

MXI2: Wrong module [0x00680011]

Module ID (decimal)	Error ID (decimal)
104: Module identification	17
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI2 is not supported by the operating system.	<ul style="list-style-type: none"> • Use a different module. • Please contact Lenze.

Incorrect memory module [0x00680012]

Module ID (decimal)	Error ID (decimal)
104: Module identification	18
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The memory module is not supported by the operating system.	<ul style="list-style-type: none"> • Use a different module. • Please contact Lenze.

Incorrect safety module [0x00680013]

Module ID (decimal)	Error ID (decimal)
104: Module identification	19
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The safety module is not supported by the operating system.	<ul style="list-style-type: none"> • Use a different module. • Please contact Lenze.

Power section was changed [0x00680014]

Module ID (decimal)	Error ID (decimal)
104: Module identification	20
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The power section has been changed since the last mains switching.	(Only information or warning locked if the hardware type has also changed.)

MXI1: Module has been changed [0x00680015]

Module ID (decimal)	Error ID (decimal)
104: Module identification	21
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI1 has been changed since the last mains switching.	(Only information or warning locked if the hardware type has also changed.)

MXI2: Module has been changed [0x00680016]

Module ID (decimal)	Error ID (decimal)
104: Module identification	22
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI2 has been changed since the last mains switching.	(Only information or warning locked if the hardware type has also changed.)

Memory module has been changed [0x00680017]

Module ID (decimal)	Error ID (decimal)
104: Module identification	23
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The memory module has been changed since the last mains switching.	(Only information or warning locked if the hardware type has also changed.)

Safety module has been changed [0x00680018]

Module ID (decimal)	Error ID (decimal)
104: Module identification	24
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The safety module has been changed since the last mains switching.	(Only information or warning locked if the hardware type has also changed.)

Combination MXI1/MXI2 not possible [0x00680019]

Module ID (decimal)	Error ID (decimal)
104: Module identification	25
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Extension modules which are not supported in this combination are plugged into module slots MXI1 & MXI2.	Create permitted module combination.

Firmware has been changed [0x0068001a]

Module ID (decimal)	Error ID (decimal)
104: Module identification	26
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The firmware of the operating system has been updated.	- (Information only)

Electronic nameplate: Communication error [0x0068001b]

Module ID (decimal)	Error ID (decimal)
104: Module identification	27
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Communication with the electronic nameplate is interrupted, the data could not be read.	Check correct connection of the encoder cable.

Memory module: Faulty file system [0x0068001c]

Module ID (decimal)	Error ID (decimal)
104: Module identification	28
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Memory module is plugged in incorrectly or is defective.	<ul style="list-style-type: none"> • Plug in the memory module correctly. • Exchange defective memory module.

Electronic nameplate: Checksum error [0x0068001d]

Module ID (decimal)	Error ID (decimal)
104: Module identification	29
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The checksum of the electronic nameplate is defective.	Please contact Lenze.

Firmware is incompatible with control card [0x0068001e]

Module ID (decimal)	Error ID (decimal)
104: Module identification	30
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Firmware is not compatible with the hardware.	Import the compatible firmware.

Combination memory module/device not possible [0x0068001f]

Module ID (decimal)	Error ID (decimal)
104: Module identification	31
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The memory module used is not supported by the controller according to the license model.	Plug in supported module and switch the mains. <ul style="list-style-type: none"> • The 9400 HighLine supports the MM220 (licence: Motion Control HighLevel) and MM330 memory modules (licence: Motion Control TopLevel).

Combination of module in MXI1/device not possible [0x00680020]

Module ID (decimal)	Error ID (decimal)
104: Module identification	32
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI1 is not supported by the controller.	<ul style="list-style-type: none"> • Remove the extension module and switch the mains. • Plug in supported extension module and switch the mains.

Combination of module in MXI2/device not possible [0x00680021]

Module ID (decimal)	Error ID (decimal)
104: Module identification	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The extension module in module slot MXI2 is not supported by the controller.	<ul style="list-style-type: none"> • Remove the extension module and switch the mains. • Plug in supported extension module and switch the mains.

Real-time clock is defective [0x00680022]

Module ID (decimal)	Error ID (decimal)
104: Module identification	34
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error: The clock integrated in the MM440 memory module is defective.	<ul style="list-style-type: none"> • Replacing the memory module. • Please contact Lenze.

Real-time clock: Change battery [0x00680023]

Module ID (decimal)	Error ID (decimal)
104: Module identification	35
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The battery in the clock integrated in the MM440 memory module is low. The clock is expected to fail soon.	Replacing the memory module.

Real-time clock: Battery empty, time lost [0x00680024]

Module ID (decimal)	Error ID (decimal)
104: Module identification	36
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The battery integrated in the clock in the MM440 memory module is empty. The clock has been reset to its initial value (01.01.1970 - 00:00:00 o'clock).	<ul style="list-style-type: none"> • If the memory module is used for the first time, restart the controller to initialise the memory module. • If the problem occurs again, replace the memory module.

Code refresh [0x00690000]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Internal error (memory area - logbook) [0x00690001]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Internal error (LDS instance data) [0x00690002]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Internal error (LDS tasks) [0x00690003]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (storage blocks) [0x00690004]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (task queue) [0x00690005]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (message memory) [0x00690006]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (message queue) [0x00690007]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (name data base) [0x00690008]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (event mechanism) [0x00690009]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (event mechanism) [0x0069000a]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (semaphores) [0x0069000b]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	11
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (semaphores) [0x0069000c]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Serious device error or component failure.	Switch the controller off and then on again. • Please contact Lenze if the problem occurs again.

Internal error (file system lifetime) [0x0069000d]

Module ID (decimal)	Error ID (decimal)
105: Error check of the program memory during runtime	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The maximum number of permissible writing cycles has been reached for the memory module.	Remedy
	Replace memory module, otherwise data may get lost.

General error in the application [0x006a0000]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
General application error.	Remedy
	Mains switching. Transmit the application to the controller again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Faulty program download [0x006a0001]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Faulty transmission of the application to the controller (checksum error).	Remedy
	Repeat transmission.

Fault during the update of the inputs and outputs [0x006a0002]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Internal error	Remedy
	Mains switching. Transmit the application to the controller again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

New application loaded [0x006a0003]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Application has been changed by transmission from Engineer or loading from the memory module.	- (Information only)

ApplicationTask: Overflow [0x006a0004]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Program runtime in Application task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"> • Omitting functions (e.g. by reducing the number of active FBs). • Optimisation of functions to the calculating time.

UserTask: Overflow [0x006a0005]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Program runtime in user task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"> • Omitting functions (e.g. by reducing the number of active FBs). • Optimisation of functions to the calculating time.

IdleTask: Overflow [0x006a0006]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Program runtime in idle task is too high.	Reduce program runtime by means of: <ul style="list-style-type: none"> • Omitting functions (e.g. by reducing the number of active FBs). • Optimisation of functions to the calculating time.

Runtime error [0x006a000d]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
A runtime error has occurred in the application. The application processing has been interrupted.	Remove runtime error in the application and retransfer application to controller.

Application has stopped [0x006a000e]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	14
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The application has been stopped using the device command <code>C00002="32"</code> . All user tasks are stopped.	Restart application with device command <code>C00002="31"</code> .

Breakpoint reached [0x006a000f]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	15
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The application has reached a set breakpoint and the user task with the breakpoint has stopped.	Delete breakpoint and restart application.

Faulty application parameter [0x006a0010]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	16
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid parameter description is available.	Transmit application and parameter set to the controller again.

Division by zero [0x006a0011]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	17
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An impermissible division by zero occurred in the application. The division has been intercepted and the divisor was replaced by the value "1".	Replace application.

Pointer access in impermissible memory area [0x006a0012]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	18
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid pointer access to a protected area occurred in the application.	Replace application.

Application has started [0x006a0013]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	19
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The application in the controller has been started.	- (Information only)

Application has stopped [0x006a0014]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	20
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The application in the controller has been stopped.	- (Information only)

PDO mapping (MXI1): Faulty configuration [0x006a0015]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	21
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Incorrectly configured process data mapping. <ul style="list-style-type: none"> • The corresponding PDO channel is not installed, e. g. because no communication module was selected for module slot MXI1 in the Engineer project. • The communication module selected for module slot MXI1 in the Engineer project does not support PDO mapping. • The mapping information downloaded to the controller is faulty. 	<ul style="list-style-type: none"> • Integrate suitable communication module for module slot MXI1 in the Engineer project. • Check the configuration of the network. Then recompile the project and transmit it to the controller.

PDO mapping (MXI2): Faulty configuration [0x006a0016]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	22
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Incorrectly configured process data mapping. <ul style="list-style-type: none"> • The corresponding PDO channel is not installed, e. g. because no communication module was selected for module slot MXI2 in the Engineer project. • The communication module selected for module slot MXI2 in the Engineer project does not support PDO mapping. • The mapping information downloaded to the controller is faulty. 	<ul style="list-style-type: none"> • Integrate suitable communication module for module slot MXI2 in the Engineer project. • Check the configuration of the network. Then recompile the project and transmit it to the controller.

Fault in the control configuration [0x006a0017]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	23
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid control configuration has occurred.	Load a different application.

Retain memory of the application faulty [0x006a001a]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	26
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
During reading or saving the retain memory of the application a fault has occurred.	Check whether the memory module suitable for the application is plugged in. Mains switching. (C00002) = 33 (reset program). Carry out project download again. <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Watchdog cycle is greater than task cycle [0x006a001b]

Module ID (decimal)	Error ID (decimal)
106: Runtime environment for IEC 61131-3 programs	27
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
An application has been downloaded <ul style="list-style-type: none"> with the highest priority task having a smaller cycle than the parameterised watchdog cycle or <ul style="list-style-type: none"> with the watchdog of the highest priority task being deactivated. 	You can acknowledge the error if you follow the below procedure: <ol style="list-style-type: none"> 1. Activate watchdog 2. Set a watchdog cycle that is smaller than or equal to the task cycle 3. Recreate the application and download it again <ul style="list-style-type: none"> From software version V11.0: If the device boots with an application without an activated watchdog or with a watchdog set incorrectly, only an information is entered in the logbook.

Control card: Supply voltage (24 V DC) too low [0x006f0000]

Module ID (decimal)	Error ID (decimal)
111: Monitoring of the 24V supply voltage	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
External 24 V supply voltage of the control card is lower than 18 V.	Check external supply voltage. <ul style="list-style-type: none"> If the external supply voltage is available and the error message does not disappear, please contact Lenze.

Read error service register [0x00720000]

Module ID (decimal)	Error ID (decimal)
114: Service register	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
During reading or writing the service register a fault has occurred.	Mains switching <ul style="list-style-type: none"> Please contact Lenze if the problem occurs again.

External error [0x00750000]

Module ID (decimal)	Error ID (decimal)
117: Device control	0
Reaction (Lenze setting in bold)	
Setting: C00581 (<input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The drive interface has activated the error message "External error". <ul style="list-style-type: none"> The input <code>DI_bSetExternError</code> of the system block <code>LS_DriveInterface</code> has been set to TRUE. 	<ul style="list-style-type: none"> Check external device to be monitored. Check assignment of the input <code>DI_bSetExternError</code> in the application.

Controller enabled [0x00750001]

Module ID (decimal)	Error ID (decimal)
117: Device control	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The controller is enabled and has the "Operation" state.	- (Information only)

Controller in STO state [0x00750003]

Module ID (decimal)	Error ID (decimal)
117: Device control	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The controller has received the "Safe torque off (STO)" request by the safety module and is now in the "Safe torque off active" device state.	- (Information only)

Controller: Pulse inhibit is active [0x00750005]

Module ID (decimal)	Error ID (decimal)
117: Device control	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The pulse inhibit is active in the controller.	- (Information only)

PLC configuration invalid [0x00750006]

Module ID (decimal)	Error ID (decimal)
117: Device control	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid control configuration has occurred.	Load a different application.

Heatsink: Temperature > C00122 [0x00770000]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	0
Reaction (Lenze setting in bold)	
Setting: C00582 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Heatsink temperature higher than variable temperature limit (C00122). <ul style="list-style-type: none"> Ambient controller temperature too high. Dirty fan or ventilation slots. Value set under C00122 is too low. 	<ul style="list-style-type: none"> Check control cabinet temperature. Clean filter. Clean inverter. Set a higher value in C00122.

Heatsink: Overtemperature [0x00770001]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Heatsink temperature greater than fixed temperature limit. <ul style="list-style-type: none"> • Ambient controller temperature too high. • Dirty fan or ventilation slots. Note: The fixed temperature limit is dependent on the device size (DS). <ul style="list-style-type: none"> • Temperature limit 90 °C: DS1 - DS7, i.e. for devices with a rated current up to 104 A • Temperature limit 100 °C: DS81 - DS91, i.e. for devices with a rated current from 145 A 	<ul style="list-style-type: none"> • Check control cabinet temperature. • Clean filter. • Clean inverter.

Motor: Temperature > C00121 [0x00770002]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	2
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: C00584 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
Motor temperature higher than variable temperature limit (C00121). <ul style="list-style-type: none"> • Motor too hot due to impermissibly high currents or frequent and too long acceleration processes. • No PTC connected. • Value set under C00121 is too low. 	<ul style="list-style-type: none"> • Check drive dimensioning. • Connect PTC or switch off monitoring (C00584="0"). • Set a higher value in C00121.

Motor: Overtemperature [0x00770003]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	3
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Setting: C00583 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
Motor temperature higher than fixed temperature limit (150 °C). <ul style="list-style-type: none"> • Motor too hot due to impermissibly high currents or frequent and too long acceleration processes. • No PTC connected. 	<ul style="list-style-type: none"> • Check drive dimensioning. • Connect PTC or switch off monitoring (C00583="0").

CPU: Temperature > C00126 [0x00770008]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	8
Reaction (Lenze setting in bold)	
Setting: C00589 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
CPU temperature higher than variable temperature limit (C00126). <ul style="list-style-type: none"> • Ambient controller temperature too high. • Dirty fan or ventilation slots. • Value set under C00126 is too low. 	Remedy <ul style="list-style-type: none"> • Check control cabinet temperature. • Clean filter. • Clean inverter. • Set a higher value in C00126.

CPU: Overtemperature [0x00770009]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
CPU temperature higher than fixed limit temperature (85 °C). <ul style="list-style-type: none"> • Ambient controller temperature too high. • Dirty fan or ventilation slots. 	Remedy <ul style="list-style-type: none"> • Check control cabinet temperature. • Clean filter. • Clean inverter.

Heatsink: Thermal detector is defect [0x0077000a]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	10
Reaction (Lenze setting in bold)	
Setting: C00588 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Encoder for heatsink temperature supplies undefined values.	Remedy Check control cabinet temperature, maybe it is too low.

Inside the device: Thermal detector is defective [0x0077000b]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	11
Reaction (Lenze setting in bold)	
Setting: C00588 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Encoder for interior temperature supplies undefined values.	Remedy Check control cabinet temperature, maybe it is too low.

Motor: Thermal detector is defect [0x0077000c]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	12
Reaction (Lenze setting in bold)	Setting: C00594 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The signals of the connected encoder for the motor temperature detection (resolver at X7 or encoder at X8) are outside the defined operating range of the detection.	<ul style="list-style-type: none"> • Check contacts of the encoder cable at the motor and controller. • Check selection of the motor temperature sensor in C01190 and make sure that it complies with the assembly in the motor. • Possibly switch off temperature sensor monitoring (C00594="0"). • If a PTC is in the motor, activate the monitoring of the PTC temperature in C00585 instead.

DC-bus capacitor: Thermal detector is defect [0x0077000d]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	13
Reaction (Lenze setting in bold)	Setting: C00588 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Encoder for capacitor temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.

CPU: Thermal detector is defect [0x0077000e]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	14
Reaction (Lenze setting in bold)	Setting: C00588 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Encoder for CPU temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.

Motor: PTC has triggered [0x0077000f]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	15
Reaction (Lenze setting in bold)	Setting: C00585 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>The motor temperature detected via the terminals T1/T2 is too high.</p> <ul style="list-style-type: none"> • Motor is too hot due to an increased effective current that results from operation with too high/too frequent acceleration processes. • Motor too hot due to increased ambient conditions. • Motor too hot due to lacking cooling in the case of self-ventilation and continuous operation with speeds lower than the rated speed. • Terminals T1/T2 are not assigned. • Open circuit of the supply cables for terminals T1/T2. 	<ul style="list-style-type: none"> • Check drive dimensioning. • Connect PTC or thermal contact to terminals T1/T2. • If a motor without integrated temperature monitoring is used, switch off the monitoring function (C00585="0").

Heatsink: Fan is defect [0x00770010]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	16
Reaction (Lenze setting in bold)	
Setting: C00610 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Speed of heatsink fan too low, e.g. due to dirt.	Remedy
	Check/clean fan.

Inside the device: Fan is defective [0x00770011]

Module ID (decimal)	Error ID (decimal)
119: Temperature monitoring	17
Reaction (Lenze setting in bold)	
Setting: C00611 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Speed of internal fan is too low, e.g. due to dirt.	Remedy
	Check/clean fan.

Device utilisation Ixt > C00123 [0x00780000]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	0
Reaction (Lenze setting in bold)	
Setting: C00604 . (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Frequent and too long acceleration processes with overcurrent > C00123 .	Remedy
	Check drive dimensioning.

Device utilisation Ixt > 100 % [0x00780001]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Frequent and too long acceleration processes with overcurrent.	Remedy
	Check drive dimensioning.

Motor load I²xt > C00127 [0x00780002]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	2
Reaction (Lenze setting in bold)	
Setting: C00606 . (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> • impermissible continuous current • frequent or too long acceleration processes 	Remedy
	<ul style="list-style-type: none"> • Check drive dimensioning. • Check setting in C00127.

Motor load I³t > C00120 [0x00780003]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> • impermissible continuous current • frequent or too long acceleration processes 	<ul style="list-style-type: none"> • Check drive dimensioning. • Check setting in C00120.

Control card is defect (UB24) [0x00780004]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Control card is defect (VCC15) [0x00780005]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Control card is defect (UB8) [0x00780006]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Control card is defect (VCC15 neg.) [0x00780007]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Control card is defect (UB18 neg.) [0x00780008]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Control card is defect (VCC5) [0x00780009]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Please contact Lenze.

Electronic nameplate: Data are incompatible [0x0078000a]

Module ID (decimal)	Error ID (decimal)
120: Analog signal monitoring	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.

Device command transferred incorrectly [0x00790000]

Module ID (decimal)	Error ID (decimal)
121: Motor data interface	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Time error - controller interface [0x00790001]

Module ID (decimal)	Error ID (decimal)
121: Motor data interface	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Violation of time slice [0x00790002]

Module ID (decimal)	Error ID (decimal)
121: Motor data interface	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Motor: Calculated motor impedance unrealistic [0x007b0001]

Module ID (decimal)	Error ID (decimal)
123: Motor control	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Calculated mutual inductance unrealistic [0x007b0002]

Module ID (decimal)	Error ID (decimal)
123: Motor control	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor data are inconsistent [0x007b0003]

Module ID (decimal)	Error ID (decimal)
123: Motor control	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Phase resistance too high [0x007b0004]

Module ID (decimal)	Error ID (decimal)
123: Motor control	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Device current too low for rated magnetisation [0x007b0006]

Module ID (decimal)	Error ID (decimal)
123: Motor control	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Controller current is too low for rated magnetisation, i.e. the controller cannot energise the motor sufficiently.	Check drive dimensioning.

Motor: Rated current < rated magnetising current [0x007b0007]

Module ID (decimal)	Error ID (decimal)
123: Motor control	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters and setting of C00022 .

Motor: Calculated rotor resistance unrealistic [0x007b0009]

Module ID (decimal)	Error ID (decimal)
123: Motor control	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Calculated mutual inductance unrealistic [0x007b000a]

Module ID (decimal)	Error ID (decimal)
123: Motor control	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Calculated e. m. f. factor unrealistic [0x007b000b]

Module ID (decimal)	Error ID (decimal)
123: Motor control	11
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Calculated rotor time constant unrealistic [0x007b000c]

Module ID (decimal)	Error ID (decimal)
123: Motor control	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Motor: Calculated flux factor unrealistic [0x007b000d]

Module ID (decimal)	Error ID (decimal)
123: Motor control	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

DC bus overvoltage [0x007b000e]

Module ID (decimal)	Error ID (decimal)
123: Motor control	14
Reaction (Lenze setting in bold)	
Setting: C00600 . <input checked="" type="checkbox"/> Adjustable response <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Due to a too high braking energy, the DC-bus voltage exceeds the overvoltage threshold which results from the mains voltage setting in C00173 .	<ul style="list-style-type: none"> • Use brake resistor or regenerative module. • Check setting in C00173.

DC bus undervoltage [0x007b000f]

Module ID (decimal)	Error ID (decimal)
123: Motor control	15
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
DC bus voltage is lower than the undervoltage threshold resulting from the mains setting under C00173 .	<ul style="list-style-type: none"> • Check mains voltage. • Check setting in C00173.

Overcurrent detected [0x007b0010]

Module ID (decimal)	Error ID (decimal)
123: Motor control	16
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • Short circuit/earth fault in motor cable. • Excessive capacitive charging current in the motor cable. 	<ul style="list-style-type: none"> • Check motor cable. • Use shorter or lower-capacitance motor cable.

Earth fault detected [0x007b0011]

Module ID (decimal)	Error ID (decimal)
123: Motor control	17
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • Earth fault in motor cable. • Excessive capacitive charging current in the motor cable. 	<ul style="list-style-type: none"> • Check motor cable. • Use shorter or lower-capacitance motor cable.

Actual speed value outside the tolerance (C00576) [0x007b0012]

Module ID (decimal)	Error ID (decimal)
123: Motor control	18
Reaction (Lenze setting in bold)	
Setting: C00579 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Difference between actual and setpoint speed is too big.	<ul style="list-style-type: none"> • Increase speed tolerance margin under C00576. • Check drive dimensioning.

Motor control: Task overflow [0x007b0013]

Module ID (decimal)	Error ID (decimal)
123: Motor control	19
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error (motor control).	Please contact Lenze.

Internal communication error (host MCTRL) [0x007b0014]

Module ID (decimal)	Error ID (decimal)
123: Motor control	20
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error (motor control).	Please contact Lenze.

Motor data are inconsistent [0x007b0017]

Module ID (decimal)	Error ID (decimal)
123: Motor control	23
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Resolver: Open circuit [0x007b0018]

Module ID (decimal)	Error ID (decimal)
123: Motor control	24
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • Resolver cable interrupted. • Resolver defective. 	<ul style="list-style-type: none"> • Check resolver cable. • Check resolver. • Switch off the monitoring function (C00586="0") if no resolver is used.

Motor: Calculated leakage inductance unrealistic [0x007b0019]

Module ID (decimal)	Error ID (decimal)
123: Motor control	25
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Faulty motor parameterisation.	Check motor parameters.

Absolute value encoder: Communication error [0x007b001a]

Module ID (decimal)	Error ID (decimal)
123: Motor control	26
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Absolute value encoder does not send any data or a digital readout has been activated while the machine is coasting down.	<ul style="list-style-type: none"> • Check supply cable. • Check encoder. • Check voltage supply (C00421). • For Hiperface absolute value encoders: Check the initialisation time (C00412).

Encoder: Open circuit [0x007b001b]

Module ID (decimal)	Error ID (decimal)
123: Motor control	27
Reaction (Lenze setting in bold)	
Setting: C00580 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
<ul style="list-style-type: none"> Encoder cable interrupted. Encoder defective. Faulty parameter setting of the encoder. Interruption of the light path of laser measuring systems. Insufficient reflection of the light of laser measuring systems. <p>Note: The encoder open-circuit monitoring for incremental encoders (C00422 = "0: Incremental encoder (TTL signal)") requires a signal amplitude > 3.5 V! If the signal amplitude is lower than 3.0 V, the error response parameterised in C00580 is triggered.</p>	Remedy
	<ul style="list-style-type: none"> Check encoder cable. Check encoder. Check parameter setting (C00422). Switch off the monitoring function (C00580="0") if no encoder is used. Correct the light path (for laser measuring systems). Improve the reflection (for laser measuring systems).

Brake transistor: Ixt overload [0x007b001c]

Module ID (decimal)	Error ID (decimal)
123: Motor control	28
Reaction (Lenze setting in bold)	
Setting: C00573 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Too frequent and too long braking processes.	Remedy
	Check drive dimensioning.

Brake resistor: I²xt overload [0x007b001d]

Module ID (decimal)	Error ID (decimal)
123: Motor control	29
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Too frequent and too long braking processes.	Remedy
	<ul style="list-style-type: none"> Check drive dimensioning. Check parameter setting (C00129, C00130, C00131).

Motor: Actual current value > C00620 [0x007b001e]

Module ID (decimal)	Error ID (decimal)
123: Motor control	30
Reaction (Lenze setting in bold)	
Setting: C00619 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The instantaneous value of the motor current has exceeded the value set in C00620 .	Remedy
	<ul style="list-style-type: none"> Set a higher value in C00620. Reduce maximum current (C00022). Change response (C00619).

Resolver: Calculated acceleration unrealistic [0x007b001f]

Module ID (decimal)	Error ID (decimal)
123: Motor control	31
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Resolver evaluation faulty (implausible acceleration at the resolver).	Check structure.

Motor: Actual speed value > C00596 [0x007b0020]

Module ID (decimal)	Error ID (decimal)
123: Motor control	32
Reaction (Lenze setting in bold)	
Setting: C00607 <input checked="" type="checkbox"/> Adjustable response	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Threshold for speed monitoring set in C00596 has been exceeded.	Check drive dimensioning.

Brake transistor: Overcurrent [0x007b0021]

Module ID (decimal)	Error ID (decimal)
123: Motor control	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Brake chopper short circuit/earth fault detected.	Check brake chopper cable and brake resistor.

Position encoder: Module selected in C00490 not available [0x007b0023]

Module ID (decimal)	Error ID (decimal)
123: Motor control	35
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The position encode selected under C00490 has not been recognised.	<ul style="list-style-type: none"> • Check position encoder. • Check parameter setting (C00490).

Motor encoder: Module selected in C00495 not available [0x007b0024]

Module ID (decimal)	Error ID (decimal)
123: Motor control	36
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The motor encoder selected under C00495 has not been recognised.	<ul style="list-style-type: none"> • Check motor encoder. • Check parameter setting (C00495).

Motor temperature: Module selected in C01193 not available [0x007b0025]

Module ID (decimal)	Error ID (decimal)
123: Motor control	37
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The module for temperature feedback selected in C01193 has not been recognised.	<ul style="list-style-type: none"> • Check feedback module. • Check parameter setting (C01193).

EnDat encoder: Lamp error [0x007b0026]

Module ID (decimal)	Error ID (decimal)
123: Motor control	38
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Signal error [0x007b0027]

Module ID (decimal)	Error ID (decimal)
123: Motor control	39
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Position error [0x007b0028]

Module ID (decimal)	Error ID (decimal)
123: Motor control	40
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Overvoltage [0x007b0029]

Module ID (decimal)	Error ID (decimal)
123: Motor control	41
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Undervoltage [0x007b002a]

Module ID (decimal)	Error ID (decimal)
123: Motor control	42
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Overcurrent [0x007b002b]

Module ID (decimal)	Error ID (decimal)
123: Motor control	43
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
EnDat encoder defective.	Check EnDat encoder.

EnDat encoder: Battery empty [0x007b002c]

Module ID (decimal)	Error ID (decimal)
123: Motor control	44
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
EnDat encoder defective.	Check EnDat encoder.

Failure of motor phase U [0x007b002d]

Module ID (decimal)	Error ID (decimal)
123: Motor control	45
Reaction (Lenze setting in bold)	
Setting: C00597 (<input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
U phase interruption of motor cable.	<ul style="list-style-type: none"> • Check cabling between the controller and motor. • Check parameter setting (C00599).

Failure of motor phase V [0x007b002e]

Module ID (decimal)	Error ID (decimal)
123: Motor control	46
Reaction (Lenze setting in bold)	
Setting: C00597 (<input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
V phase interruption of the motor cable.	<ul style="list-style-type: none"> • Check cabling between the controller and motor. • Check parameter setting (C00599).

Failure of motor phase W [0x007b002f]

Module ID (decimal)	Error ID (decimal)
123: Motor control	47
Reaction (Lenze setting in bold)	
Setting: C00597 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
W phase interruption of the motor cable.	<ul style="list-style-type: none"> • Check cabling between the controller and motor. • Check parameter setting (C00599).

Electronic nameplate: Data loaded [0x007b0030]

Module ID (decimal)	Error ID (decimal)
123: Motor control	48
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
New electronic nameplate (ENP) has been found.	- (Information only)

Electronic nameplate: Not found [0x007b0031]

Module ID (decimal)	Error ID (decimal)
123: Motor control	49
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Electronic nameplate (ENP) is not available.	- (Information only)

Electronic nameplate: Encoder protocol unknown [0x007b0032]

Module ID (decimal)	Error ID (decimal)
123: Motor control	50
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.

Electronic nameplate: Encoder signal unknown [0x007b0033]

Module ID (decimal)	Error ID (decimal)
123: Motor control	51
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.

Internal communication error (DMA) [0x007b0034]

Module ID (decimal)	Error ID (decimal)
123: Motor control	52
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error.	Please contact Lenze.

Controller: Overload during acceleration phases [0x007b0035]

Module ID (decimal)	Error ID (decimal)
123: Motor control	53
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Frequent or too long acceleration processes.	<ul style="list-style-type: none"> • Check drive dimensioning. • Reduce steepness of acceleration ramps.

Internal communication error (MCTRL host) [0x007b0036]

Module ID (decimal)	Error ID (decimal)
123: Motor control	54
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error.	Please contact Lenze.

PLC configuration invalid [0x007b0037]

Module ID (decimal)	Error ID (decimal)
123: Motor control	55
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid control configuration has occurred.	Load a different application.

Motor parameter identification was cancelled [0x007b0038]

Module ID (decimal)	Error ID (decimal)
123: Motor control	56
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The motor current during identification was too high.	<ul style="list-style-type: none"> • The motor must not move during identification. • Check motor parameters.

Electronic nameplate: Data outside the parameter limits [0x007b0039]

Module ID (decimal)	Error ID (decimal)
123: Motor control	57
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The motor parameters of the electronic nameplate are outside of the limit values of the controller and therefore cannot be accepted.	Please contact Lenze.

Hiperface encoder: Transmission error [0x007b003a]

Module ID (decimal)	Error ID (decimal)
123: Motor control	58
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> Encoder signal interferences (EMC). Encoder cable interrupted. Encoder defective. Faulty parameter setting of the encoder. <p>Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).</p>	<ul style="list-style-type: none"> Check encoder cable, use shorter encoder cable if required. Check encoder. Check parameter setting (C00420, C00421, C00422).

Hiperface encoder: Command error [0x007b003b]

Module ID (decimal)	Error ID (decimal)
123: Motor control	59
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> Encoder signal interferences (EMC). Encoder cable interrupted. Encoder defective. Faulty parameter setting of the encoder. <p>Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).</p>	<ul style="list-style-type: none"> Check encoder cable, use shorter encoder cable if required. Check encoder. Check parameter setting (C00420, C00421, C00422).

HiPerface encoder: Unknown encoder [0x007b003c]

Module ID (decimal)	Error ID (decimal)
123: Motor control	60
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Encoder is not supported by the controller firmware.	<ul style="list-style-type: none"> • Exchange encoder for known type. • From software version V4.0: Parameterise the unknown encoder with the codes C00414 (type code) and C00415 (number of revolutions).

HiPerface encoder: Position initialisation error [0x007b003d]

Module ID (decimal)	Error ID (decimal)
123: Motor control	61
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<p>A digital readout of the absolute encoder is only possible at standstill.</p> <p>The readout is activated by the following actions:</p> <ul style="list-style-type: none"> • Mains switching • Change of C00420, C00422 and C00427 • To "Absolute value encoder: Communication error" • To "Encoder: Open circuit" <p>Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).</p>	Prevent coasting of the machine while the absolute encoder is read out.

Encoder monitoring: Pulse deviation detected [0x007b003e]

Module ID (decimal)	Error ID (decimal)
123: Motor control	62
Reaction (Lenze setting in bold)	
Setting: C00621 (<input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • Encoder signal interferences (EMC). • Encoder cable interrupted. • Encoder defective. • Faulty parameter setting of the encoder. 	<ul style="list-style-type: none"> • Check encoder cable, use shorter encoder cable if required. • Check encoder. • Check parameter setting (C00422). • Possibly switch off monitoring (C00621).

Failure of a mains phase [0x007b003f]

Module ID (decimal)	Error ID (decimal)
123: Motor control	63
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Missing mains phase. Note: This monitoring is only available for devices ≥ 75 kW (type 8S and bigger).	Check mains connection.

Brake chopper: Ixt > C00570 [0x007b0040]

Module ID (decimal)	Error ID (decimal)
123: Motor control	64
Reaction (Lenze setting in bold)	
Setting: C00569 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Frequent and too long braking.	<ul style="list-style-type: none"> • Check drive dimensioning. • Check setting in C00570.

Brake resistor: I2t > C00572 [0x007b0041]

Module ID (decimal)	Error ID (decimal)
123: Motor control	65
Reaction (Lenze setting in bold)	
Setting: C00571 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Frequent and too long braking.	<ul style="list-style-type: none"> • Check drive dimensioning. • Check setting in C00572. • Check settings for brake resistor (C00129, C00130, C00131).

Power section is defect [0x007b0042]

Module ID (decimal)	Error ID (decimal)
123: Motor control	66
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Device error	Mains switching <ul style="list-style-type: none"> • Please contact Lenze if the problem occurs again.

Controller: Clamp operation [0x007b0047]

Module ID (decimal)	Error ID (decimal)
123: Motor control	71
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Actual motor current is higher than the maximum device current (C00789).	<ul style="list-style-type: none"> • Increase speed setpoint ramps. • Optimise I_{max} controller.

Pole position recognition cancelled [0x007b004a]

Module ID (decimal)	Error ID (decimal)
123: Motor control	74
Reaction (Lenze setting in bold)	
Setting: C00640 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
From software version V4.0 An error occurred during the pole position identification. The pole position identification could not be completed successfully.	<ul style="list-style-type: none"> • Check whether all requirements for an identification of the pole position are fulfilled. • Ensure that the machine is not braked or blocked during the pole position identification. • Repeat the pole position identification.

Motor switched off [0x007b004c]

Module ID (decimal)	Error ID (decimal)
123: Motor control	76
Reaction (Lenze setting in bold)	
Setting: C00597 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
From software version V5.0 Interruption of several motor cable phases.	Check cabling between the controller and motor.

EnDat encoder: Transmission error [0x007b004e]

Module ID (decimal)	Error ID (decimal)
123: Motor control	78
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • Encoder signal interferences (EMC). • Encoder cable interrupted. • Encoder defective. • Faulty parameter setting of the encoder. Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).	<ul style="list-style-type: none"> • Check encoder cable, use shorter encoder cable if required. • Check encoder. • Check parameter setting (C00420, C00421, C00422).

EnDat encoder: Command error [0x007b004f]

Module ID (decimal)	Error ID (decimal)
123: Motor control	79
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> Encoder signal interferences (EMC). Encoder cable interrupted. Encoder defective. Faulty parameter setting of the encoder. <p>Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).</p>	<ul style="list-style-type: none"> Check encoder cable, use shorter encoder cable if required. Check encoder. Check parameter setting (C00420, C00421, C00422).

EnDat encoder: Position initialisation error [0x007b0050]

Module ID (decimal)	Error ID (decimal)
123: Motor control	80
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<p>A digital readout of the absolute encoder is only possible at standstill.</p> <p>The readout is activated by the following actions:</p> <ul style="list-style-type: none"> Mains switching Change of C00420, C00422 and C00427 To "Absolute value encoder: Communication error" To "Encoder: Open circuit" <p>Note: This information is always supplied together with the "I/O error - encoder communication" error message and is entered in the logbook even if the encoder monitoring is deactivated (C00580).</p>	Prevent coasting of the machine while the absolute encoder is read out.

Memory module: File system has been formatted [0x007c0000]

Module ID (decimal)	Error ID (decimal)
124: Device command module (C00002)	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
File system of the memory module has been formatted.	- (Information only)

Memory module: File system has been restored [0x007c0001]

Module ID (decimal)	Error ID (decimal)
124: Device command module (C00002)	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
File system of the memory module has been restored.	- (Information only)

Analog input 1: Master current < 4 mA [0x007d0000]

Module ID (decimal)	Error ID (decimal)
125: Processing of analog inputs/outputs	0
Reaction (Lenze setting in bold)	
Setting: C00598 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Master current is in the impermissible range -4 ... +4 mA, e. g. due to a cable break or a defective master current value encoder.	
<ul style="list-style-type: none"> Only for parameterisation as master current input (see C00034). 	
Remedy	
Remove cable break.	

PLC configuration invalid [0x007d0001]

Module ID (decimal)	Error ID (decimal)
125: Processing of analog inputs/outputs	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
An invalid control configuration has occurred.	
Remedy	
Load a different application.	

Communication error between device and device module [0x007f0002]

Module ID (decimal)	Error ID (decimal)
127: Interface to the intelligent communication module	2
Reaction (Lenze setting in bold)	
Setting: C01501 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
Communication between the controller and extension module is interrupted, e.g. due to disturbances in the ambience (EMC), defective hardware, or loose contact.	
<ul style="list-style-type: none"> This monitoring is designed for safe process data communication. 	
Remedy	
<ul style="list-style-type: none"> Eliminate EMC interference. Switch off inverter, correctly plug in the module, switch on the inverter again. Switch mains or restart inverter. Replace module/inverter. Please contact Lenze if the problem occurs again. 	

Communication with module in MXI1 interrupted [0x007f0003]

Module ID (decimal)	Error ID (decimal)
127: Interface to the intelligent communication module	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Communication between the controller and the extension module in module slot MXI1 cannot be established.	
Remedy	
<ul style="list-style-type: none"> Switch off controller, plug module correctly in module slot MXI1, switch on controller again. If the problem occurs again, replace the module. 	

Communication with module in MX12 interrupted [0x007f0004]

Module ID (decimal)	Error ID (decimal)
127: Interface to the intelligent communication module	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Communication between the controller and the extension module in module slot MX12 cannot be established.	<ul style="list-style-type: none"> • Switch off controller, plug module correctly in module slot MX12, switch on controller again. • If the problem occurs again, replace the module.

CAN on board: Bus off [0x00830000]

Module ID (decimal)	Error ID (decimal)
131: "CAN on board": CAN dispatcher	0
Reaction (Lenze setting in bold)	
Setting: C00595 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: "Bus-Off" state <ul style="list-style-type: none"> • Received too many faulty telegrams. • Defective cable (e.g. loose contact). • Two nodes with the same ID. 	<ul style="list-style-type: none"> • Remove fault (e.g. EMC). • Remove loose contact, screw down adapter. • Assign different IDs to nodes.

CAN on board: Invalid node address 0 [0x00830001]

Module ID (decimal)	Error ID (decimal)
131: "CAN on board": CAN dispatcher	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: initialisation error <ul style="list-style-type: none"> • The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero. Note: Instead of the impermissible node address 0, node address 1 is used.	<ul style="list-style-type: none"> • Set a non-zero node address by means of the DIP switches and then switch mains. • Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains.

CAN on board: Basic configuration invalid [0x00830002]

Module ID (decimal)	Error ID (decimal)
131: "CAN on board": CAN dispatcher	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: configuration error <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project • Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN on board: Heartbeat error index 1 ... 32 [0x00840000 ... 0x0084001f]

Module ID (decimal)	Error ID (decimal)
132: "CAN on board": CAN-NMT handler	0 ... 31
Reaction (Lenze setting in bold)	
Setting: C00613/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary. Tip: Save the current parameter set before mains switching and restart of the controller (C00002 ="11").

CAN on board: Lifeguarding error [0x00840020]

Module ID (decimal)	Error ID (decimal)
132: "CAN on board": CAN-NMT handler	32
Reaction (Lenze setting in bold)	
Setting: C00614 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded. 	Select a different Lifeguarding monitoring time or switch off monitoring.

CAN on board: Faulty NMT slave configuration [0x00840021]

Module ID (decimal)	Error ID (decimal)
132: "CAN on board": CAN-NMT handler	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN on board: Faulty emergency configuration [0x00850000]

Module ID (decimal)	Error ID (decimal)
133: "CAN on board": CAN emergency handler	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN emergency configuration is faulty. <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project • Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN on board: Node guarding error 1 ... 32 [0x00860000 ... 0x0086001f]

Module ID (decimal)	Error ID (decimal)
134: "CAN on board": CAN-NMT master	0 ... 31
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: C00612/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> • CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> • Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. • Select a different node guarding monitoring time or switch off monitoring. • Reset potentially caught error status. Tip: Save the current parameter set before mains switching and restart of the controller (C00002 ="11").

CAN on board: Faulty NMT master configuration [0x00860020]

Module ID (decimal)	Error ID (decimal)
134: "CAN on board": CAN-NMT master	32
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project. • Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer. • Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN on board RPDO1: Telegram not received or faulty [0x00870000]

Module ID (decimal)	Error ID (decimal)
135: "CAN on board": CAN-PDO handler	0
Reaction (Lenze setting in bold)	
Setting: C00591/1 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 1 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN on board RPDO2: Telegram not received or faulty [0x00870001]

Module ID (decimal)	Error ID (decimal)
135: "CAN on board": CAN-PDO handler	1
Reaction (Lenze setting in bold)	
Setting: C00591/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 2 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN on board RPDO3: Telegram not received or faulty [0x00870002]

Module ID (decimal)	Error ID (decimal)
135: "CAN on board": CAN-PDO handler	2
Reaction (Lenze setting in bold)	
Setting: C00591/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 3 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN on board RPDO4: Telegram not received or faulty [0x00870003]

Module ID (decimal)	Error ID (decimal)
135: "CAN on board": CAN-PDO handler	3
Reaction (Lenze setting in bold)	
Setting: C00591/4 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 4 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN on board PDO manager: Faulty configuration [0x00870008]

Module ID (decimal)	Error ID (decimal)
135: "CAN on board": CAN-PDO handler	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-PDO configuration error <ul style="list-style-type: none"> • Faulty project download. • Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. • Mapping variables have incorrect CANopen indices according to DS405. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN on board SDO server: Faulty configuration [0x00880000]

Module ID (decimal)	Error ID (decimal)
136: "CAN on board": CAN-SDO server	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: A configuration error has occurred in the CAN SDO server. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN on board SDO client: Faulty configuration [0x00890000]

Module ID (decimal)	Error ID (decimal)
137: "CAN on board": CAN-SDO client	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: A configuration error has occurred in the CAN SDO client. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

File ProjectSelection.dat defect [0x008c0000]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002="1030") and repeat project download.

File ProjectList.dat defect [0x008c0001]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File DeviceCFG.dat defect [0x008c0002]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File ProjectSelection.dat is missing [0x008c0003]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File ProjectList.dat is missing [0x008c0004]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File DeviceCFG.dat is missing [0x008c0005]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File ProjectSelection.dat invalid [0x008c0006]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File ProjectList.dat invalid [0x008c0007]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

File DeviceCFG.dat invalid [0x008c0008]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Reformat memory module (C00002 ="1030") and repeat project download.

Project is not loaded [0x008c0009]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Application could not be loaded because of a file error.	Load new or different application.

Project is not available [0x008c000a]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Application not available.	<ul style="list-style-type: none"> • Download application with Engineer • Switch off controller and use a different memory module with an existing application.

Required licence missing [0x008c000b]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	11
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Memory module could not be initialised.	Two possibilities: <ul style="list-style-type: none"> • Use Engineer to download and activate an application suitable for the memory module. • Switch off controller and use memory module suitable for the application.

Application and device are incompatible [0x008c000c]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Application is incompatible with the controller.	<ul style="list-style-type: none"> • Download of an application suitable for the controller using Engineer. • Switch off controller and use a different memory module with suitable application.

MX11: Module is missing or incompatible [0x008c000d]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Extension module in module slot MX11 is incompatible with the application.	Use extension module supported by the application.

MX12: Module is missing or incompatible [0x008c000e]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	14
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Extension module in module slot MX12 is incompatible with the application.	Use extension module supported by the application.

MXI1: PROFIBUS module is missing or incompatible [0x008c000f]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	15
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
E94AYCPM communication module (PROFIBUS) in module slot MXI1 is incompatible with the application.	Use communication module supported by the application.

MXI2: PROFIBUS module is missing or incompatible [0x008c0010]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	16
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
E94AYCPM communication module (PROFIBUS) in module slot MXI2 is incompatible with the application.	Use communication module supported by the application.

MXI1: Ethernet module is missing or incompatible [0x008c0011]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	17
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
E94AYCEN communication module (Ethernet) in module slot MXI1 is incompatible with the application.	Use communication module supported by the application.

MXI2: Ethernet module is missing or incompatible [0x008c0012]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	18
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
E94AYCEN communication module (Ethernet) in module slot MXI2 is incompatible with the application.	Use communication module supported by the application.

MXI1: Digital frequency module is missing or incompatible [0x008c0013]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	19
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in module slot MXI1 is incompatible with the application.	Use extension module supported by the application.

MXI2: Digital frequency module is missing or incompatible [0x008c0014]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	20
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Digital frequency extension module in module slot MXI2 is incompatible with the application.	Remedy
	Use extension module supported by the application.

MXI1: ICM module is missing or incompatible [0x008c0015]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	21
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
ICM extension module in module slot MXI1 is incompatible with the application.	Remedy
	Use extension module supported by the application.

MXI2: ICM module is missing or incompatible [0x008c0016]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	22
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
ICM extension module in module slot MXI2 is incompatible with the application.	Remedy
	Use extension module supported by the application.

MXI1: CAN module is missing or incompatible [0x008c0017]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	23
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
CANopen communication module in module slot MXI1 is incompatible with the application.	Remedy
	Use communication module supported by the application.

MXI2: CAN module is missing or incompatible [0x008c0018]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	24
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
CANopen communication module in module slot MXI2 is incompatible with the application.	Remedy
	Use communication module supported by the application.

ConnectTable active [0x008c001a]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	26
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The application is provided with a so-called connection table, i. e. connections can be altered "online" in the function block editor without having to carry out a new complete download.	- (Information only)

Internal error (CRC application) [0x008c001d]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	29
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • The checksum of the application is faulty. • Files required to run the application are missing. • The supply voltage failed before the entire parameter set could be saved. 	Transmit the application to the controller again.

Storage capacity for user parameters exceeded [0x008c001e]

Module ID (decimal)	Error ID (decimal)
140: Application project manager	30
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Due to the creation of too many user parameters within the application, the storage capacity available on the memory module has been exceeded. User parameters are produced directly by manual creation or indirectly by the insertion of function blocks.	<ul style="list-style-type: none"> • Use an MM4xx memory module instead of the MM3xx type (approx. twice the storage capacity). • Remove unnecessary, manually created user parameters from the application. • Remove unnecessary function blocks from the application. • Recompile the application and download it again. • Acknowledge the error. Then the current utilisation of the memory can be assessed using code C02112 . If 100 % is displayed, this corresponds to the maximum utilisation for an executable application.

Parameter set faulty [0x00900000]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Parameter set is invalid.	Transfer parameter set from Engineer to the controller and save with C00002 ="11".

Lenze setting loaded [0x00900001]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Lenze setting has been loaded.	- (Information only)

Parameter set saved [0x00900002]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Parameter set has been saved.	- (Information only)

Parameter set loaded [0x00900003]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Parameter set has been loaded.	- (Information only)

Loading of Lenze setting failed [0x00900004]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Lenze setting of a parameter is not within the valid limits.	Eliminate error in the application and retransfer application to controller.

Parameter set restored [0x00900005]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An error has occurred while loading the selected parameter set.	Transfer parameter set from Engineer to the controller and save with <code>C00002="11"</code> .

Saving of parameters failed [0x00900006]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An error has occurred while saving the current parameter set.	Use a different memory module.

Parameter set: Version conflict [0x00900007]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	7
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The parameter set version on the memory module is not compatible with the firmware of the controller.	Transfer parameter set from Engineer to the controller and save with <code>C00002="11"</code> .

Code number duplicated [0x00900008]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Code number of the operating system has been assigned to the application.	Eliminate error in the application and retransfer application to controller.

Parameter set: Type of standard device has been changed [0x00900009]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The firmware has loaded a parameter set the type code of which does not correspond to the type code of the controller.	Load a suitable parameter set.

No parameters for module in MXI1 [0x0090000a]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	10
Reaction (Lenze setting in bold)	
Setting: C00615/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
The parameter set contains no parameters for the module inserted in MXI1.	Remedy
	Integrate the module inserted in MXI1 into the Engineer project and then retransmit the parameter set to the controller.

No parameters for module in MXI2 [0x0090000b]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	11
Reaction (Lenze setting in bold)	
Setting: C00615/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
The parameter set contains no parameters for the module inserted in MXI2.	Remedy
	Integrate the module inserted in MXI2 into the Engineer project and then retransmit the parameter set to the controller.

Disconnection in the case of par. storage [0x0090000c]

Module ID (decimal)	Error ID (decimal)
144: Parameter manager	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The supply voltage has failed before the saving of the parameter set could be completed. In the case of a device replacement/firmware update, the parameter set can no longer be established automatically.	Remedy
	Save the start parameters again, and in doing this, ensure that the supply voltage is applied until the saving process has been completed. Afterwards acknowledge the error message with "Reset error".

Mains voltage is switched on [0x00910000]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Mains voltage has been switched on.	Remedy
	- (Information only)

Mains voltage is switched off [0x00910001]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Mains voltage has been switched off.	- (Information only)

No heartbeat signal detected [0x00910002]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Heartbeat not periodic [0x00910003]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Internal error: See C00180 [0x00910004]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Internal error: See C00180 [0x00910005]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	Please contact Lenze.

Internal error: See C00180 [0x00910006]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	6
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Divisor of division was "0".	Replace application.

Internal error: See C00180 [0x00910008]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Internal error: See C00180 [0x00910009]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	9
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

System task 1: Task overflow [0x0091000a]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	10
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
System overload.	Please contact Lenze.

System task 2: Task overflow [0x0091000b]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	11
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
System overload.	Please contact Lenze.

System task 3: Task overflow [0x0091000c]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	12
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
System overload.	Please contact Lenze.

System task: Task overflow [0x0091000d]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	13
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
System overload.	Please contact Lenze.

Communication task: Standstill > 3 s [0x0091000e]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	14
Reaction (Lenze setting in bold)	
Setting: C01230 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Service data communication within the system (SDO communication of all bus systems connected) has caused an overload of service data processing. Due to this, the monitoring interval of the processing task has been violated. PDO communication is not affected by this overload.	Reduce system load. <ul style="list-style-type: none"> • Reduce the data and communication volume on the buses. Processing will restart automatically when the overload has been eliminated. For systems frequently affected by this type of overload, the error response can be changed to warning via code C01230 in order to increase the drive availability.

Cyclic task: Standstill > 60 s [0x0091000f]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	15
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
System overload or CRC check task crash.	Reduce system load. <ul style="list-style-type: none"> • This is possible in the application or data transfer of the communication interfaces.

Position value faulty [0x00910010]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	16
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Error during initialisation [0x00910011]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	17
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Block function in wrong MEC task [0x00910012]

Module ID (decimal)	Error ID (decimal)
145: Lenze runtime system	18
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Internal error	If the error occurs frequently, please contact Lenze.

Safety module: Incompatible with setting in C00214 [0x00920000]

Module ID (decimal)	Error ID (decimal)
146: Interface to the safety module	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The controller has detected a safety module which does not match the setting under C00214 .	Change setting under C00214 or use a suitable safety module. <ul style="list-style-type: none"> • Afterwards mains switching is required.

Communication with safety module interrupted [0x00920001]

Module ID (decimal)	Error ID (decimal)
146: Interface to the safety module	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
It is not possible to establish communication between the controller and safety module.	<ul style="list-style-type: none"> • Switch off the controller, plug in safety module correctly and switch on the controller again. • If the problem occurs again, replace the safety module.

DFIN (MXI1): Track error A-/A [0x00990000]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	0
Reaction (Lenze setting in bold)	
Setting: C13040 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track A.	<ul style="list-style-type: none"> • Check signal cable for track A. • Check encoder.

DFIN (MXI1): Track error B-/B [0x00990001]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	1
Reaction (Lenze setting in bold)	
Setting: C13040 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track B.	<ul style="list-style-type: none"> • Check signal cable for track B. • Check encoder.

DFIN (MXI1): Track error Z-/Z [0x00990002]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	2
Reaction (Lenze setting in bold)	
Setting: C13040 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"> • Check signal cable for track Z. • Check encoder.

DFIN (MXI1): Signal error enable/lamp control [0x00990003]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	3
Reaction (Lenze setting in bold)	
Setting: C13041 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"> • Check signal cable for "Enable" signal. • Check encoder.

DFIN (MXI1): Supply cannot be corrected anymore [0x00990004]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	4
Reaction (Lenze setting in bold)	
Setting: C13042 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Digital frequency extension module in MXI1: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	
Remedy	
Check encoder.	

DFOUT (MXI1): Maximum frequency reached [0x00990005]

Module ID (decimal)	Error ID (decimal)
153: Extension module - digital frequency in MXI1	5
Reaction (Lenze setting in bold)	
Setting: C13080 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
Digital frequency extension module in MXI1: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"> The digital frequency has reached the limit value set in C013053. 	
Remedy	
Check limit value set.	

CAN module (MXI1): Bus off [0x009d0000]

Module ID (decimal)	Error ID (decimal)
157: CAN module in MXI1: CAN dispatcher	0
Reaction (Lenze setting in bold)	
Setting: C13595 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
CANopen communication module in MXI1: "Bus-off" state <ul style="list-style-type: none"> Received too many faulty telegrams. Defective cable (e.g. loose contact). Two nodes with the same ID. 	
Remedy	
<ul style="list-style-type: none"> Remove fault (e.g. EMC). Remove loose contact, screw down adapter. Assign different IDs to nodes. 	

CAN module (MXI1): Invalid node address 0 [0x009d0001]

Module ID (decimal)	Error ID (decimal)
157: CAN module in MXI1: CAN dispatcher	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
CANopen communication module in MXI1: Initialisation error <ul style="list-style-type: none"> The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero. Note: Instead of the impermissible node address 0, node address 1 is used.	
Remedy	
<ul style="list-style-type: none"> Set a non-zero node address by means of the DIP switches and then switch mains. Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains. 	

CAN module (MXI1): Basic configuration invalid [0x009d0002]

Module ID (decimal)	Error ID (decimal)
157: CAN module in MXI1: CAN dispatcher	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Configuration error <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN module (MXI1): Heartbeat error index 1 ... 32 [0x009e0000 ... 0x009e001f]

Module ID (decimal)	Error ID (decimal)
158: CAN module in MXI1: CAN-NMT handler	0 ... 31
Reaction (Lenze setting in bold)	
Setting: C13613/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"> Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary. <p>Tip: Save the current parameter set before mains switching and restart of the controller (C00002="11").</p>

CAN module (MXI1): Lifeguarding error [0x009e0020]

Module ID (decimal)	Error ID (decimal)
158: CAN module in MXI1: CAN-NMT handler	32
Reaction (Lenze setting in bold)	
Setting: C13614 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"> Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded. 	Select a different Lifeguarding monitoring time or switch off monitoring.

CAN module (MXI1): Faulty NMT slave configuration [0x009e0021]

Module ID (decimal)	Error ID (decimal)
158: CAN module in MXI1: CAN-NMT handler	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project • Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. • Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN module (MXI1): Faulty emergency configuration [0x009f0000]

Module ID (decimal)	Error ID (decimal)
159: CAN module in MXI1: CAN emergency handler	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN emergency configuration is faulty. <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project • Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN module (MXI1): Node guarding error 1 ... 32 [0x00a00000 ... 0x00a0001f]

Module ID (decimal)	Error ID (decimal)
160: CAN module in MXI1: CAN-NMT master	0 ... 31
Reaction (Lenze setting in bold)	
Setting: C13612/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"> • CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> • Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. • Select a different node guarding monitoring time or switch off monitoring. • Reset potentially caught error status. Tip: Save the current parameter set before mains switching and restart of the controller (C00002 ="11").

CAN module (MXI1): Faulty NMT master configuration [0x00a00020]

Module ID (decimal)	Error ID (decimal)
160: CAN module in MXI1: CAN-NMT master	32
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"> • Faulty download of an Engineer or PLC Designer project. • Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer. • Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

CAN module (MXI1) RPDO1: Telegram not received or faulty [0x00a10000]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	0
Reaction (Lenze setting in bold)	
Setting: C13591/1 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 1 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO2: Telegram not received or faulty [0x00a10001]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	1
Reaction (Lenze setting in bold)	
Setting: C13591/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 2 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO3: Telegram not received or faulty [0x00a10002]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	2
Reaction (Lenze setting in bold)	
Setting: C13591/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 3 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO4: Telegram not received or faulty [0x00a10003]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	3
Reaction (Lenze setting in bold)	
Setting: C13591/4 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 4 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO5: Telegram not received or faulty [0x00a10004]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	4
Reaction (Lenze setting in bold)	
Setting: C13591/5 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 5 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO6: Telegram not received or faulty [0x00a10005]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	5
Reaction (Lenze setting in bold)	
Setting: C13591/6 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 6 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO7: Telegram not received or faulty [0x00a10006]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	6
Reaction (Lenze setting in bold)	
Setting: C13591/7 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 7 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) RPDO8: Telegram not received or faulty [0x00a10007]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	7
Reaction (Lenze setting in bold)	
Setting: C13591/8 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-IN 8 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI1) PDO manager: Faulty configuration [0x00a10008]

Module ID (decimal)	Error ID (decimal)
161: CAN module in MXI1: CAN-PDO handler	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: CAN-PDO configuration error <ul style="list-style-type: none"> • Faulty project download. • Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. • Mapping variables have incorrect CANopen indices according to DS405. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN module (MXI1) SDO server: Faulty configuration [0x00a20000]

Module ID (decimal)	Error ID (decimal)
162: CAN module in MXI1: CAN-SDO server	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: In the CAN SDO server a configuration error has occurred. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN module (MXI1) SDO client: Faulty configuration [0x00a30000]

Module ID (decimal)	Error ID (decimal)
163: CAN module in MXI1: CAN-SDO client	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI1: In the CAN SDO client a configuration error has occurred. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

DFIN (MXI2): Track error A-/A [0x00aa0000]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	0
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: C14040 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track A.	<ul style="list-style-type: none"> • Check signal cable for track A. • Check encoder.

DFIN (MXI2): Track error B-/B [0x00aa0001]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	1
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: C14040 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track B.	<ul style="list-style-type: none"> • Check signal cable for track B. • Check encoder.

DFIN (MXI2): Track error Z-/Z [0x00aa0002]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	2
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: C14040 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"> • Check signal cable for track Z. • Check encoder.

DFIN (MXI2): Signal error enable/lamp control [0x00aa0003]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	3
Reaction (Lenze setting in bold)	Setting: C14041 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"> • Check signal cable for "Enable" signal. • Check encoder.

DFIN (MXI2): Supply cannot be corrected anymore [0x00aa0004]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	4
Reaction (Lenze setting in bold)	Setting: C14042 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI2: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	Check encoder.

DFOUT (MXI2): Maximum frequency reached [0x00aa0005]

Module ID (decimal)	Error ID (decimal)
170: Extension module - digital frequency in MXI2	5
Reaction (Lenze setting in bold)	Setting: C14080 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Digital frequency extension module in MXI2: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"> • The digital frequency has reached the limit value set in C014053. 	Check limit value set.

CAN module (MXI2): Bus off [0x00ac0000]

Module ID (decimal)	Error ID (decimal)
172: CAN module in MXI2: CAN dispatcher	0
Reaction (Lenze setting in bold)	Setting: C14595 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: "Bus-off" state <ul style="list-style-type: none"> • Received too many faulty telegrams. • Defective cable (e.g. loose contact). • Two nodes with the same ID. 	<ul style="list-style-type: none"> • Remove fault (e.g. EMC). • Remove loose contact, screw down adapter. • Assign different IDs to nodes.

CAN module (MXI2): Invalid node address 0 [0x00ac0001]

Module ID (decimal)	Error ID (decimal)
172: CAN module in MXI2: CAN dispatcher	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Initialisation error <ul style="list-style-type: none"> The hardware allocation of the node address was selected via DIP switches, and the DIP switches of the node address are all on zero. Note: Instead of the impermissible node address 0, node address 1 is used.	<ul style="list-style-type: none"> Set a non-zero node address by means of the DIP switches and then switch mains. Activation of the software allocation of the node number by switching over DIP switch 2, then switch mains.

CAN module (MXI2): Basic configuration invalid [0x00ac0002]

Module ID (decimal)	Error ID (decimal)
172: CAN module in MXI2: CAN dispatcher	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Configuration error <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN module (MXI2): Heartbeat error index 1 ... 32 [0x00ad0000 ... 0x00ad001f]

Module ID (decimal)	Error ID (decimal)
173: CAN module in MXI2: CAN-NMT handler	0 ... 31
Reaction (Lenze setting in bold)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: C14613/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
Cause	Remedy
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> Node station has not received a heartbeat telegram from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary. Tip: Save the current parameter set before mains switching and restart of the controller (C00002 ="11").

CAN module (MXI2): Lifeguarding error [0x00ad0020]

Module ID (decimal)	Error ID (decimal)
173: CAN module in MXI2: CAN-NMT handler	32
Reaction (Lenze setting in bold)	
Setting: C14614 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded. 	Select a different Lifeguarding monitoring time or switch off monitoring.

CAN module (MXI2): Faulty NMT slave configuration [0x00ad0021]

Module ID (decimal)	Error ID (decimal)
173: CAN module in MXI2: CAN-NMT handler	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN module (MXI2): Faulty emergency configuration [0x00ae0000]

Module ID (decimal)	Error ID (decimal)
174: CAN module in MXI2: CAN emergency handler	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN emergency configuration is faulty. <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN module (MXI2): Node guarding error 1 ... 32 [0x00af0000 ... 0x00a0001f]

Module ID (decimal)	Error ID (decimal)
175: CAN module in MXI2: CAN-NMT master	0 ... 31
Reaction (Lenze setting in bold)	
Setting: C14612/1...32 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 ... 32 within the defined time. 	<ul style="list-style-type: none"> Reactivate CAN node by mains switching, restart of the controller (C00002="11000") or CAN reset node. Select a different node guarding monitoring time or switch off monitoring. Reset potentially caught error status. Tip: Save the current parameter set before mains switching and restart of the controller (C00002 ="11").

CAN module (MXI2): Faulty NMT master configuration [0x00af0020]

Module ID (decimal)	Error ID (decimal)
175: CAN module in MXI2: CAN-NMT master	32
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"> Faulty download of an Engineer or PLC Designer project. Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer. Incorrect parameterisation of node guarding or heartbeat. 	<ul style="list-style-type: none"> Repeat download Correct CAN settings in the project and regenerate project.

CAN module (MXI2) RPDO1: Telegram not received or faulty [0x00b00000]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	0
Reaction (Lenze setting in bold)	
Setting: C14591/1 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 1 error <ul style="list-style-type: none"> Incorrect PDO telegram length. Transmission error. Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> Set correct telegram length for CAN master (transmitter). Eliminate trouble in the environment (e. g. EMC). Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO2: Telegram not received or faulty [0x00b00001]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	1
Reaction (Lenze setting in bold)	
Setting: C14591/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 2 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO3: Telegram not received or faulty [0x00b00002]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	2
Reaction (Lenze setting in bold)	
Setting: C14591/3 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 3 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO4: Telegram not received or faulty [0x00b00003]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	3
Reaction (Lenze setting in bold)	
Setting: C14591/4 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 4 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO5: Telegram not received or faulty [0x00b00004]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	4
Reaction (Lenze setting in bold)	
Setting: C14591/5 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 5 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO6: Telegram not received or faulty [0x00b00005]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	5
Reaction (Lenze setting in bold)	
Setting: C14591/6 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 6 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO7: Telegram not received or faulty [0x00b00006]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	6
Reaction (Lenze setting in bold)	
Setting: C14591/7 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 7 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) RPDO8: Telegram not received or faulty [0x00b00007]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	7
Reaction (Lenze setting in bold)	
Setting: C14591/8 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-IN 8 error <ul style="list-style-type: none"> • Incorrect PDO telegram length. • Transmission error. • Time monitoring of the PDOs has tripped. 	<ul style="list-style-type: none"> • Set correct telegram length for CAN master (transmitter). • Eliminate trouble in the environment (e. g. EMC). • Select a different time monitoring or switch off time monitoring.

CAN module (MXI2) PDO manager: Faulty configuration [0x00b00008]

Module ID (decimal)	Error ID (decimal)
176: CAN module in MXI2: CAN-PDO handler	8
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: CAN-PDO configuration error <ul style="list-style-type: none"> • Faulty project download. • Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer. • Mapping variables have incorrect CANopen indices according to DS405. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN module (MXI2) SDO server: Faulty configuration [0x00b10000]

Module ID (decimal)	Error ID (decimal)
177: CAN module in MXI2: CAN-SDO server	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: In the CAN SDO server a configuration error has occurred. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download. • Correct CAN settings in the project and regenerate project.

CAN module (MXI2) SDO client: Faulty configuration [0x00b20000]

Module ID (decimal)	Error ID (decimal)
178: CAN module in MXI2: CAN-SDO client	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CANopen communication module in MXI2: In the CAN SDO client a configuration error has occurred. <ul style="list-style-type: none"> • Faulty project download. • Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer. 	<ul style="list-style-type: none"> • Repeat download • Correct CAN settings in the project and regenerate project.

PLC configuration invalid [0x00b80000]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	0
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
An invalid control configuration has occurred.	Load a different application.

Positive limit switch has triggered [0x00b80001]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	1
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The travel range limit switch in positive traversing direction has tripped.	Reset fault message and retract limit switch .

Negative limit switch has triggered [0x00b80002]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	2
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The travel range limit switch in negative traversing direction has tripped.	Remedy
	Reset fault message and retract limit switch .

Motor brake: Angular drift with closed brake too high [0x00b80003]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	3
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	
The stop position of the motor axis has changed by more than the permissible angle of rotation set in C02595 , although the brake is engaged.	Remedy
	<ul style="list-style-type: none"> • Deactivate standstill monitoring (C02595 = 0). • Increase waiting time for status monitoring (C02591). The standstill monitoring only starts after this waiting time has elapsed. • Increase brake closing time (C02589) since during the brake closing time the standstill monitoring is not active. • Reduce threshold for brake activation (C02581).

Motor brake: Automatically activated after waiting time has elapsed [0x00b80004]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	4
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	
This time monitoring will only be active if the speed setpoint has reached the threshold for brake activation (C02581). If the actual speed value does not reach/fall below the threshold set in C02581 within the parameterised waiting time for brake activation (C02593), the brake will be closed due to time-out.	Remedy
	<ul style="list-style-type: none"> • Increase waiting time for brake activation (C02593). • Reduce threshold for brake activation (C02581).

Motor brake: Status monitoring error [0x00b80005]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	5
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Faulty external feedback of the brake status to the brake control.	<ul style="list-style-type: none"> • Check brake configuration with regard to the control selection in C02580. • Check setting for status input monitoring in C02583. When monitoring is active, the input <i>bBrakeApplied</i> must be triggered correctly (<i>bBrakeApplied</i> = <i>bBrakeReleased</i>). • Check voltage supply of the brake module.

Positive software limit switch overtravelled [0x00b80007]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	7
Reaction (Lenze setting in bold)	
Setting: C02716/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The positive software limit position parameterised in C02702/2 has been overtravelled.	<ul style="list-style-type: none"> • Position within the software limit positions. • Increase permissible traversing range (change setting of the software limit positions). • Deactivate monitoring of the software limit positions by the basic function "Limiter".

Negative software limit switch overtravelled [0x00b80008]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	8
Reaction (Lenze setting in bold)	
Setting: C02716/2 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The negative software limit position parameterised in C02702/1 has been overtravelled.	<ul style="list-style-type: none"> • Position within the software limit positions. • Increase permissible traversing range (change setting of the software limit positions). • Deactivate monitoring of the software limit positions by the basic function "Limiter".

Positive direction of rotation limited [0x00b80009]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	9
Reaction (Lenze setting in bold)	
Setting: C02716/1 (<input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Due to the setting of C02707 it was tried to traverse in the impermissible positive direction of rotation.	<ul style="list-style-type: none"> • Only traverse in permissible (negative) direction of rotation. • Change setting of the permissible direction of rotation (C02707).

Negative direction of rotation limited [0x00b8000a]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	10
Reaction (Lenze setting in bold)	Setting: C02716/1 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
Due to the setting of C02707 it was tried to traverse in the impermissible negative direction of rotation.	<ul style="list-style-type: none"> • Only traverse in permissible (positive) direction of rotation. • Change setting of the permissible direction of rotation (C02707).

Speed has been limited [0x00b8000b]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	11
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<ul style="list-style-type: none"> • The requested profile speed is higher than the maximum speed set in C02703 and has been limited to this speed. • The required profile speed cannot be achieved with the motor reference speed set in C00011. 	<ul style="list-style-type: none"> • Reduce speed of the traversing profile of the basic function (manual jog, homing, or positioning). • Increase maximum speed (C02703). • Deactivate monitoring of the limit values by the basic function "Limiter". • Set motor reference speed correctly (C00011).

Acceleration has been limited [0x00b8000c]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	12
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The requested profile acceleration is higher than the maximum acceleration set in C02705 and has been limited to this acceleration.	<ul style="list-style-type: none"> • Reduce acceleration of the traversing profile of the basic function (manual jog, homing, or positioning). • Increase maximum acceleration (C02705). • Deactivate monitoring of the limit values by the basic function "Limiter".

Deceleration has been limited [0x00b8000d]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	13
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The requested profile deceleration is higher than the maximum acceleration set in C02705 and has been limited to this acceleration.	<ul style="list-style-type: none"> • Reduce acceleration of the traversing profile of the basic function (manual jog, homing, or positioning). • Increase maximum acceleration (C02705). • Deactivate monitoring of the limit values by the basic function "Limiter".

Jerk has been limited [0x00b8000e]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	14
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The requested S-ramp time is lower than the minimum S-ramp time set in C02706 and has been limited to this S-ramp time.	<ul style="list-style-type: none"> • Increase S-ramp time of the traversing profile of the basic function (manual jog, homing, or positioning). • Reduce minimum S-ramp time (C02706). • Deactivate monitoring of the limit values by the basic function "Limiter".

Position target outside the software limit positions [0x00b8000f]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	15
Reaction (Lenze setting in bold)	Setting: C02716/2 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
It was tried to position to a target outside the software limit positions.	<ul style="list-style-type: none"> • Select a target within the software limit positions. • Increase permissible traversing range (change setting of the software limit positions). • Deactivate monitoring of the software limit positions by the basic function "Limiter".

Maximum speed exceeded [0x00b80010]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	16
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The max. speed parameterised in C02703 or C00011 has been exceeded.	<ul style="list-style-type: none"> • Reduce speed. • Increase maximum speed (C02703). • Deactivate monitoring of the limit values by the basic function "Limiter".

Maximum acceleration exceeded [0x00b80011]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	17
Reaction (Lenze setting in bold)	Setting: C02716/3 (<input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
The max. acceleration parameterised in C02705 has been exceeded.	<ul style="list-style-type: none"> • Reduce acceleration. • Increase maximum acceleration (C02705). • Deactivate monitoring of the limit values by the basic function "Limiter".

Time-out torque feedforward control - brake [0x00b80012]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	18
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
After 1 second the actual torque has not yet reached 90 % of the precontrolled setpoint torque for releasing the brake.	Check settings for torque feedforward control. <ul style="list-style-type: none"> • Possibly the maximum current (C00022) is not sufficient for the required torque feedforward control.

Cam data: Serial number MM does not match [0x00b80013]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	19
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The cam data are provided with an access protection of level 3 (linkage to the memory module), and the serial number contained in the cam data does not correspond to the serial number of the memory module.	Check and, if required, correct the serial number entered in »Cam Designer«. Afterwards redownload the cam data.

Cam data are corrupted [0x00b80014]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	20
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
Checksum error during reading the file, or the password was manipulated.	Redownload cam data.

Cam data restored [0x00b80015]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	21
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The last download of the cam data was faulty or has not been completed successfully. The previous cam data – if available – have been downloaded from the backup file.	<ul style="list-style-type: none"> • Redownload cam data. • Save cam data within the controller in the memory module via device command C00002 = "502: Save cam data".

Cam data locked due to incorrect password [0x00b80016]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	22
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The cam data were locked since the user password was entered incorrectly for three times. The cam data were not loaded.	Reset parameters to the Lenze setting via device command C00002 = "0: Load Lenze setting". Then download cam data again.

Cam data locked due to incorrect safety key [0x00b80017]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	23
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
The cam data were not loaded because the safety key is damaged. The password in the cam data or the serial number of the memory module has been manipulated.	Reset parameters to the Lenze setting via device command C00002 = "0: Load Lenze setting". Then download cam data again.

Homing mode not allowed [0x00b80019]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	25
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
From software version V3.0 The homing mode selected in C02640 is not supported in the motor control type selected in C00006 .	Select another homing mode in C02640 .

Int. overflow C02620 (manual jog: Speed 1) [0x00b8001a]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	26
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter " Max. position, speed, and acceleration that can be displayed internally ".	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02620.

Int. overflow C02621 (manual jog: Speed 2) [0x00b8001b]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	27
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02621.

Int. overflow C02622 (manual jog: Acceleration) [0x00b8001c]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	28
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02622.

Int. overflow C02623 (manual jog: Deceleration) [0x00b8001d]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	29
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02623.

Int. overflow C02701/1 (positive software limit position) [0x00b80020]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	32
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02701/1.

Int. overflow C02701/2 (negative software limit position) [0x00b80021]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	33
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02701/2.

Int. overflow C02703 (maximum speed) [0x00b80022]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	34
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02703.

Int. overflow C02705 (maximum acceleration) [0x00b80023]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	35
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02705.

Int. overflow C02708/1 (limited speed 1) [0x00b80024]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	36
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02708/1.

Int. overflow C02708/2 (limited speed 2) [0x00b80025]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	37
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02708/2.

Int. overflow C02708/3 (limited speed 3) [0x00b80026]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	38
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02708/3.

Int. overflow C02708/4 (limited speed 4) [0x00b80027]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	39
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02708/4.

Int. overflow C02708/1 (decel. limited speed 1) [0x00b80028]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	40
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02710/1.

Int. overflow C02708/2 (decel. limited speed 2) [0x00b80029]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	41
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02710/2.

Int. overflow C02708/3 (decel.limited speed 3) [0x00b8002a]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	42
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02710/3.

Int. overflow C02708/4 (decel. limited speed 4) [0x00b8002b]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	43
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02710/4.

Int. overflow C02713 (max. dist. manual control) [0x00b8002c]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	44
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02713.

Int. overflow C02642 (home position) [0x00b8002d]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	45
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02642.

Int. overflow C02643 (homing: Target position) [0x00b8002e]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	46
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02643.

Int. overflow C02644 (homing: Speed 1) [0x00b8002f]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	47
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02644.

Int. overflow C02645 (homing: Acceleration 1) [0x00b80030]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	48
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02645.

Int. overflow C02646 (homing: Speed 2) [0x00b80031]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	49
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02646.

Int. overflow C02647 (homing: Acceleration 2) [0x00b80032]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	50
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02647.

Int. overflow C02670 (positioner: Tol. for target position) [0x00b80033]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	51
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V3.0 Due to a subsequent change of the machine parameters for gearbox ratio, feed constant, or resolution of an encoder revolution, the value set in the parameter cannot be displayed in the internal unit. See chapter "Max. position, speed, and acceleration that can be displayed internally".</p>	<ul style="list-style-type: none"> • Check machine parameters and adapt them if required. • Change setting in C02670.

Cam data: Invalidated due to change of mechanical data [0x00b80034]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	52
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
<p>From software version V4.0 One or several machine parameters have been changed that have an influence on the internal scaling of the Cam data. The Cam data has to be recalculated. See chapter "Invalid Cam data due to changed machine parameters".</p>	<p>Execute device command C00002 = "503: Calculate Cam Data". This automatically resets the warning.</p>

Cam data: invalid product number [0x00b80035]

Module ID (decimal)	Error ID (decimal)
184: Basic drive functions	53
Reaction (Lenze setting in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
<p>From software version V5.0</p> <p>A product number has been created in the system block LS_CamInterface which is not in the range of product number of the downloaded cam data.</p>	<p>Check number of products.</p> <ul style="list-style-type: none"> • The product number must be higher than 0 and lower than the value displayed in C02908. • C02908 displays the highest product number +1 of the cam data currently being processed.

14 Parameter reference

All parameters for controller parameterising or monitoring are saved as "codes".

- The codes are numbered and indicated by the prefix "C" before the code, e.g. "C00002".
- For the sake of clarity, some codes contain "subcodes" for saving parameters. This Manual uses a slash "/" as a separator between code and subcode, e.g. C00118/3".

Parameters available in the controller only from a certain software version are marked accordingly ("From software version Vx.x").

The parameter descriptions are based on the software version V15.00.xx.



Tip!

For quick reference of a parameter with a certain name simply use the **index** of the online documentation. The index always contains the corresponding code in parentheses behind the name.

For general information on how to read and change parameters, please see the online documentation for the »Engineer«.

14 Parameter reference

14.1 Structure of the parameter descriptions

14.1 Structure of the parameter descriptions

Each parameter is described in the [Parameter list](#) in the form of a table which consists of the following three areas:

Table header

The table header contains the following general information:

- Parameter number (Cxxxxx)
- Parameter name (display text in the »Engineer« and keypad)
- [Data type](#)
- Decimal and hexadecimal parameter index for access via bus systems

Table contents

The table contains further general explanations & notes on the parameter and the possible settings, which are represented in different ways depending on the parameter type:

- [Parameters with read-only access](#)
- [Parameters with write access](#)

Table footer

The table footer contains the [Parameter attributes](#).

14.1.1 Data type

The following data types are available for parameters:

Data type	Meaning
INTEGER_8	8-bit value with sign
INTEGER_16	16-bit value with sign
INTEGER_32	32-bit value with sign
INTEGER_64	64-bit value with sign
UNSIGNED_8	8-bit value without sign
UNSIGNED_16	16-bit value without sign
UNSIGNED_32	32-bit value without sign
UNSIGNED_64	64-bit value without sign
FLOATING_POINT	32-bit floating point number
VISIBLE_STRING	String of characters of printable characters
OCTET_STRING	String of characters of any characters
BITFIELD_8	8-bit value bit-coded
BITFIELD_16	16-bit value bit-coded
BITFIELD_32	32-bit value bit coded

14.1.2 Parameters with read-only access

Parameters for which the "write access" attribute has not been set can only be read and not be changed by the user.

Description structure

Parameter Name: Cxxxxx _____	Data type: _____ Index: _____
Description	
Display range (min. value unit max. value)	

<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer	

Representation in the »Engineer«

The »Engineer« displays these parameters with a grey background or, with an online connection, with a pale-yellow background:

	/ C...	/ S/	Name	Value	Unit
	61	0	Heatsink temperature	30	°C

14.1.3 Parameters with write access

Only parameters with a check mark (☑) in front of the "write access" attribute can be changed by the user. The Lenze setting for these parameters is **printed in bold**.

- The settings can either be selected from a selection list or the values can be entered directly.
- Values outside the valid setting range are represented in red in the »Engineer«.

14 Parameter reference

14.1 Structure of the parameter descriptions

14.1.3.1 Parameters with setting range

Description structure

Parameter Name: Cxxxxx _____	Data type: _____ Index: _____
Description	
Setting range (min. value unit max. value)	Lenze setting
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer	

Parameter setting in the »Engineer«

In the »Engineer«, parameters are set by entering the desired value into the input field:

C...	S	Name	Value	Unit
22	0	Maximum current	0.00	A

14.1.3.2 Parameters with selection list

Description structure

Parameter Name: Cxxxxx _____	Data type: _____ Index: _____
Description	
Selection list (Lenze setting printed in bold)	
1	
2	
3	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer	

Parameter setting in the »Engineer«

In the »Engineer«, a list field is used for parameter setting:

C...	S	Name	Value	Unit
34	0	Config. analog input 1	0: -10 ... +10 V	

0: -10 ... +10 V
1: -20...-4 mA, +4...+20 mA
2: -20 ... +20 mA

14 Parameter reference

14.1 Structure of the parameter descriptions


14.1.3.3 Parameters with bit-coded setting

Description structure

Parameter Name: Cxxxxx _____	Data type: _____ Index: _____
Description	
Value is bit-coded:	
Bit 0	
...	
Bit 31	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer	

Parameter setting in the »Engineer«

The »Engineer« uses a dialog box for parameter setting in which the individual bits can be set or reset. Alternatively, the value can be entered as a decimal or hexadecimal value:



14.1.3.4 Parameters with subcodes

Description structure

Parameter Name: Cxxxxx _____		Data type: _____ Index: _____
Description		
Setting range (min. value unit max. value)		
Subcodes	Lenze setting	
Cxxxxx/1		
Cxxxxx/2		
Cxxxxx/3		
Cxxxxx/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		

Parameter setting in the »Engineer«

The »Engineer« parameter list displays each subcode individually. The parameters are set as described in the previous chapters.

#	C...	S	Name	Value	Unit
	114	1	Dig. input. 1: Terminal polarity	0	
	114	2	Dig. input. 2: Terminal polarity	0	
	114	3	Dig. input. 3: Terminal polarity	0	
	114	4	Dig. input. 4: Terminal polarity	0	

14 Parameter reference

14.1 Structure of the parameter descriptions

14.1.4 Parameter attributes

Description structure

The table footers contain the parameter attributes:

Read access Write access CINH PLC-STOP No transfer

Meaning of the attributes

Attribute	Meaning	
<input checked="" type="checkbox"/> Read access	Read access to parameter possible.	
<input checked="" type="checkbox"/> Write access	Write access to parameter possible. • Please also observe the following attributes:	
	<input checked="" type="checkbox"/> CINH	Parameter value can only be changed when the controller is inhibited.
	<input checked="" type="checkbox"/> PLC STOP	Parameter value can only be changed when the application is stopped.
<input checked="" type="checkbox"/> No transfer	The parameter is not transferred to the regenerative power supply module when the command <u>Download parameter set</u> is executed.	

Scaling factor

The "scaling factor" is important for the parameter access via a bus system:

$$\text{Read value (via bus system)} = \text{Scaling factor} \cdot \text{Indicated value (Engineer)}$$

14.1.5 Abbreviations used in parameter & selection texts

Since the character length of the parameter and selection texts is limited, the following abbreviations are used:

Abbreviation	Meaning
CAN module	CANopen communication module (type E94AYCCA)
ENP	Electronic nameplate
Ethernet module	Ethernet communication module (type E94AYCEN)
MXI1	<i>Module eXtension Interface 1</i> - module slot for extension 1
MXI2	<i>Module eXtension Interface 2</i> - module slot for extension 2

14.2 Parameter list

This chapter lists all parameters of the operating system in numerically ascending order.



Note!

The parameter descriptions are based on the software version V15.00.xx.

C00002

Parameter Name: C00002 Device command		Data type: UNSIGNED_32 Index: 24573 _d = 5FFD _h
Device commands <ul style="list-style-type: none"> • C00003 shows the status of the last executed device command. • Under C00150 you can query the current status of the device control. 		
Note: Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in C00003 ! The meaning of the status display in C00003 can be obtained from the subchapter for the corresponding device command in chapter " Device commands ".		
Selection list (Lenze setting printed in bold)		Info
0	Load Lenze setting	Resets parameters to Lenze setting. <ul style="list-style-type: none"> • Only possible when the application has stopped and the controller is inhibited.
1	Load start parameters	Loads parameters from the memory module. <ul style="list-style-type: none"> • Only possible when the application has stopped and the controller is inhibited.
2	ENP: Load plant data	Reads plant data from the electronic motor nameplate. <ul style="list-style-type: none"> • Only possible when the application has stopped and the controller is inhibited.
5	Activate application	Activates the application selected under C00005 . <ul style="list-style-type: none"> • Whether the application is also started, depends on the auto-start setting selected. • Only possible when the application has stopped.
7	Save selected application	Selects the active application as start application.
11	Save start parameters	Saves parameters fail-safe in the memory module.
20	Delete logbook	Deletes all logbook entries.
21	Archive logbook	Exports logbook entries to file.
27	Device search function ON	
28	Device search function OFF	
31	Start application	
32	Stop application	
33	Reset program	Carries out a reset. <ul style="list-style-type: none"> • All variables are reset to their initialisation value. • The situation corresponds to the start of a new program loaded into the control (cold start).
34	Delete program	Carries out a reset (source). <ul style="list-style-type: none"> • All variables are reset to their initialisation value. • The application program is deleted and the controller is reset to its original state.

Parameter Name: C00002 Device command		Data type: UNSIGNED_32 Index: 24573 _d = 5FFD _h
35	Restart program	Carries out a reset (warm start). <ul style="list-style-type: none"> All variables except the RETAIN variables are reset to their initialisation value. The situation corresponds to a power failure or switching the controller off/on (warm start) while the program is running.
36	Reset runtime measurement	▶ Runtime measurement
41	Inhibit inverter	
42	Enable inverter	
43	Error reset	
45	Activate quick stop	▶ Basic function " Quick stop "
46	Reset quick stop	▶ Basic function " Quick stop "
47	Internal command 47	For Lenze service only
48	Internal command 48	For Lenze service only
51	Identify pole position (360°)	Executes identification of pole position. <ul style="list-style-type: none"> The function can only be activated when the controller is inhibited. After this, the execution of the command starts automatically when the controller is enabled. During the pole position identification, the motor carries out one electrical revolution. This leads to a mechanical rotation of the motor shaft. The determined pole position is indicated under code C00058. ▶ Pole position identification
52	Identify pole position (min. motion)	Executes identification of pole position. <ul style="list-style-type: none"> The function can only be activated when the controller is inhibited. After this, the execution of the command starts automatically when the controller is enabled. During the pole position identification, the rotor aligns itself. This is compensated by a position control. The determined pole position is indicated under code C00058. ▶ Pole position identification
58	Internal command 58	From software version V15.0 onwards For Lenze service only
59	Resolver error identification	From software version V7.0 Execute resolver error identification. ▶ Resolver error compensation
70	Load Lenze inverter characteristic	From software version V4.0 Load type-dependent inverter error characteristic. <ul style="list-style-type: none"> For the case that the determination of the inverter error characteristic with the device command "71: Determine inverter characteristic" was not possible or has supplied incorrect results. The function can only be activated when the controller is inhibited.
71	Calculate inv. characteristic	Determines inverter error characteristic. <ul style="list-style-type: none"> The function can only be activated when the controller is inhibited. After this, the execution of the command starts automatically when the controller is enabled. ▶ Optimise the switching performance of the inverter

Parameter Name: C00002 Device command		Data type: UNSIGNED_32 Index: 24573 _d = 5FFD _h
72	Determine motor parameters	Determines motor parameters automatically. <ul style="list-style-type: none"> The function can only be activated when the controller is inhibited. After this, the execution of the command starts automatically when the controller is enabled. ▶ Determine motor parameters
77	Calculate current controller parameters	From software version V5.0 Calculates the gain and reset time of the current controller. <ul style="list-style-type: none"> Usually not required for a Lenze motor. The device command is no identification procedure for determining the current controller parameters! ▶ Calculate current controller parameters
78	Calculate speed controller parameters	From software version V5.0 Calculates the gain, reset, and rate time of the speed controller. <ul style="list-style-type: none"> The device command is no identification procedure for determining the speed controller parameters! ▶ Calculate speed controller parameters
91	CAN on-board: Reset node	Reinitialise "CAN on board" interface. <ul style="list-style-type: none"> Required when changing the baud rate, node address, or identifiers. ▶ "CAN on board" system bus
92	CAN module: Reset node	Reinitialises CANopen interface of the CANopen communication module. <ul style="list-style-type: none"> Required when changing the baud rate, node address, or identifiers.
93	CAN on-board: Pred.Connect.Set	Sets basic identifier for the "CAN on board" interface according to the "Predefined Connection Set" (DS301 V4.02). <ul style="list-style-type: none"> ▶ "CAN on board" system bus
94	CAN module: Pred.Connect.Set	Sets basic identifier for the CANopen interface of the CANopen communication module according to the Predefined Connection Set" (DS301 V4.02).
95	CAN on-board: Identify node	Detects nodes connected to the "CAN on board" interface. <ul style="list-style-type: none"> The result of the CAN bus scan is displayed in C00393. ▶ "CAN on board" system bus
96	CAN module: Identify node	Detects the nodes connected to the CANopen interface of the CANopen communication module. <ul style="list-style-type: none"> The result of the CAN bus scan is displayed in C13393 (for MX1) or C14393 (for MX2).
101	Unbind/bind Ethernet module MX1	Reinitialises the Ethernet interface of the Ethernet communication module in module slot MX1. <ul style="list-style-type: none"> Required when a new setting for an IP or gateway address is to be accepted without mains switching.
102	Unbind/bind Ethernet module MX2	
201	Activate parameter set 1	Loads parameter set 1 from the memory module. <ul style="list-style-type: none"> Only possible when the application has stopped and the controller is inhibited.
202	Activate parameter set 2	Loads parameter set 2 from the memory module. <ul style="list-style-type: none"> Only possible when the application has stopped and the controller is inhibited.
203	Activate parameter set 3	Loads parameter set 3 from the memory module. <ul style="list-style-type: none"> Only possible when the application has stopped and the controller is inhibited.

Parameter Name: C00002 Device command		Data type: UNSIGNED_32 Index: 24573 _d = 5FFD _h
204	Activate parameter set 4	Loads parameter set 4 from the memory module. • Only possible when the application has stopped and the controller is inhibited.
301	Archive parameter set 1	Saves the current parameter set as parameter set 1 in the memory module.
302	Archive parameter set 2	Saves the current parameter set as parameter set 2 in the memory module.
303	Archive parameter set 3	Saves the current parameter set as parameter set 3 in the memory module.
304	Archive parameter set 4	Saves the current parameter set as parameter set 4 in the memory module.
401	Internal command 401	For Lenze service only
501	Load cam data	From software version V3.0 Reloads cam data from the memory module into the controller. • Only possible when the application has stopped and the controller is inhibited. • If the cam data are provided with an access protection, the user password has to be entered in C02900 first. ▶ Basic function " Cam data management "
502	Save cam data	From software version V3.0 Saves the cam data available in the main memory of the controller in the memory module with mains failure protection. • If the cam data are provided with an access protection, the user password has to be entered in C02900 first. ▶ Basic function " Cam data management "
503	Calculate cam data	From software version V3.0 Converts the cam data available in the main memory of the controller into the internal format and provides them to the application. ▶ Basic function " Cam data management "
504	Calculate cam data checksum	From software version V3.0 Recalculates the checksum of the cam data available in the main memory of the controller. • Required if the cam data in the main memory of the controller have been changed via parameters. ▶ Basic function " Cam data management "
730	Internal command 730	For Lenze service only
731	Internal command 731	For Lenze service only
732	Internal command 732	For Lenze service only
733	Internal command 733	For Lenze service only
800	Internal command 800	For Lenze service only
810	Internal command 810	

Parameter Name: C00002 Device command		Data type: UNSIGNED_32 Index: 24573 _d = 5FFD _h
811	Internal command 811	
812	Internal command 812	
1001	Internal command 1001	For Lenze service only
1020	Internal command 1020	For Lenze service only
1021	Export parameters to file	For Lenze service only
1030	Format file system	Formats file system of the memory module.
1040	Restore file system	Restores file system of the memory module (low level formatting). • The low level formatting of the file system by the user is only intended for the exceptional case when the standard formatting is not possible anymore, e.g. due to damaged internal management information.
10000	Prepare firmware update	Sets the controller to the firmware update mode.
11000	Restart controller	Restarts controller via parameter setting.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C00003

Parameter Name: C00003 Device command status		Data type: UNSIGNED_32 Index: 24572 _d = 5FFC _h
Display of the number/status of the device command last executed (C00002). • The number of the command is situated in the upper 16 bits (for the meaning of the number see code C00002). • The result of the command stands in the lower 16 bits.		
Note:		
Before switching off the supply voltage after a device command has been executed, check the successful execution of the device command via the status display in C00003 ! The meaning of the status display in C00003 can be obtained from the subchapter for the corresponding device command in chapter " Device commands ".		
Display range (min. value unit max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

Status	Meaning	Device command
0	Device command executed successfully	0: Load Lenze setting
1	General error	
34050	Device command in process	
39424	CAN fault	
...	...	
39679	CAN fault	
65536	Device command executed successfully	1: Load start parameters
65537	General error	
99371	Fault while reading the parameter set partition	
99374	No memory module available	
99586	Device command in process	
104960	CAN fault	
...	...	
105215	CAN fault	

Status	Meaning	Device command
131072	Device command executed successfully	2: ETS: Load plant data
131073	General error	
165122	Device command in process	
327680	Device command executed successfully	5: Activate application
327681	General error	
361730	Device command in process	
458752	Device command executed successfully	7: Save selected application
458753	General error	
492802	Device command in process	
720896	Device command executed successfully	11: Save start parameters
720897	General error	
754718	Fault while writing into a file	
754734	No memory module available	
754946	Device command in process	
761857	Access to file has been denied since the file is already accessed from another position	
761861	I/O fault when accessing the file system	
761868	RAM is full	
761869	Access authorisation denied	
761884	No free memory on the memory module	
1310720	Device command executed successfully	20: Delete logbook
1310721	General error	
1344770	Device command in process	
1376256	Device command executed successfully	21: Archive logbook
1376257	General error	
1410306	Device command in process	
2031616	Device command executed successfully	31: Start application
2031617	General error	
2065666	Device command in process	
2097152	Device command executed successfully	32: Stop application
2097153	General error	
2131202	Device command in process	
2162688	Device command executed successfully	33: Reset program
2162689	General error	
2196738	Device command in process	
2228224	Device command executed successfully	34: Delete program
2228225	General error	
2262274	Device command in process	
2293760	Device command executed successfully	35: Restart program
2293761	General error	
2327810	Device command in process	
2359296	Device command executed successfully	36: Reset runtime measurement
2359297	General error	
2393346	Device command in process	

Status	Meaning	Device command
3342336	Device command executed successfully	51: Identify pole position (360°)
3342337	General error	
3376386	Device command in process	
3382023	Pole position identification cannot be executed because of wrong motor type (asynchronous motor).	
3382024	Pole position identification has been aborted	
3382025	Pole position identification cannot be executed because another identification is already active.	
3382026	Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.	
3382027	Identification of pole position cannot be executed because current controller optimisation mode is active.	
3382033	Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.	
3382047	Pole position identification cannot be executed because an error or trouble is active.	
3382065 <small>From software version V3.0</small>	Pole position identification cannot be executed because either the entire motor or a motor phase is not connected.	
3407872	Device command executed successfully	
3407873	General error	
3441922	Device command in process	
3447559	Pole position identification cannot be executed because of wrong motor type (asynchronous motor).	
3447560	Pole position identification has been aborted	
3447561	Pole position identification cannot be executed because another identification is already active.	
3447562	Identification of pole position cannot be executed because U-rotation or I-rotation test mode is active.	
3447563	Identification of pole position cannot be executed because current controller optimisation mode is active.	
3447569 <small>From software version V4.0</small>	Pole position identification cannot be executed because the motor is blocked (e.g. by a mechanical brake), a motor phase is not connected, or a phase shifter is in the motor cable.	
3447583	Pole position identification cannot be executed because an error or trouble is active.	
3447597	Identification of pole position cannot be executed because the rotor has moved too strongly.	
3447601 <small>From software version V3.0</small>	Pole position identification cannot be executed because either the entire motor or a motor phase is not connected.	

Status	Meaning	Device command
3900674	Device command in process	59: Resolver error identification
3866624	Device command executed successfully	
3866625	General error	
3906358	Resolver error identification cannot be executed since the wrong control type is active (no servo control).	
3906359	Resolver error identification cannot be executed since an error or trouble is active.	
3906360	Resolver error identification cannot be executed because another identification is already active.	
3906361	Resolver error identification cannot be executed because of too small speed (< 500 rpm).	
4587520	Device command executed successfully	70: Load Lenze INV characteristic
4587521	General error	
4621570	Device command in process	71: Calculate inv. characteristic
4653056	Device command executed successfully	
4653057	General error	
4687106	Device command in process	
4692754	The calculation of the inverter characteristic cannot be started since the current controller test mode is active.	
4692755	The calculation of the inverter characteristic cannot be started since the V/f test mode is active.	
4692756	The calculation of the inverter characteristic cannot be started since the pole position identification is active.	
4692757	Calculation of the inverter characteristic has been aborted.	
4692758	Calculation of the inverter characteristic has been interrupted by error.	
4692789 <small>From software version V5.0</small>	Detected inverter error characteristic exceeds internal limits. This situation can for instance occur if the motor power is very much lower than the device power.	
4718592	Device command executed successfully	72: Determine motor parameters
4718593	General error	
4752642	Device command in process	
4758290	Motor identification cannot be started since the current controller test mode is active.	
4758291	Motor identification cannot be started since the V/f test mode is active.	
4758292	Motor identification cannot be started because pole position identification is active.	
4758293	Motor identification has been aborted.	
4758294	Motor identification has been aborted by fault.	
4758332 <small>From software version V7.0</small>	Motor identification aborted due to inconsistent motor parameters.	
5046272	Device command executed successfully	
5046273	General error	
5080322	Device command in process	
5086002	At least one calculated value is outside the valid setting range.	
5086003	Stator resistance (C00084) too small (zero).	

Status	Meaning	Device command
5111808	Device command executed successfully	78: Calculate speed controller parameters
5111809	General error	
5145858	Device command in process	
5151540	At least one calculated value is outside the valid setting range.	91: CAN on board: Reset Node
5963776	Device command executed successfully	
5963777	General error	
5997826	Device command in process	
6003200	CAN fault	
...	...	
6003455	CAN fault	
6029312	Device command executed successfully	92: CAN module: Reset node
6029313	General error	
6063362	Device command in process	
6068736	CAN fault	
...	...	
6068991	CAN fault	93: CAN on board: Pred.Connect.Set
6094848	Device command executed successfully	
6094849	General error	
6128898	Device command in process	94: CAN module: Pred.Connect.Set
6160384	Device command executed successfully	
6160385	General error	
6194434	Device command in process	
6225920	Device command executed successfully	95: CAN on board: Identify node
6225921	General error	
6259970	Device command in process	
6291456	Device command executed successfully	96: CAN module: Identify node
6291457	General error	
6325506	Device command in process	
6619136	Device command executed successfully	101: Unbind/bind Ethernet module MXI1
6619137	General error	
6653186	Device command in process	102: Unbind/bind Ethernet module MXI2
6684672	Device command executed successfully	
6684673	General error	
6718722	Device command in process	

Status	Meaning	Device command
13172731	General error	201: Activate parameter set 1
13172736	Device command executed successfully	
13206532	File could not be opened.	
13206557	Fault while reading out of a file.	
13206558	Fault while writing into a file.	
13206559	Invalid file type.	
13206560	Unexpected end of file.	
13206562	Checksum error	
13206786	Device command in process	
13212160	CAN fault	
...	...	
13212415	CAN fault	
13213697	Access to file has been denied since the file is already accessed from another position	
13213701	I/O fault when accessing the file system	
13213708	RAM is full	
13213709	Access authorisation denied	
13213724	No free memory on the memory module	
13238272	Device command executed successfully	202: Activate parameter set 2
13238273	General error	
13272068	File could not be opened.	
13272093	Fault while reading out of a file.	
13272094	Fault while writing into a file.	
13272095	Invalid file type.	
13272096	Unexpected end of file.	
13272098	Checksum error	
13272322	Device command in process	
13277696	CAN fault	
...	...	
13277951	CAN fault	
13279233	Access to file has been denied since the file is already accessed from another position	
13279237	I/O fault when accessing the file system	
13279244	RAM is full	
13279245	Access authorisation denied	
13279260	No free memory on the memory module	

Status	Meaning	Device command
13303808	Device command executed successfully	203: Activate parameter set 3
13303809	General error	
13337604	File could not be opened.	
13337629	Fault while reading out of a file.	
13337630	Fault while writing into a file.	
13337631	Invalid file type.	
13337632	Unexpected end of file.	
13337634	Checksum error	
13337858	Device command in process	
13343232	CAN fault	
...	...	
13343487	CAN fault	
13344769	Access to file has been denied since the file is already accessed from another position	
13344773	I/O fault when accessing the file system	
13344780	RAM is full	
13344781	Access authorisation denied	
13344796	No free memory on the memory module	
13369344	Device command executed successfully	204: Activate parameter set 4
13369345	General error	
13403140	File could not be opened.	
13403165	Fault while reading out of a file.	
13403166	Fault while writing into a file.	
13403167	Invalid file type.	
13403168	Unexpected end of file.	
13403170	Checksum error	
13403394	Device command in process	
13408768	CAN fault	
...	...	
13409023	CAN fault	
13410305	Access to file has been denied since the file is already accessed from another position	
13410309	I/O fault when accessing the file system	
13410316	RAM is full	
13410317	Access authorisation denied	
13410332	No free memory on the memory module	

Status	Meaning	Device command
19726336	Device command executed successfully	301: Archive parameter set 1
19726337	General error	
19760132	File could not be opened.	
19760157	Fault while reading out of a file.	
19760158	Fault while writing into a file.	
19760160	Unexpected end of file.	
19760386	Device command in process	
19767297	Access to file has been denied since the file is already accessed from another position	
19767301	I/O fault when accessing the file system	
19767308	RAM is full	
19767309	Access authorisation denied	
19767324	No free memory on the memory module	
19791872	Device command executed successfully	
19791873	General error	
19825668	File could not be opened.	
19825693	Fault while reading out of a file.	
19825694	Fault while writing into a file.	
19825696	Unexpected end of file.	
19825922	Device command in process	
19832833	Access to file has been denied since the file is already accessed from another position	
19832837	I/O fault when accessing the file system	
19832844	RAM is full	
19832845	Access authorisation denied	
19832860	No free memory on the memory module	
19857408	Device command executed successfully	303: Archive parameter set 3
19857409	General error	
19891204	File could not be opened.	
19891229	Fault while reading out of a file.	
19891230	Fault while writing into a file.	
19891232	Unexpected end of file.	
19891458	Device command in process	
19898369	Access to file has been denied since the file is already accessed from another position	
19898373	I/O fault when accessing the file system	
19898380	RAM is full	
19898381	Access authorisation denied	
19898396	No free memory on the memory module	

Status	Meaning	Device command	
19922944	Device command executed successfully	304: Archive parameter set 4	
19922945	General error		
19956740	File could not be opened.		
19956765	Fault while reading out of a file.		
19956766	Fault while writing into a file.		
19956768	Unexpected end of file.		
19956994	Device command in process		
19963905	Access to file has been denied since the file is already accessed from another position		
19963909	I/O fault when accessing the file system		
19963916	RAM is full		
19963917	Access authorisation denied		
19963932	No free memory on the memory module		
32833536	Device command executed successfully		501: Load cam data
32833537	General error		
32867586	Device command in process		
32875521	No cam data available on the memory module		
32875523	Loading of the cam data failed		
32875525	Checksum error		
32875542	Wrong password entered		
32875545	The cam functionality is deactivated		
32899072	Device command executed successfully	502: Save cam data	
32899073	General error		
32933122	Device command in process		
32941057	No cam data to be saved are available in the RAM of the controller		
32941060	Saving of the cam data failed		
32941078	Wrong password entered		
32941081	The cam functionality is deactivated		
32964608	Device command executed successfully	503: Calculate cam data	
32964609	General error		
32998658	Device command in process		
33006617	The cam functionality is deactivated		
33030144	Device command executed successfully	504: Calculate cam data checksum	
33030145	General error		
33064194	Device command in process		
33072153	The cam functionality is deactivated		
67502080	Device command executed successfully	1030: Format file system	
67502081	General error		
67536130	Device command in process		
655360000	Device command executed successfully	10000: Prepare firmware update	
655360001	General error		
655394050	Device command in process		
720896001	General error	11000: Restart controller	
720930050	Device command in process		

C00004

Parameter Name: C00004 Service password		Data type: UNSIGNED_32 Index: 24571 _d = 5FFB _h
Service code to unlock protected device commands (C00002).		
Setting range (min. value unit max. value)		Lenze setting
0		4294967295 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C00005

Parameter Name: C00005 Application selection		Data type: INTEGER_32 Index: 24570 _d = 5FFA _h
Application selection <ul style="list-style-type: none"> • Use the device command C00002="5" to activate the selected application. 		
Note regarding the setting values: <ul style="list-style-type: none"> • -1: No response • 0: For Lenze service only • 1: Active application (after download via the Engineer) • 2 ... 16: Application spots cannot be used 		
Setting range (min. value unit max. value)		Lenze setting
-1		16 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C00006

Parameter Name: C00006 Select motor control		Data type: UNSIGNED_32 Index: 24569 _d = 5FF9 _h
▶ Motor interface		
Selection list (Lenze setting printed in bold)		Info
1	SC: Servo control sync. motor	For synchronous motors with speed sensor ▶ Servo control
2	SC: Servo control async. motor	For asynchronous motors with speed sensor ▶ Servo control
4	SLVC: sensorless vector control	From software version V3.0 ▶ Sensorless vector control
6	VFCplus: V/f control open loop	From software version V3.0 ▶ V/f control
7	VFCplus: V/f control closed loop	From software version V3.0 ▶ V/f control
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00007

Parameter Name: C00007 Active application		Data type: INTEGER_32 Index: 24568 _d = 5FF8 _h
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00008

Parameter Name: C00008 Progress of device command		Data type: UNSIGNED_32 Index: 24567 _d = 5FF7 _h
From software version V7.0		
Display range (min. value unit max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00011

Parameter Name: C00011 Motor reference speed		Data type: UNSIGNED_32 Index: 24564 _d = 5FF4 _h
For parameter setting via interface: In case of bigger changes, only change the setting in one step when the controller is inhibited!		
Setting range (min. value unit max. value)		Lenze setting
50	rpm	50000 3000 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00018

Parameter Name: C00018 Switching frequency		Data type: UNSIGNED_32 Index: 24557 _d = 5FED _h
Selection list (Lenze setting printed in bold)		Info
2	1 kHz fixed/drive-optimised	Note: <ul style="list-style-type: none"> The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected here! The switching frequencies that can be selected depend on the device type (see Hardware Manual, chapter "Rated data"). In the case of an offline parameter setting or when exchanging the memory module between different Servo Drives 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change!
3	2 kHz fixed/drive-optimised	
4	4 kHz fixed/drive-optimised	
5	8 kHz fixed/drive-optimised	
8	2 kHz var./drive-optimised	
9	4 kHz var./drive-optimised	
10	8 kHz var./drive-optimised	
11	16 kHz var./drive-optimised	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00019

Parameter Name: C00019 Threshold - standstill recognition		Data type: UNSIGNED_32 Index: 24556 _d = 5FEC _h
Setting range (min. value unit max. value)		Lenze setting
0	rpm	450 5 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00022

Parameter Name: C00022 Maximum current			Data type: UNSIGNED_32 Index: 24553 _d = 5FE9 _h
Note:			
<ul style="list-style-type: none"> To avoid that the motor starts unintentionally without adjusting the plant data, the maximum current in the Lenze setting is set to "0 A"! The upper limit value is the maximum device current (see display in C00789). In the case of an offline parameter setting or when exchanging the memory module between different 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change! Also check the threshold set for the maximum motor current monitoring (C00620). 			
Setting range (min. value unit max. value)			Lenze setting
0.00	A	21474836.47	0.00 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00034

Parameter Name: C00034 Config. analog input 1			Data type: UNSIGNED_32 Index: 24541 _d = 5FDD _h
Selection list (Lenze setting printed in bold)			
0	-10...+10 V		
1	-20...-4 mA, +4...+20 mA		
2	-20 ... +20 mA		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00050

Parameter Name: C00050 Speed setpoint [rpm]			Data type: INTEGER_32 Index: 24525 _d = 5FCD _h
Display range (min. value unit max. value)			
-480000	rpm	480000	
Subcodes			Info
C00050/1			Speed setpoint 1 [rpm]
C00050/2			Speed setpoint 2 [rpm]
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00051

Parameter Name: C00051 Actual speed [rpm]			Data type: INTEGER_32 Index: 24524 _d = 5FCC _h
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00052

Parameter Name: C00052 Motor voltage			Data type: UNSIGNED_32 Index: 24523 _d = 5FCB _h
Display range (min. value unit max. value)			
0	V	2147483647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00053

Parameter Name: C00053 DC-bus voltage		Data type: UNSIGNED_32 Index: 24522 _d = 5FC _{Ah}
Display range (min. value unit max. value)		
0	V	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00054

Parameter Name: C00054 Motor current		Data type: UNSIGNED_32 Index: 24521 _d = 5FC _{9h}
Display range (min. value unit max. value)		
0.00	A	500.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00055

Parameter Name: C00055 Phase currents		Data type: INTEGER_32 Index: 24520 _d = 5FC _{8h}
Display range (min. value unit max. value)		
-500.00	A	500.00
Subcodes		Info
C00055/1		Phase zero system
C00055/2		Phase U
C00055/3		Phase V
C00055/4		Phase W
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00056

Parameter Name: C00056 Torque setpoint		Data type: INTEGER_32 Index: 24519 _d = 5FC _{7h}
Display range (min. value unit max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00057

Parameter Name: C00057 Torque		Data type: UNSIGNED_32 Index: 24518 _d = 5FC _{6h}
Display range (min. value unit max. value)		
0.000	Nm	2147483.647
Subcodes		Info
C00057/1		Maximum torque • With regard to the selected motor and the max. short-time output current of the device.
C00057/2		Motor reference torque • Torque at maximum current (C00022).
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C00058

Parameter Name: C00058 Pole position		Data type: INTEGER_32 Index: 24517 _d = 5FC5 _h
Setting range (min. value unit max. value)		
-179.9	°	179.9
Subcodes	Lenze setting	Info
C00058/1	-90.0 °	Resolver pole position
C00058/2	0.0 °	Encoder pole position
C00058/3	0.0 °	Module pole position
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00059

Parameter Name: C00059 Motor - number of pole pairs		Data type: UNSIGNED_32 Index: 24516 _d = 5FC4 _h
Display range (min. value unit max. value)		
0		200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00060

Parameter Name: C00060 Rotor position		Data type: INTEGER_32 Index: 24515 _d = 5FC3 _h
Display range (min. value unit max. value)		
0		2047
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00061

Parameter Name: C00061 Heatsink temperature		Data type: INTEGER_32 Index: 24514 _d = 5FC2 _h
Display range (min. value unit max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00062

Parameter Name: C00062 Temperature inside the controller		Data type: INTEGER_32 Index: 24513 _d = 5FC1 _h
Display range (min. value unit max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00063

Parameter Name: C00063 Motor temperature		Data type: INTEGER_32 Index: 24512 _d = 5FC0 _h
▶ Motor temperature monitoring		
Display range (min. value unit max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00064

Parameter Name: C00064 Device utilisation (Ixt)			Data type: UNSIGNED_32 Index: 24511 _d = 5FBF _h
Device utilisation during the last 180 seconds <ul style="list-style-type: none"> • C00064 > 100 % activates error (OC5). • Error reset only possible if C00064 < 95 %. 			
Display range (min. value unit max. value)			
0	%	250	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00065

Parameter Name: C00065 Ext. 24-V voltage			Data type: INTEGER_32 Index: 24510 _d = 5FBE _h
Display range (min. value unit max. value)			
0.0	V	1000.0	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00066

Parameter Name: C00066 Thermal motor load (I²xt)			Data type: UNSIGNED_32 Index: 24509 _d = 5FBD _h
A 100 % load corresponds to a permanently flowing rated motor current			▶ I²xt motor monitoring
Display range (min. value unit max. value)			
0	%	250	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00068

Parameter Name: C00068 Capacitor temperature			Data type: INTEGER_32 Index: 24507 _d = 5FBB _h
Display range (min. value unit max. value)			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00069

Parameter Name: C00069 CPU temperature			Data type: INTEGER_32 Index: 24506 _d = 5FBA _h
Display range (min. value unit max. value)			
-200	°C	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00070

Parameter Name: C00070 Speed controller gain			Data type: UNSIGNED_32 Index: 24505 _d = 5FB9 _h
Setting range (min. value unit max. value)		Lenze setting	
0.00000	Nm/rpm	20000.00000	0.00044 Nm/rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100000

C00071

Parameter Name: C00071 Speed contr. reset time			Data type: UNSIGNED_32 Index: 24504 _d = 5FB8 _h
Setting range (min. value unit max. value)			Lenze setting
1.0	ms	6000.0	14.4 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00072

Parameter Name: C00072 Speed contr.D component			Data type: UNSIGNED_32 Index: 24503 _d = 5FB7 _h
Setting range (min. value unit max. value)			Lenze setting
0.00	ms	3.00	0.00 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00074

Parameter Name: C00074 Feedfwd. ctrl. - current contr.			Data type: UNSIGNED_8 Index: 24501 _d = 5FB5 _h
Selection list (Lenze setting printed in bold)			
0	Deactivate feedfwd. ctrl		
1	Activate feedfwd. ctrl		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00075

Parameter Name: C00075 Current controller gain			Data type: UNSIGNED_32 Index: 24500 _d = 5FB4 _h
Setting range (min. value unit max. value)			Lenze setting
0.00	V/A	750.00	105.00 V/A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00076

Parameter Name: C00076 Current contr. reset time			Data type: UNSIGNED_32 Index: 24499 _d = 5FB3 _h
Setting range (min. value unit max. value)			Lenze setting
0.01	ms	2000.00	2.00 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00077

Parameter Name: C00077 Field controller gain			Data type: UNSIGNED_32 Index: 24498 _d = 5FB2 _h
Setting range (min. value unit max. value)			Lenze setting
0.00	A/Vs	50000.00	165.84 A/Vs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00078

Parameter Name: C00078 Field contr. reset time			Data type: UNSIGNED_32 Index: 24497 _d = 5FB1 _h
Setting range (min. value unit max. value)			Lenze setting
1.0	ms	6000.0	15.1 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00079

Parameter Name: C00079 Motor - mutual inductance			Data type: UNSIGNED_32 Index: 24496 _d = 5FB0 _h
Display range (min. value unit max. value)			
0.0	mH	214748364.7	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00080

Parameter Name: C00080 Resolver - number of pole pairs			Data type: UNSIGNED_32 Index: 24495 _d = 5FAF _h
			▶ Adaptation of the resolver evaluation dynamics ▶ Homing ▶ Behaviour of the home position after mains switching
Setting range (min. value unit max. value)			Lenze setting
1		10	1
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00081

Parameter Name: C00081 Rated motor power			Data type: UNSIGNED_32 Index: 24494 _d = 5FAE _h
Setting range (min. value unit max. value)			Lenze setting
0.01	kW	500.00	0.25 kW
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00082

Parameter Name: C00082 Motor rotor resistance			Data type: UNSIGNED_32 Index: 24493 _d = 5FAD _h
Display range (min. value unit max. value)			
0.0000	Ohm	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C00083

Parameter Name: C00083 Motor rotor time constant			Data type: UNSIGNED_32 Index: 24492 _d = 5FAC _h
Display range (min. value unit max. value)			
0.00	ms	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00084

Parameter Name: C00084 Motor stator resistance			Data type: UNSIGNED_32 Index: 24491 _d = 5FAB _h
Setting range (min. value unit max. value)			Lenze setting
0.0000	Ohm	125.0000	18.2200 Ohm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C00085

Parameter Name: C00085 Motor stator leakage inductance			Data type: UNSIGNED_32 Index: 24490 _d = 5FAA _h
Setting range (min. value unit max. value)			Lenze setting
0.000	mH	500.000	51.000 mH
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00087

Parameter Name: C00087 Rated motor speed			Data type: UNSIGNED_32 Index: 24488 _d = 5FA8 _h
Setting range (min. value unit max. value)			Lenze setting
50	rpm	50000	4050 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00088

Parameter Name: C00088 Rated motor current			Data type: UNSIGNED_32 Index: 24487 _d = 5FA7 _h
Setting range (min. value unit max. value)			Lenze setting
0.01	A	1500.00	1.30 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00089

Parameter Name: C00089 Rated motor frequency			Data type: UNSIGNED_32 Index: 24486 _d = 5FA6 _h
Setting range (min. value unit max. value)			Lenze setting
0.1	Hz	1000.0	270.0 Hz
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00090

Parameter Name: C00090 Rated motor voltage			Data type: UNSIGNED_32 Index: 24485 _d = 5FA5 _h
Setting range (min. value unit max. value)			Lenze setting
50	V	15000	225 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00091

Parameter Name: C00091 Motor cosine phi			Data type: UNSIGNED_32 Index: 24484 _d = 5FA4 _h	
Setting range (min. value unit max. value)			Lenze setting	
0.50		1.00	0.80	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100	

C00092

Parameter Name: C00092 Motor - magnetising current			Data type: UNSIGNED_32 Index: 24483 _d = 5FA3 _h	
Display range (min. value unit max. value)				
0.00	A	500.00		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100	

C00093

Parameter Name: C00093 Field weakening for SM			Data type: UNSIGNED_32 Index: 24482 _d = 5FA2 _h	
From software version V2.0 onwards				
► Field weakening for synchronous machines				
Selection list (Lenze setting printed in bold)				
0	Field weakening for SM off			
1	Field weakening for SM on			
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

C00099

Parameter Name: C00099 Firmware version			Data type: VISIBLE_STRING Index: 24476 _d = 5F9C _h	
Format: "xx.xx.xx.xx" (main version, subversion, release version, build number)				
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer			Scaling factor: 1 Character length: 12	

C00100

Parameter Name: C00100 Resol. of an encoder revolution			Data type: UNSIGNED_32 Index: 24475 _d = 5F9B _h	
Setting range (min. value unit max. value)			Lenze setting	
10		24	16	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

C00105

Parameter Name: C00105 Decel. time - quick stop			Data type: UNSIGNED_32 Index: 24470 _d = 5F96 _h	
Time between quick stop activation and standstill plus relative S-ramp time (C00106).				
► Basic function "Quick stop"				
Setting range (min. value unit max. value)			Lenze setting	
0.000	s	999.999	0.000 s	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000	

C00106

Parameter Name: C00106 Quick stop S-ramp time		Data type: UNSIGNED_32 Index: 24469 _d = 5F95 _h	
S-ramp time in [%] relating to the deceleration time set under C00105 .			
▶ Basic function " Quick stop "			
Setting range (min. value unit max. value)		Lenze setting	
0.00	%	100.00	0.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00107

Parameter Name: C00107 Ref. for quick stop dec. time		Data type: UNSIGNED_8 Index: 24468 _d = 5F94 _h	
Reference for the deceleration time set in C00105 .			
▶ Basic function " Quick stop "			
Selection list (Lenze setting printed in bold)			
0	Motor reference speed (C00011)		
1	Current speed		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00114

Parameter Name: C00114 Dig. input x: Terminal polarity		Data type: UNSIGNED_8 Index: 24461 _d = 5F8D _h	
"0" = positive logic (HIGH level = TRUE, LOW level = FALSE) "1" = negative logic (HIGH level = FALSE, LOW level = TRUE)			
Setting range (min. value unit max. value)			
0		1	
Subcodes	Lenze setting	Info	
C00114/1	0	Terminal polarity - digital input 1 ... 8	
C00114/...			
C00114/8			
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00118

Parameter Name: C00118 Dig. output. x: Terminal polarity		Data type: UNSIGNED_8 Index: 24457 _d = 5F89 _h	
"0" ≡ positive logic (TRUE ≡ HIGH level, FALSE ≡ LOW level) "1" ≡ negative logic (FALSE ≡ HIGH level, TRUE ≡ LOW level)			
Setting range (min. value unit max. value)			
0		1	
Subcodes	Lenze setting	Info	
C00118/1	0	Terminal polarity - digital output 1 ... 4	
C00118/...			
C00118/4			
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00120

Parameter Name: C00120 Mot. overload protection (I²t)		Data type: UNSIGNED_32 Index: 24455 _d = 5F87 _h	
Threshold for I ² x t disconnection <ul style="list-style-type: none"> • Disconnection is carried out if the thermal motor load (C00066) is higher than the set threshold. • A 100 % thermal motor load corresponds to a permanently flowing rated motor current Note: When the value is parameterised to 200 %, the monitoring mode of the motor overload protection is switched off! ▶ I²x t motor monitoring			
Setting range (min. value unit max. value)		Lenze setting	
0	%	200	105 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00121

Parameter Name: C00121 Warning threshold motor temperature		Data type: UNSIGNED_32 Index: 24454 _d = 5F86 _h	
Temperature threshold for motor temperature advance warning <ul style="list-style-type: none"> • The response to reaching the threshold can be selected in C00584. ▶ Motor temperature monitoring			
Setting range (min. value unit max. value)		Lenze setting	
0	°C	150	120 °C
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00122

Parameter Name: C00122 Heatsink temp. warn. threshold		Data type: UNSIGNED_32 Index: 24453 _d = 5F85 _h	
Temperature threshold for heatsink temperature advance warning <ul style="list-style-type: none"> • The response to reaching the threshold can be selected in C00582. 			
Setting range (min. value unit max. value)		Lenze setting	
0	°C	85	85 °C
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00123

Parameter Name: C00123 Warning threshold device util.		Data type: UNSIGNED_32 Index: 24452 _d = 5F84 _h	
Adjustable threshold for I x t advance warning <ul style="list-style-type: none"> • The advance warning is sent if the device utilisation (C00064) is higher than the set threshold. • The response for reaching the threshold can be selected in C00604. 			
Setting range (min. value unit max. value)		Lenze setting	
0	%	100	90 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00126

Parameter Name: C00126 CPU temp. warning threshold			Data type: UNSIGNED_32 Index: 24449 _d = 5F81 _h
Temperature threshold for advance warning of CPU temperature on the control card			
<ul style="list-style-type: none"> The response to reaching the threshold can be selected in C00589. 			
Setting range (min. value unit max. value)			Lenze setting
0	°C	85	70 °C
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00127

Parameter Name: C00127 Mot. overload warning threshold			Data type: UNSIGNED_32 Index: 24448 _d = 5F80 _h
Adjustable threshold for I ² x t advance warning			
<ul style="list-style-type: none"> The advance warning is sent if the thermal motor load (C00066) is higher than the set threshold. The response for reaching the threshold can be selected in C00606. 			
▶ I2xt motor monitoring			
Setting range (min. value unit max. value)			Lenze setting
0	%	200	100 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00128

Parameter Name: C00128 Therm. motor time constant			Data type: UNSIGNED_32 Index: 24447 _d = 5F7F _h
▶ I2xt motor monitoring			
Setting range (min. value unit max. value)			
0.1	min	600.0	
Subcodes	Lenze setting	Info	
C00128/1	1.0 min	Therm. time constant coil	
C00128/2	5.0 min	Therm. time constant plates	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00129

Parameter Name: C00129 Brake resistance value			Data type: INTEGER_32 Index: 24446 _d = 5F7E _h
Required for monitoring of the brake resistor temperature.			
▶ Braking operation			
Setting range (min. value unit max. value)			Lenze setting
0.0	Ohm	500.0	180.0 Ohm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00130

Parameter Name: C00130 Rated power - brake resistor			Data type: INTEGER_32 Index: 24445 _d = 5F7D _h
Required for monitoring of the brake resistor temperature.			▶ Braking operation
Setting range (min. value unit max. value)		Lenze setting	
0	W	800000	5600 W
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00131

Parameter Name: C00131 - Rated quantity of heat for brake res.			Data type: INTEGER_32 Index: 24444 _d = 5F7C _h
Required for monitoring of the brake resistor temperature.			▶ Braking operation
Setting range (min. value unit max. value)		Lenze setting	
0	kWs	100000	485 kWs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00132

Parameter Name: C00132 Service code			Data type: INTEGER_32 Index: 24443 _d = 5F7B _h
This code is for device-internal use only and must not be written to by the user!			

C00133

Parameter Name: C00133 Ref.: Brake chopper utilisation			Data type: UNSIGNED_8 Index: 24442 _d = 5F7A _h
From software version V1.5			▶ Braking operation
Selection list (Lenze setting printed in bold)		Info	
0	Minimum resistance (C00134)	▶ C00134	
1	Resistance in C00129	▶ C00129	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00134

Parameter Name: C00134 Minimum brake resistance			Data type: INTEGER_32 Index: 24441 _d = 5F79 _h
From software version V1.5			▶ Braking operation
Display range (min. value unit max. value)			
0.0	Ohm	500.0	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00137

Parameter Name: C00137 Brake transistor utilisation		Data type: INTEGER_32 Index: 24438 _d = 5F76 _h
From software version V1.5		▶ Braking operation
Display range (min. value unit max. value)		
0	%	250
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00138

Parameter Name: C00138 Brake resistor utilisation		Data type: INTEGER_32 Index: 24437 _d = 5F75 _h
From software version V1.5		▶ Braking operation
Display range (min. value unit max. value)		
0	%	250
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00142

Parameter Name: C00142 Autom. restart after mains ON		Data type: UNSIGNED_32 Index: 24433 _d = 5F71 _h
Starting performance of the controller after mains connection and reset of "Trouble", "Fault" or "Safe torque off active".		
<p>⚠ Danger!</p> <ul style="list-style-type: none"> If automatic restart is enabled (C00142 = "1: Enabled"), the drive can restart automatically from the "Trouble" and "Safe torque off" device states when the trouble or request for "Safe torque off active" has been eliminated! The controller enable generated by the application via a connection of the terminal 28 (RFR) with one of the digital outputs <i>DIGOUT_bOut(x)</i> is not permissible if the following functions are active: "Auto-start after mains ON" (C00142 = "1") and "Program auto-start after mains switching" (C02104 = "1") If this is not observed, the controller can start automatically after mains connection! 		
		▶ Automatic restart after mains connection ▶ Activate application
Selection list (Lenze setting printed in bold)		
0	Blocked	
1	Released	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00150

Parameter Name: C00150 Status word device control 1		Data type: BITFIELD_16 Index: 24425 _d = 5F69 _h
Status word 1 of the drive interface		
Display area		
0x0000		0xFFFF
Value is bit-coded:		Info
Bit 0	Reserved	For the meaning of bits 8 ... 11 see chapter " Device states ".
Bit 1	Pulse inhibit active	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Reserved	
Bit 5	Reserved	
Bit 6	Actual speed value = 0	
Bit 7	Controller inhibit active	
Bit 8	Device state - Bit 1	
Bit 9	Device state - Bit 2	
Bit 10	Device state - Bit 3	
Bit 11	Device state - Bit 4	
Bit 12	Warning is active	
Bit 13	Trouble active	
Bit 14	Reserved	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00155

Parameter Name: C00155 Status word device control 2		Data type: BITFIELD_16 Index: 24420 _d = 5F64 _h
Status word 2 of the drive interface		
Display area		
0x0000		0xFFFF
Value is bit-coded:		
Bit 0	Error status active	
Bit 1	Torque limit reached	
Bit 2	Current limit reached	
Bit 3	Reserved	
Bit 4	Drive switched on/in operation	
Bit 5	Drive ready for operation	
Bit 6	Fault active	
Bit 7	Drive initialisation	
Bit 8	Motor CCW rotation active	
Bit 9	Quick stop by trouble active	
Bit 10	Safe torque off active	
Bit 11	Application active	
Bit 12	Reserved	
Bit 13	Reserved	
Bit 14	Quick stop active	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00156

Parameter Name: C00156 Status/Control word MCTRL		Data type: UNSIGNED_32 Index: 24419 _d = 5F63 _h
Status and control word of the motor interface		
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C00156/1		Status word motor control
C00156/2		Control word motor control
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00158

Parameter Name: C00158 Controller inhibit by (source)		Data type: BITFIELD_16 Index: 24417 _d = 5F61 _h
Display of the sources for controller inhibit		
Display area		
0x0000		0xFFFF
Value is bit-coded:		
Bit 0	Terminal	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Device command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Energy saving mode	
Bit 10	Operating system	
Bit 11	Identification program	
Bit 12	Brake	
Bit 13	Limiter	
Bit 14	PPI	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00159

Parameter Name: C00159 Quick stop by (source)		Data type: BITFIELD_16 Index: 24416 _d = 5F60 _h
Display area		
0x0000		0xFFFF
Value is bit-coded:		
Bit 0	Reserved	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Device command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Reserved	
Bit 13	Reserved	
Bit 14	Reserved	
Bit 15	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00162

Parameter Name: C00162 Masked Error number		Data type: UNSIGNED_32 Index: 24413 _d = 5F5D _h
From software version V5.0 Display of the individual components of the error number shown in C00168 .		
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C00162/1		Module ID + error number • As described in the chapter " Error messages ".
C00162/2		Instance number
C00162/3		Error response
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00166

Parameter Name: C00166 Error description		Data type: VISIBLE_STRING Index: 24409 _d = 5F59 _h
Error description for error number indicated in C00168		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer Scaling factor: 1 Character length: 64		

C00167

Parameter Name: C00167 Service code	Data type: VISIBLE_STRING Index: 24408 _d = 5F58 _h
This code is for device-internal use only and must not be written to by the user!	

C00168

Parameter Name: C00168 Error number	Data type: UNSIGNED_32 Index: 24407 _d = 5F57 _h
Display of the error number of the first error with highest priority	
Display range (min. value unit max. value)	
0	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00169

Parameter Name: C00169 Logbook - event filter	Data type: BITFIELD_32 Index: 24406 _d = 5F56 _h
Bit coded word for filtering system events (trouble, warning, information) <ul style="list-style-type: none"> • A set filter bit inhibits entry of the corresponding event into the logbook. • From software version V5.0 the option that identical consecutive entries ("Multiple entries") into the logbook are suppressed can be additionally activated via bit 0. Then only the time stamp of the last (latest) entry and the number of times the same event has occurred successively are saved. 	
▶ Logbook	
Setting range	Lenze setting
0x00000000	0xFFFFFFFF 0x00000001 (decimal: 1)
Value is bit-coded: (<input checked="" type="checkbox"/> = bit set)	Info
Bit 0 <input checked="" type="checkbox"/> No multiple entries	Bits not listed are reserved for future extensions!
Bit 1 <input type="checkbox"/> Error	
Bit 2 <input type="checkbox"/> Fault	
Bit 3 <input type="checkbox"/> Quick stop by trouble	
Bit 4 <input type="checkbox"/> Warning locked	
Bit 5 <input type="checkbox"/> Warning	
Bit 6 <input type="checkbox"/> Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00171

Parameter Name: C00171 Service code	Data type: UNSIGNED_32 Index: 24404 _d = 5F54 _h
This code is for device-internal use only and must not be written to by the user!	

C00173

Parameter Name: C00173 Mains voltage		Data type: UNSIGNED_8 Index: 24402 _d = 5F52 _h
Adjustment of the DC bus voltage thresholds <ul style="list-style-type: none"> • Check during commissioning and adapt, if necessary. • All drive components connected via the DC bus must have the same thresholds. • For selection 0 ... 3, the undervoltage threshold is firmly defined depending on the device type (see "Rated data" chapter in the Hardware Manual). Note: Altering this setting also has an impact on the permissible device utilisation! In the chapter "Rated data" of the hardware manual the device types and their permissible device utilisation at a certain mains voltage and switching frequency are specified.		
Selection list (Lenze setting printed in bold)		Info
0	230 V	Operation on 230 V mains <ul style="list-style-type: none"> • Threshold for "Undervoltage on" = 200 V • Threshold for "Undervoltage off" = 225 V • Overvoltage threshold = 400 V • Brake chopper threshold = 390 V
1	400/415 V	Operation on 400 V mains/415 V mains <ul style="list-style-type: none"> • Threshold for "Undervoltage on" = 285 V (BF1 to BF7) • Threshold for "Undervoltage on" = 400 V (BF8 to BF10) • Threshold for "Undervoltage off" = 430 V • Overvoltage threshold = 800 V • Brake chopper threshold = 725 V
2	460/480 V	Operation on 460 V mains/480 V mains <ul style="list-style-type: none"> • Threshold for "Undervoltage on" = 490 V • Threshold for "Undervoltage off" = 535 V • Overvoltage threshold = 800 V • Brake chopper threshold = 765 V
3	500 V	Operation on 500 V mains <ul style="list-style-type: none"> • Threshold for "Undervoltage on" = 540 V • Threshold for "Undervoltage off" = 585 V • Overvoltage threshold = 800 V • Brake chopper threshold = 790 V
4	230 V, LU configurable	Operation on 230 V mains <ul style="list-style-type: none"> • Undervoltage threshold is defined in C00174. • Overvoltage threshold = 400 V • Brake chopper threshold = 390 V
5	400/415 V, LU configurable	Operation on 400 V mains/415 V mains <ul style="list-style-type: none"> • Undervoltage threshold is defined in C00174. • Overvoltage threshold = 800 V • Brake chopper threshold = 725 V
6	460/480 V, LU configurable	Operation on 460 V mains/480 V mains <ul style="list-style-type: none"> • Undervoltage threshold is defined in C00174. • Overvoltage threshold = 800 V • Brake chopper threshold = 765 V
7	500 V, LU configurable	Operation on 500 V mains <ul style="list-style-type: none"> • Undervoltage threshold is defined in C00174. • Overvoltage threshold = 800 V • Brake chopper threshold = 790 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00174

Parameter Name: C00174 Undervoltage (LU) threshold		Data type: UNSIGNED_32 Index: 24401 _d = 5F51 _h
When C00173 = 4 ... 7, the undervoltage threshold (LU) can be freely selected.		
Note: The minimum adjustable undervoltage threshold depends on the device type:		
<ul style="list-style-type: none"> • Single-axis controller (Single Drive) up to and including BF7: 210 V • Single-axis controller (Single Drive) from BF8s: 400 V • Multi-axis controller (Multi Drive): 15 V 		
In the case of an offline parameter setting or when exchanging the memory module between different 9400 HighLine device types, always check the setting of this parameter and adapt it, if required, to prevent a parameter error after the parameter set download or module change!		
Setting range (min. value unit max. value)		Lenze setting
15	V	400 285 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00175

Parameter Name: C00175 Service code		Data type: UNSIGNED_32 Index: 24400 _d = 5F50 _h
This code is for device-internal use only and must not be written to by the user!		

C00176

Parameter Name: C00176 Service code		Data type: UNSIGNED_32 Index: 24399 _d = 5F4F _h
This code is for device-internal use only and must not be written to by the user!		

C00177

Parameter Name: C00177 Service code		Data type: UNSIGNED_32 Index: 24398 _d = 5F4E _h
This code is for device-internal use only and must not be written to by the user!		

C00178

Parameter Name: C00178 Elapsed-hour meter		Data type: UNSIGNED_32 Index: 24397 _d = 5F4D _h
Display range (min. value unit max. value)		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00179

Parameter Name: C00179 Power-on time meter		Data type: UNSIGNED_32 Index: 24396 _d = 5F4C _h
Display range (min. value unit max. value)		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00180

Parameter Name: C00180 Service code		Data type: VISIBLE_STRING Index: 24395 _d = 5F4B _h
For Lenze service only		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Character length: 192		

C00181

Parameter Name: C00181 Red. brake chopper threshold		Data type: UNSIGNED_32 Index: 24394 _d = 5F4A _h
		▶ Braking operation
Setting range (min. value unit max. value)		Lenze setting
0	V	100
		0 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00182

Parameter Name: C00182 Time for device search function		Data type: UNSIGNED_16 Index: 24393 _d = 5F49 _h
From software version V9.0		
Setting range (min. value unit max. value)		Lenze setting
0		6000
		5
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00183

Parameter Name: C00183 Device status		Data type: UNSIGNED_32 Index: 24392 _d = 5F48 _h
Display of the device state for diagnostic purposes		
Selection list (read only)		
0	Operation	
1	Operation/Warning active	
2	Operation/warning locked act.	
3	Operation/Quick stop active	
4	Operation/Application stopped	
10	Initialisation active	
20	System fault active	
90	Device is switched on	
91	Device is switched on/QSP trouble	
95	Device switched-on/energy saving mode	
101	Safe torque off active	
102	Fault active	
104	Trouble active	
141	Drive ready to start --> C00142	
151	Quick stop by trouble active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00185

Parameter Name: C00185 Mains recov. detect. threshold		Data type: UNSIGNED_32 Index: 24390 _d = 5F46 _h
This code must not be written to by the user!		
Setting range (min. value unit max. value)		Lenze setting
0	%	100
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00186

Parameter Name: C00186 ENP: Identified motor type		Data type: VISIBLE_STRING Index: 24389 _d = 5F45 _h
Motor type read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 19

C00187

Parameter Name: C00187 ENP: Identified serial number		Data type: VISIBLE_STRING Index: 24388 _d = 5F44 _h
Serial number read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 22

C00188

Parameter Name: C00188 ENP: Status		Data type: UNSIGNED_8 Index: 24387 _d = 5F43 _h
Selection list (read only)		
0	No ENP found	
1	ENP data loaded	
2	Known ENP found	
3	ENP found but not read	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00198

Parameter Name: C00198 Service code		Data type: UNSIGNED_32 Index: 24377 _d = 5F39 _h
This code is for device-internal use only and must not be written to by the user!		

C00199

Parameter Name: C00199 Device name		Data type: VISIBLE_STRING Index: 24376 _d = 5F38 _h
Device name to be defined by the user (e.g. "Cross cutter" or "hoist axis 1") with max. 128 characters		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 128

C00200

Parameter Name: C00200 Firmware product type		Data type: VISIBLE_STRING Index: 24375 _d = 5F37 _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 18

C00201

Parameter Name: C00201 Firmware - compiling date	Data type: VISIBLE_STRING Index: 24374 _d = 5F36 _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer Scaling factor: 1 Character length: 21	

C00202

Parameter Name: C00202 Autom. ENP data transfer	Data type: UNSIGNED_32 Index: 24373 _d = 5F35 _h
From software version V1.5	
Selection list (Lenze setting printed in bold)	
0	Off
1	On
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00203

Parameter Name: C00203 HW product types	Data type: VISIBLE_STRING Index: 24372 _d = 5F34 _h
Subcodes	Info
C00203/1	Type: Control card
C00203/2	Type: Power section
C00203/3	Type: Module in MXI1
C00203/4	Type: Module in MXI2
C00203/5	Type: Memory module
C00203/6	Type: Safety module
C00203/7	Type: Standard device
C00203/8	Type: Complete device
C00203/9	Type: ENP
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer Scaling factor: 1 Character length: 18	

C00204

Parameter Name: C00204 HW serial numbers	Data type: VISIBLE_STRING Index: 24371 _d = 5F33 _h
Subcodes	Info
C00204/1	Serial no.: Control card
C00204/2	Serial no.: Power section
C00204/3	Serial no.: Module in MXI1
C00204/4	Serial no.: Module in MXI2
C00204/5	Serial no.: Memory module
C00204/6	Serial no.: Safety module
C00204/7	Serial no.: Standard device
C00204/8	Serial no.: Complete device
C00204/9	Serial no.: ENP
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer Scaling factor: 1 Character length: 22	

C00205

Parameter Name: C00205 HW descriptions		Data type: VISIBLE_STRING Index: 24370 _d = 5F32 _h
Subcodes	Info	
C00205/1	Info: Control card	
C00205/2	Info: Power section	
C00205/3	Info: Module in MXI1	
C00205/4	Info: Module in MXI2	
C00205/5	Info: Memory module	
C00205/6	Info: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 18

C00206

Parameter Name: C00206 HW manufacturing data		Data type: VISIBLE_STRING Index: 24369 _d = 5F31 _h
Subcodes	Info	
C00206/1	Date: Control card	
C00206/2	Date: Power section	
C00206/3	Date: Module in MXI1	
C00206/4	Date: Module in MXI2	
C00206/5	Date: Memory module	
C00206/6	Date: Safety module	
C00206/7	Date: Standard device	
C00206/8	Date: Complete device	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 20

C00208

Parameter Name: C00208 HW manufacturer		Data type: VISIBLE_STRING Index: 24367 _d = 5F2F _h
Subcodes	Info	
C00208/1	Manufacturer: Control card	
C00208/2	Manufacturer: Power section	
C00208/3	Manufacturer: Module in MXI1	
C00208/4	Manufacturer: Module in MXI2	
C00208/5	Manufacturer: Memory module	
C00208/6	Manufacturer: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 20

C00209

Parameter Name: C00209 HW countries of origin		Data type: VISIBLE_STRING Index: 24366 _d = 5F2E _h
Subcodes	Info	
C00209/1	Country: Control card	
C00209/2	Country: Power section	
C00209/3	Country: Module in MXI1	
C00209/4	Country: Module in MXI2	
C00209/5	Country: Memory module	
C00209/6	Country: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 4

C00210

Parameter Name: C00210 HW versions		Data type: VISIBLE_STRING Index: 24365 _d = 5F2D _h
Subcodes	Info	
C00210/1	HW version: Control card	
C00210/2	HW version: Power section	
C00210/3	HW version: Module in MXI1	
C00210/4	HW version: Module in MXI2	
C00210/5	HW version: Memory module	
C00210/6	HW version: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 5

C00211

Parameter Name: C00211 Application: Version		Data type: VISIBLE_STRING Index: 24364 _d = 5F2C _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 12

C00212

Parameter Name: C00212 Application: Type code		Data type: VISIBLE_STRING Index: 24363 _d = 5F2B _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> RSP <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 20

C00213

Parameter Name: C00213 Application: Compiler date		Data type: VISIBLE_STRING Index: 24362 _d = 5F2A _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 21

C00214

Parameter Name: C00214 Required safety module		Data type: UNSIGNED_8 Index: 24361 _d = 5F29 _h
Setting of the expected safety module		
<ul style="list-style-type: none"> If a different safety module is detected, a fault (trouble) will be activated. The fault can only be reset by mains switching. 		
Selection list (Lenze setting printed in bold)		
1	SM0	
2	SM100	
4	SM300	
5	SM301	
6	SM302	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00217

Parameter Name: C00217 Parameter error information		Data type: UNSIGNED_32 Index: 24358 _d = 5F26 _h
This code is for device-internal use only and must not be written to by the user!		

C00218

Parameter Name: C00218 Application: ID number		Data type: UNSIGNED_32 Index: 24357 _d = 5F25 _h
Display range (min. value unit max. value)		
0		0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00219

Parameter Name: C00219 CAN/EPL device type		Data type: UNSIGNED_32 Index: 24356 _d = 5F24 _h
This code is for device-internal use only and must not be written to by the user!		

C00220

Parameter Name: C00220 Memory module Firmw. Rev.		Data type: UNSIGNED_32 Index: 24355 _d = 5F23 _h
Display range (min. value unit max. value)		
0		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00225

Parameter Name: C00225 Check configuration		Data type: UNSIGNED_32 Index: 24350 _d = 5F1E _h
This code is for device-internal use only and must not be written to by the user!		

C00227

Parameter Name: C00227 Behaviour due to change of parameter set		Data type: UNSIGNED_32 Index: 24348 _d = 5F1C _h
From software version V5.0		
By selecting "1" in the corresponding subcode a module plugged into module slot MXI1 or MXI2 can be excepted from the parameter set changeover via the device command "Activate parameter set n".		
<ul style="list-style-type: none"> • By this the parameter set changeover, in particular for active modules, is carried out much more quickly. • An exception from the parameter set changeover for instance is reasonable if different parameter sets are used (e. g. for different tools within the machine), but if the parameters are always the same for the module (e. g. communication parameters). 		
Selection list (Lenze setting printed in bold)		
0	Included	
1	Excluded	
Subcodes	Lenze setting	Info
C00227/1	0: Included	Change of parameter set: MXI1
C00227/2	0: Included	Change of parameter set: MXI2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00254

Parameter Name: C00254 Phase controller gain		Data type: UNSIGNED_32 Index: 24321 _d = 5F01 _h
Setting range (min. value unit max. value)		Lenze setting
0.00	1/s	1000.00
		20.00 1/s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00270

Parameter Name: C00270 Freq. - current setpoint filter		Data type: UNSIGNED_32 Index: 24305 _d = 5EF1 _h
▶ Set current setpoint filter (band-stop filter)		
Setting range (min. value unit max. value)		
1.0	Hz	1000.0
Subcodes	Lenze setting	Info
C00270/1	200.0 Hz	Freq. - current setp. filter 1
C00270/2	400.0 Hz	Freq. - current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00271

Parameter Name: C00271 Width - current setp. filter		Data type: UNSIGNED_32 Index: 24304 _d = 5EF0 _h
▶ Set current setpoint filter (band-stop filter)		
Setting range (min. value unit max. value)		
0.0	Hz	500.0
Subcodes	Lenze setting	Info
C00271/1	20.0 Hz	Width current setp. filter 1
C00271/2	40.0 Hz	Width current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00272

Parameter Name: C00272 Depth - current setp. filter		Data type: UNSIGNED_32 Index: 24303 _d = 5EEF _h
The setting "0 dB" deactivates the current setpoint filter. ▶ Set current setpoint filter (band-stop filter)		
Setting range (min. value unit max. value)		
0	db	100
Subcodes	Lenze setting	Info
C00272/1	0 db	Depth current setp. filter 1
C00272/2	0 db	Depth current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00273

Parameter Name: C00273 Moment of inertia		Data type: UNSIGNED_32 Index: 24302 _d = 5EEE _h
Note: The load moment of inertia must be set with regard to the motor end (i.e. considering the gearbox factors).		
Setting range (min. value unit max. value)		
0.00	kg cm ²	20000000.00
Subcodes	Lenze setting	Info
C00273/1	0.14 kg cm ²	Motor moment of inertia
C00273/2	0.00 kg cm ²	Load moment of inertia
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00274

Parameter Name: C00274 Max. acceleration change		Data type: UNSIGNED_32 Index: 24301 _d = 5EED _h
Setting range (min. value unit max. value)		Lenze setting
0.0	%/ms	400.0 400.0 %/ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00275

Parameter Name: C00275 Signal source - speed setpoint		Data type: UNSIGNED_16 Index: 24300 _d = 5EEC _h
Selection list (Lenze setting printed in bold)		
0	SpeedAdd signal	
1	Differentiated PosSet signal	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00276

Parameter Name: C00276 Signal source - torque setpoint		Data type: UNSIGNED_16 Index: 24299 _d = 5EEB _h
Selection list (Lenze setting printed in bold)		Info
0	TorqueAdd/AccAdd signal	
1	Differentiated SpeedSet signal	
2	2x diff. PosSet signal	This setting only exists due to compatibility reasons and should not be used anymore. Use the setting 3 instead: "Differentiated SpeedAdd signal" that both can be used for the FB LS_SpeedFollower and the FB LS_PositionFollower .
3	Differentiated SpeedAdd signal	From software version V5.0 This alternative selection to the differentiated SpeedSet signal is recommended if the position controller works with a high gain. By the position controller also troubles within to the actual position value are detected and like this reach the speed setpoint. In the following differentiation of the feedforward control, these troubles in particular in the case of high position controller gains result in a very unsettled torque feedforward control value. By means of this selection the problem can be avoided, because then only the trouble-free speed feedforward control value is differentiated.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00280

Parameter Name: C00280 Filter time const. DC detection			Data type: UNSIGNED_32 Index: 24295 _d = 5EE7 _h
Setting range (min. value unit max. value)		Lenze setting	
1.0	ms	1000.0	25.0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00281

Parameter Name: C00281 Filter for PWM adjustment		Data type: UNSIGNED_8 Index: 24294 _d = 5EE6 _h
From software version V7.0		
<p>The output voltage of the inverter is generated from the DC-bus voltage by a pulse width modulation (PWM). The product from the DC-bus voltage and the control factor of the PWM corresponds to the height of the output voltage. If the DC-bus voltage changes due to mains fluctuations or load changes, the control factor of the PWM must be adapted if the output voltage is to remain constant. This correction is carried out in the control software by measuring the DC-bus voltage. In order that no response takes place to faults in the DC-bus voltage measurement, a filter can be activated for the measured signal via this parameter.</p> <ul style="list-style-type: none"> • The filter time constant is selected so that a quick correction can be carried out even under bad EMC conditions. • A disadvantage of this filter is that the responses to real flickers on the DC-bus voltage are too slow. In positioning tasks, this may cause an extreme increase of the following error. • Under good EMC conditions, this filter is not required (Lenze setting). • For devices > BF7 the filter is ineffective. 		
Selection list (Lenze setting printed in bold)		
0	Deactivated	
1	enabled	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

14 Parameter reference

14.2 Parameter list | C00308

C00308

Parameter Name: C00308 Service code	Data type: UNSIGNED_16 Index: 24267 _d = 5ECB _h
This code is for device-internal use only and must not be written to by the user!	

C00309

Parameter Name: C00309 Service code	Data type: UNSIGNED_32 Index: 24266 _d = 5ECA _h
This code is for device-internal use only and must not be written to by the user!	

C00310

Parameter Name: C00310 Service code	Data type: UNSIGNED_8 Index: 24265 _d = 5EC9 _h
This code is for device-internal use only and must not be written to by the user!	

C00311

Parameter Name: C00311 CAN TPDO1 mask byte x	Data type: BITFIELD_8 Index: 24264 _d = 5EC8 _h	
<p>For each byte of the TPDO1 a mask can be parameterised in the corresponding subcode.</p> <ul style="list-style-type: none"> In case of an event-controlled PDO transmission, only the masked bits will be considered for event control. Mask "0x0" means that no bit of the corresponding byte actuates the transmission. Mask "0xff" means that every bit of the corresponding byte can actuate the transmission. <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00	0xFF	
Value is bit-coded:		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
Subcodes	Lenze setting	Info
C00311/1	0x00	Mask for byte 1 ... byte 8 of TPDO1
C00311/...		
C00311/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00312

Parameter Name:		Data type: BITFIELD_8 Index: 24263 _d = 5EC7 _h
C00312 CAN TPDO2 mask byte x		
<p>For each byte of the TPDO2 a mask can be parameterised in the corresponding subcode.</p> <ul style="list-style-type: none"> • In case of an event-controlled PDO transmission, only the masked bits will be considered for event control. • Mask "0x0" means that no bit of the corresponding byte actuates the transmission. • Mask "0xff" means that every bit of the corresponding byte can actuate the transmission. <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00		0xFF
Value is bit-coded:		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
Subcodes	Lenze setting	Info
C00312/1	0x00	Mask for byte 1 ... byte 8 of TPDO2
C00312/...		
C00312/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00313

Parameter Name:		Data type: BITFIELD_8 Index: 24262 _d = 5EC6 _h
C00313 CAN TPDO3 mask byte x		
<p>For each byte of the TPDO3 a mask can be parameterised in the corresponding subcode.</p> <ul style="list-style-type: none"> • In case of an event-controlled PDO transmission, only the masked bits will be considered for event control. • Mask "0x0" means that no bit of the corresponding byte actuates the transmission. • Mask "0xff" means that every bit of the corresponding byte can actuate the transmission. <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00		0xFF
Value is bit-coded:		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
Subcodes	Lenze setting	Info
C00313/1	0x00	Mask for byte 1 ... byte 8 of TPDO3
C00313/...		
C00313/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00314

Parameter Name:		Data type: BITFIELD_8 Index: 24261 _d = 5EC5 _h
C00314 CAN TPDO4 mask byte x		
<p>For each byte of the TPDO4 a mask can be parameterised in the corresponding subcode.</p> <ul style="list-style-type: none"> • In case of an event-controlled PDO transmission, only the masked bits will be considered for event control. • Mask "0x0" means that no bit of the corresponding byte actuates the transmission. • Mask "0xff" means that every bit of the corresponding byte can actuate the transmission. <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00		0xFF
Value is bit-coded:		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
Subcodes	Lenze setting	Info
C00314/1	0x00	Mask for byte 1 ... byte 8 of TPDO4
C00314/...		
C00314/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00320

Parameter Name:		Data type: BITFIELD_32 Index: 24255 _d = 5EBF _h
C00320 CAN TPDOx identifier		
<p>Identifier for TPDO1 ... TPDO4</p> <ul style="list-style-type: none"> • If bit 31 is set (0x8nnnnnnn), the TPDO is deactivated. • The basic setting is according to the "Predefined Connection Set". • Mapping of the CANopen objects I-1800/1 ... I-1803/1 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		
Bit 0	COB-ID bit 0	
...	...	
Bit 31	PDO invalid	
Subcodes	Lenze setting	Info
C00320/1	0x00000181	TPDO1 identifier • After a node address change and CAN reset node, the value 0x180 + node address will be set by default.
C00320/2	0x00000281	TPDO2 identifier • After a node address change and CAN reset node, the value 0x280 + node address will be set by default.
C00320/3	0x00000381	TPDO3 identifier • After a node address change and CAN reset node, the value 0x380 + node address will be set by default.
C00320/4	0x00000481	Identifier TPDO4 • After a node address change and CAN reset node, the value 0x480 + node address will be set by default.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00321

Parameter Name: C00321 CAN RPDOx identifier		Data type: BITFIELD_32 Index: 24254 _d = 5EBE _h
Identifier for RPDO1 ... RPDO4 <ul style="list-style-type: none"> • If bit 31 is set (0x8nnnnnnn), the RPDO is deactivated. • The basic setting is according to the "Predefined Connection Set". • Mapping of the CANopen objects I-1400/1 ... I-1403/1 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Info
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> • Bit 0 ... 10: COB-ID • Bit 11 ... 30: Reserved • Bit 31: PDO invalid
...	...	
Bit 31	PDO invalid	
Subcodes	Lenze setting	Info
C00321/1	0x00000201	RPDO1 identifier <ul style="list-style-type: none"> • After a node address change and CAN reset node, the value 0x200 + node address will be set by default.
C00321/2	0x00000301	RPDO2 identifier <ul style="list-style-type: none"> • After a node address change and CAN reset node, the value 0x300 + node address will be set by default.
C00321/3	0x00000401	RPDO3 identifier <ul style="list-style-type: none"> • After a node address change and CAN reset node, the value 0x400 + node address will be set by default.
C00321/4	0x00000501	Identifier RPDO4 <ul style="list-style-type: none"> • After a node address change and CAN reset node, the value 0x500 + node address will be set by default.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00322

Parameter Name: C00322 CAN TPDOx Tx mode		Data type: UNSIGNED_8 Index: 24253 _d = 5EBD _h
TPDO transmission type according to DS301 V4.02 <ul style="list-style-type: none"> • Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported. • The basic PDO setting is "254" (event-controlled). • Illustration of the CANopen objects I-1800/2 ... I-1803/2 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range (min. value unit max. value)		
0		255
Subcodes	Lenze setting	Info
C00322/1	254	Transmission mode for TPDO1 ... TPDO4
C00322/...		
C00322/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00323

Parameter Name: C00323 CAN RPDOx Rx mode		Data type: UNSIGNED_8 Index: 24252 _d = 5EBC _h
<p>RPDO transmission type according to DS301 V4.02</p> <ul style="list-style-type: none"> For the RPDO, it serves as monitoring setting in the case of sync-controlled PDOs. Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported. The basic PDO setting is "254" (event-controlled). Illustration of the CANopen objects I-1400/2 ... I-1403/2 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range (min. value unit max. value)		
0		255
Subcodes	Lenze setting	Info
C00323/1	254	Transmission mode for RPDO1 ... RPDO4
C00323/...		
C00323/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00324

Parameter Name: C00324 CAN TPDOx delay time		Data type: UNSIGNED_16 Index: 24251 _d = 5EBB _h
<p>TPDO inhibit time according to DS301 V4.02</p> <ul style="list-style-type: none"> Minimum time between the transmission of two identical TPDOs. The time is entered in 1/10 ms and automatically rounded to full milliseconds by the code. Mapping of the CANopen objects I-1800/3 ... I-1803/3 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range (min. value unit max. value)		
0	1/10 ms	65535
Subcodes	Lenze setting	Info
C00324/1	0 1/10 ms	Delay time for TPDO1 ... TPDO4
C00324/...		
C00324/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00325

Parameter Name: C00325 Service code		Data type: UNSIGNED_8 Index: 24250 _d = 5EBA _h
This code is for device-internal use only and must not be written to by the user!		

C00326

Parameter Name: C00326 Service code		Data type: UNSIGNED_8 Index: 24249 _d = 5EB9 _h
This code is for device-internal use only and must not be written to by the user!		

C00327

Parameter Name: C00327 Service code		Data type: BITFIELD_32 Index: 24248 _d = 5EB8 _h
This code is for device-internal use only and must not be written to by the user!		

C00328

Parameter Name: C00328 Service code	Data type: BITFIELD_32 Index: 24247 _d = 5EB7 _h
This code is for device-internal use only and must not be written to by the user!	

C00329

Parameter Name: C00329 Service code	Data type: BITFIELD_32 Index: 24246 _d = 5EB6 _h
This code is for device-internal use only and must not be written to by the user!	

C00330

Parameter Name: C00330 Service code	Data type: BITFIELD_32 Index: 24245 _d = 5EB5 _h
This code is for device-internal use only and must not be written to by the user!	

C00335

Parameter Name: C00335 Service code	Data type: BITFIELD_32 Index: 24240 _d = 5EB0 _h
This code is for device-internal use only and must not be written to by the user!	

C00336

Parameter Name: C00336 Service code	Data type: BITFIELD_32 Index: 24239 _d = 5EAF _h
This code is for device-internal use only and must not be written to by the user!	

C00337

Parameter Name: C00337 Service code	Data type: BITFIELD_32 Index: 24238 _d = 5EAE _h
This code is for device-internal use only and must not be written to by the user!	

C00338

Parameter Name: C00338 Service code	Data type: BITFIELD_32 Index: 24237 _d = 5EAD _h
This code is for device-internal use only and must not be written to by the user!	

C00343

Parameter Name: C00343 CAN TPDO counter	Data type: UNSIGNED_32 Index: 24232 _d = 5EA8 _h
Display range (min. value unit max. value)	
0 4294967295	
Subcodes	Info
C00343/1	From software version V1.5
C00343/...	Counter for TPDO1 ... TPDO4
C00343/4	▶ "CAN on board" system bus
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00344

Parameter Name: C00344 CAN RPDO counter		Data type: UNSIGNED_32 Index: 24231 _d = 5EA7 _h
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C00344/1		From software version V1.5
C00344/...		Counter for RPDO1 ... RPDO4
C00344/4		▶ "CAN on board" system bus
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00345

Parameter Name: C00345 CAN error		Data type: UNSIGNED_8 Index: 24230 _d = 5EA6 _h
▶ "CAN on board" system bus		
Selection list (read only)		
0	No error	
1	Guard Event	
2	Warning	
3	Bus off	
4	Sync telegram error	
6	CAN controller overflow	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00346

Parameter Name: C00346 CAN heartbeat activity		Data type: BITFIELD_32 Index: 24229 _d = 5EA5 _h
▶ "CAN on board" system bus: heartbeat protocol		
Display area		
0x00000000		0xFFFFFFFF
Value is bit-coded:		
Bit 0	Heartbeat node 1	
...	...	
Bit 31	Heartbeat node 32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00347

Parameter Name: C00347 CAN heartbeat status		Data type: UNSIGNED_8 Index: 24228 _d = 5EA4 _h
▶ "CAN on board" system bus: heartbeat protocol		
Selection list (read only)		
0	Unknown	
4	Stopped	
5	Operational	
127	Pre-Operational	
Subcodes		Info
C00347/1		Status node 1 ... 32
C00347/...		
C00347/32		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00348

Parameter Name: C00348 CAN status DIP switch		Data type: UNSIGNED_8 Index: 24227 _d = 5EA3 _h
<ul style="list-style-type: none"> • "1" means that the CAN DIP switch has been identified after mains switching and a valid baud rate and node address have been set. • "0" means that no CAN DIP switch or no valid setting has been identified or the setting has been overwritten by writing to code C00350 or C00351. 		
▶ "CAN on board" system bus		
Selection list (read only)		Info
0	Setting not accepted	
1	Setting accepted	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00349

Parameter Name: C00349 CAN setting - DIP switch		Data type: UNSIGNED_8 Index: 24226 _d = 5EA2 _h
Setting of the CAN DIP switch at the last mains connection		
▶ "CAN on board" system bus		
Display range (min. value unit max. value)		
0		255
Subcodes		Info
C00349/1		Node address
C00349/2		Baud rate: 0: 500 kbps 1: 250 kbps 2: 125 kbps 3: 50 kbps 4: 1 Mbps 5: 20 kbps 6: 10 kbit/s 14: 800 kbps 255: Automatic detection
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00350

Parameter Name: C00350 CAN node address		Data type: UNSIGNED_8 Index: 24225 _d = 5EA1 _h
<ul style="list-style-type: none"> • A change in the node address will not be effective until a CAN Reset Node is performed. • The basic server channel RX/TX is automatically provided by the node address (C00372 and C00373; subcode 1). • Overwriting the value deactivates a possibly existing node address selection entered by means of hardware. ▶ "CAN on board" system bus 		
Setting range (min. value unit max. value)		Lenze setting
1		127 1
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00351

Parameter Name: C00351 CAN baud rate		Data type: UNSIGNED_8 Index: 24224 _d = 5EA0 _h
<ul style="list-style-type: none"> • A change in the baud rate will not be effective until a CAN Reset Node is performed. • Overwriting the value deactivates a possibly existing node address selection entered by means of hardware. ▶ "CAN on board" system bus 		
Selection list (Lenze setting printed in bold)		
0	500 kbps	
1	250 kbps	
2	125 kbps	
3	50 kbps	
4	1 Mbps	
5	20 kbps	
6	10 kbps	
8	Reserved	
9	Reserved	
10	Reserved	
11	Reserved	
12	Reserved	
13	Reserved	
14	800 kbps	
15	Reserved	
255	Automatic recognition	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00352

Parameter Name: C00352 CAN slave/master		Data type: UNSIGNED_8 Index: 24223 _d = 5E9F _h
<p>The drive starts as CAN master after mains switching if a value of "1" has been entered and saved here. ▶ "CAN on board" system bus</p>		
Selection list (Lenze setting printed in bold)		
0	slave	
1	master	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00356

Parameter Name: C00356 CAN TPDOx cycle time		Data type: UNSIGNED_16 Index: 24219 _d = 5E9B _h
TPDO event time according to DS301 V4.02 <ul style="list-style-type: none"> • If a different value than "0" is entered, the TPDO is transmitted without further consideration of the transport type after the time set has elapsed. • Mapping of the CANopen objects I-1800/5 ... I-1803/5 (see DS301 V4.02). 		
▶ "CAN on board" system bus		
Setting range (min. value unit max. value)		
0	ms	65535
Subcodes	Lenze setting	Info
C00356/1	0 ms	Cycle time for TPDO1 ... TPDO4
C00356/...		
C00356/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00357

Parameter Name: C00357 CAN RPDOx monitoring time		Data type: UNSIGNED_16 Index: 24218 _d = 5E9A _h
Mapping of the RPDO event time (see DS301 V4.02) <ul style="list-style-type: none"> • If a value unequal to "0" is entered, the RPDO is not expected before the set time has expired. • If the RPDO is not received within this time, a parameterisable error message can be activated. 		
▶ "CAN on board" system bus		
Setting range (min. value unit max. value)		
0	ms	65535
Subcodes	Lenze setting	Info
C00357/1	3000 ms	Monitoring time for RPDO1 ... RPDO4
C00357/...		
C00357/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00359

Parameter Name: C00359 CAN status		Data type: UNSIGNED_8 Index: 24216 _d = 5E98 _h
▶ "CAN on board" system bus		
Selection list (read only)		
0	Operational	
1	Pre-Operational	
4	Boot-up	
5	Stopped	
7	Reset	
8	Initialisation	
9	Unknown	
10	Baud rate autom. detected	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00360

Parameter Name: C00360 CAN telegram and error counter		Data type: UNSIGNED_16 Index: 24215 _d = 5E97 _h
<ul style="list-style-type: none"> • After mains connection, all counters start with "0". • After the maximum value has been reached, counting restarts with "0". <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Display range (min. value unit max. value)		
0		65535
Subcodes	Info	
C00360/1	Stuffing bit error counter • More than five identical bits have been detected.	
C00360/2	Format error counter • CAN frame has not been observed.	
C00360/3	Acknowledge error counter • No node has confirmed the telegram.	
C00360/4	Bit1 error counter • "1" should be sent after bus arbitration, but "0" was read.	
C00360/5	Bit0 error counter • "0" should be sent after bus arbitration, but "1" was read.	
C00360/6	CRC error counter • Checksum check has indicated an error.	
C00360/7	Tx telegram counter • Telegrams received without errors.	
C00360/8	Rx telegram counter • Telegrams sent without errors.	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00361

Parameter Name: C00361 CAN bus load		Data type: UNSIGNED_32 Index: 24214 _d = 5E96 _h
<p>The display of the node peak load (subcodes 4 ... 6) is reset by repeated mains switching or via the "Reset node" device command (C00002).</p> <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Display range (min. value unit max. value)		
0	%	100
Subcodes	Info	
C00361/1	Current node load in Tx direction	
C00361/2	Current node load in Rx direction	
C00361/3	Current node load by faulty telegrams	
C00361/4	Node peak load in Tx direction	
C00361/5	Node peak load in Rx direction	
C00361/6	Node peak load by faulty telegrams	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00367

Parameter Name: C00367 CAN SYNC Rx identifier		Data type: UNSIGNED_32 Index: 24208 _d = 5E90 _h	
Identifier by means of which the sync slave is to receive sync telegrams. <ul style="list-style-type: none"> • Mapping of the CANopen object I-1005 (see DS301 V4.02). ▶ "CAN on board" system bus: sync telegram 			
Setting range (min. value unit max. value)		Lenze setting	
0		2047	128
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00368

Parameter Name: C00368 CAN SYNC Tx identifier		Data type: UNSIGNED_32 Index: 24207 _d = 5E8F _h	
Identifier by means of which the sync master is to transmit sync telegrams. <ul style="list-style-type: none"> • Mapping of the CANopen object I-1005 (see DS301 V4.02). ▶ "CAN on board" system bus: sync telegram 			
Setting range (min. value unit max. value)		Lenze setting	
0		2047	128
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00369

Parameter Name: C00369 CAN sync transmission cycle time		Data type: UNSIGNED_16 Index: 24206 _d = 5E8E _h	
Cycle during which the sync master is to transmit sync telegrams. <ul style="list-style-type: none"> • If "0 ms" is set (Lenze setting), no sync telegrams are generated. • Mapping of the CANopen object I-1006 (see DS301 V4.02). ▶ "CAN on board" system bus: sync telegram 			
Setting range (min. value unit max. value)			
0	ms	65535	
Subcodes	Lenze setting	Info	
C00369/1	0 ms	Transmission cycle time for CAN on board	
C00369/2	0 ms	Transmission cycle time for CAN module in MXI1/MXI2	
C00369/3	0 ms	- (no meaning)	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00372

Parameter Name: C00372 CAN SDO server Rx identifier		Data type: BITFIELD_32 Index: 24203 _d = 5E8B _h
Identifier with which the corresponding SDO server can be reached. <ul style="list-style-type: none"> • If bit 31 is set (0x8nnnnnnn), the corresponding SDO server is deactivated. • Mapping of the CANopen objects I-1200/1 ... I-1209/1 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Info
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> • Bit 0 ... 10: COB-ID • Bit 11 ... 30: Reserved • Bit 31: SDO invalid
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Info
C00372/1	0x00000601	SDO server channel 1 RX <ul style="list-style-type: none"> • Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301 V4.02. Writing to the subcode has no effect. • The value under subcode 1 results from the node address (C00350) + 0x600.
C00372/2	0x80000000	SDO server channel 2 RX
C00372/3	0x80000000	SDO server channel 3 RX
C00372/4	0x80000000	SDO server channel 4 RX
C00372/5	0x80000000	SDO server channel 5 RX
C00372/6	0x80000000	SDO server channel 6 RX
C00372/7	0x80000000	SDO server channel 7 RX
C00372/8	0x80000000	SDO server channel 8 RX
C00372/9	0x80000000	SDO server channel 9 RX
C00372/10	0x80000000	SDO server channel 10 RX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00373

Parameter Name: C00373 CAN SDO server Tx identifier		Data type: BITFIELD_32 Index: 24202 _d = 5E8A _h
Identifier with which the corresponding SDO server can carry out transmissions. <ul style="list-style-type: none"> • If bit 31 is set (0x8nnnnnnn), the corresponding SDO server is deactivated. • Mapping of the CANopen objects I-1200/2 ... I-1209/2 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Info
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> • Bit 0 ... 10: COB-ID • Bit 11 ... 30: Reserved • Bit 31: SDO invalid
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Info
C00373/1	0x00000581	SDO server channel 1 TX <ul style="list-style-type: none"> • Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301 V4.02. Writing to the subcode has no effect. • The value under subcode 1 results from the node address (C00350) + 0x580.
C00373/2	0x80000000	SDO server channel 2 TX
C00373/3	0x80000000	SDO server channel 3 TX
C00373/4	0x80000000	SDO server channel 4 TX
C00373/5	0x80000000	SDO server channel 5 TX
C00373/6	0x80000000	SDO server channel 6 TX
C00373/7	0x80000000	SDO server channel 7 TX
C00373/8	0x80000000	SDO server channel 8 TX
C00373/9	0x80000000	SDO server channel 9 TX
C00373/10	0x80000000	SDO server channel 10 TX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00374

Parameter Name:		Data type: UNSIGNED_8 Index: 24201 _d = 5E89 _h	
C00374 CAN SDO client node address			
Node address of the client assigned to this server (see DS301 V4.02). ▶ "CAN on board" system bus			
Setting range (min. value unit max. value)			
1		127	
Subcodes	Lenze setting	Info	
C00374/1	1	SDO server channel 1 remote client node address • Subcode 1 contains the basic SDO channel which, according to DS301 V4.02, does not feature this entry. Writing to the subcode has no effect. • The value of subindex 1 is 0.	
C00374/2	1	SDO server channel 2 remote client node address	
C00374/3	1	SDO server channel 3 remote client node address	
C00374/4	1	SDO server channel 4 remote client node address	
C00374/5	1	SDO server channel 5 remote client node address	
C00374/6	1	SDO server channel 6 remote client node address	
C00374/7	1	SDO server channel 7 remote client node address	
C00374/8	1	SDO server channel 8 remote client node address	
C00374/9	1	SDO server channel 9 remote client node address	
C00374/10	1	SDO server channel 10 remote client node address	
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00375

Parameter Name:		Data type: BITFIELD_32 Index: 24200 _d = 5E88 _h	
C00375 CAN SDO client Rx identifier			
Identifier with which the corresponding SDO client can be reached. • If bit 31 is set (0x8nnnnnnn), the corresponding SDO client channel is deactivated (see DS301 V4.02). • The client channels need not be parameterised right now. Their functionality will only be required when using the gateway services. ▶ "CAN on board" system bus			
Setting range			
0x00000000		0xFFFFFFFF	
Value is bit-coded:		Info	
Bit 0	COB-ID bit 0	• Bit 0 ... 10: COB-ID • Bit 11 ... 30: Reserved • Bit 31: SDO invalid	
...	...		
Bit 31	SDO invalid		
Subcodes	Lenze setting	Info	
C00375/1	0x80000000	SDO client channel 1 RX ... 10 RX	
C00375/...			
C00375/10			
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00376

Parameter Name:		Data type: BITFIELD_32 Index: 24199 _d = 5E87 _h	
C00376 CAN SDO client Tx identifier			
Identifier with which the corresponding SDO client can carry out transmissions. <ul style="list-style-type: none"> • If bit 31 is set (0x8nnnnnnn), the corresponding SDO client channel is deactivated (see DS301 V4.02). • The client channels need not be parameterised right now. Their functionality will only be required when using the gateway services. <p style="text-align: right;">▶ "CAN on board" system bus</p>			
Setting range			
0x00000000		0xFFFFFFFF	
Value is bit-coded:		Info	
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> • Bit 0 ... 10: COB-ID • Bit 11 ... 30: Reserved • Bit 31: SDO invalid 	
...	...		
Bit 31	SDO invalid		
Subcodes		Lenze setting	
C00376/1	0x80000000	SDO client channel 1 TX ... 10 TX	
C00376/...			
C00376/10			
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00377

Parameter Name:		Data type: UNSIGNED_8 Index: 24198 _d = 5E86 _h	
C00377 CAN SDO server node address			
Node address of the server with which this client communicates via the client channel selected. <ul style="list-style-type: none"> • An activation of the client functionality is not required. • The entry is required so that the CAN-SDO client channel can be activated (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>			
Setting range (min. value unit max. value)			
1		127	
Subcodes		Lenze setting	
C00377/1	1	Remote server node address for SDO client channel 1 ... 10	
C00377/...			
C00377/10			
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00378

Parameter Name:		Data type: UNSIGNED_16 Index: 24197 _d = 5E85 _h	
C00378 CAN delay boot-up - Operational			
Time that has to elapse after mains switching before the CAN NMT master places the "Start Remote Node" telegram to the bus. <ul style="list-style-type: none"> • This time is only used if the master bit is activated (C00352) and after mains switching. <p style="text-align: right;">▶ "CAN on board" system bus</p>			
Setting range (min. value unit max. value)			Lenze setting
0	ms	65535	3000 ms
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00379

Parameter Name: C00379 Service code	Data type: UNSIGNED_8 Index: 24196 _d = 5E84 _h
This code is for device-internal use only and must not be written to by the user!	

C00381

Parameter Name: C00381 CAN Heartbeat producer time	Data type: UNSIGNED_16 Index: 24194 _d = 5E82 _h
<p>Time interval for the transmission of the heartbeat telegram to the consumer(s).</p> <ul style="list-style-type: none"> • The parameterised time is rounded down to an integer multiple of 5 ms. • The heartbeat telegram is transmitted automatically as soon as a time > 0 ms is set. The monitoring function "Node Guarding" is deactivated in this case. • Mapping of the CANopen object I-1017 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus: heartbeat protocol</p>	
Setting range (min. value unit max. value)	Lenze setting
0 ms 65535	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00382

Parameter Name: C00382 CAN Guard Time	Data type: UNSIGNED_16 Index: 24193 _d = 5E81 _h
<p>After the set guard time multiplied by the life time factor (C00383), a node guarding telegram must have been received.</p> <ul style="list-style-type: none"> • Mapping of the CANopen object I-100C (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus: node guarding protocol</p>	
Setting range (min. value unit max. value)	Lenze setting
0 ms 65535	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00383

Parameter Name: C00383 CAN Life Time Factor	Data type: UNSIGNED_8 Index: 24192 _d = 5E80 _h
<p>The life time factor multiplied by the guard time (C00382) results in the time in which a node guarding telegram must have been received.</p> <ul style="list-style-type: none"> • Mapping of the CANopen object I-100D (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus: node guarding protocol</p>	
Setting range (min. value unit max. value)	Lenze setting
0 255	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00385

Parameter Name:		Data type: BITFIELD_32 Index: 24190 _d = 5E7E _h
C00385 CAN Heartbeat Consumer Time		
<p>The 32 subcodes represent the nodes which are to be monitored via heartbeat.</p> <ul style="list-style-type: none"> • Each subcode entry contains the expected "heartbeat" time and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code. • The parameterised time is rounded down to an integer multiple of 5 ms and must have a greater value than the heartbeat producer time of the node to be monitored. • The response to a missing heartbeat telegram can be parameterised in C00613. • Mapping of the CANopen object I-1016 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus: heartbeat protocol</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Info
Bit 0	Heartbeat time bit 0	<ul style="list-style-type: none"> • Bit 0 ... 15: Heartbeat time • Bit 16 ... 23: Node address • Bit 24 ... 31: Reserved
...	...	
Bit 31	Reserved	
Subcodes	Lenze setting	Info
C00385/1	0x00000000	Monitoring entry 1 ... 32
C00385/...		
C00385/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00386

Parameter Name:		Data type: BITFIELD_32 Index: 24189 _d = 5E7D _h
C00386 CAN Node Guarding		
<p>The 32 subcodes represent the nodes to be monitored by the master by means of node guarding.</p> <ul style="list-style-type: none"> • Each subcode entry contains the guard time, the lifetime factor and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code. • The response to a missing node guarding response can be parameterised in C00612. <p style="text-align: right;">▶ "CAN on board" system bus: node guarding protocol</p>		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded:		Info
Bit 0	Guard time bit 0	<ul style="list-style-type: none"> • Bit 0 ... 15: Guard time • Bit 16 ... 23: Node address • Bit 24 ... 31: Lifetime factor
...	...	
Bit 31	Lifetime factor bit 7	
Subcodes	Lenze setting	Info
C00386/1	0x00000000	Monitoring entry 1 ... 32
C00386/...		
C00386/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C00387

Parameter Name: C00387 CAN Node Guarding Activity		Data type: BITFIELD_32 Index: 24188 _d = 5E7C _h
▶ "CAN on board" system bus: node guarding protocol		
Display area		
0x00000000		0xFFFFFFFF
Value is bit-coded:		
Bit 0	Node guarding of node 1	
...	...	
Bit 31	Node guarding of node 32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00388

Parameter Name: C00388 CAN node guarding status		Data type: UNSIGNED_8 Index: 24187 _d = 5E7B _h
▶ "CAN on board" system bus: node guarding protocol		
Selection list (read only)		
0	Unknown	
4	Stopped	
5	Operational	
127	Pre-Operational	
Subcodes		Info
C00388/1		Status node 1 ... 32
C00388/...		
C00388/32		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00390

Parameter Name: C00390 CAN Error Register (DS301V402)		Data type: BITFIELD_8 Index: 24185 _d = 5E79 _h
Mapping of the CANopen object I-1001 (see DS301 V4.02).		
▶ "CAN on board" system bus		
Display area		
0x00		0xFF
Value is bit-coded:		Info
Bit 0	Generic error	Currently only bits 0 and 4 contain the corresponding information.
Bit 1	Current error (not used)	
Bit 2	Voltage error (not used)	
Bit 3	Temperature error (not used)	
Bit 4	Communication error	
Bit 5	Dev. prof. spec. err (not used)	
Bit 6	Reserved	
Bit 7	Manuf. spec. error (not used)	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00391

Parameter Name: C00391 CAN Emergency Object		Data type: BITFIELD_32 Index: 24184 _d = 5E78 _h
Identifier of the emergency telegram <ul style="list-style-type: none"> If bit 31 of this code is set (0x8nnnnnnn), the generation of emergency telegrams is deactivated. Mapping of the CANopen object I-1014 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range		Lenze setting
0x00000000	0xFFFFFFFF	0x00000081 (decimal: 129)
Value is bit-coded: (<input checked="" type="checkbox"/> = bit set)		Info
Bit 0 <input checked="" type="checkbox"/> COB-ID bit 0		
Bit 1 <input type="checkbox"/> COB-ID bit 1		
Bit 2 <input type="checkbox"/> COB-ID bit 2		
Bit 3 <input type="checkbox"/> COB-ID bit 3		
Bit 4 <input type="checkbox"/> COB-ID bit 4		
Bit 5 <input type="checkbox"/> COB-ID bit 5		
Bit 6 <input type="checkbox"/> COB-ID bit 6		
Bit 7 <input checked="" type="checkbox"/> COB-ID bit 7		
Bit 8 <input type="checkbox"/> COB-ID bit 8		
Bit 9 <input type="checkbox"/> COB-ID bit 9		
Bit 10 <input type="checkbox"/> COB-ID bit 10		
Bit 11 <input type="checkbox"/> Reserved		
Bit 12 <input type="checkbox"/> Reserved		
Bit 13 <input type="checkbox"/> Reserved		
Bit 14 <input type="checkbox"/> Reserved		
Bit 15 <input type="checkbox"/> Reserved		
Bit 16 <input type="checkbox"/> Reserved		
Bit 17 <input type="checkbox"/> Reserved		
Bit 18 <input type="checkbox"/> Reserved		
Bit 19 <input type="checkbox"/> Reserved		
Bit 20 <input type="checkbox"/> Reserved		
Bit 21 <input type="checkbox"/> Reserved		
Bit 22 <input type="checkbox"/> Reserved		
Bit 23 <input type="checkbox"/> Reserved		
Bit 24 <input type="checkbox"/> Reserved		
Bit 25 <input type="checkbox"/> Reserved		
Bit 26 <input type="checkbox"/> Reserved		
Bit 27 <input type="checkbox"/> Reserved		
Bit 28 <input type="checkbox"/> Reserved		
Bit 29 <input type="checkbox"/> Reserved		
Bit 30 <input type="checkbox"/> Reserved		
Bit 31 <input type="checkbox"/> Emergency inactive/active		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00392

Parameter Name: C00392 CAN emergency delay time		Data type: UNSIGNED_16 Index: 24183 _d = 5E77 _h
Minimum time that has to elapse between two successive emergency telegrams. <ul style="list-style-type: none"> • If "0" is set, checking of the inhibit time is deactivated. • The time is entered in 1/10 ms. The code automatically rounds the entries down to the preceding full millisecond. • Mapping of the CANopen object I-1015 (see DS301 V4.02). <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Setting range (min. value unit max. value)		Lenze setting
0		65535 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00393

Parameter Name: C00393 CAN result - bus scan		Data type: UNSIGNED_8 Index: 24182 _d = 5E76 _h
Result of CAN bus scanning (see controller commands under C00002). <ul style="list-style-type: none"> • Subcode number 1 ... 128 corresponds to CAN node address 1 ... 128. <p style="text-align: right;">▶ "CAN on board" system bus</p>		
Display range (min. value unit max. value)		
0		1
Subcodes		Info
C00393/1		Result of CAN bus scanning for CAN node address 1 ... 128 <ul style="list-style-type: none"> • The value "1" means that a device with the corresponding node address has been found.
C00393/...		
C00393/128		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00394

Parameter Name: C00394 CAN predefined error field (DS301V402)		Data type: UNSIGNED_32 Index: 24181 _d = 5E75 _h
<p style="text-align: right;">▶ "CAN on board" system bus</p>		
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C00394/1		
C00394/...		
C00394/10		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00395

Parameter Name: C00395 Service code		Data type: UNSIGNED_32 Index: 24180 _d = 5E74 _h
This code is for device-internal use only and must not be written to by the user!		

C00396

Parameter Name: C00396 Service code		Data type: UNSIGNED_32 Index: 24179 _d = 5E73 _h
This code is for device-internal use only and must not be written to by the user!		

C00397

Parameter Name: C00397 Service code	Data type: UNSIGNED_32 Index: 24177 _d = 5E72 _h
This code is for device-internal use only and must not be written to by the user!	

C00398

Parameter Name: C00398 Test mode motor control	Data type: UNSIGNED_32 Index: 24177 _d = 5E71 _h
<p>⚠ Danger! When the test mode is activated, the parameterisable error response "Quick stop by trouble" has no effect! If the test mode is active and a monitoring function responds with this error response, no quick stop is executed but the motor continues to rotate with the frequency set for the test mode!</p>	
Selection list (Lenze setting printed in bold)	Info
0 Test mode deactivated	
1 U rotation test mode	
2 I rotation test mode	
3 Current controller optimisation mode	After controller enable, the motor is supplied with current as long as the controller is enabled.
4 Current controller optimisation mode impulse	From software version V7.0 The motor is supplied with voltage for 50 ms after controller enable. Due to this time limit, the load of the machine is reduced. Afterwards, the controller is inhibited automatically.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Scaling factor: 1	

C00399

Parameter Name: C00399 Settings for test mode	Data type: INTEGER_32 Index: 24176 _d = 5E70 _h	
Setting range (min. value unit max. value)		
-1000.0 Hz/1° 1000.0		
Subcodes	Lenze setting	Info
C00399/1	0.0 Hz/1°	Frequency [Hz] for test mode
C00399/2	0.0 Hz/1°	Start angle [°] for test mode
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Scaling factor: 10		

C00412

Parameter Name: C00412 Hiperface: Initialisation time	Data type: UNSIGNED_32 Index: 24163 _d = 5E63 _h
<p>From software version V11.0 ▶ Parameterisation of a Hiperface encoder with increased initialisation time</p>	
Setting range (min. value unit max. value)	Lenze setting
150 ms 2000	650 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00413

Parameter Name: C00413 Hiperface: detected TypeCode		Data type: UNSIGNED_32 Index: 24162 _d = 5E62 _h
From software version V4.0 Type code read out of the connected Hiperface encoder ▶ Parameterisation of an unknown Hiperface encoder		
Display range (min. value unit max. value)		
0		255
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00414

Parameter Name: C00414 Hiperface: TypeCode		Data type: UNSIGNED_32 Index: 24161 _d = 5E61 _h
From software version V4.0 Setting the type code for a Hiperface encoder unknown to the controller ▶ Parameterisation of an unknown Hiperface encoder		
Setting range (min. value unit max. value)		Lenze setting
0		255 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00415

Parameter Name: C00415 Hiperface: number of rev.		Data type: UNSIGNED_32 Index: 24160 _d = 5E60 _h
From software version V4.0 Number of displayable revolutions for a multi-turn encoder ▶ Parameterisation of an unknown Hiperface encoder		
Setting range (min. value unit max. value)		Lenze setting
0		16384 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00416

Parameter Name: C00416 Service code		Data type: UNSIGNED_32 Index: 24159 _d = 5E5F _h
This code is for device-internal use only and must not be written to by the user!		

C00417

Parameter Name: C00417 Dynamic of resolver evaluation		Data type: UNSIGNED_32 Index: 24158 _d = 5E5E _h
From software version V5.0 ▶ Adaptation of the resolver evaluation dynamics		
Setting range (min. value unit max. value)		Lenze setting
100	%	1000 100 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00418

Parameter Name: C00418 Activate resolver error compensation		Data type: UNSIGNED_8 Index: 24157 _d = 5E5D _h
From software version V7.0		► Resolver error compensation
Selection list (Lenze setting printed in bold)		
0	Deactivated	
1	enabled	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00420

Parameter Name: C00420 Number of encoder increments		Data type: UNSIGNED_16 Index: 24155 _d = 5E5B _h
Setting range (min. value unit max. value)		Lenze setting
1		16384 512
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00421

Parameter Name: C00421 Encoder voltage		Data type: UNSIGNED_16 Index: 24154 _d = 5E5A _h
Setting range (min. value unit max. value)		Lenze setting
5.0	V	12.0 5.0 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00422

Parameter Name: C00422 Encoder type		Data type: UNSIGNED_16 Index: 24153 _d = 5E59 _h
Selection list (Lenze setting printed in bold)		Info
0	Incremental encoder (TTL signal)	
1	Sin/cos encoder	
2	Absolute value encoder (Hiperface)	
3	Absolute value encoder (EnDat)	
4	SSI encoder	From software version V5.0 ► Use of an SSI encoder at X8
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00423

Parameter Name: C00423 SSI encoder: Bit rate		Data type: UNSIGNED_32 Index: 24152 _d = 5E58 _h
From software version V5.0		► Use of an SSI encoder at X8
Setting range (min. value unit max. value)		Lenze setting
150	kbps	1000 400 kbps
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00424

Parameter Name: C00424 SSI encoder: Data word length		Data type: UNSIGNED_32 Index: 24151 _d = 5E57 _h	
From software version V5.0			
▶ Use of an SSI encoder at X8			
Setting range (min. value unit max. value)		Lenze setting	
1	Bit	31	25 bits
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00427

Parameter Name: C00427 TTL encoder signal evaluation		Data type: UNSIGNED_16 Index: 24148 _d = 5E54 _h	
Selection list (Lenze setting printed in bold)			
	0	4x evaluation (A, B)	
	1	A:Increments B:Sign	
	2	Increments A:pos. B:neg.	
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00435

Parameter Name: C00435 SSI encoder: partword start position		Data type: UNSIGNED_8 Index: 24140 _d = 5E4C _h	
From software version V5.0			
▶ Use of an SSI encoder at X8			
Setting range (min. value unit max. value)			
0		30	
Subcodes	Lenze setting	Info	
C00435/1	0	SSI enc.: Partword 1 start	
C00435/2	0	SSI enc.: Partword 2 start	
C00435/3	0	SSI enc.: Partword 3 start	
C00435/4	0	SSI enc.: Partword 4 start	
C00435/5	0	Ssi-enc.: Partword 5 start	
C00435/6	0	SSI enc.: Partword 6 start	
C00435/7	0	SSI enc.: Partword 7 start	
C00435/8	0	Ssi-enc.: Partword 8 start	
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00436

Parameter Name: C00436 SSI encoder: partword length		Data type: UNSIGNED_8 Index: 24139 _d = 5E4B _h
From software version V5.0		
▶ Use of an SSI encoder at X8		
Setting range (min. value unit max. value)		
0		31
Subcodes	Lenze setting	Info
C00436/1	31	SSI enc.: Partword 1 length
C00436/2	0	SSI enc.: Partword 2 length
C00436/3	0	SSI enc.: Partword 3 length
C00436/4	0	SSI enc.: Partword 4 length
C00436/5	0	SSI enc.: Partword 5 length
C00436/6	0	SSI enc.: Partword 6 length
C00436/7	0	SSI enc.: Partword 7 length
C00436/8	0	SSI enc.: Partword 8 length
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00437

Parameter Name: C00437 SSI encoder: partword data coding		Data type: UNSIGNED_8 Index: 24138 _d = 5E4A _h
From software version V5.0		
▶ Use of an SSI encoder at X8		
Selection list (Lenze setting printed in bold)		
0	binary coded	
1	gray coded	
Subcodes	Lenze setting	Info
C00437/1	0: binary coded	SSI enc.: Partword 1 coding
C00437/2	0: binary coded	SSI enc.: Partword 2 coding
C00437/3	0: binary coded	SSI enc.: Partword 3 coding
C00437/4	0: binary coded	SSI enc.: Partword 4 coding
C00437/5	0: binary coded	SSI enc.: Partword 5 coding
C00437/6	0: binary coded	SSI enc.: Partword 6 coding
C00437/7	0: binary coded	SSI enc.: Partword 7 coding
C00437/8	0: binary coded	SSI enc.: Partword 8 coding
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00443

Parameter Name: C00443 Status: Digital inputs		Data type: UNSIGNED_8 Index: 24132 _d = 5E44 _h
Display range (min. value unit max. value)		
0		1
Subcodes	Info	
C00443/1	Digital input 1	
C00443/2	Digital input 2	
C00443/3	Digital input 3	
C00443/4	Digital input 4	
C00443/5	Digital input 5	
C00443/6	Digital input 6	
C00443/7	Digital input 7	
C00443/8	Digital input 8	
C00443/9	Controller inhibit (inversion of input X5/RFR)	
C00443/10	Internal signal	
C00443/11	Feedback input of holding brake	
C00443/12	State bus input	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00444

Parameter Name: C00444 Status: Digital outputs		Data type: UNSIGNED_8 Index: 24131 _d = 5E43 _h
Display range (min. value unit max. value)		
0		1
Subcodes	Info	
C00444/1	Digital output 1	
C00444/2	Digital output 2	
C00444/3	Digital output 3	
C00444/4	Digital output 4	
C00444/5	Internal signal	
C00444/6	Internal signal	
C00444/7	Internal signal	
C00444/8	Internal signal	
C00444/9	User LED	
C00444/10	Internal signal	
C00444/11	Internal signal	
C00444/12	Internal signal	
C00444/13	Control output of holding brake	
C00444/14	Internal signal	
C00444/15	Internal signal	
C00444/16	Internal signal	
C00444/17	Internal signal	
C00444/18	State bus output	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00462

Parameter Name: C00462 Noise signal activation	Data type: UNSIGNED_8 Index: 24113 _d = 5E31 _h
This code is for device-internal use only and must not be written to by the user!	

C00464

Parameter Name: C00464 Keypad: Mode	Data type: UNSIGNED_16 Index: 24111 _d = 5E2F _h
<p>From software version V5.0</p> <p>Definition of the mode in which the keypad attached is to be activated.</p> <ul style="list-style-type: none"> • If both keypad versions (V1.0 and V2.0) are used, the Lenze setting is to be maintained. • If only the new keypad V2.0 is used, the initialisation time of the keypad can be reduced by changing over to mode 2. Furthermore mode 2 supports greater future keypad files. <p>Note: If mode 2 is selected, the keypad V1.0 can no longer be operated on the controller!</p>	
Selection list (Lenze setting printed in bold)	Info
0 Mode 1	For keypad V1.0 and V2.0
1 Mode 2	Only for keypad V2.0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00465

Parameter Name: C00465 Keypad: Timeout welcome screen	Data type: UNSIGNED_8 Index: 24110 _d = 5E2E _h
Selection list (Lenze setting printed in bold)	
0 Never show welcome screen	
5 5 min	
15 15 min	
30 30 min	
60 60 min	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00466

Parameter Name: C00466 Keypad: Default parameter	Data type: UNSIGNED_16 Index: 24109 _d = 5E2D _h
Setting range (min. value unit max. value)	Lenze setting
0 65535	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00467

Parameter Name: C00467 Keypad: Default welcome screen	Data type: UNSIGNED_8 Index: 24108 _d = 5E2C _h
Selection list (Lenze setting printed in bold)	
0 Main menu	
1 Parameter list	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00468

Parameter Name: C00468 Service code	Data type: UNSIGNED_8 Index: 24107 _d = 5E2B _h
This code is for device-internal use only and must not be written to by the user!	

C00469

Parameter Name: C00469 Keypad: Fct. STOP key	Data type: UNSIGNED_8 Index: 24106 _d = 5E2A _h
Selection list (Lenze setting printed in bold)	
0 No function	
1 Inhibit inverter	
2 Activate quick stop	
3 Stop application	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00490

Parameter Name: C00490 Position encoder selection	Data type: UNSIGNED_16 Index: 24085 _d = 5E15 _h
Chapter " Controller configuration " provides you with more information on parameter setting.	
Selection list (Lenze setting printed in bold)	
0 Resolver on X7	
1 Encoder on X8	
4 Encoder signal on LS_Feedback	
10 Motor encoder (C00495)	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00494

Parameter Name: C00494 Motor standstill time constant	Data type: UNSIGNED_32 Index: 24081 _d = 5E11 _h
Setting range (min. value unit max. value)	Lenze setting
0 ms 100000	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00495

Parameter Name: C00495 Motor encoder selection	Data type: UNSIGNED_16 Index: 24080 _d = 5E10 _h
Selection list (Lenze setting printed in bold)	
0 Resolver on X7	
1 Encoder on X8	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	Scaling factor: 1

C00497

Parameter Name: C00497 Speed act. val. time const.		Data type: UNSIGNED_32 Index: 24078 _d = 5E0E _h	
Time constant for actual speed filter			
<ul style="list-style-type: none"> In order to maximise the dynamics of the speed control loop, the actual speed filter should be operated with a time constant as low as possible. The lower the time constant the higher the gain of the speed controller. Since actual value filters have the task to dampen measuring errors or interference components, it must be found a compromise between filter task and the resulting delay. If a Lenze motor is selected from the motor catalogue, a time constant is automatically preset here which serves to operate the motor even with a faulty detection (e.g. in case of a bad shield connection). <ul style="list-style-type: none"> Servo control (SC): Optimise speed controller Sensorless vector control (SLVC): Optimise speed controller 			
Setting range (min. value unit max. value)		Lenze setting	
0.0	ms	50.0	2.0 ms
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10	

C00512

Parameter Name: C00512 Service code		Data type: UNSIGNED_32 Index: 24063 _d = 5DFF _h	
This code is for device-internal use only and must not be written to by the user!			

C00513

Parameter Name: C00513 Service code		Data type: VISIBLE_STRING Index: 24062 _d = 5DFE _h	
This code is for device-internal use only and must not be written to by the user!			

C00514

Parameter Name: C00514 Service code		Data type: UNSIGNED_32 Index: 24061 _d = 5DFD _h	
This code is for device-internal use only and must not be written to by the user!			

C00515

Parameter Name: C00515 Service code		Data type: UNSIGNED_32 Index: 24060 _d = 5DFC _h	
This code is for device-internal use only and must not be written to by the user!			

C00516

Parameter Name: C00516 Service code		Data type: UNSIGNED_32 Index: 24059 _d = 5DFB _h	
This code is for device-internal use only and must not be written to by the user!			

C00569

Parameter Name: C00569 Resp. brake trans. ixt > C00570		Data type: UNSIGNED_32 Index: 24006 _d = 5DC6 _h
From software version V1.5 Response if adjustable warning threshold (C00570) of brake chopper monitoring is reached. ▶ Braking operation		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00570

Parameter Name: C00570 Warning thres. brake transistor		Data type: UNSIGNED_32 Index: 24005 _d = 5DC5 _h
From software version V1.5 Warning threshold for brake chopper monitoring • The response to reaching the threshold can be selected in C00569 . ▶ Braking operation		
Setting range (min. value unit max. value)		Lenze setting
0	%	100
		90 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00571

Parameter Name: C00571 Resp. to brake res. i²xt > C00572		Data type: UNSIGNED_32 Index: 24004 _d = 5DC4 _h
From software version V1.5 Response if adjustable warning threshold (C00572) of brake resistor monitoring is reached. ▶ Braking operation		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00572

Parameter Name: C00572 Warning thres. brake resistor		Data type: UNSIGNED_32 Index: 24003 _d = 5DC3 _h
From software version V1.5 Warning threshold for brake resistor monitoring <ul style="list-style-type: none"> The response to reaching the threshold can be selected in C00571. <p style="text-align: right;">▶ Braking operation</p>		
Setting range (min. value unit max. value)		Lenze setting
0	%	100
		90 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00573

Parameter Name: C00573 Resp. to overload brake trans.		Data type: UNSIGNED_32 Index: 24002 _d = 5DC2 _h
Response to activation of brake chopper monitoring <p style="text-align: right;">▶ Braking operation</p>		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00574

Parameter Name: C00574 Resp. to brake resist. overtemp.		Data type: UNSIGNED_32 Index: 24001 _d = 5DC1 _h
Response to activation of brake resistor monitoring <p style="text-align: right;">▶ Braking operation</p>		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00576

Parameter Name: C00576 Speed monitoring tolerance		Data type: UNSIGNED_32 Index: 23999 _d = 5DBF _h
Monitoring window for speed control error in [%] of nmax		
Setting range (min. value unit max. value)		Lenze setting
0	%	100
		100 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00577

Parameter Name: C00577 Field weakening controller gain			Data type: UNSIGNED_32 Index: 23998 _d = 5DBE _h
At "0" the P component is deactivated, a pure I-controller is used.			
Setting range (min. value unit max. value)			Lenze setting
0.000	Vs/V	2147483.647	0.000 Vs/V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00578

Parameter Name: C00578 Field weak. contr. reset time			Data type: UNSIGNED_32 Index: 23997 _d = 5DBD _h
At "240000.0 ms" the I component of the field weakening controller is deactivated.			
Setting range (min. value unit max. value)			Lenze setting
1.0	ms	240000.0	2000.0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00579

Parameter Name: C00579 Resp. to speed monitoring			Data type: UNSIGNED_32 Index: 23996 _d = 5DBC _h
Response to activation of speed monitoring			
Selection list (Lenze setting printed in bold)			
1	Error		
2	Fault		
5	Warning		
4	Warning locked		
3	Quick stop by trouble		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00580

Parameter Name: C00580 Resp. to encoder open circuit			Data type: UNSIGNED_32 Index: 23995 _d = 5DBB _h
Response to open circuit in encoder			
⚠ Danger!			
If the encoder is used as motor encoder:			
In the event of a fault, safe operation of the motor is no longer guaranteed!			
For safety reasons, the "Fault" response should always be set for this case!			
Selection list (Lenze setting printed in bold)			
1	Error		
2	Fault		
5	Warning		
4	Warning locked		
3	Quick stop by trouble		
13	Quick Stop open loop by trouble		
0	No response		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00581

Parameter Name: C00581 Resp. to external fault		Data type: UNSIGNED_32 Index: 23994 _d = 5DBA _h
Response to an external error		▶ Drive interface
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00582

Parameter Name: C00582 Resp. to heatsink temp. > C00122		Data type: UNSIGNED_32 Index: 23993 _d = 5DB9 _h
Response if heatsink temperature > variable limit temperature (C00122).		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00583

Parameter Name: C00583 Resp. to motor KTY overtemp.		Data type: UNSIGNED_32 Index: 23992 _d = 5DB8 _h
Response if motor temperature > fixed limit temperature.		▶ Motor temperature monitoring
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00584

Parameter Name: C00584 Resp. to motor temp. > C00121		Data type: UNSIGNED_32 Index: 23991 _d = 5DB7 _h
Response if motor temperature > variable limit temperature (C00121).		▶ Motor temperature monitoring
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00585

Parameter Name: C00585 Resp. to motor overtemp. PTC		Data type: UNSIGNED_32 Index: 23990 _d = 5DB6 _h
Response if motor temperature across PTC input T1/T2 too high.		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00586

Parameter Name: C00586 Resp. to resolver open circuit		Data type: UNSIGNED_32 Index: 23989 _d = 5DB5 _h
Response to open circuit in resolver ⚠ Danger! If the resolver is used as motor encoder: In the event of a fault, safe operation of the motor is no longer guaranteed! For safety reasons, the "Fault" response should always be set for this case!		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
13	Quick Stop open loop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00587

Parameter Name: C00587 Fan control status		Data type: BITFIELD_8 Index: 23988 _d = 5DB4 _h
Display area		
0x00		0xFF
Value is bit-coded:		
Bit 0	Heatsink fan ON	
Bit 1	Integral fan ON	
Bit 2	Heatsink fan status 1	
Bit 3	Heatsink fan status 2	
Bit 4	Integral fan status	
Bit 5	Reserved	
Bit 6	Reserved	
Bit 7	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00588

Parameter Name: C00588 Resp. to failure t. sensor drive		Data type: UNSIGNED_32 Index: 23987 _d = 5DB3 _h
Response to error/failure of temperature sensor for heatsink temperature/temperature inside the controller		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00589

Parameter Name: C00589 Resp. to CPU temp. > C00126		Data type: UNSIGNED_32 Index: 23986 _d = 5DB2 _h
Response if CPU temperature on the control card > variable limit temperature (C00126).		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00591

Parameter Name: C00591 Resp. to CAN-RPDOx error		Data type: UNSIGNED_8 Index: 23984 _d = 5DB0 _h
Response if the corresponding CAN RPDO has not been received in the configured time or with the configured sync. ▶ "CAN on board" system bus		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Info
C00591/1	0: No Response	Response to non-received RPDO1 ... RPDO4
C00591/...		
C00591/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00594

Parameter Name: C00594 Resp. temp. sensor motor X7/X8		Data type: UNSIGNED_32 Index: 23981 _d = 5DAD _h
Response to motor temperature sensor error. <ul style="list-style-type: none"> The response to a too high motor temperature via PTC input T1/T2 can be selected in C00585. ▶ Motor temperature monitoring 		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00595

Parameter Name: C00595 Resp. to CAN bus OFF		Data type: UNSIGNED_8 Index: 23980 _d = 5DAC _h
Response if CAN node switches to the bus-off state. ▶ "CAN on board" system bus		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00596

Parameter Name: C00596 Threshold max. speed reached		Data type: UNSIGNED_32 Index: 23979 _d = 5DAB _h
Threshold for speed monitoring <ul style="list-style-type: none"> The response to reaching the threshold can be selected in C00607. 		
Setting range (min. value unit max. value)		Lenze setting
50	rpm	50000
		6500 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00597

Parameter Name: C00597 Resp. to motor phase failure		Data type: UNSIGNED_32 Index: 23978 _d = 5DAA _h
Response to activation of motor phase failure monitoring		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00598

Parameter Name: C00598 Resp. to open circuit AIN1		Data type: UNSIGNED_32 Index: 23978 _d = 5DA9 _h
Please observe the following: A response is only triggered when the current is in the range of -2 mA ... +2 mA with a parameterized master current at AIN1 and selection of the "LifeZero" mode ($\pm 4 \dots \pm 20$ mA).		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00599

Parameter Name: C00599 Motor phase failure threshold		Data type: INTEGER_32 Index: 23976 _d = 5DA8 _h
Current value for activating the Motor phase failure monitoring <ul style="list-style-type: none"> In [%] relating to the maximum device current (display in C00789). The response to be triggered by the monitoring can be selected in C00597. 		
Setting range (min. value unit max. value)		Lenze setting
1.0	%	100.0
		5.0 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00600

Parameter Name: C00600 Resp. to DC bus overvoltage		Data type: UNSIGNED_32 Index: 23975 _d = 5DA7 _h
Response to DC bus overvoltage		
▶ Braking operation		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00601

Parameter Name: C00601 Resp. to encoder comm. error		Data type: UNSIGNED_32 Index: 23974 _d = 5DA6 _h
Response to activation of encoder monitoring		
<ul style="list-style-type: none"> • For the use of the encoder as motor encoder: If an error occurs, the safe operation of the motor is no longer ensured, therefore for safety reasons the "Fault" response should always be set! 		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
13	Quick Stop open loop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00604

Parameter Name: C00604 Resp. to device overload > C00123		Data type: UNSIGNED_32 Index: 23971 _d = 5DA3 _h
Response if adjustable "I x t" warning threshold (C00123) is reached.		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00606

Parameter Name: C00606 Resp. to motor overload > C00127		Data type: UNSIGNED_32 Index: 23969 _d = 5DA1 _h
Response if adjustable "I ² x t" warning threshold (C00127) is reached.		
▶ I²x t motor monitoring		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00607

Parameter Name: C00607 Resp. to max. speed reached		Data type: UNSIGNED_32 Index: 23968 _d = 5DA0 _h
Response if adjustable speed threshold (C00596) is reached.		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00610

Parameter Name: C00610 Resp. to failure heatsink fan		Data type: UNSIGNED_32 Index: 23965 _d = 5D9D _h
Response if fan speed of heatsink fan is too low.		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00611

Parameter Name: C00611 Resp. to failure integral fan		Data type: UNSIGNED_32 Index: 23964 _d = 5D9C _h
Response if fan speed of internal fan is too low.		
Selection list (Lenze setting printed in bold)		
1	Error	
5	Warning	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00612

Parameter Name:		Data type: UNSIGNED_8 Index: 23963 _d = 5D9B _h
C00612 Resp. to CAN node guarding error		
Response of master if the corresponding node guarding response is missing. ▶ "CAN on board" system bus: node guarding protocol		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Info
C00612/1	0: No Response	Response to non-received telegram for monitoring entry 1 ... 32
C00612/...		
C00612/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00613

Parameter Name:		Data type: UNSIGNED_8 Index: 23962 _d = 5D9A _h
C00613 Resp. to CAN heartbeat error		
Response if the corresponding heartbeat telegram is missing. ▶ "CAN on board" system bus: heartbeat protocol		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Info
C00613/1	0: No Response	Response to non-received telegram for monitoring entry 1 ... 32
C00613/...		
C00613/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00614

Parameter Name: C00614 Resp. to CAN life guarding error		Data type: UNSIGNED_8 Index: 23961 _d = 5D99 _h
Response of slave if node guarding request is missing.		
▶ "CAN on board" system bus: node guarding protocol		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00615

Parameter Name: C00615 Resp. to imp. device conf.		Data type: UNSIGNED_32 Index: 23960 _d = 5D98 _h
Selection list		
1	Error	
3	Quick stop by trouble	
4	Warning locked	
6	Information	
0	No response	
Subcodes	Lenze setting	Info
C00615/1	0: No Response	Reserved
C00615/2	1: Error	Resp. to imp. module in MXI1
C00615/3	1: Error	Resp. to imp. module in MXI2
C00615/4	0: No Response	Reserved
C00615/5	0: No Response	Reserved
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00618

Parameter Name: C00618 No. of CRC cycles		Data type: UNSIGNED_32 Index: 23957 _d = 5D95 _h
Display range (min. value unit max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00619

Parameter Name:		Data type: UNSIGNED_32 Index: 23956 _d = 5D94 _h
C00619 Resp. to motor current > C00620		
Response if the ultimate motor current I _{ult} parameterised in C00620 is reached.		
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00620

Parameter Name:		Data type: UNSIGNED_32 Index: 23955 _d = 5D93 _h
C00620 Ultimate motor current I_{ult}		
Limit value to protect the motor from destruction or influence of the rated data. <ul style="list-style-type: none"> • This limit value must not be travelled cyclically in the drive process. • The maximum current parameterisable in C00022 should have a sufficient distance from this limit value. • If the set limit value is exceeded, the error response parameterised in C00619 is carried out for motor protection. 		
Setting range (min. value unit max. value)		Lenze setting
0.0	A	3000.0
		3000.0 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00621

Parameter Name:		Data type: UNSIGNED_32 Index: 23954 _d = 5D92 _h
C00621 Resp. to encoder pulse deviation		
From software version V1.5 Response to be triggered by angular drift monitoring		
		▶ Angular drift monitoring
Selection list (Lenze setting printed in bold)		
1	Error	
2	Fault	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
13	Quick Stop open loop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00625

Parameter Name: C00625 CAN behaviour in case of fault		Data type: UNSIGNED_8 Index: 23950 _d = 5D8E _h
Mapping of the CANopen object I-1029 (see DS301 V4.02).		▶ "CAN on board" system bus
Selection list (Lenze setting printed in bold)		
0	Pre-operational state	
1	No state change	
2	Stopped state	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00635

Parameter Name: C00635 Resp to new firmw. standard dev.		Data type: UNSIGNED_32 Index: 23940 _d = 5D84 _h
Selection list (Lenze setting printed in bold)		
1	Error	
6	Information	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00636

Parameter Name: C00636 Resp. to new module in MX1		Data type: UNSIGNED_32 Index: 23939 _d = 5D83 _h
Selection list (Lenze setting printed in bold)		
1	Error	
6	Information	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00637

Parameter Name: C00637 Resp. to new module in MX12		Data type: UNSIGNED_32 Index: 23938 _d = 5D82 _h
Selection list (Lenze setting printed in bold)		
1	Error	
6	Information	
5	Warning	
4	Warning locked	
3	Quick stop by trouble	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00640

Parameter Name: C00640 Resp. to pole pos. id. monit.		Data type: UNSIGNED_32 Index: 23935 _d = 5D7F _h
From software version V4.0 Error response for abort of the pole position identification ▶ Adjustment of the pole position identification		
Selection list (Lenze setting printed in bold)		
1	Error	
4	Warning locked	
0	No response	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00641

Parameter Name: C00641 PLI 360° current amplitude		Data type: UNSIGNED_32 Index: 23934 _d = 5D7E _h
From software version V4.0 Percentage adjustment of the current amplitude for the pole position identification Stop! If there is no temperature monitoring in the motor and/or the I2xt motor monitoring is not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)! ▶ Adjustment of the pole position identification		
Setting range (min. value unit max. value)		Lenze setting
1	%	1000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00642

Parameter Name: C00642 PolePosId 360° ramp time		Data type: UNSIGNED_32 Index: 23933 _d = 5D7D _h
From software version V4.0 Percentage adjustment of the ramp time for the pole position identification ▶ Adjustment of the pole position identification		
Setting range (min. value unit max. value)		Lenze setting
5	%	1000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00643

Parameter Name: C00643 PLI 360° traversing direction		Data type: UNSIGNED_32 Index: 23932 _d = 5D7C _h
From software version V4.0 Selection of the traversing direction for the pole position identification ▶ Adjustment of the pole position identification		
Selection list (Lenze setting printed in bold)		
0	Right rotating field	
1	Left rotating field	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00644

Parameter Name: C00644 PolePosId 360° fault tol.			Data type: INTEGER_32 Index: 23931 _d = 5D7B _h	
From software version V4.0 Fault tolerance for the plausibility check of the pole position identification ▶ Adjustment of the pole position identification				
Setting range (min. value unit max. value)			Lenze setting	
-6.0	°	30.0	0.0 °	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10	

C00645

Parameter Name: C00645 PLI 360° absolute current amplitude			Data type: UNSIGNED_32 Index: 23930 _d = 5D7A _h	
From software version V7.0 ▶ Adjustment of the pole position identification				
Display range (min. value unit max. value)				
0.00	A	1000.00		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100	

C00646

Parameter Name: C00646 PLI min.mov. curr. amplitude			Data type: UNSIGNED_32 Index: 23929 _d = 5D79 _h	
From software version V4.0 Percentage adjustment of the current amplitude for the pole position identification Stop! If there is no temperature monitoring in the motor and/or the I2xt motor monitoring is not parameterised correctly, the motor may be permanently damaged when the current amplitude is set too high (e.g. to the maximum value)! ▶ Adjustment of the pole position identification				
Setting range (min. value unit max. value)			Lenze setting	
1	%	1000	100 %	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

C00647

Parameter Name: C00647 PolePosId min.mov. cur.rise rate			Data type: UNSIGNED_32 Index: 23928 _d = 5D78 _h	
From software version V4.0 Percentage adjustment of the rate of current rise for the pole position identification ▶ Adjustment of the pole position identification				
Setting range (min. value unit max. value)			Lenze setting	
5	%	1000	100 %	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

C00648

Parameter Name: C00648 PolePosId min.mov. gain		Data type: UNSIGNED_32 Index: 23927 _d = 5D77 _h	
From software version V4.0 P component of the PI controller for the pole position identification ▶ Adjustment of the pole position identification			
Setting range (min. value unit max. value)		Lenze setting	
0.00		10.00	0.00
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00649

Parameter Name: C00649 PLI min. mov. reset time		Data type: UNSIGNED_32 Index: 23926 _d = 5D76 _h	
From software version V4.0 I component of the PI controller for the pole position identification ▶ Adjustment of the pole position identification			
Setting range (min. value unit max. value)		Lenze setting	
0.01	ms	6000.00	62.50 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00650

Parameter Name: C00650 PolePosId min.mov. max.perm.mov.		Data type: INTEGER_32 Index: 23925 _d = 5D75 _h	
From software version V4.0 Max. movement permitted during the pole position identification ▶ Adjustment of the pole position identification			
Setting range (min. value unit max. value)		Lenze setting	
1	°	90	20 °
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00651

Parameter Name: C00651 PLI min. motion absolute cur. amp.		Data type: UNSIGNED_32 Index: 23924 _d = 5D74 _h	
From software version V7.0 ▶ Adjustment of the pole position identification			
Display range (min. value unit max. value)			
0.00	A	1000.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00658

Parameter Name: C00658 Noise signal amplitude		Data type: UNSIGNED_32 Index: 23917 _d = 5D6D _h	
This code is for device-internal use only and must not be written to by the user!			

C00659

Parameter Name: C00659 Noise signal period	Data type: UNSIGNED_32 Index: 23916 _d = 5D6C _h
This code is for device-internal use only and must not be written to by the user!	

C00691

Parameter Name: C00691 Total speed setpoint	Data type: INTEGER_32 Index: 23884 _d = 5D4C _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00692

Parameter Name: C00692 Speed setpoint [%]	Data type: INTEGER_32 Index: 23883 _d = 5D4B _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00693

Parameter Name: C00693 Actual speed [%]	Data type: INTEGER_32 Index: 23882 _d = 5D4A _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00694

Parameter Name: C00694 Speed controller output	Data type: INTEGER_32 Index: 23881 _d = 5D49 _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00695

Parameter Name: C00695 Total torque setpoint	Data type: INTEGER_32 Index: 23880 _d = 5D48 _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00696

Parameter Name: C00696 Torque setpoint [%]	Data type: INTEGER_32 Index: 23879 _d = 5D47 _h
Display range (min. value unit max. value)	
-200.00 % 200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C00697

Parameter Name: C00697 Filtered torque setpoint		Data type: INTEGER_32 Index: 23878 _d = 5D46 _h
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00698

Parameter Name: C00698 Actual torque [%]		Data type: INTEGER_32 Index: 23877 _d = 5D45 _h
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00730

Parameter Name: C00730 GDO general parameters		Data type: INTEGER_32 Index: 23845 _d = 5D25 _h
This code is for device-internal use only and must not be written to by the user!		

C00731

Parameter Name: C00731 GDO channel 1/trigger 1		Data type: INTEGER_32 Index: 23844 _d = 5D24 _h
This code is for device-internal use only and must not be written to by the user!		

C00732

Parameter Name: C00732 GDO channel 2/trigger 2		Data type: INTEGER_32 Index: 23843 _d = 5D23 _h
This code is for device-internal use only and must not be written to by the user!		

C00733

Parameter Name: C00733 GDO channel 3		Data type: INTEGER_32 Index: 23842 _d = 5D22 _h
This code is for device-internal use only and must not be written to by the user!		

C00734

Parameter Name: C00734 GDO channel 4		Data type: INTEGER_32 Index: 23841 _d = 5D21 _h
This code is for device-internal use only and must not be written to by the user!		

C00735

Parameter Name: C00735 GDO channel 5		Data type: INTEGER_32 Index: 23840 _d = 5D20 _h
This code is for device-internal use only and must not be written to by the user!		

C00736

Parameter Name: C00736 GDO channel 6	Data type: INTEGER_32 Index: 23839 _d = 5D1F _h
This code is for device-internal use only and must not be written to by the user!	

C00737

Parameter Name: C00737 GDO channel 7	Data type: INTEGER_32 Index: 23838 _d = 5D1E _h
This code is for device-internal use only and must not be written to by the user!	

C00738

Parameter Name: C00738 GDO channel 8	Data type: INTEGER_32 Index: 23837 _d = 5D1D _h
This code is for device-internal use only and must not be written to by the user!	

C00739

Parameter Name: C00739 GDO status information	Data type: INTEGER_32 Index: 23836 _d = 5D1C _h
This code is for device-internal use only and must not be written to by the user!	

C00770

Parameter Name: C00770 MCTRL_dnMotorPosAct	Data type: UNSIGNED_32 Index: 23805 _d = 5CFD _h
Internal motor control (MCTRL) signal	
Display range (min. value unit max. value)	
0	Incr. 4294967295
Subcodes	Info
C00770/1	LOW word
C00770/2	High word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00771

Parameter Name: C00771 MCTRL_dnLoadPosAct	Data type: UNSIGNED_32 Index: 23804 _d = 5CFE _h
Internal motor control (MCTRL) signal	
Display range (min. value unit max. value)	
0	Incr. 4294967295
Subcodes	Info
C00771/1	LOW word
C00771/2	High word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C00772

Parameter Name: C00772 MCTRL_dnMotorSpeedAct			Data type: INTEGER_32 Index: 23803 _d = 5CFB _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00773

Parameter Name: C00773 MCTRL_dnLoadSpeedAct			Data type: INTEGER_32 Index: 23802 _d = 5CFA _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00774

Parameter Name: C00774 MCTRL_dnTorqueAct			Data type: INTEGER_32 Index: 23801 _d = 5CF9 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00775

Parameter Name: C00775 MCTRL_dnOutputSpeedCtrl			Data type: INTEGER_32 Index: 23800 _d = 5CF8 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00776

Parameter Name: C00776 MCTRL_dnInputJerkCtrl			Data type: INTEGER_32 Index: 23799 _d = 5CF7 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00777

Parameter Name: C00777 MCTRL_dnInputTorqueCtrl			Data type: INTEGER_32 Index: 23798 _d = 5CF6 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-21474836.47	Nm	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00778

Parameter Name: C00778 MCTRL_dnFluxAct			Data type: INTEGER_32 Index: 23797 _d = 5CF5 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00779

Parameter Name: C00779 MCTRL_dnDCBusVoltage			Data type: INTEGER_32 Index: 23796 _d = 5CF4 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0	V	1000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00780

Parameter Name: C00780 MCTRL_dnImotAct			Data type: INTEGER_32 Index: 23795 _d = 5CF3 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-500.00	A	500.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00781

Parameter Name: C00781 MCTRL_dwMaxMotorSpeed			Data type: UNSIGNED_32 Index: 23794 _d = 5CF2 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00782

Parameter Name: C00782 MCTRL_dwMaxMotorTorque		Data type: UNSIGNED_32 Index: 23793 _d = 5CF1 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
0.000	Nm	2147483.647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C00783

Parameter Name: C00783 MCTRL_dwMotorVoltageAct		Data type: UNSIGNED_32 Index: 23792 _d = 5CF0 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
0	V	2000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00784

Parameter Name: C00784 MCTRL_dnMotorFreqAct		Data type: INTEGER_32 Index: 23791 _d = 5CEF _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-800.0	Hz	800.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00786

Parameter Name: C00786 MCTRL_dnIxtLoad		Data type: INTEGER_32 Index: 23789 _d = 5CED _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00787

Parameter Name: C00787 MCTRL_dnFlyingSpeedAct		Data type: INTEGER_32 Index: 23788 _d = 5CEC _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00788

Parameter Name: C00788 MCTRL_dwMaxEffMotorTorque			Data type: INTEGER_32 Index: 23787 _d = 5CEB _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0.000	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00789

Parameter Name: C00789 MCTRL_dwMaxDeviceCurrent			Data type: INTEGER_32 Index: 23786 _d = 5CEA _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0.00	A	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00790

Parameter Name: C00790 MCTRL_dnl2xtLoad			Data type: INTEGER_32 Index: 23785 _d = 5CE9 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00791

Parameter Name: C00791 MCTRL_dnDeltaMotorPos_p			Data type: INTEGER_32 Index: 23784 _d = 5CE8 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-2147483647	Incr.	2147483647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00792

Parameter Name: C00792 MCTRL_dnOutputPosCtrlMotor_s			Data type: INTEGER_32 Index: 23783 _d = 5CE7 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200	%	200	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00800

Parameter Name: C00800 MCTRL_dnPosSet			Data type: UNSIGNED_32 Index: 23775 _d = 5CDF _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0	Incr.	4294967295	
Subcodes			Info
C00800/1			LOW word
C00800/2			High word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00802

Parameter Name: C00802 MCTRL_dnSpeedAdd			Data type: INTEGER_32 Index: 23773 _d = 5CDD _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00803

Parameter Name: C00803 MCTRL_dnTorqueAdd			Data type: INTEGER_32 Index: 23772 _d = 5CDC _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-2147483.647	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00804

Parameter Name: C00804 MCTRL_dnAccelerationAdd			Data type: INTEGER_32 Index: 23770 _d = 5CDB _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-2147483.647	1/s ²	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00805

Parameter Name: C00805 MCTRL_dnSpeedLowLimit			Data type: INTEGER_32 Index: 23770 _d = 5CDA _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00806

Parameter Name: C00806 MCTRL_dnTorqueLowLimit		Data type: INTEGER_32 Index: 23769 _d = 5CD9 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00807

Parameter Name: C00807 MCTRL_dnTorqueHighLimit		Data type: INTEGER_32 Index: 23768 _d = 5CD8 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00808

Parameter Name: C00808 MCTRL_dnPosCtrlOutLimit		Data type: INTEGER_32 Index: 23767 _d = 5CD7 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00809

Parameter Name: C00809 MCTRL_dnTorqueCtrlAdapt		Data type: INTEGER_32 Index: 23766 _d = 5CD6 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00810

Parameter Name: C00810 MCTRL_dnSpeedCtrlAdapt		Data type: INTEGER_32 Index: 23765 _d = 5CD5 _h
Internal motor control (MCTRL) signal		
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C00811

Parameter Name: C00811 MCTRL_dnPosCtrlAdapt			Data type: INTEGER_32 Index: 23764 _d = 5CD4 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00812

Parameter Name: C00812 MCTRL_dnMotorPosRefValue			Data type: UNSIGNED_32 Index: 23763 _d = 5CD3 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0	Incr.	4294967295	
Subcodes		Info	
C00812/1		LOW word	
C00812/2		High word	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00813

Parameter Name: C00813 MCTRL_dnLoadPosRefValue			Data type: UNSIGNED_32 Index: 23762 _d = 5CD2 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
0	Incr.	4294967295	
Subcodes		Info	
C00813/1		LOW word	
C00813/2		High word	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00814

Parameter Name: C00814 MCTRL_dnBoost			Data type: INTEGER_32 Index: 23761 _d = 5CD1 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-1000	V	1000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00815

Parameter Name: C00815 MCTRL_dnSpeedCtrlIntegrator			Data type: INTEGER_32 Index: 23760 _d = 5CD0 _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-2147483.647	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00816

Parameter Name: C00816 MCTRL_dnFieldWeak			Data type: INTEGER_32 Index: 23759 _d = 5CCF _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00817

Parameter Name: C00817 MCTRL_dnSpeedSet_s			Data type: INTEGER_32 Index: 23758 _d = 5CCF _h
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00818

Parameter Name: C00818 MCTRL_dnMvorAdapt			Data type: INTEGER_32 Index: 23757 _d = 5CCD _h
From software version V1.5			
Internal motor control (MCTRL) signal			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00854

Parameter Name: C00854 ID status			Data type: UNSIGNED_32 Index: 23721 _d = 5CA9 _h
From software version V3.0			
Display range (min. value unit max. value)			
0		100	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00878

Parameter Name: C00878 Status DCTRL control input			Data type: UNSIGNED_8 Index: 23697 _d = 5C91 _h
Display range (min. value unit max. value)			
0		1	
Subcodes		Info	
C00878/1		Status of control inputs	
C00878/...			
C00878/5			
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00909

Parameter Name: C00909 Speed limitation		Data type: INTEGER_16 Index: 23666 _d = 5C72 _h
Speed limitation for speed setpoint <ul style="list-style-type: none"> For the upper speed limit value only positive values are permissible (0.0 % ... 175.0 %). For the lower speed limit value only negative values are permissible (-175.0 % ... 0.0 %). 		
Setting range (min. value unit max. value)		
-175.0	%	175.0
Subcodes	Lenze setting	Info
C00909/1	175.0 %	Upper speed limit value
C00909/2	-175.0 %	Lower speed limit value
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C00950

Parameter Name: C00950 VFC: V/f characteristic shape		Data type: UNSIGNED_32 Index: 23625 _d = 5C49 _h
From software version V3.0		▶ V/f control
Selection list (Lenze setting printed in bold)		
0	Linear (V/f)	
1	Quadratic (V/f ²)	
2	Curve	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00951

Parameter Name: C00951 VFC: V/f base frequency		Data type: INTEGER_32 Index: 23624 _d = 5C48 _h
From software version V3.0		▶ V/f control
Setting range (min. value unit max. value)		Lenze setting
1	Hz	5000
		50 Hz
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C00952

Parameter Name: C00952 VFC: Frequency interpol. point n			Data type: INTEGER_32 Index: 23623 _d = 5C47 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)			
-5000	Hz	5000	
Subcodes	Lenze setting	Info	
C00952/1	-50 Hz		
C00952/2	-40 Hz		
C00952/3	-30 Hz		
C00952/4	-20 Hz		
C00952/5	-10 Hz		
C00952/6	0 Hz		
C00952/7	10 Hz		
C00952/8	20 Hz		
C00952/9	30 Hz		
C00952/10	40 Hz		
C00952/11	50 Hz		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1			

C00953

Parameter Name: C00953 VFC: Voltage interpol. point n			Data type: INTEGER_32 Index: 23622 _d = 5C46 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)			
0.00	V	1000.00	
Subcodes	Lenze setting	Info	
C00953/1	400.00 V		
C00953/2	320.00 V		
C00953/3	240.00 V		
C00953/4	160.00 V		
C00953/5	80.00 V		
C00953/6	0.00 V		
C00953/7	80.00 V		
C00953/8	160.00 V		
C00953/9	240.00 V		
C00953/10	320.00 V		
C00953/11	400.00 V		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100			

C00954

Parameter Name:		Data type: UNSIGNED_32 Index: 23621 _d = 5C45 _h	
C00954 VFC: Activat. interpol. point n			
From software version V3.0		▶ V/f control	
Selection list			
0	Off		
1	On		
Subcodes	Lenze setting	Info	
C00954/1	1: On		
C00954/2	1: On		
C00954/3	1: On		
C00954/4	1: On		
C00954/5	1: On		
C00954/6	1: On		
C00954/7	1: On		
C00954/8	1: On		
C00954/9	1: On		
C00954/10	1: On		
C00954/11	1: On		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00955

Parameter Name:		Data type: UNSIGNED_32 Index: 23620 _d = 5C44 _h	
C00955 VFC: Vmax reduction			
From software version V3.0		▶ V/f control	
Setting range (min. value unit max. value)		Lenze setting	
0	V	500	0 V
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00957

Parameter Name:		Data type: INTEGER_32 Index: 23618 _d = 5C42 _h	
C00957 VFC: VVC current setpoint			
From software version V3.0		▶ V/f control	
Setting range (min. value unit max. value)		Lenze setting	
0.00	A	1500.00	0.00 A
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 100	

C00958

Parameter Name: C00958 VFC: VVC gain		Data type: UNSIGNED_32 Index: 23617 _d = 5C41 _h	
From software version V3.0			
▶ V/f control			
Setting range (min. value unit max. value)		Lenze setting	
0.00	V/A	750.00	0.00 V/A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00959

Parameter Name: C00959 VFC: VVC reset time		Data type: UNSIGNED_32 Index: 23616 _d = 5C40 _h	
From software version V3.0			
▶ V/f control			
Setting range (min. value unit max. value)		Lenze setting	
0.01	ms	2000.00	2000.00 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00960

Parameter Name: C00960 VFC: V/f voltage boost		Data type: INTEGER_32 Index: 23615 _d = 5C3F _h	
From software version V3.0			
▶ V/f control			
Setting range (min. value unit max. value)		Lenze setting	
0	V	1000	0 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00961

Parameter Name: C00961 VFC: Load - cw/ccw-operation		Data type: UNSIGNED_32 Index: 23614 _d = 5C3E _h	
From software version V3.0			
▶ V/f control			
Selection list (Lenze setting printed in bold)			
0	CW: mot. / CCW: mot.		
1	CW: mot. / CCW: regen.		
2	CW: regen. / CCW: mot.		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00962

Parameter Name: C00962 VFC: Load adjustment		Data type: UNSIGNED_32 Index: 23613 _d = 5C3D _h	
From software version V3.0			
▶ V/f control			
Setting range (min. value unit max. value)		Lenze setting	
0.00	%	200.00	20.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00963

Parameter Name: C00963 VFC: Gain - I_{max} controller			Data type: UNSIGNED_32 Index: 23612 _d = 5C3C _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
0.000	Hz/A	1000.000	0.001 Hz/A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00964

Parameter Name: C00964 VFC: Reset time - I_{max} contr.			Data type: UNSIGNED_32 Index: 23611 _d = 5C3B _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
1.0	ms	2000.0	100.0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00965

Parameter Name: C00965 VFC: Gain - slip compensation			Data type: INTEGER_32 Index: 23610 _d = 5C3A _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
-200.00	%	200.00	0.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00966

Parameter Name: C00966 VFC: Time const. slip comp.			Data type: UNSIGNED_32 Index: 23609 _d = 5C39 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
1	ms	6000	2000 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00967

Parameter Name: C00967 VFC: Gain - oscillation damping			Data type: INTEGER_32 Index: 23608 _d = 5C38 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
-100	%	100	20 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00968

Parameter Name: C00968 VFC: Time const. - oscill. damp.			Data type: INTEGER_32 Index: 23607 _d = 5C37 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
1	ms	600	5 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00969

Parameter Name: C00969 VFC: Limitation - oscill. damp.			Data type: INTEGER_32 Index: 23606 _d = 5C36 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
0.1	Hz	20.0	0.2 Hz
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00970

Parameter Name: C00970 VFC: ramp-end frequ. - oscill. damp.			Data type: INTEGER_32 Index: 23605 _d = 5C35 _h
From software version V5.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
0	%	100	0 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00971

Parameter Name: C00971 VFC: Influence - speed controller			Data type: UNSIGNED_32 Index: 23604 _d = 5C34 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
0.00	%	100.00	10.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00972

Parameter Name: C00972 VFC: Gain - speed controller			Data type: UNSIGNED_32 Index: 23603 _d = 5C33 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
0.000	Hz/rpm	1000.000	0.000 Hz/rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C00973

Parameter Name: C00973 VFC: Reset time - speed contr.			Data type: UNSIGNED_32 Index: 23602 _d = 5C32 _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
1.0	ms	6000.0	6000.0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C00974

Parameter Name: C00974 DC brake: Current			Data type: INTEGER_32 Index: 23601 _d = 5C31 _h
From software version V3.0			▶ DC-injection braking
Setting range (min. value unit max. value)		Lenze setting	
0.00	A	500.00	0.00 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00975

Parameter Name: C00975 DC brake: Current for quick stop			Data type: INTEGER_32 Index: 23600 _d = 5C30 _h
From software version V3.0			▶ DC-injection braking
Setting range (min. value unit max. value)		Lenze setting	
0.00	A	500.00	0.00 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00976

Parameter Name: C00976 DC brake: Activat. by quick stop			Data type: UNSIGNED_32 Index: 23599 _d = 5C2F _h
From software version V3.0			▶ DC-injection braking
Selection list (Lenze setting printed in bold)			
0	Off		
1	On		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00977

Parameter Name: C00977 Min. inh-time aft. overvolt			Data type: UNSIGNED_32 Index: 23598 _d = 5C2E _h
From software version V3.0			▶ V/f control
Setting range (min. value unit max. value)		Lenze setting	
1	ms	10000	500 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00980

Parameter Name: C00980 VFC: Override point of field weakening		Data type: INTEGER_32 Index: 23595 _d = 5C2B _h	
From software version V8.0			
Offset of the override point for field weakening			
<ul style="list-style-type: none"> In the VFCplus operating mode the pull-out protection function or the maximally permissible current in the field weakening range can be adapted. 			
Setting range (min. value unit max. value)		Lenze setting	
-500	Hz	500	0 Hz
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C00985

Parameter Name: C00985 SLVC: Gain of field current controller		Data type: UNSIGNED_32 Index: 23590 _d = 5C26 _h	
From software version V3.0			
▶ Sensorless vector control			
Setting range (min. value unit max. value)		Lenze setting	
0.00		21474836.47	0.00
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00986

Parameter Name: C00986 SLVC: Gain of cross current controller		Data type: UNSIGNED_32 Index: 23589 _d = 5C25 _h	
From software version V3.0			
▶ Sensorless vector control			
Setting range (min. value unit max. value)		Lenze setting	
0.00		21474836.47	0.00
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00987

Parameter Name: C00987 SLVC: Gain - torque controller		Data type: UNSIGNED_32 Index: 23588 _d = 5C24 _h	
From software version V3.0			
▶ Sensorless vector control			
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Hz/A	1000.0000	0.5000 Hz/A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000	

C00988

Parameter Name: C00988 SLVC: Reset time - torque contr.		Data type: UNSIGNED_32 Index: 23587 _d = 5C23 _h	
From software version V3.0			
▶ Sensorless vector control			
Setting range (min. value unit max. value)		Lenze setting	
0.01	ms	2000.00	10.00 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C00989

Parameter Name: C00989 SLVC: Time const.- Para. adj.		Data type: UNSIGNED_32 Index: 23586 _d = 5C22 _h	
From software version V3.0			
▶ Sensorless vector control			
Setting range (min. value unit max. value)			
0	ms	20000	
Subcodes	Lenze setting	Info	
C00989/1	20000 ms	SLVC: Time const.- Para.Rs adj.	
C00989/2	20000 ms	SLVC: Time const.- Para.Lh adj.	
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00990

Parameter Name: C00990 Flying restart: Activation		Data type: UNSIGNED_32 Index: 23585 _d = 5C21 _h	
From software version V3.0			
Note! Only deactivate the flying restart for the V/f control or sensorless vector control if it is ensured that the drive is always at standstill in the case of controller enable!			
▶ Flying restart fct.			
Selection list (Lenze setting printed in bold)			
0	Off		
1	On		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00991

Parameter Name: C00991 Flying restart: Current		Data type: INTEGER_32 Index: 23584 _d = 5C20 _h	
From software version V3.0			
▶ Flying restart fct.			
Setting range (min. value unit max. value)			Lenze setting
0	%	100	15 %
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C00992

Parameter Name: C00992 Flying restart: Start frequency		Data type: INTEGER_32 Index: 23583 _d = 5C1F _h	
From software version V3.0			
▶ Flying restart fct.			
Setting range (min. value unit max. value)			Lenze setting
-600.0	Hz	600.0	20.0 Hz
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10	

C00993

Parameter Name: C00993 Flying restart: Integration time			Data type: UNSIGNED_32 Index: 23582 _d = 5C1E _h
From software version V3.0			▶ Flying restart fct.
Setting range (min. value unit max. value)		Lenze setting	
1	ms	6000	60 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00994

Parameter Name: C00994 Flying restart: Min. deviation			Data type: UNSIGNED_32 Index: 23581 _d = 5C1D _h
From software version V3.0			▶ Flying restart fct.
Setting range (min. value unit max. value)		Lenze setting	
0.00	°	90.00	5.00 °
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C00995

Parameter Name: C00995 Flying restart: Delay time			Data type: UNSIGNED_32 Index: 23580 _d = 5C1C _h
From software version V3.0			▶ Flying restart fct.
Setting range (min. value unit max. value)		Lenze setting	
0	ms	10000	0 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C00998

Parameter Name: C00998 VFC: Frequency setpoint			Data type: INTEGER_32 Index: 23577 _d = 5C19 _h
From software version V3.0			▶ V/f control
Display range (min. value unit max. value)			
-800.0	Hz	800.0	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C01120

Parameter Name: C01120 Sync source		Data type: UNSIGNED_8 Index: 23455 _d = 5B9F _h
Selection of the source for the synchronisation signals. <ul style="list-style-type: none"> The drive can only be synchronised by one source. Note: Set the selection "2: CAN module" for the communication module CANopen (E94AYCCA). ▶ "CAN on board" system bus: sync telegram		
Selection list (Lenze setting printed in bold)		
0	Off	
1	CAN on board	
2	CAN module	
4	Module in MXI1	
5	Module in MXI2	
6	Digital input 1	
7	Digital input 2	
8	Digital input 3	
9	Digital input 4	
10	Digital input 5	
11	Digital input 6	
12	Digital input 7	
13	Digital input 8	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C01121

Parameter Name: C01121 Sync cycle time		Data type: UNSIGNED_32 Index: 23454 _d = 5B9E _h
Time interval at which the phase control loop (PLL) in the controller expects the synchronisation signals. <ul style="list-style-type: none"> The time interval set must correspond to the cycle of the synchronisation source. Note: For synchronisation via the system bus (CANopen), only integer multiples of 1000 µs should be set. Example: For the system bus, the interval between two synchronisation signals is set to 2 ms. If the system bus is to be used as the synchronisation source, a synchronisation cycle of 2000 µs must be set in C01121. ▶ "CAN on board" system bus: sync telegram		
Setting range (min. value unit max. value)		Lenze setting
250	µs	20000
		1000 µs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C01122

Parameter Name: C01122 Sync phase position		Data type: UNSIGNED_32 Index: 23453 _d = 5B9D _h	
<p>The phase position defines the zero point of time for the application relating to the synchronisation signal (bus cycle). Since PDO processing is integrated in the system part of the application, the instant of the PDO acceptance also changes if the phase position is changed.</p> <ul style="list-style-type: none"> • If 0 is set, the application is started together with the synchronisation signal. • If a value > 0 is set, the application starts by the set time interval before the synchronisation signal arrives (the phase position acts negatively). <p>Example: If the phase position is set to 400 µs, the system part of the application starts 400 µs before the synchronisation signal arrives.</p> <p>From software version V3.0: The effect of the sync phase position can be affected by the application cycle set in C01130. For the Lenze setting of C01130 the behaviour remains as before.</p> <p style="text-align: right;">▶ "CAN on board" system bus: sync telegram</p>			
Setting range (min. value unit max. value)		Lenze setting	
0	µs	64000	400 µs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01123

Parameter Name: C01123 Sync tolerance		Data type: UNSIGNED_32 Index: 23452 _d = 5B9C _h	
<p>Time slot for monitoring the synchronisation signal via the LS_SyncInput system block</p> <ul style="list-style-type: none"> • If the last synchronisation signal has been within this time slot around the expected value, the SYNC_bSynclnsideWindow output of the LS_SyncInput system block is set to TRUE. • This setting does not affect the synchronisation process. <p style="text-align: right;">▶ "CAN on board" system bus: sync telegram</p>			
Setting range (min. value unit max. value)		Lenze setting	
0	µs	1000	0 µs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01124

Parameter Name: C01124 Sync-PLL increment		Data type: UNSIGNED_8 Index: 23451 _d = 5B9B _h
<p>When the cycle times of the synchronisation signal and the phase control loop (PLL) differ, this setting defines the increment to be used to readjust the phase control loop.</p> <ul style="list-style-type: none"> • If the system bus (CANopen) is used as the synchronisation source, the recommended value is 109 ns. <p style="text-align: right;">▶ "CAN on board" system bus: sync telegram</p>		
Selection list (Lenze setting printed in bold)		
1	7 ns	
2	15 ns	
3	23 ns	
4	31 ns	
5	39 ns	
6	46 ns	
7	54 ns	
8	62 ns	
9	70 ns	
10	78 ns	
11	85 ns	
12	93 ns	
13	101 ns	
14	109 ns	
15	117 ns	
16	125 ns	
17	132 ns	
18	140 ns	
19	148 ns	
20	156 ns	
21	164 ns	
22	171 ns	
23	179 ns	
24	187 ns	
25	195 ns	
26	203 ns	
27	210 ns	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01125

Parameter Name: C01125 Service code		Data type: UNSIGNED_32 Index: 23450 _d = 5B9A _h
This code is for device-internal use only and must not be written to by the user!		

C01126

Parameter Name: C01126 Service code		Data type: UNSIGNED_32 Index: 23449 _d = 5B99 _h
This code is for device-internal use only and must not be written to by the user!		

14 Parameter reference

14.2 Parameter list | C01127

C01127

Parameter Name: C01127 Service code	Data type: UNSIGNED_32 Index: 23448 _d = 5B98 _h
This code is for device-internal use only and must not be written to by the user!	

C01128

Parameter Name: C01128 Service code	Data type: UNSIGNED_32 Index: 23447 _d = 5B97 _h
This code is for device-internal use only and must not be written to by the user!	

C01129

Parameter Name: C01129 Service code	Data type: UNSIGNED_32 Index: 23446 _d = 5B96 _h
This code is for device-internal use only and must not be written to by the user!	

C01130

Parameter Name: C01130 CAN SYNC application cycle	Data type: UNSIGNED_16 Index: 23445 _d = 5B95 _h	
<p>From software version V3.0</p> <p>This parameter affects the effect of the sync phase position (C01122) regarding the instant of acceptance of the synchronous PDOs in the application and the instant of transmission of the synchronous PDOs on the system bus (CANopen).</p> <ul style="list-style-type: none"> The resulting PDO delay can be calculated with the following formula taking into account an internal processing time of 150 µs: PDO delay = (C01121 - C01122 + 150 µs) modulo C01130 For the Lenze setting, the behaviour remains as before, the sync phase position (C01122) is always calculated modulo 1000. The set value is automatically rounded down to multiples of 1000 µs. <p>► Effect of C01130 on the sync phase position</p> <p>Note: Setting the application cycle to a higher value than the sync cycle time (C01121) results in undefined behaviour. The same applies if the value set for the sync phase position (C01122) is higher than the sync cycle time (C01121). In this case, the drive usually cannot send synchronous PDOs on the system bus anymore.</p> <p style="text-align: right;">► "CAN on board" system bus: sync telegram</p>		
Setting range (min. value unit max. value)		
1000	µs	65000
		Lenze setting
		1000 µs
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01190

Parameter Name: C01190 Motor thermal sensor	Data type: UNSIGNED_32 Index: 23385 _d = 5B59 _h	
► Motor temperature monitoring		
Selection list (Lenze setting printed in bold)		
0	KTY83-110	Lenze standard KTY83-110 (MDSKX, MCS06)
1	Spec. characteristic	Characteristic defined via C01191 and C01192
2	KTY83-110 + 2 x PTC	Lenze standard KTY83-110 + 2 x PTC 150°C (MCS09-MCS19)
5	Pt1000	
6	Pt1000 + 2 x PTC	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01191

Parameter Name: C01191 Spec. charact.: temperature		Data type: UNSIGNED_32 Index: 23384 _d = 5B58 _h
The spec. thermal sensor characteristic is selected through the setting C01190="1" ▶ Motor temperature monitoring		
Setting range (min. value unit max. value)		
0	°C	255
Subcodes	Lenze setting	Info
C01191/1	25 °C	Value 1 for spec. thermal sensor characteristic
C01191/2	150 °C	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01192

Parameter Name: C01192 Spec. characteristic: resistance		Data type: UNSIGNED_32 Index: 23383 _d = 5B57 _h
The spec. thermal sensor characteristic is selected through the setting C01190="1" ▶ Motor temperature monitoring		
Setting range (min. value unit max. value)		
0	Ohm	30000
Subcodes	Lenze setting	Info
C01192/1	1000 Ohm	Value 1 for spec. thermal sensor characteristic
C01192/2	2225 ohms	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01193

Parameter Name: C01193 Motor temp. feedback system		Data type: UNSIGNED_16 Index: 23382 _d = 5B56 _h
Selection of feedback system for motor temperature detection. ▶ Motor temperature monitoring		
Selection list (Lenze setting printed in bold)		
0	Speed feedback	
1	X7 (Input Resolver)	
2	X8 (Input Encoder)	
3	Reserved	
4	Reserved	
5	X7 and X8 parallel	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01194

Parameter Name: C01194 Motor operating temperature		Data type: INTEGER_32 Index: 23381 _d = 5B55 _h
Setting range (min. value unit max. value)		Lenze setting
1	°C	200 140 °C
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01195

Parameter Name: C01195 Influence winding I²xt mon.		Data type: UNSIGNED_32 Index: 23380 _d = 5B54 _h	
I ² xt motor monitoring: Influence of the winding temperature			
<ul style="list-style-type: none"> By setting "0 %", the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/laminated core. 			
▶ I²xt motor monitoring			
Setting range (min. value unit max. value)		Lenze setting	
0	%	100	0 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01196

Parameter Name: C01196 S1 torque characteristic I²xt mon.		Data type: UNSIGNED_32 Index: 23379 _d = 5B53 _h	
<ul style="list-style-type: none"> By selecting a characteristic, the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation. 			
▶ I²xt motor monitoring			
Setting range (min. value unit max. value)			
0	%	600	
Subcodes	Lenze setting	Info	
C01196/1	0 %	S1 torque characteristic n1/nn	
C01196/2	100 %	S1 torque characteristic I1/In	
C01196/3	0 %	S1 torque characteristic n2/nn	
C01196/4	100 %	S1 torque characteristic I2/In	
C01196/5	100 %	S1 torque characteristic n3/nn	
C01196/6	100 %	S1 torque characteristic I3/In	
C01196/7	100 %	S1 torque characteristic n4/nn	
C01196/8	100 %	S1 torque characteristic I4/In	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01197

Parameter Name: C01197 Starting value I²xt monitoring		Data type: UNSIGNED_32 Index: 23378 _d = 5B52 _h	
From software version V11.0			
▶ I²xt motor monitoring			
Setting range (min. value unit max. value)		Lenze setting	
0	%	200	0 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01198

Parameter Name: C01198 Async. motor: Stall protection		Data type: UNSIGNED_32 Index: 23377 _d = 5B51 _h	
Setting range (min. value unit max. value)		Lenze setting	
0	%	100	0 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C01199

Parameter Name: C01199 Enhanced Power		Data type: UNSIGNED_32 Index: 23376 _d = 5B50 _h
From software version V3.0		
Stop! During operation with increased continuous power, the max. permissible ambient temperature is reduced to 40 °C. The overload current must be reduced. An overload current of 180 % for 10 s is no longer permissible during operation with increased continuous power.		
▶ Operation with increased continuous power		
Selection list (Lenze setting printed in bold)		
0	Enhanced Power off	
1	Enhanced Power Mode 1 on	
2	Enhanced Power Mode 2 on	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01200

Parameter Name: C01200 Dual motor temperature		Data type: INTEGER_32 Index: 23375 _d = 5B4F _h
From software version V7.0		
▶ Motor temperature monitoring ▶ Motor temperature monitoring of a second motor		
Display range (min. value unit max. value)		
-200	°C	200
Subcodes		Info
C01200/1		Motor temperature via X7
C01200/2		Motor temperature via X8
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01201

Parameter Name: C01201 Delay time for fan start		Data type: UNSIGNED_32 Index: 23374 _d = 5B4E _h
From software version V8.0		
Selection list (Lenze setting printed in bold)		
0	Via power section serial no.	
1	500 ms	
2	1000 ms	
3	1500 ms	
4	2000 ms	
5	2500 ms	
6	3000 ms	
7	3500 ms	
8	4000 ms	
9	4500 ms	
10	5000 ms	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01203

Parameter Name: C01203 Counter: Brake chopper overload		Data type: UNSIGNED_16 Index: 23372 _d = 5B4C _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01204

Parameter Name: C01204 Counter: lxt overload		Data type: UNSIGNED_16 Index: 23371 _d = 5B4B _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01205

Parameter Name: C01205 Counter: DC bus overvoltage		Data type: UNSIGNED_16 Index: 23370 _d = 5B4A _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01206

Parameter Name: C01206 Counter: Mains switching		Data type: UNSIGNED_16 Index: 23369 _d = 5B49 _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01208

Parameter Name: C01208 Counter: Heatsink overtemp.		Data type: UNSIGNED_16 Index: 23367 _d = 5B47 _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01209

Parameter Name: C01209 Counter: Housing overtemp.		Data type: UNSIGNED_16 Index: 23366 _d = 5B46 _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

14 Parameter reference

14.2 Parameter list | C01210

C01210

Parameter Name: C01210 Counter: Internal		Data type: UNSIGNED_8 Index: 23365 _d = 5B45 _h
From software version V8.0		
Display range (min. value unit max. value)		
0		255
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01211

Parameter Name: C01211 Service code		Data type: UNSIGNED_32 Index: 23364 _d = 5B44 _h
This code is for device-internal use only and must not be written to by the user!		

C01212

Parameter Name: C01212 Counter: Power section overload		Data type: UNSIGNED_16 Index: 23363 _d = 5B43 _h
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01213

Parameter Name: C01213 Service code DataFlash		Data type: UNSIGNED_32 Index: 23362 _d = 5B42 _h
This code is for device-internal use only and must not be written to by the user!		

C01214

Parameter Name: C01214 Internal clock		Data type: VISIBLE_STRING Index: 23361 _d = 5B41 _h
Display of the system time of the controller in the format "dd/mm/yyyy hh:mm:ss" <ul style="list-style-type: none">• Time and date are set via C01215.		
If the MM440 memory module with real-time clock is plugged into the controller, the internal clock is adjusted to the real-time clock every time the mains is switched on and every 24 hours at 0:00 o'clock. <ul style="list-style-type: none">• The daily adjustment is executed on a low-priority level. This is why it may take some seconds until the adjusted time is displayed.• During the adjustment process, status information of the real-time clock is also queried and entered into the logbook.		
Note: If a memory module without real-time clock is plugged into the controller, the internal clock is initialised with "01.01.1970 00:00:00" every time the mains is switched on.		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC-STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 21

C01215

Parameter Name: C01215 Set time and date		Data type: UNSIGNED_16 Index: 23360 _d = 5B40 _h
From software version V1.5		
Setting of the system time of the controller displayed in C01214 .		
<ul style="list-style-type: none"> • If the MM440 memory module with real-time clock is plugged into the controller, the real-time clock is set simultaneously. 		
Set time and date.		
<ul style="list-style-type: none"> • Before writing to a subcode for the first time, the current time information according to the internal clock is displayed in the subcodes. • When a value has been written into a subcode, the displays in the subcodes freeze to the last values. • The new system time set is only accepted after a value has been written into each subcode at least once. • After the new system time has been accepted, the display in the subcodes is updated according to the internal clock. 		
Note:		
If a memory module without real-time clock is plugged into the controller, the internal clock is initialised with "01.01.1970 00:00:00" every time the mains is switched on.		
Setting range (min. value unit max. value)		
0		65535
Subcodes	Lenze setting	Info
C01215/1	0	Seconds
C01215/2	0	Minutes
C01215/3	0	Hours
C01215/4	1	Day
C01215/5	1	Month
C01215/6	1970	Year
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C01217

Parameter Name: C01217 Service code	Data type: VISIBLE_STRING Index: 23358 _d = 5B3E _h
This code is for device-internal use only and must not be written to by the user!	

C01218

Parameter Name: C01218 Service code	Data type: UNSIGNED_32 Index: 23357 _d = 5B3D _h
This code is for device-internal use only and must not be written to by the user!	

C01220

Parameter Name: C01220 MEC history: RAM address	Data type: UNSIGNED_32 Index: 23354 _d = 5B3B _h
This code is for device-internal use only and must not be written to by the user!	

C01221

Parameter Name: C01221 MEC history: RAM value	Data type: UNSIGNED_32 Index: 23354 _d = 5B3A _h
This code is for device-internal use only and must not be written to by the user!	

C01222

Parameter Name: C01222 MEC history: Flash value	Data type: UNSIGNED_32 Index: 23353 _d = 5B39 _h
This code is for device-internal use only and must not be written to by the user!	

C01223

Parameter Name: C01223 MEC history: Error number	Data type: UNSIGNED_32 Index: 23352 _d = 5B38 _h
This code is for device-internal use only and must not be written to by the user!	

C01230

Parameter Name: C01230 Resp. to comm. task overflow	Data type: UNSIGNED_8 Index: 23345 _d = 5B31 _h
From software version V7.0	
Selection list (Lenze setting printed in bold)	
1	Error
2	Fault
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
0	No response
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C01501

Parameter Name: C01501 Resp. to comm. error with MXI1	Data type: UNSIGNED_32 Index: 23074 _d = 5A22 _h
Response to a communication error between an "intelligent" module in slot 1 and the standard device	
Selection list (Lenze setting printed in bold)	
0	No response
1	Error
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C01502

Parameter Name:		Data type: UNSIGNED_32 Index: 23073 _d = 5A21 _h
C01502 Resp. to comm. error with MXI2		
Response to a communication error between an "intelligent" module in module slot 2 and the standard device		
Selection list (Lenze setting printed in bold)		
0	No response	
1	Error	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01510

Parameter Name:		Data type: VISIBLE_STRING Index: 23065 _d = 5A19 _h
C01510 Ethernet IP address client x		
Display of the three possible server channels		
<ul style="list-style-type: none"> • If a client is connected via one of these server channels, the IP address and the port of the client will be indicated in the form of "xxx.xxx.xxx.xxx : yyyy". • If no client is connected via the server channel, "----:----:----:----" will be indicated. 		
Subcodes		Info
C01510/1		Server channel 1 ... 3
C01510/...		
C01510/3		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 24

C01511

Parameter Name:		Data type: UNSIGNED_8 Index: 23064 _d = 5A18 _h
C01511 Ethernet status client x		
Status of the three possible server channels		
Selection list (read only)		
0	Not connected	
1	Connected	
2	Stop,	
3	Unknown status	
Subcodes		Info
C01511/1		State of server channels 1 ... 3
C01511/...		
C01511/3		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01700

Parameter Name: C01700 Energy: Mode inform.		Data type: UNSIGNED_8 Index: 22875 _d = 595B _h
From software version V9.0		
Display range (min. value unit max. value)		
0		255
Subcodes	Info	
C01700/1	Energy: Max. modes	
C01700/2	Energy: Curr. mode	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01701

Parameter Name: C01701 Energy: toff min		Data type: UNSIGNED_32 Index: 22874 _d = 595A _h
From software version V9.0		
Setting range (min. value unit max. value)		
0	ms	4294967295
Subcodes	Lenze setting	Info
C01701/1	0 ms	Energy mode 1: toff min
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01702

Parameter Name: C01702 Energy: toff		Data type: UNSIGNED_32 Index: 22873 _d = 5959 _h
From software version V9.0		
Setting range (min. value unit max. value)		
0	ms	4294967295
Subcodes	Lenze setting	Info
C01702/1	0 ms	Energy mode 1: toff
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01703

Parameter Name: C01703 Energy: ton		Data type: UNSIGNED_32 Index: 22872 _d = 5958 _h
From software version V9.0		
Setting range (min. value unit max. value)		
0	ms	4294967295
Subcodes	Lenze setting	Info
C01703/1	0 ms	Energy mode 1: ton
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01704

Parameter Name: C01704 Energy: Comp. to be switched off		Data type: BITFIELD_32 Index: 22871 _d = 5957 _h
From software version V9.0		
Setting range		
0x00000000		0xFFFFFFFF
Value is bit-coded: (<input checked="" type="checkbox"/> = bit set)		
Bit 0 <input checked="" type="checkbox"/> IMP		
Bit 1 <input type="checkbox"/> Reserved		
Bit 2 <input type="checkbox"/> Reserved		
Bit 3 <input type="checkbox"/> Reserved		
Bit 4 <input type="checkbox"/> Reserved		
Bit 5 <input type="checkbox"/> Reserved		
Bit 6 <input type="checkbox"/> Reserved		
Bit 7 <input type="checkbox"/> Reserved		
Bit 8 <input type="checkbox"/> Reserved		
Bit 9 <input type="checkbox"/> Reserved		
Bit 10 <input type="checkbox"/> Reserved		
Bit 11 <input type="checkbox"/> Reserved		
Bit 12 <input type="checkbox"/> Reserved		
Bit 13 <input type="checkbox"/> Reserved		
Bit 14 <input type="checkbox"/> Reserved		
Bit 15 <input type="checkbox"/> Reserved		
Bit 16 <input type="checkbox"/> Reserved		
Bit 17 <input type="checkbox"/> Reserved		
Bit 18 <input type="checkbox"/> Reserved		
Bit 19 <input type="checkbox"/> Reserved		
Bit 20 <input type="checkbox"/> Reserved		
Bit 21 <input type="checkbox"/> Reserved		
Bit 22 <input type="checkbox"/> Reserved		
Bit 23 <input type="checkbox"/> Reserved		
Bit 24 <input type="checkbox"/> Reserved		
Bit 25 <input type="checkbox"/> Reserved		
Bit 26 <input type="checkbox"/> Reserved		
Bit 27 <input type="checkbox"/> Reserved		
Bit 28 <input type="checkbox"/> Reserved		
Bit 29 <input type="checkbox"/> Reserved		
Bit 30 <input type="checkbox"/> Reserved		
Bit 31 <input type="checkbox"/> Reserved		
Subcodes	Lenze setting	Info
C01704/1	0x00000000	Energy m. 1: Comp. to be sw. off
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01705

Parameter Name: C01705 Energy: Power input		Data type: UNSIGNED_32 Index: 22870 _d = 5956 _h
From software version V9.0		
Setting range (min. value unit max. value)		
0	W	4294967295
Subcodes	Lenze setting	Info
C01705/1	0 W	Energy m. 1: Power input
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01902

Parameter Name: C01902 Diagnostics X6: Max. baud rate		Data type: UNSIGNED_32 Index: 22673 _d = 5891 _h
Maximum permissible baud rate of the standard device after determination of the baud rate at the diagnostic interface X6 • Communication starts with the default standard device baud rate of 19200 baud.		
Selection list (Lenze setting printed in bold)		
9600	9600 baud	
19200	19.200 baud	
38400	38.400 baud	
57600	57.600 baud	
115200	115.200 baud	
230400	230.400 baud	
375000	375.000 baud	
750000	750.000 baud	
1500000	1.500.000 baud	
3000000	3.000.000 baud	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C01903

Parameter Name: C01903 Diagnostics X6: Change baud rate		Data type: UNSIGNED_32 Index: 22672 _d = 5890 _h
New determination of the baud rate at the diagnostic interface X6		
Selection list (Lenze setting printed in bold)		
1	Set a higher baud rate	
0	Ignore changes	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C01905

Parameter Name: C01905 Diagnostics X6: Curr. baud rate		Data type: UNSIGNED_32 Index: 22670 _d = 588E _h
Current baud rate at diagnostics interface X6		
Display range (min. value unit max. value)		
0		3000000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02104

Parameter Name: C02104 Program auto-start		Data type: UNSIGNED_32 Index: 22471 _d = 57C7 _h
<p>⚠ Danger! The controller enable generated by the application via a connection of the terminal 28 (RFR) with one of the digital outputs <i>DIGOUT_bOut(x)</i> is not permissible if the following functions are active: "Auto-start after mains ON" (C00142 = "1") and "Program auto-start after mains switching" (C02104 = "1") If this is not observed, the controller can start automatically after mains connection!</p> <p style="text-align: right;">▶ Automatic restart after mains connection ▶ Activate application</p>		
Selection list (Lenze setting printed in bold)		
0	Off	
1	Autom. after mains connection	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02108

Parameter Name: C02108 Program status		Data type: UNSIGNED_8 Index: 22467 _d = 57C3 _h
Selection list (read only)		
1	Program stopped	
0	Program is running	
2	Program stopped at breakpoint	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02109

Parameter Name: C02109 Program runtime		Data type: UNSIGNED_16 Index: 22466 _d = 57C2 _h
Display range (min. value unit max. value)		
0	μs	65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02110

Parameter Name: C02110 User code memory load		Data type: UNSIGNED_32 Index: 22465 _d = 57C1 _h
From software version V2.0 onwards		
Display range (min. value unit max. value)		
0	%	100
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02111

Parameter Name: C02111 Resp. to task overflow		Data type: UNSIGNED_8 Index: 22464 _d = 57C0 _h
From software version V5.0		
Response to an application or user task overflow.		
Selection list (Lenze setting printed in bold)		
1	Error	
3	Quick stop by trouble	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02112

Parameter Name: C02112 B. code: Read non-vol. memory		Data type: UNSIGNED_32 Index: 22463 _d = 57BF _h
From software version V9.0		
Display range (min. value unit max. value)		
0	%	1000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02113

Parameter Name: C02113 Program name		Data type: VISIBLE_STRING Index: 22462 _d = 57BE _h
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 32

C02119

Parameter Name: C02119 Active target ID		Data type: UNSIGNED_32 Index: 22456 _d = 57B8 _h
From software version V9.0		
Display range (min. value unit max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02121

Parameter Name: C02121 Runtime ApplicationTask		Data type: UNSIGNED_32 Index: 22454 _d = 57B6 _h
▶ Runtime measurement		
Display range (min. value unit max. value)		
0	μs	3600000000
Subcodes		Info
C02121/1		Curr. runtime ApplicationTask
C02121/2		Max. runtime ApplicationTask
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02122

Parameter Name: C02122 Runtime UserTask		Data type: UNSIGNED_32 Index: 22453 _d = 57B5 _h	
▶ Runtime measurement			
Display range (min. value unit max. value)			
0	μs	3600000000	
Subcodes		Info	
C02122/1		Curr. runtime UserTask	
C02122/2		Max. runtime UserTask	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02123

Parameter Name: C02123 Runtime IdleTask		Data type: UNSIGNED_32 Index: 22452 _d = 57B4 _h	
▶ Runtime measurement			
Display range (min. value unit max. value)			
0	μs	3600000000	
Subcodes		Info	
C02123/1		Curr. runtime IdleTask	
C02123/2		Max. runtime IdleTask	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02520

Parameter Name: C02520 Gearbox factor numerator: Motor		Data type: INTEGER_32 Index: 22054 _d = 5627 _h	
▶ Drive interface			
Setting range (min. value unit max. value)		Lenze setting	
1		2147483647	1
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02521

Parameter Name: C02521 Gearbox factor denom.: Motor		Data type: INTEGER_32 Index: 22053 _d = 5626 _h	
▶ Drive interface			
Setting range (min. value unit max. value)		Lenze setting	
1		2147483647	1
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02522

Parameter Name: C02522 Gearbox factor num.: Pos. enc.		Data type: INTEGER_32 Index: 22053 _d = 5625 _h	
▶ Drive interface			
Setting range (min. value unit max. value)		Lenze setting	
1		2147483647	1
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input checked="" type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02523

Parameter Name: C02523 Gearbox fac. denom.: Pos. enc.		Data type: INTEGER_32 Index: 22052 _d = 5624 _h
▶ Drive interface		
Setting range (min. value unit max. value)		Lenze setting
1		2147483647 1
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02524

Parameter Name: C02524 Feed constant		Data type: UNSIGNED_32 Index: 22051 _d = 5623 _h
▶ Drive interface		
Setting range (min. value unit max. value)		Lenze setting
0.0001	Unit/rev.	214748.3647 360.0000 Unit/rev.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02525

Parameter Name: C02525 Unit		Data type: UNSIGNED_32 Index: 22050 _d = 5622 _h
▶ Drive interface		
Selection list (Lenze setting printed in bold)		Info
0	User-defined	The text entered in C02526 is displayed for the unit.
1	Incr.	
2	µm	
3	mm	
4	m	
5	inch	
6	yard	
7	°	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02526

Parameter Name: C02526 User-defined unit		Data type: VISIBLE_STRING Index: 22049 _d = 5621 _h
User-defined unit which is displayed when C02525 ="0" is selected.		
▶ Drive interface		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 8

C02527

Parameter Name: C02527 Motor mounting direction		Data type: UNSIGNED_32 Index: 22048 _d = 5620 _h
▶ Drive interface		
Selection list (Lenze setting printed in bold)		
0	Motor rotating CW	
1	Motor rotating CCW	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02528

Parameter Name: C02528 Traversing range		Data type: UNSIGNED_32 Index: 22047 _d = 561F _h
		▶ Drive interface
Selection list (Lenze setting printed in bold)		
0	Unlimited	
1	Limited	
2	Modulo	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02529

Parameter Name: C02529 Position encoder mounting dir.		Data type: UNSIGNED_32 Index: 22046 _d = 561E _h
		▶ Drive interface
Selection list (Lenze setting printed in bold)		
0	Encoder rotating CW	
1	Encoder rotating CCW	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02530

Parameter Name: C02530 Active function state		Data type: INTEGER_32 Index: 22045 _d = 561D _h
Displays the basic drive function that currently controls the drive.		▶ Basic drive functions: Internal state machine
Selection list (read only)		
0	Program stopped	
1	Initial/boot state active	
2	Torque follower active	
3	Speed follower active	
4	Position follower active	
5	Setpoint follower active	
6	Positioning active	
7	Homing active	
8	Manual jog active	
9	Brake test active	
10	Drive at standstill	
11	Drive is stopped	
12	Quick stop active	
13	Reserve 1	
14	Controller is not ready	
15	Initialisation	
16	Error	
17	Encoderless manual jog active	
18	Pole position identification active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02531

Parameter Name: C02531 Gearbox factors (decimal)		Data type: UNSIGNED_32 Index: 22044 _d = 561C _h
<p>Note: In subcode 3 the effective gearbox factor resulting from the motor and the load is displayed if a separate position encoder is configured and the position control is activated (C02570="2"). For a different encoder configuration (without a separate position encoder) the value "1" is shown in subcode 3.</p> <p style="text-align: right;">▶ Drive interface</p>		
Display range (min. value unit max. value)		
0.000		2147483.647
Subcodes		Info
C02531/1		Motor gearbox factor (dec.)
C02531/2		Pos. enc. gearbox factor (dec.)
C02531/3		Effective gearbox factor (dec.)
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02532

Parameter Name: C02532 Resolution of a unit		Data type: UNSIGNED_32 Index: 22043 _d = 561B _h
▶ Drive interface		
Display range (min. value unit max. value)		
0.0000	Incr./unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02533

Parameter Name: C02533 Time unit		Data type: UNSIGNED_32 Index: 22042 _d = 561A _h
▶ Drive interface		
Selection list (read only)		
2 s		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02534

Parameter Name: C02534 Used time unit		Data type: VISIBLE_STRING Index: 22041 _d = 5619 _h
Display of the time unit as a character string		
▶ Drive interface		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 8

C02535

Parameter Name: C02535 Used unit		Data type: VISIBLE_STRING Index: 22040 _d = 5618 _h
Display of the unit set in C02525 and C02526 as a character string		
▶ Drive interface		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1 Character length: 8

C02536

Parameter Name: C02536 Cycle			Data type: UNSIGNED_32 Index: 22039 _d = 5617 _h
			▶ Drive interface
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit	214748.3647	360.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02537

Parameter Name: C02537 Speed unit			Data type: VISIBLE_STRING Index: 22038 _d = 5616 _h
			▶ Drive interface
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1 Character length: 16

C02538

Parameter Name: C02538 Acceleration unit			Data type: VISIBLE_STRING Index: 22037 _d = 5615 _h
			▶ Drive interface
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1 Character length: 16

C02539

Parameter Name: C02539 Max. presentable position			Data type: INTEGER_32 Index: 22036 _d = 5614 _h
			▶ Drive interface
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02540

Parameter Name: C02540 Max. presentable speed			Data type: INTEGER_32 Index: 22035 _d = 5613 _h
			▶ Drive interface
Display range (min. value unit max. value)			
-214748.3647	Unit/s	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02541

Parameter Name: C02541 Max. presentable acceleration			Data type: INTEGER_32 Index: 22034 _d = 5612 _h
			▶ Drive interface
Display range (min. value unit max. value)			
-214748.3647	Unit/s ²	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

14 Parameter reference

14.2 Parameter list | C02542

C02542

Parameter Name: C02542 Load reference speed			Data type: UNSIGNED_32 Index: 22033 _d = 5611 _h
			▶ Drive interface
Display range (min. value unit max. value)			
0.000	rpm	4294967.295	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02543

Parameter Name: C02543 Load reference torque			Data type: UNSIGNED_32 Index: 22032 _d = 5610 _h
			▶ Drive interface
Display range (min. value unit max. value)			
0.000	Nm	4294967.295	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02544

Parameter Name: C02544 Reference speed			Data type: INTEGER_32 Index: 22031 _d = 560F _h
From software version V1.5			▶ Drive interface
Display range (min. value unit max. value)			
-214748.3647	Unit/s	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02545

Parameter Name: C02545 Reference S-ramp time			Data type: UNSIGNED_32 Index: 22030 _d = 560E _h
From software version V7.0			▶ Drive interface
Setting range (min. value unit max. value)		Lenze setting	
0.000	s	2147483.647	0.001 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02547

Parameter Name: C02547 DI_dnState			Data type: INTEGER_32 Index: 22028 _d = 560C _h
Bit coded status of the drive interface .			
Display range (min. value unit max. value)			
-2147483648		2147483647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02548

Parameter Name: C02548 DI_bErrors		Data type: UNSIGNED_32 Index: 22027 _d = 560B _h
Display of the digital error signals of the drive interface .		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02548/1	DI_bResetError1	
C02548/2	DI_bResetError2	
C02548/3	DI_bResetError3	
C02548/4	DI_bSetExternError	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02549

Parameter Name: C02549 Drive interface: Signals		Data type: UNSIGNED_32 Index: 22026 _d = 560A _h
Display of the digital signals of the drive interface .		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02549/1	DI_bSetClnh	
C02549/2	Reserved	
C02549/3	Reserved	
C02549/4	DI_bSwitchOn	
C02549/5	Reserved	
C02549/6	DI_bReady	
C02549/7	DI_bFailActive	
C02549/8	DI_bImpActive	
C02549/9	DI_bClnhActive	
C02549/10	DI_bWarningActive	
C02549/11	DI_bUVDetected	
C02549/12	DI_bOVDetected	
C02549/13	DI_bMainSupplyOk	
C02549/14	DI_bReadyToSwitchOn	
C02549/15	DI_bOperationEnabled	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02550

Parameter Name: C02550 Setpoint interpolation		Data type: UNSIGNED_32 Index: 22025 _d = 5609 _h
▶ Motor interface		
Selection list		
0	Off	
1	On	
Subcodes	Lenze setting	Info
C02550/1	1: On	Position setpoint interpolat.
C02550/2	1: On	Speed setpoint interpolat.
C02550/3	1: On	Torque setpoint interpolat.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02552

Parameter Name: C02552 Position setpoint (mctrl)		Data type: INTEGER_32 Index: 22023 _d = 5607 _h
▶ Motor interface		
Display range (min. value unit max. value)		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02553

Parameter Name: C02553 Position controller gain		Data type: UNSIGNED_32 Index: 22022 _d = 5606 _h
▶ Motor interface		
Setting range (min. value unit max. value)		Lenze setting
0.00	1/s	1000.00
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		20.00 1/s Scaling factor: 100

C02554

Parameter Name: C02554 Position controller reset time		Data type: UNSIGNED_32 Index: 22021 _d = 5605 _h
▶ Motor interface		
Setting range (min. value unit max. value)		Lenze setting
0.001	s	60.000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		60.000 s Scaling factor: 1000

C02555

Parameter Name: C02555 D component position controller		Data type: UNSIGNED_32 Index: 22020 _d = 5604 _h
▶ Motor interface		
Setting range (min. value unit max. value)		Lenze setting
0.000		100.000
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		0.000 Scaling factor: 1000

C02556

Parameter Name: C02556 Pos. contr. limitation			Data type: INTEGER_32 Index: 22019 _d = 5603 _h
▶ Motor interface			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s	214748.3647	214748.3647 Unit/s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02557

Parameter Name: C02557 Phase controller output			Data type: INTEGER_32 Index: 22018 _d = 5602 _h
▶ Motor interface			
Display range (min. value unit max. value)			
-214748.3647	Unit/s	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02558

Parameter Name: C02558 Pos. contr. output			Data type: INTEGER_32 Index: 22017 _d = 5601 _h
▶ Motor interface			
Display range (min. value unit max. value)			
-214748.3647	Unit/s	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02559

Parameter Name: C02559 Internal torque limits			Data type: INTEGER_32 Index: 22016 _d = 5600 _h
▶ Motor interface			
Display range (min. value unit max. value)			
-200.00	%	200.00	
Subcodes		Info	
C02559/1		Upper int. torque limit	
C02559/2		Lower int. torque limit	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02560

Parameter Name: C02560 Messages - motor interface			Data type: UNSIGNED_32 Index: 22015 _d = 55FF _h
▶ Motor interface			
Display range (min. value unit max. value)			
0		4294967295	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02561

Parameter Name: C02561 Speed feedforw. control gain		Data type: INTEGER_32 Index: 22014 _d = 55FE _h	
From software version V1.5			
Percentage reduction of the speed feedforward control of the profile generator			
<ul style="list-style-type: none"> • Required in some applications if a 100 % speed feedforward control causes overshoots. • Only effective for the basic functions "Positioning", "Homing" and "Manual jog". 			
▶ Motor interface			
Setting range (min. value unit max. value)		Lenze setting	
0.00	%	200.00	100.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100	

C02562

Parameter Name: C02562 Filter time constant		Data type: UNSIGNED_32 Index: 22013 _d = 55FD _h	
From software version V7.0			
▶ Motor interface			
Setting range (min. value unit max. value)		Lenze setting	
0.000	s	60.000	0.002 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000	

C02564

Parameter Name: C02564 Service code		Data type: BITFIELD_8 Index: 22011 _d = 55FB _h	
From software version V9.0			
▶ Motor interface			
Setting range		Lenze setting	
0x00		0xFF	0x00 (decimal: 0)
Value is bit-coded: (<input checked="" type="checkbox"/> = bit set)		Info	
Bit 0 <input type="checkbox"/>	Option 0		
Bit 1 <input type="checkbox"/>	Option 1		
Bit 2 <input type="checkbox"/>	Option 2		
Bit 3 <input type="checkbox"/>	Option 3		
Bit 4 <input type="checkbox"/>	Option 4		
Bit 5 <input type="checkbox"/>	Option 5		
Bit 6 <input type="checkbox"/>	Option 6		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02567

Parameter Name: C02567 Control mode		Data type: UNSIGNED_32 Index: 22008 _d = 55F8 _h	
▶ Motor interface			
Selection list (read only)			
0	Position control		
1	closed-loop speed control		
2	Closed-loop torque control		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02568

Parameter Name: C02568 Motor interface: % signals		Data type: INTEGER_32 Index: 22007 _d = 55F7 _h
Display of the scaled signals of the motor interface .		
Display range (min. value unit max. value)		
-200.00	%	200.00
Subcodes	Info	
C02568/1	MI_dnPosCtrlAdaptLoad_n	
C02568/2	MI_dnPosCtrlAdaptMotor_n	
C02568/3	MI_dnSpeedCtrlAdapt_n	
C02568/4	MI_dnTorqueHighLimit_n	
C02568/5	MI_dnTorqueLowLimit_n	
C02568/6	MI_dnTorqueCtrlAdapt_n	
C02568/7	MI_dnFluxSetpoint_n	
C02568/8	MI_dnInertiaAdapt_n	
C02568/9	MI_dnBoostSet_n	
C02568/10	MI_dnTorqueAdd_n	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02569

Parameter Name: C02569 Motor interface.: Dig. signals		Data type: UNSIGNED_32 Index: 22006 _d = 55F6 _h
Display of the digital signals of the motor interface .		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02569/1	Reserved	
C02569/2	MI_bResetSpeedCtrlIntegrator	
C02569/3	MI_bLimitationActive	
C02569/4	MI_bPosCtrlLimited	
C02569/5	MI_bSpeedSetPointLimited	
C02569/6	MI_bSpeedCtrlLimited	
C02569/7	MI_bTorqueSetpointLimited	
C02569/8	MI_bCurrentSetpointLimited	
C02569/9	MI_bSpeedBelowC19	
C02569/10	MI_bSpeedFollowingError	
C02569/11	MI_bMotorOverloadWarning	
C02569/12	MI_bMotorOrientationInverse	
C02569/13	MI_bFlyingSyncBusy	
C02569/14	MI_bClampsActive	
C02569/15	MI_bMagnetisationFinished	
C02569/16	MI_bFlyingSyncBlocked	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02570

Parameter Name: C02570 Position control structure		Data type: UNSIGNED_32 Index: 22005 _d = 55F5 _h
Chapter " Controller configuration " provides you with more information on parameter setting. ▶ Encoder evaluation		
Selection list (Lenze setting printed in bold)		Info
1	Phase controller is active	Motor encoder selection is effected in C00495 .
2	Position controller active (<= FW V5.xx)	Position controller selection is effected in C00490 .
3	Position controller is active	Position controller selection is effected in C00490 .
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02571

Parameter Name: C02571 Source - actual position		Data type: UNSIGNED_32 Index: 22004 _d = 55F4 _h
This code is for device-internal use only and must not be written to by the user!		

C02572

Parameter Name: C02572 Speed setpoint (enc. eval.)		Data type: INTEGER_32 Index: 22003 _d = 55F3 _h
▶ Encoder evaluation		
Display range (min. value unit max. value)		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02573

Parameter Name: C02573 Position setpoint (enc. eval.)		Data type: INTEGER_32 Index: 22002 _d = 55F2 _h
▶ Encoder evaluation		
Display range (min. value unit max. value)		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02574

Parameter Name: C02574 Actual speed (enc. eval.)		Data type: INTEGER_32 Index: 22001 _d = 55F1 _h
▶ Encoder evaluation		
Display range (min. value unit max. value)		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02575

Parameter Name: C02575 Actual position (enc. eval.)			Data type: INTEGER_32 Index: 22000 _d = 55F0 _h
▶ Encoder evaluation			
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02576

Parameter Name: C02576 Following error			Data type: INTEGER_32 Index: 21999 _d = 55EF _h
▶ Encoder evaluation			
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02577

Parameter Name: C02577 External actual position			Data type: INTEGER_32 Index: 21998 _d = 55EE _h
▶ Encoder evaluation			
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02578

Parameter Name: C02578 Offset actual pos. value/setp.			Data type: INTEGER_32 Index: 21997 _d = 55ED _h
▶ Encoder evaluation			
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02579

Parameter Name: C02579 Encoder eval.: Dig. signals			Data type: UNSIGNED_32 Index: 21996 _d = 55EC _h
Display of the digital signals of the encoder evaluation .			
Selection list (read only)			
0	FALSE		
1	TRUE		
Subcodes		Info	
C02579/1		FDB_bResolverError	
C02579/2		FDB_bSinCosSignalError	
C02579/3		FDB_bEncoderComError	
C02579/4		FDB_bResetPosFollowingError	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02580

Parameter Name:		Data type: UNSIGNED_32 Index: 21995 _d = 55EB _h	
C02580 Operating mode brake		▶ Basic function " Brake control "	
Selection list (Lenze setting printed in bold)			
0	Brake control off		
1	Directly with brake module		
2	Autom. with brake module		
11	Directly - external switching		
12	Autom. - external switching		
22	Autom. - DC brake		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02581

Parameter Name:		Data type: INTEGER_32 Index: 21994 _d = 55EA _h	
C02581 Threshold - brake activation		▶ Basic function " Brake control "	
Setting range (min. value unit max. value)		Lenze setting	
0	rpm	50000	50 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02582

Parameter Name:		Data type: UNSIGNED_32 Index: 21993 _d = 55E9 _h	
C02582 Brake resp. to pulse inhibit		▶ Basic function " Brake control "	
Selection list (Lenze setting printed in bold)			
0	Activate the brake immediately		
1	Activate brake when n < nmin		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02583

Parameter Name:		Data type: UNSIGNED_32 Index: 21992 _d = 55E8 _h	
C02583 Status input monitoring		▶ Basic function " Brake control "	
Selection list (Lenze setting printed in bold)			
0	Not active		
1	Active		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02585

Parameter Name: C02585 Brake control polarity		Data type: UNSIGNED_32 Index: 21990 _d = 55E6 _h	
▶ Basic function " Brake control "			
Selection list (Lenze setting printed in bold)			
0	Not inverted		
1	Inverted		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02586

Parameter Name: C02586 Starting torque 1		Data type: INTEGER_32 Index: 21989 _d = 55E5 _h	
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)		Lenze setting	
-21474836.47	Nm	21474836.47	0.00 Nm
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 100	

C02587

Parameter Name: C02587 Starting torque 2		Data type: INTEGER_32 Index: 21988 _d = 55E4 _h	
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)		Lenze setting	
-21474836.47	Nm	21474836.47	0.00 Nm
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 100	

C02588

Parameter Name: C02588 Source of starting torque		Data type: UNSIGNED_32 Index: 21987 _d = 55E3 _h	
▶ Basic function " Brake control "			
Selection list (Lenze setting printed in bold)			
0	Starting torque 1/2		
1	Stopping value		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02589

Parameter Name: C02589 Brake closing time		Data type: UNSIGNED_32 Index: 21986 _d = 55E2 _h	
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)		Lenze setting	
0	ms	60000	100 ms
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02590

Parameter Name: C02590 Brake opening time			Data type: UNSIGNED_32 Index: 21985 _d = 55E1 _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0	ms	60000	100 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02591

Parameter Name: C02591 Waiting time - state monitoring			Data type: UNSIGNED_32 Index: 21984 _d = 55E0 _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0	ms	60000	100 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02593

Parameter Name: C02593 Waiting time - brake activation			Data type: UNSIGNED_32 Index: 21982 _d = 55DE _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0.000	s	1000.000	0.000 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02594

Parameter Name: C02594 Test torque			Data type: INTEGER_32 Index: 21981 _d = 55DD _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
-21474836.47	Nm	21474836.47	0.00 Nm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02595

Parameter Name: C02595 Permissible angle of rotation			Data type: INTEGER_32 Index: 21980 _d = 55DC _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0	°	36000	5 °
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02596

Parameter Name: C02596 Grinding speed			Data type: INTEGER_32 Index: 21979 _d = 55DB _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0	rpm	300	100 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02597

Parameter Name: C02597 Accel./decel. time - grinding			Data type: UNSIGNED_32 Index: 21978 _d = 55DA _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0.000	s	60.000	1.000 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02598

Parameter Name: C02598 Grinding ON time			Data type: UNSIGNED_32 Index: 21977 _d = 55D9 _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0.2	s	2.0	0.5 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02599

Parameter Name: C02599 Grinding OFF time			Data type: UNSIGNED_32 Index: 21976 _d = 55D8 _h
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0.2	s	2.0	0.5 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02600

Parameter Name: C02600 Acceleration time feedf. control			Data type: UNSIGNED_32 Index: 21975 _d = 55D7 _h
From software version V3.0			
▶ Basic function " Brake control "			
Setting range (min. value unit max. value)			Lenze setting
0.000	s	1000.000	0.000 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02601

Parameter Name: C02601 Ref. for Accel. time of brake		Data type: UNSIGNED_32 Index: 21974 _d = 55D6 _h
From software version V3.0		▶ Basic function " Brake control "
Selection list (Lenze setting printed in bold)		
0	Motor reference value	
1	Current starting value	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02602

Parameter Name: C02602 Source for feedf. control brake		Data type: UNSIGNED_32 Index: 21973 _d = 55D5 _h
From software version V3.0		▶ Basic function " Brake control "
Selection list (Lenze setting printed in bold)		
0	Torque	
1	Speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02603

Parameter Name: C02603 Threshold 1 for opening brake		Data type: INTEGER_32 Index: 21972 _d = 55D4 _h
From software version V3.0		▶ Basic function " Brake control "
Setting range (min. value unit max. value)		Lenze setting
-50000	rpm	50000
		0 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02604

Parameter Name: C02604 Threshold 2 for opening brake		Data type: INTEGER_32 Index: 21971 _d = 55D3 _h
From software version V3.0		▶ Basic function " Brake control "
Setting range (min. value unit max. value)		Lenze setting
-50000	rpm	50000
		0 rpm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02605

Parameter Name: C02605 Brake test - time		Data type: UNSIGNED_16 Index: 21970 _d = 55D2 _h
From software version V10.0		
Setting range (min. value unit max. value)		
0.001	s	65.535
Subcodes	Lenze setting	Info
C02605/1	1.024 s	Brake test - ramp-up time
C02605/2	4.000 s	Brake test - constant ph. time
C02605/3	1.024 s	Brake test - ramp-down time
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02606

Parameter Name: C02606 Minimum starting torque		Data type: INTEGER_32 Index: 21969 _d = 55D1 _h
From software version V15.0 onwards		
Minimum starting torque that is built when the holding brake is released.		
▶ Brake control		
Setting range (min. value unit max. value)		Lenze setting
-21474836.47	Nm	21474836.47 0.00 Nm
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02607

Parameter Name: C02607 BRK_dnState		Data type: INTEGER_32 Index: 21968 _d = 55D0 _h
Bit coded status of the basic function " Brake control ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02608

Parameter Name: C02608 BRK_dnTorqueAdd_n		Data type: INTEGER_32 Index: 21967 _d = 55CF _h
Display of the additive torque value of the basic function " brake control ".		
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02609

Parameter Name:		Data type: UNSIGNED_32 Index: 21966 _d = 55CE _h	
C02609 Brake control: Dig. signals			
Display of the digital signals of the basic function " brake control ".			
Selection list (read only)			
0	FALSE		
1	TRUE		
Subcodes		Info	
C02609/1		BRK_bReleaseBrake	
C02609/2		BRK_bStartingTorque2	
C02609/3		BRK_bBrakeApplied	
C02609/4		BRK_bBrakeTest	
C02609/5		BRK_bBrakeGrindIn	
C02609/6		BRK_bReleaseBrakeOut	
C02609/7		BRK_bBrakeReleased	
C02609/8		BRK_bError	
C02609/9		BRK_bClnhActive	
C02609/10		BRK_bDisableStop	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02610

Parameter Name:		Data type: UNSIGNED_32 Index: 21965 _d = 55CD _h	
C02610 Deceleration time for stop			
▶ Basic function " Stop "			
Setting range (min. value unit max. value)		Lenze setting	
0.000	s	1000.000	1.000 s
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1000	

C02611

Parameter Name:		Data type: UNSIGNED_32 Index: 21964 _d = 55CC _h	
C02611 S-ramp time for stop			
▶ Basic function " Stop "			
Setting range (min. value unit max. value)		Lenze setting	
0.000	s	10.000	0.100 s
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1000	

C02612

Parameter Name:		Data type: UNSIGNED_32 Index: 21963 _d = 55CB _h	
C02612 Ref. for decel. time of stop			
▶ Basic function " Stop "			
Selection list (Lenze setting printed in bold)			
0	Motor reference speed (C00011)		
1	Current speed		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02616

Parameter Name: C02616 STP_dnState		Data type: INTEGER_32 Index: 21959 _d = 55C7 _h
Bit coded status of the basic function " Stop ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02617

Parameter Name: C02617 STP_bStopActive		Data type: UNSIGNED_32 Index: 21958 _d = 55C6 _h
Status of the basic function " Stop ".		
Selection list (read only)		
0	Normal stop not active	
1	Normal stop active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02619

Parameter Name: C02619 Quick stop: Dig. signals		Data type: UNSIGNED_32 Index: 21956 _d = 55C4 _h
Display of the digital signals of the basic function " Quick stop ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02619/1		QSP_bActivate1
C02619/2		QSP_bActivate2
C02619/3		QSP_bActivate3
C02619/4		QSP_bActive
C02619/5		QSP_bActivateDCBrake
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02620

Parameter Name: C02620 Manual jog: Speed 1		Data type: INTEGER_32 Index: 21955 _d = 55C3 _h
▶ Basic function " Manual jog "		
Setting range (min. value unit max. value)		Lenze setting
0.0000	Unit/s	214748.3647 360.0000 Unit/s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02621

Parameter Name: C02621 Manual jog: Speed 2			Data type: INTEGER_32 Index: 21954 _d = 55C2 _h
▶ Basic function " Manual jog "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s	214748.3647	720.0000 Unit/s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02622

Parameter Name: C02622 Manual jog: Acceleration			Data type: INTEGER_32 Index: 21953 _d = 55C1 _h
▶ Basic function " Manual jog "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s ²	214748.3647	360.0000 Unit/s²
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02623

Parameter Name: C02623 Manual jog: Deceleration			Data type: INTEGER_32 Index: 21952 _d = 55C0 _h
▶ Basic function " Manual jog "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s ²	214748.3647	1440.0000 Unit/s²
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02624

Parameter Name: C02624 Manual jog: S-ramp time			Data type: UNSIGNED_32 Index: 21951 _d = 55BF _h
▶ Basic function " Manual jog "			
Setting range (min. value unit max. value)			Lenze setting
0.000	s	10.000	0.100 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02625

Parameter Name: C02625 Manual jog: Step size			Data type: INTEGER_32 Index: 21950 _d = 55BE _h
From software version V5.0 Step distance for " Manual jog with step limitation " mode.			
▶ Basic function " Manual jog "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit	214748.3647	360.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02626

Parameter Name: C02626 Manual jog:Index Stop position		Data type: INTEGER_32 Index: 21949 _d = 55BD _h
<p>From software version V5.0</p> <p>Selection of the breakpoint positions for "Manual jog with breakpoint" mode.</p> <ul style="list-style-type: none"> In connection with a function block instance of type L_PosPositionerTable: The index [1...75] of the table position in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used. In connection with a function block instance of type L_PosProfileTable: The index [1...4] of the profile data set in the VTPOS table has to be specified, which contains the intermediate stop position x that is to be used. <p style="text-align: right;">▶ Basic function "Manual jog"</p>		
Setting range (min. value unit max. value)		
0		75
Subcodes	Lenze setting	Info
C02626/1	0	Index of the breakpoint positions 1 ... 16
C02626/...		
C02626/16		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02627

Parameter Name: C02627 Manual jog:Selected Stop position		Data type: INTEGER_32 Index: 21948 _d = 55BC _h
<p>From software version V5.0</p> <p>Display of the breakpoint positions selected via C02626/1...16 for "Manual jog with breakpoints".</p> <p style="text-align: right;">▶ Basic function "Manual jog"</p>		
Display range (min. value unit max. value)		
-214748.3648	Unit	214748.3647
Subcodes		Info
C02627/1		Breakpoint position 1 ... 16
C02627/...		
C02627/16		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02637

Parameter Name: C02637 MAN_dnSpeedOverride_n		Data type: INTEGER_32 Index: 21938 _d = 55B2 _h
<p>From software version V5.0</p> <p>Display of the speed override for the basic function "Manual jog".</p>		
Display range (min. value unit max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02638

Parameter Name: C02638 Manual jog: Status		Data type: INTEGER_32 Index: 21937 _d = 55B1 _h
Status of the basic function " Manual jog ".		
Display range (min. value unit max. value)		
0		8
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02639

Parameter Name: C02639 Manual jog: Dig. signals		Data type: UNSIGNED_32 Index: 21936 _d = 55B0 _h
Display of the digital signals of the basic function " Manual jog ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02639/1	MAN_bEnable	
C02639/2	MAN_bJogPositive	
C02639/3	MAN_bJogNegative	
C02639/4	MAN_bActivateJogSpeed2	
C02639/5	MAN_bReleaseLimitSwitch	
C02639/6	MAN_bEnabled	
C02639/7	MAN_bActive	
C02639/8	MAN_bStepMode	
C02639/9	MAN_bIntermediateStopMode	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

14 Parameter reference

14.2 Parameter list | C02640

C02640

14 Parameter reference

14.2 Parameter list | C02640

Parameter Name: C02640 Homing mode		Data type: UNSIGNED_32 Index: 21935 _d = 55AF _h
Selection of the homing mode.		▶ Basic function " Homing "
Selection list (Lenze setting printed in bold)	Info	
0	cw_Rn_TP	Positive direction - via home mark - to TP ▶ Process description
1	ccw_Rn_TP	Negative direction - via home mark - to TP ▶ Process description
2	cw_Lp_ccw_Rn_TP	Pos. direction - reversing to limit switch - via home mark - to TP ▶ Process description
3	ccw_Ln_cw_Rn_TP	Neg. direction - reversing to limit switch - via home mark - to TP ▶ Process description
4	cw_Rp_ccw_Rn_TP	Pos. direction - reversing to home mark - to TP ▶ Process description
5	ccw_Rp_cw_Rn_TP	Neg. direction - reversing to home mark - to TP ▶ Process description
8	cw_TP	Positive direction to touch probe ▶ Process description
9	ccw_TP	Negative direction to touch probe ▶ Process description
10	cw_Lp_ccw_TP	Pos. direction - reversing to limit switch - to TP ▶ Process description
11	ccw_Ln_cw_TP	Neg. direction - reversing to limit switch - to TP ▶ Process description
12	cw_Lp	Positive direction to limit switch ▶ Process description
13	ccw_Ln	Negative direction to limit switch ▶ Process description
14	cw_Trq_Lim	Positive direction to torque limit ▶ Process description
15	ccw_Trq_Lim	Negative direction to torque limit ▶ Process description
100	Directly set reference	Directly set reference ▶ Process description
1001	DS402 homing method 01	From software version V3.0 also the homing methods in accordance with DS402 are provided. ▶ Overview of DS402 homing modes

Parameter Name: C02640 Homing mode		Data type: UNSIGNED_32 Index: 21935 _d = 55AF _h
1002	DS402 homing method 02	
1003	DS402 homing method 03	
1004	DS402 homing method 04	
1005	DS402 homing method 05	
1006	DS402 homing method 06	
1007	DS402 homing method 07	
1008	DS402 homing method 08	
1009	DS402 homing method 09	
1010	DS402 homing method 10	
1011	DS402 homing method 11	
1012	DS402 homing method 12	
1013	DS402 homing method 13	
1014	DS402 homing method 14	
1015	DS402 homing method 15	
1016	DS402 homing method 16	
1017	DS402 homing method 17	
1018	DS402 homing method 18	
1019	DS402 homing method 19	
1020	DS402 homing method 20	
1021	DS402 homing method 21	
1022	DS402 homing method 22	
1023	DS402 homing method 23	
1024	DS402 homing method 24	
1025	DS402 homing method 25	
1026	DS402 homing method 26	
1027	DS402 homing method 27	
1028	DS402 homing method 28	
1029	DS402 homing method 29	
1030	DS402 homing method 30	
1031	DS402 homing method 31	
1032	DS402 homing method 32	
1033	DS402 homing method 33	
1034	DS402 homing method 34	
1035	DS402 homing method 35	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02641

Parameter Name: C02641 Action after detect Home position		Data type: UNSIGNED_32 Index: 21934 _d = 55AE _h	
From software version V4.0		▶ Basic function " Homing "	
Selection list (Lenze setting printed in bold)			
0	Move absolute on target position		
1	Move relative by Target position		
2	Stop immediately		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02642

Parameter Name: C02642 Home position		Data type: INTEGER_32 Index: 21933 _d = 55AD _h	
		▶ Basic function " Homing "	
Setting range (min. value unit max. value)		Lenze setting	
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02643

Parameter Name: C02643 Homing: Target position		Data type: INTEGER_32 Index: 21932 _d = 55AC _h	
		▶ Basic function " Homing "	
Setting range (min. value unit max. value)		Lenze setting	
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02644

Parameter Name: C02644 Homing: Speed 1		Data type: INTEGER_32 Index: 21931 _d = 55AB _h	
		▶ Basic function " Homing "	
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit/s	214748.3647	360.0000 Unit/s
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02645

Parameter Name: C02645 Homing: Acceleration 1		Data type: INTEGER_32 Index: 21930 _d = 55AA _h	
		▶ Basic function " Homing "	
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit/s ²	214748.3647	720.0000 Unit/s²
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02646

Parameter Name: C02646 Homing: Speed 2			Data type: INTEGER_32 Index: 21929 _d = 55A9 _h
▶ Basic function " Homing "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s	214748.3647	0.0000 Unit/s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02647

Parameter Name: C02647 Homing: Acceleration 2			Data type: INTEGER_32 Index: 21928 _d = 55A8 _h
▶ Basic function " Homing "			
Setting range (min. value unit max. value)			Lenze setting
0.0000	Unit/s ²	214748.3647	360.0000 Unit/s²
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10000

C02648

Parameter Name: C02648 Homing: S-ramp time			Data type: INTEGER_32 Index: 21927 _d = 55A7 _h
▶ Basic function " Homing "			
Setting range (min. value unit max. value)			Lenze setting
0	ms	10000	100 ms
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02649

Parameter Name: C02649 Homing: Torque limit			Data type: INTEGER_32 Index: 21926 _d = 55A6 _h
▶ Basic function " Homing "			
Setting range (min. value unit max. value)			Lenze setting
0.00	%	200.00	10.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02650

Parameter Name: C02650 Homing: Blocking time			Data type: UNSIGNED_32 Index: 21925 _d = 55A5 _h
▶ Basic function " Homing "			
Setting range (min. value unit max. value)			Lenze setting
0.000	s	120.000	1.000 s
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02651

Parameter Name: C02651 Homing: TP configuration		Data type: UNSIGNED_32 Index: 21924 _d = 55A4 _h	
▶ Basic function " Homing "			
Setting range (min. value unit max. value)		Lenze setting	
0		4294967295	16
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1			

C02652

Parameter Name: C02652 Ref. pos. after mains switching		Data type: UNSIGNED_32 Index: 21923 _d = 55A3 _h	
▶ Basic function " Homing "			
Selection list (Lenze setting printed in bold)			
0	Delete		
1	Retain		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1			

C02653

Parameter Name: C02653 Max. rot. ang. aft. mns. swtch.		Data type: INTEGER_32 Index: 21922 _d = 55A2 _h	
▶ Basic function " Homing "			
Setting range (min. value unit max. value)		Lenze setting	
0	°	1000000	180 °
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 1			

C02655

Parameter Name: C02655 HM_dnSpeedOverride_n		Data type: INTEGER_32 Index: 21920 _d = 55A0 _h	
From software version V5.0			
Display of the speed override for the basic function " Homing ".			
Display range (min. value unit max. value)			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 100			

C02656

Parameter Name: C02656 Actual position (homing)		Data type: INTEGER_32 Index: 21919 _d = 559F _h	
▶ Basic function " Homing "			
Display range (min. value unit max. value)			
-214748.3647	Unit	214748.3647	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer	
Scaling factor: 10000			

C02657

Parameter Name: C02657 HM_dnState		Data type: INTEGER_32 Index: 21918 _d = 559E _h
Bit coded status of the basic function " Homing ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02658

Parameter Name: C02658 HM_dnHomePos_p		Data type: INTEGER_32 Index: 21917 _d = 559D _h
Display of the <i>HM_dnHomePos_p</i> input signal of the basic function " Homing ".		
Display range (min. value unit max. value)		
-214748.3647		214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02659

Parameter Name: C02659 Homing: Dig. signals		Data type: UNSIGNED_32 Index: 21916 _d = 559C _h
Display of the digital signals of the basic function " Homing ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02659/1	HM_bEnable	
C02659/2	HM_bActivateHoming	
C02659/3	HM_bHomingMark	
C02659/4	HM_bLoadHomePos	
C02659/5	HM_bResetHomePos	
C02659/6	HM_bEnabled	
C02659/7	HM_bActive	
C02659/8	HM_bDone	
C02659/9	HM_bHomePosAvailable	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02670

Parameter Name: C02670 Tolerance for POS_bActPosInTarget		Data type: INTEGER_32 Index: 21905 _d = 5591 _h
From software version V1.5 Tolerance window for actual value-based evaluation "Target position reached" (Output <i>POS_bActPosInTarget</i>)		
▶ Basic function " Positioning "		
Setting range (min. value unit max. value)		Lenze setting
0.0000	Unit	214748.3647
		0.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02671

Parameter Name: C02671 Tolerance for POS_bDriveInTarget		Data type: INTEGER_32 Index: 21904 _d = 5590 _h	
From software version V5.0 Tolerance window for actual value and setpoint-based evaluation "Drive in the target" (Output POS_bDriveInTarget) <p style="text-align: right;">▶ Basic function "Positioning"</p>			
Setting range (min. value unit max. value)		Lenze setting	
0.0001	Unit	214748.3647	2.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000	

C02672

Parameter Name: C02672 Hysteresis for POS_bDriveInTarget		Data type: INTEGER_32 Index: 21903 _d = 558F _h	
From software version V5.0 Hysteresis window for actual value and setpoint-based evaluation "Drive in the target" (Output POS_bDriveInTarget) <p style="text-align: right;">▶ Basic function "Positioning"</p>			
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit	214748.3647	1.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000	

C02673

Parameter Name: C02673 Activate DriveInTarget Modulo		Data type: UNSIGNED_32 Index: 21902 _d = 558E _h	
From software version V5.0 For actual value and setpoint-based evaluation "Drive in target" (output POS_bDriveInTarget): Definition how the modulo evaluation is to be carried out if the actual position value enters the tolerance and hysteresis window again. <p style="text-align: right;">▶ Basic function "Positioning"</p>			
Selection list (Lenze setting printed in bold)			
0	Only setpoint Cycle		
1	All cycles		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02674

Parameter Name: C02674 POS_dwActualProfileNumber		Data type: UNSIGNED_32 Index: 21901 _d = 558D _h	
Current profile of the basic function " Positioning ".			
Display range (min. value unit max. value)			
0		1000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02675

Parameter Name: C02675 POS_dnState		Data type: INTEGER_32 Index: 21900 _d = 558C _h
Bit coded status of the basic function " Positioning ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02676

Parameter Name: C02676 POS_dnProfileSpeed_s		Data type: INTEGER_32 Index: 21899 _d = 558B _h
Display of the max. speed of the current profile of the basic function " Positioning ".		
Display range (min. value unit max. value)		
-214748.3647		214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02677

Parameter Name: C02677 Positioning: % signals		Data type: INTEGER_32 Index: 21898 _d = 558A _h
Display of the scaled signals of the basic function " Positioning ".		
Display range (min. value unit max. value)		
-200.00	%	200.00
Subcodes		Info
C02677/1		POS_dnSpeedOverride_n
C02677/2		POS_dnAccOverride_n
C02677/3		POS_dnDecOverride_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02678

Parameter Name: C02678 Positioning: Pos. signals		Data type: INTEGER_32 Index: 21897 _d = 5589 _h
Display of the position signals of the basic function " Positioning ".		
Display range (min. value unit max. value)		
-214748.3647	Unit	214748.3647
Subcodes		Info
C02678/1		POS_dnSetPos_p
C02678/2		POS_dnProfileTarget_p
C02678/3		POS_dnActPosRelative_p
C02678/4		POS_dnSetPosRelative_p
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02679

Parameter Name: C02679 Positioning: Dig. signals		Data type: UNSIGNED_32 Index: 21896 _d = 5588 _h
Display of the digital signals of the basic function " Positioning ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02679/1	POS_bEnable	
C02679/2	POS_bStart	
C02679/3	POS_bAbort	
C02679/4	POS_bRestart	
C02679/5	POS_bEnableOverride	
C02679/6	POS_bDisableTP	
C02679/7	POS_bEnabled	
C02679/8	POS_bActive	
C02679/9	POS_bDone	
C02679/10	POS_bInTarget	
C02679/11	POS_bActPosInTarget	
C02679/12	POS_bDrivelnTarget	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02680

Parameter Name: C02680 Source position setpoint		Data type: UNSIGNED_32 Index: 21895 _d = 5587 _h
▶ Basic function " Positioning "		
Selection list (Lenze setting printed in bold)		
0	Position setpoint input	
1	From add. speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02681

Parameter Name: C02681 Source add. speed		Data type: UNSIGNED_32 Index: 21894 _d = 5586 _h
▶ Basic function " Positioning "		
Selection list (Lenze setting printed in bold)		
0	Add. speed input	
1	From position setpoint	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02685

Parameter Name: C02685 PF_dnMotorAcc_x		Data type: INTEGER_32 Index: 21890 _d = 5582 _h
Display of the motor acceleration of the basic function " Position follower ".		
Display range (min. value unit max. value)		
-7680000.0		7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02686

Parameter Name: C02686 PF_dnSpeedAdd1_s		Data type: INTEGER_32 Index: 21889 _d = 5581 _h
Display of the speed feedforward control value of the basic function " Position follower ".		
Display range (min. value unit max. value)		
-480000.0	rpm	480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02687

Parameter Name: C02687 Position follower: % signals		Data type: INTEGER_32 Index: 21888 _d = 5580 _h
Display of the scaled signals of the basic function " Position follower ".		
Display range (min. value unit max. value)		
-200.00	%	200.00
Subcodes		Info
C02687/1		PF_dnSpeedAdd2_n
C02687/2		PF_dnTorqueAdd_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02688

Parameter Name: C02688 PF_dnPositionSet_p		Data type: INTEGER_32 Index: 21887 _d = 557F _h
Display of the position signals of the basic function " Position follower ".		
Display range (min. value unit max. value)		
-214748.3648	Revolution	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02689

Parameter Name: C02689 Position follower: Dig. signals		Data type: UNSIGNED_32 Index: 21886 _d = 557E _h
Display of the digital signals of the basic function " Position follower ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02689/1		PF_bEnable
C02689/2		PF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02692

Parameter Name: C02692 SF_dnMotorAcc_x		Data type: INTEGER_32 Index: 21883 _d = 557B _h
Display of the motor acceleration of the basic function " Speed follower ".		
Display range (min. value unit max. value)		
-7680000.0		7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02693

Parameter Name: C02693 SF_dnSpeedAdd_s		Data type: INTEGER_32 Index: 21882 _d = 557A _h
Display of the additive speed setpoint of the basic function " Speed follower ".		
Display range (min. value unit max. value)		
-480000.0	rpm	480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02694

Parameter Name: C02694 Speed follower: % signals		Data type: INTEGER_32 Index: 21881 _d = 5579 _h
Display of the scaled signals of the basic function " Speed follower ".		
Display range (min. value unit max. value)		
-200.00	%	200.00
Subcodes		Info
C02694/1		SF_dnSpeedSet_n
C02694/2		SF_dnTorqueAdd_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02695

Parameter Name: C02695 Speed follower: Dig. signals		Data type: UNSIGNED_32 Index: 21880 _d = 5578 _h
Display of the digital signals of the basic function " Speed follower ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02695/1		SF_bEnable
C02695/2		SF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02698

Parameter Name: C02698 Torque follower: % signals		Data type: INTEGER_32 Index: 21877 _d = 5575 _h
Display of the scaled signals of the basic function " Torque follower ".		
Display range (min. value unit max. value)		
-200.00	%	200.00
Subcodes		Info
C02698/1		TF_TorqueSet_n
C02698/2		TF_dnSpeedHighLimit_n
C02698/3		TF_dnSpeedLowLimit_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02699

Parameter Name: C02699 Torque follower: Dig. signals		Data type: UNSIGNED_32 Index: 21876 _d = 5574 _h
Display of the digital signals of the basic function " Torque follower ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02699/1		TF_bEnable
C02699/2		TF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02700

Parameter Name: C02700 Software limits pos. effective		Data type: UNSIGNED_32 Index: 21875 _d = 5573 _h
▶ Basic function " Limiter "		
Selection list (Lenze setting printed in bold)		
0	Deactivated	
1	enabled	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02701

Parameter Name: C02701 Software limit positions		Data type: INTEGER_32 Index: 21874 _d = 5572 _h
▶ Basic function " Limiter "		
Setting range (min. value unit max. value)		
-214748.3647	Unit	214748.3647
Subcodes		Info
C02701/1	0.0000 Unit	Positive software limit position
C02701/2	0.0000 Unit	Negative software limit position
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02702

Parameter Name: C02702 Limitations effective		Data type: UNSIGNED_32 Index: 21873 _d = 5571 _h	
▶ Basic function " "Limiter" "			
Selection list (Lenze setting printed in bold)			
0	Deactivated		
1	enabled		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02703

Parameter Name: C02703 Max. speed		Data type: INTEGER_32 Index: 21872 _d = 5570 _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit/s	214748.3647	3600.0000 Unit/s
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02704

Parameter Name: C02704 Max. speed [rpm]		Data type: INTEGER_32 Index: 21871 _d = 556F _h	
▶ Basic function " "Limiter" "			
Display range (min. value unit max. value)			
0.0	rpm	214748364.7	
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10	

C02705

Parameter Name: C02705 Max. acceleration		Data type: INTEGER_32 Index: 21870 _d = 556E _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit/s ²	214748.3647	3600.0000 Unit/s²
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02706

Parameter Name: C02706 Min. S-ramp time		Data type: UNSIGNED_32 Index: 21869 _d = 556D _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)		Lenze setting	
0	ms	10000	100 ms
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02707

Parameter Name: C02707 Permissible direction of rot.		Data type: UNSIGNED_32 Index: 21868 _d = 556C _h
▶ Basic function " Limiter "		
Selection list (Lenze setting printed in bold)		
0	Positive and negative	
1	Positive only	
2	Negative only	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02708

Parameter Name: C02708 Limited speed		Data type: INTEGER_32 Index: 21867 _d = 556B _h
▶ Basic function " Limiter "		
Setting range (min. value unit max. value)		
0.0000	Unit/s	214748.3647
Subcodes	Lenze setting	Info
C02708/1	3600.0000 Unit/s	Limited speed 1 ... 4
C02708/2	7200.0000 Unit/s	
C02708/3	14400.0000 Unit/s	
C02708/4	28800.0000 Unit/s	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10000

C02709

Parameter Name: C02709 Limited speed [rpm]		Data type: INTEGER_32 Index: 21866 _d = 556A _h
▶ Basic function " Limiter "		
Display range (min. value unit max. value)		
0.0	rpm	214748364.7
Subcodes		Info
C02709/1		Limited speed 1 ... 4
C02709/2		
C02709/3		
C02709/4		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02710

Parameter Name: C02710 Delay lim. speed		Data type: UNSIGNED_32 Index: 21865 _d = 5569 _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)			
0.0000	Unit/s ²	214748.3647	
Subcodes	Lenze setting	Info	
C02710/1	0.0100 Unit/s ²	Delays for limited speed 1 ... 4	
C02710/2	0.0100 Unit/s ²		
C02710/3	0.0100 Unit/s ²		
C02710/4	0.0100 Unit/s ²		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02711

Parameter Name: C02711 S-ramp time lim. speed		Data type: UNSIGNED_32 Index: 21864 _d = 5568 _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)			
0	ms	10000	
Subcodes	Lenze setting	Info	
C02711/1	100 ms	S-ramp times for limited speed 1 ... 4	
C02711/2	100 ms		
C02711/3	100 ms		
C02711/4	100 ms		
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02712

Parameter Name: C02712 Decel. time lim. speed		Data type: UNSIGNED_32 Index: 21863 _d = 5567 _h	
▶ Basic function " "Limiter" "			
Display range (min. value unit max. value)			
0	ms	10000	
Subcodes		Info	
C02712/1		Deceleration times for limited speed 1 ... 4	
C02712/2			
C02712/3			
C02712/4			
<input checked="" type="checkbox"/> Read access		<input type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 1	

C02713

Parameter Name: C02713 Max. dist. manual control		Data type: UNSIGNED_32 Index: 21862 _d = 5566 _h	
▶ Basic function " "Limiter" "			
Setting range (min. value unit max. value)		Lenze setting	
0.0000	Unit	214748.3647	360.0000 Unit
<input checked="" type="checkbox"/> Read access		<input checked="" type="checkbox"/> Write access	
<input type="checkbox"/> CINH		<input type="checkbox"/> PLC STOP	
<input type="checkbox"/> No transfer		Scaling factor: 10000	

C02714

Parameter Name: C02714 Max. dist. manual jog [inc.]		Data type: UNSIGNED_32 Index: 21861 _d = 5565 _h
▶ Basic function " "Limiter" "		
Display range (min. value unit max. value)		
0	Incr.	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02715

Parameter Name: C02715 Limitation active		Data type: UNSIGNED_32 Index: 21860 _d = 5564 _h
▶ Basic function " "Limiter" "		
Selection list (read only)		
0	Deactivated	
1	enabled	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02716

Parameter Name: C02716 Resp. to limitation		Data type: UNSIGNED_32 Index: 21859 _d = 5563 _h
▶ Basic function " "Limiter" "		
Selection list		
1	Error	
2	Fault	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
0	No response	
Subcodes	Lenze setting	Info
C02716/1	6: Information	Resp. to rotation limitation
C02716/2	3: Quick stop by trouble	Resp. to SW lim. pos. exceeded
C02716/3	6: Information	Resp. to max. value exceeded
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02717

Parameter Name: C02717 LIM_dwControl		Data type: UNSIGNED_32 Index: 21858 _d = 5562 _h
Bit coded control word of the basic function " "Limiter" ".		
Display range (min. value unit max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02718

Parameter Name: C02718 LIM_dnState		Data type: INTEGER_32 Index: 21857 _d = 5561 _h
Status of the basic function " Limiter ".		
Display range (min. value unit max. value)		
0		1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02719

Parameter Name: C02719 Limiter: Dig. signals		Data type: UNSIGNED_32 Index: 21856 _d = 5560 _h
Display of the digital input signals of the basic function " Limiter ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02719/1	LIM_bLimitSwitchPositive	
C02719/2	LIM_bLimitSwitchNegative	
C02719/3	LIM_bActivateLimitedSpeed1	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02720

Parameter Name: C02720 observation software limit positions		Data type: UNSIGNED_32 Index: 21855 _d = 555F _h
From software version V4.0		► Basic function " Limiter "
Selection list (Lenze setting printed in bold)		
0	Based on set value	
1	Based on set and actual value	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02730

Parameter Name: C02730 Analog inputs: Gain		Data type: INTEGER_32 Index: 21845 _d = 5555 _h
Setting range (min. value unit max. value)		
-200.00	%	200.00
Subcodes		Info
C02730/1	100.00 %	Gain - analog input 1
C02730/2	100.00 %	Analog input 2: Gain
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02731

Parameter Name: C02731 Analog inputs: Offset			Data type: INTEGER_32 Index: 21844 _d = 5554 _h
Setting range (min. value unit max. value)			
-200.00	%	200.00	
Subcodes	Lenze setting	Info	
C02731/1	0.00 %	Offset - analog input 1	
C02731/2	0.00 %	Analog input 2: Offset	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02732

Parameter Name: C02732 Analog inputs: Dead band			Data type: INTEGER_32 Index: 21843 _d = 5553 _h
Setting range (min. value unit max. value)			
0.00	%	100.00	
Subcodes	Lenze setting	Info	
C02732/1	0.00 %	Dead band - analog input 1	
C02732/2	0.00 %	Analog input 2: Dead band	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02733

Parameter Name: C02733 Analog outputs: Gain			Data type: INTEGER_32 Index: 21842 _d = 5552 _h
Setting range (min. value unit max. value)			
-200.00	%	200.00	
Subcodes	Lenze setting	Info	
C02733/1	100.00 %	Gain - analog output 1	
C02733/2	100.00 %	Analog output 2: Gain	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02734

Parameter Name: C02734 Analog outputs: Offset			Data type: INTEGER_32 Index: 21841 _d = 5551 _h
Setting range (min. value unit max. value)			
-200.00	%	200.00	
Subcodes	Lenze setting	Info	
C02734/1	0.00 %	Offset - analog output 1	
C02734/2	0.00 %	Analog output 2: Offset	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02760

Parameter Name: C02760 Activate encoder		Data type: UNSIGNED_32 Index: 21815 _d = 5537 _h
From software version V7.0		► Encoder evaluation: Provision of the encoder signal of input X8
Selection list (Lenze setting printed in bold)		
0	Deactivated	
1	enabled	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02761

Parameter Name: C02761 Multiturn resolution		Data type: UNSIGNED_32 Index: 21814 _d = 5536 _h
From software version V7.0		► Encoder evaluation: Provision of the encoder signal of input X8
Display range (min. value unit max. value)		
0	Rev.	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02762

Parameter Name: C02762 Encoderpos		Data type: INTEGER_32 Index: 21813 _d = 5535 _h
From software version V7.0		► Encoder evaluation: Provision of the encoder signal of input X8
Display range (min. value unit max. value)		
-2147483647	Steps	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02763

Parameter Name: C02763 Encoderrev		Data type: INTEGER_32 Index: 21812 _d = 5534 _h
From software version V7.0		► Encoder evaluation: Provision of the encoder signal of input X8
Display range (min. value unit max. value)		
-2147483647	Steps	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02764

Parameter Name: C02764 Encoderspeed		Data type: INTEGER_32 Index: 21811 _d = 5533 _h
From software version V7.0		► Encoder evaluation: Provision of the encoder signal of input X8
Display range (min. value unit max. value)		
-214748364.7	rpm	214748364.7
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02765

Parameter Name: C02765 Enc_bError		Data type: UNSIGNED_32 Index: 21810 _d = 5532 _h
From software version V7.0		▶ Encoder evaluation: Provision of the encoder signal of input X8
Selection list (read only)		
0	FALSE	
1	TRUE	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02770

Parameter Name: C02770 Operating mode		Data type: UNSIGNED_32 Index: 21805 _d = 552D _h
From software version V7.0		▶ Basic function " Manual jog open loop "
Selection list (Lenze setting printed in bold)		
0	Deactivate	
1	Activation	
Subcodes	Lenze setting	Info
C02770/1	0: Deactivate	EnableManualMode
C02770/2	0: Deactivate	JogPositive
C02770/3	0: Deactivate	JogNegative
C02770/4	0: Deactivate	SelectTab1
C02770/5	0: Deactivate	SelectTab2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02771

Parameter Name: C02771 Frequency		Data type: INTEGER_32 Index: 21804 _d = 552C _h
From software version V7.0		▶ Basic function " Manual jog open loop "
Setting range (min. value unit max. value)		
0.0	Hz	1000.0
Subcodes	Lenze setting	Info
C02771/1	1.0 Hz	Frequency 1
C02771/2	1.0 Hz	Frequency 2
C02771/3	1.0 Hz	Frequency 3
C02771/4	1.0 Hz	Frequency 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02772

Parameter Name: C02772 Starting angle			Data type: INTEGER_32 Index: 21803 _d = 552B _h
From software version V7.0			▶ Basic function " Manual jog open loop "
Setting range (min. value unit max. value)			
-180.0	°	180.0	
Subcodes	Lenze setting	Info	
C02772/1	0.0 °	Startangle 1	
C02772/2	0.0 °	Startangle 2	
C02772/3	0.0 °	Startangle 3	
C02772/4	0.0 °	Startangle 4	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02773

Parameter Name: C02773 Current			Data type: INTEGER_32 Index: 21802 _d = 552A _h
From software version V7.0			▶ Basic function " Manual jog open loop "
100 % $\frac{1}{2}$ _{max_device} (C00022)			
Setting range (min. value unit max. value)			
0.00	%	100.00	
Subcodes	Lenze setting	Info	
C02773/1	10.00 %	Current 1	
C02773/2	10.00 %	Current 2	
C02773/3	10.00 %	Current 3	
C02773/4	10.00 %	Current 4	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02774

Parameter Name: C02774 Acceleration time			Data type: INTEGER_32 Index: 21801 _d = 5529 _h
From software version V7.0			▶ Basic function " Manual jog open loop "
Setting range (min. value unit max. value)			
0.001	s	2147483.647	
Subcodes	Lenze setting	Info	
C02774/1	1.000 s	Acceleration time 1	
C02774/2	1.000 s	Acceleration time 2	
C02774/3	1.000 s	Acceleration time 3	
C02774/4	1.000 s	Acceleration time 4	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1000

C02775

Parameter Name: C02775 Deceleration time		Data type: INTEGER_32 Index: 21800 _d = 5528 _h
From software version V7.0		▶ Basic function " Manual jog open loop "
Setting range (min. value unit max. value)		
0.001	s	2147483.647
Subcodes	Lenze setting	Info
C02775/1	1.000 s	Deceleration time 1
C02775/2	1.000 s	Deceleration time 2
C02775/3	1.000 s	Deceleration time 3
C02775/4	1.000 s	Deceleration time 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02776

Parameter Name: C02776 Time		Data type: INTEGER_32 Index: 21799 _d = 5527 _h
From software version V7.0		▶ Basic function " Manual jog open loop "
Setting range (min. value unit max. value)		
0.001	s	2147483.647
Subcodes	Lenze setting	Info
C02776/1	1.000 s	Max. activation time 1
C02776/2	1.000 s	Max. activation time 2
C02776/3	1.000 s	Max. activation time 3
C02776/4	1.000 s	Max. activation time 4
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1000

C02779

Parameter Name: C02779 MOL_SetpointCurrent		Data type: UNSIGNED_32 Index: 21796 _d = 5524 _h
From software version V7.0 Maximum current of the selected profile parameter set.		▶ Basic function " Manual jog open loop "
Display range (min. value unit max. value)		
0.00	A	42949672.95
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 100

C02780

Parameter Name: C02780 MOL_dnState		Data type: INTEGER_32 Index: 21795 _d = 5523 _h
From software version V7.0 Status of the basic function " Manual jog open loop ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02781

Parameter Name: C02781 ManualJogOpenLoop: Dig. signals		Data type: UNSIGNED_32 Index: 21794 _d = 5522 _h
From software version V7.0 Display of the digital signals of the basic function " Manual jog open loop ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes	Info	
C02781/1	MOL_bEnable	
C02781/2	MOL_bJogPositive	
C02781/3	MOL_bJogNegative	
C02781/4	MOL_bSelectTab1	
C02781/5	MOL_bSelectTab2	
C02781/6	MOL_bEnabled	
C02781/7	MOL_bActive	
C02781/8	MOL_bDone	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02785

Parameter Name: C02785 PPI activation		Data type: UNSIGNED_32 Index: 21790 _d = 551E _h
From software version V7.0		► Basic function " pole position identification "
Selection list (Lenze setting printed in bold)		
0	PPI disabled	
1	PPI in progress	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02786

Parameter Name: C02786 PPI mode		Data type: UNSIGNED_32 Index: 21789 _d = 551D _h
From software version V7.0		► Basic function " pole position identification "
Selection list (Lenze setting printed in bold)		
0	360°	
1	<20°	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02787

Parameter Name: C02787 PPI_dnState		Data type: INTEGER_32 Index: 21788 _d = 551C _h
From software version V7.0 Status of the basic function " pole position identification ".		
Display range (min. value unit max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02788

Parameter Name: C02788 PolePosition setpoint		Data type: INTEGER_32 Index: 21787 _d = 551B _h
From software version V7.0		
▶ Basic function " pole position identification "		
Display range (min. value unit max. value)		
-214748364.8	°	214748364.7
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 10

C02789

Parameter Name: C02789 PolePositionIdentification: Dig. signals		Data type: UNSIGNED_32 Index: 21786 _d = 551A _h
From software version V7.0		
Display of the digital signals of the basic function " pole position identification ".		
Selection list (read only)		
0	FALSE	
1	TRUE	
Subcodes		Info
C02789/1	PPI_bEnable	
C02789/2	PPI_bStart	
C02789/3	PPI_bLoadPolePosition	
C02789/4	PPI_bResetPolePosition	
C02789/5	PPI_bEnabled	
C02789/6	PPI_bActive	
C02789/7	PPI_bDone	
C02789/8	PPI_bError	
C02789/9	PPI_bPolePositionAvailable	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02800

Parameter Name: C02800 Analog input x: Input signal		Data type: INTEGER_16 Index: 21775 _d = 550F _h
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %		
Display range (min. value unit max. value)		
-16384		16383
Subcodes		Info
C02800/1	Input signal - analog input 1	
C02800/2	Analog input 2: Input signal	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02801

Parameter Name: C02801 Analog output x: Output signal		Data type: INTEGER_16 Index: 21774 _d = 550E _h
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %		
Display range (min. value unit max. value)		
-16384		16383
Subcodes		Info
C02801/1		Output signal - analog output 1
C02801/2		Analog output 2: Output signal
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02802

Parameter Name: C02802 Status word: Digital outputs		Data type: BITFIELD_32 Index: 21773 _d = 550D _h
Display of the hexadecimal value of the digital outputs • Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well.		
Display area		
0x00000000		0xFFFFFFFF
Value is bit-coded:		
Bit 0	Reserved	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Reserved	
Bit 5	Reserved	
Bit 6	Reserved	
Bit 7	Reserved	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Dig. output. 1: Terminal state	
Bit 13	Dig. output. 2: Terminal state	
Bit 14	Dig. output. 3: Terminal state	
Bit 15	Dig. output. 4: Terminal state	
Bit 16	Reserved	
Bit 17	Reserved	
Bit 18	Reserved	
Bit 19	Reserved	
Bit 20	Reserved	
Bit 21	Reserved	
Bit 22	Reserved	
Bit 23	Reserved	
Bit 24	Reserved	
Bit 25	Reserved	
Bit 26	Reserved	
Bit 27	Reserved	
Bit 28	Reserved	
Bit 29	Reserved	
Bit 30	Reserved	
Bit 31	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02803

Parameter Name: C02803 Status word: Digital inputs		Data type: BITFIELD_32 Index: 21772 _d = 550C _h
Display of the hexadecimal value of the digital inputs <ul style="list-style-type: none"> Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well. 		
Display area		
0x00000000		0xFFFFFFFF
Value is bit-coded:		
Bit 0	Dig. input. 1: Terminal state	
Bit 1	Dig. input. 2: Terminal state	
Bit 2	Dig. input. 3: Terminal state	
Bit 3	Dig. input. 4: Terminal state	
Bit 4	Dig. input. 5: Terminal state	
Bit 5	Dig. input. 6: Terminal state	
Bit 6	Dig. input. 7: Terminal state	
Bit 7	Dig. input. 8: Terminal state	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Reserved	
Bit 13	Reserved	
Bit 14	Reserved	
Bit 15	Reserved	
Bit 16	Reserved	
Bit 17	Reserved	
Bit 18	Reserved	
Bit 19	Reserved	
Bit 20	Reserved	
Bit 21	Reserved	
Bit 22	Reserved	
Bit 23	Reserved	
Bit 24	Reserved	
Bit 25	Reserved	
Bit 26	Reserved	
Bit 27	Reserved	
Bit 28	Reserved	
Bit 29	Reserved	
Bit 30	Reserved	
Bit 31	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02810

Parameter Name:		Data type: UNSIGNED_32 Index: 21765 _d = 5505 _h	
C02810 Touch probe x: Delay time			
The delay time set will be considered when the position is determined at the time of touch probe and will be used to compensate for dead times, if necessary.			
• Please observe the setting of the input filter for the digital inputs (C02830).			
Setting range (min. value unit max. value)			
0	μs	7000	
Subcodes	Lenze setting	Info	
C02810/1	0 μs	TP1 (DI1): Delay time	
C02810/2	0 μs	TP2 (DI2): Delay time	
C02810/3	0 μs	TP3 (DI3): Delay time	
C02810/4	0 μs	TP4 (DI4): Delay time	
C02810/5	0 μs	TP5 (DI5): Delay time	
C02810/6	0 μs	TP6 (DI6): Delay time	
C02810/7	0 μs	TP7 (DI7): Delay time	
C02810/8	0 μs	TP8 (DI8): Delay time	
C02810/9	0 μs	TPM (motor encoder): Delay time	
C02810/10	0 μs	TPL (pos. encoder): Delay time	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02830

Parameter Name: C02830 Digital inputs: Delay time		Data type: UNSIGNED_8 Index: 21745 _d = 54F1 _h
Input filter for digital inputs <ul style="list-style-type: none"> Can be used to filter out "spikes" at the digital inputs, if necessary. Each digital input is assigned to a subcode. Since the filter is a "counting" filter, the indicated times are only approximate values. 		
Selection list (Lenze setting printed in bold)	Info	
0	2 μs	Filter time
1	4 μs	
2	8 μs	
3	16 μs	
4	32 μs	
5	64 μs	
6	128 μs	
7	256 μs	
8	512 μs	
9	1024 μs	
10	2048 μs	
11	4096 μs	
12	8192 μs	
13	16384 μs	
14	32768 μs	
Subcodes	Lenze setting	Info
C02830/1	0: 2 μs	Setting for digital input 1 ... 8
C02830/...		
C02830/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02850

Parameter Name: C02850 Service code	Data type: UNSIGNED_32 Index: 21724 _d = 54DD _h
This code is for device-internal use only and must not be written to by the user!	

C02851

Parameter Name: C02851 Service code	Data type: UNSIGNED_32 Index: 21724 _d = 54DC _h
This code is for device-internal use only and must not be written to by the user!	

C02852

Parameter Name: C02852 Service code	Data type: UNSIGNED_16 Index: 21723 _d = 54DB _h
This code is for device-internal use only and must not be written to by the user!	

C02853

Parameter Name: C02853 Lss sat. characteristic			Data type: UNSIGNED_16 Index: 21722 _d = 54DA _h
Setting range (min. value unit max. value)			
0	%	400	
Subcodes	Lenze setting	Info	
C02853/1	100 %	Saturation characteristic to correct the leakage inductance and the current controller parameters. <ul style="list-style-type: none"> The saturation characteristic is defined by 17 interpolation points which are distributed linearly on the x axis. Interpolation point 17 represents 100 % of the maximum motor current in the process (C02855). The values to be entered in the subcodes represent the y values of the interpolation points 1 ... 17. ▶ Correction of the leakage inductance via saturation characteristic	
C02853/2	100 %		
C02853/3	100 %		
C02853/4	100 %		
C02853/5	100 %		
C02853/6	100 %		
C02853/7	100 %		
C02853/8	100 %		
C02853/9	100 %		
C02853/10	100 %		
C02853/11	100 %		
C02853/12	100 %		
C02853/13	100 %		
C02853/14	100 %		
C02853/15	100 %		
C02853/16	100 %		
C02853/17	100 %		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1			

C02854

Parameter Name: C02854 Service code		Data type: UNSIGNED_32 Index: 21721 _d = 54D9 _h
This code is for device-internal use only and must not be written to by the user!		

C02855

Parameter Name: C02855 I _{max} f. Lss sat. characteristic			Data type: UNSIGNED_32 Index: 21720 _d = 54D8 _h
Maximum motor current in the process <ul style="list-style-type: none"> Defines the interpolation point 17 of the saturation characteristic set in C02853. ▶ Correction of the leakage inductance via saturation characteristic			
Setting range (min. value unit max. value)			Lenze setting
0.0	A	6000.0	5.4 A
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 10			

C02856

Parameter Name: C02856 Service code		Data type: VISIBLE_STRING Index: 21719 _d = 54D7 _h
This code is for device-internal use only and must not be written to by the user!		

C02857

Parameter Name: C02857 Service code	Data type: VISIBLE_STRING Index: 21718 _d = 54D6 _h
This code is for device-internal use only and must not be written to by the user!	

C02858

Parameter Name: C02858 Electronic nameplate status	Data type: UNSIGNED_8 Index: 21717 _d = 54D5 _h
This code is for device-internal use only and must not be written to by the user!	

C02859

Parameter Name: C02859 Activate Lss sat. char.	Data type: UNSIGNED_8 Index: 21716 _d = 54D4 _h
▶ Correction of the leakage inductance via saturation characteristic	
Selection list (Lenze setting printed in bold)	
0	Off
1	On
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C02860

Parameter Name: C02860 Rr adjustment	Data type: UNSIGNED_32 Index: 21715 _d = 54D3 _h
Setting range (min. value unit max. value)	Lenze setting
50.00 % 200.00	100.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C02861

Parameter Name: C02861 Lh adjustment	Data type: UNSIGNED_32 Index: 21714 _d = 54D2 _h
Setting range (min. value unit max. value)	Lenze setting
50.00 % 200.00	100.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 100	

C02862

Parameter Name: C02862 Resolver: Gain	Data type: UNSIGNED_16 Index: 21713 _d = 54D1 _h	
From software version V7.0		
▶ Resolver error compensation		
Setting range (min. value unit max. value)		
0	100	
Subcodes	Lenze setting	Info
C02862/1	100	Gain of cosine track
C02862/2	100	Gain of sine track
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1		

C02863

Parameter Name: C02863 Resolver: phase correction		Data type: INTEGER_16 Index: 21712 _d = 54D0 _h	
From software version V7.0			
▶ Resolver error compensation			
Setting range (min. value unit max. value)			Lenze setting
-100		100	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1

C02864

Parameter Name: C02864 Service code		Data type: INTEGER_32 Index: 21711 _d = 54CF _h	
This code is for device-internal use only and must not be written to by the user!			

C02865

Parameter Name: C02865 Adaptation of Ur		Data type: UNSIGNED_32 Index: 21710 _d = 54CE _h	
From software version V8.0			
Setting range (min. value unit max. value)			Lenze setting
50.00	%	200.00	100.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 100

C02866

Parameter Name: C02866 Curr. control par. of C75 C76		Data type: UNSIGNED_8 Index: 21709 _d = 54CD _h	
This code is for device-internal use only and must not be written to by the user!			

C02867

Parameter Name: C02867 Motor phase failure volt. threshold		Data type: INTEGER_32 Index: 21708 _d = 54CC _h	
From software version V10.0			
Setting range (min. value unit max. value)			Lenze setting
0.0	V	1000.0	10.0 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 10

C02868

Parameter Name: C02868 Service code		Data type: UNSIGNED_32 Index: 21707 _d = 54CB _h	
This code is for device-internal use only and must not be written to by the user!			

C02869

Parameter Name: C02869 Service code		Data type: UNSIGNED_32 Index: 21706 _d = 54CA _h	
This code is for device-internal use only and must not be written to by the user!			

14 Parameter reference

14.2 Parameter list | C02870

C02870

Parameter Name: C02870 Service code	Data type: UNSIGNED_32 Index: 21705 _d = 54C9 _h
This code is for device-internal use only and must not be written to by the user!	

C02871

Parameter Name: C02871 Voltage reserve	Data type: UNSIGNED_32 Index: 21704 _d = 54C8 _h
<p>From software version V12.0</p> <p>Voltage reserve at the transition point to field weakening</p> <ul style="list-style-type: none"> • Only relevant for servo control for asynchronous motor (selection "2" in C00006). 	
Setting range (min. value unit max. value)	Lenze setting
1 % 20	5 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C02872

Parameter Name: C02872 PLI 360° result in C58	Data type: UNSIGNED_32 Index: 21703 _d = 54C7 _h
<p>From software version V15.0 onwards</p> <p style="text-align: right;">▶ Result in C0058</p>	
Selection list (Lenze setting printed in bold)	Info
0 OFF	
1 ON	In the case of PLI 360°, the absolute position determined is not saved in the encoder, but is transferred to code C0058:2 instead. This is the response compatible with i700 / i900.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1	

C02900

Parameter Name: C02900 User Password	Data type: VISIBLE_STRING Index: 21675 _d = 54AB _h
<p>From software version V3.0</p> <p>If the cam data are provided with a user password, the defined user password must be entered once to execute the following actions:</p> <ul style="list-style-type: none"> • Changing the cam data via parameter setting • Loading/saving the cam data <p>Validity</p> <p>The user password entered is maintained until the next download, mains switching, or until reset by the user (logout).</p> <ul style="list-style-type: none"> • You can "logout" deliberately by entering an invalid password. <p style="text-align: right;">▶ Basic function "Cam data management"</p>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Character length: 22	

C02901

Parameter Name: C02901 CamMemory		Data type: UNSIGNED_32 Index: 21674 _d = 54AA _h
From software version V5.0		
▶ Basic function "Cam data management": Memory mapping		
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C02901/1		Size of the memory for quick download to RAM
C02901/2		Size of the memory for "Online change"
C02901/3		Size of the memory from which the cam data are processed.
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02902

Parameter Name: C02902 Timestamp		Data type: UNSIGNED_32 Index: 21673 _d = 54A9 _h
From software version V3.0		
▶ Basic function " Cam data management "		
Display range (min. value unit max. value)		
0		4294967295
Subcodes		Info
C02902/1		Time stamp of the cam data in the controller
C02902/2		Time stamp of the cam data which are currently being processed in the controller.
C02902/3		Time stamp of the cam data in the controller which have already been converted into the internal format.
C02902/4		Time stamp of the cam data in the memory module
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02903

Parameter Name: C02903 GUID		Data type: OCTET_STRING Index: 21672 _d = 54A8 _h
From software version V3.0		
▶ Basic function " Cam data management "		
Display range (min. value unit max. value)		
Subcodes		Info
C02903/1		GUID of the cam data in the controller
C02903/2		GUID of the cam data which are currently being processed in the controller.
C02903/3		GUID of the cam data in the controller which have already been converted into the internal format.
C02903/4		GUID of the cam data in the memory module
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02905

Parameter Name: C02905 Online Change Mode		Data type: UNSIGNED_32 Index: 21670 _d = 54A6 _h
From software version V3.0		
▶ Basic function "Cam data management": Online change mode		
Selection list (Lenze setting printed in bold)		
10	Manual activation	
15	Automatic activation	
16	Automatic activation with controller inhibit	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02906

Parameter Name: C02906 Online Change State		Data type: UNSIGNED_32 Index: 21669 _d = 54A5 _h
From software version V3.0		
▶ Basic function "Cam data management": Online change mode		
Selection list (read only)		
0	Ready	
5	Initialisation	
7	Saving is active	
8	Loading is active	
11	Waiting for controlled acceptance	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02908

Parameter Name: C02908 Product Count		Data type: UNSIGNED_32 Index: 21667 _d = 54A3 _h
From software version V3.0		
Display of the highest product number +1 of the cam data currently being processed		
▶ Basic function " Cam data management "		
Display range (min. value unit max. value)		
0		0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02909

Parameter Name: C02909 Active Product		Data type: UNSIGNED_32 Index: 21666 _d = 54A2 _h
From software version V3.0		
Display of the product number of the active product of the cam data currently being processed		
▶ Basic function " Cam data management "		
Display range (min. value unit max. value)		
0		0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02910

Parameter Name: C02910 Product Name		Data type: VISIBLE_STRING Index: 21665 _d = 54A1 _h
From software version V3.0		▶ Basic function " Cam data management "
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1 Character length: 16

C02911

Parameter Name: C02911 Product Choice		Data type: UNSIGNED_32 Index: 21664 _d = 54A0 _h
From software version V3.0		▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting
0		255 0
<input checked="" type="checkbox"/> Read access	<input checked="" type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Scaling factor: 1

C02912

Parameter Name: C02912 Product Count		Data type: UNSIGNED_32 Index: 21663 _d = 549F _h
From software version V3.0		▶ Changing cam data via parameterisation
Display range (min. value unit max. value)		
0		65536
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1

C02919

Parameter Name: C02919 Number Of Cam Tracks		Data type: UNSIGNED_32 Index: 21656 _d = 5498 _h
From software version V3.0		▶ Changing cam data via parameterisation
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access	<input type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer Scaling factor: 1

C02920

Parameter Name: C02920 Cam Track Choice		Data type: UNSIGNED_32 Index: 21655 _d = 5497 _h
From software version V3.0		▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting
0		65535 0
<input checked="" type="checkbox"/> Read access	<input checked="" type="checkbox"/> Write access	<input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer Scaling factor: 1

C02921

Parameter Name: C02921 Cam Track Type		Data type: UNSIGNED_32 Index: 21654 _d = 5496 _h
From software version V3.0		▶ Changing cam data via parameterisation
Selection list (read only)		
1	Linear	
5	Spline	
11	LinearPC	
15	SplinePC	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02922

Parameter Name: C02922 Number Of Cam Data Points		Data type: UNSIGNED_32 Index: 21653 _d = 5495 _h
From software version V3.0		▶ Changing cam data via parameterisation
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02923

Parameter Name: C02923 Cam Data Point Choice		Data type: UNSIGNED_32 Index: 21652 _d = 5494 _h
From software version V3.0		▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting
0		65535
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C02924

Parameter Name: C02924 Change Cam Data Point X		Data type: INTEGER_32 Index: 21651 _d = 5493 _h
From software version V3.0		▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 10000

C02925

Parameter Name: C02925 Change Cam Data Point Y		Data type: INTEGER_32 Index: 21650 _d = 5492 _h
From software version V3.0		▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 10000

C02926

Parameter Name: C02926 Change Cam Data Point M		Data type: INTEGER_32 Index: 21649 _d = 5491 _h	
From software version V3.0			
			▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting	
-200.00	%	200.00	0.00 %
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 100	

C02927

Parameter Name: C02927 Auto Inc Cam Data Points		Data type: UNSIGNED_32 Index: 21648 _d = 5490 _h	
From software version V3.0			
			▶ Changing cam data via parameterisation
Selection list (Lenze setting printed in bold)			
0	Deactivate		
1	Activation		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1	

C02939

Parameter Name: C02939 Number Of Cont Tracks		Data type: UNSIGNED_32 Index: 21636 _d = 5484 _h	
From software version V3.0			
			▶ Changing cam data via parameterisation
Display range (min. value unit max. value)			
0		65535	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1	

C02940

Parameter Name: C02940 Cont Track Choice		Data type: UNSIGNED_32 Index: 21635 _d = 5483 _h	
From software version V3.0			
			▶ Changing cam data via parameterisation
Setting range (min. value unit max. value)		Lenze setting	
0		65535	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1	

C02941

Parameter Name: C02941 Cont Type		Data type: UNSIGNED_32 Index: 21634 _d = 5482 _h
From software version V3.0		
▶ Changing cam data via parameterisation		
Selection list (read only)		
1	Pos. position cam	
2	Neg. position cam	
3	Bidirect. position cam	
11	Pos. time cam	
12	Neg. time cam	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02942

Parameter Name: C02942 Number Of Cont Data Points		Data type: UNSIGNED_32 Index: 21633 _d = 5481 _h
From software version V3.0		
▶ Changing cam data via parameterisation		
Display range (min. value unit max. value)		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer		Scaling factor: 1

C02943

Parameter Name: C02943 Cont Data Point Choice		Data type: UNSIGNED_32 Index: 21632 _d = 5480 _h
From software version V3.0		
▶ Changing cam data via parameterisation		
Setting range (min. value unit max. value)		Lenze setting
0		65535
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1

C02944

Parameter Name: C02944 Cont Pos X0		Data type: INTEGER_32 Index: 21631 _d = 547F _h
From software version V3.0		
▶ Changing cam data via parameterisation		
Setting range (min. value unit max. value)		Lenze setting
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 10000

C02945

Parameter Name: C02945 Cont Pos X1			Data type: INTEGER_32 Index: 21630 _d = 547E _h	
From software version V3.0				
▶ Changing cam data via parameterisation				
Setting range (min. value unit max. value)			Lenze setting	
-214748.3647	Unit	214748.3647	0.0000 Unit	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000	

C02946

Parameter Name: C02946 Cont Time			Data type: UNSIGNED_32 Index: 21629 _d = 547D _h	
From software version V3.0				
▶ Changing cam data via parameterisation				
Setting range (min. value unit max. value)			Lenze setting	
0.0000	ms	214748.3647	0.0000 ms	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 10000	

C02959

Parameter Name: C02959 Number of Pos Tracks			Data type: UNSIGNED_32 Index: 21616 _d = 5470 _h	
From software version V3.0				
▶ Changing cam data via parameterisation				
Display range (min. value unit max. value)				
0		65535		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

C02960

Parameter Name: C02960 Pos Track Choice			Data type: UNSIGNED_32 Index: 21615 _d = 546F _h	
From software version V3.0				
▶ Changing cam data via parameterisation				
Setting range (min. value unit max. value)			Lenze setting	
0		65535	0	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer			Scaling factor: 1	

C02962

Parameter Name: C02962 Number of Pos Data Points			Data type: UNSIGNED_32 Index: 21613 _d = 546D _h	
From software version V3.0				
▶ Changing cam data via parameterisation				
Display range (min. value unit max. value)				
0		65535		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer			Scaling factor: 1	

14 Parameter reference

14.2 Parameter list

C02963

Parameter Name: C02963 Pos Data Point Choice		Data type: UNSIGNED_32 Index: 21612 _d = 546C _h	
From software version V3.0		▶ Changing cam data via parameterisation	
Setting range (min. value unit max. value)		Lenze setting	
0		65535	0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 1	

C02964

Parameter Name: C02964 Change Pos Data Point X		Data type: INTEGER_32 Index: 21611 _d = 546B _h	
From software version V3.0		▶ Changing cam data via parameterisation	
Setting range (min. value unit max. value)		Lenze setting	
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 10000	

C02965

Parameter Name: C02965 Change Pos Data Point Y		Data type: INTEGER_32 Index: 21610 _d = 546A _h	
From software version V3.0		▶ Changing cam data via parameterisation	
Setting range (min. value unit max. value)		Lenze setting	
-214748.3647	Unit	214748.3647	0.0000 Unit
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer		Scaling factor: 10000	

C02996

Parameter Name: C02996 Service code		Data type: UNSIGNED_32 Index: 21579 _d = 544B _h	
This code is for device-internal use only and must not be written to by the user!			

C02997

Parameter Name: C02997 Service code		Data type: UNSIGNED_32 Index: 21578 _d = 544A _h	
This code is for device-internal use only and must not be written to by the user!			

C02998

Parameter Name: C02998 Service code		Data type: UNSIGNED_32 Index: 21577 _d = 5449 _h	
This code is for device-internal use only and must not be written to by the user!			

C02999

Parameter Name: C02999 Service code		Data type: UNSIGNED_32 Index: 21576 _d = 5448 _h	
This code is for device-internal use only and must not be written to by the user!			

14 Parameter reference

14.3 Table of attributes

14.3 Table of attributes

The table of attributes contains information required for communication with the inverter via parameters.

How to read the table of attributes:

Column		Meaning	Entry	
code		Parameter name	Cxxxx	
Name		Parameter short text (display text)	Text	
Type		Parameter type	Selection list	Value from selection list
			Bit coded	Bit coded value
			Linear value	Value with setting range
			String	String
Index	dec	Index under which the parameter is addressed. The subindex for array variables corresponds to the Lenze subcode number.	24575 - Lenze code number	Is only required for access via a bus system.
	hex		5FFF _h - Lenze code number	
Data	DS	Data structure	E	Single variable (only one parameter element)
			A	
	DA	Number of array elements (subcodes)	Number	
	DT	Data type	BITFIELD_8	1 byte, bit-coded
			BITFIELD_16	2 bytes bit-coded
			BITFIELD_32	4 bytes bit-coded
			INTEGER_8	1 byte, with sign
			INTEGER_16	2 bytes with sign
			INTEGER_32	4 bytes with sign
			UNSIGNED_8	1 byte without sign
UNSIGNED_16			2 bytes without sign	
UNSIGNED_32	4 bytes without sign			
VISIBLE_STRING [xx]	ASCII string (with character length xx)			
Factor	Factor for data transmission via a bus system, depending on the number of decimal positions	Factor	1 = No decimal positions 10 = 1 decimal position 100 = 2 decimal positions 1000 = 3 decimal positions 10000 = 4 decimal positions	
CINH	Writing is only possible if the controller is inhibited	CINH		

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00002	Device commands	Selection list	24573	5FFD	E	1	UNSIGNED_32	1	
C00003	Device command status	Linear value	24572	5FFC	E	1	UNSIGNED_32	1	
C00004	Service password	Linear value	24571	5FFB	E	1	UNSIGNED_32	1	
C00005	Application selection	Linear value	24570	5FFA	E	1	INTEGER_32	1	
C00006	Select motor control	Selection list	24569	5FF9	E	1	UNSIGNED_32	1	CINH
C00007	Active application	Linear value	24568	5FF8	E	1	INTEGER_32	1	
C00008	Device command progress	Linear value	24567	5FF7	E	1	UNSIGNED_32	1	
C00011	Reference speed motor	Linear value	24564	5FF4	E	1	UNSIGNED_32	1	
C00018	Switching frequency	Selection list	24557	5FED	E	1	UNSIGNED_32	1	
C00019	Threshold - standstill recognition	Linear value	24556	5FEC	E	1	UNSIGNED_32	1	
C00022	Maximum current	Linear value	24553	5FE9	E	1	UNSIGNED_32	100	
C00034	Config. analog input 1	Selection list	24541	5FDD	E	1	UNSIGNED_32	1	
C00050	Speed setpoint [rpm]	Linear value	24525	5FCD	A	2	INTEGER_32	1	
C00051	Actual speed value [min-1]	Linear value	24524	5FCC	E	1	INTEGER_32	1	
C00052	Motor voltage	Linear value	24523	5FCB	E	1	UNSIGNED_32	1	
C00053	DC-bus voltage	Linear value	24522	5FCA	E	1	UNSIGNED_32	1	
C00054	Motor current	Linear value	24521	5FC9	E	1	UNSIGNED_32	100	
C00055	Phase currents	Linear value	24520	5FC8	A	4	INTEGER_32	100	
C00056	Torque setpoint	Linear value	24519	5FC7	E	1	INTEGER_32	100	
C00057	Torque	Linear value	24518	5FC6	A	2	UNSIGNED_32	1000	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00058	Pole position	Linear value	24517	5FC5	A	3	INTEGER_32	10	
C00059	Motor - number of pole pairs	Linear value	24516	5FC4	E	1	UNSIGNED_32	1	
C00060	Motor pole angle	Linear value	24515	5FC3	E	1	INTEGER_32	1	
C00061	Heatsink temperature	Linear value	24514	5FC2	E	1	INTEGER_32	1	
C00062	Interior temperature	Linear value	24513	5FC1	E	1	INTEGER_32	1	
C00063	Motor temperature	Linear value	24512	5FC0	E	1	INTEGER_32	1	
C00064	Device utilisation (lxt)	Linear value	24511	5FBF	E	1	UNSIGNED_32	1	
C00065	Ext. 24-V voltage	Linear value	24510	5FBE	E	1	INTEGER_32	10	
C00066	Thermal motor load (l*xt)	Linear value	24509	5FBD	E	1	UNSIGNED_32	1	
C00068	Capacitor temperature	Linear value	24507	5FBB	E	1	INTEGER_32	1	
C00069	CPU temperature	Linear value	24506	5FBA	E	1	INTEGER_32	1	
C00070	Speed controller gain	Linear value	24505	5FB9	E	1	UNSIGNED_32	100000	
C00071	Speed controller reset time	Linear value	24504	5FB8	E	1	UNSIGNED_32	10	
C00072	Speed controller rate time	Linear value	24503	5FB7	E	1	UNSIGNED_32	100	
C00074	Feedfwd. ctrl. - current contr.	Selection list	24501	5FB5	E	1	UNSIGNED_8	1	
C00075	Current controller gain	Linear value	24500	5FB4	E	1	UNSIGNED_32	100	
C00076	Current contr. reset time	Linear value	24499	5FB3	E	1	UNSIGNED_32	100	
C00077	Field controller gain	Linear value	24498	5FB2	E	1	UNSIGNED_32	100	
C00078	Field contr. reset time	Linear value	24497	5FB1	E	1	UNSIGNED_32	10	
C00079	Motor magnetising inductance	Linear value	24496	5FB0	E	1	UNSIGNED_32	10	
C00080	Number of resolver pole pairs	Linear value	24495	5FAF	E	1	UNSIGNED_32	1	CINH
C00081	Rated motor power	Linear value	24494	5FAE	E	1	UNSIGNED_32	100	CINH
C00082	Motor rotor resistance	Linear value	24493	5FAD	E	1	UNSIGNED_32	10000	
C00083	Motor rotor time constant	Linear value	24492	5FAC	E	1	UNSIGNED_32	100	
C00084	Motor stator resistance	Linear value	24491	5FAB	E	1	UNSIGNED_32	10000	CINH
C00085	Motor stator leakage inductance	Linear value	24490	5FAA	E	1	UNSIGNED_32	1000	CINH
C00087	Rated motor speed	Linear value	24488	5FA8	E	1	UNSIGNED_32	1	CINH
C00088	Rated motor current	Linear value	24487	5FA7	E	1	UNSIGNED_32	100	CINH
C00089	Rated motor frequency	Linear value	24486	5FA6	E	1	UNSIGNED_32	10	CINH
C00090	Rated motor voltage	Linear value	24485	5FA5	E	1	UNSIGNED_32	1	CINH
C00091	Motor cosine phi	Linear value	24484	5FA4	E	1	UNSIGNED_32	100	CINH
C00092	Motor magnetising current	Linear value	24483	5FA3	E	1	UNSIGNED_32	100	
C00093	Field weakening for SM	Selection list	24482	5FA2	E	1	UNSIGNED_32	1	
C00099	Firmware version	String	24476	5F9C	E	1	VISIBLE_STRING [12]		
C00100	Resolution	Linear value	24475	5F9B	E	1	UNSIGNED_32	1	CINH
C00105	Decel. time - quick stop	Linear value	24470	5F96	E	1	UNSIGNED_32	1000	
C00106	Quick stop S-ramp time	Linear value	24469	5F95	E	1	UNSIGNED_32	100	
C00107	Ref. for quick stop dec. time	Selection list	24468	5F94	E	1	UNSIGNED_8	1	
C00114	Digital input x - terminal pol.	Linear value	24461	5F8D	A	8	UNSIGNED_8	1	
C00118	Digital output x - terminal pol.	Linear value	24457	5F89	A	4	UNSIGNED_8	1	
C00120	Motor overload protection (l*xt)	Linear value	24455	5F87	E	1	UNSIGNED_32	1	
C00121	Motor temp. warning threshold	Linear value	24454	5F86	E	1	UNSIGNED_32	1	
C00122	Heatsink temp. warn. threshold	Linear value	24453	5F85	E	1	UNSIGNED_32	1	
C00123	Device utilisation warning threshold	Linear value	24452	5F84	E	1	UNSIGNED_32	1	
C00126	CPU temp. warning threshold	Linear value	24449	5F81	E	1	UNSIGNED_32	1	
C00127	Mot. overload warning threshold	Linear value	24448	5F80	E	1	UNSIGNED_32	1	
C00128	Therm. motor time constant	Linear value	24447	5F7F	A	2	UNSIGNED_32	10	
C00129	Brake resistance value	Linear value	24446	5F7E	E	1	INTEGER_32	10	
C00130	Rated brake resistor power	Linear value	24445	5F7D	E	1	INTEGER_32	1	
C00131	Rated quantity of heat for brake res.	Linear value	24444	5F7C	E	1	INTEGER_32	1	
C00133	Ref.: Brake chopper utilisation	Selection list	24442	5F7A	E	1	UNSIGNED_8	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00134	Min. brake resistance	Linear value	24441	5F79	E	1	INTEGER_32	10	
C00137	Brake transistor utilisation	Linear value	24438	5F76	E	1	INTEGER_32	1	
C00138	Brake resistor utilisation	Linear value	24437	5F75	E	1	INTEGER_32	1	
C00142	Autom. restart after mains ON	Selection list	24433	5F71	E	1	UNSIGNED_32	1	
C00150	Status word device control 1	Bit coded	24425	5F69	E	1	BITFIELD_16	1	
C00155	Status word device control 2	Bit coded	24420	5F64	E	1	BITFIELD_16	1	
C00156	Status/Control word MCTRL	Linear value	24419	5F63	A	2	UNSIGNED_32	1	
C00158	Controller inhibit by (source)	Bit coded	24417	5F61	E	1	BITFIELD_16	1	
C00159	Quick stop by (source)	Bit coded	24416	5F60	E	1	BITFIELD_16	1	
C00162	Masked error number	Linear value	24413	5F5D	A	3	UNSIGNED_32	1	
C00166	Error description	String	24409	5F59	E	1	VISIBLE_STRING [64]		
C00168	Error number	Linear value	24407	5F57	E	1	UNSIGNED_32	1	
C00169	Logbook event filter	Bit coded	24406	5F56	E	1	BITFIELD_32	1	
C00173	Mains voltage	Selection list	24402	5F52	E	1	UNSIGNED_8	1	
C00174	Undervoltage (LU) threshold	Linear value	24401	5F51	E	1	UNSIGNED_32	1	
C00178	Elapsed-hour meter	Linear value	24397	5F4D	E	1	UNSIGNED_32	1	
C00179	Power-on time meter	Linear value	24396	5F4C	E	1	UNSIGNED_32	1	
C00180	Service code	String	24395	5F4B	E	1	VISIBLE_STRING [192]		
C00181	Red. brake chopper threshold	Linear value	24394	5F4A	E	1	UNSIGNED_32	1	
C00182	Time for device search function	Linear value	24393	5F49	E	1	UNSIGNED_16	1	
C00183	Device status	Selection list	24392	5F48	E	1	UNSIGNED_32	1	
C00185	Mains recov. detect. threshold	Linear value	24390	5F46	E	1	UNSIGNED_32	1	
C00186	ENP: Identified motor type	String	24389	5F45	E	1	VISIBLE_STRING [19]		
C00187	ENP: Identified serial number	String	24388	5F44	E	1	VISIBLE_STRING [22]		
C00188	ENP: Status	Selection list	24387	5F43	E	1	UNSIGNED_8	1	
C00199	Device name	String	24376	5F38	E	1	VISIBLE_STRING [128]		
C00200	Firmware product type	String	24375	5F37	E	1	VISIBLE_STRING [18]		
C00201	Firmware compilation date	String	24374	5F36	E	1	VISIBLE_STRING [21]		
C00202	Autom. ENP data transfer	Selection list	24373	5F35	E	1	UNSIGNED_32	1	
C00203	HW product types	String	24372	5F34	A	9	VISIBLE_STRING [18]		
C00204	HW serial numbers	String	24371	5F33	A	9	VISIBLE_STRING [22]		
C00205	HW descriptions	String	24370	5F32	A	6	VISIBLE_STRING [18]		
C00206	HW manufacturing data	String	24369	5F31	A	8	VISIBLE_STRING [20]		
C00208	HW manufacturer	String	24367	5F2F	A	6	VISIBLE_STRING [20]		
C00209	HW countries of origin	String	24366	5F2E	A	6	VISIBLE_STRING [4]		
C00210	HW versions	String	24365	5F2D	A	6	VISIBLE_STRING [5]		
C00211	Application: Version	String	24364	5F2C	E	1	VISIBLE_STRING [12]		
C00212	Application: Type code	String	24363	5F2B	E	1	VISIBLE_STRING [20]		
C00213	Application: compilation date	String	24362	5F2A	E	1	VISIBLE_STRING [21]		
C00214	Required safety module	Selection list	24361	5F29	E	1	UNSIGNED_8	1	CINH
C00218	Application: ID number	Linear value	24357	5F25	E	1	UNSIGNED_32	1	
C00220	Memory module Firmw. Rev.	Linear value	24355	5F23	E	1	UNSIGNED_32	1	
C00227	Behav. at parameter set changeover	Selection list	24348	5F1C	A	2	UNSIGNED_32	1	
C00254	Phase controller gain	Linear value	24321	5F01	E	1	UNSIGNED_32	100	
C00270	Freq. - current setpoint filter	Linear value	24305	5EF1	A	2	UNSIGNED_32	10	
C00271	Width - current setp. filter	Linear value	24304	5EF0	A	2	UNSIGNED_32	10	
C00272	Depth - current setp. filter	Linear value	24303	5EEF	A	2	UNSIGNED_32	1	
C00273	Moment of inertia	Linear value	24302	5EEE	A	2	UNSIGNED_32	100	
C00274	Max. acceleration change	Linear value	24301	5EED	E	1	UNSIGNED_32	10	
C00275	Signal source - speed setpoint	Selection list	24300	5EEC	E	1	UNSIGNED_16	1	
C00276	Signal source - torque setpoint	Selection list	24299	5EEB	E	1	UNSIGNED_16	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00280	Filter time const. DC detection	Linear value	24295	5EE7	E	1	UNSIGNED_32	10	
C00281	Filter for PWM adjustment	Selection list	24294	5EE6	E	1	UNSIGNED_8	1	
C00311	CAN TPDO1 mask byte x	Bit coded	24264	5EC8	A	8	BITFIELD_8	1	
C00312	CAN TPDO2 mask byte x	Bit coded	24263	5EC7	A	8	BITFIELD_8	1	
C00313	CAN TPDO3 mask byte x	Bit coded	24262	5EC6	A	8	BITFIELD_8	1	
C00314	CAN TPDO4 mask byte x	Bit coded	24261	5EC5	A	8	BITFIELD_8	1	
C00320	CAN TPDOx identifier	Bit coded	24255	5EBF	A	4	BITFIELD_32	1	
C00321	CAN RPDOx identifier	Bit coded	24254	5EBE	A	4	BITFIELD_32	1	
C00322	CAN TPDOx Tx mode	Linear value	24253	5EBD	A	4	UNSIGNED_8	1	
C00323	CAN RPDOx Rx mode	Linear value	24252	5EBC	A	4	UNSIGNED_8	1	
C00324	CAN TPDOx delay time	Linear value	24251	5EBB	A	4	UNSIGNED_16	1	
C00343	CAN TPDO counter	Linear value	24232	5EA8	A	4	UNSIGNED_32	1	
C00344	CAN RPDO counter	Linear value	24231	5EA7	A	4	UNSIGNED_32	1	
C00345	CAN error	Selection list	24230	5EA6	E	1	UNSIGNED_8	1	
C00346	CAN heartbeat activity	Bit coded	24229	5EA5	E	1	BITFIELD_32	1	
C00347	CAN heartbeat status	Selection list	24228	5EA4	A	32	UNSIGNED_8	1	
C00348	CAN status DIP switch	Selection list	24227	5EA3	E	1	UNSIGNED_8	1	
C00349	CAN setting - DIP switch	Linear value	24226	5EA2	A	2	UNSIGNED_8	1	
C00350	CAN node address	Linear value	24225	5EA1	E	1	UNSIGNED_8	1	
C00351	CAN baud rate	Selection list	24224	5EA0	E	1	UNSIGNED_8	1	
C00352	CAN slave/master	Selection list	24223	5E9F	E	1	UNSIGNED_8	1	
C00356	CAN TPDOx cycle time	Linear value	24219	5E9B	A	4	UNSIGNED_16	1	
C00357	CAN RPDOx monitoring time	Linear value	24218	5E9A	A	4	UNSIGNED_16	1	
C00359	CAN status	Selection list	24216	5E98	E	1	UNSIGNED_8	1	
C00360	CAN telegram and error counter	Linear value	24215	5E97	A	8	UNSIGNED_16	1	
C00361	CAN bus load	Linear value	24214	5E96	A	6	UNSIGNED_32	1	
C00367	CAN SYNC Rx identifier	Linear value	24208	5E90	E	1	UNSIGNED_32	1	
C00368	CAN SYNC Tx identifier	Linear value	24207	5E8F	E	1	UNSIGNED_32	1	
C00369	CAN sync transmission cycle time	Linear value	24206	5E8E	A	3	UNSIGNED_16	1	
C00372	CAN SDO server Rx identifier	Bit coded	24203	5E8B	A	10	BITFIELD_32	1	
C00373	CAN SDO server Tx identifier	Bit coded	24202	5E8A	A	10	BITFIELD_32	1	
C00374	CAN SDO client node address	Linear value	24201	5E89	A	10	UNSIGNED_8	1	
C00375	CAN SDO client Rx identifier	Bit coded	24200	5E88	A	10	BITFIELD_32	1	
C00376	CAN SDO client Tx identifier	Bit coded	24199	5E87	A	10	BITFIELD_32	1	
C00377	CAN SDO server node address	Linear value	24198	5E86	A	10	UNSIGNED_8	1	
C00378	CAN delay boot-up - Operational	Linear value	24197	5E85	E	1	UNSIGNED_16	1	
C00381	CAN Heartbeat producer time	Linear value	24194	5E82	E	1	UNSIGNED_16	1	
C00382	CAN guard time	Linear value	24193	5E81	E	1	UNSIGNED_16	1	
C00383	CAN life time factor	Linear value	24192	5E80	E	1	UNSIGNED_8	1	
C00385	CAN heartbeat consumer time	Bit coded	24190	5E7E	A	32	BITFIELD_32	1	
C00386	CAN node guarding	Bit coded	24189	5E7D	A	32	BITFIELD_32	1	
C00387	CAN Node Guarding Activity	Bit coded	24188	5E7C	E	1	BITFIELD_32	1	
C00388	CAN node guarding status	Selection list	24187	5E7B	A	32	UNSIGNED_8	1	
C00390	CAN error register (DS301V402)	Bit coded	24185	5E79	E	1	BITFIELD_8	1	
C00391	CAN emergency object	Bit coded	24184	5E78	E	1	BITFIELD_32	1	
C00392	CAN emergency delay time	Linear value	24183	5E77	E	1	UNSIGNED_16	1	
C00393	CAN bus scan result	Linear value	24182	5E76	A	128	UNSIGNED_8	1	
C00394	CAN predefined error field (DS301V402)	Linear value	24181	5E75	A	10	UNSIGNED_32	1	
C00398	Test mode motor control	Selection list	24177	5E71	E	1	UNSIGNED_32	1	CINH
C00399	Settings for test mode	Linear value	24176	5E70	A	2	INTEGER_32	10	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00412	Hiperface: Initialisation time	Linear value	24163	5E63	E	1	UNSIGNED_32	1	
C00413	Hiperface: detected TypeCode	Linear value	24162	5E62	E	1	UNSIGNED_32	1	
C00414	Hiperface: TypeCode	Linear value	24161	5E61	E	1	UNSIGNED_32	1	
C00415	Hiperface: Number of revolutions	Linear value	24160	5E60	E	1	UNSIGNED_32	1	
C00417	Dynamic of resolver evaluation	Linear value	24158	5E5E	E	1	UNSIGNED_32	1	
C00418	Activate resolver error compensation	Selection list	24157	5E5D	E	1	UNSIGNED_8	1	
C00420	Number of encoder increments	Linear value	24155	5E5B	E	1	UNSIGNED_16	1	CINH
C00421	Encoder voltage	Linear value	24154	5E5A	E	1	UNSIGNED_16	10	CINH
C00422	Encoder type	Selection list	24153	5E59	E	1	UNSIGNED_16	1	CINH
C00423	SSI encoder: Bit rate	Linear value	24152	5E58	E	1	UNSIGNED_32	1	CINH
C00424	Ssi-encoder: Data word length	Linear value	24151	5E57	E	1	UNSIGNED_32	1	CINH
C00427	TTL encoder signal evaluation	Selection list	24148	5E54	E	1	UNSIGNED_16	1	CINH
C00435	SSI encoder: Partword starting position	Linear value	24140	5E4C	A	8	UNSIGNED_8	1	
C00436	SSI encoder: Partword length	Linear value	24139	5E4B	A	8	UNSIGNED_8	1	
C00437	SSI encoder: Partword data coding	Selection list	24138	5E4A	A	8	UNSIGNED_8	1	
C00443	Status: Digital inputs	Linear value	24132	5E44	A	12	UNSIGNED_8	1	
C00444	Status: Digital outputs	Linear value	24131	5E43	A	18	UNSIGNED_8	1	
C00464	Keypad: Mode	Selection list	24111	5E2F	E	1	UNSIGNED_16	1	
C00465	Keypad: Time-out welcome screen	Selection list	24110	5E2E	E	1	UNSIGNED_8	1	
C00466	Keypad: Default parameter	Linear value	24109	5E2D	E	1	UNSIGNED_16	1	
C00467	Keypad: Default welcome screen	Selection list	24108	5E2C	E	1	UNSIGNED_8	1	
C00469	Keypad: Fct. STOP key	Selection list	24106	5E2A	E	1	UNSIGNED_8	1	
C00490	Position encoder selection	Selection list	24085	5E15	E	1	UNSIGNED_16	1	CINH
C00494	Motor standstill time constant	Linear value	24081	5E11	E	1	UNSIGNED_32	1	
C00495	Motor encoder selection	Selection list	24080	5E10	E	1	UNSIGNED_16	1	CINH
C00497	Act. speed value time constant	Linear value	24078	5E0E	E	1	UNSIGNED_32	10	
C00569	Resp. to brake trans. Ixt > C00570	Selection list	24006	5DC6	E	1	UNSIGNED_32	1	
C00570	Warning thres. brake transistor	Linear value	24005	5DC5	E	1	UNSIGNED_32	1	
C00571	Resp. to brake res. i ² t > C00572	Selection list	24004	5DC4	E	1	UNSIGNED_32	1	
C00572	Warning thres. brake resistor	Linear value	24003	5DC3	E	1	UNSIGNED_32	1	
C00573	Resp. to brake transistor overload	Selection list	24002	5DC2	E	1	UNSIGNED_32	1	
C00574	Resp. to brake resist. overtemp.	Selection list	24001	5DC1	E	1	UNSIGNED_32	1	
C00576	Speed monitoring tolerance	Linear value	23999	5DBF	E	1	UNSIGNED_32	1	
C00577	Field weakening controller gain	Linear value	23998	5DBE	E	1	UNSIGNED_32	1000	
C00578	Field weak. contr. reset time	Linear value	23997	5DBD	E	1	UNSIGNED_32	10	
C00579	Resp. to speed monitoring	Selection list	23996	5DBC	E	1	UNSIGNED_32	1	
C00580	Resp. to encoder open circuit	Selection list	23995	5DBB	E	1	UNSIGNED_32	1	
C00581	Resp. to external fault	Selection list	23994	5DBA	E	1	UNSIGNED_32	1	
C00582	Resp. to heatsink temp. > C00122	Selection list	23993	5DB9	E	1	UNSIGNED_32	1	
C00583	Resp. to motor KTY overtemp.	Selection list	23992	5DB8	E	1	UNSIGNED_32	1	
C00584	Resp. to motor temp. > C00121	Selection list	23991	5DB7	E	1	UNSIGNED_32	1	
C00585	Resp. to motor overtemp. PTC	Selection list	23990	5DB6	E	1	UNSIGNED_32	1	
C00586	Resp. to resolver open circuit	Selection list	23989	5DB5	E	1	UNSIGNED_32	1	
C00587	Fan control status	Bit coded	23988	5DB4	E	1	BITFIELD_8	1	
C00588	Resp. to failure t. sensor drive	Selection list	23987	5DB3	E	1	UNSIGNED_32	1	
C00589	Resp. to CPU temperature > C00126	Selection list	23986	5DB2	E	1	UNSIGNED_32	1	
C00591	Resp. to CAN RPDOx error	Selection list	23984	5DB0	A	4	UNSIGNED_8	1	
C00594	Response to temp. sensor motor X7/ X8	Selection list	23981	5DAD	E	1	UNSIGNED_32	1	
C00595	Resp. to CAN bus OFF	Selection list	23980	5DAC	E	1	UNSIGNED_8	1	
C00596	Threshold max. speed reached	Linear value	23979	5DAB	E	1	UNSIGNED_32	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00597	Resp. to motor phase failure	Selection list	23978	5DAA	E	1	UNSIGNED_32	1	
C00598	Resp. to open circuit AIN1	Selection list	23977	5DA9	E	1	UNSIGNED_32	1	
C00599	Motor phase failure threshold	Linear value	23976	5DA8	E	1	INTEGER_32	10	
C00600	Resp. to DC bus overvoltage	Selection list	23975	5DA7	E	1	UNSIGNED_32	1	
C00601	Resp. to encoder comm. error	Selection list	23974	5DA6	E	1	UNSIGNED_32	1	
C00604	Resp. to device monit. > C00123	Selection list	23971	5DA3	E	1	UNSIGNED_32	1	
C00606	Resp. to motor overload > C00127	Selection list	23969	5DA1	E	1	UNSIGNED_32	1	
C00607	Resp. to max. speed reached	Selection list	23968	5DA0	E	1	UNSIGNED_32	1	
C00610	Resp. to failure heatsink fan	Selection list	23965	5D9D	E	1	UNSIGNED_32	1	
C00611	Resp. to failure integral fan	Selection list	23964	5D9C	E	1	UNSIGNED_32	1	
C00612	Resp. to CAN node guarding error	Selection list	23963	5D9B	A	32	UNSIGNED_8	1	
C00613	Resp. to CAN Heartbeat error	Selection list	23962	5D9A	A	32	UNSIGNED_8	1	
C00614	Resp. to CAN life guarding error	Selection list	23961	5D99	E	1	UNSIGNED_8	1	
C00615	Resp. to imp. device config.	Selection list	23960	5D98	A	5	UNSIGNED_32	1	
C00618	No. of CRC cycles	Linear value	23957	5D95	E	1	UNSIGNED_32	1	
C00619	Resp. to motor current > C00620	Selection list	23956	5D94	E	1	UNSIGNED_32	1	
C00620	Ultimate motor current I_ult	Linear value	23955	5D93	E	1	UNSIGNED_32	10	
C00621	Resp. to encoder pulse deviation	Selection list	23954	5D92	E	1	UNSIGNED_32	1	
C00625	CAN behaviour in case of fault	Selection list	23950	5D8E	E	1	UNSIGNED_8	1	
C00635	Resp to new firmw. standard dev.	Selection list	23940	5D84	E	1	UNSIGNED_32	1	
C00636	Resp. to new module in MXI1	Selection list	23939	5D83	E	1	UNSIGNED_32	1	
C00637	Resp. to new module in MXI2	Selection list	23938	5D82	E	1	UNSIGNED_32	1	
C00640	Resp. to PLI monitoring	Selection list	23935	5D7F	E	1	UNSIGNED_32	1	
C00641	PLI 360° current amplitude	Linear value	23934	5D7E	E	1	UNSIGNED_32	1	
C00642	PLI 360° ramp time	Linear value	23933	5D7D	E	1	UNSIGNED_32	1	
C00643	PLI 360° traversing direction	Selection list	23932	5D7C	E	1	UNSIGNED_32	1	
C00644	PolePosId 360° fault tol.	Linear value	23931	5D7B	E	1	INTEGER_32	10	
C00645	PolePosId 360° absolute cur. amp.	Linear value	23930	5D7A	E	1	UNSIGNED_32	100	
C00646	PolePosId min.mov. cur. amp.	Linear value	23929	5D79	E	1	UNSIGNED_32	1	
C00647	PolePosId min.mov. cur.rise rate	Linear value	23928	5D78	E	1	UNSIGNED_32	1	
C00648	PLI min. motion gain	Linear value	23927	5D77	E	1	UNSIGNED_32	100	
C00649	PLI min. motion reset time	Linear value	23926	5D76	E	1	UNSIGNED_32	100	
C00650	PLI min. motion max. perm. motion	Linear value	23925	5D75	E	1	INTEGER_32	1	
C00651	PolePosId min.mov. absolute cur. amp.	Linear value	23924	5D74	E	1	UNSIGNED_32	100	
C00691	Total speed setpoint	Linear value	23884	5D4C	E	1	INTEGER_32	100	
C00692	Speed setpoint [%]	Linear value	23883	5D4B	E	1	INTEGER_32	100	
C00693	Actual speed [%]	Linear value	23882	5D4A	E	1	INTEGER_32	100	
C00694	Speed controller output	Linear value	23881	5D49	E	1	INTEGER_32	100	
C00695	Total torque setpoint	Linear value	23880	5D48	E	1	INTEGER_32	100	
C00696	Torque setpoint [%]	Linear value	23879	5D47	E	1	INTEGER_32	100	
C00697	Filtered torque setpoint	Linear value	23878	5D46	E	1	INTEGER_32	100	
C00698	Actual torque [%]	Linear value	23877	5D45	E	1	INTEGER_32	100	
C00770	MCTRL_dnMotorPosAct	Linear value	23805	5CFD	A	2	UNSIGNED_32	1	
C00771	MCTRL_dnLoadPosAct	Linear value	23804	5CFC	A	2	UNSIGNED_32	1	
C00772	MCTRL_dnMotorSpeedAct	Linear value	23803	5CFB	E	1	INTEGER_32	1	
C00773	MCTRL_dnLoadSpeedAct	Linear value	23802	5CFA	E	1	INTEGER_32	1	
C00774	MCTRL_dnTorqueAct	Linear value	23801	5CF9	E	1	INTEGER_32	100	
C00775	MCTRL_dnOutputSpeedCtrl	Linear value	23800	5CF8	E	1	INTEGER_32	100	
C00776	MCTRL_dnInputJerkCtrl	Linear value	23799	5CF7	E	1	INTEGER_32	100	
C00777	MCTRL_dnInputTorqueCtrl	Linear value	23798	5CF6	E	1	INTEGER_32	100	
C00778	MCTRL_dnFluxAct	Linear value	23797	5CF5	E	1	INTEGER_32	100	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00779	MCTRL_dnDCBusVoltage	Linear value	23796	5CF4	E	1	INTEGER_32	1	
C00780	MCTRL_dnImotAct	Linear value	23795	5CF3	E	1	INTEGER_32	100	
C00781	MCTRL_dwMaxMotorSpeed	Linear value	23794	5CF2	E	1	UNSIGNED_32	1	
C00782	MCTRL_dwMaxMotorTorque	Linear value	23793	5CF1	E	1	UNSIGNED_32	1000	
C00783	MCTRL_dwMotorVoltageAct	Linear value	23792	5CF0	E	1	UNSIGNED_32	1	
C00784	MCTRL_dnMotorFreqAct	Linear value	23791	5CEF	E	1	INTEGER_32	10	
C00786	MCTRL_dnIxtLoad	Linear value	23789	5CED	E	1	INTEGER_32	100	
C00787	MCTRL_dnFlyingSpeedAct	Linear value	23788	5CEC	E	1	INTEGER_32	1	
C00788	MCTRL_dwMaxEffMotorTorque	Linear value	23787	5CEB	E	1	INTEGER_32	1000	
C00789	MCTRL_dwMaxDeviceCurrent	Linear value	23786	5CEA	E	1	INTEGER_32	100	
C00790	MCTRL_dnI2xtLoad	Linear value	23785	5CE9	E	1	INTEGER_32	100	
C00791	MCTRL_dnDeltaMotorPos_p	Linear value	23784	5CE8	E	1	INTEGER_32	1	
C00792	MCTRL_dnOutputPosCtrlMotor_s	Linear value	23783	5CE7	E	1	INTEGER_32	1	
C00800	MCTRL_dnPosSet	Linear value	23775	5CDF	A	2	UNSIGNED_32	1	
C00802	MCTRL_dnSpeedAdd	Linear value	23773	5CDD	E	1	INTEGER_32	1	
C00803	MCTRL_dnTorqueAdd	Linear value	23772	5CDC	E	1	INTEGER_32	1000	
C00804	MCTRL_dnAccelerationAdd	Linear value	23771	5CDB	E	1	INTEGER_32	1000	
C00805	MCTRL_dnSpeedLowLimit	Linear value	23770	5CDA	E	1	INTEGER_32	1	
C00806	MCTRL_dnTorqueLowLimit	Linear value	23769	5CD9	E	1	INTEGER_32	100	
C00807	MCTRL_dnTorqueHighLimit	Linear value	23768	5CD8	E	1	INTEGER_32	100	
C00808	MCTRL_dnPosCtrlOutLimit	Linear value	23767	5CD7	E	1	INTEGER_32	1	
C00809	MCTRL_dnTorqueCtrlAdapt	Linear value	23766	5CD6	E	1	INTEGER_32	100	
C00810	MCTRL_dnSpeedCtrlAdapt	Linear value	23765	5CD5	E	1	INTEGER_32	100	
C00811	MCTRL_dnPosCtrlAdapt	Linear value	23764	5CD4	E	1	INTEGER_32	100	
C00812	MCTRL_dnMotorPosRefValue	Linear value	23763	5CD3	A	2	UNSIGNED_32	1	
C00813	MCTRL_dnLoadPosRefValue	Linear value	23762	5CD2	A	2	UNSIGNED_32	1	
C00814	MCTRL_dnBoost	Linear value	23761	5CD1	E	1	INTEGER_32	1	
C00815	MCTRL_dnSpeedCtrlIntegrator	Linear value	23760	5CD0	E	1	INTEGER_32	1000	
C00816	MCTRL_dnFieldWeak	Linear value	23759	5CCF	E	1	INTEGER_32	100	
C00817	MCTRL_dnSpeedSet_s	Linear value	23758	5CCE	E	1	INTEGER_32	1	
C00818	MCTRL_dnMvorAdapt	Linear value	23757	5CCD	E	1	INTEGER_32	100	
C00854	ID status	Linear value	23721	5CA9	E	1	UNSIGNED_32	1	
C00878	Status DCTRL control input	Linear value	23697	5C91	A	5	UNSIGNED_8	1	
C00909	Speed limitation	Linear value	23666	5C72	A	2	INTEGER_16	10	
C00950	VFC: V/f characteristic shape	Selection list	23625	5C49	E	1	UNSIGNED_32	1	
C00951	VFC: V/f base frequency	Linear value	23624	5C48	E	1	INTEGER_32	1	
C00952	VFC: Frequency interpol. point n	Linear value	23623	5C47	A	11	INTEGER_32	1	CINH
C00953	VFC: Voltage interpol. point n	Linear value	23622	5C46	A	11	INTEGER_32	100	CINH
C00954	VFC: Activat. interpol. point n	Selection list	23621	5C45	A	11	UNSIGNED_32	1	CINH
C00955	VFC: Vmax reduction	Linear value	23620	5C44	E	1	UNSIGNED_32	1	
C00957	VFC: VVC current setpoint	Linear value	23618	5C42	E	1	INTEGER_32	100	
C00958	VFC: VVC gain	Linear value	23617	5C41	E	1	UNSIGNED_32	100	
C00959	VFC: VVC reset time	Linear value	23616	5C40	E	1	UNSIGNED_32	100	
C00960	VFC: V/f voltage boost	Linear value	23615	5C3F	E	1	INTEGER_32	1	
C00961	VFC: Load - cw/ccw-operation	Selection list	23614	5C3E	E	1	UNSIGNED_32	1	CINH
C00962	VFC: Load adjustment	Linear value	23613	5C3D	E	1	UNSIGNED_32	100	
C00963	VFC: Gain - lmax controller	Linear value	23612	5C3C	E	1	UNSIGNED_32	1000	
C00964	VFC: Reset time - lmax controller	Linear value	23611	5C3B	E	1	UNSIGNED_32	10	
C00965	VFC: Gain - slip compensation	Linear value	23610	5C3A	E	1	INTEGER_32	100	
C00966	VFC: Time const. slip comp.	Linear value	23609	5C39	E	1	UNSIGNED_32	1	
C00967	VFC: Gain - oscillation damping	Linear value	23608	5C38	E	1	INTEGER_32	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C00968	VFC: Time const. - oscill. damp.	Linear value	23607	5C37	E	1	INTEGER_32	1	
C00969	VFC: Limitation - oscillation damping	Linear value	23606	5C36	E	1	INTEGER_32	10	
C00970	VFC: ramp-end frequ. - oscill. damp.	Linear value	23605	5C35	E	1	INTEGER_32	1	
C00971	VFC: Influence - speed controller	Linear value	23604	5C34	E	1	UNSIGNED_32	100	
C00972	VFC: Gain - speed controller	Linear value	23603	5C33	E	1	UNSIGNED_32	1000	
C00973	VFC: Reset time - speed contr.	Linear value	23602	5C32	E	1	UNSIGNED_32	10	
C00974	DC brake: Current	Linear value	23601	5C31	E	1	INTEGER_32	100	
C00975	DC brake: Current for quick stop	Linear value	23600	5C30	E	1	INTEGER_32	100	
C00976	DC brake: Activat. by quick stop	Selection list	23599	5C2F	E	1	UNSIGNED_32	1	
C00977	Min. inh-time aft. overvolt.	Linear value	23598	5C2E	E	1	UNSIGNED_32	1	
C00980	VFC: Override point of field weakening	Linear value	23595	5C2B	E	1	INTEGER_32	1	
C00985	SLVC: Gain of field current controller	Linear value	23590	5C26	E	1	UNSIGNED_32	100	
C00986	SLVC: Gain of cross current controller	Linear value	23589	5C25	E	1	UNSIGNED_32	100	
C00987	SLVC: Gain - torque controller	Linear value	23588	5C24	E	1	UNSIGNED_32	10000	
C00988	SLVC: Torque controller reset time	Linear value	23587	5C23	E	1	UNSIGNED_32	100	
C00989	SLVC: Time const.- Para. adj.	Linear value	23586	5C22	A	2	UNSIGNED_32	1	
C00990	Flying restart: Activation	Selection list	23585	5C21	E	1	UNSIGNED_32	1	
C00991	Flying restart: Current	Linear value	23584	5C20	E	1	INTEGER_32	1	
C00992	Flying restart circuit: start frequency	Linear value	23583	5C1F	E	1	INTEGER_32	10	
C00993	Flying restart: Integration time	Linear value	23582	5C1E	E	1	UNSIGNED_32	1	
C00994	Flying restart: Min. deviation	Linear value	23581	5C1D	E	1	UNSIGNED_32	100	
C00995	Flying restart: Delay time	Linear value	23580	5C1C	E	1	UNSIGNED_32	1	
C00998	VFC: Frequency setpoint	Linear value	23577	5C19	E	1	INTEGER_32	10	
C01120	Sync source	Selection list	23455	5B9F	E	1	UNSIGNED_8	1	
C01121	Sync cycle time	Linear value	23454	5B9E	E	1	UNSIGNED_32	1	
C01122	Sync phase position	Linear value	23453	5B9D	E	1	UNSIGNED_32	1	
C01123	Sync tolerance	Linear value	23452	5B9C	E	1	UNSIGNED_32	1	
C01124	Sync PLL increment	Selection list	23451	5B9B	E	1	UNSIGNED_8	1	
C01130	CAN SYNC application cycle	Linear value	23445	5B95	E	1	UNSIGNED_16	1	
C01190	Motor thermal sensor	Selection list	23385	5B59	E	1	UNSIGNED_32	1	
C01191	Spec. characteristic: temperature	Linear value	23384	5B58	A	2	UNSIGNED_32	1	
C01192	Spec. characteristic: resistance	Linear value	23383	5B57	A	2	UNSIGNED_32	1	
C01193	Motor temp. feedback system	Selection list	23382	5B56	E	1	UNSIGNED_16	1	CINH
C01194	Motor operating temperature	Linear value	23381	5B55	E	1	INTEGER_32	1	
C01195	Influence winding I [∗] xt mon.	Linear value	23380	5B54	E	1	UNSIGNED_32	1	
C01196	S1 torque characteristic I [∗] xt mon.	Linear value	23379	5B53	A	8	UNSIGNED_32	1	
C01197	Starting value I [∗] xt monitoring	Linear value	23378	5B52	E	1	UNSIGNED_32	1	
C01198	Async. motor: Stall protection	Linear value	23377	5B51	E	1	UNSIGNED_32	1	
C01199	Enhanced power	Selection list	23376	5B50	E	1	UNSIGNED_32	1	CINH
C01200	Dual motor temperature	Linear value	23375	5B4F	A	2	INTEGER_32	1	
C01201	Delay time for fan start	Selection list	23374	5B4E	E	1	UNSIGNED_32	1	
C01203	Counter: Brake chopper overload	Linear value	23372	5B4C	E	1	UNSIGNED_16	1	
C01204	Counter: Ixt overload	Linear value	23371	5B4B	E	1	UNSIGNED_16	1	
C01205	Counter: DC bus overvoltage	Linear value	23370	5B4A	E	1	UNSIGNED_16	1	
C01206	Counter: Mains switching	Linear value	23369	5B49	E	1	UNSIGNED_16	1	
C01208	Counter: Heatsink overtemp.	Linear value	23367	5B47	E	1	UNSIGNED_16	1	
C01209	Counter: Housing overtemp.	Linear value	23366	5B46	E	1	UNSIGNED_16	1	
C01210	Counter: internal	Linear value	23365	5B45	E	1	UNSIGNED_8	1	
C01212	Counter: Power section overload	Linear value	23363	5B43	E	1	UNSIGNED_16	1	
C01214	Internal clock	String	23361	5B41	E	1	VISIBLE_STRING [21]		
C01215	Set time and date	Linear value	23360	5B40	A	6	UNSIGNED_16	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C01230	Resp. to comm. task overflow	Selection list	23345	5B31	E	1	UNSIGNED_8	1	
C01501	Resp. to comm. error with MX1	Selection list	23074	5A22	E	1	UNSIGNED_32	1	
C01502	Resp. to comm. error with MX12	Selection list	23073	5A21	E	1	UNSIGNED_32	1	
C01510	Ethernet IP address client x	String	23065	5A19	A	3	VISIBLE_STRING [24]		
C01511	Ethernet status client x	Selection list	23064	5A18	A	3	UNSIGNED_8	1	
C01700	Energy: Mode inform.	Linear value	22875	595B	A	2	UNSIGNED_8	1	
C01701	Energy: toff min	Linear value	22874	595A	A	1	UNSIGNED_32	1	
C01702	Energy: toff	Linear value	22873	5959	A	1	UNSIGNED_32	1	
C01703	Energy: ton	Linear value	22872	5958	A	1	UNSIGNED_32	1	
C01704	Energy: Comp. to be switched off	Bit coded	22871	5957	A	1	BITFIELD_32	1	
C01705	Energy: Power input	Linear value	22870	5956	A	1	UNSIGNED_32	1	
C01902	Diagnostics X6: Max. baud rate	Selection list	22673	5891	E	1	UNSIGNED_32	1	
C01903	Diagnostics X6: Change baud rate	Selection list	22672	5890	E	1	UNSIGNED_32	1	
C01905	Diagnostics X6: Curr. baud rate	Linear value	22670	588E	E	1	UNSIGNED_32	1	
C02104	Program auto-start	Selection list	22471	57C7	E	1	UNSIGNED_32	1	
C02108	Program status	Selection list	22467	57C3	E	1	UNSIGNED_8	1	
C02109	Program runtime	Linear value	22466	57C2	E	1	UNSIGNED_16	1	
C02110	User code: Memory utilisation	Linear value	22465	57C1	E	1	UNSIGNED_32	1	
C02111	Resp. to task overflow	Selection list	22464	57C0	E	1	UNSIGNED_8	1	
C02112	B. code: Read non-vol. memory	Linear value	22463	57BF	E	1	UNSIGNED_32	1	
C02113	Program name	String	22462	57BE	E	1	VISIBLE_STRING [32]		
C02119	Active target ID	Linear value	22456	57B8	E	1	UNSIGNED_32	1	
C02121	Runtime ApplicationTask	Linear value	22454	57B6	A	2	UNSIGNED_32	1	
C02122	Runtime UserTask	Linear value	22453	57B5	A	2	UNSIGNED_32	1	
C02123	Runtime IdleTask	Linear value	22452	57B4	A	2	UNSIGNED_32	1	
C02520	Gearbox factor numerator: Motor	Linear value	22055	5627	E	1	INTEGER_32	1	CINH
C02521	Gearbox factor denom.: Motor	Linear value	22054	5626	E	1	INTEGER_32	1	CINH
C02522	Gearbox factor num.: Pos. enc.	Linear value	22053	5625	E	1	INTEGER_32	1	CINH
C02523	Gearbox fac. denom.: Pos. enc.	Linear value	22052	5624	E	1	INTEGER_32	1	CINH
C02524	Feed constant	Linear value	22051	5623	E	1	UNSIGNED_32	10000	CINH
C02525	Unit	Selection list	22050	5622	E	1	UNSIGNED_32	1	
C02526	User-defined unit	String	22049	5621	E	1	VISIBLE_STRING [8]		
C02527	Motor mounting direction	Selection list	22048	5620	E	1	UNSIGNED_32	1	CINH
C02528	Traversing range	Selection list	22047	561F	E	1	UNSIGNED_32	1	CINH
C02529	Position encoder mounting direction	Selection list	22046	561E	E	1	UNSIGNED_32	1	CINH
C02530	Active function state	Selection list	22045	561D	E	1	INTEGER_32	1	
C02531	Gearbox factors (decimal)	Linear value	22044	561C	A	3	UNSIGNED_32	1000	
C02532	Resolution of a unit	Linear value	22043	561B	E	1	UNSIGNED_32	10000	
C02533	Time unit	Selection list	22042	561A	E	1	UNSIGNED_32	1	
C02534	Time unit used	String	22041	5619	E	1	VISIBLE_STRING [8]		
C02535	Unit used	String	22040	5618	E	1	VISIBLE_STRING [8]		
C02536	Cycle length	Linear value	22039	5617	E	1	UNSIGNED_32	10000	CINH
C02537	Speed unit	String	22038	5616	E	1	VISIBLE_STRING [16]		
C02538	Acceleration unit	String	22037	5615	E	1	VISIBLE_STRING [16]		
C02539	Maximum position that can be displayed	Linear value	22036	5614	E	1	INTEGER_32	10000	
C02540	Max. presentable speed	Linear value	22035	5613	E	1	INTEGER_32	10000	
C02541	Max. presentable acceleration	Linear value	22034	5612	E	1	INTEGER_32	10000	
C02542	Load reference speed	Linear value	22033	5611	E	1	UNSIGNED_32	1000	
C02543	Load reference torque	Linear value	22032	5610	E	1	UNSIGNED_32	1000	
C02544	Reference speed	Linear value	22031	560F	E	1	INTEGER_32	10000	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C02545	Reference Jerktime	Linear value	22030	560E	E	1	UNSIGNED_32	1000	
C02547	DI_dnState	Linear value	22028	560C	E	1	INTEGER_32	1	
C02548	DI_bErrors	Selection list	22027	560B	A	4	UNSIGNED_32	1	
C02549	Drive interface: Signals	Selection list	22026	560A	A	15	UNSIGNED_32	1	
C02550	Setpoint interpolation	Selection list	22025	5609	A	3	UNSIGNED_32	1	
C02552	Position setpoint (motor interface)	Linear value	22023	5607	E	1	INTEGER_32	10000	
C02553	Position controller gain	Linear value	22022	5606	E	1	UNSIGNED_32	100	
C02554	Position controller reset time	Linear value	22021	5605	E	1	UNSIGNED_32	1000	
C02555	D component position controller	Linear value	22020	5604	E	1	UNSIGNED_32	1000	
C02556	Pos. contr. limitation	Linear value	22019	5603	E	1	INTEGER_32	10000	
C02557	Phase controller output	Linear value	22018	5602	E	1	INTEGER_32	10000	
C02558	Position controller output	Linear value	22017	5601	E	1	INTEGER_32	10000	
C02559	Internal torque limits	Linear value	22016	5600	A	2	INTEGER_32	100	
C02560	Messages - motor interface	Linear value	22015	55FF	E	1	UNSIGNED_32	1	
C02561	Speed feedforw. control gain	Linear value	22014	55FE	E	1	INTEGER_32	100	
C02562	Filter time constant	Linear value	22013	55FD	E	1	UNSIGNED_32	1000	
C02564	Service code	Bit coded	22011	55FB	E	1	BITFIELD_8	1	
C02567	Control mode	Selection list	22008	55F8	E	1	UNSIGNED_32	1	
C02568	Motor interface: % signals	Linear value	22007	55F7	A	10	INTEGER_32	100	
C02569	Motor interface.: Dig. signals	Selection list	22006	55F6	A	16	UNSIGNED_32	1	
C02570	Position control structure	Selection list	22005	55F5	E	1	UNSIGNED_32	1	CINH
C02572	Speed setpoint (enc. eval.)	Linear value	22003	55F3	E	1	INTEGER_32	10000	
C02573	Position setpoint (enc. eval.)	Linear value	22002	55F2	E	1	INTEGER_32	10000	
C02574	Actual speed (enc. eval.)	Linear value	22001	55F1	E	1	INTEGER_32	10000	
C02575	Actual position (enc. eval.)	Linear value	22000	55F0	E	1	INTEGER_32	10000	
C02576	Following error	Linear value	21999	55EF	E	1	INTEGER_32	10000	
C02577	External actual position	Linear value	21998	55EE	E	1	INTEGER_32	10000	
C02578	Offset actual pos. value/setp.	Linear value	21997	55ED	E	1	INTEGER_32	10000	
C02579	Encoder eval.: Dig. signals	Selection list	21996	55EC	A	4	UNSIGNED_32	1	
C02580	Brake operating mode	Selection list	21995	55EB	E	1	UNSIGNED_32	1	CINH
C02581	Threshold - brake activation	Linear value	21994	55EA	E	1	INTEGER_32	1	
C02582	Brake resp. to pulse inhibit	Selection list	21993	55E9	E	1	UNSIGNED_32	1	
C02583	Status input monitoring	Selection list	21992	55E8	E	1	UNSIGNED_32	1	
C02585	Brake control polarity	Selection list	21990	55E6	E	1	UNSIGNED_32	1	
C02586	Starting torque 1	Linear value	21989	55E5	E	1	INTEGER_32	100	
C02587	Starting torque 2	Linear value	21988	55E4	E	1	INTEGER_32	100	
C02588	Source of starting torque	Selection list	21987	55E3	E	1	UNSIGNED_32	1	
C02589	Brake closing time	Linear value	21986	55E2	E	1	UNSIGNED_32	1	
C02590	Brake opening time	Linear value	21985	55E1	E	1	UNSIGNED_32	1	
C02591	Waiting time - status monitoring	Linear value	21984	55E0	E	1	UNSIGNED_32	1	
C02593	Waiting time - brake activation	Linear value	21982	55DE	E	1	UNSIGNED_32	1000	
C02594	Test torque	Linear value	21981	55DD	E	1	INTEGER_32	100	
C02595	Permissible angle of rotation	Linear value	21980	55DC	E	1	INTEGER_32	1	
C02596	Grinding speed	Linear value	21979	55 db	E	1	INTEGER_32	1	
C02597	Accel./decel. time - grinding	Linear value	21978	55DA	E	1	UNSIGNED_32	1000	
C02598	Grinding ON time	Linear value	21977	55D9	E	1	UNSIGNED_32	10	
C02599	Grinding OFF time	Linear value	21976	55D8	E	1	UNSIGNED_32	10	
C02600	Acceleration time feedf. control	Linear value	21975	55D7	E	1	UNSIGNED_32	1000	
C02601	Reference for acceleration time of brake	Selection list	21974	55D6	E	1	UNSIGNED_32	1	
C02602	Source for feedf. control brake	Selection list	21973	55D5	E	1	UNSIGNED_32	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C02603	Threshold 1 for opening brake	Linear value	21972	55D4	E	1	INTEGER_32	1	
C02604	Threshold 2 for opening brake	Linear value	21971	55D3	E	1	INTEGER_32	1	
C02605	Brake test - time	Linear value	21970	55D2	A	3	UNSIGNED_16	1000	
C02606	Minimum starting torque	Linear value	21969	55D1	E	1	INTEGER_32	100	
C02607	BRK_dnState	Linear value	21968	55D0	E	1	INTEGER_32	1	
C02608	BRK_dnTorqueAdd_n	Linear value	21967	55CF	E	1	INTEGER_32	100	
C02609	Brake control: Dig. signals	Selection list	21966	55CE	A	10	UNSIGNED_32	1	
C02610	Deceleration time for stop	Linear value	21965	55CD	E	1	UNSIGNED_32	1000	
C02611	S-ramp time for stop	Linear value	21964	55CC	E	1	UNSIGNED_32	1000	
C02612	Ref. for decel. time of stop	Selection list	21963	55CB	E	1	UNSIGNED_32	1	
C02616	STP_dnState	Linear value	21959	55C7	E	1	INTEGER_32	1	
C02617	STP_bStopActive	Selection list	21958	55C6	E	1	UNSIGNED_32	1	
C02619	Quick stop: Dig. signals	Selection list	21956	55C4	A	5	UNSIGNED_32	1	
C02620	Manual jog: Speed 1	Linear value	21955	55C3	E	1	INTEGER_32	10000	
C02621	Manual jog: Speed 2	Linear value	21954	55C2	E	1	INTEGER_32	10000	
C02622	Manual jog: Acceleration	Linear value	21953	55C1	E	1	INTEGER_32	10000	
C02623	Manual jog: Deceleration	Linear value	21952	55C0	E	1	INTEGER_32	10000	
C02624	Manual jog: S-ramp time	Linear value	21951	55BF	E	1	UNSIGNED_32	1000	
C02625	Manual jog: Step size	Linear value	21950	55BE	E	1	INTEGER_32	10000	
C02626	Manual jog: Index stop position	Linear value	21949	55BD	A	16	INTEGER_32	1	
C02627	Manual jog: Selected stop position	Linear value	21948	55BC	A	16	INTEGER_32	10000	
C02637	MAN_dnSpeedOverride_n	Linear value	21938	55B2	E	1	INTEGER_32	100	
C02638	Manual jog: Status	Linear value	21937	55B1	E	1	INTEGER_32	1	
C02639	Manual jog: Dig. signals	Selection list	21936	55B0	A	9	UNSIGNED_32	1	
C02640	Homing mode	Selection list	21935	55AF	E	1	UNSIGNED_32	1	
C02641	Action after detect home position	Selection list	21934	55AE	E	1	UNSIGNED_32	1	
C02642	Home position	Linear value	21933	55AD	E	1	INTEGER_32	10000	
C02643	Homing: target position	Linear value	21932	55AC	E	1	INTEGER_32	10000	
C02644	Homing: Speed 1	Linear value	21931	55AB	E	1	INTEGER_32	10000	
C02645	Homing: Acceleration 1	Linear value	21930	55AA	E	1	INTEGER_32	10000	
C02646	Homing: veloc. 2	Linear value	21929	55A9	E	1	INTEGER_32	10000	
C02647	Homing: acceleration 2	Linear value	21928	55A8	E	1	INTEGER_32	10000	
C02648	Homing: S-ramp time	Linear value	21927	55A7	E	1	INTEGER_32	1	
C02649	Homing: Torque limit	Linear value	21926	55A6	E	1	INTEGER_32	100	
C02650	Homing: Blocking time	Linear value	21925	55A5	E	1	UNSIGNED_32	1000	
C02651	Homing: TP configuration	Linear value	21924	55A4	E	1	UNSIGNED_32	1	
C02652	Home pos. following mains switching	Selection list	21923	55A3	E	1	UNSIGNED_32	1	
C02653	Max. rot. ang. aft. mns. swtch.	Linear value	21922	55A2	E	1	INTEGER_32	1	
C02655	HM_dnSpeedOverride_n	Linear value	21920	55A0	E	1	INTEGER_32	100	
C02656	Actual position (homing)	Linear value	21919	559F	E	1	INTEGER_32	10000	
C02657	HM_dnState	Linear value	21918	559E	E	1	INTEGER_32	1	
C02658	HM_dnHomePos_p	Linear value	21917	559D	E	1	INTEGER_32	10000	
C02659	Homing: Dig. signals	Selection list	21916	559C	A	9	UNSIGNED_32	1	
C02670	Tolerance for POS_bActPosInTarget	Linear value	21905	5591	E	1	INTEGER_32	10000	
C02671	Tolerance for POS_bDriveInTarget	Linear value	21904	5590	E	1	INTEGER_32	10000	
C02672	Hysteresis for POS_bDriveInTarget	Linear value	21903	558F	E	1	INTEGER_32	10000	
C02673	Activate DriveInTarget Modulo	Selection list	21902	558E	E	1	UNSIGNED_32	1	
C02674	POS_dwActualProfileNumber	Linear value	21901	558D	E	1	UNSIGNED_32	1	
C02675	POS_dnState	Linear value	21900	558C	E	1	INTEGER_32	1	
C02676	POS_dnProfileSpeed_s	Linear value	21899	558B	E	1	INTEGER_32	10000	
C02677	Positioning: % signals	Linear value	21898	558A	A	3	INTEGER_32	100	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C02678	Positioning: Pos. signals	Linear value	21897	5589	A	4	INTEGER_32	10000	
C02679	Positioning: Dig. signals	Selection list	21896	5588	A	12	UNSIGNED_32	1	
C02680	Source position setpoint	Selection list	21895	5587	E	1	UNSIGNED_32	1	
C02681	Source add. speed	Selection list	21894	5586	E	1	UNSIGNED_32	1	
C02685	PF_dnMotorAcc_x	Linear value	21890	5582	E	1	INTEGER_32	10	
C02686	PF_dnSpeedAdd1_s	Linear value	21889	5581	E	1	INTEGER_32	10	
C02687	Position follower: % signals	Linear value	21888	5580	A	2	INTEGER_32	100	
C02688	PF_dnPositionSet_p	Linear value	21887	557F	E	1	INTEGER_32	10000	
C02689	Position follower: Dig. signals	Selection list	21886	557E	A	2	UNSIGNED_32	1	
C02692	SF_dnMotorAcc_x	Linear value	21883	557B	E	1	INTEGER_32	10	
C02693	SF_dnSpeedAdd_s	Linear value	21882	557A	E	1	INTEGER_32	10	
C02694	Speed follower: % signals	Linear value	21881	5579	A	2	INTEGER_32	100	
C02695	Speed follower: Dig. signals	Selection list	21880	5578	A	2	UNSIGNED_32	1	
C02698	Torque follower: % signals	Linear value	21877	5575	A	3	INTEGER_32	100	
C02699	Torque follower: Dig. signals	Selection list	21876	5574	A	2	UNSIGNED_32	1	
C02700	Software limit positions active	Selection list	21875	5573	E	1	UNSIGNED_32	1	
C02701	Software limit positions	Linear value	21874	5572	A	2	INTEGER_32	10000	
C02702	Limitations effective	Selection list	21873	5571	E	1	UNSIGNED_32	1	
C02703	Max. speed	Linear value	21872	5570	E	1	INTEGER_32	10000	
C02704	Max. speed [rpm]	Linear value	21871	556F	E	1	INTEGER_32	10	
C02705	Max. acceleration	Linear value	21870	556E	E	1	INTEGER_32	10000	
C02706	Min. S-ramp time	Linear value	21869	556D	E	1	UNSIGNED_32	1	
C02707	Permissible direction of rotation	Selection list	21868	556C	E	1	UNSIGNED_32	1	
C02708	Limited speed	Linear value	21867	556B	A	4	INTEGER_32	10000	
C02709	Limited speed [rpm]	Linear value	21866	556 A	A	4	INTEGER_32	10	
C02710	Delay lim. speed	Linear value	21865	5569	A	4	UNSIGNED_32	10000	
C02711	S-ramp time lim. speed	Linear value	21864	5568	A	4	UNSIGNED_32	1	
C02712	Decel. time lim. speed	Linear value	21863	5567	A	4	UNSIGNED_32	1	
C02713	Max. distance manual control	Linear value	21862	5566	E	1	UNSIGNED_32	10000	
C02714	Max. dist. manual jog [inc.]	Linear value	21861	5565	E	1	UNSIGNED_32	1	
C02715	Limitation active	Selection list	21860	5564	E	1	UNSIGNED_32	1	
C02716	Resp. to limitation	Selection list	21859	5563	A	3	UNSIGNED_32	1	
C02717	LIM_dwControl	Linear value	21858	5562	E	1	UNSIGNED_32	1	
C02718	LIM_dnState	Linear value	21857	5561	E	1	INTEGER_32	1	
C02719	Limiter: Dig. signals	Selection list	21856	5560	A	3	UNSIGNED_32	1	
C02720	Software limit position monitoring	Selection list	21855	555F	E	1	UNSIGNED_32	1	
C02730	Analog inputs: Gain	Linear value	21845	5555	A	2	INTEGER_32	100	
C02731	Analog inputs: Offset	Linear value	21844	5554	A	2	INTEGER_32	100	
C02732	Analog inputs: Dead band	Linear value	21843	5553	A	2	INTEGER_32	100	
C02733	Analog outputs: Gain	Linear value	21842	5552	A	2	INTEGER_32	100	
C02734	Analog outputs: Offset	Linear value	21841	5551	A	2	INTEGER_32	100	
C02760	Activate Encoder	Selection list	21815	5537	E	1	UNSIGNED_32	1	
C02761	Resolution Multiturn	Linear value	21814	5536	E	1	UNSIGNED_32	1	
C02762	Encoder position	Linear value	21813	5535	E	1	INTEGER_32	1	
C02763	Encoder revolution	Linear value	21812	5534	E	1	INTEGER_32	1	
C02764	Encoder speed	Linear value	21811	5533	E	1	INTEGER_32	10	
C02765	ENC_bError	Selection list	21810	5532	E	1	UNSIGNED_32	1	
C02770	Operating mode	Selection list	21805	552D	A	5	UNSIGNED_32	1	
C02771	Frequency	Linear value	21804	552C	A	4	INTEGER_32	10	
C02772	Start angle	Linear value	21803	552B	A	4	INTEGER_32	10	
C02773	Current	Linear value	21802	552A	A	4	INTEGER_32	100	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C02774	Acceleration time	Linear value	21801	5529	A	4	INTEGER_32	1000	
C02775	Deceleration time	Linear value	21800	5528	A	4	INTEGER_32	1000	
C02776	Duration time	Linear value	21799	5527	A	4	INTEGER_32	1000	
C02779	Mol_SetpointCurrent	Linear value	21796	5524	E	1	UNSIGNED_32	100	
C02780	Mol_dnState	Linear value	21795	5523	E	1	INTEGER_32	1	
C02781	ManualLogOpenLoop: Dig. signals	Selection list	21794	5522	A	8	UNSIGNED_32	1	
C02785	Activation of PPI	Selection list	21790	551E	E	1	UNSIGNED_32	1	
C02786	Mode of PPI	Selection list	21789	551D	E	1	UNSIGNED_32	1	
C02787	Ppi_dnState	Linear value	21788	551C	E	1	INTEGER_32	1	
C02788	PolePosition Setpoint	Linear value	21787	551B	E	1	INTEGER_32	10	
C02789	PolePositionIdentification: Dig. signals	Selection list	21786	551A	A	9	UNSIGNED_32	1	
C02800	Analog input x: Input signal	Linear value	21775	550F	A	2	INTEGER_16	1	
C02801	Analog output x: Output signal	Linear value	21774	550E	A	2	INTEGER_16	1	
C02802	Status word: Digital outputs	Bit coded	21773	550D	E	1	BITFIELD_32	1	
C02803	Status word: Digital inputs	Bit coded	21772	550C	E	1	BITFIELD_32	1	
C02810	Touch probe x: Delay time	Linear value	21765	5505	A	10	UNSIGNED_32	1	
C02830	Digital inputs: Delay time	Selection list	21745	54F1	A	8	UNSIGNED_8	1	
C02853	Lss sat. characteristic	Linear value	21722	54DA	A	17	UNSIGNED_16	1	CINH
C02855	lmax Lss saturation characteristic	Linear value	21720	54D8	E	1	UNSIGNED_32	10	CINH
C02859	Activate Lss saturation charact.	Selection list	21716	54D4	E	1	UNSIGNED_8	1	CINH
C02860	Rr adjustment	Linear value	21715	54D3	E	1	UNSIGNED_32	100	
C02861	Lh adjustment	Linear value	21714	54D2	E	1	UNSIGNED_32	100	
C02862	Resolver: Gain	Linear value	21713	54D1	A	2	UNSIGNED_16	1	
C02863	Resolver: Angle correction	Linear value	21712	54D0	E	1	INTEGER_16	1	
C02865	Adaptation of Ur	Linear value	21710	54CE	E	1	UNSIGNED_32	100	
C02867	Motor phase failure volt. threshold	Linear value	21708	54CC	E	1	INTEGER_32	10	
C02871	Voltage reserve	Linear value	21704	54C8	E	1	UNSIGNED_32	1	
C02872	PLI 360° result in C58	Selection list	21703	54C7	E	1	UNSIGNED_32	1	
C02900	User Password	String	21675	54AB	E	1	VISIBLE_STRING [22]		
C02901	CamMemory	Linear value	21674	54AA	A	3	UNSIGNED_32	1	
C02902	Time stamp of cam data	Linear value	21673	54A9	A	4	UNSIGNED_32	1	
C02903	GUID cam data		21672	54A8	A	4	OCTET_STRING [16]		
C02905	Online change mode	Selection list	21670	54A6	E	1	UNSIGNED_32	1	
C02906	Online change status	Selection list	21669	54A5	E	1	UNSIGNED_32	1	
C02908	Number of products	Linear value	21667	54A3	E	1	UNSIGNED_32	1	
C02909	Active Product	Linear value	21666	54A2	E	1	UNSIGNED_32	1	
C02910	Product designation	String	21665	54A1	E	1	VISIBLE_STRING [16]		
C02911	Product Choice	Linear value	21664	54A0	E	1	UNSIGNED_32	1	
C02912	Number of products	Linear value	21663	549F	E	1	UNSIGNED_32	1	
C02919	Number of curve tracks	Linear value	21656	5498	E	1	UNSIGNED_32	1	
C02920	Cam Track Choice	Linear value	21655	5497	E	1	UNSIGNED_32	1	
C02921	Cam Track Type	Selection list	21654	5496	E	1	UNSIGNED_32	1	
C02922	Number of Cam Data Points	Linear value	21653	5495	E	1	UNSIGNED_32	1	
C02923	Cam Data Point Choice	Linear value	21652	5494	E	1	UNSIGNED_32	1	
C02924	Change Cam Data Point X	Linear value	21651	5493	E	1	INTEGER_32	10000	
C02925	Change Cam Data Point Y	Linear value	21650	5492	E	1	INTEGER_32	10000	
C02926	Torque feedforward control value	Linear value	21649	5491	E	1	INTEGER_32	100	
C02927	Auto Inc Cam Data Points	Selection list	21648	5490	E	1	UNSIGNED_32	1	
C02939	Number of Cont Tracks	Linear value	21636	5484	E	1	UNSIGNED_32	1	
C02940	Cont Track Choice	Linear value	21635	5483	E	1	UNSIGNED_32	1	
C02941	Cam type	Selection list	21634	5482	E	1	UNSIGNED_32	1	

code	Name	Parameter type	Index		Data				
			dec	hex	DS	DA	Data type	Factor	CINH
C02942	Number of Cont Data Points	Linear value	21633	5481	E	1	UNSIGNED_32	1	
C02943	Cont Data Point Choice	Linear value	21632	5480	E	1	UNSIGNED_32	1	
C02944	Cont Pos X0	Linear value	21631	547F	E	1	INTEGER_32	10000	
C02945	Cont Pos X1	Linear value	21630	547E	E	1	INTEGER_32	10000	
C02946	Cont Time	Linear value	21629	547D	E	1	UNSIGNED_32	10000	
C02959	Number of Position Tracks	Linear value	21616	5470	E	1	UNSIGNED_32	1	
C02960	Pos Track Choice	Linear value	21615	546F	E	1	UNSIGNED_32	1	
C02962	Number of Pos Data Points	Linear value	21613	546D	E	1	UNSIGNED_32	1	
C02963	Pos Data Point Choice	Linear value	21612	546C	E	1	UNSIGNED_32	1	
C02964	Change Pos Data Point X	Linear value	21611	546B	E	1	INTEGER_32	10000	
C02965	Change Pos Data Point Y	Linear value	21610	546A	E	1	INTEGER_32	10000	

Figures

"CAN on board" system bus [295](#)
"LS_SafetyModuleInterface" system block [370](#)
"Online" tab [558](#)

A

Absolute value encoder
 Communication error (error message) [663](#)
Accel./decel. time - grinding (C02597) [876](#)
Acceleration has been limited (error message) [711](#)
Acceleration reduction [385](#)
Acceleration time (C02774) [906](#)
Acceleration time feedf. control (C02600) [876](#)
Acceleration unit (C02538) [864](#)
Access protection [560](#)
Action after detect Home position (C02641) [888](#)
Activate DriveInTarget Modulo (C02673) [892](#)
Activate encoder (C02760) [904](#)
Activate Lss sat. char. (C02859) [916](#)
Activate resolver error compensation (C00418) [798](#)
Active application (C00007) [745](#)
Active function state (C02530) [862](#)
Active Product (C02909) [920](#)
Active target ID (C02119) [859](#)
Actual position (enc. eval.) (C02575) [872](#)
Actual position (homing) (C02656) [890](#)
Actual speed (enc. eval.) (C02574) [871](#)
Actual speed [%] (C00693) [822](#)
Actual speed [rpm] (C00051) [747](#)
Actual speed filter [152](#), [179](#)
Actual speed value outside the tolerance (C00576) (error message) [662](#)
Actual torque [%] (C00698) [823](#)
Actual value detection [152](#)
Adaptation of Ur (C02865) [917](#)
Analog input 1
 Master current < 4 mA (error message) [675](#)
Analog input x
 Input signal (C02800) [909](#)
Analog inputs [277](#)
 Dead band (C02732) [903](#)
 Gain (C02730) [902](#)
 Offset (C02731) [903](#)
Analog output x
 Output signal (C02801) [910](#)
Analog outputs [280](#)
 Gain (C02733) [903](#)
 Offset (C02734) [903](#)
Angular drift monitoring (encoder) [267](#)
Application
 Compiler date (C00213) [770](#)
 ID number (C00218) [771](#)
 Type code (C00212) [770](#)
 Version (C00211) [770](#)

Application and device are incompatible (error message) [683](#)
Application has started (error message) [649](#)
Application is stopped (error message) [648](#), [649](#)
Application notes [17](#)
Application selection (C00005) [744](#)
Application unit [36](#)
ApplicationTask
 Overflow (error message) [647](#)
Asynchronous machine in the field weakening range [159](#)
Asynchronous motor
 Stall protection (C01198) [848](#)
Auto Inc Cam Data Points [570](#)
Auto Inc Cam Data Points (C02927) [923](#)
Auto increment CAM grid points [570](#)
Autom. ENP data transfer (C00202) [768](#)
Autom. restart after mains ON (C00142) [759](#)
Automatic restart [107](#)
Automatic switching frequency reduction [110](#)

B

B. code
 Read non-vol. memory (C02112) [859](#)
Band-stop filter [153](#)
Basic drive functions [377](#)
Basic function "Limiter" [370](#)
Basic functions [377](#)
Behaviour after task overflow [109](#), [293](#)
Behaviour due to change of parameter set (C00227) [772](#)
Behaviour of the outputs after a system event [293](#)
Block function in wrong MEC task (error message) [693](#)
Brake chopper [269](#), [272](#)
 Ixt > C00570 (error message) [672](#)
Brake chopper monitoring [272](#)
Brake chopper utilisation [272](#)
Brake closing time (C02589) [874](#)
Brake control [521](#)
 Dig. signals (C02609) [879](#)
Brake control polarity (C02585) [874](#)
Brake module [528](#), [529](#), [530](#)
Brake opening time (C02590) [875](#)
Brake resistance value (C00129) [757](#)
Brake resistor [273](#)
 I²t overload (error message) [664](#)
 I²t > C00572 (error message) [672](#)
Brake resistor monitoring [273](#)
Brake resistor utilisation [273](#)
Brake resistor utilisation (C00138) [758](#)
Brake resp. to pulse inhibit (C02582) [873](#)
Brake test - time (C02605) [878](#)
Brake transistor [269](#)
 Ixt overload (error message) [664](#)
 Overcurrent (error message) [665](#)
Brake transistor utilisation (C00137) [758](#)
Braking operation [269](#)

Index

Breakpoint reached (error message) [648](#)
BRK_dnState (C02607) [878](#)
BRK_dnTorqueAdd_n (C02608) [878](#)

C

C100 [754](#)
C105 [754](#)
C106 [754](#)
C107 [755](#)
C11 [745](#)
C1120 [843](#)
C1121 [843](#)
C1122 [844](#)
C1123 [844](#)
C1124 [845](#)
C1125 [845](#)
C1126 [845](#)
C1127 [846](#)
C1128 [846](#)
C1129 [846](#)
C1130 [846](#)
C114 [755](#)
C118 [755](#)
C1190 [846](#)
C1191 [847](#)
C1192 [847](#)
C1193 [847](#)
C1194 [847](#)
C1195 [848](#)
C1196 [848](#)
C1197 [848](#)
C1198 [848](#)
C1199 [849](#)
C120 [755](#)
C1200 [849](#)
C1201 [849](#)
C1203 [850](#)
C1204 [850](#)
C1205 [850](#)
C1206 [850](#)
C1208 [850](#)
C1209 [850](#)
C121 [756](#)
C1210 [851](#)
C1211 [851](#)
C1212 [851](#)
C1213 [851](#)
C1214 [851](#)
C1215 [852](#)
C1217 [852](#)
C1218 [852](#)
C122 [756](#)
C1220 [852](#)
C1221 [852](#)
C1222 [853](#)
C1223 [853](#)
C123 [756](#)
C1230 [853](#)
C126 [756](#)
C127 [756](#)
C128 [757](#)
C129 [757](#)
C130 [757](#)
C131 [757](#)
C132 [757](#)
C133 [758](#)
C134 [758](#)
C137 [758](#)
C138 [758](#)
C142 [759](#)
C150 [759](#)
C1501 [853](#)
C1502 [854](#)
C1510 [854](#)
C1511 [854](#)
C155 [760](#)
C156 [760](#)
C158 [761](#)
C159 [762](#)
C162 [762](#)
C166 [762](#)
C167 [763](#)
C168 [763](#)
C169 [763](#)
C1700 [855](#)
C1701 [855](#)
C1702 [855](#)
C1703 [855](#)
C1704 [856](#)
C1705 [857](#)
C171 [763](#)
C173 [764](#)
C174 [765](#)
C175 [765](#)
C176 [765](#)
C177 [765](#)
C178 [765](#)
C179 [765](#)
C18 [746](#)
C180 [766](#)
C181 [766](#)
C182 [766](#)
C183 [766](#)
C185 [767](#)
C186 [767](#)
C187 [767](#)

Index

C188	767	C2533	863
C19	746	C2534	863
C1902	857	C2535	863
C1903	857	C2536	864
C1905	857	C2537	864
C198	767	C2538	864
C199	767	C2539	864
C2	731	C254	772
C200	767	C2540	864
C201	768	C2541	864
C202	768	C2542	865
C203	768	C2543	865
C204	768	C2544	865
C205	769	C2545	865
C206	769	C2547	865
C208	769	C2548	866
C209	770	C2549	866
C210	770	C2550	867
C2104	858	C2552	867
C2108	858	C2553	867
C2109	858	C2554	867
C211	770	C2555	867
C2110	858	C2556	868
C2111	859	C2557	868
C2112	859	C2558	868
C2113	859	C2559	868
C2119	859	C2560	868
C212	770	C2561	869
C2121	859	C2562	869
C2122	860	C2564	869
C2123	860	C2567	869
C213	770	C2568	870
C214	371 , 771	C2569	870
C217	771	C2570	871
C218	771	C2571	871
C219	771	C2572	871
C22	746	C2573	871
C220	771	C2574	871
C225	771	C2575	872
C227	772	C2576	872
C2520	860	C2577	872
C2521	860	C2578	872
C2522	860	C2579	872
C2523	861	C2580	873
C2524	861	C2581	873
C2525	861	C2582	873
C2526	861	C2583	873
C2527	861	C2585	874
C2528	862	C2586	874
C2529	862	C2587	874
C2530	862	C2588	874
C2531	863	C2589	874
C2532	863	C2590	875

Index

C2591	875	C2659	891
C2593	875	C2670	891
C2594	875	C2671	892
C2595	875	C2672	892
C2596	876	C2673	892
C2597	876	C2674	892
C2598	876	C2675	893
C2599	876	C2676	893
C2600	876	C2677	893
C2601	877	C2678	893
C2602	877	C2679	894
C2603	877	C2680	894
C2604	877	C2681	894
C2605	878	C2685	895
C2606	878	C2686	895
C2607	878	C2687	895
C2608	878	C2688	895
C2609	879	C2689	895
C2610	879	C2692	896
C2611	879	C2693	896
C2612	879	C2694	896
C2616	880	C2695	896
C2617	880	C2698	897
C2619	880	C2699	897
C2620	880	C270	772
C2621	881	C2700	897
C2622	881	C2701	897
C2623	881	C2702	898
C2624	881	C2703	898
C2625	881	C2704	898
C2626	882	C2705	898
C2627	882	C2706	898
C2637	882	C2707	899
C2638	883	C2708	899
C2639	883	C2709	899
C2640	886	C271	772
C2641	888	C2710	900
C2642	888	C2711	900
C2643	888	C2712	900
C2644	888	C2713	900
C2645	888	C2714	901
C2646	889	C2715	901
C2647	889	C2716	901
C2648	889	C2717	901
C2649	889	C2718	902
C2650	889	C2719	902
C2651	890	C272	773
C2652	890	C2720	902
C2653	890	C273	773
C2655	890	C2730	902
C2656	890	C2731	903
C2657	891	C2732	903
C2658	891	C2733	903

Index

C2734	903	C2870	918
C274	773	C2871	918
C275	773	C2872	918
C276	774	C2900	918
C2760	904	C2901	919
C2761	904	C2902	919
C2762	904	C2903	919
C2763	904	C2905	920
C2764	904	C2906	920
C2765	905	C2908	920
C2770	905	C2909	920
C2771	905	C2910	921
C2772	906	C2911	921
C2773	906	C2912	921
C2774	906	C2919	921
C2775	907	C2920	921
C2776	907	C2921	922
C2779	907	C2922	922
C2780	907	C2923	922
C2781	908	C2924	922
C2785	908	C2925	922
C2786	908	C2926	923
C2787	908	C2927	923
C2788	909	C2939	923
C2789	909	C2940	923
C280	774	C2941	924
C2800	909	C2942	924
C2801	910	C2943	924
C2802	911	C2944	924
C2803	912	C2945	925
C281	774	C2946	925
C2810	913	C2959	925
C2830	914	C2960	925
C2850	914	C2962	925
C2851	914	C2963	926
C2852	914	C2964	926
C2853	915	C2965	926
C2854	915	C2996	926
C2855	915	C2997	926
C2856	915	C2998	926
C2857	916	C2999	926
C2858	916	C3	735
C2859	916	C308	775
C2860	916	C309	775
C2861	916	C310	775
C2862	916	C311	775
C2863	917	C312	776
C2864	917	C313	776
C2865	917	C314	777
C2866	917	C320	777
C2867	917	C321	778
C2868	917	C322	778
C2869	917	C323	779

Index

C324	779	C398	796
C325	779	C399	796
C326	779	C4	744
C327	779	C412	796
C328	780	C413	797
C329	780	C414	797
C330	780	C415	797
C335	780	C416	797
C336	780	C417	797
C337	780	C418	798
C338	780	C420	798
C34	746	C421	798
C343	780	C422	798
C344	781	C423	798
C345	781	C424	799
C346	781	C427	799
C347	782	C435	799
C348	782	C436	800
C349	782	C437	800
C350	783	C443	801
C351	783	C444	801
C352	783	C462	802
C356	784	C464	802
C357	784	C465	802
C359	784	C466	802
C360	785	C467	802
C361	785	C468	803
C367	786	C469	803
C368	786	C490	803
C369	786	C494	803
C372	787	C495	803
C373	788	C497	804
C374	789	C5	744
C375	789	C50	747
C376	790	C51	747
C377	790	C512	804
C378	790	C513	804
C379	791	C514	804
C381	791	C515	804
C382	791	C516	804
C383	791	C52	747
C385	792	C53	747
C386	792	C54	747
C387	793	C55	748
C388	793	C56	748
C390	793	C569	805
C391	794	C57	748
C392	795	C570	805
C393	795	C571	805
C394	795	C572	806
C395	795	C573	806
C396	795	C574	806
C397	796	C576	806

Index

C577	807	C646	820
C578	807	C647	820
C579	807	C648	821
C58	748	C649	821
C580	807	C65	750
C581	808	C650	821
C582	808	C651	821
C583	808	C658	821
C584	808	C659	822
C585	809	C66	750
C586	809	C68	750
C587	809	C69	750
C588	810	C691	822
C589	810	C692	822
C59	749	C693	822
C591	810	C694	822
C594	811	C695	822
C595	811	C696	822
C596	811	C697	823
C597	812	C698	823
C598	812	C7	745
C599	812	C70	750
C6	745	C71	750
C60	749	C72	751
C600	813	C730	823
C601	813	C731	823
C604	813	C732	823
C606	813	C733	823
C607	814	C734	823
C61	749	C735	823
C610	814	C736	824
C611	814	C737	824
C612	815	C738	824
C613	815	C739	824
C614	816	C74	751
C615	816	C75	751
C618	816	C76	751
C619	817	C77	751
C62	749	C770	824
C620	817	C771	824
C621	817	C772	825
C625	818	C773	825
C63	749	C774	825
C635	818	C775	825
C636	818	C776	825
C637	818	C777	826
C64	749	C778	826
C640	819	C779	826
C641	819	C78	751
C642	819	C780	826
C643	819	C781	826
C644	820	C782	827
C645	820	C783	827

- C784 [827](#)
- C786 [827](#)
- C787 [827](#)
- C788 [828](#)
- C789 [828](#)
- C79 [752](#)
- C790 [828](#)
- C791 [828](#)
- C792 [828](#)
- C8 [745](#)
- C80 [752](#)
- C800 [829](#)
- C802 [829](#)
- C803 [829](#)
- C804 [829](#)
- C805 [829](#)
- C806 [830](#)
- C807 [830](#)
- C808 [830](#)
- C809 [830](#)
- C81 [752](#)
- C810 [830](#)
- C811 [831](#)
- C812 [831](#)
- C813 [831](#)
- C814 [831](#)
- C815 [831](#)
- C816 [832](#)
- C817 [832](#)
- C818 [832](#)
- C82 [752](#)
- C83 [752](#)
- C84 [752](#)
- C85 [753](#)
- C854 [832](#)
- C87 [753](#)
- C878 [832](#)
- C88 [753](#)
- C89 [753](#)
- C90 [753](#)
- C909 [833](#)
- C91 [753](#)
- C92 [754](#)
- C93 [754](#)
- C950 [833](#)
- C951 [833](#)
- C952 [834](#)
- C953 [834](#)
- C954 [835](#)
- C955 [835](#)
- C957 [835](#)
- C958 [836](#)
- C959 [836](#)
- C960 [836](#)
- C961 [836](#)
- C962 [836](#)
- C963 [837](#)
- C964 [837](#)
- C965 [837](#)
- C966 [837](#)
- C967 [837](#)
- C968 [838](#)
- C969 [838](#)
- C970 [838](#)
- C971 [838](#)
- C972 [838](#)
- C973 [839](#)
- C974 [839](#)
- C975 [839](#)
- C976 [839](#)
- C977 [839](#)
- C980 [840](#)
- C985 [840](#)
- C986 [840](#)
- C987 [840](#)
- C988 [840](#)
- C989 [841](#)
- C99 [754](#)
- C990 [841](#)
- C991 [841](#)
- C992 [841](#)
- C993 [842](#)
- C994 [842](#)
- C995 [842](#)
- C998 [842](#)
- Cam data
 - Invalid product number (error message) [723](#)
 - Invalidated due to change of mechanical data (error message) [722](#)
 - Serial number MM does not match (error message) [713](#)
- Cam data are corrupted (error message) [713](#)
- Cam data locked due to incorrect password (error message) [714](#)
- Cam data locked due to incorrect safety key (error message) [714](#)
- Cam data management [557](#)
- Cam Data Point Choice (C02923) [922](#)
- Cam data restored (error message) [713](#)
- Cam Track Choice (C02920) [921](#)
- Cam Track Type (C02921) [922](#)
- CamMemory (C02901) [919](#)
- CAN baud rate (C00351) [783](#)
- CAN baud rate setting [300](#)
- CAN behaviour in case of fault (C00625) [818](#)
- CAN bus load (C00361) [785](#)
- CAN delay boot-up - Operational (C00378) [790](#)
- CAN emergency delay time (C00392) [795](#)

- CAN Emergency Object (C00391) [794](#)
- CAN error (C00345) [781](#)
- CAN Error Register (DS301V402) (C00390) [793](#)
- CAN Guard Time (C00382) [791](#)
- CAN heartbeat activity (C00346) [781](#)
- CAN Heartbeat Consumer Time (C00385) [792](#)
- CAN Heartbeat producer time (C00381) [791](#)
- CAN heartbeat status (C00347) [782](#)
- CAN Life Time Factor (C00383) [791](#)
- CAN module (MXI1)
 - Basic configuration invalid (error message) [696](#)
 - Bus off (error message) [695](#)
 - Faulty emergency configuration (error message) [697](#)
 - Faulty NMT slave configuration (error message) [697](#)
 - Heartbeat error index 1 ... 32 (error message) [696](#)
 - Invalid node address 0 (error message) [695](#)
 - Lifeguarding error (error message) [696](#)
 - NMT master configuration faulty (error message) [698](#)
 - Node guarding error 1 ... 32 (error message) [697](#)
- CAN module (MXI1) PDO manager
 - Faulty configuration (error message) [700](#)
- CAN module (MXI1) RPDO1
 - Telegram not received or faulty (error message) [698](#)
- CAN module (MXI1) RPDO2
 - Telegram not received or faulty (error message) [698](#)
- CAN module (MXI1) RPDO3
 - Telegram not received or faulty (error message) [699](#)
- CAN module (MXI1) RPDO4
 - Telegram not received or faulty (error message) [699](#)
- CAN module (MXI1) RPDO5
 - Telegram not received or faulty (error message) [699](#)
- CAN module (MXI1) RPDO6
 - Telegram not received or faulty (error message) [699](#)
- CAN module (MXI1) RPDO7
 - Telegram not received or faulty (error message) [700](#)
- CAN module (MXI1) RPDO8
 - Telegram not received or faulty (error message) [700](#)
- CAN module (MXI1) SDO client
 - Faulty configuration (error message) [701](#)
- CAN module (MXI1) SDO server
 - Faulty configuration (error message) [700](#)
- CAN module (MXI2)
 - Basic configuration invalid (error message) [703](#)
 - Bus off (error message) [702](#)
 - Faulty emergency configuration (error message) [704](#)
 - Heartbeat error index 1 ... 32 (error message) [703](#)
 - Invalid node address 0 (error message) [703](#)
 - Lifeguarding error (error message) [704](#)
 - NMT master configuration faulty (error message) [705](#)
 - NMT slave configuration faulty (error message) [704](#)
 - Node guarding error 1 ... 32 (error message) [705](#)
- CAN module (MXI2) PDO manager
 - Faulty configuration (error message) [707](#)
- CAN module (MXI2) RPDO1
 - Telegram not received or faulty (error message) [705](#)
- CAN module (MXI2) RPDO2
 - Telegram not received or faulty (error message) [706](#)
- CAN module (MXI2) RPDO3
 - Telegram not received or faulty (error message) [706](#)
- CAN module (MXI2) RPDO4
 - Telegram not received or faulty (error message) [706](#)
- CAN module (MXI2) RPDO5
 - Telegram not received or faulty (error message) [706](#)
- CAN module (MXI2) RPDO6
 - Telegram not received or faulty (error message) [707](#)
- CAN module (MXI2) RPDO7
 - Telegram not received or faulty (error message) [707](#)
- CAN module (MXI2) RPDO8
 - Telegram not received or faulty (error message) [707](#)
- CAN module (MXI2) SDO client
 - Faulty configuration (error message) [708](#)
- CAN module (MXI2) SDO server
 - Faulty configuration (error message) [708](#)
- CAN node address (C00350) [783](#)
- CAN Node Guarding (C00386) [792](#)
- CAN Node Guarding Activity (C00387) [793](#)
- CAN node guarding status (C00388) [793](#)
- CAN on board [295](#)
 - Basic configuration invalid (error message) [676](#)
 - Bus off (error message) [676](#)
 - emergency configuration faulty (error message) [678](#)
 - Heartbeat error index 1 ... 32 (error message) [677](#)
 - Invalid node address 0 (error message) [676](#)
 - Lifeguarding guarding error (error message) [677](#)
 - NMT master configuration faulty (error message) [678](#)
 - NMT slave configuration faulty (error message) [677](#)
 - Node guarding error 1 ... 32 (error message) [678](#)
- CAN on board PDO manager
 - configuration faulty (error message) [680](#)
- CAN on board RPDO1
 - Telegram not received or faulty (error message) [679](#)
- CAN on board RPDO2
 - Telegram not received or faulty (error message) [679](#)
- CAN on board RPDO3
 - Telegram not received or faulty (error message) [679](#)
- CAN on board RPDO4
 - Telegram not received or faulty (error message) [679](#)
- CAN on board SDO client
 - configuration faulty (error message) [680](#)
- CAN on board SDO server
 - configuration faulty (error message) [680](#)
- CAN predefined error field (DS301V402) (C00394) [795](#)
- CAN result - bus scan (C00393) [795](#)
- CAN RPDO counter (C00344) [781](#)
- CAN RPDOx identifier (C00321) [778](#)
- CAN RPDOx monitoring time (C00357) [784](#)
- CAN RPDOx Rx mode (C00323) [779](#)
- CAN SDO client node address (C00374) [789](#)
- CAN SDO client Rx identifier (C00375) [789](#)
- CAN SDO client Tx identifier (C00376) [790](#)
- CAN SDO server node address (C00377) [790](#)

- CAN SDO server Rx identifier (C00372) [787](#)
 - CAN SDO server Tx identifier (C00373) [788](#)
 - CAN setting - DIP switch (C00349) [782](#)
 - CAN slave/master (C00352) [783](#)
 - CAN status (C00359) [784](#)
 - CAN status DIP switch (C00348) [782](#)
 - CAN SYNC application cycle (C01130) [846](#)
 - CAN SYNC Rx identifier (C00367) [786](#)
 - CAN sync transmission cycle time (C00369) [786](#)
 - CAN SYNC Tx identifier (C00368) [786](#)
 - CAN telegram and error counter (C00360) [785](#)
 - CAN TPDO counter (C00343) [780](#)
 - CAN TPDO1 mask byte x (C00311) [775](#)
 - CAN TPDO2 mask byte x (C00312) [776](#)
 - CAN TPDO3 mask byte x (C00313) [776](#)
 - CAN TPDO4 mask byte x (C00314) [777](#)
 - CAN TPDOx cycle time (C00356) [784](#)
 - CAN TPDOx delay time (C00324) [779](#)
 - CAN TPDOx identifier (C00320) [777](#)
 - CAN TPDOx Tx mode (C00322) [778](#)
 - CAN/EPL device type (C219) [771](#)
 - Capacitor temperature (C00068) [750](#)
 - Change Cam Data Point M (C02926) [923](#)
 - Change Cam Data Point X (C02924) [922](#)
 - Change Cam Data Point Y (C02925) [922](#)
 - Change of the basic function [385](#)
 - Change Pos Data Point X (C02964) [926](#)
 - Change Pos Data Point Y (C02965) [926](#)
 - Changing cam data via parameterisation [569](#)
 - Check configuration (C225) [771](#)
 - Clock [851](#), [852](#)
 - COB-ID [302](#)
 - COB-ID EMCY (I-1014) [350](#)
 - COB-ID SYNC message (I-1005) [346](#)
 - Code number duplicated (error message) [688](#)
 - Code refresh (error message) [643](#)
 - Combination memory module/device not possible (error message) [641](#)
 - Combination MXI1/MXI2 not possible (error message) [640](#)
 - Combination of module in MXI1/device not possible (error message) [642](#)
 - Combination of module in MXI2/device not possible (error message) [642](#)
 - Communication cycle period (I-1006) [347](#)
 - Communication error between device and device module (error message) [675](#)
 - Communication task
 - Standstill > 3 s (error message) [692](#)
 - Communication with module in MXI1 interrupted (error message) [675](#)
 - Communication with module in MXI2 interrupted (error message) [676](#)
 - Communication with safety module interrupted (error message) [693](#)
 - Config. analog input 1 (C00034) [746](#)
 - Configuration of system events [293](#)
 - ConnectTable active (error message) [686](#)
 - Consumer heartbeat time (I-1016) [351](#)
 - Cont Data Point Choice (C02943) [924](#)
 - Cont Pos X0 (C02944) [924](#)
 - Cont Pos X1 (C02945) [925](#)
 - Cont Time (C02946) [925](#)
 - Cont Track Choice (C02940) [923](#)
 - Cont Type (C02941) [924](#)
 - Control card
 - Supply voltage (24 V DC) too low (error message) [651](#)
 - Control card is defect (error message) [635](#), [637](#)
 - Control card is defect (UB18 neg.) (error message) [658](#)
 - Control card is defect (UB24) (error message) [657](#)
 - Control card is defect (UB8) (error message) [657](#)
 - Control card is defect (VCC15 neg.) (error message) [657](#)
 - Control card is defect (VCC15) (error message) [657](#)
 - Control card is defect (VCC5) (error message) [658](#)
 - Control card is incompatible (error message) [638](#)
 - Control mode (C02567) [869](#)
 - Control of two motor brakes [556](#)
 - Controlled operation (without feedback) [412](#)
 - Controller enabled (error message) [652](#)
 - Controller in STO state (error message) [652](#)
 - Controller inhibit by (source) (C00158) [761](#)
 - Correction of the leakage inductance [204](#)
 - CPU
 - Overtemperature (error message) [654](#)
 - Temperature > C00126 (error message) [654](#)
 - Thermal detector is defect (error message) [655](#)
 - CPU temp. warning threshold (C00126) [756](#)
 - CPU temperature (C00069) [750](#)
 - Curr. control par. of C75 C76 (C2866) [917](#)
 - Current (C02773) [906](#)
 - Current contr. reset time (C00076) [751](#)
 - Current controller gain (C00075) [751](#)
 - Current setpoint filter [153](#)
 - Cycle (C02536) [864](#)
 - Cyclic task
 - Standstill > 60 s (error message) [692](#)
- ## D
- D component position controller (C02555) [867](#)
 - Data type [725](#)
 - Date [851](#), [852](#)
 - DC brake
 - Activat. by quick stop (C00976) [839](#)
 - Current (C00974) [839](#)
 - Current for quick stop (C00975) [839](#)
 - DC bus overvoltage (error message) [661](#)
 - DC bus undervoltage (error message) [661](#)
 - DC-bus capacitor
 - Thermal detector is defect (error message) [655](#)
 - DC-bus voltage (C00053) [747](#)

DC-injection braking [215](#), [397](#)
Decel. time - quick stop (C00105) [754](#)
Decel. time lim. speed (C02712) [900](#)
Deceleration has been limited (error message) [711](#)
Deceleration time (C02775) [907](#)
Deceleration time for stop (C02610) [879](#)
Delay lim. speed (C02710) [900](#)
Delay time for fan start (C01201) [849](#)
Depth of current setpoint filter (C00272) [773](#)
Device command status (C00003) [735](#)
Device command transferred incorrectly (error message) [658](#)
Device commands (C00002) [731](#)
Device commands, commands
 See device commands, C2 (device command), C3 (device command status) [45](#)
Device name (C00199) [767](#)
Device state (C00183) [766](#)
Device states [100](#)
Device type (I-1000) [344](#)
Device utilisation (Ixt) (C00064) [749](#)
Device utilisation Ixt > 100 % (error message) [656](#)
Device utilisation Ixt > C00123 (error message) [656](#)
DFIN (MXI1)
 Signal error enable/lamp control (error message) [694](#)
 Supply cannot be corrected anymore (error message) [695](#)
 Track error A-/A (error message) [694](#)
 Track error B-/B (error message) [694](#)
 Track error Z-/Z (error message) [694](#)
DFIN (MXI2)
 Signal error enable/lamp control (error message) [702](#)
 Supply cannot be corrected anymore (error message) [702](#)
 Track error A-/A (error message) [701](#)
 Track error B-/B (error message) [701](#)
 Track error Z-/Z (error message) [701](#)
DFOUT (MXI1)
 Maximum frequency reached (error message) [695](#)
DFOUT (MXI2)
 Maximum frequency reached (error message) [702](#)
DI_bErrors (C02548) [866](#)
DI_dnState (C02547) [865](#)
Diagnostics X6
 Change baud rate (C01903) [857](#)
 Curr. baud rate (C01905) [857](#)
 Max. baud rate (C01902) [857](#)
Dig. input x
 Terminal polarity (C00114) [755](#)
Dig. output x
 Terminal polarity (C00118) [755](#)
Digital inputs [282](#)
 Delay time (C02830) [914](#)
Digital outputs [284](#)
DIP switches of the memory module [299](#)
direct control [528](#)
Disconnection in the case of par. storage (error message) [689](#)
Distribution cam data memory [559](#)

Division by zero (error message) [648](#)
Document history [14](#)
Double motor [228](#), [556](#)
Drive
 Clamp operation (error message) [673](#)
 Overload during acceleration phases (error message) [669](#)
 Pulse inhibit is active (error message) [652](#)
Drive interface [31](#)
 Signals (C02549) [866](#)
DRIVE-ERROR LED [101](#), [609](#)
DRIVE-READY LED [101](#), [609](#)
Dual motor temperature (C01200) [849](#)
Dynamic of resolver evaluation (C00417) [797](#)
Dynamics of the actual value detection [152](#)

E

Earth fault detected (error message) [662](#)
Elapsed-hour meter (C00178) [765](#)
Electronic cam [557](#)
Electronic nameplate
 Checksum error (error message) [641](#)
 Communication error (error message) [641](#)
 Data are incompatible (error message) [658](#)
 Data loaded (error message) [668](#)
 Data outside the parameter limits (error message) [670](#)
 Encoder protocol unknown (error message) [668](#)
 Encoder signal unknown (error message) [668](#)
 Not found (error message) [668](#)
Electronic nameplate status (C2858) [916](#)
E-mail to Lenze [967](#)
Emergency telegram [341](#)
EN 60204-1 [369](#)
EN 954 [369](#)
ENC_bError (C02765) [905](#)
Encoder
 Open circuit (error message) [664](#)
Encoder - angular drift monitoring [267](#)
Encoder evaluation [239](#)
 Dig. signals (C02579) [872](#)
Encoder monitoring
 Pulse deviation detected (error message) [671](#)
Encoder position (C02762) [904](#)
Encoder revolution (C02763) [904](#)
Encoder signal X8 [263](#)
Encoder type (C00422) [798](#)
Encoder voltage (C00421) [798](#)
Encoderspeed (C02764) [904](#)
EnDat encoder
 Battery empty (error message) [667](#)
 Command error (error message) [674](#)
 Lamp error (error message) [666](#)
 Overcurrent (error message) [667](#)
 Overvoltage (error message) [666](#)
 Position error (error message) [666](#)
 Position initialisation error (error message) [674](#)

Index

Signal error (error message) 666	0x0068001c 641
Transmission error (error message) 673	0x0068001d 641
Undervoltage (error message) 667	0x0068001e 641
Energy	0x0068001f 641
Comp. to be switched off (C01704) 856	0x00680020 642
Mode inform. (C01700) 855	0x00680021 642
Power input (C01705) 857	0x00680022 642
toff (C01702) 855	0x00680023 642
toff min (C01701) 855	0x00680024 643
ton (C01703) 855	0x00690000 643
Enhanced Power (C01199) 849	0x00690001 643
ENP	0x00690002 643
Identified motor type (C00186) 767	0x00690003 644
Identified serial number (C00187) 767	0x00690004 644
Status (C00188) 767	0x00690005 644
Error	0x00690006 644
Lenze Setting Loaded (error message) 687	0x00690007 644
Error behaviour (I-1029) 352	0x00690008 645
Error description (C00166) 762	0x00690009 645
Error during initialisation (error message) 693	0x0069000a 645
Error message "Unknown error" 626 , 634	0x0069000b 645
Error messages 620	0x0069000c 645
Error messages (short overview) 626	0x0069000d 646
Error messages (system bus) 322	0x006a0000 646
Error number 620	0x006a0001 646
0x00650000 634	0x006a0002 646
0x00650001 634	0x006a0003 647
0x00650002 634	0x006a0004 647
0x00650003 635	0x006a0005 647
0x00680000 635	0x006a0006 647
0x00680001 635	0x006a000d 648
0x00680002 635	0x006a000e 648
0x00680003 636	0x006a000f 648
0x00680004 636	0x006a0010 648
0x00680005 636	0x006a0011 648
0x00680006 636	0x006a0012 649
0x00680007 637	0x006a0013 649
0x00680008 637	0x006a0014 649
0x00680009 637	0x006a0015 649
0x0068000a 637	0x006a0016 650
0x0068000b 637	0x006a0017 650
0x0068000c 638	0x006a001a 650
0x0068000d 638	0x006a001b 651
0x0068000e 638	0x006f0000 651
0x0068000f 638	0x00720000 651
0x00680010 638	0x00750000 651
0x00680011 639	0x00750001 652
0x00680012 639	0x00750003 652
0x00680013 639	0x00750005 652
0x00680014 639	0x00750006 652
0x00680015 639	0x00770000 652
0x00680016 640	0x00770001 653
0x00680017 640	0x00770002 653
0x00680018 640	0x00770003 653
0x00680019 640	0x00770008 654
0x0068001a 640	0x00770009 654
0x0068001b 641	0x0077000a 654
	0x0077000b 654

Index

0x0077000c	655	0x007b002c	667
0x0077000d	655	0x007b002d	667
0x0077000e	655	0x007b002e	667
0x0077000f	655	0x007b002f	668
0x00770010	656	0x007b0030	668
0x00770011	656	0x007b0031	668
0x00780000	656	0x007b0032	668
0x00780001	656	0x007b0033	668
0x00780002	656	0x007b0034	669
0x00780003	657	0x007b0035	669
0x00780004	657	0x007b0036	669
0x00780005	657	0x007b0037	669
0x00780006	657	0x007b0038	669
0x00780007	657	0x007b0039	670
0x00780008	658	0x007b003a	670
0x00780009	658	0x007b003b	670
0x0078000a	658	0x007b003c	671
0x00790000	658	0x007b003d	671
0x00790001	658	0x007b003e	671
0x00790002	659	0x007b003f	672
0x007b0001	659	0x007b0040	672
0x007b0002	659	0x007b0041	672
0x007b0003	659	0x007b0042	672
0x007b0004	659	0x007b0047	673
0x007b0006	660	0x007b004a	673
0x007b0007	660	0x007b004c	673
0x007b0009	660	0x007b004e	673
0x007b000a	660	0x007b004f	674
0x007b000b	660	0x007b0050	674
0x007b000c	661	0x007c0000	674
0x007b000d	661	0x007c0001	674
0x007b000e	661	0x007d0000	675
0x007b000f	661	0x007d0001	675
0x007b0010	661	0x007f0002	675
0x007b0011	662	0x007f0003	675
0x007b0012	662	0x007f0004	676
0x007b0013	662	0x00830000	676
0x007b0014	662	0x00830001	676
0x007b0017	662	0x00830002	676
0x007b0018	663	0x00840000	677
0x007b0019	663	0x00840020	677
0x007b001a	663	0x00840021	677
0x007b001b	664	0x00850000	678
0x007b001c	664	0x00860000	678
0x007b001d	664	0x00860020	678
0x007b001e	664	0x00870000	679
0x007b001f	665	0x00870001	679
0x007b0020	665	0x00870002	679
0x007b0021	665	0x00870003	679
0x007b0023	665	0x00870008	680
0x007b0024	665	0x00880000	680
0x007b0025	666	0x00890000	680
0x007b0026	666	0x008c0000	680
0x007b0027	666	0x008c0001	681
0x007b0028	666	0x008c0002	681
0x007b0029	666	0x008c0003	681
0x007b002a	667	0x008c0004	681
0x007b002b	667	0x008c0005	681

Index

0x008c0006	682	0x00990003	694
0x008c0007	682	0x00990004	695
0x008c0008	682	0x00990005	695
0x008c0009	682	0x009d0000	695
0x008c000a	682	0x009d0001	695
0x008c000b	683	0x009d0002	696
0x008c000c	683	0x009e0000	696
0x008c000d	683	0x009e0020	696
0x008c000e	683	0x009e0021	697
0x008c000f	684	0x009f0000	697
0x008c0010	684	0x00a00000	697
0x008c0011	684	0x00a00020	698
0x008c0012	684	0x00a10000	698
0x008c0013	684	0x00a10001	698
0x008c0014	685	0x00a10002	699
0x008c0015	685	0x00a10003	699
0x008c0016	685	0x00a10004	699
0x008c0017	685	0x00a10005	699
0x008c0018	685	0x00a10006	700
0x008c001a	686	0x00a10007	700
0x008c001d	686	0x00a10008	700
0x008c001e	686	0x00a20000	700
0x00900000	686	0x00a30000	701
0x00900001	687	0x00aa0000	701
0x00900002	687	0x00aa0001	701
0x00900003	687	0x00aa0002	701
0x00900004	687	0x00aa0003	702
0x00900005	687	0x00aa0004	702
0x00900006	688	0x00aa0005	702
0x00900007	688	0x00ac0000	702
0x00900008	688	0x00ac0001	703
0x00900009	688	0x00ac0002	703
0x0090000a	689	0x00ad0000	703
0x0090000b	689	0x00ad0020	704
0x0090000c	689	0x00ad0021	704
0x00910000	689	0x00ae0000	704
0x00910001	690	0x00af0000	705
0x00910002	690	0x00af0020	705
0x00910003	690	0x00b00000	705
0x00910004	690	0x00b00001	706
0x00910005	690	0x00b00002	706
0x00910006	691	0x00b00003	706
0x00910008	691	0x00b00004	706
0x00910009	691	0x00b00005	707
0x0091000a	691	0x00b00006	707
0x0091000b	691	0x00b00007	707
0x0091000c	692	0x00b00008	707
0x0091000d	692	0x00b10000	708
0x0091000e	692	0x00b20000	708
0x0091000f	692	0x00b80000	708
0x00910010	693	0x00b80001	708
0x00910011	693	0x00b80002	709
0x00910012	693	0x00b80003	709
0x00920000	693	0x00b80004	709
0x00920001	693	0x00b80005	710
0x00990000	694	0x00b80007	710
0x00990001	694	0x00b80008	710
0x00990002	694	0x00b80009	710

- 0x00b8000a [711](#)
- 0x00b8000b [711](#)
- 0x00b8000c [711](#)
- 0x00b8000d [711](#)
- 0x00b8000e [712](#)
- 0x00b8000f [712](#)
- 0x00b80010 [712](#)
- 0x00b80011 [712](#)
- 0x00b80012 [713](#)
- 0x00b80013 [713](#)
- 0x00b80014 [713](#)
- 0x00b80015 [713](#)
- 0x00b80016 [714](#)
- 0x00b80017 [714](#)
- 0x00b80019 [714](#)
- 0x00b8001a [714](#)
- 0x00b8001b [715](#)
- 0x00b8001c [715](#)
- 0x00b8001d [715](#)
- 0x00b80020 [716](#)
- 0x00b80021 [716](#)
- 0x00b80022 [716](#)
- 0x00b80023 [717](#)
- 0x00b80024 [717](#)
- 0x00b80025 [717](#)
- 0x00b80026 [718](#)
- 0x00b80027 [718](#)
- 0x00b80028 [718](#)
- 0x00b80029 [719](#)
- 0x00b8002a [719](#)
- 0x00b8002b [719](#)
- 0x00b8002c [720](#)
- 0x00b8002d [720](#)
- 0x00b8002e [720](#)
- 0x00b8002f [721](#)
- 0x00b80030 [721](#)
- 0x00b80031 [721](#)
- 0x00b80032 [722](#)
- 0x00b80033 [722](#)
- 0x00b80034 [722](#)
- 0x00b80035 [723](#)
- Error number (C00168) [763](#)
- Error register (I-1001) [344](#)
- Ethernet IP address client x (C01510) [854](#)
- Ethernet status client x (C01511) [854](#)
- Exception response [109](#)
- Exporting logbook entries [616](#)
- Ext. 24-V voltage (C00065) [750](#)
- External actual position (C02577) [872](#)
- External error (error message) [651](#)
- F**
- Failure of a mains phase (error message) [672](#)
- Failure of motor phase U (error message) [667](#)
- Failure of motor phase V (error message) [667](#)
- Failure of motor phase W (error message) [668](#)
- Fan control status (C00587) [809](#)
- Fault during the update of inputs and outputs (error message) [646](#)
- Fault in the control configuration (error message) [650](#)
- Faulty application parameter (error message) [648](#)
- Faulty program download (error message) [646](#)
- Feed constant (C02524) [861](#)
- Feedback [35](#)
- Feedback to Lenze [967](#)
- Feedforward control of torque [157](#)
- Feedfwd. ctrl. - current contr. (C00074) [751](#)
- Field contr. reset time (C00078) [751](#)
- Field controller gain (C00077) [751](#)
- Field weak. contr. reset time (C00578) [807](#)
- Field weakening controller gain (C00577) [807](#)
- Field weakening for SM (C00093) [754](#)
- Field weakening for synchronous machines [209](#)
- File DeviceCFG.dat defect (error message) [681](#)
- File DeviceCFG.dat invalid (error message) [682](#)
- File DeviceCFG.dat is missing (error message) [681](#)
- File ProjectList.dat defect (error message) [681](#)
- File ProjectList.dat invalid (error message) [682](#)
- File ProjectList.dat is missing (error message) [681](#)
- File ProjectSelection.dat defect (error message) [680](#)
- File ProjectSelection.dat invalid (error message) [682](#)
- File ProjectSelection.dat is missing (error message) [681](#)
- Filter for PWM adjustment (C00281) [774](#)
- Filter time const. DC detection (C00280) [774](#)
- Filter time constant (C02562) [869](#)
- Filtered torque setpoint (C00697) [823](#)
- Firmware - compiling date (C00201) [768](#)
- Firmware has been changed (error message) [640](#)
- Firmware is incompatible with control card (error message) [641](#)
- Firmware product type (C00200) [767](#)
- Firmware version (C00099) [754](#)
- Flying restart circuit
 - Activation (C00990) [841](#)
 - Current (C00991) [841](#)
 - Delay time (C00995) [842](#)
 - Integration time (C00993) [842](#)
 - Min. deviation (C00994) [842](#)
 - Start frequency (C00992) [841](#)
- Flying restart function [212](#)
- Following error (C02576) [872](#)
- Freq. - current setpoint filter (C00270) [772](#)
- Frequency (C02771) [905](#)
- G**
- GDO channel 1/trigger 1 (C731) [823](#)
- GDO channel 2/trigger 2 (C732) [823](#)
- GDO channel 3 (C733) [823](#)
- GDO channel 4 (C734) [823](#)
- GDO channel 5 (C735) [823](#)
- GDO channel 6 (C736) [824](#)

Index

GDO channel 7 (C737) [824](#)
GDO channel 8 (C738) [824](#)
GDO general parameters (C730) [823](#)
GDO status information (C739) [824](#)
Gearbox fac. denom.
 Pos. enc. (C02523) [861](#)
Gearbox factor denominator
 Motor (C02521) [860](#)
Gearbox factor num.
 Pos. enc. (C02522) [860](#)
Gearbox factor numerator
 Motor (C02520) [860](#)
Gearbox factors (decimal) (C02531) [863](#)
General error in the application (error message) [646](#)
gotolink parameter.fm
 c2702 [520](#)
Grinding OFF time (C02599) [876](#)
Grinding ON time (C02598) [876](#)
Grinding speed (C02596) [876](#)
Guard time [333](#)
Guard time (I-100C) [347](#)
GUID (C02903) [919](#)

H

Hardware limit positions [515](#)
Heartbeat not periodic (error message) [690](#)
Heartbeat protocol [337](#)
Heatsink
 Fan is defect (error message) [656](#)
 Overtemperature (error message) [653](#)
 Temperature > C00122 (error message) [652](#)
 Thermal detector is defect (error message) [654](#)
Heatsink temp. warn. threshold (C00122) [756](#)
Heatsink temperature (C00061) [749](#)
Hiperface
 detected TypeCode (C00413) [797](#)
 Initialisation time (C00412) [796](#)
 number of rev. (C00415) [797](#)
 TypeCode (C00414) [797](#)
Hiperface encoder
 Command error (error message) [670](#)
 Position initialisation error (error message) [671](#)
 Transmission error (error message) [670](#)
 Unknown encoder (error message) [671](#)
HM_dnHomePos_p (C02658) [891](#)
HM_dnSpeedOverride_n (C02655) [890](#)
HM_dnState (C02657) [891](#)
Holding brake [521](#)
Home position (C02642) [888](#)
Homing [421](#)
 Acceleration 1 (C02645) [888](#)
 Acceleration 2 (C02647) [889](#)
 Blocking time (C02650) [889](#)
 Dig. signals (C02659) [891](#)
 Speed 1 (C02644) [888](#)

 Speed 2 (C02646) [889](#)
 S-ramp time (C02648) [889](#)
 Target position (C02643) [888](#)
 Torque limit (C02649) [889](#)
 TP configuration (C02651) [890](#)
Homing mode (C02640) [886](#)
Homing mode not allowed (error message) [714](#)
HW countries of origin (C00209) [770](#)
HW descriptions (C00205) [769](#)
HW manufacturer (C00208) [769](#)
HW manufacturing data (C00206) [769](#)
HW product types (C00203) [768](#)
HW serial numbers (C00204) [768](#)
HW versions (C00210) [770](#)
Hysteresis for POS_bDrivelnTarget (C02672) [892](#)

I

I-1000 [344](#)
I-1001 [344](#)
I-1003 [345](#)
I-1005 [346](#)
I-1006 [347](#)
I-100C [347](#)
I-100D [347](#)
I-1010 [348](#)
I-1011 [349](#)
I-1014 [350](#)
I-1015 [350](#)
I-1016 [351](#)
I-1017 [351](#)
I-1018 [352](#)
I-1029 [352](#)
I-1200 [353](#)
I-1201 [354](#)
I-1202 [356](#)
I-1203 [356](#)
I-1204 [356](#)
I-1205 [356](#)
I-1206 [357](#)
I-1207 [357](#)
I-1208 [357](#)
I-1209 [357](#)
I-1400 [358](#)
I-1401 [359](#)
I-1402 [359](#)
I-1403 [360](#)
I-1600 [360](#)
I-1601 [361](#)
I-1602 [361](#)
I-1603 [361](#)
I-1800 [362](#)
I-1801 [363](#)
I-1802 [364](#)
I-1803 [364](#)

I-1A00 [365](#)
I-1A01 [365](#)
I-1A02 [366](#)
I-1A03 [366](#)
ID status (C00854) [832](#)
Identifier (CAN) [302](#)
Identity object (I-1018) [352](#)
IdleTask
 Overflow (error message) [647](#)
IEC 61508 [369](#)
I_{max} L_{ss} saturation characteristic (C02855) [915](#)
Inching mode [400](#)
Incorrect memory module (error message) [639](#)
Incorrect safety module (error message) [639](#)
Increased continuous power [112](#)
Influence winding I³t mon. (C01195) [848](#)
Information regarding the validity [13](#)
Inhibit time EMCY (I-1015) [350](#)
Inside the device
 Fan is defect (error message) [656](#)
 Thermal detector is defective (error message) [654](#)
Instant of PDO acceptance [316](#)
Instant of PDO transmission [316](#)
Int. overflow C02620 (manual jog
 Speed 1) (error message) [714](#)
Int. overflow C02621 (manual jog
 Speed 2) (error message) [715](#)
Int. overflow C02622 (manual jog
 acceleration) (error message) [715](#)
Int. overflow C02623 (manual jog
 deceleration) (error message) [715](#)
Int. overflow C02642 (home position) (error message) [720](#)
Int. overflow C02643 (homing
 Target position) (error message) [720](#)
Int. overflow C02644 (homing
 Speed 1) (error message) [721](#)
Int. overflow C02645 (homing
 Acceleration 1) (error message) [721](#)
Int. overflow C02646 (homing
 Speed 2) (error message) [721](#)
Int. overflow C02647 (homing
 Acceleration 2) (error message) [722](#)
Int. overflow C02670 (positioner
 Tol. for target position) (error message) [722](#)
Int. overflow C02701/1 (positive software limit position) (error
message) [716](#)
Int. overflow C02701/2 (negative software limit position) (error
message) [716](#)
Int. overflow C02703 (maximum speed) (error message) [716](#)
Int. overflow C02705 (maximum acceleration) (error message)
[717](#)
Int. overflow C02708/1 (decel. limited speed 1) (error message)
[718](#)
Int. overflow C02708/1 (limited speed 1) (error message) [717](#)
Int. overflow C02708/2 (decel. limited speed 2) (error message)

[719](#)
Int. overflow C02708/2 (limited speed 2) (error message) [717](#)
Int. overflow C02708/3 (decel. limited speed 3) (error message)
[719](#)
Int. overflow C02708/3 (limited speed 3) (error message) [718](#)
Int. overflow C02708/4 (decel. limited speed 4) (error message)
[719](#)
Int. overflow C02708/4 (limited speed 4) (error message) [718](#)
Int. overflow C02713 (max. dist. manual control) (error
message) [720](#)
Integrated safety system [369](#)
Internal clock (C01214) [851](#)
Internal communication error (DMA) (error message) [669](#)
Internal communication error (host MCTRL) (error message)
[662](#)
Internal communication error (MCTRL host) (error message)
[669](#)
Internal error
 See C00180 (error message) [690](#), [691](#)
Internal error (CRC application) (error message) [686](#)
Internal error (event mechanism) (error message) [645](#)
Internal error (file system lifetime) (error message) [646](#)
Internal error (LDS instance data) (error message) [643](#)
Internal error (LDS tasks) (error message) [644](#)
Internal error (memory area - logbook) (error message) [643](#)
Internal error (message memory) (error message) [644](#)
Internal error (message queue) (error message) [644](#)
Internal error (name data base) (error message) [645](#)
Internal error (semaphores) (error message) [645](#)
Internal error (storage blocks) (error message) [644](#)
Internal error (task queue) (error message) [644](#)
Internal torque limits (C02559) [868](#)

J

Jerk [385](#), [387](#)
Jerk has been limited (error message) [712](#)

K

Keypad
 Default parameter (C00466) [802](#)
 Default welcome screen (C00467) [802](#)
 Fct. STOP key (C00469) [803](#)
 Mode (C00464) [802](#)
 Timeout welcome screen (C00465) [802](#)
Keypad LCD display [611](#)

L

Layout of the safety instructions [17](#)
LCD display (keypad) [611](#)
LED status display [608](#)
LED status displays for the system bus [301](#)
Lh adjustment (C02861) [916](#)
Life guarding event [334](#)
Life time factor (I-100D) [347](#)
LIM_dnState (C02718) [902](#)

LIM_dwControl (C02717) [901](#)
Limit positions [512](#), [515](#)
 Triggering behaviour [514](#)
Limit switch [515](#)
Limitation active (C02715) [901](#)
Limitations effective (C02702) [898](#)
Limited speed (C02708) [899](#)
Limited speed [rpm] (C02709) [899](#)
Limiter [370](#), [506](#)
 Dig. signals (C02719) [902](#)
Load reference speed (C02542) [865](#)
Load reference torque (C02543) [865](#)
Loading of Lenze setting failed (error message) [687](#)
Logbook [613](#)
 Overflow (error message) [634](#)
 Reset (read error) (error message) [634](#)
 Reset (version error) (error message) [634](#)
Logbook - event filter (C00169) [763](#)
LS_AnalogInput [279](#)
LS_AnalogOutput [281](#)
LS_Brake [523](#)
LS_CamInterface [563](#)
LS_DigitalInput [283](#)
LS_DigitalOutput [285](#)
LS_DriveInterface [113](#)
LS_EncoderX8 [263](#)
LS_Feedback [240](#)
LS_Homing [423](#)
LS_Limiter [506](#)
LS_ManualJog [401](#)
LS_ManualJogOpenLoop [419](#)
LS_MotorInterface [234](#)
LS_PolePositionIdentification [576](#)
LS_Positioner [480](#)
LS_PositionFollower [491](#)
LS_quick stop [393](#)
LS_SafetyModuleInterface [371](#)
LS_SpeedFollower [496](#)
LS_SsiEncoderX8 [256](#)
LS_Stop [390](#)
LS_SyncInput [367](#)
LS_TorqueFollower [502](#)
LS_TouchProbe1 [291](#)
LS_TouchProbe2 [291](#)
LS_TouchProbe3 [291](#)
LS_TouchProbe4 [291](#)
LS_TouchProbe5 [291](#)
LS_TouchProbe6 [291](#)
LS_TouchProbe7 [291](#)
LS_TouchProbe8 [291](#)
LS_TouchProbeLoad [292](#)
LS_TouchProbeMotor [292](#)
Lss sat. characteristic (C02853) [915](#)

M

Machine parameters [32](#)
Mains connection [107](#)
Mains recov. detect. threshold (C00185) [767](#)
Mains voltage (C00173) [764](#)
Mains voltage is switched off (error message) [690](#)
Mains voltage is switched on (error message) [689](#)
MAN_dnSpeedOverride_n (C02637) [882](#)
Manual jog [400](#)
 Acceleration (C02622) [881](#)
 Deceleration (C02623) [881](#)
 Dig. signals (C02639) [883](#)
 Index Stop position (C02626) [882](#)
 Selected Stop position (C02627) [882](#)
 Speed 1 (C02620) [880](#)
 Speed 2 (C02621) [881](#)
 S-ramp time (C02624) [881](#)
 Status (C02638) [883](#)
 Step size (C02625) [881](#)
Manual jog to software limit position [410](#)
Manual jog, encoderless [412](#)
ManualJogOpenLoop
 Dig. signals (C02781) [908](#)
Masked Error number (C00162) [762](#)
Master functionality (CAN) [308](#)
Max. acceleration (C02705) [898](#)
Max. acceleration change (C00274) [773](#)
Max. dist. manual control (C02713) [900](#)
Max. dist. manual jog [Incr.] (C02714) [901](#)
Max. presentable acceleration (C02541) [864](#)
Max. presentable position (C02539) [864](#)
Max. presentable speed (C02540) [864](#)
Max. rot. ang. aft. mns. swtch. (C02653) [890](#)
Max. speed (C02703) [898](#)
Max. speed [rpm] (C02704) [898](#)
Maximum acceleration exceeded (error message) [712](#)
Maximum current [128](#)
Maximum current (C00022) [746](#)
Maximum current monitoring [233](#)
Maximum speed exceeded (error message) [712](#)
MCTRL_dnAccelerationAdd (C00804) [829](#)
MCTRL_dnBoost (C00814) [831](#)
MCTRL_dnDCBusVoltage (C00779) [826](#)
MCTRL_dnDeltaMotorPos_p (C00791) [828](#)
MCTRL_dnFieldWeak (C00816) [832](#)
MCTRL_dnFluxAct (C00778) [826](#)
MCTRL_dnFlyingSpeedAct (C00787) [827](#)
MCTRL_dnI2xtLoad (C00790) [828](#)
MCTRL_dnImotAct (C00780) [826](#)
MCTRL_dnInputJerkCtrl (C00776) [825](#)
MCTRL_dnInputTorqueCtrl (C00777) [826](#)
MCTRL_dnIxtLoad (C00786) [827](#)
MCTRL_dnLoadPosAct (C00771) [824](#)
MCTRL_dnLoadPosRefValue (C00813) [831](#)

- MCTRL_dnLoadSpeedAct (C00773) [825](#)
- MCTRL_dnMotorFreqAct (C00784) [827](#)
- MCTRL_dnMotorPosAct (C00770) [824](#)
- MCTRL_dnMotorPosRefValue (C00812) [831](#)
- MCTRL_dnMotorSpeedAct (C00772) [825](#)
- MCTRL_dnMvorAdapt (C00818) [832](#)
- MCTRL_dnOutputPosCtrlMotor_s (C00792) [828](#)
- MCTRL_dnOutputSpeedCtrl (C00775) [825](#)
- MCTRL_dnPosCtrlAdapt (C00811) [831](#)
- MCTRL_dnPosCtrlOutLimit (C00808) [830](#)
- MCTRL_dnPosSet (C00800) [829](#)
- MCTRL_dnSpeedAdd (C00802) [829](#)
- MCTRL_dnSpeedCtrlAdapt (C00810) [830](#)
- MCTRL_dnSpeedCtrlIntegrator (C00815) [831](#)
- MCTRL_dnSpeedLowLimit (C00805) [829](#)
- MCTRL_dnSpeedSet_s (C00817) [832](#)
- MCTRL_dnTorqueAct (C00774) [825](#)
- MCTRL_dnTorqueAdd (C00803) [829](#)
- MCTRL_dnTorqueCtrlAdapt (C00809) [830](#)
- MCTRL_dnTorqueHighLimit (C00807) [830](#)
- MCTRL_dnTorqueLowLimit (C00806) [830](#)
- MCTRL_dwMaxDeviceCurrent (C00789) [828](#)
- MCTRL_dwMaxEffMotorTorque (C00788) [828](#)
- MCTRL_dwMaxMotorSpeed (C00781) [826](#)
- MCTRL_dwMaxMotorTorque (C00782) [827](#)
- MCTRL_dwMotorVoltageAct (C00783) [827](#)
- MEC history
 - Error number (C1223) [853](#)
 - Flash value (C1222) [853](#)
 - RAM address (C1220) [852](#)
 - RAM value (C1221) [852](#)
- Memory distribution for cam data [559](#)
- Memory module
 - Faulty file system (error message) [641](#)
 - File system has been formatted (error message) [674](#)
 - File system has been restored (error message) [674](#)
- Memory module Firmw. Rev. (C00220) [771](#)
- Memory module has been changed (error message) [640](#)
- Memory module has been removed (error message) [636](#)
- Memory module is defect or missing (error message) [635](#), [638](#)
- Memory module is missing (error message) [635](#)
- Messages - motor interface (C02560) [868](#)
- Meters
 - Brake chopper overload (C01203) [850](#)
 - DC bus overvoltage (C01205) [850](#)
 - Heatsink overtemp. (C01208) [850](#)
 - Housing overtemp. (C01209) [850](#)
 - Internal (C01210) [851](#)
 - Ixt overload (C01204) [850](#)
 - Mains switching (C01206) [850](#)
 - Power section overload (C01212) [851](#)
- Min. S-ramp time (C02706) [898](#)
- Minimum brake resistance (C00134) [758](#)
- Minimum starting torque (C02606) [878](#)
- MM440 [851](#), [852](#)
- Modulation modes [110](#)
- MOL_dnState (C02780) [907](#)
- MOL_SetpointCurrent (C02779) [907](#)
- Moment of inertia (C00273) [773](#)
- Monitoring [617](#)
- Monitoring of limit positions [512](#)
- Mot. overload protection (I²t) (C00120) [755](#)
- Mot. overload warning threshold (C00127) [756](#)
- Motor
 - Actual current value > C00620 (error message) [664](#)
 - Actual speed value > C00596 (error message) [665](#)
 - Calculated e.m.f. factor unrealistic (error message) [660](#)
 - Calculated flux factor unrealistic (error message) [661](#)
 - Calculated leakage inductance unrealistic (error message) [663](#)
 - Calculated motor impedance unrealistic (error message) [659](#)
 - Calculated mutual inductance unrealistic (error message) [659](#), [660](#)
 - Calculated rotor resistance unrealistic (error message) [660](#)
 - Calculated rotor time constant unrealistic (error message) [661](#)
 - Device current too low for rated magnetisation (error message) [660](#)
 - Overtemperature (error message) [653](#)
 - Phase resistance too high (error message) [659](#)
 - PTC has triggered (error message) [655](#)
 - Rated current < rated magnetising current (error message) [660](#)
 - Temperature > C00121 (error message) [653](#)
 - Thermal detector is defect (error message) [655](#)
- Motor - magnetising current (C00092) [754](#)
- Motor - mutual inductance (C00079) [752](#)
- Motor - number of pole pairs (C00059) [749](#)
- Motor brake
 - Angular drift with closed brake too high (error message) [709](#)
 - Motor brake
 - Autom. activated after waiting time has elapsed (error message) [709](#)
 - Status monitoring error (error message) [710](#)
- Motor control
 - Task overflow (error message) [662](#)
- Motor cosine phi (C00091) [753](#)
- Motor current (C00054) [747](#)
- Motor data are inconsistent (error message) [659](#), [662](#)
- Motor encoder [248](#)
 - Module selected in C00495 not available (error message) [665](#)
- Motor encoder selection (C00495) [803](#)
- Motor holding brake [521](#)
- Motor holding brake control module E94AZHA0051 [529](#)
- Motor holding brake control module E94AZHX0051 [530](#)
- Motor interface [118](#)
 - % signals (C02568) [870](#)
 - Dig. signals (C02569) [870](#)
- Motor load I²t > C00120 (error message) [657](#)
- Motor load I²t > C00127 (error message) [656](#)

Motor mounting direction (C02527) [861](#)
Motor operating temperature (C01194) [847](#)
Motor parameter identification was cancelled (error message) [669](#)
Motor phase failure [229](#)
Motor phase failure monitoring [229](#)
Motor phase failure threshold (C00599) [812](#)
Motor phase failure volt. threshold (C02867) [917](#)
Motor protection [128](#), [233](#)
Motor reference speed (C00011) [745](#)
Motor rotor resistance (C00082) [752](#)
Motor rotor time constant (C00083) [752](#)
Motor speed [128](#)
Motor standstill time constant (C00494) [803](#)
Motor stator leakage inductance (C00085) [753](#)
Motor stator resistance (C00084) [752](#)
Motor switched off (error message) [673](#)
Motor temp. feedback system (C01193) [847](#)
Motor temperature
Module selected in C01193 not available (error message) [666](#)
Motor temperature (C00063) [749](#)
Motor temperature monitoring (PTC) [227](#)
Motor thermal sensor (C01190) [846](#)
Motor voltage (C00052) [747](#)
Multiturn resolution (C02761) [904](#)
MXI1
CAN module is missing or incompatible (error message) [685](#)
Digital frequency module is missing or incompatible (error message) [684](#)
Ethernet module is missing or incompatible (error message) [684](#)
ICM module is missing or incompatible (error message) [685](#)
Module changed during operation (error message) [636](#)
Module has been changed (error message) [639](#)
Module is defect or missing (error message) [637](#)
Module is missing or incompatible (error message) [683](#)
PROFIBUS module is missing or incompatible (error message) [684](#)
Wrong module (error message) [638](#)
MXI2
CAN module is missing or incompatible (error message) [685](#)
Digital frequency module is missing or incompatible (error message) [685](#)
Ethernet module is missing or incompatible (error message) [684](#)
ICM module is missing or incompatible (error message) [685](#)
Module changed during operation (error message) [636](#)
Module has been changed (error message) [640](#)
Module is defect or missing (error message) [637](#)
Module is missing or incompatible (error message) [683](#)
PROFIBUS module is missing or incompatible (error message) [684](#)
Wrong module (error message) [639](#)

N

Negative direction of rotation limited (error message) [711](#)
Negative limit switch has triggered (error message) [709](#)
Negative software limit switch overtravelled (error message) [710](#)
Network management telegram (NMT) [307](#)
New application loaded (error message) [647](#)
NMT (network management) [307](#)
No heartbeat signal detected (error message) [690](#)
No parameters for module in MXI1 (error message) [689](#)
No parameters for module in MXI2 (error message) [689](#)
No. of CRC cycles (C00618) [816](#)
Node address [303](#)
Node guarding event [334](#)
Node guarding protocol [331](#)
Node ID [303](#)
Node life time [333](#)
Noise signal activation (C462) [802](#)
Noise signal amplitude (C658) [821](#)
Noise signal period (C659) [822](#)
Number Of Cam Data Points (C02922) [922](#)
Number Of Cam Tracks (C02919) [921](#)
Number Of Cont Data Points (C02942) [924](#)
Number Of Cont Tracks (C02939) [923](#)
Number of encoder increments (C00420) [798](#)
Number of Pos Data Points (C02962) [925](#)
Number of Pos Tracks (C02959) [925](#)

O

observation software limit positions (C02720) [902](#)
Offset actual pos. value/setp. (C02578) [872](#)
Online change mode [567](#)
Online Change Mode (C02905) [920](#)
Online Change State (C02906) [920](#)
Operating mode (C02770) [905](#)
Operating mode brake (C02580) [873](#)
Operation with increased continuous power [112](#)
Optimising response to setpoint changes [157](#)
Overcurrent detected (error message) [661](#)
overload [112](#)

P

Parameter error information (C217) [771](#)
Parameter set
Type of standard device has been changed (error message) [688](#)
Version conflict (error message) [688](#)
Parameter set faulty (error message) [686](#)
Parameter set loaded (error message) [687](#)
Parameter set restored (error message) [687](#)
Parameter set saved (error message) [687](#)
Parameter set switching [86](#)
Parameter sets [86](#)
Password entry [566](#)

- Password for cam data [560](#)
 - PDO delay [316](#)
 - PDO mapping (MXI1)
 - configuration faulty (error message) [649](#)
 - PDO mapping (MXI2)
 - configuration faulty (error message) [650](#)
 - PDO synchronisation [313](#)
 - Permissible angle of rotation (C02595) [875](#)
 - Permissible direction of rot. (C02707) [899](#)
 - PF_dnMotorAcc_x (C02685) [895](#)
 - PF_dnPositionSet_p (C02688) [895](#)
 - PF_dnSpeedAdd1_s (C02686) [895](#)
 - Phase controller gain (C00254) [772](#)
 - Phase controller output (C02557) [868](#)
 - Phase currents (C00055) [748](#)
 - Plant parameters [127](#)
 - PLC configuration invalid (error message) [652](#), [669](#), [675](#), [708](#)
 - PLI 360° absolute current amplitude (C00645) [820](#)
 - PLI 360° current amplitude (C00641) [819](#)
 - PLI 360° result in C58 (C02872) [918](#)
 - PLI 360° traversing direction (C00643) [819](#)
 - PLI min. motion absolute cur. amp. (C00651) [821](#)
 - PLI min. mov. reset time (C00649) [821](#)
 - PLI min.mov. curr. amplitude (C00646) [820](#)
 - Pointer access in impermissible memory area (error message) [649](#)
 - Pole position (C00058) [748](#)
 - Pole position identification [68](#), [69](#), [575](#)
 - Pole position recognition cancelled (error message) [673](#)
 - PolePosId 360° fault tol. (C00644) [820](#)
 - PolePosId 360° ramp time (C00642) [819](#)
 - PolePosId min.mov. cur.rise rate (C00647) [820](#)
 - PolePosId min.mov. gain (C00648) [821](#)
 - PolePosId min.mov. max.perm.mov. (C00650) [821](#)
 - PolePosition setpoint (C02788) [909](#)
 - PolePositionIdentification
 - Dig. signals (C02789) [909](#)
 - Pos Data Point Choice (C02963) [926](#)
 - Pos Track Choice (C02960) [925](#)
 - Pos. contr. limitation (C02556) [868](#)
 - Pos. contr. output (C02558) [868](#)
 - POS_dnProfileSpeed_s (C02676) [893](#)
 - POS_dnState (C02675) [893](#)
 - POS_dwActualProfileNumber (C02674) [892](#)
 - Position control structure (C02570) [871](#)
 - Position controller gain (C02553) [867](#)
 - Position controller reset time (C02554) [867](#)
 - Position encoder [249](#)
 - Module selected in C00490 not available (error message) [665](#)
 - Position encoder mounting dir. (C02529) [862](#)
 - Position encoder selection (C00490) [803](#)
 - Position follower [490](#)
 - % signals (C02687) [895](#)
 - Dig. signals (C02689) [895](#)
 - Position setpoint (enc. eval.) (C02573) [871](#)
 - Position setpoint (mctrl) (C02552) [867](#)
 - Position target outside the software limit positions (error message) [712](#)
 - Position value faulty (error message) [693](#)
 - Positioning [479](#)
 - % signals (C02677) [893](#)
 - Dig. signals (C02679) [894](#)
 - Pos. signals (C02678) [893](#)
 - Positive direction of rotation limited (error message) [710](#)
 - Positive limit switch has triggered (error message) [708](#)
 - Positive software limit switch overtravelled (error message) [710](#)
 - Power section incompatible (error message) [638](#)
 - Power section is defect (error message) [635](#), [637](#), [672](#)
 - Power section was changed (error message) [639](#)
 - Power-on time meter (C00179) [765](#)
 - PPI activation (C02785) [908](#)
 - PPI mode (C02786) [908](#)
 - PPI_dnState (C02787) [908](#)
 - Pre-defined error field (I-1003) [345](#)
 - Producer heartbeat time (I-1017) [351](#)
 - Product change-over [572](#)
 - Product Choice (C02911) [921](#)
 - Product Count (C02908) [920](#)
 - Product Count (C02912) [921](#)
 - Product Name (C02910) [921](#)
 - Profile data [557](#)
 - Program auto-start (C02104) [858](#)
 - Program name (C02113) [859](#)
 - Program runtime (C02109) [858](#)
 - Program status (C02108) [858](#)
 - Progress of device command (C00008) [745](#)
 - Project is not available (error message) [682](#)
 - Project is not loaded (error message) [682](#)
 - PTC [227](#)
- ## Q
- QSP [393](#)
 - Quick stop [393](#)
 - Dig. signals (C02619) [880](#)
 - Quick stop by (source) (C00159) [762](#)
 - Quick stop S-ramp time (C00106) [754](#)
- ## R
- Rated motor current (C00088) [753](#)
 - Rated motor current. See rated motor current
 - Rated motor frequency (C00089) [753](#)
 - Rated motor power (C00081) [752](#)
 - Rated motor speed (C00087) [753](#)
 - Rated motor voltage (C00090) [753](#)
 - Rated power - brake resistor (C00130) [757](#)
 - Rated quantity of heat for brake res. (C00131) [757](#)

- React. brake transist. lxt > C00570 (C00569) [805](#)
 - React. CPU temperature > C00126 (C00589) [810](#)
 - React. device overload > C00123 (C00604) [813](#)
 - React. heat sink temp. > C00122 (C00582) [808](#)
 - React. motor overload > C00127 (C00606) [813](#)
 - React. motor temp. > C00121 (C00584) [808](#)
 - Read error service register (error message) [651](#)
 - Real-time clock [851](#), [852](#)
 - Battery empty, time lost (error message) [643](#)
 - Change battery (error message) [642](#)
 - Real-time clock is defective (error message) [642](#)
 - Red. brake chopper threshold (C00181) [766](#)
 - Ref. for Accel. time of brake (C02601) [877](#)
 - Ref. for decel. time of stop (C02612) [879](#)
 - Ref. for quick stop dec. time (C00107) [755](#)
 - Ref. pos. after mains switching (C02652) [890](#)
 - Reference
 - Brake chopper utilisation (C00133) [758](#)
 - Reference search [427](#)
 - Reference setting [427](#)
 - Reference speed (C02544) [865](#)
 - Reference speed motor [128](#)
 - Reference S-ramp time (C02545) [865](#)
 - Required licence missing (error message) [683](#)
 - Required safety module (C00214) [771](#)
 - Required safety module (C214) [371](#)
 - Reset error message [117](#), [625](#)
 - Resol. of an encoder revolution (C00100) [754](#)
 - Resolution of a unit (C02532) [863](#)
 - Resolver
 - Calculated acceleration unrealistic (error message) [665](#)
 - Gain (C02862) [916](#)
 - Open circuit (error message) [663](#)
 - Phase correction (C02863) [917](#)
 - Resolver - number of pole pairs (C00080) [752](#)
 - Resolver error compensation [266](#)
 - Resp to new firmw. standard dev. (C00635) [818](#)
 - Resp. temp. sensor motor X7/X8 (C00594) [811](#)
 - Resp. to brake res. i²xt > C00572 (C00571) [805](#)
 - Resp. to brake resist. overtemp. (C00574) [806](#)
 - Resp. to CAN bus OFF (C00595) [811](#)
 - Resp. to CAN heartbeat error (C00613) [815](#)
 - Resp. to CAN life guarding error (C00614) [816](#)
 - Resp. to CAN node guarding error (C00612) [815](#)
 - Resp. to CAN-RPDOx error (C00591) [810](#)
 - Resp. to comm. error with MXI1 (C01501) [853](#)
 - Resp. to comm. error with MXI2 (C01502) [854](#)
 - Resp. to comm. task overflow (C01230) [853](#)
 - Resp. to DC bus overvoltage (C00600) [813](#)
 - Resp. to encoder comm. error (C00601) [813](#)
 - Resp. to encoder open circuit (C00580) [807](#)
 - Resp. to encoder pulse deviation (C00621) [817](#)
 - Resp. to external fault (C00581) [808](#)
 - Resp. to failure heatsink fan (C00610) [814](#)
 - Resp. to failure integral fan (C00611) [814](#)
 - Resp. to failure t. sensor drive (C00588) [810](#)
 - Resp. to imp. device config. (C00615) [816](#)
 - Resp. to limitation (C02716) [901](#)
 - Resp. to max. speed reached (C00607) [814](#)
 - Resp. to motor current > C00620 (C00619) [817](#)
 - Resp. to motor KTY overtemp. (C00583) [808](#)
 - Resp. to motor overtemp. PTC (C00585) [809](#)
 - Resp. to motor phase failure (C00597) [812](#)
 - Resp. to new module in MXI1 (C00636) [818](#)
 - Resp. to new module in MXI2 (C00637) [818](#)
 - Resp. to open circuit AIN1 (C00598) [812](#)
 - Resp. to overload brake trans. (C00573) [806](#)
 - Resp. to pole pos. id. monit. (C00640) [819](#)
 - Resp. to resolver open circuit (C00586) [809](#)
 - Resp. to speed monitoring (C00579) [807](#)
 - Resp. to task overflow (C02111) [859](#)
 - Restart [107](#)
 - Restore default parameters (I-1011) [349](#)
 - Retain memory of the application faulty (error message) [650](#)
 - Retracting from limit switches [411](#)
 - Rotor position (C00060) [749](#)
 - RPDO1 communication parameter (I-1400) [358](#)
 - RPDO1 mapping parameter (I-1600) [360](#)
 - RPDO2 communication parameter (I-1401) [359](#)
 - RPDO2 mapping parameter (I-1601) [361](#)
 - RPDO3 communication parameter (I-1402) [359](#)
 - RPDO3 mapping parameter (I-1602) [361](#)
 - RPDO4 communication parameter (I-1403) [360](#)
 - RPDO4 mapping parameter (I-1603) [361](#)
 - Rr adjustment (C02860) [916](#)
 - Runtime ApplicationTask (C02121) [859](#)
 - Runtime error (error message) [648](#)
 - Runtime IdleTask (C02123) [860](#)
 - Runtime measurement [61](#)
 - Runtime UserTask (C02122) [860](#)
- ## S
- S1 torque characteristic I²xt mon. (C01196) [848](#)
 - Safety instructions [17](#)
 - Safety module [369](#)
 - Incompatible with setting in C00214 (error message) [693](#)
 - Interface [374](#), [510](#)
 - Safety module has been changed (error message) [640](#)
 - Safety module has been removed (error message) [637](#)
 - Safety module is defect or missing (error message) [636](#), [638](#)
 - Safety system [369](#)
 - Saturation characteristic [204](#)
 - Saving of parameters failed (error message) [688](#)
 - Scaling of physical units [24](#)
 - SDO1 server parameter (I-1200) [353](#)
 - SDO10 server parameter (I-1209) [357](#)
 - SDO2 server parameter (I-1201) [354](#)
 - SDO3 server parameter (I-1202) [356](#)

- SDO4 server parameter (I-1203) [356](#)
- SDO5 server parameter (I-1204) [356](#)
- SDO6 server parameter (I-1205) [356](#)
- SDO7 server parameter (I-1206) [357](#)
- SDO8 server parameter (I-1207) [357](#)
- SDO9 server parameter (I-1208) [357](#)
- Select motor control [124](#)
- Select motor control (C00006) [745](#)
- Sensorless vector control (SLVC) [166](#)
- Service code (C00180) [766](#)
- Service code (C02564) [869](#)
- Service code (C1125) [845](#)
- Service code (C1126) [845](#)
- Service code (C1127) [846](#)
- Service code (C1128) [846](#)
- Service code (C1129) [846](#)
- Service code (C1211) [851](#)
- Service code (C1217) [852](#)
- Service code (C1218) [852](#)
- Service code (C132) [757](#)
- Service code (C167) [763](#)
- Service code (C171) [763](#)
- Service code (C175) [765](#)
- Service code (C176) [765](#)
- Service code (C177) [765](#)
- Service code (C198) [767](#)
- Service code (C2850) [914](#)
- Service code (C2851) [914](#)
- Service code (C2852) [914](#)
- Service code (C2854) [915](#)
- Service code (C2856) [915](#)
- Service code (C2857) [916](#)
- Service code (C2864) [917](#)
- Service code (C2868) [917](#)
- Service code (C2869) [917](#)
- Service code (C2870) [918](#)
- Service code (C2996) [926](#)
- Service code (C2997) [926](#)
- Service code (C2998) [926](#)
- Service code (C2999) [926](#)
- Service code (C308) [775](#)
- Service code (C309) [775](#)
- Service code (C310) [775](#)
- Service code (C325) [779](#)
- Service code (C326) [779](#)
- Service code (C327) [779](#)
- Service code (C328) [780](#)
- Service code (C329) [780](#)
- Service code (C330) [780](#)
- Service code (C335) [780](#)
- Service code (C336) [780](#)
- Service code (C337) [780](#)
- Service code (C338) [780](#)
- Service code (C379) [791](#)
- Service code (C395) [795](#)
- Service code (C396) [795](#)
- Service code (C397) [796](#)
- Service code (C416) [797](#)
- Service code (C468) [803](#)
- Service code (C512) [804](#)
- Service code (C513) [804](#)
- Service code (C514) [804](#)
- Service code (C515) [804](#)
- Service code (C516) [804](#)
- Service code DataFlash (C1213) [851](#)
- Service password (C00004) [744](#)
- Servo control (SC) [145](#)
- Set time and date (C01215) [852](#)
- Setpoint interpolation (C02550) [867](#)
- Setting of actual speed filter [152](#), [179](#)
- Setting the baud rate for CAN [300](#)
- Setting the CAN node address [299](#)
- Setting the error response [618](#)
- Setting the field weakening for asynchronous machines [159](#)
- Setting the node address for CAN [299](#)
- Setting the S-ramp time [387](#)
- Settings for test mode (C00399) [796](#)
- SF_dnMotorAcc_x (C02692) [896](#)
- SF_dnSpeedAdd_s (C02693) [896](#)
- Short overview of error messages [626](#)
- Signal flow
 - Encoder evaluation [243](#)
 - Monitoring [217](#)
 - Position follower [492](#)
 - Sensorless vector control [183](#)
 - Servo control for asynchronous motor [164](#)
 - Servo control for synchronous motor [162](#)
 - Speed follower [498](#)
 - Torque slave [503](#)
 - V/f characteristic control [199](#)
 - V/f control [201](#)
- Signal source - speed setpoint (C00275) [773](#)
- Signal source - torque setpoint (C00276) [774](#)
- SLVC
 - Gain - torque controller (C00987) [840](#)
 - Gain of cross current controller (C00986) [840](#)
 - Gain of field current controller (C00985) [840](#)
 - Reset time - torque contr. (C00988) [840](#)
 - Time const.- Para. adj. (C00989) [841](#)
- Software limit positions [512](#)
 - Triggering behaviour [514](#)
- Software limit positions (C02701) [897](#)
- Software limits pos. effective (C02700) [897](#)
- Source - actual position (C2571) [871](#)
- Source add. speed (C02681) [894](#)
- Source for feedf. control brake (C02602) [877](#)
- Source of starting torque (C02588) [874](#)
- Source position setpoint (C02680) [894](#)

Spec. characteristic
 resistance (C01192) [847](#)
 temperature (C01191) [847](#)
Speed act. val. time const. (C00497) [804](#)
Speed contr. reset time (C00071) [750](#)
Speed contr.D component (C00072) [751](#)
Speed controller gain (C00070) [750](#)
Speed controller output (C00694) [822](#)
Speed feedforw. control gain (C02561) [869](#)
Speed follower [496](#)
 % signals (C02694) [896](#)
 Dig. signals (C02695) [896](#)
Speed has been limited (error message) [711](#)
Speed limitation (C00909) [833](#)
Speed monitoring tolerance (C00576) [806](#)
Speed setpoint (enc. eval.) (C02572) [871](#)
Speed setpoint [%] (C00692) [822](#)
Speed setpoint [rpm] (C00050) [747](#)
Speed unit (C02537) [864](#)
S-ramp time for stop (C02611) [879](#)
S-ramp time lim. speed (C02711) [900](#)
SSI encoder [255](#)
 bit rate (C00423) [798](#)
 data word length (C00424) [799](#)
 partword data coding (C00437) [800](#)
 partword length (C00436) [800](#)
 partword start position (C00435) [799](#)
Start acceleration [385](#)
Starting angle (C02772) [906](#)
Starting performance [107](#)
Starting torque 1 (C02586) [874](#)
Starting torque 2 (C02587) [874](#)
Starting value I^{xt} monitoring (C01197) [848](#)
State bus [286](#)
Status
 Digital inputs (C00443) [801](#)
 Digital outputs (C00444) [801](#)
Status DCTRL control input (C00878) [832](#)
Status displays [608](#)
Status input monitoring (C02583) [873](#)
Status word
 Digital inputs (C02803) [912](#)
 Digital outputs (C02802) [911](#)
Status word device control 1 (C00150) [759](#)
Status word device control 2 (C00155) [760](#)
Status/Control word MCTRL (C00156) [760](#)
Stop [389](#)
Storage capacity for user parameters exceeded (error message) [686](#)
Store parameters (I-1010) [348](#)
STP_bStopActive (C02617) [880](#)
STP_dnState (C02616) [880](#)
Switching frequency (C00018) [746](#)
Switching frequency reduction [111](#)
Sync cycle time (C01121) [843](#)

Sync phase position [316](#)
Sync phase position (C01122) [844](#)
Sync source (C01120) [843](#)
Sync telegram [313](#)
Sync tolerance (C01123) [844](#)
Sync-PLL increment (C01124) [845](#)
System block "LS_Limiter" [370](#)
System error messages [620](#)
System event [293](#)
System task
 Task overflow (error message) [692](#)
System task 1
 Task overflow (error message) [691](#)
System task 2
 Task overflow (error message) [691](#)
System task 3
 Task overflow (error message) [692](#)
T
Table of attributes [927](#)
Target group [13](#)
Task overflow [109](#), [293](#)
Task runtimes [61](#)
Temperature inside the controller (C00062) [749](#)
Temperature monitoring of a second motor [228](#)
Terminology used [16](#)
Test mode motor control (C00398) [796](#)
Test torque (C02594) [875](#)
Therm. motor time constant (C00128) [757](#)
Thermal motor load (I^{xt}) (C00066) [750](#)
Threshold - brake activation (C02581) [873](#)
Threshold - standstill recognition (C00019) [746](#)
Threshold 1 for opening brake (C02603) [877](#)
Threshold 2 for opening brake (C02604) [877](#)
Threshold max. speed reached (C00596) [811](#)
Time [851](#), [852](#)
Time (C02776) [907](#)
Time constant of actual speed filter [152](#), [179](#)
Time error - controller interface (error message) [658](#)
Time for device search function (C00182) [766](#)
Time unit (C02533) [863](#)
Time-out torque feedforward control - brake (error message) [713](#)
Timestamp (C02902) [919](#)
Tolerance for POS_bActPosInTarget (C02670) [891](#)
Tolerance for POS_bDriveInTarget (C02671) [892](#)
Torque (C00057) [748](#)
Torque feedforward control [157](#)
Torque setpoint (C00056) [748](#)
Torque setpoint [%] (C00696) [822](#)
Torque slave [501](#)
 % signals (C02698) [897](#)
 Dig. signals (C02699) [897](#)
Total speed setpoint (C00691) [822](#)

Total torque setpoint (C00695) [822](#)
Touch probe detection [288](#)
Touch probe x
 Delay time (C02810) [913](#)
TPDO1 communication parameter (I-1800) [362](#)
TPDO1 mapping parameter (I-1A00) [365](#)
TPDO2 communication parameter (I-1801) [363](#)
TPDO2 mapping parameter (I-1A01) [365](#)
TPDO3 communication parameter (I-1802) [364](#)
TPDO3 mapping parameter (I-1A02) [366](#)
TPDO4 communication parameter (I-1803) [364](#)
TPDO4 mapping parameter (I-1A03) [366](#)
Track switch-over [572](#)
Travel range monitoring [506](#)
Traversing range (C02528) [862](#)
TTL encoder signal evaluation (C00427) [799](#)

U

Ultimate motor current I_{ult} [128](#), [233](#)
Ultimate motor current I_{ult} (C00620) [817](#)
Undervoltage (LU) threshold (C00174) [765](#)
Unit [36](#)
Unit (C02525) [861](#)
Unknown error (error message) [626](#), [634](#)
Update cam data [562](#)
Used time unit (C02534) [863](#)
Used unit (C02535) [863](#)
User code
 Memory load (C02110) [858](#)
User Password (C02900) [918](#)
User-defined unit (C02526) [861](#)
UserTask
 Overflow (error message) [647](#)

V

V/f control (VFCplus) [184](#), [200](#)
VFC
 Activat. interpol. point n (C00954) [835](#)
 Frequency interpol. point n (C00952) [834](#)
 Frequency setpoint (C00998) [842](#)
 Gain - I_{max} controller (C00963) [837](#)
 Gain - oscillation damping (C00967) [837](#)
 Gain - slip compensation (C00965) [837](#)
 Gain - speed controller (C00972) [838](#)
 Influence - speed controller (C00971) [838](#)
 Limitation - oscill. damp. (C00969) [838](#)
 Load - cw/ccw-operation (C00961) [836](#)
 Load adjustment (C00962) [836](#)
 min. inh-time aft. overvolt. (C00977) [839](#)
 Override point of field weakening (C00980) [840](#)
 ramp-end frequ. - oscill. damp. (C00970) [838](#)
 Reset time - I_{max} contr. (C00964) [837](#)
 Reset time - speed contr. (C00973) [839](#)
 Time const. - oscill. damp. (C00968) [838](#)
 Time const. slip comp. (C00966) [837](#)

V/f base frequency (C00951) [833](#)
V/f characteristic shape (C00950) [833](#)
V/f voltage boost (C00960) [836](#)
V_{max} reduction (C00955) [835](#)
Voltage interpol. point n (C00953) [834](#)
VVC current setpoint (C00957) [835](#)
VVC gain (C00958) [836](#)
VVC reset time (C00959) [836](#)
VFCplus [200](#)
Violation of time slice (error message) [659](#)
Voltage reserve (C02871) [918](#)

W

Waiting time - brake activation (C02593) [875](#)
Waiting time - state monitoring (C02591) [875](#)
Warning thres. brake resistor (C00572) [806](#)
Warning thres. brake transistor (C00570) [805](#)
Warning threshold device util. (C00123) [756](#)
Warning threshold motor temperature (C00121) [756](#)
Watchdog cycle is greater than task cycle (error message) [651](#)
Width of current setpoint filter (C00271) [772](#)

X

X8 (encoder signal) [263](#)

FEEDBACK



Your opinion is important to us

These instructions were created to the best of our knowledge and belief to give you the best possible support for handling our product.

If you have suggestions for improvement, please e-mail us to:

feedback-docu@Lenze.de

Thank you for your support.

Your Lenze documentation team



Lenze Automation GmbH
Hans-Lenze-Str. 1
D-31855 Aerzen
Germany
HR Hannover B 205381
☎ +49 (0)51 54 / 82-0
☎ +49 (0)51 54 / 82-28 00
✉ sales.de@lenze.de
🌐 www.Lenze.com

Service

Lenze Service GmbH
Breslauer Straße 3
D-32699 Extertal
Germany
☎ 00 80 00 / 24 4 68 77 (24 h helpline)
☎ +49 (0)51 54 / 82-11 12
✉ service.de@lenze.de