



EDBMF2141
455968



Lenze

Operating Instructions



Fieldbus module type 2141

LON (Local Operating Network)

These Operating Instructions are valid for fieldbus modules with the following nameplates:

2141 IB. 0x. 0x. LON

In connection with the unit series as from the nameplate data:

820X	E./C.	2x.	1x.	(8201 - 8204)
821X	E./C.	2x.	2x.	(8211 - 8218)
822X	E.	1x.	1x.	(8221 - 8227)
824X	E.C.	1x.	1x.	(8241 - 8246)
82EVxxxxBxxxXX	Vx	1x		8200 vector
EPL 10200	I.T.	1x.	1x.	(Drive PLC)
93XX	E./C.	2x.	1x.	(9321 - 9333)
93XX	E./C. I.T.	2x.	1x.	(9300 Servo PLC)


Type					
Design: E = Built-in unit IP20 IB = Module					
Hardware version and index					
Software version and index					
Variant					
Explanation					

Important:


These Operating Instructions are only valid together with the corresponding Operating Instructions for the 82XX, 8200 vector, 93XX and 9300 Servo PLC and Drive PLC.

What is new?

Material no.	Version	Important	Contents
455968	1.0 08/02 TD02	1st edition	




1 Preface and general information	1-1
1.1 How to use these Operating Instructions	1-1
1.1.1 Terminology used	1-1
1.2 Packing list	1-1
1.2.1 Legal regulations	1-2
2 Safety information	2-1
2.1 Persons responsible for the safety	2-1
2.2 General safety information	2-1
2.3 Layout of the safety information	2-2
3 Technical data	3-1
3.1 Features of the 2141 fieldbus module	3-1
3.2 General data / application conditions	3-1
3.3 Rated data	3-2
3.4 Dimensions	3-2
3.5 Communication times	3-3
3.5.1 Processing time in the basic unit	3-3
3.5.2 Number of devices connected to the bus	3-3
4 Installation	4-1
4.1 Elements at the front of the 2141 fieldbus module	4-1
4.1.1 Connection of external voltage supply	4-2
4.1.2 Connection for LON bus	4-2
4.1.3 Data for connection terminals	4-2
4.2 Mechanical installation	4-3
4.3 Electrical installation	4-4
4.3.1 Wiring to a host	4-4
4.3.2 Voltage supply	4-5
5 Commissioning	5-1
5.1 First switch-on	5-1
5.2 Configure the controller for the communication with the 2141 fieldbus module	5-2
5.2.1 Protection against uncontrolled restart	5-2




Contents


6	Parameter setting	6-1
6.1	Parameter data channel configuration	6-2
6.1.1	Parameter data	6-2
6.1.2	Network variable for the parameter data channel	6-3
6.1.2.1	Structure of network variables	6-3
6.2	Overview: Network variable and configuration variable	6-1
6.2.1	Overview: Node Object	6-1
6.2.2	Overview: Network variable for VSD control	6-2
6.2.3	Overview: Network variable for AIF-CTRL control	6-2
6.2.4	Overview: Configuration variable for VSD control	6-3
6.3	Node Object	6-4
6.3.1	Inhibit / Enable all objects	6-4
6.3.2	Status messages	6-4
6.4	VSD control VSD	6-5
6.4.1	Network variable (VSD)	6-5
6.4.1.1	Speed setpoint	6-5
6.4.1.2	Actual speed value	6-6
6.4.1.3	Scaling of the speed setpoint	6-7
6.4.1.4	Motor current	6-8
6.4.1.5	Motor voltage	6-9
6.4.1.6	Operating time	6-10
6.4.2	Configuration variable (VSD)	6-11
6.4.2.1	Location label	6-11
6.4.2.2	Receive Heartbeat Time	6-12
6.4.2.3	Maximum Send Time	6-13
6.4.2.4	Minimum Send Time	6-14
6.4.2.5	Maximum speed	6-15
6.4.2.6	Minimum speed	6-16
6.4.2.7	Rated speed value	6-17
6.4.2.8	Rated frequency	6-18
6.4.2.9	Acceleration time	6-19
6.4.2.10	Deceleration time	6-20
6.4.2.11	Receive heartbeat for AIF-CTRL	6-21
6.4.2.12	Monitoring reaction for AIF-CTRL	6-22
6.4.2.13	Default value for nviDrvSpeedScale	6-23
6.5	Device control AIF-CTRL	6-24
6.5.1	General information	6-24
6.5.1.1	Output variable	6-24
6.5.1.2	Input variable	6-25
6.5.2	Network variable for 82XX controllers	6-26
6.5.2.1	Status word for 82XX	6-27
6.5.2.2	Control word for 82XX	6-29
6.5.3	Network variable for 8200 vector controllers	6-30
6.5.3.1	Status word for 8200 vector	6-32
6.5.3.2	Control word for 8200 vector	6-33
6.5.4	Network variable for 93XX controllers	6-35
6.5.4.1	Status word for 93XX	6-37
6.5.4.2	Control word for 93XX	6-40
6.5.5	Network variable for 9300 Servo PLC and Drive PLC	6-42



7 Troubleshooting and fault elimination	7-1
7.1 No communication with the controller.	7-1
7.2 Controller does not execute write job	7-1
8 Appendix	8-1
8.1 Starting Global Drive Control (GDC) from LONMakert	8-1
8.1.1 Installation instructions for the plug-In	8-1
8.1.2 Open GDC from the LONMakert	8-2
8.2 Configuration of the LON network	8-3
8.2.1 Configuration of the LON network	8-3
8.2.2 Working with network variables	8-5
8.2.3 Registration of new data types	8-8
8.3 List of abbreviations	8-9
8.4 Glossary	8-10
8.5 More information sources	8-10
8.6 Table of keywords	8-11



Contents



1 Preface and general information

1.1 How to use these Operating Instructions

- These Operating Instructions are intended for safety-relevant working on and with the 2141 fieldbus module. They contain safety information which must be observed.
- All personnel working on and with the 2141 fieldbus module must have these Operating Instructions available and observe the information and notes relevant for them.
- The Operating Instructions must always be complete and perfectly readable.


These Operating Instructions contain the most important technical data and describe the installation of the 2141 fieldbus module. They are only valid in combination with the Operating Instructions of the corresponding controller.

1.1.1 Terminology used

Controller	In the following, the term "controller" is used for "93XX servo inverters" or "82XX frequency inverters".
Drive system	In the following, the term "drive system" is used for drive systems with fieldbus modules or other Lenze drive components.
Field bus module	In the following text, the term "fieldbus module" is used for the fieldbus module type 2141 LON.
Cxxx/y	Subcode y of code Cxxx (z.B. C0410/3 = subcode 3 of code C0410)
Xk/y	Terminal strip Xk/terminal y (z.B. X3/28 = terminal 28 on terminal strip X3)
(□xx-yyy)	Cross reference (chapter - page)

1.2 Packing list

Scope of supply	Important
• 1 2141 fieldbus module with housing (enclosure IP20) • 1 M3 fixing screw • 1 2-pole plug connector for voltage supply • 1 2-pole plug connector for LON • 1 Mounting Instructions • 1 floppy	After the delivery has been received, check immediately whether the items supplied match the accompanying papers. Lenze does not accept any liability for deficiencies claimed subsequently. Claim • visible transport damage immediately to the forwarder • visible deficiencies/incompleteness immediately to your Lenze representative.



Preface and general information

1.2.1 Legal regulations

Labelling	Nameplate	CE mark	Manufacturer
	Lenze 2141 fieldbus modules are unambiguously identified by their nameplates.	Conforms to the EC Low Voltage Directive	Lenze Drive Systems GmbH Postfach 101352 D-31763 Hameln
Application as directed	Fieldbus module 2141 • Operate the fieldbus module only under the conditions prescribed in these Operating Instructions. • The fieldbus module is an additional module and can be optionally attached to the Lenze controller series 820X, 821X, 822X, 8200 vector and 93XX. The 2141 fieldbus module links these Lenze controllers with the standardized serial communication system LON. • The fieldbus module must be attached and electrically connected so that it complies with its function and does not cause any hazards when attached and operated as instructed. • Observe all notes given in chapter „Safety information“ 2-1. • Please observe all information given in these Operating Instructions.This means: – Read these Operating Instructions carefully before you start to work with the system. – These Operating Instructions must always be available during operation of the fieldbus module. Any other use shall be deemed as inappropriate!		
Liability	• The information, data, and notes in these instructions met the state of the art at the time of printing. Claims referring to drive systems which have already been supplied cannot be derived from the information, illustrations, and descriptions given in these Operating Instructions. • The specifications, processes, and circuitry described in these instructions are for guidance only and must be adapted to your own specific application. Lenze does not take responsibility for the suitability of the process and circuit proposals. • The specifications in these Instructions describe the product features without guaranteeing them. • Lenze does not accept any liability for damage and operating interference caused by: – disregarding these Instructions – unauthorized modifications to the controller – operating errors – improper working on and with the controller		
Warranty	• Warranty conditions: see Sales and Delivery Conditions of Lenze Drive Systems GmbH. • Warranty claims must be made to Lenze immediately after detecting the deficiency or fault. • The warranty is void in all cases where liability claims cannot be made.		
Disposal	Material	recycle	dispose
	Metal	●	-
	Plastic	●	-
	Assembled PCBs	-	●
	Operating Instructions	●	



2 Safety information

2.1 Persons responsible for the safety

Operator

- An operator is any natural or legal person who uses the drive system or on behalf of whom the drive system is used.
- The operator or his safety personnel is obliged
 - to ensure the compliance with all relevant regulations, instructions and legislation.
 - to ensure that only skilled personnel works on and with the 2102IB fieldbus module.
 - to ensure that the personnel has the Operating Instructions available for all corresponding works.
 - to ensure that all unqualified personnel are prohibited from working on and with the drive system.

Qualified personnel

Qualified personnel are persons who - because of their education, experience, instructions and knowledge about corresponding standards and regulations, rules for the prevention of accidents and operating conditions - are authorized by the person responsible for the safety of the plant to perform the required actions and who are able to recognize potential hazards.

(Definition for skilled personnel to VDE105 or IEC364)

2.2 General safety information

- These safety notes do not claim to be complete. In case of questions and problems please contact your Lenze representative.
- At the time of delivery the fieldbus module meets the state of the art and ensures basically safe operation.
- The indications given in these Operating Instructions refer to the stated hardware and software versions of the fieldbus modules.
- The fieldbus module is hazardous if:
 - unqualified personnel works on and with the fieldbus module.
 - the fieldbus module is used inappropriately.
- The processing notes and circuit sections shown in these Operating Instructions are proposals which cannot be transferred to other applications without being tested and checked.
- Ensure by appropriate measures that neither personal injury nor damage to property may occur in the event of failure of the fieldbus module.
- The drive system must only be operated when no faults occur.
- Retrofittings, modifications or redesigns are basically prohibited. Lenze must be contacted in all cases.
- The fieldbus module is electrical equipment intended for use in industrial high-power plants. The fieldbus module must be tightly screwed to the corresponding controller during operation. In addition, all measures described in the Operating Instructions of the controller used must be taken. Example: Fastening of covers to ensure protection against contact.



Safety information

Restgefahren, Gestaltung der Sicherheitshinweise

2.3 Layout of the safety information


All safety information given in these Instructions have got the same structure:



Signal word (indicates the severity of danger)

Note (describes the danger and informs the reader how to avoid danger)

	Icons used		Signal words	
Warning of danger to persons		Warning of hazardous electrical voltage	Danger!	Warns of impending dangerr . Consequences if disregarded: Death or severe injuries.
		Warning of a general danger	Warning!	Warns of potential, very hazardous situations . Consequences if disregarded: Death or severe injuries.
			Caution!	Warns of potential, hazardous situations . Consequences if disregarded: Light or minor injuries.
Warning of damage to materials			Stop!	Warns of possible damage to material . Consequences if disregarded: Damage of the controller/drive system or its environment.
Other notes			Tip!	It designates general, useful notes. If you follow the tip, handling of the controller/drive system will be easier.




3 Technical data

3.1 Features of the 2141 fieldbus module

- Attachable additional module for the following devices:
 - 82XX
 - 8200 vector
 - Drive PLC
 - 93XX
 - 9300 Servo PLC
- LON connection module with the LONMARK® Functional Profile “Variable Speed Motor Drive”
- Access to all Lenze parameters
- Internal and external 24-V-DC voltage supply possible with devices listed above (exception 820X: only external supply)

3.2 General data / application conditions

Field	Values
Order name	EMF2141IB
Network topology	Free topology (line, tree, star, ring)
Possible number of nodes	64
Max. cable length	2700 m with bus topology 500 m if the topology is mixed
Baud rate	78 kBit/s
Ambient temperature	during operation: 0° C ... 55° C during transport: -25° C ... 70° C during storage: -25° C ... 60 °C
Permissible humidity	Class 3K3 to EN 50178 (without condensation, average relative humidity 85%)



Technical data

3.3 Rated data

Field	Values	
Voltage supply	24 V DC $\pm$ 10 %; max. 120 mA	
Communication profile	LONMARK® Functional Profile "Variable Speed Motor Drive"	
Communication medium	FTT - 10 A (Free Topology Transceiver)	
Insulation voltage between bus and ...	Rated insulation voltage	Insulation type
• Earth reference / PE	50 V AC	Mains isolation
• External supply (terminal 39/59)	50 V AC	Mains isolation
• Power stage		
– 820X / 821X	270 V AC	Basic insulation
– 822X / 8200 vector	270 V AC	Double insulation
– 93XX	270 V AC	Double insulation
• Control terminals		
– 820X / 8200 vector (with internal supply)	0 V AC	No mains isolation
– 8200 vector (with external supply)	100 V AC	Basic insulation
– 821X	50 V AC	Mains isolation
– 822X	270 V AC	Basic insulation
– 93XX	270 V AC	Basic insulation
Degree of pollution	VDE0110, part 2, pollution degree 2	

3.4 Dimensions





Fig. 3-1 Dimensions of the 2141 fieldbus module (all dimensions in mm)



3.5 Communication times

The communication times depend on

- the data transmission time which depends on
 - the baud rate
 - the user-data length
- the processing time in the basic unit (see the following chapter)



Tip!

You will find more information about the data-transfer time in the documentation for your host system.

3.5.1 Processing time in the basic unit

The processing time in the basic unit starts when a message arrives at the fieldbus module (action) and ends with the response of the basic unit to this message.

Processing time 820X

Action	Processing step	Max. time required by the controller	
• Writing of control word or setpoint, if the value has changed	Writing of status word and actual value	200 ms	+40 ms tolerance
• Alternating reading of status word and actual value	Control word <u>or</u> setpoint reading	27 ms	+48 ms Toleranz
	Control word <u>and</u> setpoint reading	54 ms	+56 ms tolerance
• Processing of parameter access if there is a service	Read parameter	55 ms	+48 ms tolerance
	Parameter writing	108 ms	+32 ms tolerance

Tab. 3-1

Processing time: 820X

Processing time: 821X / 8200 vector / 822X

Parameter data and process data are independent of each other.

- Parameter data: 30 ms + 20 ms tolerance
- Process data: approx. 3 ms + 2 ms tolerance

Processing time: 9300 servo inverter

Parameter data and process data are independent of each other.

- Parameter data: approx. 30 ms + 20 ms tolerance (typical)
 - The processing time can be longer for some codes (see 9300 Manual).
- Process data: approx. 3 ms + 2 ms tolerance

Processing time: Drive PLC / 9300 Servo PLC

Parameter data and process data are independent of each other.


- Parameter data: approx. 30 ms + 20 ms tolerance
- Process data depend on the process image.
 - The process image is an update of process data made after every task cycle.

3.5.2 Number of devices connected to the bus


The maximum bus size depends on

- the baud rate used
- the number of repeaters

For more detailed information see the documentation for the control system.



Technical data



4 Installation

4.1 Elements at the front of the 2141 fieldbus module





Fig. 4-1

Front view of the 2141 LON fieldbus module

Pos.	Name/meaning
[A]	Green bus LED indicates the voltage supply status for the 2141 fieldbus module. ON: 2141 fieldbus module is supplied with voltage and connected to the controller. OFF: 2141 is not supplied with voltage; controller and external voltage supply are switched off. BLINKING: 2141 fieldbus module is supplied with voltage but not connected to the controller. Possible reasons: Controller is switched off, in initialisation or not connected.
[B]	Yellow bus LED indicates the communication status for the 2141 fieldbus module. OFF: 2141 fieldbus module has not been initialised yet. BLINKING: LON communication is not active
[C]/ [D]	Green or red DRIVE-LED Operating status of 82XX, 8200 vector or 93XX (see Operating Instructions for controller)
[E]	Service LED OFF: Normal operating status BLINKING: Fieldbus module not configured yet ON: No program available in Neuron
[F]	Service key e.g. for signing on a fieldbus module with the configuration tool "LONMaker™ for Windows®" 8-1
[G]	Two-pole plug for external voltage supply of the 2141 fieldbus module +: Input voltage (see chapter: Technical Data) - : Reference potential for external voltage (GND)
[H]	Two-pole plug for LON communication Max. cable cross-section: 1.5 mm ²
[I]	Only for 820X, 821X: Additional PE shield cable avoids EMC related communication interference



Installation

4.1.1 Connection of external voltage supply


Name	Explanation
24 V DC /+	External voltage supply +24 V DC/ $\pm 10\%$, 120 mA max.
24 V DC /-	GND; reference for external voltage supply

4.1.2 Connection for LON bus

Name	Explanation
FTT /	Connection for LON bus, two cores (twisted pair)


4.1.3 Data for connection terminals

Electrical connection	Plug connector with threaded terminal end
Possible connections	rigid: 1.5 mm ² (AWG 16)
	
	flexible:
	without wire crimp cap 1.5 mm ² (AWG 16)
	with wire crimp cap, without plastic sleeve 1.5 mm ² (AWG 16)
Tightening torque	0.5 Nm (4.4 lb-in)
	7 mm
Bare end	7 mm



4.2 Mechanical installation

- Plug the fieldbus module onto the controller (here: 8200 vector)




2141LON001

- Use the fixing screw to mount the fieldbus module.



2141LON002



Installation

4.3 Electrical installation

4.3.1 Wiring to a host



Stop!

An additional mains isolation is required, if

- a 820X or 821X controller is connected to a host and
- a safe mains isolation (double basic insulation) to VDE 0160 is necessary.


For this, it is, for instance, possible to use an interface module which provides an additional mains isolation (see corresponding manufacturer's data).


For wiring, the electrical isolation of the supply voltage must be taken into account.



Tip!

The communication of controllers 820X and 821X may be interfered by electromagnetic radiation. If necessary, use an additional PE shield cable.





4.3.2 Voltage supply

- Internal voltage supply
 - If possible, use all devices without external voltage supply because of EMC-relevant reasons.
- External voltage supply (4-1)
 - Absolutely required for 820X controllers.
 - If the 2141 fieldbus module is to be able to communicate even if the basic device is switch off.
- If the bus system is distributed over several control cabinets, install a separate power supply in every control cabinet to supply all devices/fieldbus modules.
Install an equipotential bonding conductor between the control cabinets.




Tip!

Internal voltage supply of the fieldbus module connected to a 8200 vector


Controllers with an extended AIF interface (front of the 8200 vector) can be internally supplied. The part of the drawing highlighted in grey shows the jumper position.

With Lenze setting, the fieldbus module is not internally supplied.
For internal voltage supply, put the jumper in the position indicated below.

Lenze setting (only external voltage supply)	Internal voltage supply



Installation



5 Commissioning

5.1 First switch-on

Please do not change the switch-on sequence explained below!




Stop!

Prior to first switch-on of the controller, check the wiring for

- Completeness
- Short circuit
- Earth fault

Step	Procedure	Remarks
1.	Connect the basic unit and if available external supply for the fieldbus module.	• One of the two operating status LEDs at the controller, see 4-1, must be on or blinking. If this is not the case, see 7-1 • The green Vcc display must also be on, see 4-1. If this is not the case, see 7-1.
2.	Configuration of controllers connected to the bus	Configure the controllers connected to the bus by means of an appropriate configuration tool → e.g. LONMAKER™ for Windows®, see 8-1
3.	It should now be possible to communicate with the drive.	The yellow bus LED is blinking, see 4-1, when data is exchanged between the 2141 fieldbus module and other controllers connected to the bus.
4.	Drive-specific settings	→ Operating Instructions of the basic unit
5.	Enable controller	→ Terminal controller inhibit (CINH) = HIGH
6.	Setpoint selection	→ The drive should be running now.



Commissioning

5.2 Configure the controller for the communication with the 2141 fieldbus module

82XX / 8200 vector	- The drive can be controlled through LON, if the Lenze parameter "Operating mode" (C0001) is changed from 0 to 3. This change can be made by using the keypad or directly via LON. - Example: For LON Write (C0001=3), subindex: 0, value = 30000. Please see the information about how to change parameter values of a code in chapter 6.1.2.1. - Terminal 28 (controller enable) <u>is always active</u> and must be HIGH for LON operation (see the corresponding Operating Instructions). Otherwise, the controller cannot be enabled by the LON. 821X, 8200vector and 822X: The QSP function (quick stop) <u>is always active</u>. A input terminal configured for QSP (default setting: not assigned) must be HIGH during LON operation (see Operating Instructions for the controller). - The controller now accepts control and parameter-setting data from the LON.
93XX	- If you want to control the drive via LON, configure the Lenze parameter "Signal configuration" (C0005) for xxx3. This change can be carried out using the 9371BB keypad or the LON. Select the signal configuration 1013 for first commissioning. - Example: For LON Write (C0005=1013), subindex: 0, value: 10130000. Please see the information about how to change parameter values of a code in chapter 6.1.2.1. - Set the parameter C0142 to 0. Please read the next TIP for code C0142. - Terminal 28 (RFR = controller enable) <u>is always active</u> and must be HIGH for LON operation (see Operating Instructions for the controller). Otherwise, the controller cannot be enabled by the LON. - With the signal configuration C0005=1013, the QSP function (quick stop) and the CW/CCW changeover are assigned to the input terminals E1 and E2, and thus they are always active. E1 must be HIGH for LON operation (see 93XX Operating Instructions). With the signal configuration C0005=xx13, terminal A1 is configured as voltage output. Therefore, only the following terminals must be connected via cables: - X5.A1 with X5.28 (ctrl. enable) - X5.A1 with X5.E1 (CW/QSP) - The controller now accepts control and parameter-setting data from the LON.

5.2.1 Protection against uncontrolled restart




Tip!

After an error or fault (e.g. short-term mains failure) a restart of the drive is not always wanted.

- The start condition can be changed, i.e. the drive can be inhibited by setting C0142 = 0 for the event that
 - the corresponding controller sets a fault „Message“
 - the fault is active for more than 0.5 s

Parameter function:

- C0142 = 0
 - Controller remains inhibited (even if the fault is not active any longer)
 - The drive restarts in a controlled mode: LOW-HIGH transition at one of the inputs for „Controller inhibit“ (CHIN, e.g. at terminal X5/28)
- C0142 = 1
 - Uncontrolled restart of the controller possible



6 Parameter setting

General information on parameter setting

Two different data types are transferred by the 2141 fieldbus module:

- Parameter data
- Process data,


Different communication channels are assigned to parameter and process data:

Telegram type		Communication channel	
Parameter data	These are, for instance, • Operating parameters • diagnostics information • motor data In general, the parameter transfer is not as time-critical as the transfer of process data.	Parameter data channel (chapter 6.1)	• Enables the access to all Lenze codes. • Parameter changes are normally saved in the controller (observe C0003). • If the parameter channel is active, it assigns 4 words of the input and output process data. (6-2)
Process data	These are, for instance, • Setpoints • Actual values Exchange between host and controller required as fast as possible. Small amounts of data, which are transferred cyclically.	Process-data channel (chapter 6.2)	• The controller can be controlled using the process data. (6-7). • The host has direct access to the process data. In the PLC, for instance, the data are directly assigned to the I/O area. • Process data are – not stored in the controller. – cyclically transferred between the host and the controller (continuous exchange of current input and output data).

Tab. 6-1

Division of parameter data and process data into different communication channels

The communication protocol is only described as much as it is needed for building up the network with Lenze controllers.



Parameter setting

6.1 Parameter data channel configuration

6.1.1 Parameter data

Parameter data are addressed through Lenze codes. You find a code table in the Operating Instructions for your controller.

Lenze parameter sets

Parameter sets are for special code saving which is necessary because of different configurations for different application processes.


The following table informs about the number of parameter sets and how to address them.

82XX	8200 vector	93XX
82XX and 8200 vector controllers have 2 and 4 parameter sets. They can be directly addressed through LON. They are addressed by means of a code-digit offset: - Offset 0 addresses parameter set 1 with Lenze codes C0000 to C1999 - Offset 2000 addresses parameter set 2 with Lenze codes C2000 to C3999 No additional parameter sets available.		93XX controllers have 4 parameter sets (depending on the variant) for non-volatile saving. Another parameter set is in the user memory of the controller. This is the current parameter set . After switching on the controller, parameter set 1 is automatically loaded into the current parameter set. Changes of the current parameter set will be lost after switching off the controller. The current parameter set is stored in code C0003. Only the current parameter set can be directly addressed through LON. The 93XX codes are listed in the Operating Instructions and the Manual.
If a parameter is available only once (see Operating Instructions for 82XX or 8200 vector), use the code digit offset 0. Example for C0011 (maximum field frequency): C0011 in parameter set 1: Lenze code = 11 C0011 in parameter set 2: Lenze code = 2011 - C0011 in parameter set 3: Lenze code = 4011 C0011 in parameter set 4: Lenze code = 6011		
Parameter changes		
Automatic saving in the controller	Automatic saving (can be switched off under C0003)	Changes must be saved in code C0003. All changes made without storing them will be lost after the controller is switched off.
Process data changes		
No automatic saving	No automatic saving	No automatic saving



Stop!

- For 8200 vector
 - Please note that it is not allowed to write parameter data to the EEPROM.
 - If you want to cyclically change parameter data, the code must be configured as follows after every mains switching: C0003 = 0.
- For 82XX
 - Please note that it is not allowed to cyclically write parameter data to the EEPROM.



6.1.2 Network variable for the parameter data channel

The network variables `nviParamReq`, `nvoParamRes` and `nvoLongRes`

- enable parameter setting and diagnostics.
- allow access to all Lenze parameters (codes).

The input network variable `nviParamReq` allows to send a read or write request to the drive.

With parameters with a length of up to 4 bytes, the response is output through the output network variable `nvoParamRes`.

With parameters bigger than 4 bytes, the response to a read request is output through the network variable `nvoLongRes`.

6.1.2.1 Structure of network variables



Tip!

User data are displayed in left-justified Motorola format.

High byte or high word are shown before low byte or low word (see Calculation examples (6-6)).

The structure of `nviParamReq` and `nvoParamRes` is defined as follows:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte	9th byte
Length	code High byte	code Low byte	Subcode	Service	Data 4	Data 3	Data2	Data1
								Error code

The structure of `nvoLongRes` is defined as follows:

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte		28th byte
Length	code High byte	code Low byte	Subcode	Service	Data 1		Data23

Details about the parameter data telegram:	1st byte
	Length

Indicates the length of the following byte for write orders. Value range: 1, 2 or 4.

Details about the parameter data telegram:	2nd byte	3rd byte
	code High byte	code Low byte

Byte 2 and byte 3 contain the code to be used.


Details about the parameter data telegram:	4th byte
	Subcode

Byte 4 contains the subcode to be used.

- The series 82XX do not have codes with subindex, the value is always 0.
- Many codes of 93XX and 8200 vector controllers require additional addressing via a subindex.

Example for 9300 servo inverters:

Code C0039 / subcode 3 addresses " NSET JOG" (50% = default setting)



Parameter setting

Details about the parameter data telegram:

5th byte

Service

Order type

1 = Read

2 = Write

Data contents

- Response ok
 - Read: 1
 - Write: 2
- Faulty response
 - Read: $81_{\text{hex}} (80_{\text{hex}} + 1)$
 - Write: $82_{\text{hex}} (80_{\text{hex}} + 2)$

Details about the parameter data telegram:

6th byte

Data 4

7th byte

Data 3

8th byte

Data 2

9th byte

Data 1

Bytes 6 to 9 contain the data to be written.

Bytes 6 to 9 are not relevant for reading orders.

The parameters of the corresponding code are changed by multiplying the parameter value with 10000 (the result is an integer value). Lenze parameters are mainly in the fixed-point format ,data type Integer32, with four decimal codes.



Tip!

Please see the Operating Instructions for your controller for the value range of Lenze codes.


Lenze parameters		dec	hex
Example:	Set C0039 (JOG) = 150.4 Hz	$150.4 \times 10000 = 1504000$	$= 0016F300$

The parameter value needs 1 to 4 bytes depending on the data format (see “Attribute table” in the Operating Instructions for your controller)

6th byte	7th byte	8th byte	9th byte
Data 4	Data 3	Data 2	Data 1
High byte	Low byte	High byte	Low byte
High word		Low word	
Double word			

Assignment of bytes 6 to 9 with parameter value of different lengths

6th byte	7th byte	8th byte	9th byte
00	00	00	Parameter value (length 1)
00	00	Parameter value (length 2)	
Parameter value (length 4)			



Details about the parameter data telegram:	6th byte	7th byte	8th byte	9th byte
				Error code

If processing the order is completed correctly, the variable `nvoParamRes` contains the read data or a copy of the written data.

If an error occurs in the network variable `nvoParamRes` the error code will be entered in byte 9. The error code can be read from byte 9 if

- the value of byte 1 = 1 and
- bit 7 is set in byte 5 (i.e. the value of byte 5 = 80_{hex}, see example below).



Tip!

Strings and data blocks cannot be written.

The following table explains the error codes.


Error code		Meaning of error message
dec	hex	
01	01	Service-ID invalid
02	02	Caller-ID invalid
03	03	Data type invalid
04	04	Subcode-No. invalid
05	05	Code-No. invalid
06	06	Parameter invalid, general
07	07	No access authorisation because of operating status
08	08	No access authorisation because of operating mode
09	09	No access authorisation because parameter can only be read
10	A	No access authorisation
11	B	Data block too long
12	C	Collision with other parameter values
14	D	Quit value range
15	I	General limit value exceeding
32	20	General
33	21	Time limit exceeded
34	22	Frame error
35	23	Parity error
36	24	Overflow

Example:

The brake opening time, code C0196 (C4_{hex}), is wrong.

Error code 14, 'Parameter value exceeds the max. permissible value'.

1st byte	2nd byte	3rd byte	4th byte	5th byte	6th byte	7th byte	8th byte	9th byte
01	00	C4	00	80	00	00	00	0E



Parameter setting

Example 1: Read parameter

The heat sink temperature (Here: $\vartheta = 43^{\circ}\text{C}$) of the controller is to be read (C0061).

- Byte 1: Length
– 4 (data length 4 bytes)
- Byte 2 and byte 3: Code
– C0061: 61 = 3D_{hex}
- Byte 4: Subcode
– Subindex = 0, as there is not subindex under code C0061.
- Byte 5: Service
– Service = 1 (Read)
- Byte 6 ... 9: Data (part of the response of nvoParamRes)
– Data 1 to data 4 = $43[^{\circ}\text{C}] \times 10000 = 430000 = 00\ 06\ 8F\ B0_{\text{hex}}$

Result:

	Byte1 Lengt h	Byte 2 + byte 3 code	Byte 4 Lenze subcode	Byte 5 Service	Byte 6	Byte 7	Byte 8	Byte 9
Request telegram from master to drive								
Hex:	04	003D	00	01	00	00	00	00
Wait for response identification with code = 003D and subcode 0								
Response telegram from drive to master (for faulty execution)								
Hex:	04	003D	00	01	00	06	8F	B0

Tab. 6-2

Telegram exchange in LON parameter data channel

Example 2: Write parameter

The acceleration time (C0012) of the controller is to be set to $T_{ir} = 20\text{ s}$.


- Byte 1: Length
– 4 (data length 4 bytes)
- Byte 2 and byte 3: Code
– C0012: 12 = 0C_{hex}
- Byte 4: Subcode
– Subindex = 0, as there is not subindex under code C0061.
- Byte 5: Service
– Service = 2 (Write)
- Byte 6 ... 9: Data (part of the response of nvoParamRes)
– Data 1 to data 4 = $20\text{ [s]} \times 10000 = 200000 = 00\ 03\ 0D\ 40_{\text{hex}}$

Result:

	Byte1 Lengt h	Byte 2 + byte 3 code	Byte 4 Lenze subcode	Byte 5 Service	Byte 6	Byte 7	Byte 8	Byte 9
Request telegram from master to drive								
hex:	04	000C	00	02	00	03	0D	40
Wait for response identification with code = 000C and subcode 0								
Response telegram from drive to master (for faulty execution)								
hex:	04	000C	00	02	00	00	00	00

Tab. 6-3

Telegram exchange in LON parameter data channel



6.2 Overview: Network variable and configuration variable

Communication with 2141 fieldbus module via network variable.

The control **Variable Speed Motor Drive (VSD)** is the part of the network variable defined in the LonMark® Functional Profile.

The Lenze control **AIF-CTRL** is the manufacturer-related part of the network variable. Lenze drives are parameterised and controlled by AIF-CTRL.

The changeover between the two controls is automatic.

- VSD is active if one of the variables `nviDriveSpeedStpt` or `nviDriveSpeedScale` gets a new value.
- AIF-CTRL is active if one of the variables `nviAIFIn1` to `nviAIFIn3` or `nviAIFStw` gets a new value.

The network variable **Node Object** accesses the entire node.

6.2.1 Overview: Node Object





Fig. 6-1

Node Object, described in chapter 6.3



Parameter setting

6.2.2 Overview: Network variable for VSD control




Fig. 6-2 Network variable VSD, described in chapter 6.4

6.2.3 Overview: Network variable for AIF-CTRL control





Fig. 6-3 Network variable AIF-CTRL, described in chapter 6.5



6.2.4 Overview: Configuration variable for VSD control





Fig. 6-4 Configuration variable VSD, described in chapter 6.4.2



Parameter setting

6.3 Node Object

6.3.1 Inhibit / Enable all objects

All objects can be inhibited or enabled via the network variable `nvi00Request`:


- Inhibit: `nvi00Request.object_id = Object no.`
`nvi00Request.object_request = 1 (RQ_DISABLED)`
- Enable: `nvi00Request.object_id = Object no.`
`nvi00Request.object_request = 7 (RQ_ENABLED)`

6.3.2 Status messages

In the event of a communication error between the LON interface module and the basic unit the bit `comm_failure` will be set under `nvo00State`.

Structure Type Definition:

```
typedef struct {  
    unsigned long object_id;  
    unsigned invalid_id : 1;  
    unsigned invalid_request : 1;  
    unsigned disabled : 1;  
    unsigned out_of_limits : 1;  
    unsigned open_circuits : 1;  
    unsigned out_of_service : 1;  
    unsigned mechanical_fault : 1;  
    unsigned feedback_failure : 1;  
    unsigned over_range : 1;  
    unsigned under_range : 1;  
    unsigned electrical_fault : 1;  
    unsigned unable_to_measure : 1;  
    unsigned comm_failure : 1;  
    unsigned fail_self_test : 1;  
    unsigned self_test_in_progress : 1;  
    unsigned locked_out : 1;  
    unsigned manual_control : 1;  
    unsigned in_alarm : 1;  
    unsigned in_override : 1;  
    unsigned report_mask : 1;  
    unsigned programming_mode : 1;  
    unsigned programming_fail : 1;  
    unsigned alarm_notify_disabled : 1;  
    unsigned reserved1 : 1;  
    unsigned reserved1 : 8;  
} SNVT_obj_status;
```



6.4 VSD control VSD

6.4.1 Network variable (VSD)

6.4.1.1 Speed setpoint

```
network input SNVT_switch nviDrvSpeedStpt;
```

The input network variable offers the following:

- Motor start/stop option
- Speed selection in percent
(resolution = 0.5% ref. to value selected under `nciMaxSpeed`)

Input range

Status	Value	Command	Explanation
0 (FALSE)	NA	Stop	
1 (TRUE)	0	0%	
1 (TRUE)	1 to 200	0.5% to 100.0%	
1 (TRUE)	201 to 255	100.0%	
<code>jFF_{hex}</code>	NA	AUTO (invalid)	Standard value. This value will be set after a reset or if the time set under <code>nciRcvHrtBt</code> expires with an update of the variables. AUTO has the same function as stop, but is also used to check whether the "Receive Heartbeat Time" has expired.

Function

The speed setpoint for the controller is calculated as follows:

$$n_{\text{soll}} = \frac{\text{nviDrvSpeedStpt.value} \times \text{nviDrvSpeedScale}}{100}$$

The result is used as setpoint preselection in per cent. The setpoint selection is mapped to the AIF input data word 1 of the process data channel. Since 82XX and 93XX controllers expect different values here, the setpoints are converted in two different ways.

82XX controllers use a setpoint in Hz and a factor of 50 (24000 = 480Hz).

The value for AIF data word 1 is calculated as follows:


$$\text{AIFln.W1} = \frac{\text{nviDrvSpeedStPt.value}}{100[\%] \times 2 [\text{NVfactor}]} \times \frac{\text{nviDrvSpeedScale}}{100[\%] \times 200 [\text{NVfactor}]} \times \frac{\text{nciNm1Freq}}{10 [\text{NVfactor}]} \times 50 [\text{AIFfactor}]$$

93XX servos use a setpoint in % and a factor of 163.83 (16383 = 100%).

The value for AIF input data word 1 results from the following:

$$\text{AIFln.W1} = \frac{\text{nviDrvSpeedStPt.value}}{100[\%] \times 2 [\text{NVfactor}]} \times \frac{\text{nviDrvSpeedScale}}{100[\%] \times 200 [\text{NVfactor}]} \times 16383 [\text{AIFfactor}]$$

If the result of the calculation is a negative value, the direction of rotation will be reversed. This is done by setting bit 2 in the AIF control word.



Parameter setting

6.4.1.2 Actual speed value

network output SNVT_lev_percent nvoDrvSpeed;

The output network variable indicates the current speed as proportion of the rated value. Display value in [%].

Output range

The possible bandwidth for the output variables is between -163.840% and 163.830% . Resolution: 0.005% .

The value $+163.835\%$ ($7FFF_{\text{hex}}$) is assumed to be wrong.

Update rate

The variable is sent if the value changes or if the time set under *Maximum Send Time* (nciSndHrtBt) has expired.

The variable value will not be sent quicker than set in *Minimum Send Time* (nciNinOutTm).

Standard Service Type

The Standard Service Type is acknowledged.

Function

The value of `nvoDrvSpeed` results from the AIF output data word 1 of the process data channel. Since 82XX and 93XX send different value, the actual speed values are converted in different ways.

82XX controllers send actual values in [Hz] and a factor of 50 ($24000 = 480\text{Hz}$).


The value for `nvoDrvSpeed` results from:

$$\text{nvoDrvSpeed} = \frac{\text{AIFOut.W1}}{\frac{\text{nciNm1Freq}}{10 [\text{NVfactor}]} \times 50 [\text{AIFfactor}]} \times 100[\%] \times 200 [\text{NVfactor}]$$

93XX controllers send actual values in [%] and a factor of 163.83 ($16383 = 100\%$).

The value for `nvoDrvSpeed` results from:

$$\text{nvoDrvSpeed} = \frac{\text{AIFOut.W1}}{16383 [\text{NVfactor}]} \times 100[\%] \times 200 [\text{NVfactor}]$$



6.4.1.3 Scaling of the speed setpoint

```
network input SNVT_lev_percent nviDrvSpeedScale;
```

The setpoint can be scaled through this input network variable (`nviDrvSpeedStPt`).

Negative values result in the opposite direction of rotation.

$$\text{Actual speed setpoint} = \text{nviDrvSpeedStPt} \times \text{nviDrvSpeedScale}$$

Example:

- `nviDrvSpeedStPt.value` = 50%
- `nviDrvSpeedScale` = -150%

The actual speed setpoint is -75% of the rated value.

Input range

The possible bandwidth for the input variables is between -163.840% and 163.830%. Resolution 0.005%.

The value +163.835% (7FFF_{hex}) is assumed to be wrong.

Standard value

The standard value is determined by the "Configuration Property" `nciDrvSpeedScale`.

This value will be set after a reset or if the time set under `nciRcvHrtBt` passes without an update of the variable.

Function

The value of `nviDrvSpeedStPt.value` is multiplied with the value of `nviDrvSpeedScale` and divided by 100.

The result is used as setpoint preselection in per cent. The setpoint selection is mapped to the AIF input data word 1 of the process data channel. Since 82XX and 93XX controllers expect different values here, the setpoints are converted in two different ways.


82XX controller expect the setpoint in [Hz] and a factor of 50 (24000 = 480Hz). The value for AIF data word 1 is calculated as follows:

$$\text{AIFIn.W1} = \frac{\text{nviDrvSpeedStPt.value}}{100[\%] \times 2 [\text{NVfactor}]} \times \frac{\text{nviDrvSpeedScale}}{100[\%] \times 200 [\text{NVfactor}]} \times \frac{\text{nciNmlFreq}}{10 [\text{NVfactor}]} \times 50 [\text{AIFfactor}]$$

93XX controllers expect the setpoint in [%] and a factor of 163.83 (16383 = 100%). The value for AIF input data word 1 results from the following:

$$\text{AIFIn.W1} = \frac{\text{nviDrvSpeedStPt.value}}{100[\%] \times 2 [\text{NVfactor}]} \times \frac{\text{nviDrvSpeedScale}}{100[\%] \times 200 [\text{NVfactor}]} \times 16383 [\text{AIFfactor}]$$

If the result of the calculation is a negative value, the direction of rotation will be reversed. This is done by setting bit 2 in the AIF control word.



Parameter setting

6.4.1.4 Motor current

```
network output SNVT_amp nvoDriveCurnt;
```

This network variable outputs the actual output current in Ampere.

Output range

The possible bandwidth for the output variable is between –3276.8 A and +3276.6 A. Resolution 0.1 A.

The value +3276.7 A (7FFF_{hex}) is assumed to be wrong.

Update rate

The variable is sent if the value has changed or if the time set under *Configuration Property Maximum Send Time* (nciSndHrtBt) has expired.

The variable value will not be sent quicker than set in *Configuration Property Minimum Send Time* (nciMinOutTm).

Standard Service Type


The Standard Service Type is acknowledged.

Function

The output current is cyclically read from the drive (code 0054, subcode 00). The value is calculated as follows:

$$\text{nvoDriveCurnt} = \frac{\text{SDF.LW}}{10000 [\text{A/Factor}]} \times 10 [\text{NVfactor}]$$

If an error occurs during the query, *nvoDriveCurnt* will be set to 7FFF_{hex}.



6.4.1.5 Motor voltage

```
network output SNVT_volt nvoDrvVolt;
```

The output network variable indicates the current output voltage in [Volt].

Output range

The possible bandwidth for the output variable is between –3276.8 V and +3276.6 V.
Resolution 0.1 V.

The value +3276.7 V (7FFF_{hex}) is assumed to be wrong.

The typical output range is between 0 V and 700 V.

Update rate

The variable is sent if the value has changed.

The variable is sent as heart beat if the time set under *Configuration Property Maximum Send Time* (nciSndHrtBt) has expired.

The variable value will not be sent quicker than set in *Configuration Property Minimum Send Time* (nciMinOutTm).

Function


The current output voltage is cyclically read by the drive (code 0052, subcode 00). The value is calculated as follows:

$$\text{nvoDriveVolt} = \frac{\text{SDF.LW}}{10000 [\text{AlFfactor}]} \times 10 [\text{NVfactor}]$$

If an error occurs during the query, nvoDrvVolt is set to 7FFF_{hex}.

Standard Service Type

The Standard Service Type is acknowledged.



Parameter setting

6.4.1.6 Operating time

```
network output SNVT_time_hour nvoDrvRunHours;
```

This network variable output the entire operating time in hours.

Output range

The possible bandwidth for the output variable is between 0 and 65534 hours. Resolution: 1 hour.

The value of 65535 hours (FFFF_{hex}) is assumed to be wrong.

Update rate

The variable is sent if the value has changed.

The variable value will not be sent quicker than set in *Configuration Property Minimum Send Time* (nciMinOutTm).

Standard Service Type

The Standard Service Type is acknowledged.

Function

The operating time is cyclically read by the drive (code 0174, subcode 00).

82XX controllers send the operating time in hours with the AIF factor 10000 (30000 = 3 hours).

The value is calculated as follows:


$$\text{nvoDriveRunHours} = \frac{\text{SDF.LW}}{10000 [\text{AIFactor}]} \times 1 [\text{NVfactor}]$$

93XX controllers send the operating time in seconds without AIF factor.

The value is calculated as follows:

$$\text{nvoDriveRunHours} = \frac{\text{SDF.LW}}{3600 \left[\frac{\text{seconds}}{\text{hour}} \right]} \times 1 [\text{NVfactor}]$$

If an error occurs during the query, nvoDrvRunHours is set to FFFF_{hex}.



6.4.2 Configuration variable (VSD)

6.4.2.1 Location label

```
network input config SNVT_str_asc nciLocation;
```

This configuration variable can be used to store a 31-byte string.

Input range


A ZERO terminated string of max. 31 byte

Standard value

ZERO

SCPT Reference

SCPT_location (17)



Parameter setting

6.4.2.2 Receive Heartbeat Time

```
network input config SNVT_time_sec nciRcvHrtBt;
```

This configuration variable is used to store the time expected for an update, if this time expires without an update, the values for the following network variables will be reset to their default settings:

nviDrvSpeedStpt (6-11)

nviDrvSpeedScale (6-13)

It is also used to monitor the variables configured in nciAIFRecHrtBt (6-27). The variables are: nviAIFStw, nviAIFIn1, nviAIFIn2, nviAIFIn3.

Input range


The possible bandwidth for the configuration variable is between 0.0 and 6553.4 seconds (resolution 0.1 seconds)

Standard value

0.0 (no monitoring)

SCPT Reference

SCPTmaxRcvTime (48)



6.4.2.3 Maximum Send Time

```
network input config SNVT_time_sec nciSndHrtBt;
```

This configuration variable stores the time needed before the following network variables will be updated:

nvoDrvSpeed

nvoDrvCurnt

nvoDrvVolt

nvoAIFStw

nvoAIFOut1

nvoAIFOut2

nvoAIFOut3

Input range


The possible bandwidth for the configuration variable is between 0.0 and 6553.4 seconds (resolution 0.1 seconds)

Standard value

0.0 (no automatic update)

SCPT Reference

SCPTmaxSendTime(49)



Parameter setting

6.4.2.4 Minimum Send Time

```
network input config SNVT_time_sec nciMinOutTm;
```

Here you store the time needed before an output network variable can be updated.

Input range


The possible bandwidth for the configuration variable is between 0.1 and 6553.4 seconds (resolution 0.1 seconds)

Standard value

0.5 seconds

SCPT Reference

SCPTminSendTime (52)



6.4.2.5 Maximum speed

```
network input config SNVT_lev_percent nciMaxSpeed;
```

The configuration variable contains the maximum motor speed. The value is indicated as percentage of the rated value ($N_{ciNmlSpeed}$).

Input range

The possible bandwidth for the configuration variable is between -163.840% and 163.830% (resolution 0.005%). The value $+163.835\%$ ($7FFF_{hex}$) is assumed to be wrong.

The entered value will be checked by means of the following formula:

$$-163.840\% \leq \text{Minimum speed} \leq \text{Maximum speed} \leq 163.830\%$$

If the result is wrong, the lower value is taken as maximum speed.

Standard value


100.000 %

Function

After a change of the maximum speed, the value will be sent to the drive via the parameter channel (code 0011, subcode 00).

SCPT Reference

SCPTmaxSetpoint (50)



Parameter setting

6.4.2.6 Minimum speed

```
network input config SNVT_lev_percent nciMinSpeed;
```

The configuration variable contains the minimum motor speed. The value is indicated as percentage of the rated value (`nciNm1Speed`).

Input range

The possible bandwidth for the configuration variable is between -163.840% and 163.830% (resolution 0.005%). The value $+163.835\%$ ($7FFF_{\text{hex}}$) is assumed to be wrong.

The entered value will be checked by means of the following formula:

$$-163.840\% \leq \text{Minimum speed} \leq \text{Maximum speed} \leq 163.830\%$$

If the result is wrong, the lower value is taken as minimum speed.

Standard value


0.000 %

Function

After a change of the minimum speed, the value will be sent to the drive via the parameter channel (code 0010, subcode 00).

SCPT Reference

SCPTminSetpoint (53)



6.4.2.7 Rated speed value

```
network input config SNVT_rpm nciNmlSpeed;
```

This configuration variable contains the rated motor speed in rpm.

Input range

The possible bandwidth for the configuration variable is between 0 and 65534 rpm (resolution 1 rpm)

Standard value


3000 rpm

Function

After a change of the rated speed, the value will be sent to the drive via the parameter channel (code 0087, subcode 00).

SCPT Reference

SCPTnomRPM (158)



Parameter setting

6.4.2.8 Rated frequency

```
network input config SNVT_freq_hz nciNmlFreq;
```

This configuration variable contains the rated motor frequency in Hz.

Input range

The possible bandwidth for the configuration variable is between 0 and 6553,4 Hz (resolution 0,1 Hz)

Standard value


50 Hz

Function

After a change of the rated frequency, the value will be sent to the drive via the parameter channel (code 0089, subcode 00).

SCPT Reference

SCPTnomFreq (159)



6.4.2.9 Acceleration time

```
network input config SNVT_time_sec nciRampUpTm;
```

This configuration variable indicates the acceleration time of the motor.

Input range

The possible bandwidth for the configuration variable is between 0 and 6553.4 seconds (resolution 0,1 Sekunden)

Standard value


5 seconds

Function

After a change of the acceleration time, the value will be sent to the drive via the parameter channel (code 0012, subcode 00).

SCPT Reference

SCPT rampUpTm (160)



Parameter setting

6.4.2.10 Deceleration time

```
network input config SNVT_time_sec nciRampDownTm;
```

This configuration variable indicates the deceleration time of the motor.

Input range

The possible bandwidth for the configuration variable is between 0 and 6553.4 seconds (resolution 0,1 Sekunden)

Standard value


5 seconds

Function

After a change of the deceleration time, the value will be sent to the drive via the parameter channel (code 0013, subcode 00).

SCPT Reference

SCPTrampDownTm (161)



6.4.2.11 Receive heartbeat for AIF-CTRL

```
network input config SNVT_state nciAIFRecHrtBt;
```

Here you can select the manufacturer-specific network variables (`nviAIFStw`, `nviAIFIn1`, `nviAIFIn2`, `nviAIFIn3`) which are to be monitored with a *Receive Timeout*.

`nciAIFRecHrtBt.bit0 = 0` – No timeout monitoring for `nviAIFStw`

`nciAIFRecHrtBt.bit0 = 1` – Timeout monitoring for `nviAIFStw`

`nciAIFRecHrtBt.bit1 = 0` – No timeout monitoring for `nviAIFIn1`

`nciAIFRecHrtBt.bit1 = 1` – Timeout monitoring for `nviAIFIn1`

`nciAIFRecHrtBt.bit2 = 0` – No timeout monitoring for `nviAIFIn2`

`nciAIFRecHrtBt.bit2 = 1` – Timeout monitoring for `nviAIFIn2`

`nciAIFRecHrtBt.bit3 = 0` – No timeout monitoring for `nviAIFIn3`

`nciAIFRecHrtBt.bit3 = 1` – Timeout monitoring for `nviAIFIn3`

If one of the monitored variables gets a *Receive Heartbeat Timeout*, the function selected in `nciAIFDefStw` will be carried out.


Input range

The possible range for the input variable is 0 or 1 for every bit.

Only bits 0 and 3 will be evaluated.

Standard value

0



Parameter setting

6.4.2.12 Monitoring reaction for AIF-CTRL

```
network input config SNVT_state nciAIFDefStw;
```

If one of the monitored variables of the AIF-CTRL gets a Receive Heartbeat Timeout (▢ 6-30), the function selected in `nciAIFDefStw` will be carried out.

The quick stop functions sets bit 3 in the AIF control word, the controller inhibit function sets bit 9 in the AIF control word.



Tip!

The functions quick stop and controller inhibit will only be reset after all monitored variables have been updated within the Receive Heartbeat Timeout.

Input range

The possible bandwidth for the configuration variables is 0, 1 ooder 2


`nciAIFDefStw = 0` – No reaction

`nciAIFDefStw = 1` – Quick stop

`nciAIFDefStw = 2` – Controller inhibit

Standard value

0



6.4.2.13 Default value for nciDrvSpeedScale

```
network input config_lev_percent nciDrvSpeedScale;
```

This value determines the default setting for `nciDrvSpeedScale`. The current configuration variable `nciDrvSpeedScale` is overwritten with the default value

- after a reset or
- if the time from `nciRcvHrtBt` passes without an update of the variable `nciDrvSpeedScale`.

Input range

The possible bandwidth for the input variable is between -163.840 % and 163.830 % (resolution 0.005 %).


The value +163.835 % (7FFF_{hex}) is assumed to be wrong.

Standard value

0

SCPT Reference

SCPTdefScale (162)



6.5 Device control AIF-CTRL

6.5.1 General information

6.5.1.1 Output variable

```
network output SNVT_count nvoAIFStatus;
```

```
network output SNVT_count nvoAIFOut1;
```

```
network output SNVT_count nvoAIFOut2;
```

```
network output SNVT_count nvoAIFOut3;
```

The output network variable `nvoAIFStatus` is directly taken from the AIF status word.

The output network variables `nvoAIFOut1` to `nvoAIFOut3` are directly taken from the corresponding AIF data words.

Output range

The possible bandwidth for the output variable is between 0 and 65535.


Update range

The variables are sent if the value changes or if the time set under *Configuration Property Maximum Send Time* (`nciSndHrtBt`) has expired.

The variable value will not be sent quicker than set in *Configuration Property Minimum Send Time* (`nciMinOutTm`).

Standard Service Type

The Standard Service Type is acknowledged.



6.5.1.2 Input variable

```
network input SNVT_count nviAIFStw;
```

```
network input SNVT_count nviAIFIn1;
```

```
network input SNVT_count nviAIFIn2;
```

```
network input SNVT_count nviAIFIn3;
```

The input network variable `nviAIFStw` is directly accepted by the AIF control word.

The input network variables `nviAIFIn1` to `nviAIFIn3` are directly accepted by the corresponding AIF input data words.

1 Input range

The possible bandwidth for the output variable is between 0 and 65535.

Standard value

The standard value after a reset is 0 for all four variables.

The standard value for `nviAIFStw` is determined by the configuration properties `nciAIFDefStw` and `nciAIFRecHrtBt`. `nciAIFDefStw` indicates the function to be executed in the event of a *Receive Heartbeat Timeout* and `nciAIFRecHrtBt` indicates the variables monitored by a *Receive Heartbeat*.

`nciAIFRecHrtBt.bit0 = 1` – Timeout monitoring for `nviAIFStw`

`nciAIFRecHrtBt.bit1 = 1` – Timeout monitoring for `nviAIFIn1`

`nciAIFRecHrtBt.bit2 = 1` – Timeout monitoring for `nviAIFIn2`

`nciAIFRecHrtBt.bit3 = 1` – Timeout monitoring for `nviAIFIn3`


`nciAIFStw = 0` – No reaction

`nciAIFStw = 1` – Quick stop

`nciAIFStw = 2` – Controller inhibit

If one of the monitored variables gets a *Receive Heartbeat Timeout*, the function selected in `nciAIFDefStw` will be carried out.

The quick stop functions sets bit 3 in the AIF control word, the controller inhibit function sets bit 9 in the AIF control word. The functions quick stop and controller inhibit will only be reset after all monitored variables have been updated within the Receive Timeouts.



Parameter setting

6.5.2 Network variable for 82XX controllers

Setpoint source selection

The setpoint source for these controllers is selected under code C0001. An evaluation of process data is only possible if code C0001 is set to "3" when the controller is operated together with the fieldbus module.

Therefore the process data channel serves as setpoint source, describing the frequency setpoint (C0046) and the control word (parameter channel, C0135) (see Operating Instructions 82XX).



Tip!

Please observe that code C0001 is available in all parameter sets.

Network variable from drive

- `nvoAIFStatus` reads the status word (▢ 6-38)

Status word	
LOW byte	HIGH byte
Bits 0 to 7 of the status word (code C0150) are entered here.	Bits 8 to 15 of the status word (code C0150) are entered here.

- `nvoAifOut1` reads the actual frequency value

Actual frequency value	
LOW byte	HIGH byte
The actual frequency value is read from code C0050. The actual frequency value with the signed normalisation $24000 = 480$ Hz is provided here.	


Network variable to drive

- `nviAIFStw` writes the control word (▢ 6-39)

Control word	
LOW byte	HIGH byte
Bits 0 to 7 of the control word (code C0135) are entered here.	Bits 8 to 15 of the control word (code C0135) are entered here.


- `nviAIFIn1` writes the frequency setpoint

Frequency setpoint	
LOW byte	HIGH byte
The frequency setpoint (code C0046 via parameter data channel) is selected as process data word. The normalization differs from the setting under C0046. It is a signed value, $24000 = 480$ Hz.	



6.5.2.1 Status word for 82XX

Bit	820X	821x,822x
00	Actual parameter set 0 = Parameter set 1 or 3 active 1 = Parameter set 2 or 4 active	Actual parameter set 0 = Parameter set 1 or 3 active 1 = Parameter set 2 or 4 active
01	IMP (pulse inhibit) 0 = Pulses for power stage enabled 1 = Pulses for power stage inhibited	IMP (pulse inhibit) 0 = Pulses for power stage enabled 1 = Pulses for power stage inhibited
02	$I_{\max}$ (current limit reached) 0 = Current limit not reached 1 = current limit reached	$I_{\max}$ (current limit reached) 0 = Current limit not reached 1 = current limit reached
03	not assigned	$f_d = f_{dset}$ 0 = $f_d \neq f_{dset}$ 1 = $f_d = f_{dset}$
04	$f_d = f_{dset}$ 0: $f_d \neq f_{dset}$ 1: $f_d = f_{dset}$	RFG on = RFG off 0 = RFG on $\neq$ RFG off 1 = RFG on = RFG out
05	$Q_{\min}$ ($f_d \leq f_{dQ\min}$) 0 = $Q_{\min}$ not active 1 = $Q_{\min}$ active	$Q_{\min}$ ($f_d \leq f_{dQ\min}$) 0 = $Q_{\min}$ not active 1 = $Q_{\min}$ active
06	$f_d = 0$ (act. frequency = 0) 0: $f_d \neq 0$ 1: $f_d > 0$	$f_d > 0$ (actual frequency value = 0) 0 = $f_d \neq 0$ 1 = $f_d > 0$
07	Ctrl. inhibit (controller inhibit) 0 = controller not inhibited 1 = controller inhibited	Ctrl. inhibit (controller inhibit) 0 = controller not inhibited 1 = controller inhibited
08...11	Controller status 0 = Controller initialization 8 = Error active	Controller status 0 = Controller initialization 1 = Switch on inhibit 3 = Operation inhibited 4 = Flying-restart circuit active 5 = DC brake active 6 = Operation enabled 7 = Message active 8 = Error active
12	Overtemperature warning 0 = No warning 1 = Warning	Overtemperature warning 0 = No warning 1 = Warning
13	$U_{G\max}$ (DC-bus overvoltage) 0 = No overvoltage 1 = overvoltage	$U_{G\max}$ (DC-bus overvoltage) 0 = No overvoltage 1 = overvoltage
14	Direction of rotation 0 = CW rotation 1 = CCW rotation	Direction of rotation 0 = CW rotation 1 = CCW rotation
15	Ready 0 = not ready for operation 1 = ready for operation	Ready 0 = not ready for operation 1 = ready for operation



Parameter setting





Fig. 6-5 Read access to status word and actual frequency in 82XX (fixed assignment)



6.5.2.2 Control word for 82XX

Bit	820X	821x,822x
00, 01	00 = C0046 active 01 = JOG1 active in C0037 10 = JOG2 active in C0038 11 = JOG3 active in C0039	00 = C0046 active 01 = JOG1 active in C0037 10 = JOG2 active in C0038 11 = JOG3 active in C0039
02	CW/CCW (CW rotation/CCW rotation) 0 = CW rotation 1 = CCW rotation	CW/CCW (CW rotation/CCW rotation) 0 = CW rotation 1 = CCW rotation
03	QSP (quick stop) 0 = QSP not active 1 = QSP active	QSP (quick stop) 0 = QSP not active 1 = QSP active
04	Reserved	RFG stop (stop of the ramp function generator) 0 = RFG stop not active 1 = RFG stop active
05	Reserved	RFG zero (deceleration along the T _{if} ramp C0013) 0 = RFG zero not active 1 = RFG zero active
06	Reserved	UP function for motor potentiometer 0 = UP not active 1 = UP active
07	Reserved	DOWN function for motor potentiometer 0 = DOWN not active 1 = DOWN active
08	Reserved	Reserved
09	Ctrl. inhibit (controller inhibit) 0 = controller not inhibited 1 = controller inhibited	Ctrl. inhibit (controller inhibit) 0 = controller not inhibited 1 = controller inhibited
10	Reserved	Reserved
11	Reserved	TRIP reset 0 -> 1 = Edge from 0 to 1
12	PAR1 (Parameter set changeover) 0 -> 1 = Parameter set 1 -> 0 = Parameter set	PAR1 (Parameter set changeover) 0 -> 1 = Parameter set 1 -> 0 = Parameter set
13	Reserved	Reserved
14	DC brake (DC injection brake) 0 = DC brake not active 1 = DC brake active	DC brake (DC injection brake) 0 = DC brake not active 1 = DC brake active
15	Reserved	Reserved





Fig. 6-6 Access to control word and actual frequency in 82XX (fixed assignment)



Parameter setting

6.5.3 Network variable for 8200 vector controllers

Setpoint source selection

The setpoint source for these controllers is selected under code C0001. An evaluation of process data is only possible if code C0001 is set to "3" when the controller is operated together with the fieldbus module. (Selection: process data channel of a fieldbus module AIF-IN.W1 or AIF-IN.W2).

The process data channel which describes the frequency setpoint (C0046) and the control word (parameter channel, C0135) is the setpoint source (see 8200 vector Operating Instructions).


Check under C0412/x whether the setpoint source is assigned to the signal wanted.



Tip!

Please ensure that code C0001 or C0410 is the same for all parameter sets.

Digital and analog input and output signals can be freely configured (see Operating Instructions for 8200 vector; codes C0410, C0412, C0417 and C0421) The change of the code C0001 to 3 starts the preconfiguration of the process data words in the controller.



Network variable from drive (see function block AIF-OUT (6-38))

- `nvoAIFStatus` reads bits B0 ... B15 of the status word AIF-STAT (6-38)

Status word AIF-STAT	
LOW byte	HIGH byte
Bits 0 to 7 of the status word will be entered here.	Bits 8 to 15 of the status words will be entered here.

- `nvoAifOut1` reads the output word AIF-OUT.W1

Actual value	
LOW byte	HIGH byte
The actual frequency value with the signed normalisation $24000 = 480$ Hz is provided here. Torque values are normalised with $16384 = 100\%$. AIF-OUT.W1 see C0421/1, (Operating Instructions for 8200 vector)	

- `nvoAifOut2` reads the output word AIF-OUT.W2

Actual value	
LOW byte	HIGH byte
The actual frequency value with the signed normalisation $24000 = 480$ Hz is provided here. Torque values are normalised with $16384 = 100\%$. AIF-OUT.W2 see C0421/2, (Operating Instructions for 8200 vector)	

Network variable to drive (see function block AIF-IN (6-40))

- `nviAIFStw` writes bits B0 ... B15 in the control word AIF-CTRL (6-39)

Control word AIF-CTRL	
LOW byte	HIGH byte
Bits 0 to 7 of the control word will be entered here.	Bits 8 to 15 of the control word will be entered here.


- `nviAIFIn1` writes the input word AIF-IN.W1

AIF-IN.W1	
LOW byte	HIGH byte
The frequency setpoint is preselected as process data word. The normalisation differs from the setting under C0046. It is a signed value, $24000 = 480$ Hz. AIF-IN.W1 see C0412/x, Wert "10" (Operating Instructions for 8200 vector)	

- `nviAIFIn2` writes the input word AIF-IN.W2


AIF-IN.W2	
LOW byte	HIGH byte
The frequency setpoint is preselected as process data word. The normalisation differs from the setting under C0046. It is a signed value, $24000 = 480$ Hz. AIF-IN.W2 see C0412/x, Wert "11" (Operating Instructions for 8200 vector)	





6.5.3.2 Control word for 8200 vector

Bit	8200vector	
	Default setting: C0001=3 if C0007 < 52	Default setting: C0001=3 if C0007 > 51
00, 01	00 = C0046 active 01 = NSET1-JOG1 (C0037) active 10 = NSET1-JOG2 (C0038) active 11 = NSET1-JOG3 (C0039) active	Freely configurable by user
02	DCTRL1-CW/CCW 0 = not active 1 = active	
03	AIF-CTRL-QSP 0 = not active 1 = active	
04	NSET1-RFG1-STOP 0 = not active 1 = active	Freely configurable by user
05	NSET1-RFG1-0 0 = not active 1 = active	
06	MPOT1-UP 0 = not active 1 = active	
07	MPOT1-DOWN 0 = not active 1 = active	
08	Freely configurable by user	
09	AIF-CTRL-CINH 0 = not active 1 = active	
10	AIF-CTRL-TRIP-SET 0 = not active 1 = active	
11	AIF-CTRL-TRIP-RESET 0 -> 1 = Edge from 0 to 1	
12	DCTRL1-PAR2/4 0 = not active 1 = active	Freely configurable by user
13	DCTRL1-PAR3/4 0 = not active 1 = active	
14	MCTRL1-DCB 0 = not active 1 = active	
15	Freely configurable by user	



Parameter setting





Fig. 6-8 Function block AIF-IN in 8200 vector



6.5.4 Network variable for 93XX controllers

Setpoint source selection

With 93XX controllers it is not possible to select a setpoint source by means of one code only. It is however easy to adapt the controller to the drive task because it is working with preconfigured function blocks which only have to be connected. For this it is not necessary to have special programming skills.

The user himself can link the function blocks. It is however easier to use Lenze preconfigurations which are already stored in the controller ROM. The Lenze preconfigurations (see code C0005) determine the source (terminal, keypad, fieldbus module) which describes the frequency setpoint and the control word.

The value in code C0005 must be set to "xxx3" for LON bus operation (x = selected preconfiguration).

For more information please see the corresponding Manual and Operating Instructions for the controller.

With the 93XX controller the process data assignment can be changed by reconfiguring the function blocks AIF-IN and AIF-OUT.

Network variable from drive

- `nvoAIFStatus` = STAT.B0 ... STAT.B15 (status word)

Status word	
LOW byte	HIGH byte
Bits 0 to 7 of the status word will be entered here.	Bits 8 to 15 of the status word will be entered here (see chapter 6.5.4.1). The description of the bits can be obtained from the Code Table.


- `nvoAifOut1` = AIF-OUT.W1
- `nvoAifOut2` = AIF-OUT.W2
- `nvoAifOut3` = AIF-OUT.W3

AIF-OUT.Wx	
LOW byte	HIGH byte
The actual frequency value with the signed normalisation 24000 = 480 Hz is provided here.	

AIF-OUT.W1 to AIF-OUT.W3 depend on the signal configuration selected under L-C0005. For detailed description of the 93XX signal configuration see the Operating Instructions for 93XX (only the main configurations: 1000, 4000, 5000, etc.) or the Manual 93XX.

In the controller, other signals can be assigned to AIF-OUT.W1 to AIF-OUT.W3. For this, the function-block configuration - described in the Manual 93XX - is used.


The function block AIF-OUT determines the controller output data as data interface for the 2141 fieldbus module.



Parameter setting


Signal configuration (L-C0005)		AIF-OUT.W1	AIF-OUT.W2	AIF-OUT.W3	AIF-OUT.D1
Speed control	1003/1013/1113	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-MSET2 Torque display 100 % = 16383	MCTRL-NSET2 Speed controller input 100 % = 16383	not assigned
Torque control	4003/4013/4113	MCTRL-MSET2 Torque display 100 % = 16383	MCTRL-NACT Act. speed in % 100 % = 16383	MCTRL-NSET2 Speed controller input 100 % = 16383	
DF master	5003/5013/5113	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-MSET2 Torque display 100 % = 16383	MCTRL-NSET2 Speed controller input 100 % = 16383	
DF-slave bus	6003/6013/6113	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-PHI-ACT Actual phase	MCTRL-MSET2 Torque setpoint in % 100 % = 16383	
DF-slave cascade	7003/7013/7113	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-PHI-ACT Actual phase	MCTRL-MSET2 Torque setpoint in % 100 % = 16383	
Cam profiler	1xx3	MCTRL-NACT Actual speed 100 % = 16383	not assigned	not assigned	
Positioning	2xx3	MCTRL-NACT Actual speed 100 % = 16383	not assigned	not assigned	
vector control	1xx3/4xx3/5xx3/ 10xx3	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-IACT	MCTRL-NSET2 Speed controller input 100 % = 16383	
vector control	6xx3/7xx3/8xx3/ 9xx3	MCTRL-NACT Actual speed 100 % = 16383	MCTRL-PHI-ANA	MCTRL-MSET2 Torque setpoint in % 100 % = 16383	
vector control	110x3	not assigned	not assigned	not assigned	

For more detailed information about the function block AIF-OUT see the Manual 93XX.




6.5.4.1 Status word for 93XX

9300	Servo				Servo positioning controller	Servo cam profiler	vector		
C0005	1xx3	4xx3	5xx3	6xx3,7xx3	2xxx3	1xxx3	xxx, 2xxx, 3xxx, 5xxx, 10xxx, 11xxx	4xxx	6xxx, 7xxx, 8xxx, 9xxx
0	DCTRL-PAR1-0	DCTRL-PAR1-0	DCTRL-PAR1-0	DCTRL-PAR1-0	not assigned	CERR1-ERR	DCTRL-PAR1-0	DCTRL-PAR1-0	DCTRL-PAR1-0
1	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP	DCTRL-IMP
2	MCTRL-IMAX	MCTRL-IMAX	REF-OK	REF-OK	POS-REF-OK	MCTRL-IMAX	MCTRL-IMAX	MCTRL-IMAX	MCTRL-IMAX
3	MCTRL-MMAX	not assigned	MCTRL-MMAX	not assigned	not assigned	MCTRL-MMAX	MCTRL-MMAX	MCTRL-IMAX negated	MCTRL-MMAX
4	NSET-RFG-I=0	MCTRL-IMAX negated	NSET-RFG-I=0	MCTRL-IMAX negated	MCTRL-MMAX negated	DCTRL-TRIP	NSET-RFG-I=0	NSET-RFG-I=0	NSET-QSP-OUT
5	QMIN	QMIN	REF-BUSY	REF-BUSY	POS-IN-TARGET	CDATA-X0	QMIN	QMIN	QMIN
6	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0	DCTRL-NACT=0
7	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH	DCTRL-CINH
8 ... 11	Controller status: 0 = Unit initialisation 1 = Switch-on inhibit 3 = Operation inhibited 4 = Flying-restart circuit active 5 = DC injection braking active 6 = Operation enabled 7 = Message active 8 = Fault active 10 = Fail-QSP (only 9300 servo positioning controller)								
12	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN	DCTRL-WARN
13	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS	DCTRL-MESS
14	DCTRL-CW/CCW	DCTRL-CW/CCW	DCTRL-CW/CCW	not assigned	DCTRL-AIFL-QSP	DCTRL-CW/CCW	DCTRL-CW/CCW	DCTRL-CW/CCW	DCTRL-CW/CCW
15	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY	DCTRL-RDY



Parameter setting




2111BU002

Fig. 6-9

Function block AIF-OUT and AIF-OUT*)

AIF-OUT*) is available for the 9300 technology variants: servo, positioning controller and cam profiler as of software version 2.0 . AIF-OUT.D2 is new.



Network variable to drive

The function block AIF-IN determines the input data of the controller as data interface for the 2141 fieldbus module. For more detailed information about the function block AIF-IN, see the Manual 93XX.

AIF-IN.W1 to AIF-IN.W3 depend on the signal configuration selected under C0005.

Speed setpoint: 100 % = 16383


- `nviAIFStw` = AIF-CTRL.B0 ... AIF-CTRL.B15 (control word)

Control word	
LOW byte	HIGH byte
Bits 0 to 7 of the control word will be entered here.	Bits 8 to 15 of the control word will be entered here (see chapter 6.5.4.2) The description of the bits can be obtained from the Code Table.

- `nviAIFIn1` = AIF-IN.W1
- `nviAIFIn2` = AIF-IN.W2
- `nviAIFIn3` = AIF-IN.W3

AIF-IN.Wx	
LOW byte	HIGH byte

Signal configuration (L-C0005)		AIF-IN.W1	AIF-IN.W2	AIF-IN.W3	AIF-IN.D1
Speed control	1003 / 1013 / 1113	NSET-N Speed setpoint 100 % = 16383	not assigned	not assigned	not assigned
Torque control	4003 / 4013 / 4113	MCTRL-MADD Torque setpoint 100 % = 16383			
DF master	5003 / 5013 / 5113	NSET-N Speed setpoint 100 % = 16383			
DF-slave bus	6003 / 6013 / 6113	DFSET-A-TRIM Phase trimming	DFSET-N-TRIM Speed trimming		
DF-slave cascade	7003 / 7013 / 7113	DFSET-VP-DIV DF factor	DFSET-A-TRIM Phase trimming		
Cam profiler	1xx3	NSET1-FACT	not assigned		
Positioning	2xx3	not assigned			
vector control	1xx3 / 2xx3 / 3xx3 / 5xx3 / 100x3	NLIM-IN1			
vector control	4xx3	NCTRL-MADD			
vector control	6xx3	DFSET-A-TRIM	DFSET-N-TRIM		
vector control	7xx3 / 8xx3 / 9xx3	DFSET-VP-DIV	DFSET-A-TRIM		
vector control	100x3	NLIM-IN1	not assigned		
vector control	110x3	not assigned			



Parameter setting

6.5.4.2 Control word for 93XX

9300	9300 Servo				9300 Positioning controller	9300 Cam profiler	9300 Vector		
C0005	1xx3	4xx3	5xx3	6xx3,7xx3	2xxx3	xxx3	1xxx, 2xxx, 3xxx, 5xxx, 10xxx, 11xxx	4xx3	6xx3,7xx3
0	NSET-JOG*1	not assigned	NSET-JOG*1	not assigned	not assigned	CSEL1-CAM*1	NSET-JOG*1	not assigned	not assigned
1	NSET-JOG*2	not assigned	NSET-JOG*2	not assigned	not assigned	CSEL1-CAM*2	NSET-JOG*2	not assigned	not assigned
2	NSET-N-INV	NSET-N-INV	NSET-N-INV	NSET-N-INV	not assigned	CSEL1-CAM*4	NSET-N-INV	not assigned	not assigned
3	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP	AIF-CTRL.QSP
4	NSET-RFG-STOP	NSET-RFG-STOP	NSET-RFG-STOP	NSET-RFG-STOP	POS-PRG-START	CSEL1-EVENT	NSET-RFG-STOP	NSET-RFG-STOP	not assigned
5	NSET-RFG-0	NSET-RFG-0	NSET-RFG-0	NSET-RFG-0	POS-PRG-STOP	CDA-CYCLE	NSET-RFG-0	NSET-RFG-0	not assigned
6	not assigned	not assigned	not assigned	not assigned	not assigned	CSEL1-LOAD	not assigned	not assigned	not assigned
7	not assigned	not assigned	not assigned	not assigned	POS-PRG-RESET	CSEL1-LOAD	not assigned	not assigned	not assigned
8	not assigned	not assigned	not assigned	not assigned	not assigned	not assigned	not assigned	not assigned	not assigned
9	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH	AIF-CTRL.CINH
10	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET	AIF-CTRL.TRIP-SET
11	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET	AIF-CTRL.TRIP-RESET
12	DCTRL-PAR*1	DCTRL-PAR*1	DCTRL-PAR*1	DCTRL-PAR*1	POS-PS-CANCEL	not assigned	DCTRL-PAR*1	DCTRL-PAR*1	DCTRL-PAR*1
13	DCTRL-PAR-LOAD	DCTRL-PAR-LOAD	DCTRL-PAR-LOAD	DCTRL-PAR-LOAD	POS-PARAM-RD	not assigned	DCTRL-PAR-LOAD	DCTRL-PAR-LOAD	DCTRL-PAR-LOAD
14	NSET-Ti*1	NSET-JOG*1	REF-ON	REF-ON	POS-LOOP-ONH	not assigned	NSET-Ti*1	NSET-JOG*1	not assigned
15	NSET-Ti*2	NSET-JOG*2	NSET-Ti*1	not assigned	POS-STBY-STP	not assigned	NSET-Ti*2	NSET-JOG*2	not assigned



Tip!

The single bit control commands of the control word depend on other bit positions.






Fig. 6-10

Function block AIF-IN and AIF-IN^{*}

AIF-IN^{*} is available for the 9300 technology variants: servo, positioning controller and cam profiler as of software version 2.0 . AIF-IN.D2 is new.



Parameter setting

6.5.5 Network variable for 9300 Servo PLC and Drive PLC

Setpoint source selection

Communication via an AIF fieldbus module (e.g. 2141 LON) requires that AIF-IN 1 ... 3 or AIF-OUT ... 3 and if available the AIF management are part of the control configuration of the IEC1131 project.

Process data telegram from drive

Following data can be assigned to PI data:

Name/variable name	Explanation
Device status word (AIF1_DctrlStat)	
AIF_nOutW1_a	AIF word 1
AIF_nOutW2_a	AIF word 2
AIF_nOutW3_a	AIF word 3
AIF2_nOutW1_a	AIF word 4
AIF2_nOutW2_a	AIF word 5
AIF2_nOutW3_a	AIF word 6
AIF2_nOutW4_a	AIF word 7
AIF3_nOutW1_a	AIF word 8
AIF3_nOutW2_a	AIF word 9
AIF3_nOutW3_a	AIF word 10
AIF3_nOutW4_a	AIF word 11
AIF1_dnOutD1_p	AIF double word 1



Tip!

9300 Servo PLC

Link the following in the PLC program of the controller:

AIF1_wDctrlCtrl → DCTRL_wAIF1Ctrl

DCTRL_wStat → AIF1_wDctrlStat

Drive PLC

It is absolutely necessary to use the device control for the Drive PLC.






Fig. 6-11 Function blocks AIF-OUT1, AIF-OUT2 and AIF-OUT3



Parameter setting

Process data telegram to drive

Following data can be assigned to PO data:

Name/variable name	Explanation
Control word (AIF1_wDctrlCtrl)	
AIF1_nlnW1_a	AIF word 1
AIF1_nlnW2_a	AIF word 2
AIF1_nlnW3_a	AIF word 3
AIF2_nlnW1_a	AIF word 4
AIF2_nlnW2_a	AIF word 5
AIF2_nlnW3_a	AIF word 6
AIF2_nlnW4_a	AIF word 7
AIF3_nlnW1_a	AIF word 8
AIF3_nlnW2_a	AIF word 9
AIF3_nlnW3_a	AIF word 10
AIF3_nlnW4_a	AIF word 11
AIF1_dlnD1_p	AIF double word 1



Tip!

9300 Servo PLC

Link the following in the PLC program of the controller:

AIF1_wDctrlCtrl → DCTRL_wAIF1Ctrl

DCTRL_wStat → AIF1_wDctrlStat

Drive PLC

It is absolutely necessary to use the device control for the Drive PLC.






Fig. 6-12 Function blocks AIF-IN1, AIF-IN2 and AIF-IN3



Parameter setting



7 Troubleshooting and fault elimination

7.1 No communication with the controller.


Possible causes	Diagnostics	Remedy
Is the controller switched on?	One of the LED for the operating status must be on. 4-1 .	Controller supply (see Operating Instructions for controller)
Is the fieldbus module supplied with voltage?	The green bus LED on the fieldbus module must be 4-1 on or blinking	With internal supply, check the connection to the controller. With external supply, check the corresponding terminals for a 24-V voltage: A voltage of 24 V $\pm$ 10 % must be applied. The fieldbus module has not been initialised with the controller yet. Possibility 1: Controller not switched on Possibility 2: Check controller connection
Does the controller receive telegrams?	The yellow bus LED on the fieldbus module 4-1 must be blinking when a telegram is received correctly. For testing, send telegrams cyclically from the master.	Check the wiring. Check whether host sends telegrams and uses the appropriate interface. The LON address can be set differently for controller and host. Ensure that the addresses are identical. The addresses for all connected controllers must be unambiguous. If necessary, correct addresses. Check wiring to the host.

7.2 Controller does not execute write job

Possible causes	Diagnostics	Remedy
Does the controller send a negative acknowledgement?		Operating mode L-C0001: The operating mode C0001 does not match when L-C046 or L-C0135 are being addressed. Set L-C0001 = 3. Please see the corresponding information given in chapter "Parameter setting", 6-1 This parameter can only be read. See the corresponding Operating Instructions.
Does the controller send a positive acknowledgement?	ACK response from the controller.	82XX parameters can only be changed when the controller is inhibited. Please see the corresponding information given in chapter "Parameter setting", 6-1 The controller uses a different parameter set. The parameter change will become active after the parameter set has been changed.



Troubleshooting and fault elimination



8 Appendix

8.1 Starting Global Drive Control (GDC) from LONMaker™

Global Drive Control (GDC) can be directly started from LONMaker™ for Windows® by means of a plug-in.

Software requirements:

- LONMaker™ for Windows® as of version 3.00.66
- “Global Drive Control easy” or “Global Drive Control, both as of version 4.4


8.1.1 Installation instructions for the plug-In

1. Copy the files “LONMaker2GDC.exe” and “GDCWrapper.exe” from the floppy (included in the delivery package) to the harddisk.
2. Register these files in the system
 - using the following commands under DOS for Windows®
 - **LONMaker2GDC.exe /regserver**
 - **GDCWrapper.exe /regplugin**
 - As alternative, the “GDCWrapper” can also be opened in Windows (e.g. double click the file ‘GDCWrapper.exe’ in the Windows Explorer). The following dialog box comes up:




2141LON005

3. Copy the file “2141.XIF” to the directory “...\Lonworks\Import”.
4. Registration of the plug-In in LONMaker™ for Windows®.



2141LON006




Appendix

8.1.2 Open GDC from the LONMaker™

Global Drive Control (GDC) is automatically opened through the installed plug-in if you select the following from the shown context menu (right mouse key in the working area of LONMaker™):


- Start GDC directly under **Configure...**



2141LON007


- or start GDC indirectly through **Plug-Ins....**

Activate the 'GDCWrapper' in the selection box that will open.



2141LON008

Go to GDC and press the function key F2 (*Find drive*) to set the parameters for the drive. An online connection with the connected controller is necessary.



8.2 Configuration of the LON network


The LONMaker™ for Windows® helps to configure your drive. We use the software version 3.00.66 of LONMaker™ for Windows® which is only available in English at the time of this print.

The windows can be installed under Windows95®, Windows98® or WindowsNT®. The configuration is explained by examples but only as much as needed for the operation of Lenze controllers.

8.2.1 Configuration of the LON network


1. Insert new device connected to the network

Click the symbol “Device” and **A** shift it to where you need it.



2141LON105

2. Go to the dialog box *Device Name* and enter the name of the device. Highlight the function *Commission Device*.



2141LON106


3. Assignment of interface specification of the connected device

After the device name has been entered (see figure above), it must be linked with the device connected to the network.



Tip!

This link is necessary no matter whether you want to use a different device later or load a new application to the device.



Appendix

The specification can be made online and offline.

- OFFLINE ("Load XIF", **A**): The specification is read from the file 2141.XIF.
- ONLINE ("Upload from Device", **B**): The specification is read from the module. Please see steps 4. and 5.

A

Specify Device Template

Device Name:

External Interface Definition

☐ Upload From Device

☒ Load XIF File:

Template Name:

☐ Existing Template Name:

B

Specify Device Template

Device Name:

External Interface Definition

☒ Upload From Device

☐ Load XIF File:

Template Name:

☐ Existing Template Name:

2141LON107

4. Select the function *Auto-Detect* (only possible with online connection)

Specify Device Channel

Device Name:

☒ Auto-Detect

☐ Specify

Channel

Xcvt Type:

Name:

Please press the service pin on device 'Device 1'...

Options

☒ Display data from service pin

☐ Filter on program ID


☐ Filter on channel

Total Received

2141LON108/111

5. Press the Service key **F** at the front of the 2141 fieldbus module.


All configuration features of the device are automatically loaded by using the service PIN.



8.2.2 Working with network variables

Insertion of function blocks

Click the “Functional Block” symbol and **A** shift it to where you need it.



2141LON114

New Functional Block Wizard

Select Device and Functional Block Instance

Source FB Name:

FB Type:

Subsystem

Name:

Device

Type:

Name:


Functional Block

Type: ID:

Name:

< Zurück Weiter > Abbrechen Hilfe


2141LON116



Appendix


Insertion of network variables

Click *Input Network Variable* and shift it to the function block ("Func Block 1").




2141LON120

Highlight the network variables needed at the input.




2141LON123

Repeat the same procedure for the output variables. The function block will be represented as follows:




Func Block 1



2141LON122

Editing network variables with a browser




Subsystem 1	Device 1	Func Block 1	Variable Name
Subsystem 1	Device 1	Func Block 1	nviAIFStw
Subsystem 1	Device 1	Func Block 1	nviDrvSpeedScale
Subsystem 1	Device 1	Func Block 1	nviDrvSpeedStpt
Subsystem 1	Device 1	Func Block 1	nviParamReq
Subsystem 1	Device 1	Func Block 1	nvoAIFOut1
Subsystem 1	Device 1	Func Block 1	nvoAIFOut2
Subsystem 1	Device 1	Func Block 1	nvoAIFOut3
Subsystem 1	Device 1	Func Block 1	nvoAIFStatus
Subsystem 1	Device 1	Func Block 1	nvoDriveCurrt
Subsystem 1	Device 1	Func Block 1	nvoDriveSpeed
Subsystem 1	Device 1	Func Block 1	nvoDrvRunHours
Subsystem 1	Device 1	Func Block 1	nvoDrvVolt
Subsystem 1	Device 1	Func Block 1	nvoLongRes
Subsystem 1	Device 1	Func Block 1	nvoParamRes


2141LON141/125

Change of variable format

Subsystem 1	Device 1	Func Block 1	Variable Name
Subsystem 1	Device 1	Func Block 1	nviAIFIn3
Subsystem 1	Device 1	Func Block 1	nviAIFStw
Subsystem 1	Device 1	Func Block 1	nviDrvSpeedScale
Subsystem 1	Device 1	Func Block 1	nviDrvSpeedStpt
Subsystem 1	Device 1	Func Block 1	nviParamReq
Subsystem 1	Device 1	Func Block 1	nvoAIFOut1
Subsystem 1	Device 1	Func Block 1	nvoAIFOut2
Subsystem 1	Device 1	Func Block 1	nvoAIFOut3
Subsystem 1	Device 1	Func Block 1	nvoAIFStatus
Subsystem 1	Device 1	Func Block 1	nvoDriveCurrt
Subsystem 1	Device 1	Func Block 1	nvoDriveSpeed
Subsystem 1	Device 1	Func Block 1	nvoDrvRunHours
Subsystem 1	Device 1	Func Block 1	nvoDrvVolt
Subsystem 1	Device 1	Func Block 1	nvoLongRes
Subsystem 1	Device 1	Func Block 1	nvoParamRes



2141LON142/143



Appendix

8.2.3 Registration of new data types

If you use these files, you will get more information and have higher configuration friendliness for the LON network with LONMaker™ for Windows®.

Copy files to hard disk.

Dateiname	Größe	Typ
2141.eng	2 KB	Datei ENG
2141.enu	2 KB	Datei ENU
2141.fmt	1 KB	Datei FMT
2141.fpt	1 KB	Datei FPT
2141.ls	1 KB	Datei LS
2141.typ	3 KB	Datei TYP


2141LON150

Start “LNS Resource File Catalog Utility“


2141LON151/152

Select Resource File Catalog directory

2141LON153/154



Add new type directory



Catalog Information

Catalog Path:

Number of Directories: Number of Files:

Catalog Status:

Directories Lang Files Type Files FPT Files Format Files


Directory # 1 of 3:

2141LON155/154

Click the buttons “Add a new directory” and “Refresh Now”.

8.3 List of abbreviations

Abbreviation	Meaning
AIF	Automation Interface; interface between controller and automation or fieldbus modules. It also includes defined process data.
EMC	Electromagnetic Compatibility
DCB	DC-injection brake
hex	Display of values in the hexadecimal character format (0, ..., 9, A, B, ..., F).
RFG	Ramp-function generator; setpoint integrator
Imax	Current limit
IMP	Pulse inhibit
JOG	Fixed speed or input for activation of the fixed speed
CRL	Communication reference list
LSB	Least Significant Bit; low-weighting bits of a binary value
Max-PDU	Maximum Process Data Unit
MSB	Most Significant Bit; high-weighting bits of a binary value
PO-data	Process-output data
PC	Personal Computer
PI-data	Process-input data
PE	Protective earth
PCD	Process data,
QSP	Quick stop
Ctrl. enable	Controller enable
RS232	Interface standard
RS485	Interface standard with difference signals
Ctrl. inhibit	Controller inhibit
TRIP	Operation fault
Vcc	Controlled constant voltage supply




Appendix

8.4 Glossary

Technical term	Meaning
Controller	General term for servo drives, frequency inverters and DC drives
Baud rate	Transmission speed of data in bit/s
Bus terminal	Network node between long-distance and peripheral bus
Bus devices	Unit which communicates with the host via the bus
code	For input and display (access) of parameter values.
Code number/code	Clear labelling of a parameter, e.g. C0106. For calculation information see Lenze code addressing in chapter „Parameter setting“.
Fieldbus	For the exchange of data between higher-level controls (hosts) and positioning controls (e. g. controllers).
FTT	Free Topology Transceiver.
Handshake	Stipulated data-transfer method (here implemented by software).
Host	PC or PLC
Master	see host/host system
LON	Logical Operating Network
Network topology	Design and structure of a network: e.g. point-to-point network, line network, ring network)
Parameters	Adjustable controller variables and values addressable via codes
Peripheral-bus module	Bus participant in the peripheral bus
Peripheral-bus station	Consists of bus terminal, peripheral-bus module and long-distance bus controller.
Icon	Sign or symbol with an unambiguous message.
Process data,	Small amounts of data for fast and cyclic transmission; e.g. setpoints and actual values
Process-data channel (PCD channel)	Communication channel for fast and cyclic transmission of process data
Acknowledgement	Acknowledgement of a setting or change (e. g. of parameters))
Slave	Bus participant which is only allowed to transmit data after a request by a master. For instance, controllers are slaves. (See Host/host system)
Application	as directed: Appropriate use of the machine according to the manufacturer's information or to common use because of its design and function. inappropriate The use of the machine which does not comply with the manufacturer's declaration.
Cycle time	The cycle time of the communication system is the time required for the exchange of all process data between the host and the field units (e.g. controllers).

8.5 More information sources

No.	Titel	Published by
1	Engineering Bulletin 170, LonTalk Response Time Measurements	Echelon Corporation
2	LonMark [®] Functional Profile: Variable Speed Motor Drive	LONMARK Interoperability Association
3	LonWorks [®] FTT-10A Free Topology Transceiver User's Guide	Echelon Corporation
4	LonMaker [™] for Windows [®] User's Guide	Echelon Corporation



8.6 Table of keywords

A


Acceleration time, 6-19
Actual speed value, 6-6
AIF-CTRL, Device control, 6-2, 6-24
AIF-IN, Function block, 6-41
AIF-OUT, Function block, 6-38
Appendix, 8-1
Application as directed, 1-2
Application conditions, 3-1

B

Basic insulation, 4-4

C

Commissioning, 5-1
Communication interference, 4-4
Communication medium, 3-2
Communication times, 3-3
Configuration variable
 Acceleration time, 6-19
 Deceleration time, 6-20
 Description, 6-11
 Location label, 6-11
 Maximum Send Time, 6-13
 Maximum speed, 6-15
 Minimum Send Time, 6-14
 Minimum speed, 6-16
 Overview, 6-3
 Rated frequency, 6-18
 Rated speed value, 6-17
 Receive heartbeat for manufacturer-specific network variables, 6-21
 Receive Heartbeat Time, 6-12
Connection
 External supply, 4-2
 Plug connector (2-pole), 4-2
Connection terminals, 4-2
Connector plug, LON bus, 4-2
Control word
 8200 vector, 6-30, 6-33
 82XX, 6-26, 6-29
 93XX, 6-37, 6-40
Controller
 Application as directed, 1-2
 Labelling, 1-2
Controller configuration, 5-2



Appendix

D

Data types, Registration, 8-8
Deceleration time, 6-20
Definitions, 1-1
Description, Configuration variable VSD, 6-11
Device control
 AIF-CTRL, 6-24
 Monitoring reaction, 6-22
 VSD, 6-5
Dimensions, 3-2
Disposal, 1-2

E

Electrical data. *Siehe* Ratings

F

Fault elimination, 7-1
Fieldbus module, Order name, 3-1
First switch-on, 5-1
Frequency setpoint
 8200 vector, 6-30
 82XX, 6-26
Front view of the fieldbus module, 4-1
FTT, 3-2
Function module PROFIBUS-DP
 Lenze parameters, 6-4
 Parameters, Transmission, 6-1
 Process data,, Transmission, 6-1

G

GDCWrapper.exe, 8-1
Glossary, 8-10
 Siehe auch Glossary

I

Installation
 Electrical, 4-4
 Mechanical, 4-3
 Wiring to a host, 4-4

L


Labelling, Controller, 1-2
Legal regulations, 1-2
Lenze parameter sets, 6-2
Lenze parameters, Function module PROFIBUS-DP, 6-4
Liability, 1-2
List
 Abbreviations, 8-9
 Technical term. *Siehe* Glossary
List of abbreviations, 8-9
Location label, 6-11
LON network, Configuration, 8-3
LONMaker, Automatic GDC start, 8-1
LONMaker2GDC.exe, 8-1

M

Mains isolation, 4-4
Manufacturer, 1-2
Maximum Send Time, 6-13
Maximum speed, 6-15
Minimum Send Time, 6-14
Minimum speed, 6-16
Monitoring reaction, AIF-CTRL, 6-22
Motor current, 6-8
Motor voltage, 6-9

N

Network variable, 8-5
 AIF-CTRL
 8200 vector, 6-30
 82XX, 6-26
 9300 Servo PLC, 6-42
 93XX, 6-35
 Drive PLC, 6-42
 Input variables, 6-25
 Output variables, 6-24
 Overview, 6-2
 VSD
 Actual speed value, 6-6
 Motor current, 6-8
 Motor voltage, 6-9
 Operating time, 6-10
 Scaling of the speed setpoint, 6-7
 Speed setpoint, 6-5
Node Object, 6-1
Number of devices connected to the bus, 3-3



O

Operating time, 6-10

Operator, 2-1

Overview

Configuration variable, 6-1, 6-3

Network variable, 6-1
AIF-CTRL, 6-2
VSD, 6-2

Node Object, 6-1

P

Parameter data channel, configuration, 6-2

Parameter sets, 6-2

Parameter setting, 6-1

Parameters

Control word (C0135)
8200 vector, 6-30
82XX, 6-26

Frequency setpoint (C0046)
8200 vector, 6-30
82XX, 6-26

L-C0142, 5-2

PE shield cable, 4-4

Personnel, Qualified, 2-1

Processing time in the basic unit, 3-3

R

Rated frequency, 6-18

Rated speed value, 6-17

Ratings, 3-2

Receive Heartbeat Time, 6-12

Registration, of data types, 8-8

S

Safety information, 2-1

Layout, 2-2
Other notes, 2-2
Warning of material damage, 2-2
Warning of personal damage, 2-2

Safety information, Operating Instructions, 1-1

Scaling of the speed setpoint, 6-7

Scope of supply, 1-1

Service key, 4-1

Service LED, 4-1

Speed

Maximum, 6-15
Minimum, 6-16

Speed setpoint, 6-5

Scaling, 6-7

Starting GDC, from LONMaker, 8-1

Status word, 82XX, 6-27

Switch-on sequence, First switch-on, 5-1

T

Technical data, 3-1

Technical data

Communication times, 3-3
Dimensions, 3-2
Features of the fieldbus module, 3-1
General data/Application conditions, 3-1
Ratings, 3-2

Troubleshooting, 7-1

U

Use, as directed, 1-2

V

Voltage supply, 4-5

Voltage supply, external, 4-2


VSD, Device control, 6-2, 6-5

W

Warranty, 1-2

Wiring, to a host, 4-4

Write parameter (example), 6-6



Appendix