SINAMICS G120

Control Units	CU240E	CU240S
	CU240S DP	CU240S DP-F
	CU240S PN	CU240S PN-F

Operating Instructions · 03/2009

SINAMICS

Answers for industry.



SIEMENS

SINAMICS

SINAMICS G120 CU240S and CU240E Control Units, FW 3.2

Operating Instructions

Introduction	1
Description	2
Connection	3
Commissioning	4
Functions	5
Servicing and maintenance	6
Messages and fault codes	7
Technical data	8
i cominical uala	

Edition 03/2009, FW 3.2

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

indicates that death or severe personal injury will result if proper precautions are not taken.

indicates that death or severe personal injury **may** result if proper precautions are not taken.

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

CAUTION

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

NOTICE

indicates that an unintended result or situation can occur if the corresponding information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The device/system may only be set up and used in conjunction with this documentation. Commissioning and operation of a device/system may only be performed by **qualified personnel**. Within the context of the safety notes in this documentation qualified persons are defined as persons who are authorized to commission, ground and label devices, systems and circuits in accordance with established safety practices and standards.

Proper use of Siemens products

Note the following:

/!\WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be adhered to. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of the Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Siemens AG Industry Sector Postfach 48 48 90026 NÜRNBERG GERMANY A5E02440075B AA @ 03/2009

Table of contents

1	Introdu	ction	9
	1.1	About this manual	9
	1.2	Fast track commissioning	10
	1.3 1.3.1 1.3.2 1.3.3	Adapting inverters to the application (parameterization for entry level personnel) General basics Parameter Parameters with follow-on parameterization	11 12
	1.4	Frequently required parameters	14
	1.5 1.5.1 1.5.2	Extended adaptation options (parameterization for advanced level personnel) BICO technology: basic principles BICO technology: example	16
2	Descrip	tion	21
	2.1	Modularity of the converter system	21
	2.2	Overview of Control Units	23
	2.3	Overview of Power Modules	24
	2.4	Reactors and filters	25
3	Connec	tion	27
	3.1	Procedure for installing the frequency inverter	27
	3.2	Mounting reactors and filters	28
	3.3 3.3.1 3.3.2 3.3.3	Mounting Power Modules Dimensions, hole drilling templates, minimum clearances, tightening torques Wiring Power Modules EMC-compliant connection	31 36
	3.4 3.4.1	Installing the Control Unit Interfaces, connectors, switches, control terminals, LEDs on the CU	
4	Commi	ssioning	45
	4.1	Initial coupling of the CU and PM - message F0395	46
	4.2	Restoring the factory settings	47
	4.3	Preparing commissioning	48
	4.4 4.4.1 4.4.2 4.4.3	Commissioning with factory settings Wiring examples for the factory settings Factory setting of the frequency inverter Default terminal settings	52 54
	4.5 4.5.1 4.5.2 4.5.3 4.5.4	Commissioning with STARTER Creating a STARTER project. Establishing an online connection between the PC and converter (going "online") Starting the general commissioning. Commissioning the application	59 64 65

4.6 4.6.1 4.6.2 4.6.3	Commissioning with the operator panel Function of the Basic Operator Panel BOP controls and displays Parameterization with the BOP (two examples)	71
4.6.4 4.6.5	Commissioning steps Commissioning V/f control	74
4.7 4.7.1 4.7.2	Data backup with the operator panel and memory card Saving and transferring data using the BOP Saving and transferring data using the MMC	
5 Funct	ions	
5.1	Overview of inverter functions	
5.2 5.2.1 5.2.2	Inverter control Frequency inverter control using digital inputs (two/three-wire control) Two-wire control, method 1	84
5.2.3 5.2.4 5.2.5 5.2.6	Two-wire control, method 2 Two-wire control, method 3 Three-wire control, method 1 Three-wire control, method 2	
5.3 5.3.1 5.3.2 5.3.3	Command sources Selecting command sources Assigning functions to digital inputs Controlling the motor via the fieldbus	
5.4 5.4.1 5.4.2 5.4.3 5.4.4 5.4.5 5.4.6	Setpoint sources Selecting frequency setpoint sources Using analog inputs as a setpoint source Using a motorized potentiometer as a setpoint source Using the fixed frequency as a setpoint source Running the motor in jog mode (JOG function) Specifying the motor speed via the fieldbus	96 96 97 99 100 101
5.5	Changing over the command data sets (manual, automatic)	103
5.6 5.6.1 5.6.2	Setpoint preparation Minimum frequency and maximum frequency Parameterizing the ramp-function generator	106
5.7 5.7.1 5.7.1. 5.7.1. 5.7.1. 5.7.1. 5.7.2 5.7.2. 5.7.2. 5.7.2. 5.7.2.	 2 V/f control with linear characteristic 3 V/f control with parabolic characteristic. 4 Additional characteristics for the V/f control. Vector control	109 109 110 111 111 111 112 112 112 113 114
5.8 5.8.1 5.8.2 5.8.3 5.8.4	Protection functions Overtemperature protection for the frequency inverter and motor Overcurrent protection Limiting the maximum DC link voltage Load torque monitoring (system protection)	

5.9	Evaluating the frequency inverter status	
5.9.1	Assigning specific functions to digital outputs	
5.9.2	Assigning certain functions to analog outputs	
5.10	Technological functions	
5.10.1 5.10.1	Braking functions of the frequency inverter	
	2 Dynamic braking	
	3 Regenerative braking	
	4 Parameterizing a motor holding brake	
5.10.2	Automatic restart and flying restart	
	1 Flying restart: switching on the converter when the motor is running	
5.10.2 5.10.3	2 "Automatic restart" function after power failure Technology controller	
5.10.3	Positioning down ramp	
5.10.5	Logical and arithmetic functions using function blocks	
5.10.6	Changing over drive data sets (several motors connected to a frequency inverter)	
5.11	Operation in fieldbus systems	151
5.11.1	Communication interfaces	
5.11.2		
	1 User data range of the USS message frame	
5.11.2. 5.11.2	2 Data structure of the USS parameter channel3 Timeouts and other errors	154 160
	4 USS process data channel (PZD)	
	Communication via PROFIBUS and PROFINET.	
5.11.3	1 Connect the frequency inverter to PROFIBUS	161
5.11.3	2 Example for configuring the inverter on PROFIBUS	162
5.11.3	3 Integrating a frequency inverter in PROFINET	172
	4 Example for configuring the inverter on PROFINET5 The PROFIdrive profile	
	6 STEP 7 program examples	
5.12	Safety functions	
5.12.1	Overview	
5.12.2	Connecting-up the fail-safe inputs	
5.12.3	Restoring safety-related parameters to the factory setting	200
5.12.4	Controlling the safety functions via PROFIsafe	
5.12.5	Controlling the safety functions via digital inputs	
5.12.6	Settings for the "STO" function Settings of the SS1, SLS and SBC safety functions	
5.12.7 5.12.8	Acceptance test and report	
	1 Documentation of the acceptance test	
	2 Function check of the acceptance test	
5.12.8	3 Filling in the acceptance report	213
Servici	ng and maintenance	215
6.1	Behavior of the frequency inverter when replacing components	215
6.2	Replacing the Power Module	216
6.3	Replacing the Control Unit	
6.4	Standard commissioning	
Messa	ges and fault codes	
7.1	Status display using LEDs	
7.2	Alarm and error messages	

6

7

8	Technica	al data	227
	8.1	Technical data, CU240S Control Unit	227
	8.2	Technical data, CU240E Control Unit	228
	8.3	General technical data, PM240 Power Modules	229
	8.4	Power-dependent technical data, PM240 Power Modules	230
	8.5	General technical data, PM250 Power Modules	233
	8.6	Power-dependent technical data, PM250 Power Modules	234
	8.7	General technical data, PM260 Power Modules	235
	8.8	Power-dependent technical data, PM260 Power Modules	236
	Index		237

Introduction

1.1 About this manual

Who requires the operating instructions and why?

These operating instructions primarily address fitters, commissioning engineers and machine operators. The operating instructions describe the devices and device components and enable the target groups being addressed to install, connect-up, parameterize, and commission the inverters safely and in the correct manner.

What is described in the operating instructions?

These operating instructions provide a summary of all of the information required to operate the inverter under normal, safe conditions.

The information provided in the operating instructions has been compiled in such a way that it is sufficient for all standard applications and enables drives to be commissioned as efficiently as possible. Where it appears useful, additional information for entry level personnel has been added.

The operating instructions also contain information about special applications. Since it is assumed that readers already have a sound technical knowledge of how to configure and parameterize these applications, the relevant information is summarized accordingly. This relates, e.g. to operation with fieldbus systems and safety-related applications.

Additional information on SINAMICS G120

As download: List Manual (http://support.automation.siemens.com/WW/view/en/32465038) CU240E and CU240S Control Units

Among other things, the List manual includes

- A detailed description of all of the parameters
- Function diagrams of all of the inverter functions
- A list of the fault messages and alarms
- As download: All of the operating instructions, manuals on SINAMICS G120 (http://support.automation.siemens.com/WW/view/en/22339653/133300)
- On DVD: SD Manual Collection all manuals on low-voltage motors, geared motors and low-voltage inverters, 5 languages.
 - MLFB: 6SL3298-0CA00-0MG0 (supplied once)
 - MLFB: 6SL3298-0CA10-0MG0 (update service for 1 year; supplied 4 times)
- As download: Catalog D 11.1: SINAMICS G110 / G120 Inverter Chassis Units SINAMICS G120D Distributed Inverters. (http://sd.nes.siemens.de/sales_2003/support/info/catalogues/html_76/index.html#Catalogs_Inverters)

The catalog includes ordering data as well as engineering and selection data.

1.2 Fast track commissioning

1.2 Fast track commissioning

Procedure when commissioning

- 1. Required components
 - Power Module, Control Unit; optional: Operator panel or PC connection kit
- 2. Installing the inverter -> Chapter 3.3 (Page 30)
 - Installing the Power Modules (minimum clearances, components) -> Chapter 3.3.1 (Page 31)
 - Connecting-up Power Modules (line supply connections, motor circuit (Δ/Y), EMC) -> Chapter 3.3.2 (Page 36) and Chapter 3.3.3 (Page 39)
 - Installing and connecting up the Control Unit (control terminals, user interfaces) -> Chapter 3.4.1 (Page 42)
- 3. Switching-on the line supply voltage and 24 V control voltage
- 4. Preparing commissioning
 - Information and data that you should obtain before commissioning -> Chapter 4.3 (Page 48)
 - If the components are not brand new, but are *used*. Restoring the factory settings -> Chapter 4.2 (Page 47)
- 5. Quick commissioning
 - When using the factory settings -> Chapter 4.4 (Page 51)
 - With STARTER (commissioning tool) -> Chapter 4.5 (Page 58)
 - With BOP (Basic Operator Panel)-> Chapter 4.6 (Page 71)
- 6. Storing data in a power-independent manner -> Chapter 4.7 (Page 77)
- 7. You can now switch-on the motor.

Finely adjusting the inverter

With the commissioning procedure described above, your inverter is supplied with the basic functions and settings that are completely adequate for many applications.

Using the functions and parameters described in Chapter 5 (Page 81), if required, you can precisely adapt this closed-loop control structure of your inverter to your application.

Introduction

1.3 Adapting inverters to the application (parameterization for entry level personnel)

1.3 Adapting inverters to the application (parameterization for entry level personnel)

1.3.1 General basics

Parameterizable inverters transform standard motors into variable-speed drives

Inverters are parameterized to adapt them to the motor being driven so that this can be optimally operated and protected. This is realized using one of the following operator units:

- Keyboard and display unit (Operator Panel) that is snapped onto the inverter.
- Software (STARTER commissioning tool) that allows the inverter to be parameterized and controlled from a PC.

Inverters are especially used to improve and expand the starting and speed response of motors.

Many standard applications can function with the default parameters

Although inverters can be parameterized for very specific applications, many standard applications can be configured by means of just a few parameters.

Use the factory settings (where possible)

For basic applications, commissioning can be carried out using just the factory settings (see Section "Commissioning with factory settings" (Page 51)).

Use quick commissioning (for simple, standard applications)

In the majority of standard applications, commissioning can be carried out by entering or changing just a few parameters during quick commissioning (see Section "Commissioning with Operator Panel" (Page 71)).

1.3 Adapting inverters to the application (parameterization for entry level personnel)

1.3.2 Parameter

Parameter types

There are two types of parameters, adjustable and display parameters.

Adjustable parameters

Adjustable parameters are represented with four digits preceded by the letter "P". You can change the value of these parameters within a defined range.

Example:

P0305 is the parameter for the rated motor current in Amps. This parameter is set during commissioning. You can enter values between 0.01 and 10000.

Display parameters

Display parameters are represented with four digits preceded by the letter "r". You cannot change the value of these parameters.

Example:

r0027 is the parameter for the inverter output current. The inverter measures the current and writes the current value to the parameter. You can display the parameter value, e.g. using an analog output of the inverter.

Change protection for write parameters

The process of changing parameter values is subject to certain conditions. If an attempt to change a parameter is rejected by the inverter, this can have a number of causes:

- 1. The inverter operating state does not allow you to change parameters. For example, certain parameters can only be changed when the inverter is in commissioning mode.
- In some cases, you may not be able to change certain parameters due to automatic follow-on parameterization.
 Example: When P0701 = 1, the ON/OFF1 command is connected to digital input 0. As follow-on parameterization, P0840 (source of the ON/OFF1 command) is assigned value 722.0 (status of digital input 0). which means that P0840 can no longer be changed.
- 3. Parameter protection via P0927 has been activated. Example: P0927 = 1101 prevents parameters from being changed from the BOP.

For each parameter, the List Manual specifies whether and which conditions apply for changing the values.

1.3 Adapting inverters to the application (parameterization for entry level personnel)

1.3.3 Parameters with follow-on parameterization

When you change certain parameters, the system may automatically change other parameters accordingly. This makes it much easier to parameterize complex functions.

Example: Parameter P0700 (command source)

Parameter P0700 can be used to switch the command source from the fieldbus to digital inputs. When the value of P0700 is changed from 6 (command source "fieldbus") to 2 (command source "digital inputs"), other parameter values are changed automatically:

- New functions are assigned to the digital inputs (P0701 ... P0713)
- New functions are assigned to the digital outputs (P0731 ... P0733)
- Inverter control is interconnected with the signals from the digital inputs (P0800, P0801, P0840, etc.)

For more information about follow-on parameterization for P0700, see the List Manual.

1.4 Frequently required parameters

1.4 Frequently required parameters

Parameters that in many cases help

Table 1-1 This is how you filter the parameter list to keep the number of displayed parameters transparent

Parameter	Description
P0003 =	User access level 1: Standard: Allows access to the most frequently used parameters (factory setting) 2: Extended: Extended access, e.g. to inverter I/O functions 3: Expert: To be used by experts
P0004 =	Parameter filter 0: All the parameters are displayed (factory setting). 2: Inverter 3: Motor - data of the motor and output filter are displayed 4: Speed encoder - parameters for the optional speed encoder are displayed

Table 1-2 How to switch to commissioning mode or restore the factory setting

Parameter	Description
P0010 =	Commissioning parameters 0: Ready (factory setting) 1: Perform quick commissioning 30: Factory setting - initiate restore factory settings

Table 1-3 How to determine the firmware version of the Control Unit

Parameter	Description
r0018	The firmware version is displayed:

Table 1-4 This is how you reset the parameters to the factory setting

Parameter	Description
P0010 = 30	30: Factory setting - initiate restore factory settings
P0970 = 1	1: Resetting - restoring all parameters to the factory setting (Exception: Password-protected parameters of the safety functions are not reset!)

Table 1-5 This is how you select the command source of the control signals (ON/OFF, reversing) of the inverter

Parameter	Description
P0700 =	 0: Factory default setting 1: Operator Panel 2: Digital inputs (P0701 P0709); factory setting non-fieldbus-capable inverters 4: USS on RS 232 5: USS on RS 485 (not available for CU240S DP or CU240S DP-F) 6: Fieldbus (P2050 P02091); (factory setting for fieldbus-capable inverters)

1.4 Frequently required parameters

Parameters	Description
P1000 =	 0: No main setpoint 1: MOP setpoint 2: Analog setpoint (factory setting for non-fieldbus-capable inverters) 3: Fixed frequency 4: USS at RS 232 5: USS on RS 485 6: Fieldbus (factory setting for fieldbus-capable inverters) 7: Analog setpoint 2

 Table 1-6
 This is how you select the setpoint source for the frequency

Table 1-7 This is how you parameterize the up and down ramps

Parameters	Description
P1080 =	Minimum frequency 0.00 [Hz] factory setting
P1082 =	Maximum frequency 50.00 [Hz] factory setting
P1120 =	Rampup time 10.00 [s]
P1121 =	Rampdown time 10.00 [s]

Table 1- 8This is how you set the closed-loop type

Parameters	Description
P1300 = 2	Extended access
P1300 =	0: V/f control with linear characteristic (factory setting) 1: V/f control with FCC 2: V/f control with parabolic characteristic 3: V/f control with programmable characteristic
	20: Sensorless vector control 21: Vector control with encoder 22: Torque vector control without encoder

Table 1-9 This is how you optimize the starting behavior of the V/f control for a high break loose torque and overload

Parameters	Description
P0003 = 2	Extended access
P1310 =	Voltage boost to compensate resistive lossesThe voltage boost is effective from standstill up to the rated speed.The voltage boost continually decreases with increasing speed.The maximum voltage boost is effective at speed zero and is in V:Rated motor current (P305) × stator resistance (P350) × P1310 /100.
P1311 =	Voltage when accelerating The voltage boost is effective from standstill up to the rated speed. The voltage boost is independent of the speed. The voltage boost in V is: Rated motor current (P305) × stator resistance (P350) × P1311 /100

1.5 Extended adaptation options (parameterization for advanced level personnel)

1.5.1 BICO technology: basic principles

Functional principle of BICO technology and inverter closed/open-loop control functions

The inverter software offers a range of open/closed-loop control functions, communication functions, as well as various diagnostics and operating functions. These functions are interconnected via internal signal paths and represent the default control structure.



Figure 1-1 Example: Pre-assigned signal interconnection for digital input 0 of a non-bus-capable Control Unit

The functions can be parameterized and interconnected as required. The signal interconnection of the functions is realized, contrary to electric circuitry, not using cables, but in the software. The various functions use a range of inputs, outputs, and parameters.




Figure 1-2 Example: MOP function (motorized potentiometer)

Binectors and connectors

Connectors and binectors are elements used to exchange signals between the individual functions. Connectors and binectors can be seen as "storage compartments":

- Connectors are used to store "analog" signals (e.g. speed setpoint)
- Binectors are used to store "digital" signals (e.g. 'MOP raise' command)

Definition of BICO technology

BICO technology describes the type of parameterization that can be used to disconnect all the internal signal interconnections between the functions or establish new connections. This is realized using **Bi**nectors and **Co**nnectors. Hence the name **BICO** technology. (Binector Connector Technology)

BICO parameters

You can use the BICO parameters to define the sources of the input signals of a function. This means that using BICO parameters you can define from which connectors and binectors a function reads-in its input signals. thereby enabling you to "interconnect" the functions stored in the devices in accordance with your requirements. Four different BICO parameter types are available:

- Binector inputs: BI
- Connector inputs: CI
- Binector outputs: BO
- Connector outputs: CO
- Binector/connector outputs: CO/BO

Binector/connector outputs (CO/BO) are parameters that combine more than one binector output in a single word (e.g. r0052 CO/BO: status word 1). Each bit in the word represents a digital (binary) signal. This feature reduces the number of parameters and makes it easier to set parameters by means of the serial interface (data transfer).

BICO parameters of type CO, BO, or CO/BO can be used more than once.

BICO symbols, representation, and description

Abbreviation and symbol	Description	Function		
BI <u></u>	Binector input	Data flow Pxxxx Function Bl:		
во	Binector output	Data flow rxxxx Function BO:		

Table 1- 10 Binector symbols

Table 1- 11 Connector symbols

Abbreviation and symbol	Description	Function	
CI <u>></u>	Connector input	Data flow Pxxxx Function Cl:	
CO	Connector output	Data flow rxxxx Function CO:	

Abbreviation and symbol	Description	Function
со/во	Binector/connector output	Data flow rxxxx Functions CO/BO:

Table 1- 12	Connector and binector output symbols
-------------	---------------------------------------

When do you need to use BICO technology?

BICO technology allows you to adapt the inverter to a wide range of different requirements. This does not necessarily have to involve highly complex functions.

Example 1: Assign a different function to a digital input.

Example 2: Switch over the speed setpoint from the fixed frequency to the analog input.

What precautions should you take when using BICO technology?

Always apply caution when handling internal interconnections. Note which changes you make as you go along since the process of analyzing them later can be quite difficult.

The STARTER commissioning tool offers various screens that make it much easier for you to use BICO technology. The signals that you can interconnect are displayed in plain text, which means that you do not need any prior knowledge of BICO technology.

What sources of information do you need to help you set parameters using BICO technology?

- This manual is sufficient for simple signal interconnections, e.g. assigning a different significance to the to digital inputs.
- The parameter list in the List Manual is sufficient for signal interconnections that go beyond just simple ones.
- You can also refer to the function diagrams in the List Manual for complex signal interconnections.

1.5.2 BICO technology: example

Example: Shifting a basic PLC functionality into the inverter

A conveyor system is to be configured in such a way that it can only start when two signals are present simultaneously. These could be the following signals, for example:

- The oil pump is running (the required pressure level is not reached, however, until after five seconds)
- The protective door is closed

The task is realized by inserting free blocks between the digital input 0 and the internal ON command for the motor and interconnecting them.




Figure 1-3 Example: Signal interconnection for interlock

Table 1-13	Parameterizing an interlock
------------	-----------------------------

Parameter	Description		
P0003 = 3	Enable expert access to parameters		
P0700 = 2	Select the command source: Digital inputs		
P0701 (e.g.) = 99	Enable/"open" digital input 0 (DI0) for BICO parameterization		
P0702 (e.g.) = 99	Enable/"open" digital input 1 (DI1) for BICO parameterization		
P2800 = 1	Group enable all freely-programmable function blocks (FFB)		
P2801 [In000] = 1	Individual enable of the AND function block		
P2802 [In000] = 1	Individual enable of the TIMER function block		
P2850 = 5.0	Set the TIMER delay time: 5 seconds		
P2849 = r0722.0	Connect the status of DI0 to the TIMER input		
	r0722.0 = Parameter that displays the status of digital input 0.		
P2810 [In000] = r2852	Connect the TIMER output to the 1st input of the AND		
P2810 [In001] = r0722.1	Connect the status of DI1 to the 2nd AND input		
	r0722.1 = Parameter that displays the status of digital input 1.		
P0840 = r2811	Connect the AND output to the control command ON/OFF1		

Introduction

1.5 Extended adaptation options (parameterization for advanced level personnel)

Explanations of the example

Open the default signal interconnection for BICO parameterization

The default setting P0701 = 1 indicates the following internal signal interconnection:




Figure 1-4 Default parameterization

The setting P0701 = 99 means that a pre-assigned signal interconnection is disconnected and therefore the connection opened for BICO parameterization.



Figure 1-5 BICO parameterization

When P0701 = 99, the binector input of the ON/OFF1 function (P0840) is available for activation by a signal source other than r0722.0 (in this case r2852).

DI 0 - [70722.0 - [72849 - [72852 - [7282 - [72852 - [7282 - [7282 - [7282 - [72852 - [72852 - [72852	&		ON/ OFF1
---	---	--	-------------

Figure 1-6 Interconnection after insertion of two functions

Principle of connecting functions by means of BICO technology

A connection between two functions comprises a connector/binector and a BICO parameter. Connections are always established with respect to the input of a particular function, which means that the output of an upstream function must always be assigned to the input of a downstream function. The assignment is always made by entering the number of the connector/binector from which the required input signals are read in a BICO parameter.

With this functional logic in mind, where does the signal come from?

Description

Overview of the SINAMICS G120 family of inverters

Thanks to their modular design, SINAMICS G120 inverters can be used in a wide range of applications with respect to functionality and power.

Each SINAMICS G120 inverter comprises a Control Unit and a Power Module. The power range extends from 0.37 kW to 250 kW.

The Basic Operator Panel (BOP) and the STARTER commissioning tool are available for commissioning.

A range of additional, application-specific components are also available (e.g. filters, reactors, braking resistors).

2.1 Modularity of the converter system

Main components of the inverter

Each SINAMICS G120 inverter comprises a Control Unit and Power Module. In the SINAMICS G120 range, the Control Units can be combined with any Power Module.

- The Control Unit controls and monitors the Power Module and the connected motor in various control modes (which can be selected as required). It supports communication with local or central control as well as with monitoring devices.
- The Power Modules are available for motors with a power range of between 0.37 kW and 250 kW. IGBT technology and pulse-width modulation are used to ensure reliable and flexible motor operation.



Power Module Control Unit 2.1 Modularity of the converter system

Supplementary components

In addition to the main components, the following components are available for commissioning and parameterization:

	Operator Panel (OP) for parameterization, diagnostics, and control as well as for copying drive parameters. MMC memory card for carrying out standard commissioning of more than one inverter and for external data backup.
STARTER CD/DVD	PC connection kit and STARTER commissioning tool for prompted, PC-based commissioning.
	Filters and reactors
	Line filters (classes A and B)
	Line reactors
	Braking resistors
	Output reactors
	Sine-wave filter
	Further options
	Brake Relay
	Safe Brake Relay
	Adapter for DIN rail mounting
	Shield connection kit

Description 2.2 Overview of Control Units

2.2 Overview of Control Units

					Control Units relevant	with safety- functions
			Co	Control Units with fieldbus interface		
	CU240E	CU240S	CU240S DP	CU240S PN	CU240S DP-F	CU240S PN-F
SINAMICS	Cost-effective variants Functionally identical with the CU240S however, no encoder connec- tion, fewer I/Os	Control Unit CU240S for operation via terminals and USS via RS485	Control Unit CU240S additionally with PROFIBUS DP interface	Control Unit CU240S additionally with PROFINET interface	Control Unit CU240S additionally with PROFIBUS DP interface and safety-relevant functions via terminals or PROFIsafe	Control Unit CU240S additionally with PROFINET interface and safety-relevant functions via terminals or PROFIsafe

Figure 2-1 Control Unit variants

2.3 Overview of Power Modules

2.3 Overview of Power Modules



Figure 2-2 Power Module versions

A number of Power Module versions are available for different line supply voltages in a power range from between 0.37 kW and 250 kW. Depending on the Power Module used, the energy released in regenerative mode is either

- fed back to the supply system (Efficient Infeed Technology) or
- stored in the DC link and/or fed to an external braking resistor.

Overview of the available Power Modules

Depending on the output, Power Modules are available with different frame sizes The range of frame sizes extends from FSA to FSGX.

		FSA	FSB	FSC	FSD	FSE	FSF	FSGX
PM240 3-ph. 400V AC		0.37 kW 1.5 kW	2.2 kW 4kW	7.5 kW 15 kW	18.5 kW 30 kW	37 kW 45 kW	55 kW 132 kW	160 kW 250 kW
	With integr. Line filter, class A	0	•	•	•	•	(1)) 2)
	With integr. Braking chopper	•	•	•	•	•	•	0 2)
PM250 3-ph. 400V AC		-	-	7.5 kW 15 kW	18.5 kW- 3 0 kW	37 kW 45 kW	55 kW 90 kW	-
	With integr. Line filter, class A			•	•	•	•	
	Capable of energy recovery			•	•	•	•	
PM260 3-ph. 690V AC		-	-	-	11 kW 18.5 kW	-	30 kW 55 kW	-
	With/without integr. Line filter, Class A				•		•	
	With integr. Sine-wave filter				•		•	
	Capable of energy recovery				•		•	

• = Feature available; • = Feature not available; • = Feature available, modified;

1) PM240 Power Modules, 110 kW and higher, are only available without an integrated class A filter. Instead, an optional class A line filter for side mounting is available.

2) PM240 FSGX Power Module is only available without integrated components. Instead, optional line reactor, line filter, output reactor, sine-wave filter, braking chopper, braking resistor and Brake Relay are available.

2.4 Reactors and filters

Overview

Depending on the Power Module, the following combinations with filters and reactors are permitted:

Power Module		Line-side component	Load-side components		
	Line reactor	Line filters class B	Braking resistor	Sine-wave filter	Output reactor
PM240	•	•	•	•	•
PM250	-	•	-	•	•
PM260	-	•	-	integrated	-

Connection

3.1 Procedure for installing the frequency inverter

Prerequisites for installing the inverter

- Check that the following prerequisites are fulfilled before you install the inverter:
- Are the components, tools and small parts required for installation available?
- Are the ambient conditions permissible? See: Technical data (Page 227)
- Have the cables and wires been routed in accordance with the applicable regulations? See: EMC-compliant connection (Page 39)
- Are the minimum distances from other equipment complied with? (Cooling sufficient?) See: Chapter: Dimensions, hole drilling templates, minimum clearances, tightening torques (Page 31)

Installation sequence

- Install the Power Module (detailed instructions are provided in the Installation Manual for the Power Modules (http://support.automation.siemens.com/WW/view/en/30563173/133300))
 - Remove the terminal covers where applicable
 - Connect motor cable and power cable
 - Terminate the shield over a large area, if necessary using a shield connection set
 - Refit the terminal covers
- 2. Mount the Control Unit
 - Open the terminal covers of the Control Unit
 - Connect the control lines to the terminals
 - Terminate the shield over a large area, if necessary using a shield connection set
 - Close the terminal covers again
- 3. Control Unit for operation in a higher-level control connect to the fieldbus
 - For PROFIBUS DP and CANopen connect it via the 9-pin sub D connector
 - For RS 485, connect it via the two-part bus connector
- 4. To commission the drive unit, either plug-in the operator control/display instrument (operator panel) or connect the inverter to the PC using the PC connection kit.


Installation has now been completed and you can begin commissioning.

3.2 Mounting reactors and filters

3.2 Mounting reactors and filters


Mounting system components in a space-saving fashion for the inverters

Many system components for the inverters are designed as sub-chassis components, that is, the component is mounted on the baseplate and the inverter mounted above it to save space. Up to two base components can be mounted above one another.



Connection

3.2 Mounting reactors and filters



3.3 Mounting Power Modules

Options for installing the Power Module

Depending on the format, various options are available for installing inverters. This manual describes how to install inverters directly on the cabinet wall.

Installation options	Frame size						
	А	В	С	D	Е	F	GX
Installation on standard rails	Х	Х	Х				
Mounting on a cabinet panel with shield connection kit	Х	Х	Х	Х	Х	Х	
Installation directly on the cabinet wall	Х	Х	Х	Х	Х	Х	Х

Installing Power Modules

Choose the best installation option for your application and install the Power Module in accordance with the instructions provided in this section.

NOTICE

Information about installation

The Power Module must not be installed horizontally.





Correct

Incorrect

Devices that could impede the flow of cooling air must not be installed in this area. Make sure that the ventilation openings for the cooling air for the inverter are not covered and that the flow of cooling air is not obstructed.

Installing additional components

Depending on the application, additional line reactors, filters, braking resistors, brake relays etc., may also be used.


Please observe the mounting and installation instructions supplied with these components!

3.3.1 Dimensions, hole drilling templates, minimum clearances, tightening torques


0.37 kW ... 1.5 kW 2,2 kW ... 4 kW 7,5 kW ... 15 kW 73 mm -189 mm 153 mm (2.87") (7.41") (6.02") 167 mm 133 mm 04,5 (6.57") (5.24") Ψ 04,8 05,5 шШ 173 mm (6.81") (6.30") 60 258 mm -(10.16") 270 mm (10.63") 323 mm. (12.72") Retaining type Retaining type Retaining type 4 x M5 bolts 2 x M4 bolts 4 x M4 bolts . . 2 x M4 nuts 4 x M4 nuts 4 x M5 nuts 4 x M4 washers 4 x M5 washers 2 x M4 washers • **Tightening torques Tightening torques Tightening torques** 2.5 Nm (22.1 lbf.in) • 2.5 Nm (22.1 lbf.in) 2.5 Nm (22.1 lbf.in) Distances from other devices Clearances to other devices Clearances to other devices Lateral: 0 mm (0 inch) up to 40°C • Lateral: 0 mm (0 inch) up to 40°C ٠ Lateral: 0 mm (0 inch) up to 40°C ٠ 30 mm (1.18 inch) from 40°C and 40 mm (1.57 inch) from 40°C and 50 mm (1.96 inch) from 40°C and higher higher higher • Top/bottom: 100 mm (3.93 inch) • Top/bottom: 100 mm (3.93 inch) ٠ Top/bottom: 125 mm (4.92 inch) Depth Depth Depth Standalone: 145 mm (5.71 inch) Standalone: 165 mm (6.50 inch) Standalone: 185 mm (7.28 inch) • • • With CU240E: 187 mm (7.36 inch) • With CU240E: 207 mm (8.15 inch) With CU240E: 227 mm (8.94 inch) . ٠ With CU240S: 208 mm (8.19 inch) • With CU240S: 228 mm (8.98 inch) With CU240S: 248 mm (9.76 inch)

Overview of dimensions and hole drilling templates for the Power Modules

334 mm




Connection 3.3 Mounting Power Modules



55 kW 132 kW without fi 30 kW 55 k		55 kW 90 kW with filter						
(* 30	50 mm 13.8") 00 mm 11.8")	350 mm (13.8") 300 mm (11.8") (0.3") Ø 8,5 mm (0.3")						
598 mm (23.5")	635 mm (25.0")	899 mm (35.4")						
*	₫		₫					
Retaining type	 4 x M8 bolts 4 x M8 nuts 4 x M8 washers 							
Tightening torques	• 13 Nm (115 lbf.in)							
Clearances to other devices	 Lateral: 0 mm (0 inch) Top/bottom: 350 mm (²) 	13.77 inch)						
Depth	 Standalone: 316 mm (⁷ With CU240E: 358 mm With CU240S: 379 mm 	ı (14.09 inch)						

Connection 3.3 Mounting Power Modules



3.3.2 Wiring Power Modules

Prerequisites

Once the Power Module has been properly installed, the line and motor connections can now be established. The following warning information must be observed here.



Line and motor connections

The inverter must be grounded on the supply and motor side. If this is not carried out properly, this can lead to extremely hazardous conditions which, under certain circumstances, can result in death.

The device must be disconnected from the electrical power supply before any connections with the device are established or in any way altered.

The inverter terminals can carry hazardous voltages even after the inverter has been switched off. After disconnecting the line supply, wait at least 5 minutes until the drive unit has discharged itself. Only then, carry out any installation and mounting work.

When connecting the inverter to the line supply, ensure that the motor terminal box is closed.

Even if the LEDs or other indicators do not light up or remain inactive when a function is switched from ON to OFF, this does not necessarily mean that the unit has been switched off or is de-energized.

The short-circuit ratio of the power supply must be at least 100.

Make sure that the inverter is configured for the correct supply voltage (the inverter must not be connected to a higher supply voltage).

If a residual-current circuit breaker is installed on the supply side of the electronic devices to protect against direct or indirect contact, only type B is permissible. In all other cases, other protective measures must be implemented, such as creating a barrier between the electronic devices and the environment by means of double or reinforced insulation, or disconnecting them from the supply by means of a transformer.

CAUTION

Supply and control cables

The control cables must be laid separately from the supply cables to ensure that the system is not affected by inductive or capacitive interference.

Note

Electrical protective equipment

Make sure that suitable circuit breakers and/or fuses (with the prescribed rated currents) are installed between the supply system and inverter (see the technical specifications).

Connection 3.3 Mounting Power Modules

Connection example: Power Module PM240





Figure 3-1 Connection diagram: PM240 Power Module with Brake Relay

Star connection and delta connection

With SIEMENS motors, you will see a diagram of both connection types on the inside of the terminal board cover:

- Star connection (Y)
- Delta connection (Δ)

The motor rating plate provides information about the correct connection data: e.g.: 230/400V Δ /Y means that for a 400V line supply, the motor is connected up in the Y connection.



Connection

3.3 Mounting Power Modules

Connecting-up Power Modules

Line supply connection	Motor connection	Connect the braking resistor
Connect the line supply to terminals U1/L1, V1/L2 and W1/L3.	Connect the motor at terminals U2, V2, and W2.	A braking resistor can be connecting at terminals DCP/R1 and R2.
Connect the protective conductor of the line supply to terminal PE of the inverter. Power Modules without an integrated line filter can be connected to grounded (TN, TT) and non-grounded (IT) line supply systems. Power Modules with an integrated class A line filter are only suitable for TN supply systems.	 Connect the protective conductor of the motor to the terminal ⊥ of the inverter. The following cable lengths are permissible: Unshielded 100 m Shielded, 50 m for inverters without filter 25 m for inverters with filter Additional information is provided in Catalog D11.1 for longer cable lengths 	Do not ground the braking resistor at the inverter, but directly at your grounding bar.
	Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state Image: Normalized state	

	FSA	FSB	FSC	FSD	FSE	FSF	FSGX
Power	0.37 kW …	2.2 kW	7.5 kW	18.5 kW …	37 kW …	55 kW	160 kW
	1.5 kW	4 kW	15 kW	30 kW	45 kW	132 kW	250 kW
Connection	1 mm²	1.5 mm²	4 mm²	10 mm²	10 mm²	35 mm²	95 mm²
cross-section	2.5 mm²	6 mm²	10 mm²	35 mm²	35 mm²	120 mm²	2 x 240 mm²
Torque	1.1 Nm	1.5 Nm	2.25 Nm	6 Nm	6 Nm	13 Nm	14 Nm

3.3.3 EMC-compliant connection

EMC-compliant connection

The example diagram shows how shielding is implemented for frame size FSA using a shield connection kit. Corresponding shield connection kits are available for all Power Module frame sizes (you will find more information in Catalog D11.1).

The cable shields must be connected to the shield connection kit with the greatest possible surface area by means of the shield clips.




Figure 3-2 Shield connection kit FSA

Note

EMC-compliant shielding can also be implemented without this optional shield connection kit. In this case, you must ensure that the cable shields are connected to the ground potential with the greatest possible surface area.

3.3 Mounting Power Modules

Avoiding electromagnetic disturbances

The inverters are designed for operation in industrial environments where high values of electromagnetic noise and disturbances are expected. Generally, correct installation guarantees safe, reliable and disturbance-free operation. If difficulties do arise, then please note the following guidelines.


Required measures

- Ensure that all of the devices in the cabinet are well-grounded using short grounding cables with high cross-sections, connected to a common grounding point or a grounding bar.
- Ensure that every control device (e.g. a PLC) connected to the inverter is connected to the same ground or the same grounding point as the inverter through a short cable with a large cross-section.
- Connect the return ground of the motors, which are controlled from the inverters, directly at the ground connection (PE) of the associated inverter.
- Flat cables are preferred as they have a lower impedance at higher frequencies.
- The cable ends must be cleanly terminated and it must be ensured that unshielded cables are as short as possible.
- The control cables must be routed separately from the supply cables. Power and control cables should cross at a 90° angle.
- If at all possible, use shielded cables to connect the control circuit.
- Ensure that the contactors in the cabinet have the necessary interference suppression components; either using an RC circuit for AC contactors or using "free-wheeling diodes" for DC contactors, whereby the noise suppression elements should be connected at the coils. Varistor suppressors are also effective. This is important if the contactors are controlled from the inverter relay.
- Use shielded cables for the motor connections, and ground the shielding at both ends using cable clamps.

Connection 3.4 Installing the Control Unit

3.4 Installing the Control Unit

Locating the Control Unit on the power unit




The Control Unit is simply snapped-on to a Power Module. This also establishes all of the electrical connections between the two components.

The Control Unit can be removed by pressing the release button ③.

Removing the terminal cover

To access the control terminals, remove the cover as shown in the adjacent diagram.

- Maximum cable cross-section for control terminals, 2.5 mm².
- Tightening torque, 0.25 Nm



3.4 Installing the Control Unit

3.4.1 Interfaces, connectors, switches, control terminals, LEDs on the CU

Overview of the process and user interfaces

The following interfaces are provided on the Control Unit

- Terminals for the input and output signals
- · Card slot to upload and download inverter settings
- Connector to communicate with higher-level controls
- DIP switches to configure the speed encoder, the analog inputs and, if required, to set the PROFIBUS address.
- LEDs for diagnostics

All of the these interfaces are shown in the following diagram.





Figure 3-3 User interfaces of the CU240E/S

Connection

3.4 Installing the Control Unit



* Terminals for fail-safe versions / ** only for CU240E

Figure 3-4 Block diagram, CU 240

3.4 Installing the Control Unit

Arrangement and function of the terminals on the CU240S Control Unit

All Control Units are equipped with the same control terminals. However, depending on the CU version, the factory set activation for certain digital inputs and interfaces differ. (see the block diagram for CU240S/E and for CU240S-DP/CU240S-DPF/CU240S-PN/CU240S-PN-F).

Unlike the standard Control Units, the fail-safe Control Units CU240S DP-F and CU240S PN-F only have six digital inputs instead of nine. They are instead equipped with two fail-safe digital inputs. Fail-safe digital inputs are redundant and each have two terminals.




Figure 3-5 Terminal overview: CU240S-DP /-DP-F/ -PN /-PN-F

Commissioning

Alternative commissioning options


The functions of an inverter are activated and configured using parameters. Parameters can either be accessed from the operator control/display instrument (operator panel) or using the STARTER commissioning tool from the PC via the appropriate inverter interface.

Inverters can also be parameterized by saving the valid inverter parameter set on an MMC memory card or on the Operator Panel and then transferring it to a different inverter with the same configuration and function.

The commissioning scenarios listed below are described in the following sections:

- Commissioning, using the factory settings
- Commissioning using the STARTER commissioning tool
- Commissioning using the Operator Panel
- Data backup with the Operator Panel and MMC memory card

Users can access the inverter parameters via the following interfaces



4.1 Initial coupling of the CU and PM - message F0395

4.1 Initial coupling of the CU and PM - message F0395

Description

Message "F0395" is displayed when Control Units or Power Modules are switched on for the first time or after they have been replaced.

Using this message F0395, the two inverter components - Control Unit and Power Module - are monitored to ensure that they are not replaced without the appropriate authorization. If you acknowledge this message, then you accept the responsibility that the parameter set on the Control Unit matches the Power Module and the hardware has been correctly connected, e.g. all of the output phases have been correctly connected.

Acknowledging message F0395

Depending on which command source is set, you can acknowledge message F0395 in the following ways:

- If the command source is "BOP": press function key FN
- If the command source is 'Terminals' (P0700 = 2): digital input 2 (factory setting for the acknowledge command)
- If the command source is 'Fieldbus' (P0700 = 6): control word 1 (STW1 / bit 7)

Message F0395 is also acknowledged when 'Restoring the factory setting'.

4.2 Restoring the factory settings

4.2 Restoring the factory settings

If nothing else works, restore the factory settings!

You can restore the factory setting using parameter P0970.

Parameter or procedure	Description
P0003 = 1	User access level 1: Standard
P0010 = 30	Commissioning parameter 30: Factory setting - initiate restore factory settings
P0970 = 1	Restore factory settings 1: Resetting - restoring parameters to the factory settings
BOP displays "BUSY"	Once the factory settings have been restored, P0970 and P0010 are set to 0 and the BOP returns to the standard display.
STARTER displays progress bar	

Table 4-1 Restoring the factory settings

Note

Data transfer is interrupted while the factory parameter settings are being restored.

The following parameters remain unchanged even after the factory settings have been restored:

- P0014 Storage mode
- P0100 Europe / North America
- Communication parameters
- Power-Module-specific data

4.3 Preparing commissioning

4.3 Preparing commissioning

Prerequisites: before you start

Before you start parameterization, you should clarify the following issues about commissioning your application.

Are the factory settings sufficient for your application?

To start, check which factory settings you can use and which settings you wish to change (see Section 'Commissioning with factory settings' (Page 51)). When doing so, you may find that you only need to change just a few parameters.


Which motor are you using? [P0300]

• A synchronous or induction motor?

The SINAMICS inverters are preset in the factory for applications using 4-pole three-phase induction motors that correspond to the performance data of the inverter.

Motor data / data on the motor rating plate

If you use the STARTER commissioning tool and a SIEMENS motor, you only have to specify the motor Order No. In all other cases, you must read-off the data from the motor rating plate and enter into the appropriate parameters.



NOTICE

Information about installation

The rating plate data that you enter must correspond to the connection type of the motor (star connection [Y]/ delta connection [Δ]), i.e. for a delta motor connection, the delta rating plate data must be entered.

In which region of the world is the motor used? - Motor standard [P0100]

- Europe ICE: 50 Hz [kW] factory setting
- North America NEMA: 60 Hz [hp] or 60 Hz [kW]

Are you using an external speed encoder, and if yes, what is its resolution? [P0400]

- Speed encoder type
- Number of encoder pulses (resolution) per revolution

What is the prevailing temperature where the motor is operated? [P0625]

• Motor ambient temperature [P0625], if it differs from the factory setting = 20° C.

What control mode do you want to use for your application? [P1300]

A distinction is made between V/f open-loop control and vector closed-loop control.

- The V/f open-loop control is the simplest operating mode for an inverter. For example, it is used for applications involving pumps, fans or motors with belt drives.
- For closed-loop vector control, the speed deviations between the setpoint and actual value are less than for V/f open-loop control; further, it is possible to specify a torque. It is suitable for applications such as winders, hoisting equipment or special conveyor drives.

4.3 Preparing commissioning

What command and setpoint sources are you using?

The command and setpoint sources that are available depend on the inverter. Depending on whether you use an inverter with or without fieldbus interface, with or without fail-safe functions, the default command and setpoint sources set in the factory differ.

- Possible command sources [P0700]
 - Operator Panel
 - Fieldbus (factory setting for bus-capable and fail-safe inverters)
 - Local digital inputs/switches (factory setting for non-bus-capable inverters)
- Possible setpoint sources [P1000]
 - Motorized potentiometer
 - Analog setpoint
 - Fixed frequency
 - Fieldbus

Controlling motors via terminals

There are various methods to start, stop and reverse the direction of a motor. The various methods can be configured using parameter P0727.

The following two-wire control versions are available with the factory setting (P0727 = 0):

- Switching on and off with one control command and reversing with the second control command.
- Switching on and switching off a direction of rotation with each control command.

Minimum/maximum frequency of the motor

The minimum and maximum frequency with which the motor operates or is limited regardless of the frequency setpoint.

- Minimum frequency [P1080] factory setting 0 Hz
- Maximum frequency [P1082] factory setting 50 Hz

Ramp-up time and ramp-down time

The ramp-up and ramp-down time define the maximum motor acceleration when the speed setpoint changes. The ramp-up and ramp-down time is the interval between motor standstill and the maximum frequency, or between the maximum frequency and motor standstill.

- Ramp-up time [P1120] factory setting 10 s
- Ramp-down time [P1121] factory setting 10 s

Commissioning

4.4 Commissioning with factory settings

Prerequisites for using the factory settings

In simple applications, commissioning can be carried out just using the factory settings. This section explains what prerequisites must be fulfilled for this purpose and how they are fulfilled.

- 1. The inverter and motor must match one another; compare the data on the motor rating plate with the technical data of the Power Module.
 - The rated inverter current must, as a minimum, be the same as the motor.
 - The motor power should match that of the inverter; motors can be operated in the power range from 25 % ... 100 % of the inverter power rating.
- 2. The digital and analog inputs must be connected in accordance with the wiring example. (See Section 'Wiring example (Page 52) ')
- 3. You then have to "tell" the inverter the following,
 - the source of its commands:
 - from an operator panel,
 - from the digital inputs
 - from the fieldbus interface

You can change this *command source* using parameter P0700 if the factory setting is not appropriate for your application.

- where it gets its speed setpoint (setpoint source)
 - from an analog input (analog setpoint)
 - as fixed frequency from a digital input
 - from the fieldbus interface

You can change this *frequency setpoint source* using parameter P1000 if the factory setting is not appropriate for your application.

4.4 Commissioning with factory settings

4.4.1 Wiring examples for the factory settings

Many applications function using the factory settings

To ensure that the factory setting can be used, you must wire the control terminals on your inverter as shown in the following examples.

Default settings for the control terminals on the CU240E





Figure 4-1 CU240E terminal overview: wiring example for using the factory settings

Commissioning

4.4 Commissioning with factory settings



Default settings for the control terminals on the non-bus-capable CU240E

* Failsafe versions in brackets

Figure 4-2

-2 CU240S terminal overview: wiring example for using the factory settings

4.4 Commissioning with factory settings

4.4.2 Factory setting of the frequency inverter

Default command and setpoint sources

Inverters used in automation solutions have the appropriate fieldbus interfaces. These inverters are preset in the factory so that the appropriate control and status signals can be exchanged via the fieldbus interface.

Inverters without a fieldbus interface are pre-set in the factory so that the digital and analog and input output signals are exchanged via terminals.

For instance, if you do not want to control an inverter equipped with a fieldbus interface via the fieldbus, but instead using switches and pushbuttons that are connected to the digital inputs, then you must change parameter P0700 as follows.

Table 4-2 Command and setpoint sources

Parameters	Description
P0700 = 2 or 6	Select the command source 2: Digital intputs (P0701 P0709) (factory setting for CUs without fieldbus interface) 6: Fieldbus (P2050 P2091), (factory setting for CUs with fieldbus interface)
P1000 = 2 or 6	Select the setpoint source2: Analog setpoint (factory setting for CUs without fieldbus interface)6: Fieldbus (factory setting for CUs with fieldbus interface)

Table 4-3 Factory settings of additional important parameters

Parameter	Factory setting	Meaning of the factory setting	Function	Access level
P0003	1 Access to the most frequently u parameters		Selecting the user access level	1
P0004	0	All parameters are displayed	Parameter filter: filters parameters in accordance with the functionality	1
P0010	0	Ready to be entered	Commissioning parameter	1
P0100	0	Europe [50 Hz]	Frequency of the regional supply networkIEC, EuropeNEMA, North America	1
P0300	1	Induction motor	Select the motor type (induction motors / synchronous motor)	2
P0304	400	[M]	Rated motor voltage (in accordance with the rating plate in V)	1
P0305	depends on the Power Module	[A]	Rated motor current (in accordance with the rating plate in A)	1
P0307	depends on the Power Module	[kW/hp]	Rated motor output (in accordance with the rating plate in kW/hp)	1
P0308	0	[cos phi]	Rated motor power factor (in accordance with the rating plate in cos 'phi') if P0100 = 1.2, then P0308 is irrelevant	1

Commissioning

4.4 Commissioning with factory settings

Parameter	Factory setting	Meaning of the factory setting	Function	Access level
P0309	0	[%]	Rated motor efficiency (in accordance with the rating plate in %) if P0100 = 0, then P0309 is irrelevant	1
P0310	50	[Hz]	Rated motor frequency (in accordance with the rating plate in Hz)	1
P0311	1395	[rpm]	Rated motor speed (in accordance with the rating plate in rpm)	1
P0335	0	Non-ventilated: Shaft-mounted fan in the motor	Motor cooling (specify the motor cooling system)	2
P0625	20	[°C]	Ambient temperature of motor	3
P0640	200	[%]	Motor overload factor (entered in % referred to P0305)	2
P0700	2 or 6	2 for non-bus-capable CUs 6 for bus-capable CUs	Select the command source	1
P0727	0	DI0: On / off DI1: Direction reversal	Control response when the motor starts (start, stop, reverse)	3
P0970	0	Locked	Restore factory settings	1
P1000	2 or 6	2 for non-bus-capable CUs 6 for bus-capable CUs	Select the source of the frequency setpoint (setpoint input)	1
P1080	0	[Hz]	Minimum frequency	1
P1082	50	[Hz]	Maximum frequency	1
P1120	10	[s]	Ramp-up time	1
P1121	10	[s]	Ramp-down time	1
P1300	0	V/f control with linear characteristic	Control mode	2
P3900	0	No quick commissioning	Completes the quick commissioning	1

4.4 Commissioning with factory settings

4.4.3 Default terminal settings

Factory settings of the process interfaces

	Digital inputs						
Terminal	Abbreviation	Parameter	Factory setting	Meaning of the factory setting			
5	DIO	P0701	1	ON/OFF1			
6	DI1	P0702	12	Direction reversal			
7	DI2	P0703	9	Fault acknowledgment			
8	DI3	P0704	15	Fixed frequency selector bit 0 (direct) [P1001]			
16	DI4	P0705	16	Fixed frequency selector bit 1 (direct) [P1002]			
17	DI5	P0706	17	Fixed frequency selector bit 2 (direct) [P1003]			
40	DI6	P0707	18	Fixed frequency selector bit 3 (direct) [P1004]			
41	DI7	P0708	0	Digital input locked			
42	DI8	P0709	0	Digital input locked			

	Digital inputs of the safety functions					
Terminal Abbreviation Parameter Factory setting Meaning of the factory setting						
60	FDI0A	P9603	0	Digital inputs of the safety functions are locked		
61	FDI0B					
62	FDI1A					
63	FDI1B					

	Digital outputs (relay outputs)							
Terminal	Abbreviation		al Abbreviation		Parameters	Factory setting	Meaning of the factory setting	
18	NC	DO0	P0731	52.3	Drive fault active			
19	NO							
20	СОМ							
21	NO	DO1	P0732	52.7	Drive alarm active			
22	СОМ							
23	NC	DO2	P0733	0.0	Relay output is locked			
24	NO]						
25	COM							

Commissioning

4.4 Commissioning with factory settings

	Analog inputs						
Terminal	Abbrevia	ation	Parameters	Factory setting	Meaning of the factory setting		
3 4	AI0+ AI0-	AIO	P0756 [0]	0	Set unipolar voltage input 0 V +10 V DC in addition to parameterizing DIP switch on CU housing.		
10 11	Al1+ Al1-	Al1	P0756 [1]	0	Set unipolar voltage input 0 V +10 V DC in addition to parameterizing DIP switch on CU housing.		

	Analog outputs							
Terminal	Abbrevi	ation	Parameters	Factory setting	Meaning of the factory setting			
12	AO0+	AO0	P0771[0]	21	Frequency on the inverter output;			
13	AO0-				analog output 0 can be switched from current output to voltage output by means of P0776			
26	AO1+	AO1	P0771[1]	21	Frequency on the inverter output;			
27	AO1-				analog output 1 is current output only			

	Encoder interface (encoder)						
Terminal	Function	Parameter	Factory setting	Meaning of the factory setting			
70	Channel A - non-inverting	P0400	0	Evaluation of the speed encoder is locked			
71	Channel A - inverting						
72	Channel B - non-inverting						
73	Channel B - inverting						
74	Zero pulse - non-inverting						
75	Zero pulse - inverting						

PTC/KTY84 interface						
Terminal	Abbreviation	Parameters	Factory setting	Meaning of the factory setting		
14	PTC+	P0601	0	Evaluation of the motor temperature sensor is locked		
15	PTC-					

4.5 Commissioning with STARTER

Prerequisites

The STARTER commissioning tool features a project Wizard that guides you step-by-step through the commissioning process. Configuring the inverter using the PC is significantly more user friendly and faster than commissioning using the operator panel.

The following is required to commission the inverter via the PC:

• A PC connection kit for connecting the inverter to a PC. Order no.: 6SL3255-0AA00-2AA1




Figure 4-3 PC connection kit

- The installed STARTER software. (supplied with the PC connection kit). You can download the latest version from the Internet under the following address (http://support.automation.siemens.com/WW/view/en/10804985/133100):
- The motor must be connected to the inverter.

4.5.1 Creating a STARTER project

Description

An inverter can be parameterized in a user-friendly fashion using the Project Wizard. The commissioning procedure described here follows the Project Wizard. The PC communicates with the inverter via the USS interface.

- Switch on the inverter supply voltage
- Launch the STARTER commissioning tool.
- Use the Project Wizard and click on the "Find drive units online ..."




Figure 4-4 Start field

• In the screen that follows (not shown here), enter a meaningful name into your project, e.g. "Basic Commissioning" and click on "Continue". The following dialog box is displayed.




Figure 4-5 Setting the PC interface

• Click "Change and test..." to set up the PG/PC interface.

PG/PC - Set interface

• Select "PC COM-Port (USS)" from the list and click on "Properties ..."

PG/PC Interface	
ccess Path	
Access Point of the Application:	
S70NLINE (STEP 7) \rightarrow PC COM-Port (USS) 🔄
(Standard for STEP 7)	
Interface Parameter Assignment Used:	
PC COM-Port (USS)	Properties.
😻 (None)	Diagnostics
ISO Ind. Ethernet -> Intel(F	Сору.
ISO Ind. Ethernet -> Realtek	
1	Dape
(Parameterizing your PC CDM port for a USS protocol)	
- Interfaces	
Add/Remove:	Select

Figure 4-6 Setting the USS interface

• If "PC COM-Port (USS)" is not available, click on "Select ..." to install the "PC COM-Port (USS)" interface as shown in the "Install/Remove Interfaces" dialog box.

1odule		Module		N
CP5613A2		EP5512		В
CP5614A2	/ Install→		et -> Broadcom NetXtreme G	
ISO Ind. Ethernet			et -> Cisco Systems VPN Ad	
PC Adapter PC COM-Port (USS)		BPC COM-Port (at -> Intel(R) PRO/Wireless	. B
PC/PPI cable	1		dcom NetXtreme Gia	B
Serial cable(PPI)	< Uninstall		Systems VPN Adapter	B
TCP/IP			R) PRO/Wireless	B
•		<	11	>
		Display module	s ready for operation only	
ROFIBUS-to-USS converter via P	0			
HOLIDO2-0-022 COUVEINELVIE F	 Senar mienace (COW port) 			

Figure 4-7 Installing the USS interface

 If you have installed the "PC COM-Port (USS)" interface, close the dialog box and now call up "Properties - PC COM-Port (USS)".

erties - PC COM-Port	
Interface:	СОМ1
Baud rate:	38400
Baud rate test —	()
Bead	08#10
OK <u>S</u> tandard	Abbrechen Hilfe

Figure 4-8 PC COM properties

- In this dialog box, you can set the COM interface (COM1, COM2, COM3) and baud rate (default: 38400).
- To determine the correct values of your interface, choose e.g. COM1, and then click on "Read".
- Under the "RS 485" tab, in addition, select the "Automatic mode". Using various baud rates in succession, the PC checks whether communications have been established to the inverter. This can take several minutes.
- If "???" is displayed in the Baud rate test field then the baud rate test was unsuccessful. and you should choose a different COM interface. In the case of the correct COM interface, a value is displayed. Enter this value into the "baud rate" selection field.

• When you click "OK", the "Set PG/PC Interface" dialog box is displayed again.

		/	
-() –	_
\sim	伀		

Tip

In the "Set PG/PC Interface" dialog box, you can view the stations that can be accessed via USS by choosing "Diagnostics...":

	10 F F F F F F F F F F F F F F F F F F F		0		2	3	4	5	6	7	8	9
20 F F F F F F F F F F F F F F F F F F F	20 F F F F F F F F F F F F F F F F F F F	0	M	П	Г	Г	F	Г	F	Г	П	Г
30 T T Legend	30 T T Legend	10	Г	Г	Г	Г	Г	Π	Г	E	E	Г
Test-slaves E Assigned	Test-slaves Residence	20	Г	П	Г	П	Г	Г	Г	Г	Ε	Г
		_		-		_				10.00	Assi	gned

- When you choose "OK" again, this takes you back to the Project Wizard.
- By clicking on "Continue", a search is made for devices that are available online and you then come to the step "Insert drives".

Commissioning

4.5 Commissioning with STARTER

Insert drives

Project Wizard	Starter				×
Introduction	1. Create new project	2. PG/PC - Set interface	3. Insert drives	4. Summary	
Preview Basic	: Commissioning INAMICS_G120_CL	J2405		Refresh view	
		Back Continu	ie >	Cancel	

Figure 4-9 Insert drives

- In this dialog box, enter a name for your inverter, e.g. "SINAMICS_G120_CU240S" (no blanks or special characters).
- Click on "Next".
- Close the "Summary" dialog box by choosing "Finish".

4.5.2 Establishing an online connection between the PC and converter (going "online")

Description

With the procedure described above, the project has been created and your inverter is integrated into the project tree. However, there is no online connection.

• Click on 🔚 ("Connect to the target system"), in order to go online with the inverter.

The left-hand column in the dialog box below contains the online data that has been saved, while the right-hand column contains the offline data that has been saved.

• Click on "Load HW configuration to PG" to download the online data into your PC.

	Online	Offline 🔺
CU type	CU240S DP	
Fieldbus Communication	PROFIBUS	
USS Communication	Based on RS232	
MMC-Storage	Available	
Input/Outputs	DI 9, DO 3, AI 2, AO 2	
Electomech. Brake Relay	Available	
Operator Panel Interface	BOP	
Electronic	DC, Compound and Dynamic Braking	
		<u>.</u>
A	configuration to PG Note: The lo can re	ading of the hardware configuration sult in parameters being added or removed.

Figure 4-10 Inverters found online (using the SINAMICS G120 with Control Unit CU240S DP as example)

- To conclude your entry, choose "Close".
- The status display changes from the "Offline mode" with blue background into the "Online mode" with yellow background.

4.5.3 Starting the general commissioning

Description

 When the final dialog box in the "Going online" section is closed, the text "Offline mode" in the bottom right of the dialog box changes to "Online mode".

STARTER - Basic Commis	sioning_1			
Project Edit Target system	View Options Wind	low Help		
		N	🖄 🔐 % 🔺 🏜 🏜	•• 🖬 🔚 📰 🛛 👪
Basic Commissioning_1 Basic Commissioning_1 SINAMICS_G120 Project				
> Display information	Acknowledge	all	Acknowledge	Help for event
Level Time		Source		Message
📕 📥 Fault (PG) 02.1	0.2008 13:54:46	SINAMICS	_G120_CU240S	395 : Acceptance Test / Cor
				Þ
📗 🌃 Alarms 🔝 Target sys	tem output 🛛 🌿 Diagr	nostics overvi	ew	
Press F1 to open Help display.		ĺ	PC COM-Port (USS)	Online mode

Figure 4-11 Going online with STARTER (example with SINAMICS G120)

- For modular inverters that comprise a Control Unit and Power Module, when first powered-up and after replacing a control unit or a Power Module, message F0395 is output. This message is intentional and does not indicate that the inverter is faulty. This message monitors the individual inverter components (CU and PM) against unauthorized replacement.
- Select and acknowledge message F0395 that is present as described in the Section "Initial coupling of the CU and PM".

Note

For information about the symbols used in STARTER, call up the online help. Press <Shift><F1> and choose the relevant symbol. For example:



- Open the drive unit (1), by double clicking on the drive object (1)
- Click on "Wizard ..." for the (basic) commissioning, and let the Wizard guide you.

```
Commissioning
```

Carrying out commissioning

The Project Wizard navigates you step-by-step using pull-down menus through the basic settings for your application.

• You get to the next menu item by pressing, choose "Next".

Configuration - SINAMICS	_G120 - Control structure	<u>?</u> ×
Control structure	Drive: SINAMICS_G120, DDS 0, CDS C	
Drive setting Motor Motor data	Setpt. Control method: V/f with linear characteristic (0)	
Encoder		
Calculation of the moto		
		M
(French	Previously made settings are lost through a reconfiguration,	it is not
	possible to cancel the configuration online.	
	Back Next> Cancel	Help

Figure 4-12 Start field: commissioning

• For the "Drive functions" menu item, we recommend that motor data identification: "Locked" should be selected.



Figure 4-13 Deselecting motor data identification

Note

Motor data identification

Motor data identification is only required for vector control - and it is described there.

• For the menu item "Calculation of the motor data", we recommend that you select "Restore factory settings and calculate motor data".



Figure 4-14 Calculating the motor data and restoring the factory setting

- Configuration SINAMICS_G120 Summary ? × Drive: SINAMICS_G120, DDS 0, CDS 0 Control structure Defaults of the setpoint Drive setting Motor The following data of the drive has been entered: Motor data Encoder Control structure: ٠ Drive functions Control mode, Drive Dataset 0 (DDS0): 0 Defaults of the setpoints/command sources: USS address, USS on RS232: 0 Selection of command source, Command Dataset 0 (CDS0): 2 Important parameters Calculation of the moto Selection of 2/3-wire method , Command Dataset 0 (CDS0): 2 Selection of frequency setpoint, Command Dataset 0 (CDS0): 0 Selection of torque setpoint, Command Dataset 0 (CDS0): 0 Drive setting: Europe / North America: 0 + Motor: Select motor type, Drive Dataset 0 (DDS0): 1 Motor data: Rated motor voltage, Drive Dataset 0 (DDS0): 400V -Copy text to clipboard Copy RAM to ROM (save data in the drive) < Back Finish Help
- The Project Wizard for the (first) commissioning is concluded with the following summary:

Figure 4-15 Completing commissioning

• Finally, choose "Finish".

4.5.4 Commissioning the application

Description

- You can now commission your application using the "Drive Navigator" screens or by using the functions available in the project tree.
- Save your settings so that they are protected against power failure (see below).
- Once you have commissioned your application, disconnect the online connection between the PC and inverter by clicking on State.




Figure 4-16 Application communication

Storing data in a power-independent manner

- In the project tree, select your SINAMICS project
- Double-click on "Drive Navigator".
- Select "Commissioning" in the working area
- In the dialog box, select "Save data in the drive (RAM to ROM)".


You can now disconnect the online connection with 强 "Disconnect from target system"

4.6 Commissioning with the operator panel

4.6.1 Function of the Basic Operator Panel

The Basic Operator Panel (BOP) offers various commissioning options and ways tosave data and transfer data with the BOP (Page 77).

The Basic Operator Panel can be used to commission drives, monitor operation and set individual parameters. The keys can be used, for example, to set control signals and the speed setpoint. Parameter changes that are made using the BOP are saved so that they are protected against power failure.



The Basic Operator Panel for 'local' operation and how to attach it to the Control Unit

The Basic Operator Panel is an input and display instrument that allows you to operate inverters "locally". A BOP can be used for more than one inverter and is mounted directly on a Control Unit.

The BOP has 8 keys and a 2-line screen for displaying values and units:

- Line 1 shows a parameter number or value
- Line 2 shows the corresponding physical unit

4.6 Commissioning with the operator panel

4.6.2 BOP controls and displays

How to use the BOP

Key	Function	Function / result
r 0000	Status LED	Shows parameter numbers, values, and physical units of measure.
Р	Parameter access	This button allows you to access the parameter list.
		r read-only parameters: for display only
		Pwrite parameters: these can be changed
	Increase displayed values	This button allows you to scroll forwards in the parameter list;
▼	Decrease displayed values	This button allows you to scroll backwards in the parmeter list.
FN	Function key	The function of this button varies depending on the data displayed:
		If a parameter number is displayed and you press this button once briefly, you can return to the start of the parameter list r0000.
		If a parameter value is displayed and you press this button once briefly, the cursor jumps to the next position (e.g. in a multi-digit number). This allows you to change a decimal number digit by digit, for example.
		If an alarm or a fault message is displayed and you press this button once briefly, this acknowledges the message.
	Start motor	Press this button to start the motor.
		In the factory setting, this button is not active: activate with P0700 = 1
6	Stop motor	Press this button to stop the motor.
•		OFF2 is always activated: Press twice briefly or press once for longer: The motor coasts to a standstill.
		In the factory setting, OFF1 is not active. To activate it, set P0700 = 1.
ζ	Change direction of rotation	When you press this button, the direction of motor rotation is reversed (CW/CCW).
		In the factory setting, this button is not active. To activate it, set P0700 = 1.
JOG	Jog mode	Run the motor in jog mode. The motor rotates at a predefined speed for as long as this key is pressed (and kept down).
		In the factory setting, this button is not active. To activate it, set P0700 = 1.

Table 4-4 Operator controls of the Basic Operator Panel and its functions

Commissioning

4.6 Commissioning with the operator panel

4.6.3 Parameterization with the BOP (two examples)

All of the parameter changes, which are made using the BOP, are saved so that they are protected against power failure.

Changing a parameter value using the BOP

The following description is an example of how to change any parameter using the BOP.

Table 4-5 Change P0003 (set user access level "3")

	Step	Result displayed
1	Press P to access the parameters.	r 0000
2	Press 🔺 until P0003 is displayed.	P0003
3	Press P to display the parameter value.	1
4	Press \Lambda or 🔽 to set the required value (to 3).	Э
5	Press P to confirm and save the value.	P0003
6	The user can now view all parameters in steps 1 to 3.	

Using the BOP to change parameters with more than one index

The next example shows how the value of an indexed parameter can be changed.

	Step	Result displayed
1	Press P to access the parameters.	r 0000
2	Press 🚺 as often or as long as required until P0700 is displayed.	P0100
3	Press P : index "in000" is displayed.	000
4	Press 🔺 or 🔽 to select index 1.	+++++++++++++++++++++++++++++++++++++++
5	Press P to display the value that is currently set.	0
6	Press 🚺 or 🔽 until the required value is displayed.	1
7	Press P to confirm and save the value.	P0100
8	Press 🔽 until r0000 is displayed.	r 0000
9	Press P to reset the display to the standard drive display (as defined by the customer).	

 Table 4- 6
 Change index parameter P0700 (set command source "BOP" under index 1)

Note

When parameter values are being changed, the BOP sometimes displays the message **"bUSY"**. This means that the inverter is currently processing a higher-priority task.

4.6 Commissioning with the operator panel

4.6.4 Commissioning steps

The following section provides a step-by-step guide to quick commissioning, which is sufficient for the majority of applications.

The first step in commissioning a drive train is to ensure that the inverter and motor are harmonized. This inverter-motor combination can then be adapted in line with the requirements of the drive machine

The inverter is adapted to the requirements of an application by parameterizing it. A corresponding parameter list with explanations is provided on the following pages.

4.6.5 Commissioning V/f control

Since the load characteristic can be set as required, V/f control is sufficient for many drive trains. A drive train that operates with *V/f control with a linear characteristic* can be set by entering the following parameters.

Parameter settings for V/f control

Table 4- 7	Setting the ad	ccess level and	parameter filter
------------	----------------	-----------------	------------------

Parameters	Description
P0003 = 1	User access level 1: Standard: Allows access to the most frequently used parameters (factory setting) 2: Extended: Allows extended access, e.g. to inverter I/O functions 3: Expert: To be used by experts
P0010 = 1	Commissioning parameter filter 0: Ready (factory setting) 1: Quick commissioning 30: Factory setting - initiate restore factory settings To parameterize the motor rating plate data, set P0010 = 1.

Table 4-8 Data on the environmental conditions at the installation location

Parameters	Description
P0100 = 0	Europe / North America (line frequency of region) 0: Europe [kW], standard frequency 50 Hz (factory setting) 1: North America [hp], standard frequency: 60 Hz 2: North America [kW], standard frequency: 60 Hz
P0230 = 0	Output filter 0: No filter (factory setting)
P0233 =	Filter inductance of the output filter used 0.000 (factory setting)
P0234 =	Filter capacitance of the output filter used 0.000 (factory setting)

4.6 Commissioning with the operator panel

Parameters	Description
P0304 =	Rated motor voltage (enter value as specified on the motor rating plate in Volt) 400 [v] (factory setting)
	The rating plate data entered must correspond to the motor connection type (star/delta) (i.e. with a delta motor connection, the delta rating plate data must be entered).
P0305 =	Rated motor current (enter value as specified on the motor rating plate in Ampere) 1 [A] (factory setting)
P0307 =	Rated motor power (enter value as specified on the motor rating plate in kW or hp) 0.37 [kW / hp] (factory setting)
	If P0100 = 0 or 2, the data is specified in kW If P0100 = 1, the data is specified in hp.
P0308 =	Rated motor power factor [cos phi] 0.820 (factory setting)
	This parameter is irrelevant when P0100 = 1 or 2.
P0310 =	Rated motor frequency (enter value as specified on the motor rating plate in Hz) 50.00 [Hz] (factory setting)
	When this parameter is changed, the number of pole pairs for the motor is automatically recalculated.
P0311 =	Rated motor speed (enter value as specified on the motor rating plate in rpm) 1395 [U / min]

 Table 4-9
 Motor data in accordance with the specifications on the motor rating plate

Table 4-10 Specify command source and frequency setpoint source

Parameter	Description
P0700 = 2 or 6	Select the command source0: Standard factory setting (restores the CU to the factory setting)1: BOP (Basic Operator Panel keys)2: Digital inputs (factory setting for 'stand-alone' CUs)4: USS on RS 2325: USS on RS 4856: Fieldbus (factory setting for fieldbus-capable CUs)
P1000 = 2 or 6	Select the setpoint source 0: No main setpoint 1: MOP setpoint 2: Analog setpoint (factory setting for stand-alone CUs) 3: Fixed frequency 4: USS at RS 232 5: USS at RS 485 6: Fieldbus (factory setting for fieldbus-capable CUs) 7: Analog setpoint 2

4.6 Commissioning with the operator panel

Parameter	Description
P1080 =	Minimum frequency 0.00 [Hz] factory setting
	Enter the minimum frequency (in Hz) at which the motor runs independently of the frequency setpoint. The value set here applies to CW and CCW rotation.
P1082 =	Maximum frequency 50.00 [Hz] factory setting
	Enter the maximum frequency (in Hz) to which the motor is restricted independently of the frequency setpoint. The value set here applies to CW and CCW rotation.
P1120 =	Rampup time 10.00 [s]
	Enter the time (in seconds) in which the motor is to accelerate from standstill to the maximum frequency (P1082). If the ramp-up time is too short, alarm A0501 (current limit value) may be output or the inverter is shut down with fault F0001 (overcurrent).
P1121 =	Rampdown time 10.00 [s]
	Enter the time (in seconds) during which the motor is to be decelerated (braked) from the maximum frequency (P1082) to standstill. If the ramp-down time is too short, alarm A0501 (current limit value) or A0502 (overvoltage limit value) may be output or the inverter is shut down with fault F0001 (overcurrent) or F0002 (overvoltage).

Table 4- 12 End quick commissioning (= start internal motor data calculation)

Parameter	Description
P3900 = 1	End quick commissioning 0: No quick commissioning (factory setting)
	 Quick commissioning incl. restoring factory settings Calculate the motor data with the quick commissioning parameters Restore the factory settings for the I/O Restore the factory settings for all other parameters
	 2: Quick commissioning incl. restoring the factory settings for the I/O. Calculate the motor data with the modified quick commissioning parameters Restore the factory settings for the I/O All the other parameters remain unchanged
	 3: Quick commissioning with motor data only - Calculate the motor data with the quick commissioning parameters - I/O settings remain unchanged - All the other parameters remain unchanged
	When P3900 = 1, 2, or 3, the value for P1082 is written to P2000.
	When quick commissioning is being completed, the message "bUSY" is displayed on the BOP. This means that the system is in the process of calculating the control data and saving the parameter values in the EEPROM.
	Once quick commissioning has been carried out, P3900 and P0010 are set to 0.
	When you press "FN" and "P" on the BOP, the actual frequency is displayed.

Commissioning

4.7 Data backup with the operator panel and memory card

4.7 Data backup with the operator panel and memory card

4.7.1 Saving and transferring data using the BOP

The operator panel as a medium to backup and transfer data

You can save a parameter set on the operator panel and transfer it to other inverters, e.g. to identically parameterize several devices or to transfer the settings after a device has been replaced.

Prerequisites for transferring data sets from the operator panel to a different inverter

The Control Unit to which the parameter set is transferred must be of the same type and have the same firmware release as the source Control Unit. (Same 'type' means: The same Order No.)

Saving the parameters on the operator panel (upload)

Parameters	Description	
P0003 = 3	3: Expert	
P0010 = 30	30: Initiating parameter transfer	
P0802 = 1	1: Transfer data from the EEPROM (of the inverter) to the operator panel	
	 If the upload procedure is successful, P0010 and P0802 are set to 0 and the "RDY" LED lights up. 	
	• If the download procedure is unsuccessful, F0055 or F0057 is displayed and the LED "SF" (red) lights up. In this case, make another attempt to transfer data.	

Table 4- 13Transfer data from the inverter to the operator panel

Transferring parameters from the operator panel into the inverter (download)

Table 4- 14	Transfer data from the operator panel to the inverter
-------------	---

Parameters	Description	
P0003 = 3	3: Access level 3	
P0010 = 30	30: Initiating parameter transfer	
P0803 = 1	1: Transfer data to the EEPROM (of the inverter) from the operator panel	
	 If the upload procedure is successful, P0010 and P0803 are set to 0 and the "RDY" LED lights up. 	
	 If the download procedure is unsuccessful, F0055 or F0057 is displayed and the LED "SF" (red) lights up. In this case, make another attempt to transfer data. 	

4.7 Data backup with the operator panel and memory card

4.7.2 Saving and transferring data using the MMC

The MMC memory card as a medium for backing up and transferring data

You can save a parameter set on the memory card and transfer it to other inverters, e.g. to identically parameterize several devices or to transfer the settings after a device has been replaced.

Data backup

The MMC is a removable, non-volatile flash memory for the parameter set of an inverter and does not require a power supply. For instance, this can be used to transfer parameter settings to a new inverter after the previous one was replaced.

We recommend that memory card MMC (Order No.: 6SL3254-0AM00-0AA0) should be used.

Prerequisites for transferring data sets from the MMC to a different inverter

The Control Unit to which the parameter set is transferred must be of the same type and have the same firmware release as the source Control Unit. (Same 'type' means: The same Order No.)

Backup the parameters on the MMC memory card (upload)

Parameters	Description		
Insert MMC			
A0564	When saving data, this alarm can be ignored.		
	This alarm is only displayed if the value of parameter P8458 = 1 or 2 and means that the MMC was inserted while the device was in operation and an MMC was not inserted when the inverter was booted.		
P0003 = 3	3: Expert		
P0010 = 30	30: Initiating parameter transfer		
P0802 = 2	2: Transfer data from the EEPROM (of the inverter) to the MMC. "RDY" LED flashes.		
	 If the upload procedure is successful, P0010 and P0802 are set to 0 and the "RDY" LED lights up. 		
	 If the download procedure is unsuccessful, F0061 or F0062 is displayed and the LED "SF" (red) lights up. In this case, make another attempt to transfer data. 		
Remove the MMC			

Table 4-15 Transferring data from the inverter to the memory card

Note

Time it takes to save the data

It can take several minutes to transfer data to the MMC memory card.

4.7 Data backup with the operator panel and memory card

Transferring the parameters from the MMC memory card into the inverter (download)

Parameters	Description		
P0003 = 3	3: Expert		
P0010 = 30	30: Initiating parameter transfer		
P0803 = 2	2: Transfer data to the EEPROM (of the inverter) from the MMC. "RDY" LED flashes.		
	• If the upload procedure is successful, P0010 and P0803 are set to 0 and the "RDY" LED lights up.		
	• If the download procedure is unsuccessful, F0061 or F0062 is displayed and the LED "SF" (red) lights up. In this case, make another attempt to transfer data.		

Table 4-16 Transferring data from the memory card to the inverter

5

Functions

5.1 Overview of inverter functions




Figure 5-1 Overview of inverter functions

Functions

5.1 Overview of inverter functions

Functions relevant to all applications



The functions that you require in each application are located at the center of the function overview above.

switch-on the motor, e.g. via digital inputs or a fieldbus.

entered, e.g. via an analog input or a fieldbus.

The parameters of these functions are provided with a matching basic setting during quick commissioning so that in many cases, the motor can be operated without requiring additional parameterization.

The setpoint source defines how the speed setpoint is for the motor is

Inverter control is responsible for all of the other inverter functions. Among other things, it defines how the inverter responds to external control signals.

The command source defines from where the control signals are received to



The **setpoint calculation** uses a ramp-function generator to prevent speed steps occurring and to limit the speed to a permissible maximum value.



The **motor closed-loop control** ensures that the motor follows the speed setpoint.

Functions required in special applications only



The functions, whose parameters you only have to adapt when actually required, are located at the outer edge of the function overview above.



The **production functions** avoid overloads and operating states that could cause damage to the motor, inverter and driven load. The motor temperature monitoring is, e.g. set here.



The **status messages** provide digital and analog signals at the digital outputs or via the fieldbus. Examples include the actual speed of the motor or fault message output by the inverter.



The **technological functions** allow you to activate a motor holding brake or implement a higher-level pressure or temperature control using the technology controller, for example.



The **safety functions** are used for applications that must fulfill special requirements placed on the functional safety. These are only available for fail-safe inverters.

Connection to a fieldbus



If you wish to operate the inverter on a fieldbus, then you must connect the following inverter functions with the fieldbus:

- Command sources
- Setpoint sources
- Status messages

A connection with a fieldbus can be established via software tools in the control systems. This manual includes descriptions of how you proceed for PROFIBUS and PROFINET with a SIMATIC control.

5.2 Inverter control

5.2 Inverter control

5.2.1 Frequency inverter control using digital inputs (two/three-wire control)

Configuring start, stop and direction of rotation reversal using digital inputs



If the inverter is controlled using digital inputs, using parameter P0727, you can define how the motor responds when it is started, stopped, and the direction of rotation is changed (reversing).

Five different methods are available for controlling the motor. Three of the five control methods just require two control commands (two-wire control). The other two control methods require three control commands (three-wire control).

The wide range of setting options is especially intended to be able to emulate existing control methods on the plant or system side if the inverter has to be integrated into an existing application. The two most common methods use the factory setting (P0727 = 0) and are available as standard in SINAMICS inverters.

Note

When clockwise rotation is activated, the inverter generates a clockwise voltage characteristic at its output terminals. Whether the connected motor actually rotates clockwise depends on the wiring between the inverter and motor.

Factory setting for "start", "stop", and "direction reversal" control commands

In the factory setting (P0727 = 0), the motor is operated using two control commands. In this case, two versions are available

Further methods for "start", "stop", and "direction reversal" control commands

Parameter P0727 offers three additional methods for controlling the motor.

- Method 3 for controlling the motor is ideal for drives where the direction of rotation is manually changed, for instance, traction drives that are controlled from a master switch. It functions similarly to method 2. Method 3 differs from method 2 with respect to how the motor responds when both control commands are present at the same time, and that it also allows you to change the direction of rotation at any time.
- Two further methods are available for controlling motors, each of which use three control commands. With these methods, the motor is no longer controlled via the signal level only but also with the positive signal edges of certain commands.

Just the same as method 3 of the two-wire control, the first three-wire control method is especially suitable for drives where the direction of rotation is manually reversed.

Control commands	Description
Motor Motor stops Motor Motor stops	
rotating rotating rotating CW CCW	
Two-wire control, method 1 (P0727=0)	
Motor on	1. Control command: Switch the motor on or off
Reverse motor	2. Control command: Reverses the motor direction of rotation
Two-wire control, method 2 (P0727=0) If CW and CCW rotation are selected simultaneously, th second signal is ignored. The motor cannot be reversed as long as it is still rotation	
Motor on, CW	1. Control command: Switch on or switch off the motor CW rotation
Motor on, CCW	2. Control command: Switch on or switch off the motor CCW rotation
Two-wire control, method 3 (P0727=1) When CW and CCW are simultaneously selected, the m Reversing is possible at any time.	notor is stopped.
Motor on, CW	1. Control command: Switch on or switch off the motor CW rotation
Motor on, AI I I CCW IIIIIIIIIIIIIIIIIIIIIIIIIIIIII	2. Control command: Switch on or switch off the motor CCW rotation

Table 5-1 Comparison of the methods for two-wire motor control

5.2 Inverter control




Table 5-2 Comparison of the methods for three-wire motor control

A detailed description of all of the methods to control a motor can be found in the following sections.

5.2.2 Two-wire control, method 1

Function description



This control method uses two control commands as permanent signals.

One control command starts/stops the motor, while the other control command changes the direction of rotation.




Figure 5-2 Two-wire control using digital inputs, method 1

Table 5-3 Function table

Motor ON	Reverse motor	Function
0	0	OFF1: The motor decelerates to a standstill
0	1	OFF1: The motor decelerates to a standstill
1	0	The motor accelerates to the setpoint
1	1	The motor accelerates to the inverted setpoint

Table 5-4	Parameterizing the function
-----------	-----------------------------

Parameter	Description	
P0700 = 2	Controls the motor using the digital inputs of the inverter	
P0727 = 0	Two-wire control, method 1 or 2	
P0701 = 1	The motor is power-up with digital input 0 Further options: The motor can be powered-up with any other digital input, e.g. with digital input 3 via P0704 = 1	
P0702 = 12	The motor is reversed with digital input 1 Further options: The motor can be reversed with any other digital input, e.g. with digital input 3 via P0704 = 12	

5.2 Inverter control

5.2.3 Two-wire control, method 2

Function description



This control method uses two control commands as permanent signals.

CW and CCW rotation of the motor is started and stopped with one control command each. To change the direction, the drive must first decelerate to 0 Hz with OFF1 before the direction reversal signal is accepted.




Figure 5-3 Two-wire control using digital inputs, method 2

Table 5	- 5	Function	table

Motor ON / CW	Motor ON / CCW	Function
0	0	OFF1: The motor decelerates to a standstill
0	1	The motor accelerates to the inverted setpoint
1	0	The motor accelerates to the setpoint
1	1	The first active signal has priority; the second signal is ignored.

Table 5- 6Parameterizing the function

Parameter	Description	
P0700 = 2	Controls the motor using the digital inputs of the inverter	
P0727 = 0	Two-wire control, method 1 or 2	
P0701 = 1	CW rotation is activated with digital input 0 Further options: CW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 1	
P0702 = 2	CCW rotation is activated with digital input 1 Further options: CCW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 2	

5.2.4 Two-wire control, method 3

Function description



This control method uses two control commands as permanent signals.

Like method 2, CW and CCW rotation can be started/stopped by one control command each. In contrast to method 2, however, the control commands can be switched at any time regardless of the setpoint, output frequency, and direction of rotation. The motor does not have to coast to 0 Hz either before a control command is executed.




Figure 5-4 Two-wire control using digital inputs, method 3

Motor ON / CW	Motor ON / CCW	Function
0	0	OFF1: The motor decelerates to a standstill
0	1	The motor accelerates to the inverted setpoint
1	0	The motor accelerates to the setpoint
1	1	OFF1: The motor decelerates to a standstill

Table 5-8 Parameterizing the function

Parameter	Description
P0700 = 2	Controls the motor using the digital inputs of the inverter
P0727 = 1	Two-wire control, method 3
P0701 = 1	CW rotation is activated with digital input 0 Further options: CW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 1
P0702 = 2	CCW rotation is activated with digital input 1 Further options: CCW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 2

5.2 Inverter control

5.2.5 Three-wire control, method 1

Function description



- The first control command is a permanent enable signal for starting the motor. When this enable signal is canceled, the motor stops.
- CW rotation is activated with the positive edge of the second control command.
- CCW rotation is activated with the positive edge of the third control command.




Figure 5-5 Three-wire control using digital inputs, method 1

Table 5- 9	Function table
------------	----------------

Enable signal	Motor ON / CW	Motor ON / CCW	Function
0	Not relevant	Not relevant	OFF1: The motor decelerates to a standstill
1	0→1	0	The motor accelerates to the setpoint
1	0	0→1	The motor accelerates to the inverted setpoint
1	0	0	No effect on the direction of rotation.
1	1	1	OFF1: The motor decelerates to a standstill

Table 5-10 Parameterizing the function

Parameter	Description
P0700 = 2	Controls the motor using the digital inputs of the inverter
P0727 = 2	Three-wire control, method 1
P0701 = 1	The enable signal to power-up the motor is issued with digital input 0 Further options: The enable signal can be issued with any other digital input, e.g. with digital input 3 via P0704 = 1
P0702 = 2	CW rotation is activated with digital input 1 Further options: CW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 2
P0703 = 12	CCW rotation is activated with digital input 2 Further options: CCW rotation can be activated with any other digital input, e.g. with digital input 3 via P0704 = 12

5.2.6 Three-wire control, method 2

Function description



- The first control command is a permanent enable signal for starting the motor. When this enable signal is canceled, the motor stops.
- The motor is started with the positive edge of the second control command.
- The third control command defines the direction of rotation.




Figure 5-6 Three-wire control using digital inputs, method 2

Enable signal	Motor ON	Reverse motor	Function when motor is at a standstill	Function when motor is rotating
0	Not relevant	Not relevant	No effect	OFF1: The motor decelerates to a standstill
1	0→1	0	The motor accelerates to the setpoint	No effect
1	0→1	1	The motor accelerates to the inverted setpoint	No effect
1	0	1→0	No effect	The motor reverses to the setpoint.
1	0	0→1	No effect	The motor reverses to the inverted setpoint.

Table 5-11 Function table

Functions

5.2 Inverter control

Parameter	Description
P0700 = 3	Controls the motor using the digital inputs of the inverter
P0727 = 3	Three-wire control, method 2
P0701 = 2	The enable signal to power-up the motor is issued with digital input 0Further options:The enable signal can be issued with any other digital input, e.g. with digital input 3via P0704 = 2
P0702 = 1	The motor is started with digital input 1 Further options: The motor can be started with any other digital input, e.g. with digital input 3 via P0704 = 1
P0703 = 12	The direction of the motor is reversed with digital input 2Further options:The direction of the motor can be reversed with any other digital input, e.g. withdigital input 3 via P0704 = 12

Table 5-12 Parameterizing the function

5.3 Command sources

5.3.1 Selecting command sources

Selecting the command source [P0700]



The motor is switched on/off via external inverter control commands. The following command sources can be used to specify these control commands:

- Operator control / display instrument (operator panel)
- Digital inputs
- Fieldbus

The command sources available depend on the inverter version.

- For inverters with a fieldbus interface, the 'fieldbus' (P0700 = 6) is pre-selected as the command source,
- For inverters without a fieldbus interface, the digital inputs (P0700 = 2) are pre-selected as command source.

Table 5-13	Parameters,	to select the source	for the inverter	control commands
------------	-------------	----------------------	------------------	------------------

Parameters	Description
P0700 =	 0: Factory default setting 1: Operator panel 2: Digital inputs (P0701 P0709), factory setting for an inverter without fieldbus interface 4: USS at RS 232 5: USS at RS 485 (not available for all inverters) 6: Fieldbus (P2050 P02091), factory setting for inverters with fieldbus interface.

5.3.2 Assigning functions to digital inputs

Assigning control commands to digital inputs as command sources [P0701...P0709]



The digital inputs are pre-assigned with certain control commands in the factory. However, these digital inputs can be freely assigned to a control command. Depending on the Control Unit version, SINAMICS inverters are equipped with up to 9 digital inputs.

 Table 5- 14
 Factory setting of the digital inputs

Terminal no.: Digital input no.	Control command	Available in CU
Terminal 5: Digital input 0 (DI0)	Switch motor on/off (ON/OFF1)	CU240E
Terminal 6: Digital input 1 (DI1)	Reverse direction of rotation	CU240S
Terminal 7: Digital input 2 (DI2)	Fault acknowledgment	CU240S DP CU240S PN
Terminal 8: Digital input 3 (DI3)	Selects fixed frequency 1	CU240S DP-F
Terminal 16: Digital input 4 (DI4)	Selects fixed frequency 2	CU240S PN-F
Terminal 17: Digital input 5 (DI5)	Selects fixed frequency 3	
Terminal 40: Digital input 6 (DI6)	Selects fixed frequency 4	CU240S
Terminal 41: Digital input 7 (DI7)	Locked	CU240S DP
Terminal 42: Digital input 8 (DI8)	Locked	CU240S PN

Table 5-15 Changing the digital input settings

Terminal no.: Digital input no.	Parameter	Description
	P0003 = 2	Extended access to the parameters
Terminal 5: Digital input 0 (DI0)	P0701 =	Possible values for P0701 to P0709:
		0: Digital input locked
Terminal 6: Digital input 1 (DI1)	P0702 =	1: Switch motor on/off (ON/OFF1)
		2: Activate motor CW
Terminal 7: Digital input 2 (DI2)	P0703 =	3: Motor coasts to standstill (OFF2) 4: Rapid stop with ramp (OFF3)
		9: Fault acknowledgement
Terminal 8: Digital input 3 (DI3)	P0704 =	10: Jog mode CW
		11: Jog mode CCW
Terminal 16: Digital input 4 (DI4)	P0705 =	12: Change direction of rotation (reverse)
		13: Increase frequency of motorized potentiometer
Terminal 17: Digital input 5 (DI5)	P0706 =	14: Increase frequency of motorized potentiometer
		15: Select fixed frequencies (bit 0)
Terminal 40: Digital input 6 (DI6)	P0707 =	16: Select fixed frequencies (bit 1)
· · · · · · · · · · · · · · · · · · ·		17: Select fixed frequencies (bit 2)
Terminal 41: Digital input 7 (DI7)	P0708 =	 18: Select fixed frequencies (bit 3) 25: Enable signal for DC brake
	1 07 00	27: Enable signal for PID technology controller
Terminal 42: Digital input 8 (DI8)	P0709 =	29: External fault
	1 0709	33: Disable additional frequency setpoint
		99: The digital input can be freely used for the BICO technology

If you enable one of the digital inputs to be freely used for BICO technology (P701...P709 = 99), then you must interconnect this digital input to the required control command.

If value 99 is assigned to the digital input to define its function, this can only be reversed by restoring the factory setting.

5.3.3 Controlling the motor via the fieldbus

Control commands via the fieldbus



To control the motor via the fieldbus, the inverter must be connected to a higher-level control via the STARTER software tool. For more information, see Chapter "Operation in fieldbus systems".

5.4 Setpoint sources

5.4 Setpoint sources

5.4.1 Selecting frequency setpoint sources

Selecting the setpoint source [P1000]



The speed of the motor can be set via the frequency setpoint. The following sources can be used to specify the frequency setpoint:

- Analog inputs
- Fixed frequency via digital inputs
- Motorized potentiometer
- Fieldbuses

The frequency setpoint sources available depend on the inverter version.

- For inverters with a fieldbus interface, the 'fieldbus' (P0700 = 6) is pre-selected as the frequency setpoint source.
- For inverters without fieldbus interface, the analog input (P0700 = 2) is pre-selected as the frequency setpoint source.

	Table 5-16	Settings to select the possible frequency setpoint sources
--	------------	--

Parameter	Description
P0003 = 1	Standard: Access to the most frequently used parameters
P1000 =	 No main setpoint MOP setpoint / motorized potentiometer (P1031 P1040) Analog setpoint (P0756 P0762), factory setting for inverters without fieldbus interface Fixed frequency (P1001 P1023) USS on RS 232 Fieldbus (P2050 P2091), factory setting for inverters with fieldbus interface

Adding setpoints from different sources

You can add several setpoints via frequency setpoint source P1000. For more information, see the List Manual (P1000 in the parameter list and function diagram 5000).

5.4.2 Using analog inputs as a setpoint source

Frequency setpoint via analog input [for P1000 = 2]



Analog setpoints are read-in via the corresponding analog inputs. The setting specifying whether the analog input is a voltage input (10 V) or current input (20 mA) must be made via P0756 and in addition using the DIP switches on the Control Unit housing.

Note

Only analog input 0 (AI0) can be used as a *bipolar* voltage input.

Depending on the AI type of the source, a suitable connection must be established.

Terminal No. and Significance		Parameters	Description			
		Setting the DIP switch	OFF: Voltage input (factory setting) ON: Current input			
3	AI0+	P0756 [0]	Analog input 1			
4	AI0-					
10	AI1+	P0756 [1]	Analog input 2			
11	AI1-					
		P0756 = 0	 Analog input type (AI) Defines the analog input type and enables analog input monitoring. 0: Unipolar voltage input (0 +10 V) (factory setting) 1: Unipolar voltage input with monitoring (0 +10 V) 2: Unipolar current input (0 mA20 mA) 3: Unipolar current input with monitoring (0 20 mA) 4: Bipolar voltage input (-10 +10 V) 			
		P0757 = 0	Value x1 for AI scaling [V or mA]			
		P0758 = 0.0	Value y1 of AI-scaling This parameter shows the amount of x1 as a % of P2000 (reference frequency)			
		P0759 = 10	Value x2 for AI scaling [V or mA]			
F		P0760 = 100	Value y2 of AI-scaling This parameter shows the amount of x2 as a % of P2000 (reference frequency)			
		P0761 = 0	Width of the AI dead zone			

 Table 5- 17
 Set and parameterize the analog input for use as setpoint source

5.4 Setpoint sources

Terminal No. Parameters and Significance		Parameters	Description		
Setting the DIP switch		-	OFF: Voltage input (factory setting) ON: Current input		
			OLE 1 7 24 V supply Track A 11 A 10 A 10 A 10 A 10 A 10 A 10 A 1		
3	AI0+	P0756 [0]	Analog input 1		
4	AI0-				
10	AI1+	P0756 [1]	Analog input 2		
11	AI1-				
		P0756 = 2	Analog input type (AI) 2: Unipolar current input (0 mA …20 mA)		
		P0757 = 4.0	Value x1 of AI scaling [mA]		
		P0758 = 0.0	Value y1 of AI scaling This parameter shows the amount of x1 as a % of P2000 (reference frequency)		
		P0759 = 20	Value x2 of AI scaling [mA]		
		P0760 = 100	Value y2 of Al-scaling This parameter shows the amount of x2 as a % of P2000 (reference frequency)		
	P761 = 4.0		Width of the AI dead zone		

Table 5- 18 Example: Scaling an analog input to 4 - 20 mA

5.4.3 Using a motorized potentiometer as a setpoint source

Frequency setpoint via motorized potentiometer (MOP) (when P1000 = 1 -> P1031)



The 'motorized potentiometer' function simulates an electromechanical potentiometer for entering setpoints. The value of the motorized potentiometer (MOP) can be set by means of the "up" and "down" control commands.

Table 5-19 Example: Implementing the motorized potentiometer using the Operator Panel keys

Parameter	Description		
P0700 = 1	1: Operator panels; ON and OFF buttons as well as "up" and "down" keys		
P1000 = 1	1: MOP setpoint		
P1031 = 0	Setpoint memory of the MOP The last motorized potentiometer setpoint that was active prior to the OFF command or shutdown can be saved. 0: MOP setpoint is not saved (factory setting) 1: MOP setpoint is saved in P1040		
P1032 = 1	Disable opposite direction of the MOP 0: Reverse direction of rotation is permitted 1: Reverse direction of rotation is locked (factory setting)		
P1040 = 5	Setpoint of the MOP Determines the setpoint [Hz] of the motorized potentiometer (MOP). Factory setting 5 Hz		
P2000 = 50	 Reference frequency (Hz); An output value of the MOP of 100 % corresponds to the frequency setpoint from P2000. P2000 should be changed, if a maximum frequency greater than 50 Hz is required. 		

Table 5-20 Example: Implementing a motorized potentiometer using digital inputs

Parameters	Description		
P0700 = 2	2: Digital inputs P0701P0709 (DI x ON/OFF1; DI y "up" and DI z "down")		
P0701 = 1	1: ON/OFF1		
P0702 = 13	13: MOP "up"		
P0703 = 14	14: MOP "down"		
P1000 = 1	1: MOP setpoint		
P1031 = 0	Setpoint memory of the MOP The last motorized potentiometer setpoint that was active prior to the OFF command or shutdown can be saved. 0: MOP setpoint is not saved (factory setting) 1: MOP setpoint is saved in P1040		
P1032 = 1	Disable opposite direction of the MOP 0: Reverse direction of rotation is permitted 1: Reverse direction of rotation is locked (factory setting)		
P1040 = 5	Setpoint of the MOP Determines the setpoint [Hz] of the motorized potentiometer (MOP); factory setting, 5 Hz		
P2000 = 50	Reference frequency (Hz); An output value of the MOP of 100 % corresponds to the frequency setpoint from P2000. P2000 should be changed, if a maximum frequency greater than 50 Hz is required.		

5.4 Setpoint sources

5.4.4 Using the fixed frequency as a setpoint source

Frequency setpoint via fixed frequency (P1000 = 3)



The fixed frequencies are defined using parameters P1001 to P1004 and can be assigned to the corresponding digital inputs using P1020 to P1023.

Parameters Description P1016 = 1 Fixed frequency mode, The fixed frequency can be selected using four digital defines the procedure inputs (factory setting: DI3 ... DI6) and combined (e.g. for selecting fixed summed). The factory settings support the following frequencies. additional combinations: 1: Direct selection Fixed Frequency FF- Par FF (factory setting) selected via [Hz] 2: Binary-coded selection P1001 (default = 0 Hz) DI3 (P1020 =722.3) 0 P1002 (default = 5 Hz) DI4 (P1021 =722.4) P1001 = 0 Fixed frequency 1 (FF1) 5 P1003 (default = 10 Hz) DI5 (P1022 =722.5) 10 (FF values in Hz) DI6 (P1023 =722.6) P1004 (default = 15 Hz) 15 P1002 = 5 Fixed frequency 2 P1001+P1002 DI3, DI4 5 ((FF2) P1001+P1003 DI3, DI5 10 P1001+P1004 DI3, DI6 15 P1003 = 10Fixed frequency 3 (FF3) P1002+P1003 DI4, DI5 15 P1004 = 15 P1003+P1004 Fixed frequency 4 (FF4) DI5. DI6 25 P1001+P1002+P1003 DI3, DI4, DI5 15 P1020 = 722.3 FF1 selection using DI3 DI3, DI4, DI6 P1001+P1002+P1004 20 P1001+P1003+P1004 P1021 = 722.4 FF2 selection using DI4 DI3, DI5, DI6 25 P1001+P1002+P1003+P1004 DI3, DI4, DI5, DI6 30 P1022 = 722.5 FF3 selection using DI5 P1023 = 722.6 FF4 selection using DI6

Table 5-21 Parameters to directly select frequencies

Additional information about binary coded selection of the fixed frequencies (P1016 = 2) is provided in function chart 3210 of the List Manual.

Table 5-22 Example: Selecting 2 fixed frequencies using digital input 2 and digital input 3

Parameter	Description		
P0003 = 3	Enable expert access to parameters		
P0700 = 2	Selecting the command source: Digital inputs		
P0701 = 1	ON/OFF1 (DI0) - factory setting		
P0702 = 12	Direction reversal (DI1) - factory setting		
P0703 = 99	Enable / 'open' digital input 2 (DI2)		
P0704 = 99	Enable / 'open' digital input 3 (DI3)		
P0705 = 99	Enable / 'open' digital input 4 (Dl4)		
P1001 = 4.00	Defines fixed frequency 1 (FF1) in [Hz]		
P1002 = 8.00	Defines fixed frequency 2 (FF2) in [Hz]		
P1020 = r0722.2 Connect fixed frequency 1(FF1) with the status of DI2.			
	r0722.2 = Parameter, which displays the status of digital input 2.		
P1021 = r0722.3	Connect fixed frequency 2(FF2) with the status of DI3.		
	r0722.3 = Parameter, which displays the status of digital input 3.		

5.4.5 Running the motor in jog mode (JOG function)

Run motor in jog mode [JOG function]



The JOG function enables you to carry out the following:

- Test the motor and inverter after commissioning to ensure that they function properly (the first traverse movement, direction of rotation etc.)
- Move a motor or motor load to a specific position
- Run a motor (e.g. following program interruption)

This function allows the motor to start up or rotate with a specific jog frequency. This function can normally be activated via the JOG button on the Basic Operator Panel,

When this function is enabled, the motor starts up ("ready for operation" status) when the JOG button is pressed and rotates at the set JOG frequency. When the button is released, the motor stops. This button has no effect when the motor is already running.

Parameters	Description		
P0003 = 2	2: Extended		
P1057 = 1	JOG enable		
	0: JOG function locked 1: JOG function enabled (factory setting)		
P1058 = 5	JOG frequency CW		
	0 Hz 650 Hz in JOG mode of motor in clockwise direction of rotation; 5 Hz (factory setting)		
P1059 = 5	JOG frequency CCW		
	0 Hz 650 Hz in the motor JOG mode in the counter-clockwise direction; 5 Hz (factory setting)		
P1060 = 10	JOG ramp-up time	f 🔺	
	0 s 650 s / 10 s (factory setting)	P1082 (fmax)	
	Ramp-up time (in seconds) from 0 to maximum frequency (P1082). The ramp-up procedure in JOG mode is limited by P1058 or P1059.	P1058	
P1061 = 10	JOG ramp-down time 0 s 650 s / 10 s (factory setting)	← P1060 → t	
	The ramp-down time in seconds from the highest frequency (P1082) to 0.		

Table 5-23 Example: Enabling the jog mode

5.4 Setpoint sources

Using BICO technology, you can also assign the JOG function to other keys.

Parameters	Description	
P0003 = 3	3: Expert	
P1055 =	Enable JOG CW	
	Possible sources: 722.x (digital inputs) / 19.8 (JOG key on the Operator Panel) / r2090.8 (serial interface)	
P1056 =	Enable JOG CCW	
	Possible sources: 722.x (digital inputs) / 19.8 (JOG key on the Operator Panel) / r2090.9 (serial interface)	

Table 5-24 Parameter to assign the JOG function to another button

5.4.6 Specifying the motor speed via the fieldbus

Specifying the motor speed via the fieldbus



To specify the speed of the motor via the fieldbus, the inverter must be connected to a higher-level control via the STARTER software tool. For more information, see "Operation in fieldbus systems".

5.5 Changing over the command data sets (manual, automatic)

Switching operating priority

In some applications, the inverter is operated from different locations.

Example: Switchover from the automatic mode into the manual mode A central control can switch a motor on/off or change its speed either via a fieldbus or via local switches. A key-operated switch close to the motor can be used to switch the operating priority of the inverter from "control via fieldbus" to "local control".

Command data set (CDS)

The inverter offers options to parameterize the settings for the command sources, setpoint sources and status messages (with the exception of analog outputs) in three different ways. The associated parameters are indexed (index 0, 1 or 2). When the inverter is operational, control commands select one of the three indices and therefore one of the three settings that has been saved. This means that as described in the example above, the master control of the inverter can be switched over.

All of the switchable parameters for command sources, setpoint sources and status messages with the same index is known as a "command data set".

5.5 Changing over the command data sets (manual, automatic)




Figure 5-7 CDS switchover in the inverter

The command data sets are switched over using parameters P0810 and P0811. Parameters P0810 and P0811 are interlinked to control commands, e.g. the digital inputs of the inverter, using BICO technology.

5.5 Changing over the command data sets (manual, automatic)

Status of P0810	0	1	0 or 1
Status of P0811	0	0	1
The CDS that is current active is gray.	CDS0	CDS1	CDS2
Selected parameter index	0	1	2
Examples	Fieldbus as setpoint source: The speed setpoint is specifed via the fieldbus.	Analog input as setpoint source: The speed setpoint is specifed via an analog	-
	Fieldbus as command source:	input. Digital inputs as command source:	-
	The motor is switched on/off via the fieldbus.	The motor is switched on/off via digital inputs.	

 Table 5- 25
 Command data set changeover using parameters P0810 and P0811.

Note

Command data sets can be switched in the "ready for operation" and "operation" state. The switchover time is approx. 4 ms.

Table 5- 26 Parameters for switching the command data sets:

Parameter	Description		
P0810 =	1st control command for switching the command data sets Example: When P0810 = 722.0, the system switches from command data set 0 to command data set 1 via digital input 0.		
P0811 =	2nd control command for switching the command data sets		
r0050	Displaying the number of the CDS that is currently active		
A copy function	A copy function is available making it easier to commission more than one command data set:		
P0809.0 =	Number of the command data set to be copied (source)		
P0809.1 =	Number of the command data set to which the data is to be copied (target)		
P0809.2 = 1	Start copying		

For an overview of all the parameters that belong to the drive data sets and can be switched, see the List Manual.

5.6 Setpoint preparation

Overview of setpoint calculation



The setpoint calculation modifies the speed setpoint, e.g. it limits the setpoint to a maximum and minimum value and using the ramp-function generator prevents the motor from executing speed steps.




Figure 5-8 Setpoint calculation in the inverter

5.6.1 Minimum frequency and maximum frequency

Limiting the speed setpoint

The speed setpoint is limited by both the minimum and maximum frequency.

Minimum frequency

When the motor is switched on, it accelerates to the minimum frequency regardless of the frequency setpoint. The set parameter value applies to both directions of rotation. In addition to its limiting role, the minimum frequency can be used as a reference value for various monitoring functions (e.g. if a motor holding brake is engaged when the minimum frequency is reached).

Maximum frequency

The frequency setpoint is limited to the maximum frequency in both directions of rotation. A message is output if the maximum frequency is exceeded.

The maximum frequency also acts as an important reference value for various inverter functions (e.g. the ramp-function generator).

Table 5- 27	Parameters	for minimum	and maximum	frequency
-------------	------------	-------------	-------------	-----------

Parameter	Description
P1080 =	Minimum frequency
P1082 =	Maximum frequency

5.6.2 Parameterizing the ramp-function generator

Parameterizing the ramp-function generator



The ramp-function generator in the setpoint channel limits the speed of setpoint changes. This causes the motor to accelerate and decelerate more smoothly, thereby protecting the mechanical components of the driven machine.

Ramp-up/down time

The ramp-up and ramp-down times of the ramp-function generator can be set independently of each other. The times that you select depend purely on the application in question and can range from just a few 100 ms (e.g. for belt conveyor drives) to several minutes (e.g. for centrifuges).

When the motor is switched on/off via ON/OFF1, the motor also accelerates/decelerates in accordance with the times set in the ramp-function generator.

Parameters	Description	
P1120 =	Ramp-up time Duration of acceleration (in seconds) from zero speed to the maximum frequency (P1082).	f (fmax) f1
P1121 =	Ramp-down time Duration of deceleration (in seconds) from the maximum frequency (P1082) to standstill.	← P1120 → ← P1121 → t

Table 5- 28 Parameters for ramp-up time and ramp-down time

The quick-stop function (OFF3) has a separate ramp-down time, which is set with P1135.

Note

If the ramp-up/down times are too short, the motor accelerates/decelerates with the maximum possible torque and the set times will be exceeded.

5.6 Setpoint preparation

Rounding

Acceleration can be "smoothed" further by means of rounding. The jerk occurring when the motor starts and when it begins to decelerate can be reduced independently of each other. Rounding can be used to lengthen the motor acceleration/deceleration times. The ramp-up/down time parameterized in the ramp-function generator is exceeded.

Rounding does not affect the ramp-down time in the event of a quick stop (OFF3).

Parameter	Description
P1130 =	Initial rounding time for ramp up (in seconds)
P1131 =	Final rounding time for ramp up (in seconds)
P1132 =	Initial rounding time for ramp down (in seconds)
P1133 =	Final rounding time for ramp down (in seconds)
P1134 =	Rounding type

Table 5- 29 Rounding parameters

For more information about this function, see the List Manual (function diagram 5300 and the parameter list).

5.7 Closed-loop control

Overview

There are two different open-loop and closed-loop control techniques for inverters used with synchronous and induction motors.

- Closed-loop control with V/f-characteristic (called V/f control)
- Field-oriented control technology (called vector control)

5.7.1 V/f control

5.7.1.1 Typical applications for V/f control



V/f control is perfectly suitable for almost any application in which the speed of induction motors is to be changed. Examples of typical applications for V/f control include:

- Pumps
- Fans
- Compressors
- Horizontal conveyors

Basic properties of V/f control

V/f control sets the voltage at the motor terminals on the basis of the specified speed setpoint. The relationship between the speed setpoint and stator voltage is calculated using characteristic curves. The inverter provides the two most important characteristics (linear and square-law). User-defined characteristic curves are also supported.

V/f control is not a high-precision method of controling the speed of the motor. The speed setpoint and the speed of the motor shaft are always slightly different. The deviation depends on the motor load. If the connected motor is loaded with the rated torque, the motor speed is below the speed setpoint by the amount of the rated slip. If the load is driving the motor (i.e. the motor is operating as a generator), the motor speed is above the speed setpoint.

5.7 Closed-loop control

5.7.1.2 V/f control with linear characteristic



Table 5- 30	Setting the control type
-------------	--------------------------

Parameter	Description
P0003 = 2	Extended access
P1300 = 0	Control type: V/f control with linear characteristic

Optimizing the starting characteristics for a high break loose torque and brief overload

The inverter can provide a higher voltage in the lower speed range and when accelerating. Examples of applications where this is necessary, include:

- Utilizing the brief overload capability of the motor when accelerating
- Driven machines with a high breakaway torque
- Holding a load

Background information: The linear characteristic of the V/f control assumes an ideal motor without resistive losses. The resistive losses in the motor stator resistance and in the motor cable reduce the available torque and must not be neglected in all applications. These losses play a more significant role the smaller the motor and the lower the motor speed. The losses can be compensated by the V/f control by increasing the voltage at low speeds. (so-called 'boost parameters': P1310 and P1311)

Note

Only increase the voltage boost in small steps until satisfactory motor behavior is reached. Excessively high values in P1310 and P1311 can cause the motor to overhead and switch off (trip) the inverter due to overcurrent.

Parameters	Description
P0003 = 2	Extended access
P1310 =	Voltage boost to compensate resistive losses The voltage boost is effective for all speeds below the rated speed and continually decreases as the speed increases. The maximum voltage boost is effective at zero speed and is in V: Rated motor current (P305) × stator resistance (P350) × P1310 /100
P1311 =	Voltage boost when accelerating The voltage boost is effective from standstill up to the rated speed. The voltage boost is independent of the speed. The voltage boost in V is: Rated motor current (P305) × stator resistance (P350) × P1311 /100

Table 5- 31	Optimizing the starting characteristics for a linear characteristic
-------------	---

Additional information about this function is provided in the parameter list and in the function diagrams 6100 and 6200 in the List Manual.

5.7.1.3 V/f control with parabolic characteristic



Note

V/f control with a parabolic characteristic must not be used in applications in which a high torque is required at low speeds.

Table 5- 32 Setting the control type

Parameter	Description	
P0003 = 2	Extended access	
P1300 = 2	Control type: V/f control with parabolic characteristic	

5.7.1.4 Additional characteristics for the V/f control



In addition to linear and square-law characteristics, there are the following additional versions of the V/f control that are suitable for special applications.

Table 5-33 Further V/f control methods (P1300)

Parameter value	Application			
P1300 = 1	Linear V/f characteristic with Flux Current Control (FCC) Voltage losses across the stator resistance are automatically compensated. This is particularly useful for small motors since they have a relatively high stator resistance. The prerequisite is that the value of the stator resistance in P350 is parameterized as accurately as possible.			
P1300 = 3	Freely adjustable V/f characteristic, which supports the torque behavior of synchronous motors (SIEMOSYN motors)			
P1300 = 5 P1300 = 6	 Linear V/f characteristic for textile applications where it is important that the motor speed is kept constant under all circumstances. This setting has the following effects: 1. When the maximum current limit is reached, the stator voltage is reduced but not the speed. 2. Slip compensation is locked. 			
P1300 = 19	V/f control without characteristic. The interrelationship between the frequency and voltage is not calculated in the inverter, but is specified by the user. With BICO technology, P1330 defines the interface via which the voltage setpoint is entered (e.g. analog input \rightarrow P1330 = 755).			

For more information about this function, see function diagrams 6100 and 6200 in the List Manual.

5.7 Closed-loop control

5.7.2 Vector control

5.7.2.1 Typical applications for vector control



The vector control can be used to control (closed-loop) the speed and the torque of a motor.

Vector control is used in many cases without directly measuring the motor speed. This closed-loop control is known as sensorless vector control. The vector control is also used with a speed encoder in special applications.

Vector control in comparison to V/f control

When compared to V/f control, vector control offers the following advantages:

- The speed is more stable for motor load changes
- Shorter accelerating times when the setpoint changes
- Acceleration and braking are possible with an adjustable maximum torque
- Improved protection of the motor and the driven machine as a result of the adjustable torque limiting
- The full torque is possible at standstill

Vector control must not be used in the following cases:

- If the motor is too small in comparison to the inverter (the rated motor power may not be less than one quarter of the rated inverter power)
- If the maximum frequency is more than 200 Hz
- If several motors are connected to one inverter
- If a power contactor is used between the inverter and motor and is opened while the motor is powered-up

Typical applications for vector control with and without speed encoder

Vector control is typically used for the following applications:

- Hoisting gear and vertical conveyor belts
- Winders
- Extruders

5.7.2.2 Commissioning vector control



Vector control with and without speed encoder requires careful commissioning and therefore must only be performed by commissioning engineers that are experienced in handling this type of control.

Steps when commissioning the vector control

- Carry out quick commissioning (P0010 = 1) In order to ensure that the vector control functions perfectly, it is absolutely imperative that the motor data is entered correctly
- 2. Run the motor data identification (P1900 = 2) The motor data identification must be carried out with the motor in the cold state. The motor data identification must be carried out after the quick commissioning as the quick commissioning supplies output data for the motor model and the motor data identification makes these even more precise
- 3. Carry out the automatic speed controller optimization (P1960 = 1)

Parameter	Description
P0003 = 2	Extended access
P1300 = 20	Control type: Vector control without speed encoder
P0300 P0360	Motor data are transferred from the motor rating plate during the quick commissioning and calculated with the motor data identification
P1442 P1496	Speed controller parameters
P1511 =	Additional torque
P1520 =	Upper torque limit
P1521 =	Lower torque limit
P1530 =	Motoring power limit
P1531 =	Regenerative power limit

Table 5- 34The most important vector control parameters

For more information about this function, refer to the parameter list as well as the function diagrams 7000, 7500, 7700, 7800 and 7900 in the List Manual.

You will find additional information in the Internet (http://support.automation.siemens.com/WW/view/en/7494205):

5.7 Closed-loop control

5.7.2.3 Torque control



Torque control is part of the vector control and normally receives its setpoint from the speed controller output. By deactivating the speed controller and directly entering the torque setpoint, the closed-loop speed control becomes closed-loop torque control. The inverter then no longer controls the motor speed, but the torque that the motor generates.

Typical applications for torque control

The torque control is used in applications where the motor speed is specified by the connected driven load. Examples of such applications include:

- Load distribution between master and slave drives: The master drive is speed controlled, the slave drive is torque controlled
- Winding machines

Steps when commissioning the torque control

- Carry out quick commissioning (P0010 = 1) In order to ensure that the torque control functions perfectly, it is absolutely imperative that the motor data is entered correctly.
- 2. Run the motor data identification (P1900 = 2) The motor data identification must be carried out with the motor in the cold state. The motor data identification must be carried out after the quick commissioning as the quick commissioning supplies output data for the motor model and the motor data identification makes these even more precise.

Parameter	Description	
P0003 = 2	Extended access	
P1300 =	Control type: 20: Vector control without speed encoder 21: Vector control with speed encoder	
	22: Torque-vector control without speed encoder23: Torque-vector control with speed encoder	
P0300 P0360	Motor data are transferred from the motor rating plate during the quick commissioning and calculated with the motor data identification	
P1511 =	Additional torque	
P1520 =	Upper torque limit	
P1521 =	Lower torque limit	
P1530 =	Motoring power limit	
P1531 =	Regenerative power limit	

Table 5-35 The most important torque control parameters

Additional information about this function is provided in the parameter list and in the function diagrams 7200, 7700 and 7900 in the List Manual.

5.7.2.4 Using a speed encoder

Higher accuracy by using a speed encoder



A speed encoder increases the accuracy of the speed and the torque of the vector control for speeds below approx. 10% of the rated motor frequency.

Commissioning the speed encoder

A speed encoder requires the following commissioning steps:

- 1. Connect the speed encoder (see below).
- 2. Set the encoder voltage using the DIP switches on the CU (see below).
- 3. Set the speed encoder parameters (see below).
- 4. Set the inverter to V/f control (P1300 = 0).
- 5. Power-up the motor with an average speed.
- 6. Compare parameters r0061 (speed encoder signal in Hz) and r0021 (calculated speed in Hz) regarding the sign and absolute value.
- 7. If the signs do not match, invert the speed encoder signal (P0410 = 1).
- 8. If the absolute value of the two values do not correspond, check P0408, the speed encoder wiring and the setting of the corresponding DIP switch.
- 9. Switch over to a control type with speed encoder: P1300 = 21 or P1300 = 23.

Connect the speed encoder

An encoder can only be connected to CU240S, CU240S DP, CU240S DP-F, CU240S PN or CU240S PN-F.

Only encoders with two pulse tracks A and B offset through 90° may be connected.

Terminal	Designation	Function
28	U0V OUT	Reference potential of the power supply voltage (terminal 9)
33	ENC+ SUPPLY	Supply voltage for the encoder
70	ENC AP	Pulse track A, non-inverting input
71	ENC AN	Pulse track A, inverting input
72	ENC BP	Pulse track B, non-inverting input
73	ENC BN	Pulse track B, inverting input
74	ENC ZP	Zero signal, non-inverting input
75	ENC ZN	Zero signal, inverting input

Table 5-36 Terminals on the CU to connect the speed encoder

Use a shielded cable to connect the speed encoder. The shield must not be interrupted by terminal points between the encoder and inverter.

Setting the encoder voltage

The encoder voltage is set using the DIP switches at the front of the CU. If you use either a BOP or a PC Connection Kit, you must remove this module in order to be able to access the switches.

Table 5- 37	Encoder settings

Encoder type	Setting the DIP switches* at the front of the CU									
No encoder		ON	AIO	AI1	24 V supply	5 V supply	Terminate Track A	Terminate Track B	Terminate Track N	
			1	2	3	4	5	6	7	
TTL encoder **		ON								
Supply voltage: 5 V			A10	AI1	24 V supply	5 V supply	Terminate Track A	Terminate Track B	Terminate Track N	
		OFF	1				5		7	
HTL encoder		ON		2	3	4	<u> </u>	6		
Supply voltage: 24 V			AIO	AI1	24 V supply	5 V supply	Terminate Track A	Terminate Track B	Terminate Track N	
		OFF	1	2		4	5	6	7	
*) DIP switches 1 and 2 are of no significance when setting the encoder voltage										
**) When using standard TTL encoders, it is recommended that DIP switches 5, 6 and 7 are set to OFF. If TTL encoders with a differential circuit are being used, and if a long cable is required (more than 50 meters), then DIP switches 5, 6, and 7 can be set to ON.										

If DIP switch 3 is set to ON (24 V), a TTL encoder (voltage level 5 V) must not be connected to the inverter.

Parameter	Description			
P0003 = 2	Extended access			
P0400 =	 Selecting the encoder type 0: Encoder signal is not evaluated 2: Encoder with pulse tracks A and B without zero pulse 12: Encoder with pulse tracks A, B and zero pulse 			
P0408 =	Number of encoder pulses per revolution			
P0410 =	 Reversing the internal sense of rotation 0: The encoder signal is not influenced 1: The encoder signal is inverted 			
P0491 =	 Loss of speed response (response when the speed signal is lost) 0: Motor is shut down with fault message F0090 1: Alarm and switch to SLVC, if in SVC 			
P0492 =	Permissible speed difference to monitor the encoder signal (F0090)			
P0494 =	Delay time of the loss of speed (delayed response when the speed signal is lost)			
P1300 = 21 or P1300 = 23	Control type: 21: Vector control with speed encoder 23: Torque-vector control with speed encoder			

Table 5- 38The most important speed encoder parameters

5.8 Protection functions

The frequency inverter offers protective functions against overtemperature and overcurrent for both the frequency inverter as well as the motor. Further, the frequency inverter protects itself against an excessively high DC link voltage when the motor is regenerating.

The load torque monitoring functions provide effective plant and system protection.

5.8.1 Overtemperature protection for the frequency inverter and motor

フ

Parameter s	Description	
P0003 = 3 User access level		
	3: Expert	
P0290 = 2	Temperature monitoring of the Power Module This defines the response of the inverter to an internal overtemperature .	
	 0: Reduce the output frequency 1: Shutdown (F0004) 2: Reduce pulse frequency and output frequency (factory setting) 3: Reduce pulse frequency, then shut down (F0004) 	
P0292 Parameterizes the alarm threshold for heatsink and module temperature mo (Power Module)		

Temperature monitoring for the motor

Two options are available for implementing thermal motor protection:

- Temperature sensing in the motor with PTC sensor, KTY 84 sensor or ThermoClick sensor
- Temperature calculation without sensors by analyzing the rating plate data and ambient temperature of the motor. (Only possible in the 'vector control' mode)

Temperature sensing using a temperature sensor

Parameters	Description		
P0003 = 2	User access level 2: Extended		
P0335 = 0	 Specify the motor cooling 0: Self-ventilated* - with fan on the motor shaft (IC410* or IC411*) - (factory setting) 1: Forced ventilation* - with a separately driven fan (IC416*) 2: Self-ventilated* and inner cooling* (open-circuit air cooled) 3: Forced ventilated* and inner cooling* (open-circuit air cooled) 		
P0601 = 0	Specify the motor temperature sensor 0: No sensor (factory setting; → P0610) 1: PTC thermistor (→ P0604) 2: KTY84 (→ P0604) 4: ThermoClick sensor		
P0604 =	Motor overtemperature alarm threshold (0°C 220°C, factory setting 130°C) Enter the alarm threshold for motor overtemperature protection. The shutdown temperature threshold (alarm threshold + 10 %) is the value at which either the inverter is shut down or I_{max} is reduced (P0610).		
	This parameter is only visible, if P0003 = 3!		
P0610 = 2	Response for motor overtemperature I ² t Defines the behavior as soon as the motor temperature reaches the alarm threshold.		
	 0: No response, alarm only 1: Alarm and reduction of I_{max} (reduces the output frequency) 2: Fault and shutdown (F0011) (factory setting) 		
P0640	Motor overload factor (entered in % referred to P0305: rated motor current)		

 Table 5- 39
 Parameters to sense the temperature using a temperature sensor

*You will find detailed information on classifying the cooling technique in EN 60034-6

Temperature measurement without temperature sensor

This temperature calculation is only possible in the vector control mode (P1300 = 20/21/22/23) and functions by calculating a thermal motor model.

Table 5- 40 Parameter to sense the temperature without using a temperature sensor

Parameters	Description		
P0621 = 1	Motor temperature measurement after restarting		
	0: No identification (factory setting)1: Temperature measurement after the first "motor ON"2: Temperature measurement after each "motor ON".		
P0622 =	Magnetization time of the motor for temperature measurement after starting (set automatically as the result of motor data identification)		
P0625 = 20	Ambient motor temperature Enter the ambient motor temperature in [°] C at the instant that the motor data is acquired (factory setting: 20°C).		
	The difference between the motor temperature and motor environment (P0625) must lie within a tolerance range of approx. \pm 5 °C.		

5.8.2 Overcurrent protection

Method of operation



The maximum current controller (I_{max} controller) protects the motor and inverter against overload by limiting the output current. The I_{max} controller is only active with V/f control.

If an overload situation occurs, the speed and stator voltage of the motor are reduced until the current is within the permissible range. If the motor is in regenerative mode, i.e. it is being driven by the connected machine, the I_{max} controller increases the speed and stator voltage of the motor to reduce the current.

Note

The inverter load is only reduced if the frequency is reduced with a lower load and at lower speeds (e.g. parabolic torque-speed characteristic of the motor load).

In the regenerative mode, the current only decreases if the torque decreases at a higher frequency.

Settings

NOTICE

The factory setting of the I_{max} controller only needs to be changed in exceptional cases by appropriately trained personnel.

Table 5-41	Imax controller parameters
------------	----------------------------

Parameter	Description	
P0003 = 3	User access level 3: Expert	
P0305 =	Rated motor current	
P0640 =	Maximum permissible motor overload referred to P0305 rated motor current	
P1340 =	Proportional gain of controller for frequency reduction	
P1341 =	Integral time of controller for frequency reduction	
P1345 =	Proportional gain of controller for voltage reduction	
P1346 =	Integral time of controller for voltage reduction	
r0056 bit13	Status: Imax controller active	
r1343	Frequency output of I _{max} controller Shows the amount to which the I-max controller reduces the inverter output frequency.	
r1344	Voltage output of I _{max} controller Shows the amount by which the I-max controller reduces the inverter output voltage.	

For more information about this function, see function diagram 6100 in the List Manual.

5.8.3 Limiting the maximum DC link voltage

How does the motor generate overvoltage?



An induction motor can operate as a generator if it is driven by the connected load, In this case, the motor converts mechanical energy into electrical energy. The motor feeds the regenerative energy back to the inverter.

As a consequence, the DC link voltage is increased. The inverter can only reduce the increased DC link voltage if it is capable of regenerative feedback into the line supply or is equipped with a braking resistor.

Without being capable of regenerating into the line supply, only extremely low or brief regenerative loads – relative to the inverter power – are possible because the inverter may be damaged if the DC link voltage reaches critical levels. Before the voltage can reach critical levels, however, the inverter shuts down with the fault message "DC link overvoltage".

Protecting the motor and inverter against overvoltage

The V_{DCmax} controller prevents – as far as is technically possible – the DC link voltage from reaching critical levels.

The V_{DCmax} controller is not suitable for applications in which the motor is permanently in the regenerative mode, e.g. in hoisting gear or when large flywheel masses are subject to braking. For applications such as these, you must select an inverter that is equipped with a braking resistor or that can feed energy back into the line supply (e.g. PM250 and PM260)

Parameter	Description		
P0003 = 3	User access level 3: Expert		
P1240 =	Enables the V _{DCmax} controller 1: Enables the V _{DCmax} controller 3: Enables the V _{DCmax} controller with kinetic buffering		
r1242	Shows the value of the DC link voltage above which the V _{DCmax} controller is active		
P1243 =	Multiplier for the output of V_{DCmax} controller (scaling of the V_{DCmax} controller output)		
P1250 =	Proportional gain of the V _{DCmax} controller		
P1251 =	Integral time of the V _{DCmax} controller		
P1252 =	Derivative time of the V _{DCmax} controller		
P1253 =	Limits the output of the V _{DCmax} controller		
P1254 =	Activates or deactivates automatic detection of the switch-on levels of the $V_{\mbox{\scriptsize DCmax}}$ controller		

Table 5- 42 V_{DCmax} controller parameters

For more information about this function, see function diagram 4600 in the List Manual.

5.8.4 Load torque monitoring (system protection)

Applications with load torque monitoring

In many applications, it is advisable to monitor the motor torque:

- Applications in which the mechanical connection between the motor and load may be interrupted (e.g. if the drive belt in fan or conveyor belt systems tears).
- Applications that are to be protected against overload or locking (e.g. extruders or mixers).
- Applications in which no-load operation of the motor represents a critical situation (e.g. pumps).

Load torque monitoring functions

The inverter monitors the torque of the motor in different ways:

- 1. No-load monitoring: The inverter generates a message if the motor torque is too low.
- Lock protection: The inverter generates a message if the motor speed cannot match the speed setpoint despite maximum torque.
- Stall protection: The inverter generates a message if the inverter control has lost the orientation of the motor.
- 4. Frequency-dependent torque monitoring: The inverter measures the current torque and compares it with a parameterized frequency/torque characteristic.

Parameter	Description			
No-load monit	oring			
P2179 =	Current limit for no-load detection			
	If the inverter current is below this value, the message "no load" is output.			
P2180 =	Delay time for the "no load" message			
Lock protectio				
P2177 =	Delay time for the "motor locked" message			
Stall protection	<u>ו</u>			
P2178 =	Delay time for the "motor stalled" message			
P1745 =	Deviation of the setpoint from the actual value of the motor flux as of which the "motor stalled" message is generated This parameter is only evaluated as part of encoderless vector control.			
Frequency-de	pendent torque monitoring			
P2181 =	Enable signal for function			
P2182 =	Frequency threshold 1			
P2183 =	Frequency threshold 2			
P2184 =	Frequency threshold 3			
P2185 =	Upper torque threshold for frequency threshold 1			
P2186 =	Lower torque threshold for frequency threshold 1			
P2187 =	Upper torque threshold for frequency threshold 2			
P2188 =	Lower torque threshold for frequency threshold 2			
P2189 =	Upper torque threshold for frequency threshold 3			
P2190 =	Lower torque threshold for frequency threshold 3			
P2192 =	Delay time for the message "Leave torque monitoring tolerance band"			
P2189 Upper torque thres P2190 Lower torque thres				
P2187 Upper torque threst P2188 Lower torque threst Upper torque threst P2186 Lower torque threst	hold 2 hold 1 hold 1 hold 1			
	P2182 Threshold frequency 2 P2184 [Hz] Threshold frequency 3			

Table 5- 43Parameterizing the monitoring functions

For more information about these functions, see the List Manual (function diagrams 4110, 4130, and 4140 as well as the parameter list).

5.9 Evaluating the frequency inverter status

5.9 Evaluating the frequency inverter status

Frequency inverter states, such as alarms or faults or different actual value quantities of the frequency inverter can be displayed using digital and analog outputs. The pre-assignments (default settings) can be adapted to the particular plant or system requirements as explained in the following descriptions.

5.9.1 Assigning specific functions to digital outputs

Assigning specific functions to digital outputs



Three digital outputs are available that can be programmed to display different inverter states, e.g. faults, alarms, current limit value violations etc.

Table 5-44 Factory setting of the digital outputs

Term	Terminal No., significance		Function
18	NC	Digital output 0	Inverter fault active
19	NO		
20	COM		
21	NO	Digital output 1	Inverter alarm active
22	COM		
23	NC	Digital output 2	Digital output deactivated
24	NO]	
25	COM		

Functions

5.9 Evaluating the frequency inverter status

Terminal No., significance Parameter		Parameter	Description	
			P0003 = 2	Extended parameter access
18	NC	Digital output 0	P0731	Possible values and functions for P0731, P0732
19	NO			and P0732:
20	COM			ValueFunction
21	NO	Digital output 1	P0732	0 Deactivate digital output
22	COM			52.0 Drive ready 52.1 Drive ready for operation
23	NC	Digital output 2	P0733	52.2 Drive running
24	NO		1 01 00	52.3 Drive fault active
25	COM	M		52.4 OFF2 active
				52.5 OFF3 active 52.6 Switching on inhibited
				52.7 Drive alarm active
				52.8 Setpoint/actual value deviation
				52.9 PZD control
				52.10 f_act >= P1082 (f_max)
				52.11 Alarm: Motor current/torque limiting 52.12 Brake active
				52.13 Motor overload
				52.14 Motor CW rotation
				52.15 Inverter overload
				53.0 DC brake active
				53.1 f_act < P2167 (f_off)
				53.2f_act > P1080 (f_min)
				53.3 Current actual value r0027 ≥ P2170
				53.6 f_act \geq setpoint (f_set)
			P0748	Inverting digital outputs
				Bit 0:Digital output 0
				Bit 1:Digital output 1
				Bit 2:Digital output 2

Table 5- 45 Setting the functions of the digital outputs

Further, the digital outputs can be interconnected with all binector outputs. A list of the binector outputs is provided in the List Manual.

5.9 Evaluating the frequency inverter status

5.9.2 Assigning certain functions to analog outputs

Assigning specific functions to analog outputs



Two analog outputs are available, which can be parameterized to display a multitude of variables, e.g. the actual speed, the actual output voltage or the actual output current.

Table 5-46 Factory setting of the analog outputs

Term	Terminal No., significance		Function
12	AO0+	Analog input 0	Actual speed
13	AO0-		
26	AO1+	Analog input 1	Actual speed
27	AO1-		

Table 5- 47 Changing the functions of the analog outputs

Terminal No., significance Paramet		Parameter	Description	
12	AO0+	Analog input 0	P0771	Possible values and functions for P0771, Ind 0
13	AO0-		[Ind 0]	and Ind 1:
26	AO1+	Analog input 1	P0771	ValueFunction
27	A01-		[Ind 1]	21: CO actual frequency (factory setting; scaled corresponding to P2000)
				24: CO actual output frequency (scaled corresponding to P2000)
				25: CO actual output voltage (scaled corresponding to P2001)
				26: CO actual value of the DC link voltage (scaled corresponding to P2001)
				27: CO actual output current (scaled corresponding to P2002)

The analog outputs can also be interconnected with all connector outputs. A list of the connector outputs is provided in the List Manual.

5.9 Evaluating the frequency inverter status

Parameter	Description		
P0775 = 0	Permit absolute value		
	Specifies whether or not the absolute value of the analog output is used. If enabled, this parameter will use the absolute value of the value to be output. If the original value was negative, the corresponding bit is set in r0785.		
P0776 = 0	Analog output type		
	Scaling of r0774. 0: Current output (factory setting) 1: Voltage output		
	Note: P0776 changes the scaling of r0774 (0 to 20 mA \Leftrightarrow 0 to 10 V). The scaling parameters P0778 and P0780 as well as the dead band are always entered with 0 to 20 mA. Analog output 0 can be switched as a voltage output between 0 and 10 V. Analog output 1 is a current output only. If it is to be used as a voltage output, it must be terminated with a 500 Ω resistor.		
P0777 = 0.0	Value x1 for analog output scaling		
	Defines output characteristic x1 (in %). This parameter is the minimum analog value expressed as a percentage of P200x (depending on how P0771 is set).		
P0778 = 0	Value y1 for analog output scaling	mA	
	This parameter is the value of x1 (in mA).	20	
P0779 = 100	Value x2 for analog output scaling	P0780	
	This defines x2 of the output characteristic as a percentage. This parameter is the maximum analog value expressed as a percentage of P200x (depending on how P0771 is set).	P0780 y2 P0778 y1	
P0780 = 20	Value y2 for analog output scaling	0 P0777 P0779 100% %	
	This parameter is the value of x2 (in mA).		
P0781 = 0	Dead band width of the analog output		
	This can be used to set the width of the dead band for the analog output (in mA).		

Table 5-48 Additional analog output settings

Functions

5.10 Technological functions

5.10 Technological functions

The inverter offers the following technological functions:

- Braking functions
- Automatic restart and flying restart
- Basic process control functions
- Positioning down ramp
- Logical and arithmetic functions using function blocks that can be freely interconnected

Please refer to the following sections for detailed descriptions.

5.10.1 Braking functions of the frequency inverter



A differentiation is made between electrically braking and mechanically braking a motor:

- The motor is electrically braked by the inverter. An electrical braking is completely wearfree. Generally, a motor is switched off at standstill in order to save energy and so that the motor temperature is not unnecessarily increased.
- Mechanical brakes are generally motor holding brakes that are closed when the motor is at a standstill. Mechanical operating brakes, that are closed while the motor is rotating are subject to a high wear and are therefore often only used as an emergency brake.

Electrical braking and regenerative energy

If an induction motor electrically brakes the connected load and the kinetic energy that is released exceeds the mechanical and electrical losses, then it operates as a generator. In this case, the motor converts kinetic energy into electrical energy. Examples of typical applications, in which regenerative operation briefly occurs, include:

- Grinding disk drives
- Fans

For certain drive applications, the motor can operate in the regenerative mode for longer periods of time. Examples include:

- Centrifuges
- Cranes
- Conveyor belts with downward movement of load

Inverter braking methods

Depending on the particular application and the inverter type, there are different technologies to handle regenerative energy.

- The regenerative energy is converted into heat in the motor (DC and compound braking)
- The inverter converts the regenerative energy to heat using a braking resistor (dynamic braking)
- The inverter feeds the regenerative energy back into the line supply (regenerative braking)

Different electrical braking methods for different applications

Table 5- 49	Braking methods and	Power Modules	depending on	the application

Application examples	Electrical braking method	Power Modules that can be used
Pumps, fans, compressors, extruders, mixers	Not necessary	PM240, PM250, PM260
Fans, grinding machines, conveyor belts	DC braking, compound braking	PM240
Centrifuges, vertical conveyors,	Dynamic braking	PM240
hoisting gear, cranes, winders	Regenerative braking	PM250, PM260

Braking methods depending on the drive inverter being used

Table 5- 50	Power Modules depending on the braking method
-------------	---

	SINAMICS G120 Power Module		
	PM240	PM250	PM260
DC and compound braking	Х		
Dynamic braking	Х		
Regenerative braking		Х	Х

Advantages and disadvantages of the braking methods

- DC braking
 - Advantage: The motor is braked without the inverter having to convert the braking energy
 - Disadvantages: significant increase in the motor temperature; no defined braking characteristics; no constant braking torque; no braking torque at standstill; braking energy is lost as heat; does not function when the power fails
- Compound braking
 - Advantage: Defined braking characteristics, the motor is braked without the inverter having to convert any significant amount of braking energy
 - *Disadvantages:* no constant braking torque; excessive motor temperature rise; braking energy is dissipated as heat; does not function when the power fails

- Dynamic braking
 - Advantages: defined braking characteristics; no additional motor temperature increase; constant braking torque; in principle, also functions when the power fails
 - Disadvantages: A braking resistor is required; braking energy is lost as heat; the permissible load of the braking resistor must be taken into account
- Regenerative braking
 - Advantages: Constant braking torque; the regenerative energy is not converted into heat, but is regenerated into the line supply; can be used in all applications; continuous regenerative operation is possible - e.g. when lowering a crane load
 - Disadvantage: Does not function when power fails

5.10.1.1 DC and compound braking

Application areas for DC braking and compound braking



DC braking and compound braking are typically used for applications in which the motor is normally operated at a constant speed and is only braked down to standstill in longer time intervals, e.g. centrifuges, saws, grinding machines and conveyor belts.

Operating characteristics of DC braking




Figure 5-9 DC braking after an OFF1 or OFF3 command

DC braking after an OFF1 or OFF3 command has the following timing sequence:


- 1. Initially, the motor speed is reduced along the down ramp of the ramp-function generator until an adjustable speed threshold is reached.
- 2. Once the motor speed reaches this threshold, the inverter interrupts the braking operation using an internal OFF2 command until the motor is de-magnetized.
- 3. The inverter then starts the actual DC braking by allowing a DC current to flow through the motor. The magnitude and duration of the DC current can be set.

For DC braking, the kinetic energy of the motor and motor load is partially converted into thermal energy. The motor can overheat if braking lasts too long or the drive must be braked too frequently.

Parameterizing DC braking

Parameter s	Description
P003= 3	User access level
	3: Expert
P1230	Enabling DC braking using an external command
	Enables DC braking via a signal that was used by an external source (BICO). The function remains active as long as the external signal is active.
P1232=	Current, DC braking (entered as a %)
	Defines the strength of the direct current in [%] with respect to the rated motor current (P0305)
P1233=	Enable and duration of the DC braking for OFF1 or OFF3 command (entered in s)
	Defines the duration of the DC braking in seconds after an OFF1 or OFF3 command. P1233 = 0 deactivates DC braking for an OFF1 and OFF3 command.
P1234=	Starting frequency of DC braking (entered in Hz)
	Sets the speed threshold for the start of DC braking.
P0347=	Demagnetizing time of the motor
	The inverter calculates this value from the motor data during commissioning. Only commissioning engineers, who have the appropriate experience, may change the parameter values. The inverter can trip due to an overcurrent during DC braking if the demagnetizing time is too short.

Table 5- 51 Parameters to enable and set DC braking



Operating characteristics of compound braking



When the motor is in the regenerative mode, the inverter DC link voltage increases. Compound braking is active depending on the DC link voltage. From a DC link voltage threshold that can be set, the inverters adds a DC current component to the motor current. The DC current component brakes the motor, converts the regenerative energy of the motor into heat and prevents the DC link voltage from increasing too high.

Note

Compound braking is only active in conjunction with the V/f control.

Compound braking is deactivated, if:

- The "flying restart" function is active
- DC braking is active
- Vector control is selected

For compound braking, the kinetic energy of the motor and motor load is partially converted into thermal energy. The motor can overheat if braking lasts too long or the drive must be braked too frequently.

Parameterizing compound braking

	· · · · · · · · · · · · · · · · · · ·
Parameter	Description
S	
P003=3	User access level
	3: Expert
P1236=	Compound braking (entered in %)
	Parameter P1236 defines the DC current superimposed on the motor current after the DC link voltage threshold $V_{DC link comp}$ has been exceeded.
	P1236 = 0
	Compound braking locked
	P1236 = 1 250
	Current level of the DC braking current as a % of the rated motor current (P0305)
P1254=	Calculation type of the switch-in threshold $V_{DC link comp}$ for compound braking
	P1254 = 0
	$V_{DC \ link \ comp}$ is a fixed value that only depends on the parameterized value of the line supply voltage (P0210).
	P1254 = 1
	V _{DC link comp} is continually calculated using internal algorithms. This allows the inverter reserves to be better utilized.

Table 5-52 Parameters to enable and set compound braking

5.10.1.2 Dynamic braking

Dynamic braking applications



Dynamic braking is typically used in applications in which dynamic motor behavior is required at different speeds or continuous direction changes, e.g. for conveyor drives or hoisting gear.

An internal closed-loop chopper control (braking chopper) in the inverter, which can control an external braking resistor, is required for dynamic braking.

Operating characteristics of dynamic braking

Dynamic braking converts the regenerative energy, which is released when the motor brakes, into heat.




Figure 5-11 Dynamic braking with braking chopper in the inverter

The inverter controls the dynamic braking depending on the DC link voltage.

The temperature monitoring of the braking resistor should be evaluated. The inverter must be switched off if the braking resistor overheats.

If a braking resistor that is unsuitable is used, a fire could break out and severely damage the inverter.

The temperature of braking resistors increases during operation. For this reason, avoid coming into direct contact with braking resistors. Make sure that the devices are located at sufficient distances from each other and that proper ventilation is provided.

Parameterizing the dynamic braking

Parameter	Description
P0003 = 2	Extended access
P1240 = 0 or P1240 = 2	Deactivate the V _{DCmax} controller
P1237	Enable signal and ON period of dynamic braking 0: Dynamic braking is locked 1: 5% ON period** 2: 10% ON period 3: 20% ON period 4: 50% ON period 5: 100% ON period
	The ON period set here is only effective if the braking resistor has reached its operating temperature. When required, a cold braking resistor is switched-in independent of this parameter **) SIEMENS resistors are designed for 5% ON period

Table 5- 53 Parameters to enable and set dynamic braking

5.10.1.3 Regenerative braking

Regenerative braking applications



Regenerative braking is typically used in applications in which braking energy is generated either frequently or for longer periods of time, e.g. centrifuges, unwinders or cranes.

Operating characteristics of regenerative braking

The inverter can feed back up to 100% of its power (for HO base load) into the line supply.

Parameterizing regenerative braking

	r drameters to set regenerative braking	
Parameter s	Description	
Energy reco	overy option for V/f control (P1300 < 20)	
P640	Motor overload factor	
	Setting the maximum regenerative power. If the regenerative power exceeds this value for longer than 5 s, the inverter shuts down with fault message F0028.	
Energy reco	overy option for vector control (P1300 \geq 20)	
P1531	Regenerative power limit	
	If the regenerative power reaches this value, the motor can no longer follow its speed setpoint, i.e. the motor speed increases. If the regenerative power exceeds this value, the inverter shuts down with fault message F0028.	

Table 5- 54 Parameters to set regenerative braking

5.10.1.4 Parameterizing a motor holding brake

Motor holding brake applications



The motor holding brake prevents the motor turning when the inverter is switched-off. The inverter has internal logic to control a motor holding brake.

The motor holding brake control inside the inverter is suitable for the following typical applications:

- Pumps
- Fans
- Horizontal and vertical conveyors

Operating characteristics of the motor holding brake control after an OFF1 and OFF3 command




Figure 5-12 Function diagram of the motor holding brake control after an OFF1 or OFF3 command

Controlling the motor holding brake after an OFF2 or STO command

For the following signals, the brake closing time is not taken into account:

- OFF2 command, or
- For fail-safe applications, in addition, after "Safe Torque Off" (STO)

After these control commands, the signal to close the motor holding brake is immediately output independent of the motor speed.




Figure 5-13 Function diagram, motor holding brake after an OFF2 command

Commissioning the control logic of a motor holding brake

∕!∖warning

The following applications require special settings of the motor holding brake. In these cases, the motor holding brake control may only be commissioned by experienced personnel:

- All applications that involve moving and transporting people
- Hoisting gear
- Elevators
- Cranes
- 1. Before commissioning, secure any dangerous loads (e.g. loads on inclined conveyor belts)
- 2. Suppress the motor holding brake control, e.g. by disconnecting the control cables
- 3. When opening the motor holding brake, ensure that a torque is established that prevents the load from briefly dropping.
 - Check the magnetizing time P0346; the magnetizing time is pre-assigned when commissioning the system and must be greater than zero
 - For V/f operation (P1300 = 0 to 3), set the boost parameters P1310, P1311.

- 4. Parameterize the opening and closing times of the motor holding brake It is extremely important that electromechanical braking is controlled with the correct timing (brake release time, brake closing time, release time) to protect the brakes against long-term damage. The exact values can be found in the technical data of the connected brake. Typical values:
 - Brake release times are between 35 ms and 500 ms
 - Brake closing times are between 15 ms and 300 ms
 - Release times are between 25 ms and 230 ms
- 5. Restore the motor holding brake control
 - The mechanical brake is connected to the inverter via the Brake Relay. Bit 12 "Brake active" of status signal r0052 controls the brake.
 - It is not sufficient to simply select status signal r0052 bit 12 in P0731 to P0733 (relay outputs). To activate the motor holding brake, parameter P1215 must be additionally set to 1.

When a motor with a built-in holding brake is commissioned, a "clicking" sound in the motor indicates that the brake has been properly released.

Parameters	Description	
P0003 = 2	Enables extended parameter access	
P1215 =	Enable motor holding brake 0 Motor holding brake locked (factory setting) 1 Motor holding brake enabled	
P0731= 52.C	BI: Function digital output 1	
	Note: To control the Brake Relay via the digital output, the following must apply, e.g. for digital output 1: P0731 = 52.C = 52.12	
P0346 =	Magnetizing time time 0 20 s, factory setting 1 s	
P1080 =	Minimum frequency 0 650 Hz, (0 Hz factory setting): minimum motor frequency, regardless of frequency setpoint	
P1216 =	Delay time for opening the brake 0 20 s, factory setting 0.1 s	
	Note: P1216> brake release time + relay opening time	
P1217 =	Holding time after runout 0 20 s, factory setting 0.1 s	
	Note: P1217> brake closing time + relay closing time	
P1227 =	Zero value detection monitoring time 0 300 s, factory setting 4 s	
r0052.12	"Brake active" status	

Table 5- 55 Control logic parameters of the motor holding brake

Opening the motor holding brake via P1218

Using parameter P1218, you can force the brake to open, e.g. in order to be able to manually move a conveyor drive.

P1218 is ignored if the motor holding brake is closed because of an STO.

Secure loads held by the brake!

Since this procedure cancels the "Brake active" signal which, in turn, causes the brake to be forced open, the user must ensure that, even when the motor has been powered-down, all loads held by the brake are secured before the signal is canceled.

Table 5-56 Parameter to force open a motor holding brake

Parameter	Description	
P0003 = 3	Enable expert access to parameters	
P1218 = 1	Forcibly open the motor holding brake	

5.10.2 Automatic restart and flying restart

5.10.2.1 Flying restart: switching on the converter when the motor is running

Description



The "flying restart" function, which is activated by P1200, allows the inverter to be switched to a rotating motor. The function must be used whenever a motor may still be running. This could be:

- After a brief line interruption
- When an inverter is shut down but air currents cause a fan impeller to rotate (either CW or CCW)
- If the motor is driven by a load

This function is useful, therefore, with motors whose load exhibits a high moment of inertia since it can help prevent sudden loads in the mechanical components.

If this function is not used in such cases, this could cause the motor to shut down due to overcurrent (overcurrent fault F0001).

The "flying restart" function can be used to synchronize the inverter and motor frequency.

Drive starts automatically

When this function is enabled (P1200 > 0), all those working with the system must be informed of the following:

- The drive starts automatically.
- Although the drive is at a standstill, it can be started by the search current.

Functions

5.10 Technological functions

Input values

Table 5- 57	Main function parameters
-------------	--------------------------

Parameter	Description
P1200 = 	Flying restart 0: locked (factory setting), 1 - 6 Active

Table 5- 58 Overview: the "flying restart" function

P1200	Flying restart active	Search direction		
0	Flying restart locked (factory setting)	-		
1	Flying restart always active	Search performed in both directions, startup in direction of setpoint		
2	Flying restart active after:Power ONFaultsOFF2	Search performed in both directions, startup in direction of setpoint		
3	Flying restart active afterFaultsOFF2	Search performed in both directions, startup in direction of setpoint		
4	Flying restart always active	Search performed in direction of setpoint only		
5	Flying restart is active afterPower ONFaultsOFF2	Search performed in direction of setpoint only		
6	Flying restart is active afterFaultsOFF2	Search performed in direction of setpoint only		

Table 5-59 Additional commissioning parameters

Parameter	Description			
P1202 =	Motor current: Flying restart			
	(entered in %): 10 % 200 %, factory setting 100 %			
	Defines the search current with respect to the rated motor current (P0305) that is present when the "flying restart" function is used.			
P1203 =	Search rate/speed: Flying restart			
	(entered in %): 10 % 200 %, factory setting 100 %			
	Sets the factor by which the output frequency changes during the flying restart to synchronize itself with the running motor.			

Note

The higher the search rate (P1203), the longer the search time. A lower search rate shortens the search time.

The "flying restart" function decelerates the motor slightly. The smaller the drive torque, the more the drive is decelerated.

The "flying restart" function should not be activated for motors in group drives due to the different coasting characteristics of the individual motors.

5.10.2.2 "Automatic restart" function after power failure

Restart after a power failure and/or faults within a few seconds.



This automatic restart function is primarily used when the inverter is operated as a standalone device.

The "automatic restart" function is used to restart the drive automatically once the power has been restored following a power failure. All faults are acknowledged automatically and the drive is switched on again.

Line undervoltage or power failure

The term "line undervoltage" describes a situation in which the line voltage fails momentarily and is then restored. The power failure is so short that the 400V power supply of the inverter is briefly interrupted, but the electronics power supply is still maintained.

The term "power failure" describes a situation in which the power fails for a longer period, whereby the DC link collapses completely and the Control Unit of the inverter is in a zerocurrent state.

Important secondary condition

An ON command prior to the power failure and when the power returns is required for the "automatic restart" function. The ON command must be connected-up through a digital input. An ON command from a fieldbus is ignored.

Since the function is not restricted to line supply faults, it can also be used to automatically acknowledge faults and restart the motor after any tripping. To allow the drive to be switched to a motor shaft that is still rotating, the "flying restart" function must be activated via P1200.

When the "automatic restart" function is active (P1210 > 1), a motor can restart automatically once the power has been restored. This is particularly critical if it is incorrectly assumed that the motors have been shut down after a long power failure.

For this reason, death, serious injury, or considerable material damage can occur if personnel enters the working area of motors in this condition.

Commissioning the automatic restart

- 1. Parameterizing the automatic restart using P1210
- 2. Set the number of start attempts via P1211.
- 3. If, for an automatic restart, the inverter is to be connected to an already rotating motor, then the 'flying restart' function should also be activated using P1200.
- 4. Make sure that this functions properly.

Parameterizing the automatic restart

Parameter s	
P1210 =	Automatic restart mode
	 0: Automatic restart locked 1: Fault acknowledgment after an ON command; P1211 locked (factory setting) 2: Automatic restart after a power failure; P1211 locked 3: Automatic restart after a line supply undervoltage or fault; P1211 enabled 4: Automatic restart after a line supply undervoltage; P1211 enabled 5: Automatic restart after a power failure and fault; P1211 locked 6: Automatic restart after a line supply undervoltage / failure or fault; P1211 locked
P1211 =	Number of automatic restart attempts [minimum 0 maximum 10] 3 (factory setting)
P1200 =	Flying restart (Page 139)

Table 5- 61 Principle of operation of the automatic restart

P1210 = 0: Automatic restart locked (this is a practical setting for a networked drive)

After the line supply voltage returns, possible faults must be acknowledged. After this, the ON command must be switched-in again in order that the inverter starts.

P1210 = 1: Fault acknowledgment after ON command (P1211 locked)

After a power failure, the inverter automatically acknowledges all faults (it resets them), as soon as the line supply voltage returns.

- Faults due to a line supply undervoltage are not automatically acknowledged.
- The motor does not automatically start.
- The motor only starts to rotate again if an ON command is issued again after the line supply voltage returns.

P1210 = 2: Automatic restart after power failure - no additional start attempts (P1211 locked)

After power failure, the inverter automatically acknowledges fault F0003 (resets it), as soon as the line supply voltage is available again; and automatically restarts.

- All other faults are not automatically acknowledged.
- Faults due to a line supply undervoltage are not automatically acknowledged.
- Switching the ON command in the de-energized state only results in an automatic start if the inverter was in the "ready" state when the power failed.

P1210 = 3: Automatic restart after a line supply undervoltage or fault - with additional start attempts (P1211 enabled)

After a line supply undervoltage, the inverter automatically acknowledges all faults (resets them), as soon as the line supply voltage is again available; and automatically restarts.

- This behavior is independent of the power failure or line supply undervoltage.
- Switching the ON command in the de-energized state has no effect, if the inverter was "ready" before the power failure.
- The number of start attempts can be set. (If the automatic restart is interrupted due to a new fault)

P1210 = 4: Automatic restart after a line supply undervoltage (P1211 enabled)

After power failure or a line supply undervoltage, the inverter automatically acknowledges fault F0003 (resets it), as soon as the line supply voltage is again available; and automatically starts.

- All other faults are not automatically acknowledged.
- An ON command in the de-energized state has no effect.
- The number of start attempts can be set. (If the automatic restart is interrupted due to a new fault)

P1210 = 5: Automatic restart after power failure and fault (P1211 locked)

After a power failure, the inverter automatically acknowledges all faults (resets them), as soon as the line supply voltage is again available; and automatically starts.

- Faults due to a line supply undervoltage are not automatically acknowledged.
- Switching the ON command in the de-energized state always results in automatic restart. Possible faults are first automatically acknowledged.

P1210 = 6: Automatic restart after line supply undervoltage / power failure or fault (P1211 locked)

The inverter automatically acknowledges all faults (resets them), as soon as the line supply voltage is again available; and automatically starts.

- This behavior is independent of the power failure or line supply undervoltage.
- If the ON command is switched-on during the power failure, then an automatic start is always formed. Possible faults are first automatically acknowledged.

Automatic restart characteristics

P1210	ON command always active (continuously)			ON command in the de-energized state		
	Fault F0003 due to		All other faults		Inverter	Inverter ready
	Power failure	Line supply undervoltage	Before power failure	in operation	signals a fault Before power failure	Before power failure
0	*	*	*	*	*	*
1	Fault acknowledgeme nt	_*	Fault acknowledgeme nt	*	Fault acknowledgement	*
2	Fault acknowledgeme nt + restart	*	*	*	*	Restart
3	Fault acknowledgeme nt + restart	Fault acknowledgement + restart	Fault acknowledgeme nt + restart	Fault acknowledgeme nt + restart	Fault acknowledgement + restart	_*
4	Fault acknowledgeme nt + restart	Fault acknowledgement + restart	*	*	_*	_*
5	Fault acknowledgeme nt + restart	_*	Fault acknowledgeme nt + restart	*	Fault acknowledgement + restart	Restart
6	Fault acknowledgeme nt + restart	Fault acknowledgement + restart	Fault acknowledgeme nt + restart	Fault acknowledgeme nt + restart	Fault acknowledgement + restart	Restart
*) = no	o action					

Table 5- 62 Overview of the automatic restart characteristics

5.10.3 Technology controller

Technology controller for processing higher-level control functions



The technology controller supports all kinds of simple process control tasks. For example, it is used for controlling pressures, levels, or flow rates.




Figure 5-14 Example: technology controller as a level controller

The technology controller specifies the speed setpoint of the motor in such a way that the process variable to be controlled corresponds to its setpoint. The technology controller is designed as a PID controller, which makes it highly flexible.

The technology controller setpoint can be supplied via the same setpoint sources as those available for the speed setpoint. The technology controller is also equipped with its own motorized potentiometer and own fixed frequencies.

The setpoints, actual values, and control signals of the technology controller are defined by means of BICO technology.

Parameter	Description
P2200 =	Enable technology controller
P2201 r2225	Fixed frequencies
P2231 P2248	Motorized potentiometer
P2251 r2294	Technology controller parameters

Table 5-63 Technology controller parameters

You will find more information about this function in the parameter list and in (function diagram 5100 of the List manual).

5.10.4 Positioning down ramp


A basic positioning function in the inverter



In certain applications, e.g. when a conveyor belt is brought to a standstill, the belt may have to travel a defined braking distance after it has been switched-off so that it always stops at the same position.

For a fixed ramp-down type, the number of revolutions that a motor requires to reach a standstill depends on the speed of the motor at the instant of the switch-off. Using the "positioning down ramp" function, the number of revolutions from the OFF1 command down to standstill can be defined independent of the speed.

The following diagram shows the principle signal characteristic of velocity (v) and position (s) of a linearly moved load, e.g. of a conveyor belt, that is stopped using the positioning down ramp. For a low velocity (v₂) the down ramp is extended so that the load comes to a standstill at the same end position (s₀) as for a higher velocity (v₁).






Table 5- 64	Parameters for the simple positioning function
-------------	--

Description
Control command for the positioning function Example: When P2840 = 722.0, the positioning function is activated via digital input 0.
Gear ratio = P2481/P2482
Number of shaft revolutions at the gearbox output for one distance unit
Number of distance units until the end position
Additive compensation value for increasing accuracy

For more information about this function, see the List Manual.

5.10.5 Logical and arithmetic functions using function blocks

Description



Additional signal interconnections in the inverter can be established by means of free function blocks. Every digital and analog signal available via BICO technology can be routed to the appropriate inputs of the free function blocks. The outputs of the free function blocks are also interconnected to other functions using BICO technology. Among others, the following unassigned function blocks are available:

- Time blocks
- Adders, subtracters, multipliers, dividers
- AND blocks, OR blocks, XOR blocks, NOT blocks
- Memory elements

Example: OR logic operation

You want to switch-on the motor via digital input 0 and also via digital input 1:

- 1. To do so, interconnect the status signals of digital inputs r722.0 and r722.1 with the inputs of a free OR block via BICO.
- 2. Now activate the OR block.
- 3. Finally, interconnect the OR block output with the internal ON command (P0840).

Parameters	Description
P2800 =	Enable FFBs (General enable for all function blocks) 0: locked 1: enabled
P2801 =	
P2802 =	Activate FFBs (activation of the individual function blocks)
P2803 =	Activate fast FFBs (enable an 8ms time slice to calculate the activated, fast function blocks)
	0: All function blocks are calculated with a 128 ms time grid1: Some of the function blocks can be calculated with an 8 ms time grid.

Table 5- 65 Parameters for using the free function blocks

Example: AND logic operation

An example of an AND logic operation, explained in detail, including the use of a time block is provided in the Chapter BICO technology (Page 19).

For more information about this function, see function diagrams 4800, 4810, 4820, and 4830 in the List Manual.

5.10.6 Changing over drive data sets (several motors connected to a frequency inverter)

Switching motor control

In certain applications, the inverter parameters need to be switched.

Example: Operating different motors on one inverter One inverter should operate one of two different motors. Depending on which motor is to run at any given time, the motor data and the ramp-function generator times for the different motors must be adjusted accordingly in the inverter.

Drive data sets (DDS)

The inverter provides the possibility of parameterizing the following functions in up to three different ways:

- Setpoint sources (exceptions: Analog inputs and fieldbus)
- Setpoint calculation
- Motor control
- Motor and inverter protection
- Technological functions (Exception: Technology controller, brake control, automatic restart and unassigned function blocks)

The associated parameters are indexed (index 0, 1 or 2). Control commands select one of the three indices and therefore one of the three saved settings.

This means, that as described in the example above, you can switch over all of the settings of the inverter matching the particular motor.

All of the switchable parameters of the five functions mentioned above with the same index is known as a "command data set".

Functions




Figure 5-16 DDS switchover in the inverter

The drive data sets are switched over using parameters P0820 and P0821. Parameters P0820 and P0821 are interlinked to control commands, e.g. the digital inputs of the inverter, using BICO technology.

Note

Drive data sets can only be changed over in the "ready for operation" state. The switchover time is approx. 50 ms.

Exceptions: The ramp-function generator parameters, the ramp-down time for OFF3, and the speed controller gain can be switched during operation.

Parameter	Description
P0820 =	1st cntrol command for switching the drive data sets Example: When P0820 = 722.0, the system switches from drive data set 0 to drive data set 1 via digital input 0
P0821 =	2nd control command for switching the drive data sets
r0051	Displaying the number of the DDS that is currently active
A copy function	n is available making it easier to commission more than one drive data set:
P0819.0 =	Number of the drive data set to be copied (source)
P0819.1 =	Number of the drive data to which the data is to be copied (target)
P0819.2 = 1	Start copying

Table 5- 66	Parameters for switching the drive data sets:
-------------	---

For an overview of all the parameters that belong to the drive data sets and can be switched, see the List Manual.

5.11.1 Communication interfaces

Fieldbus interfaces of the CU versions

The inverters are available in different versions for communication with higher-level controls with the subsequently listed fieldbus interfaces:

- CU240E and CU240S for USS via RS485
 - Control via PZD (process data channel)
 - Parameterizing using PKW (parameter channel)
- CU240S DP and CU240S DP-F for PROFIBUS DP
 - Control in cyclic operation using telegrams 1, 20, 350, 352 and 999
 - Control and parameterizing in cyclic operation using telegrams 353 and 354
 - Parameterizing via acyclic communication
- CU240S DP and CU240S DP-F for PROFINET
 - Control in cyclic operation using telegrams 1, 20, 350, 352 and 999
 - Control and parameterizing in cyclic operation using telegrams 353 and 354
 - Parameterizing via acyclic communication

5.11.2 Communication via USS

Universal serial interface (USS)



Using the USS protocol (protocol of the universal serial interface), users can set-up a serial data connection between a higher-level master system and several slave systems (RS 485 interface). Master systems include programmable logic controllers (e.g. SIMATIC S7-200) or PCs. The inverters are always slaves on the bus system.

The USS protocol allows you to implement automation tasks with cyclic telegram transfer (fixed telegram length required) and visualization tasks. In this case, variable telegram lengths are better since texts and parameter descriptions can be transferred in a single telegram without the data being subdivided.

USS bus topology via RS 485

Communication networks with up to 31 inverters (slaves) connected to a control can be established via the RS 485 interface. The topology must be configured as a line in which the first and last devices are terminated with terminating resistors.

Functions

5.11 Operation in fieldbus systems

USS communication network via RS 485 with a CU240E





Figure 5-17 USS network via RS 485

USS communication network via RS 485 with a CU240S

The connection is established using the SUB D connector located on the lower side of the Control Unit.

The diagram shows the DIP switch for the terminating resistor at the CU240S. The default position is OFF (no terminating resistor).






Figure 5-18 USS network via RS 485

A difference in the ground potential between the master and slaves in an RS 485 network can damage the inverter Control Unit. You must make absolutely sure that the master and slaves have the same ground potential.

SUB D connection on the CU 240S (pin assignment)

The CU240S Control Units are equipped with a 9-pole SUB D socket for connecting the inverter via an RS 485 interface. A standard 9-pole SUB D connector with a 180° cable outlet can be used for the USS connection via RS 485.

	Con tact	Designation	Description
	1	-	Unused
$\left(\circ \right)$	2	-	Unused
6	1 3	RS 485P	Receive and transmit signal (+)
	4	-	Unused
00	5	0 V	Ground reference
9	56	-	Unused
$\left[\left(\circ \right) \right]$	7	-	Unused
	8	RS 485N	Receive and transmit signal (-)
	9	-	Unused
	Х	Shield (housing)	Equipotential bonding

Table 5- 67 Contact assignment of the 9-pole SUB D socket

Cable lengths and number of devices

Table 5- 68 Max. no of devices and cable length

Baud rate in bit/s	Max. no. of devices	Max. cable length	
2.400 93.750	32	1200 m	
115.200 (max. baud rate)	30	1000 m	

5.11.2.1 User data range of the USS message frame

Structure of the user data



The user data range of the USS protocol is used to transfer application data. The process data is exchanged cyclically between the inverter and controller via the process data channel (PZD), while the parameter channel is used for transferring parameter values acyclically.

The following diagram shows the structure and sequence of parameter channel and process data (PZD).




Figure 5-19 USS user data structure

The length of the parameter channel is defined via parameter P2013, while the length of the process data is defined via parameter P2012. If only parameter channel or only process data are required, the parameters of the channel not required can be set to zero ("only PKW " or "only PZD").

If both channels are required, they must be transferred together.

5.11.2.2 Data structure of the USS parameter channel

Description




The parameter channel is used to monitor and/or change parameters in the inverter. Every time data is transferred, the parameter ID and associated parameter value are sent. The parameter channel can be set to a fixed length (3 or 4 data words) or variable length.

- The first data word always contains the parameter ID (PKE)
- The second data word contains the parameter index (IND)
- The third and fourth data word contain parameter values, text, and descriptions (PWE)

Parameter ID (PKE) and parameter index (IND)

The parameter ID (PKE) is always a 16 bit value. In conjunction with the index (IND), it defines the parameter to be transferred.




PKE structure

IND structure

- The parameter number is encoded in the lower 11 bits (PNU) of the PKE. Since the PNU can only contain values up to 2000, an offset must also be encoded for parameter numbers above 2000. The offset is set in the first word of the index (IND) as shown in the table below.
- Bit 11 (SPM) is reserved and is always 0.
- Bits 12 to 15 (AK) contain the request or response ID.

The meaning of the request ID for request telegrams (master \rightarrow inverter) is explained in the following table.



IND page index

Table 5-69	Regulations for	setting the PNU
------------	-----------------	-----------------

Parameter range	Page index			Bit		Hex value	+ PNU			
	а	b	С	d	f	e	9	8		
0000 1999	0	0	0	0	0	0	0	0	0x00	0 – 7CF
2000 3999	1	0	0	0	0	0	0	0	0x80	0 – 7CF
4000 5999	0	0	0	1	0	0	0	0	0x10	0 – 7CF
6000 7999	1	0	0	1	0	0	0	0	0x90	0 – 7CF
8000 9999	0	0	1	0	0	0	0	0	0x20	0 – 7CF
32.000 33.999	0	0	0	0	1	0	0	0	0x8	0 – 7CF
64.000 65.999	1	1	1	1	0	1	0	0	0xF4	0 – 7CF

Table 5-70 Coding example for a parameter number in PKE and IND for P7841, index 2

	PK	E	IND		
decimal	xx 1841		144	2	
hex	хх	731	90	02	

The parameter index is encoded in the second word of the index (IND).

Example: Coding of a parameter number in PKE and IND for P2016, index 3

The master and slave exchange data via the request ID and response ID (AK), a process that is to take place with the parameter specified in the PKE. The transfer status is communicated with the response ID.

Table 5-71 Request ID (master → inverter)

Request ID	Description		Response ID		
		positive	negative		
0	No request	0	7/8		
1	Request parameter value	1/2	7/8		
2	Change parameter value (word)	1	7/8		
3	Change parameter value (double word)	2	7/8		
4	Request descriptive element ¹⁾	3	7/8		
6	Request parameter value (field) ¹⁾	4/5	7/8		
7	Change parameter value (field, word) 1)	4	7/8		
8	Change parameter value (field, double word) ¹⁾	5	7/8		
9	Request number of field elements	6	7/8		
11	Change parameter value (field, double word) and save in EEPROM ²⁾	5	7/8		
12	Change parameter value (field, word) and save in EEPROM ²⁾	4	7/8		
13	Change parameter value (double word) and save in EEPROM	2	7/8		
14	Change parameter value (word) and save in EEPROM	1	7/8		
1) The rec	quired element of the parameter description is specified in IND (second	l word).			
2) The rec	quired element of the indexed parameter is specified in IND (second we	ord).			

The meaning of the response ID for response telegrams (inverter \rightarrow master) is explained in the following table. The request ID determines which response IDs are possible.

Response ID	Description
0	No response
1	Transfer parameter value (word)
2	Transfer parameter value (double word)
3	Transfer descriptive element ¹⁾
4	Transfer parameter value (field, word) ²⁾
5	Transfer parameter value (field, double word) ²⁾
6	Transfer number of field elements
7	Request cannot be processed, task cannot be executed (with fault number)
8	No master controller mode / no authorization to change parameters of the PARAMETER CHANNEL interface
1) The required el	ement of the parameter description is specified in IND (second word).
2) The required el	ement of the indexed parameter is specified in IND (second word).

Table 5- 72 Response ID (inverter \rightarrow master)

If the response ID is 7 (request cannot be processed), one of the fault numbers listed in the following table is stored in parameter value 2 (PWE2).

No.	Description	Comments
0	Impermissible parameter number (PNU)	Parameter does not exist
1	Parameter value cannot be changed	The parameter can only be read
2	Minimum/maximum not reached or exceeded	_
3	Incorrect subindex	_
4	No field	An individual parameter was addressed with a field request and subindex > 0
5	Incorrect parameter type / incorrect data type	Word and double word mixed up
6	Set not permitted (reset only)	-
7	The descriptive element cannot be changed	Description can never be changed
11	Not in "master controller" mode	Change request without "master controller" mode (see P0927)
12	Keyword missing	_
17	Request cannot be processed due to the operating state	The current inverter operating state is not compatible with the request received.
101	Parameter number currently deactivated	Dependent on the operating state of the inverter
102	Channel width is insufficient	Communication channel is too small for response
104	Impermissible parameter value	The parameter only permits certain values.
106	Request not included / task not supported	After request ID 5, 10, 15
200/201	Modified mininum/maximum not reached or exceeded	The maximum or minimum can be limited further during operation.
204	The available access authorization does not cover parameter changes.	-

Table 5-73 Fault numbers for the response "request cannot be processed"

Parameter value (PWE)

When communication takes place via the USS, the number of PWEs can vary. One PWE is required for 16 bit values. If 32 bit values are exchanged, two PWEs are required.

Note

U8 data types are transferred as U16, whereby the upper byte is zero. U8 fields, therefore, require one PWE for each index.

A parameter channel for 3 words is a typical data telegram for exchanging 16 bit data or alarm messages. The mode with a fixed word length of 3 is used when P2013 = 3.

A parameter channel for 4 words is a typical data telegram for exchanging 32 bit data variables and requires P2013 = 4.

A parameter channel allowing a flexible word length is used when P2013 = 127. The telegram length between the master and slave can have a different number of PWEs.

When the length of the parameter channel is fixed (p2013 = 3 or 4), the master must always transmit either 3 or 4 words in the parameter channel, otherwise the slave will not respond to the telegram. The response from the slave will also contain either 3 or 4 words. When the length is fixed, 4 should be used because 3 is insufficient for many parameters (i.e. double words). When the parameter channel is of a variable length (P2013 = 127), the master transmits only the amount of words required for the task in the parameter channel. The length of the response telegram is also restricted to the required size.

Rules for processing requests/responses

- A request or a response can only be referred to one parameter.
- The master must constantly repeat a request until it receives a suitable response.
- The master recognizes the response to a request that it sent by:
 - Evaluating the response ID
 - Evaluating the parameter number (PNU)
 - Evaluating the parameter index IND, if required
 - Evaluating the parameter value PWE, if necessary.
- The complete request must be sent in a telegram. Request telegrams cannot be subdivided. The same applies to responses.
- If response telegrams contain parameter values, the drive always returns the current parameter value when it repeats response telegrams.

5.11.2.3 Timeouts and other errors

Process timeouts



Parameter P2014 defines the permissible timeout in ms. Value zero prevents timeout monitoring. Parameter P2014 checks the cyclic update of bit 10 in control word 1.

If the USS is configured as a command source for the drive and P2014 is not zero, bit 10 of the received control word 1 is checked. If the bit is not set, an internal timeout counter is incremented. If the threshold defined in P2014 is reached, the drive sets a process timeout error.

Other errors

P2025 = USS rejected P2026 = USS character frame error P2027 = USS overflow error P2028 = USS parity error P2029 = USS start not recognized P2030 = USS BCC error P2031 = USS length error

5.11.2.4 USS process data channel (PZD)

Description



Process data (PZD) is exchanged continuously between the master and slave in this telegram range. Depending on the direction of transfer, the process data channel contains request data for the USS slave or response data to the USS master. The request contains control words and setpoints for the slaves, while the response contains status words and actual values for the master.




Figure 5-20 USS process data channel

The number of PZD words in a USS telegram is defined by parameter P2012. The first two words are:

- Control 1 (STW1) and main setpoint (HSW)
- Status word 1 (ZSW1) and main actual value (HIW)

If P2012 is greater than or the same as 4, the additional control word (STW2) is transferred as the fourth PZD word (default setting).

The sources of all the other PZDs are defined with parameter P2019 for an RS 485 interface and with P2016 for an RS 232 interface.

5.11.3 Communication via PROFIBUS and PROFINET

5.11.3.1 Connect the frequency inverter to PROFIBUS

Assignment of the SUB-D connector to connect to the PROFIBUS-DP network



Control Units CU240S DP and CU240S DP-F of the inverter are equipped with a SUB D connection to connect to the PROFIBUS cable.

	Contact	Designation	Description	Area
	1	Shielding	Ground connection	
	2	U0V	Floating and reference point for user supply	
	3	RxD/TxD-P	Receive/transmit data P (B/B')	RS 485
0 0	4	CNTR-P	Control signal	TTL
9 5	5	DGND	Reference potential for PROFIBUS data (C/C')	
\bigcirc	6	VP	Plus pole for supply voltage	5 V ± 10 %
	7	U24V	Floating user supply +24 V at 100 mA	
	8	RxD/TxD-N	Receive/transmit data N (A/A')	RS 485
	9	-	Not assigned	
	Housing	Cable shield	Cable shield	

 Table 5-74
 Contact assignment of the 9-pole SUB D connection

The SUB D connection is suitable for the SIMATIC RS 485 bus connector.

Recommended PROFIBUS connectors

We recommend one of the following connectors for the PROFIBUS cable:

- 1. 6GK1500-0FC00
- 2. 6GK1500-0EA02

Both connectors are suitable for all SINAMICS G120 Control Units with respect to the angle of the outgoing cable.

Note

PROFIBUS communication when the 400 V supply for the inverter is switched off

If the inverter is only supplied via the 400 V line connection for the Power Module, the PROFIBUS connection for the Control Unit is interrupted as soon as the power supply is disconnected. To prevent this, the Control Unit must be connected to a separate 24 V power supply via terminals 31 (+24 V I_n) and 32 (0 V I_n).

Permissible cable length / installing and shielding the PROFIBUS cable

You can find information about this under the following link: (http://support.automation.siemens.com/WW/view/en/1971286)

5.11.3.2 Example for configuring the inverter on PROFIBUS



A drive with a SINAMICS G120 inverter is to be controlled from a central SIMATIC controller via PROFIBUS. whereby the control signals and speed setpoint are to be transferred from an S7-300 CPU to the drive. In the other direction, the drive is to transfer its status messages and actual speed value to the central controller via PROFIBUS.

Using a suitable example, the following section provides step-by-step instructions explaining how to connect an inverter to a higher-level SIMATIC controller via PROFIBUS. To extend the PROFIBUS network to include additional inverters, simply repeat the relevant steps.

What prior knowledge is required?

In this example, it is assumed that readers know now to basically use an S7 control and the STEP 7 engineering tool and is not part of this description.

Hardware components (example)



Component	Туре	Order no.	Qty
Central controller			
Power supply	PS307 2 A	6ES7307-1BA00-0AA0	1
S7 CPU	CPU 315-2DP	6ES7315-2AG10-0AB0	1
Memory card	MMC 2MB	6ES7953-8LL11-0AA0	1
DIN rail	DIN rail	6ES7390-1AE80-0AA0	1
PROFIBUS connector	PROFIBUS connector	6ES7972-0BB50-0XA0	1
PROFIBUS cable	PROFIBUS cable	6XV1830-3BH10	1
Drive			
SINAMICS G120 Control Unit	CU240S DP	6SL3244-0BA20-1PA0	1
SINAMICS G120 Power Module	PM240	6SL3224-0BE21-5UA0	1
Basic Operator Panel	BOP	6SL3255-0AA00-4BA1	1
Motor	Three-phase induction motor	1LA7060-4AB10	1
PROFIBUS connector	PROFIBUS connector	6GK1500-0FC00	1

Note

The description provided in this manual uses the hardware listed above. Other similar products not listed above can also be used.

Software components

Component	Туре	Order no.	Qty
SIMATIC STEP 7	V5.3 + SP3	6ES7810-4CC07-0YA5	1
STARTER	V4.1 SP2 HF4	6SL3072-0AA00-0AG0	1
Drive ES Basic	V5.4	6SW1700-5JA00-4AA0	1

Drive ES Basic is the basic software of the engineering system, which combines the drive technology and Siemens controllers. The STEP 7 Manager user interface acts as a basis with which Drive ES Basic is used to integrate drives in the automation environment with respect to communication, configuration, and data storage.

Functions

5.11 Operation in fieldbus systems

Setting the PROFIBUS address of the inverter



Two DIP switch blocks are located on the Control Unit. The PROFIBUS address of the inverter is set using one of these. The DIP switch for the PROFIBUS address is, depending on the firmware release, either located on the front of the CU below the operator and display instrument (operator panel) or at the side of the CU.




Figure 5-21 PROFIBUS DIP switches

Alternatively, the PROFIBUS address can be set via parameter P0918. The DIP switch setting has priority over P0918.

CAUTION

When the PROFIBUS address is changed, the Control Unit needs to be switched off and on again to activate the new address. This must be carried out by switching the power supply off and then on again, regardless of whether the interface is supplied by the power supply for the inverter or via its own 24 V power supply.




Figure 5-22 PROFIBUS interface, diagnostics, and address setting on the Control Unit

Set the DIP switch to address 10 (as shown in the following table).

Table 5-75 Examples of setting the PROFIBUS address

DIP switch		1	2	3	4	5	6	7
Address = values added in this line		1	2	4	8	16	32	64
Example 1: Address = 117 = 1 + 4 + 16 + 32 + 64	OFF							
	ON							
Example 2:	OFF							
Address = 39 = 1 + 2 + 4 + 32	ON							

The valid address range is specified in the table below:

Table 5- 76Valid PROFIBUS addresses

DIP switch settings	Significance
0	PROFIBUS address defined via P0918
1 125	Valid PROFIBUS address
126, 127	Invalid PROFIBUS address

Integrating the inverter into a higher-level SIMATIC control



Once you have set the PROFIBUS address of the inverter, all the remaining settings required for integrating it in the SIMATIC control are carried out in STEP 7 with HW Config.

Creating a STEP 7 project

Create a new STEP 7 project and assign a project name (e.g. "G120_in_S7").

SIMATIC Manager - [G120_in	_S7 C:\Siemens\Step7\S7proj\G120_in_
By File Edit Insert PLC View	Options Window Help
🗋 🗅 😅 🎛 🕽 X 🖻 🛍	📩 😰 🐾 🐁 🗽 📰 🎬 🛍 🔍 No Filter > 💽 🏹 🞇 🍘
	骨 MPI(1) 🕎 Global labeling field
" Press F1 to get Help.	PC COM-Port (US5)

Figure 5-23 Create a new project in STEP 7

Functions

5.11 Operation in fieldbus systems

Configuring SIMATIC 300 and creating the PROFIBUS network

Add an S7 300 CPU.




Figure 5-24 Add a SIMATIC 300 station

Open the hardware configuration (HW Config) in Step 7.




Figure 5-25 Open HW Config

Add an S7 300 subrack to your project by dragging and dropping it from the "SIMATIC 300" hardware catalog. Connect a power supply to slot 1 of the subrack and a CPU 315-2 DP to slot 2.

When you add the SIMATIC 300, a window is displayed in which you can define the network. Create a PROFIBUS DP network.




Figure 5-26 Add a SIMATIC 300 station with the PROFIBUS DP network

Functions

5.11 Operation in fieldbus systems

Configuring the inverter and integrating it in the Profibus network

In STEP 7, the inverter can be connected to an S7 control in two ways:

1. Using the inverter GSD

The GSD is a standardized description file for a PROFIBUS slave. It is used by all controllers that are PROFIBUS masters.

2. Via the STEP 7 object manager

This somewhat more user-friendly method is only available for S7 controls and installed Drive_ES_Basic.

The following section describes how to configure the inverter using the GSD.

Installing the GSD in STEP 7

The GSD of the SINAMICS inverters are available in the Internet.

It is integrated in STEP 7 via HW Config.

🖳 HW Config - [SIMATIC 300(1) (Co	onfiguration) G120_in_57]		
🛄 Station Edit Insert PLC View	Options Window Help		
D 🚅 🔓 🖩 🖬 🎒 🖻 🗊	Customize Ctrl	I+Alt+E	
■ (0) UR 1 PS 307 2A 2 CPU 315-2 DP X2 DP 3 4 5 6 7	Specify Module Configure Network	I+Alt+T	
1 PS 307 2A 6	Drd Fi M I Q C ES7 3	48 KB wo MPI + DP	

Figure 5-27 Install the GSD in STEP 7 with HW Config

Once the GSD has been installed, the inverter appears as an object under "PROFIBUS DP" in the HW Config product catalog.




Figure 5-28 G120 in the HW Config product catalog

Drag and drop the inverter into the PROFIBUS network. Enter the PROFIBUS address set at the inverter in HW Config.





Figure 5-29 Connect G120 to the PROFIBUS network

The inverter object in the HW Config product catalog contains several telegram types. The telegram type defines which cyclic data (= process data (PZD)) is exchanged between the control and inverter. With standard telegram 1, for example, the inverter receives the process data for the speed setpoint and control word from the control and returns its actual speed value and status word in the process data.



Add the required telegram type to slot 1 of the inverter by dragging and dropping it from the HW catalog.

Figure 5-30 Define the telegram type of the SINAMICS G120 inverter in the control

STEP 7 automatically assigns the address range containing the process data for the inverter. Standard telegram 1 occupies four bytes of input data and four bytes of output data.

Note

Defining the telegram type in the inverter

The telegram type setting in HW Config only applies to the controller side. In the inverter, the same telegram type must be set by means of STARTER or the BOP via parameter P0922.

Final steps

- Save and compile the project in STEP 7.
- Establish an online connection between your PC and the S7 CPU and download the project data to the S7 CPU.

The inverter is now connected to the S7 CPU. The communications interface between the CPU and inverter is specified by the PROFIdrive profile. An example of how you can supply this interface with data can be found in this manual.

5.11.3.3 Integrating a frequency inverter in PROFINET

Assignment of the RJ45 connector to integrate an inverter into PROFINET



The CU240S PN and CU240S PN-F Control Units are equipped with an Ethernet switch for two connections in the form of RJ45 sockets. Connections with optical networks are established via switches, which are equipped with an electrical and optical port. The inverter is then connected to an electrical port.

Table 5-77 Contact assignment of the RJ45 sockets

	Contact	Designation	Significance	Wire color
	1	TX+	Transmit data +	Yellow
	2	ТХ	Transmit data -	Orange
	3	RX+	Receive data +	White
8	4	-		
	5	-		
	6	RX -	Receive data -	Blue

For product information about assembling the SIMATIC NET Industrial Ethernet FastConnect RF45 plug 180, see "Assembly Instructions for SIMATIC NET Industrial Ethernet FastConnect RJ45 Plug". The document is available for download in the Internet (http://support.automation.siemens.com/WW/view/en/23175326/130000):

Recommended PROFINET connectors

We recommend the following connector for the PROFINET cable:

6GK1901-1BB10-2Ax0

Additional information on PROFINET

You can find information on PROFINET in the Internet (http://support.automation.siemens.com/WW/view/en/19292127):

5.11.3.4 Example for configuring the inverter on PROFINET

Differences between PROFIBUS and PROFINET

The procedure for operating the inverter on PROFINET differs only slightly from the previous description for PROFIBUS. The following section covers only the key differences between PROFIBUS and PROFINET.

Hardware components (example)



In comparison to PROFIBUS, the S7 CPU, the Control Unit of the inverter and the communication cable must be configured for PROFINET.

Component	Туре	Order no.	Qty
Central controller			
Power supply	PS307 2 A	6ES7307-1BA00-0AA0	1
S7 CPU	CPU 315-2 PN/DP from V2.5 and higher	6ES7315-2EH13-0AB0	1
Memory card	MMC 2MB	6ES7953-8LL11-0AA0	1
DIN rail	DIN rail	6ES7390-1AE80-0AA0	1
PROFINET connector	PROFINET connector	6GK1901-1BB10-2Ax0	1
PROFINET cable	PROFINET cable	6XV1840-2AH10	1
Drive			
SINAMICS G120 Control Unit	CU240S PN	6SL3244-0BA20-1FA0	1
SINAMICS G120 Power Module	PM240	6SL3224-0BE21-5UA0	1
Basic Operator Panel	BOP	6SL3255-0AA00-4BA1	1
Motor	Three-phase induction motor	1LA7060-4AB10	1
PROFINET connector	PROFINET connector	6GK1901-1BB10-2Ax0	1

Note

The description provided in this manual uses the hardware listed above. Other similar products not listed above can also be used.

Software components

Component	Туре	Order no.	Qty
SIMATIC STEP 7	V5.4 SP2	6ES7810-4CC07-0YA5	1
STARTER	V4.1 SP2 HF4	6SL3072-0AA00-0AG0	1
Drive ES Basic	V5.4	6SW1700-5JA00-4AA0	1

Integrating the inverter into a higher-level SIMATIC control



All settings required for integrating the inverter in the SIMATIC controller are carried out in STEP 7 with HW Config.

Creating the STEP 7 project and configuring SIMATIC 300

The procedure here is very similar to that described for PROFIBUS. The main differences are:

- 1. In the module catalog, choose a PROFINET-capable S7 controller (e.g. CPU 315-2 PN/DP).
- 2. Once you have added the SIMATIC 300, create a PROFINET network.




Figure 5-31 Add SIMATIC 300 station with the PROFINET network

Configuring the inverter and integrating it into a PROFINET network



The inverter is integrated into the higher-level control with its GSDML via PROFINET. The GSDML of the SINAMICS inverters are available in the Internet. Once the GSDML has been installed (see "Communication via PROFIBUS"), the inverter appears as an object under "PROFINET IO" in the HW Config product catalog.

Drag and drop the inverter into the PROFINET network and then choose the standard telegram 1 as the telegram type.

🖳 HW Config - [SIMATIC 300(1) ((Configuratio	n) (G120	_in_5	7]		
🛄 Station Edit Insert PLC View	w Options V	Vindov	v He	lp			_ <u>8</u> ×
0 🛩 🔐 🖷 🖏 🎒 🗈	R 🔬 🎕) 🗖		k?		
0) UR 1 PS 307 2A 2 CPU 315-2 PN/D X1 MPI/DP X2 PN+IO X2 PT Post 1 3 4 5 •			1): PBI		T-10-	Find: Profile:	Standard Sta
					<u> </u>		Standard telegram 1
(1) SINAMICS-G120-CU2	40S						Gateway
Slot 🚺 Module	Order Nu	1	Q	D	C		
0 SINAMICS-6120-CU2 Inta FROFINET X1 For 1	65L3 244-0			204 3 2042 2041	•	Siemens A Device SIN	0BA20-1FA0 G NAMICS G120 drive with F IO functionality (RT, cyclic and
Insertion possible					Γ		Chg //

Figure 5-32 G120 with standard telegram 1 in STEP 7 on PROFINET

Final steps

- Save and compile the project in STEP 7.
- Establish an online connection between your PC and the S7 CPU and download the project data to the S7 CPU.

The inverter is now connected to the S7 CPU. The communications interface between the CPU and inverter is specified by the PROFIdrive profile. An example of how you can supply this interface with data can be found in this manual.

5.11.3.5 The PROFIdrive profile

User data structure in the PROFIdrive profile

PROFIdrive as an inverter interface on PROFIBUS or PROFINET

The SINAMICS G120 inverters are controlled via the PROFIdrive profile, version 4.1. The PROFIdrive profile defines the user data structure with which a central control communicates with the inverter by means of cyclic or acyclic data transfer. The PROFIdrive profile is a cross-vendor standard.

Cyclic communication

Description



The PROFIdrive profile defines different telegram types. Telegrams contain the data packages for cyclic communication with a defined meaning and sequence. SINAMICS G120 inverters have the telegram types listed in the following table.

Table 5-78 SINAMICS G120 telegram types

Telegram type	Parameter channel (PKW) parameter data	Process data (PZD) - control and status words, actual values							
		PZD01 STW1 ZSW1	PZD02 HSW HIW	PZD03	PZD04	PZD05	PZD06	PZD 07	PZD 08
Telegram 1	No	STW1	NSOLL_A	⇐ The in	⇐ The inverter receives this data from the control				
speed control, 2 words		ZSW1	NIST_A	⇒ The in	verter sen	ds this data	to the contr	ol	
Telegram 20	No	STW1	NSOLL_A						
speed control, VIK/NAMUR 2 or 5 words		ZSW1	NIST_A_ GLATT	IAIST	MIST	PIST			
Telegram 350	No	STW1	NSOLL_A	M_LIM	STW2				
speed control, 4 words		ZSW1	NIST_A_ GLATT	IAIST_	ZSW2				
Telegram 352	No	STW1	NSOLL_A	PCS7 process data					
speed control, PCS7		ZSW1	NIST_A_ GLATT	IAIST	MIST	FAULT_ CODE	WARN_ CODE		
Telegram 353 speed	Yes	STW1	NSOLL_A						
control, PKW 4/4 and PZD 2/2		ZSW1	NIST_A_ GLATT						
Telegram 354 speed	Yes	STW1	NSOLL_A	PCS7 process data					
control, PKW 4/4 and PZD 6/6		ZSW1	NIST_A_ GLATT	IAIST	MIST	FAULT_ CODE	WARN_ CODE		

Functions

5.11 Operation in fieldbus systems

Telegram type	Parameter channel (PKW) parameter data	Process data (PZD) - control and status words, actual values								
		PZD01 STW1 ZSW1	PZD02 HSW HIW	PZD03	PZD04	PZD05	PZD06	PZD 07	PZD 08	
Telegram 999 free interconnection	No	STW1 Telegram length on receipt is max. 8 words. The central configure user defined (e.g. HW Config (universal module in GSD))				-	ation is			
via BICO		ZSW1	ZSW1 Telegram length on transmission is max. 8 words. The central configuration is user defined (e.g. HW Config (universal module in GSD))							
STW1/2 ZSW1/2 NSOLL_A		Control word 1/2 Status word 1/2 Speed or frequency setpoint								
NIST_A_GLATT IA_IST MIST		Smoothed speed or actual frequency value Current output current Current torque								
PIST M_LIM FAULT_CODE		Current active power Toque limit value Fault number								
WARN_CODE		Alarm number								

The following sections explain the content of this table in more detail.

Functions

5.11 Operation in fieldbus systems

Data structure of the parameter channel


Parameter channel



The parameter channel can be used to process and monitor process data (write/read) as described below. The parameter channel always comprises four words.

_				
Parameter channel				
	PKE	IND	PWE	
	1 st	2 nd	3 rd and 4 th	
:	word	word	word	

PKE : Parameter identifier IND : Index PWE: Parameter value



Abbreviations:

Parameter ID (PKE), first word

The parameter ID (PKE) is always a 16 bit value.




Figure 5-34 PKE structure

• Bits 0 to 10 (PNU) contain the rest of the parameter number (value range 1 to 61999).

An offset must be added, which is defined by IND with the upper bits (acyclic) or the lower bits (cyclic) of the byte, for parameter numbers \geq 2000.

- Bit 11 (SPM) is reserved and is always 0.
- Bits 12 to 15 (AK) contain the request or response ID.

The meaning of the request ID for request telegrams (master \rightarrow inverter) is explained in the following table.

Request ID	Description		onse D			
		positive	negative			
0	No request	0	7/8			
1	Request parameter value	1/2	1			
2	Change parameter value (word)	1				
3	Change parameter value (double word)	2				
4	Request descriptive element ¹⁾	3				
6	Request parameter value (field) ¹⁾	4/5				
7	Change parameter value (field, word) 1)	4				
8	Change parameter value (field, double word) 1)	5				
9	Request number of field elements	6				
11	Change parameter value (field, double word) and save in EEPROM 5					
12	Change parameter value (field, word) and save in EEPROM ²⁾ 4					
13	Change parameter value (double word) and save in EEPROM 2 ↓					
14	4 Change parameter value (word) and save in EEPROM 1 7 / 8					
1) The required element of the parameter description is specified in IND (second word).						
2) The required element of the indexed parameter is specified in IND (second word).						

Table 5-79 Request ID (master → inverter)

The meaning of the response ID for response telegrams (inverter \rightarrow master) is explained in the following table. The request ID determines which response identifiers are possible.

Table 5- 80	Response ID	(inverter \rightarrow master)
-------------	-------------	---------------------------------

Response identifier	Description			
0	No response			
1	ransfer parameter value (word)			
2	Transfer parameter value (double word)			
3	Transfer descriptive element ¹⁾			
4	Transfer parameter value (field, word) ²⁾			
5	Transfer parameter value (field, double word) 2)			
6	Transfer number of field elements			
7	Request cannot be processed, task cannot be executed (with fault number)			
8 No master controller mode / no authorization to change parameters of the PARAMETER CHANNEL interface				
1) The required element of the parameter description is specified in IND (second word).				
2) The required element of the indexed parameter is specified in IND (second word).				

If the response ID is 7 (request cannot be processed), one of the fault numbers listed in the following table is stored in parameter value 2 (PWE2).

No.	Description	Comments
0	Impermissible parameter number (PNU)	Parameter does not exist
1	Parameter value cannot be changed	The parameter can only be read
2	Minimum/maximum not reached or exceeded	_
3	Incorrect subindex	-
4	No field	An individual parameter was addressed with a field request and subindex > 0
5	Incorrect parameter type / incorrect data type	Word and double word mixed up
6	Setting is not permitted (reset only)	-
7	The descriptive element cannot be changed	Description can never be changed
11	Not in the "master control" mode	Change request without "master controller" mode (see P0927)
12	Keyword missing	-
17	Request cannot be processed due to the operating state	The current inverter operating state is not compatible with the request received.
101	Parameter number currently deactivated	Dependent on the operating state of the inverter
102	Channel width is insufficient	Communication channel is too small for response
104	Impermissible parameter value	The parameter only permits certain values
106	Request not included / task not supported	After request ID 5, 10, 15
200/201	Changed minimum/maximum not reached or exceeded	The maximum or minimum can be limited further during operation.
204	The available access authorization does not cover parameter changes.	-

 Table 5- 81
 Fault numbers for the response "request cannot be processed"

Parameter index (IND), second word




Figure 5-35 IND structure (cyclic)

- The field sub-index is an 8 bit value which, in cyclic data transfer mode, is transferred in the more-significant byte (bits 8 to 15) of the parameter index (IND).
- In this case, the least-significant byte (bits 0 to 7) in the parameter index selects the parameter page for additional parameters.

Rules for the parameter range

The bit for selecting the parameter page functions as follows:

When it is set to 1, an offset of 2000 is applied in the inverter to the parameter number (PNU) transferred in the parameter channel request before the data is transferred.




Figure 5-36 IND page index (cyclic)

Parameter range		Page index Bit			Sit	Hex value	+ PNU			
	a	d	С	b	f	e	9	8		
0000 1999	0	0	0	0	0	0	0	0	0x00	0 – 7CF
2000 3999	1	0	0	0	0	0	0	0	0x80	0 – 7CF
4000 5999	0	0	0	1	0	0	0	0	0x10	0 – 7CF
6000 7999	1	0	0	1	0	0	0	0	0x90	0 – 7CF
8000 9999	0	0	1	0	0	0	0	0	0x20	0 – 7CF
32.000 33.999	0	0	0	0	0	1	0	0	0x04	0 – 7CF
64.000 65.999	0	0	0	0	1	0	0	0	0x08	0 – 7CF

Table 5-82 Regulations for setting the PNU

	PK	Æ	IND					
decimal	XX	1841	144	2				
hex	XX	731	90	02				

 Table 5- 83
 Coding example for a parameter number in PKE and IND for P7841, index 2

Parameter value (PWE) 3rd and 4th word

When data is transferred via PROFIBUS or PROFINET, the parameter value (PWE) is transferred as a double word (32 bit). Only one parameter value can be transferred in a single telegram.

A 32 bit parameter value includes PWE1 (high-order word, third word) and PWE2 (low-order word, fourth word).

A 16 bit parameter value is transferred in PWE2 (low-order word, fourth word). In this case, PWE1 (high-order word, third word) must be set to 0 in the PROFIBUS DP master / PROFINET I/O controller.

Rules for processing requests/responses

- A request or a response can only be referred to one parameter.
- The master must constantly repeat a request until it receives a suitable response.
- The master recognizes the response to a request that it sent by:
 - Evaluating the response ID
 - Evaluating the parameter number (PNU)
 - Evaluating the parameter index IND, if required
 - Evaluating the parameter value PWE, if necessary.
- The complete request must be sent in a telegram. Request telegrams cannot be subdivided. The same applies to responses.
- If response telegrams contain parameter values, the drive always returns the current parameter value when it repeats response telegrams.

Control and status words

Description



The control and status words fulfill the specifications of PROFIdrive profile version 4.1 for "speed control" mode.

Control word 1 (STW1)

Control word 1 (bits 0 to 10 in accordance with PROFIdrive profile and VIK/NAMUR, bits 11 to 15 for SINAMICS G120 only).

Table 5-84 Assignment of control word	Table 5- 84	Assignment of control word 1
---------------------------------------	-------------	------------------------------

Bit	Value	Significance	Comments			
0	0	OFF1	Shutdown, deceleration on the RFG ramp, pulse inhibit when $f < f_{min}$.			
	1	ON	Switches the inverter to "ready for operation" mode. The direction of rotation must be specified via bit 11.			
1	0	Coast to standstill (OFF2)	Immediate pulse inhibit, drive coasts to standstill.			
	1	No coasting to standstill	All "coast to standstill" (OFF2) commands are canceled.			
2	0	Quick stop (OFF3)	Quick stop: Shut down with the deceleration ramp that can be additionally set.			
	1	No quick stop	All "quick stop" (OFF3) commands are canceled.			
3	0	Disable operation	Control and inverter pulses are locked.			
	1	Enable operation	Control and inverter pulses are enabled.			
4	0	Reset ramp-function generator (RFG)	RFG output is set to 0 (quickest possible deceleration), inverter remains ON.			
	1	Enable ramp-function generator (RFG)				
5	0	Inhibit ramp-function generator (RFG)	The setpoint currently provided by the ramp-function generator is "frozen".			
	1	Enable ramp-function generator (RFG)				
6	0	Deactivate setpoint	The value selected at the ramp-function generator input is set to 0 (zero).			
	1	Enable setpoint	The value selected at the ramp-function generator input is enabled.			
7	1	Fault acknowledgment	Fault is acknowledged with a positive edge; the inverter then switches to "starting inhibit" mode.			
8	0	JOG 1 OFF	Drive brakes along the ramp.			
	1	JOG 1 ON	The drive ramps-up to the setpoint for the jog mode (direction of rotation: CW = clockwise).			
9	0	JOG 2 OFF	Drive brakes along the ramp.			
	1	JOG 2 ON	The drive ramps-up to the setpoint for the jog mode (direction of rotation: CCW = counter-clockwise).			
10	0	No PLC control	Process data invalid, "sign of life" expected.			
	1	PLC control	Control via interface; process data valid			

Bit	Value	Significance	Comments
11	0	No setpoint inversion	Motor runs clockwise in response to a positive setpoint.
	1	Setpoint inversion	Motor runs counter-clockwise in response to a positive setpoint.
12		Not used	
13	1	Motorized potentiometer UP	
14	1	Motorized potentiometer LOWER	
15	1	Data set changeover	Dependent on protocol: with SINAMICS G120 inverters, you can switch between the command data sets (CDS) 0 and 1 in control word 1, bit 15 using the local/remote operation function. This triggers a data set changeover. Command data set 0 is active for local operation, while command data set 1 is active for remote operation. You can now set the application-specific parameters for command and target value sources in both command data sets.

Default assignment of control word 2 (STW2)

The settings for control word 2 are defaulted as follows. This can be changed by using BICO.

Table 5-85 Default setting for control word 2 (not defined for VIK/NAMUR)

Bit	Value	Significance					
0	1	Fixed frequency selection bit 0					
1	1	Fixed frequency selection bit 1					
2	1	Fixed frequency selection bit 2					
3	1	Fixed frequency selection bit 3					
4	_	Not used					
5	-	Not used					
6	_	Not used					
7	_	Not used					
8	1	Enable technology controller					
9	1	Enable DC brake					
10	-	Not used					
11	1	Enable droop speed controller					
12	1	Torque control					
	0	Speed control					
13	0	External fault 1					
14	_	Not used					
15	-	Not used					

Status word 1 (ZSW1)

Status word 1 (bits 0 to 10 in accordance with PROFIdrive profile and VIK/NAMUR, bits 11 to 15 for SINAMICS G120 only).

Table 5-86 Bit assignments for status word 1 (for all PROFIdrive and VIK/NAMUR telegram)

Bit	Value	Significance	Comments
0	1	Ready for switching on	Power supply switched on; electronics initialized; pulses locked.
	0	Not ready for switching on	
1	i		Inverter is switched on (ON command present), no active fault, inverter can start as soon as "enable operation" command is issued. See control word 1, bit 0.
	0	Not ready for operation	
2	1	Operation enabled	Drive follows setpoint. See control word 1, bit 3.
	0	Operation locked	
3	1	Fault present	Drive is faulty. The drive is faulty, which means that it is not in operation and switches to "starting inhibit" mode once the fault has been successfully rectified and acknowledged.
	0	No fault	
4	1	"Coast to standstill" not activated	
	0	"Coast to standstill" activated	"Coast to standstill" (OFF 2) command present.
5	1	"Quick stop" not activated	
	0	Quick stop activated	"Quick stop" (OFF 3) command present.
6	1	Switch-on locked	The drive only switches to the ON state when the "No coast down" AND "No quick stop" commands (followed by "ON") are issued.
	0	Switch-on not locked	
7	1	Alarm present	Drive still in operation; alarm in service/maintenance parameter; no acknowledgement; see alarm parameter r2110.
	0	No alarm	No alarm is present or the alarm has disappeared.
8	1	Speed deviation within tolerance range	Setpoint/actual value deviation within tolerance range.
	0	Speed deviation outside of tolerance range	
9	1	Master control requested	The automation system is requested to assume control.
	0	No control requested	The master is not currently the master controller.
10	1	Maximum frequency reached or exceeded	Inverter output frequency is greater than or equal to the maximum frequency.
	0	Maximum frequency not reached	
11	1		
	0	Alarm: Motor current/torque limit reached	
12	1	Motor holding brake active	Signal can be used to control a holding brake.
	0		-
13	1		Motor data displays overload status.
	0	Motor overload	

Functions

5.11 Operation in fieldbus systems

Bit	Value	Significance	Comments
14	1	Clockwise rotation	
	0	Counter-clockwise rotation	
15	1		
	0	Inverter overload	E.g. current or temperature

Status word 2 (ZSW2)

Status word 2 has the following default assignment. This can be changed by using BICO.

Table 5-87 De	fault setting for status word 2 (not defined for VIK/NAMUR)
---------------	---

Bit	Value	Significance	Description
0	1	DC brake active	DC brake active
1	1	n_act < P2167	Inverter frequency < shutdown limit
2	1	n_act ≧ P1080	Actual frequency > minimum frequency
3	1	i_act ≧ P2170	Current ≥ limit value
4	1	n_act > P2155	Actual frequency > reference frequency
5	1	n_act ≦ P2155	Actual frequency < reference frequency
6	1	Speed setpoint reached	Actual frequency ≥ setpoint
7	1	DC link voltage < P2172	Voltage < threshold value
8	1	DC link voltage ≧ P2172	Voltage > threshold value
9	1	Speed ramp ended	
10	1	Technology controller output ≦ P2292	PI frequency < threshold value
11	1	Technology controller output > P2291	PI saturation
12	1	Vdc_max controller	
13	1	Kinetic buffering and flexible response	
14	1	Not used	
15	1	Not used	

Acyclic communication

Overview of acyclic communication



The contents of the transferred data set corresponds to the structure of the acyclic parameter channel according to the PROFIdrive profile, Version 4.1 (http://www.profibus.com/organization.html).

The acyclic data transfer mode generally allows:

- The transfer of large volumes of user data (up to 240 bytes). A parameter request/response must fit into a data set (max. 240 bytes). The requests/responses are no longer distributed over several data sets.
- Transfer of complete fields or field parts or the complete parameter description.
- Transfer of different parameters in one access (multiple request).
- Reading of profile-specific parameters over an acyclic channel
- Acyclic data transfer in parallel with cyclic data transfer.

Only one parameter request is processed at a time (no pipelining). No spontaneous messages are transferred.

Acyclic communication over PROFIBUS DP (DPV1)

The PROFIBUS DP expansions DPV1 comprise the definition of acyclic data exchange.

It supports concurrent access by other PROFIBUS masters (Class 2 master, e.g. commissioning tool).

Implementation of the extended PROFIBUS DP functions

Suitable channels are provided in the inverters of the SINAMICS G120 series for the different masters/different data transfer types:

- Acyclic data exchange with the same Class 1 master using the DPV1 functions READ and WRITE (with data set 47 (DS47)).
- Acyclic data exchange with the help of a SIEMENS startup tool (Class 2 master, e.g. STARTER). The startup tool can acyclically access parameters and process data in the inverter.
- Acyclic data exchange with a SIMATIC HMI (Human Machine Interface) (second Class 2 master). The SIMATIC HMI can acyclically access parameters in the inverter.
- Instead of a SIEMENS startup tool or a SIMATIC HMI, it is also possible for an external master (Class 2 master) as defined in the acyclic parameter channel according to the PROFIdrive profile, Version 4.1 (with DS47), to access the inverter.

Acyclic communication over PROFInet (basic mode parameter access)

In the case of basic mode parameter access, the requests and responses are transferred acyclically using the mechanism "Acyclic data exchange" of the communication system.

It supports concurrent access by other PROFInet IO supervisors (e.g. startup tool).

Acyclic PROFInet functions

Suitable channels are provided in the inverters of the SINAMICS G120 series for the different communication devices/different data transfer types:

- Acyclic data exchange with IO controller uses the functions READ and WRITE (with 0xB02E).
- Acyclic data exchange with the help of a SIEMENS startup tool (IO supervisor, e.g. STARTER). The startup tool can acyclically access parameters and process data in the inverter.
- Acyclic data exchange with a SIMATIC HMI (Human Machine Interface) (second IO supervisor). The SIMATIC HMI can acyclically access parameters in the inverter.
- Instead of a SIEMENS startup tool or a SIMATIC HMI, it is also possible for an external IO supervisor as defined in the acyclic parameter channel according to the PROFIdrive profile, Version 4.1 (with 0xB02E), to access the inverter.

5.11.3.6 STEP 7 program examples

STEP 7 program example for cyclic communication

S7 program for controlling the inverter



The S7 program, which supplies data for cyclic communication between the inverter and the central control, can be used for PROFIBUS and PROFINET.

In the example provided below, communication between the control and inverter is handled via standard telegram 1. The control specifies control word 1 (STW1) and the speed setpoint, while the inverter responds with status word 1 (ZSW1) and its actual speed value.

STW1: 0x47E Freq: 0x2500 L W#16#47E T MW 1 L W#16#2500 T MW 3

Network 1 : Create control word 1 and speed setpoint

Network	2	:	Acknowledge	fault
---------	---	---	-------------	-------

Comment:				
	U =	E M	0.6 2.7	

Network 3: Start and stop

Comment:				
U =	E M	0.0 2.0		

Network 4 : Write process data

Comment:				
	L	MW	1	
	т	PAW	256	
	L	MW	3	
	т	PAW	258	
Figure 5-37	Со	ntrolling	the G	120 via PROFIBUS or PROFINET

Network 5 : Read process data

Comment:				
	L	PEW	256	
	т	MM	5	
	L	PEW	258	
	Т	MW	7	

Figure 5-38 Evaluating the status of G120 via PROFIBUS or PROFINET

Functions

Information about the S7 program

The hexadecimal numeric value 047E is written to control word 1. The bits in control word 1 are listed in the following table.

HEX	BIN	Bit in STW1	Significance	Bit in MW1	Bit in MB1	Bit in MB2	Inputs
Е	0	0	ON/OFF1	8		0	E0.0
	1	1	ON/OFF2	9		1	
	1	2	ON/OFF3	10		2	
	1	3	Operation enable	11		3	
7	1	4	Ramp-function generator enable	12		4	
	1	5	Start ramp-function generator	13		5	
	1	6	Setpoint enable	14		6	
	0	7	Acknowledge fault	15		7	E0.6
4	0	8	Jog 1	0	0		
	0	9	Jog 2	1	1		
	1	10	PLC control	2	2		
	0	11	Setpoint inversion	3	3		
0	0	12	Irrelevant	4	4		
	0	13	Motorized potentiometer ↑	5	5		
	0	14	Motorized potentiometer ↓	6	6		
	0	15	Data set changeover	7	7		

 Table 5-88
 Assignment of the control bits in the inverter to the SIMATIC flags and inputs

In this example, inputs E0.0 and E0.6 are linked to the -bit ON/OFF1 or to the "acknowledge fault" bit of STW 1.

The hexadecimal numeric value 2500 specifies the setpoint frequency of the inverter. The maximum frequency is the hexadecimal value 4000.

The process data is written to logical address 256 of the inverter in the cyclic time slice of S7 (e.g. OB1) and read from logical address 256 of the inverter. The logical addresses for field bus communication were defined in HW Config.

STEP 7 sample program for acyclic communication

Simple S7 program for parameterizing the inverter



The S7 program, which supplies data for acyclic communication between the inverter and the central control is valid for PROFIBUS.

For PROFINET, instead of blocks SFC58 and SFC59, use blocks SFB52 and SFB53.

The number of simultaneous requests for acyclic communication is limited. More detailed information can be found in the Internet (http://support.automation.siemens.com/WW/view/en/15364459):

Functions

```
OB1 : "Main Program Sweep (Cycle)"
Kommentar:
Netzwerk 1 : Define Read or write
Kommentar:
    // Read parameter
          0(
          U
                        9.2
                м
          UN
                        9.1
                М
          )
          0(
                        9.0
          U
                м
                        9.1
          UN
                М
          )
          R
                М
                        9.3
          SPB
                RD
    // write parameter
          0(
                       9.3
          U
                М
          UN
                М
                        9.0
          )
          0(
                        9.1
          U
                М
          UN
                М
                        9.0
          )
                        9.2
          R
                М
          SPB
                WR
          BEA
    RD:
                0
          NOP
          CALL FC
                        1
          BEA
                0
    WR:
          NOP
          CALL FC
                        3
```

Figure 5-39 STEP 7 program example for acyclic communication - OB1

Flags 9.0 to 9.3 specify whether parameters are read or written:

- M9.0: request to read parameters
- M9.1: request to write parameters
- M9.2: displays the read process
- M9.3: displays the write process

FC1 to read parameters from the inverter

Inverter parameters are read via SFC 58 and SFC 59.

FC1 : PAR_RD

Kommentar:

Netzwerk 1: Parameters for reading

Kommentar:

	-	ND (2	
	L	MB 62	2
11	Т	DB1.DBB	3
//	L	MW 50	
	Т	DB1.DBW	c
			8
	L	MB 58	F
	T	DB1.DBB	5
	L	MW 63	_
	т	DB1.DBW	8
//			
	L	MW 52	
	т	DB1.DBW	12
	г	MB 59	
	т	DB1.DBB	11
	L	MW 65	
	т	DB1.DBW	14
	-	DDI.DDW	
//			
//	 L	 MW 54	
//			
//	 L	 MW 54	
//	 L T	 MW 54 DB1.DBW	18
//	L T L	MW 54 DB1.DBW MB 60	18
//	L T L T	MW 54 DB1.DBW MB 60 DB1.DBB	18 17
//	L T L T L L	MW 54 DB1.DBW MB 60 DB1.DBB MW 67	18 17
//	L T L T L L	MW 54 DB1.DBW MB 60 DB1.DBB MW 67	18 17
//	L T L T T L T	MW 54 DB1.DBW MB 60 DB1.DBB MW 67 DB1.DBW	18 17 20
//	L T L T T L T	MW 54 DB1.DBW MB 60 DB1.DBB MW 67 DB1.DBW MW 56	18 17 20
//	L T L T L T L T L T	MW 54 DB1.DBW MB 60 DB1.DBB MW 67 DB1.DBW MW 56 DB1.DBW	18 17 20 24
//	L T L T L T L L L L	MW 54 DB1.DBW MB 60 DB1.DBB MW 67 DB1.DBW MW 56 DB1.DBW MB 61	18 17 20 24 23
//	L T L T L T L T L T	MW 54 DB1.DBW MB 60 DB1.DBB MW 67 DB1.DBW MW 56 DB1.DBW MB 61 DB1.DBB	18 17 20 24 23

Functions


5.11 Operation in fieldbus systems


```
Netzwerk 2 : Read request
```


```
Kommentar:
```

```
CALL SFC
           58
 REQ
       :=M9.0
 IOID
      :=B#16#54
LADDR :=W#16#170
RECNUM :=B#16#2F
RECORD :=P#DB1.DBX0.0 BYTE 28
RET VAL:=MW10
BUSY
      :=M8.1
U
     М
            8.1
            9.0
R
     м
s
     М
            9.2
```

Netzwerk 3: Read delay after sending the read request







```
LADDR :=W#16#170
RECNUM :=B#16#2F
RET_VAL:=MW12
BUSY :=M8.3
RECORD :=P#DB2.DBX0.0 BYTE 36
U M 8.3
R M 8.2
```

Figure 5-40 Function block for reading parameters

You first have to define how many parameters (MB62), which parameter numbers (MW50, MW52, etc.), and how many parameter indices (MW58, MB59, etc.) are read for each parameter number. The specifications are saved in DB1.

SFC 58 copies the specifications for the parameters to be read from DB1 and sends them to the inverter as a read request. No other read requests are permitted while this one is being processed.

Once the read request has been issued and a waiting time of one second has elapsed, the parameter values are copied from the inverter via SFC 59 and saved in DB2.

FC3 to write parameters to the inverter

FC3 : PAR_WR
Kommentar:
Netzwerk 1: Parameter for writing
Kommentar:
L MW 21 T DB3.DBW 6
L MW 23
T DB3.DBW 8
L MW 35
T DB3.DBW 12
Netzwerk 2 : Write request
Kommentar:
CALL SFC 58
REQ :=M9.1
IOID :=B#16#54
LADDR :=W#16#170
RECNUM :=B#16#2F
RECORD :=P#DB3.DEXO.O BYTE 14
RET_VAL:=MW10
BUSY :=M8.1
U M 8.1
R M 9.1
s M 9.3
Figure 5-41 Function block for writing parameters
You first have to define which value (MW35) is written to which parameter index (MW23) of which parameter (MW21). The specifications are saved in DB3.
SFC 58 copies the specifications for the parameters to be written from DB3 and sends the to the inverter. No other write requests are permitted while this one is being processed.

For more information about SFC 58 and SFC 59, consult the STEP 7 online help.

5.12 Safety functions

5.12.1 Overview

Functional safety



Machine components operated by electrical drives are intrinsically hazardous. If a drive is incorrectly used or acts in an unexpected manner in the event of a malfunction, not only can this damage the machine but it can also cause severe injury or death. Functional safety reduces this risk of accidents caused by machines to an acceptable residual risk.

Integrated safety functions in SINAMICS G120

The CU240S DP-F and CU240S PN-F Control Units feature a range of integrated safety functions, which are certified in accordance with Cat. 3 to EN 954-1 and SIL 2 to IEC 61508:

Abbreviation	Description (DE/EN)	Function
STO	Sicher abgeschaltetes Moment	The motor is switched safely to zero torque.
	Safe Torque Off	
SS1	Sicherer Stopp 1	The motor is brought to a controlled standstill.
	Safe Stop 1	
SLS	Sicher begrenzte Geschwindigkeit	The speed of the motor is restricted in a controlled manner.
	Safely Limited Speed	
SBC	Sichere	The motor holding brake is safely controlled.
	Bremsenansteuerung	
	Safe Brake Control	

Table 5-89 Integrated safety functions

Basic prerequisites for using fail-safe functions

- 1. The machine risk assessment (e.g. in compliance with EN ISO 1050, "Safety of machinery Risk assessment Part 1: Principles") allows the use of inverter safety functions in accordance with SIL 2 or category 3.
- 2. The speed control of the inverter must function perfectly. Each fail-safe drive (drive = inverter + motor + brake + driven machine) must be set up in such a way that all operating procedures performed by the driven machine can be properly monitored and that the inverter operates below its limit values (for current, temperature, voltage, etc.). The performance and parameters of the inverter must be compatible with both the connected motor and the application in question.
- 3. Once the machine has been successfully commissioned, you must review the typical operating conditions and operate the machine close to the permissible limit values. The fail-safe drive must not malfunction under any circumstances.

5.12 Safety functions

Permissible control modes for using fail-safe functions

When the above-mentioned conditions are fulfilled, the fail-safe functions can be used for both V/f control and vector control.

Restrictions regarding SLS and SS1

Safety functions SS1 and SLS must not be used if the motor, after it has been switched-off, can still be accelerated by the mechanical elements of the connected machine component.

Whether or not a mechanical brake is installed is irrelevant.

Examples:

- For the hoisting gear of a crane, the suspended load can accelerate the motor as soon as the motor is switched-off. In this case, safety functions SS1 and SLS are not permissible. Even if the mechanical brake of the hoisting gear is generally closed after the motor has been switched-off, this is of no significance when it comes to the fact that SS1 and SLS safety functions are prohibited in this application.
- 2. A horizontal conveyor is always braked to a standstill due to friction as soon as the motor is switched-off. In this case, safety functions SS1 and SLS can be used without any restriction.

Examples of how the safety functions can be applied

Description of problem	Suitable safety function	Solution
When the EMERGENCY STOP button is pressed, a stationary motor must not start unintentionally.	STO	Control the inverter via terminals using an Emergency-Stop button.
A central EMERGENCY STOP button is designed to prevent more than one drive from starting unintentionally.	STO	Evaluate the Emergency-Stop button in a central control, control the inverter via PROFIsafe.
A short-circuit and cable break occurring when the motor holding brake is activated are to be signaled.	SBC	Connect the motor holding brake to the optional 'Safe Brake Module' of the inverter.
Having opened a protective door, the machine operator must enter the hazardous zone around a machine and run a conveyor belt at low speed.	SLS	Control the inverter via terminals using a button to move the conveyor belt.
When a protective door is opened, the motor must be stationary.	SS1	Activate the SS1 function in the inverter and enable the protective door as soon as the inverter signals back 'STO'.

Table 5-90 Application examples for safety functions

Controlling the safety functions

The safety functions in the inverter can be controlled via fail-safe digital inputs as well as over safe bus communication PROFIsafe via PROFIBUS or PROFINET in conjunction with a fail-safe CPU.

Safe feedback signals from the inverter

When fail-safe functions are used, feedback is generally required as to whether or not the drive is in a safe state.

With the SLS function, for example, this is the case if the inverter has decelerated the motor to below the speed monitoring limit. This safe state is signaled by the inverter via fail-safe channels. On the basis of this, a higher-level controller can trigger further actions (e.g. enable a protective door).

Fail-safe feedback signals from the inverter are realized using PROFIsafe.

Monitoring the safety functions -passivation:

A fail-safe inverter permanently monitors its hardware and software as well as the timing of the safety function as soon as it was activated. In the case of a fault, the inverter passivates itself:

- The inverter initiates an STO, i.e. the motor is safely switched into a no-torque condition
- The inverter signals a fault

In the List Manual, under the inverter fault message, you will find information and instructions as to what you must do in order to acknowledge the fault and to terminate the inverter passivation.

5.12 Safety functions

5.12.2 Connecting-up the fail-safe inputs

Connecting sensors to fail-safe inputs



The fail-safe inputs of the inverter are designed for connecting electromechanical sensors with two NC contacts.

It is not possible to directly connect sensors with two NO contacts and antivalent contacts (1 NO contact and 1 NC contact).




Figure 5-42 Sensors that can be connected to the fail-safe inputs

The following diagrams show the principle connection options for fail-safe inputs for the case that all of the components are mounted and installed inside a control cabinet.

- Connecting sensors with electromechanical contacts, e.g. Emergency Stop mushroom pushbuttons and end position switches
- Connecting electronic sensors, e.g. SIMATIC FS-400 light curtains
- Connecting safety relays, e.g. SIRIUS 3TK28.
- Connecting fail-safe outputs, e.g. SIMATIC F digital output modules




Figure 5-43 Connecting an electromechanical sensor




Figure 5-44 Connecting-up an electronic sensor inside a control cabinet

Functions 5.12 Safety functions




Figure 5-45 Connecting-up a safety relay in a control cabinet






Figure 5-46 Connecting up an F digital output module in a control cabinet

Additional interconnection options are listed under (http://support.automation.siemens.com/WW/view/en/27231237):

5.12.3 Restoring safety-related parameters to the factory setting



Before starting to commission the safety functions, you should know whether the safetyrelevant parameters of the inverter have already been changed. If you do not precisely know the setting of the safety-relevant parameters, then reset these parameters to the factory setting.

Which parameters are reset to the factory setting?

Resetting the safety-relevant parameters to the factory setting does not change the setting of the other parameters, e.g. the motor data or the significance of these terminals.

Restoring the factory setting sets all of the safety-relevant parameters back to their standard values. Exceptions:

- P9761 SI password input
- P9762 SI password change
- P9763 SI confirmation of password change

Procedure

- 1. Connect the PC and the inverter using the PC connection kit or via the fieldbus
- Go online by clicking on the button and call the screen of the safety functions by double clicking. The Safety Integrated menu is displayed in the main screen.
 STATUR EN_STATUR [SNAMES_G120 Safety Integrated]



3. With the mouse, click on the button

_____ at the lower edge of the screen.

4. Enter the safety password in the following screen and confirm with OK.

The safety-relevant parameters of the inverter have now been reset to the factory setting.

5.12.4 Controlling the safety functions via PROFIsafe



The safety functions can either be controlled via digital inputs or via the fieldbus i.e. PROFIBUS or PROFINET with the fail-safe PROFIsafe profile.

Examples for connecting an inverter to a fail-safe SIMATIC control via PROFIsafe is provided in the Internet under the following URL:

- PROFIBUS control of the safety functions (STO, SLS and SS1) of a SINAMICS G120 with an S7 300-F CPU (http://support.automation.siemens.com/WW/view/en/24093625)
- PROFINET control of the safety functions (STO, SLS and SS1) of a SINAMICS G120 with an S7 300-F CPU (http://support.automation.siemens.com/WW/view/en/29585944)

5.12.5 Controlling the safety functions via digital inputs

Activating fail-safe inputs



A fail-safe input of the inverter is activated by assigning it a safety function. This is described in the following using an example. The example shows the assignment of the fail-safe digital input FDI0 to the STO safety function using STARTER.

Procedure

- 1. Connect your PC to the inverter e.g. using the PC connection kit.
- 2. Launch the STARTER parameterization tool and go online.
- 3. In STARTER, call the screens with the fail-safe functions



5.12 Safety functions

4. Select the "Enables" tab. None of the fail-safe inputs are activated in the factory setting, i.e. no input is assigned to a safety function

ROFIsale		STO, SS1, SLS
afe digital input 0 (FD10)		
Channel A (FDI0A)		STO (FDI 0)
Channel B (FDI0B)		SS1 (FDI 0)
		SLS (FDI 0)
afe digital input 1 (FDI1)		
Channel A (FDI1A)		STO (FDI 1)
Channel B (FDI1B)		SS1 (FDI 1)
		SLS (FDI1)
afe brake control	-	
	L &	SBC

5. Click on the button

Change settings

on the lower edge of the STARTER screen and enter the safety password. The default password is '12345'.

The inverter outputs alarm A1698 to signal that safety settings are currently being changed. Further, the following LEDs flash on the Control Unit: RDY, ES, STO, SS1, and SLS.

Assign the fail-safe digital input 0 (FDI0) to the STO function by clicking on the appropriate two switches.

OFIsate		SS1. SLS
_		
fe digital input 0 (FDI0)		
Channel A (FDI0A)	- STC	(FDI 0)
		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

The required function is always selected on two channels, i.e. both switches should always be closed to activate. An activated fail-safe input is represented by a green line.

You can then make additional settings in the safety function screens or finalize the commissioning of the safety functions.

Debouncing and filtering the signals from the fail-safe input




As soon as a fail-safe input has been assigned to a safety function, the inverter checks the consistency of the input signal. Consistent signals at both terminals always assume the same signal state (high or low).

Reasons for inconsistent input signals

With electromechanical sensors (e.g. EMERGENCY STOP buttons or door switches), the contacts may bounce briefly at the moment switching takes place. The two sensor contacts never switch at exactly the same time either. As a result, the inverter responds with a fault and indicates signal inconsistencies.

To prevent this, the input signals in the inverter must be filtered.



Debouncing and filtering the signals at the fail-safe inputs Figure 5-47

Setting the signal filters in the inverter

Set the debounce time (P9650 and P9850) to such a level that faults caused by contact bounce or signal faults cannot occur.

Note

Short response times are essential for ensuring the functional safety of machines. The filter times increase the time required by the inverter to respond to fail-safe signals. For this reason, do not set the filter times any longer than required.

Transferring the safety-relevant parameters

1. Click on the button

Accept settings

- to accept all of the settings that you have made.
- 2. If the default password has not been changed, you are prompted to change it.
- 3. In the following dialog box, confirm the checksums of the safety-related parameters. This concludes the process of changing the safety settings.

5.12.6 Settings for the "STO" function



You can make two settings for the STO safety function.

Testing the shutdown paths

Shutdown paths are electronic circuits of the inverter used to disconnect a motor in a safetyrelevant fashion. The shutdown paths must be checked regularly to ensure that the fail-safe inverter complies with certification requirements.

The shutdown paths are always checked after the inverter has been switched on. Further, the inverter always checks, in its factory setting, the shutdown paths if the STO function is de-selected.

The shutdown path test takes approximately three seconds. The motor cannot be switched on during the test. The inverter signals this status as 'switch on inhibit' in the status word (r0052, bit 6). A higher-level control must evaluate this bit to ensure that the inverter accepts the ON command.

Deactivating the shutdown path test after an ON command

For applications where the STO safety function is very frequently required, the delay caused by testing the shutdown paths can be disturbing. If you wish to avoid the waiting time after each STO request, deactivate the regular shutdown path test when exiting the STO function (P9601, bit 1 and P9801, bit 1).

- 1. Connect your PC to the inverter e.g. using the PC connection kit.
- 2. Launch the STARTER parameterization tool and go online.
- 3. In STARTER, call up the screens displaying the fail-safe functions.
- 4. Select the "Safe Torque Off (STO)" screen from the safety function screens

Test of the shutdown channels when leaving STO
Activated Activated
Leaving the STO

5. Click on the button

Change settings


on the lower edge of the STARTER screen and enter the safety password. The default password is '12345'.

The inverter outputs alarm A1698 to signal that safety settings are currently being changed. Further, the following LEDs flash on the Control Unit: RDY, ES, STO, SS1 and SLS

6. Deactivate the regular shutdown path test when exiting the STO function.

Test periods to monitor the shutdown paths

A timer monitors the execution of the shutdown path test. The monitoring time (P9659) can be extended up to a maximum of one year. When the timer has expired, this is signaled via status word r9772, bit 15. A higher-level controller must monitor this bit to ensure that the STO safety function is tested on a regular basis.



Note

If you have deactivated the regular shutdown path test, before the test period expires, the inverter must be switched off once and switched-on again.

Transferring the safety-relevant parameters

- Accept settings
- 1. Click on the button ______ to accept all of the settings that you have made.
- 2. If the default password has not been changed, you are prompted to change it.
- 3. In the following dialog box, confirm the checksums of the safety-related parameters. This concludes the process of changing the safety settings.

5.12.7 Settings of the SS1, SLS and SBC safety functions



Always parameterize the fail-safe functions using the STARTER PC tool. Parameterizing failsafe functions using the BOP is always very time consuming due to the fact that parameters must be set twice.

The safety functions are parameterized according to the following schematic:

1. Go online with STARTER, open the screen with the safety functions and click on the button

Change settings

- 2. Enable the safety-related parameters by entering the correct password
- 3. Change the parameters of the safety function
- 4. Complete parameterization using the button

Accept settings

5. Confirm the checksums of the safety-related parameters

You will find a detailed description of the SS1, SLS and SBC functions in the Function Manual: (http://support.automation.siemens.com/WW/view/en/31676845)

Safety function SS1 (Safe Stop 1)

Parameters	Description
P9603 = P9803 =	Selecting the signal source of the safety functions
P9680 = P9880 =	Ramp deceleration You will find a calculation formula for the ramp deceleration in the Function Manual
P9681 = P9881 =	Ramp-down time of the braking ramp
P9682 = P9882 =	Minimum frequency for the standstill detection
P9761 =	Password for the safety functions
P9799 = P9899 =	Checksum of the safety-related parameters
r9798 = r9898 =	

Table 5- 91 Safety-related parameters for SS1

Safety function SLS (Safely Limited Speed)

The SLS safety function can be operated in three different modes. Depending on the mode, the inverter behavior differs when the SLS safety function is activated.

Parameters	Description
P9603 = P9803 =	Selecting the signal source of the safety functions
P9680 = P9880 =	Ramp deceleration You will find a calculation formula for the ramp deceleration in the Function Manual
P9681 = P9881 =	Ramp-down time of the braking ramp
P9690 = P9890 =	Fixed setpoint for SLS
P9691 = P9891 =	Tolerance to monitor the velocity
P9692 = P9892 =	Mode of the SLS safety function
P9761 =	Password for the safety functions
P9799 = P9899 =	Checksum of the safety-related parameters
r9798 = r9898 =	

Table 5- 92 Safety-related parameters for SLS

Safety function SBC (Safe Brake Control)

The SBC safety function is only possible in conjunction with the Safe Brake Relay.

Table 5-93 Safety-related parameters for SBC

Parameters	Description
P9602 = P9802 =	Enabling the SBC safety function
P9761 =	Password for the safety functions
P9799 = P9899 =	Checksum of the safety-related parameters
r9798 = r9898 =	

5.12.8 Acceptance test and report

Acceptance test report for safety functions



To verify safety-related parameters, an acceptance test must be performed after initial commissioning has been carried out and after the safety-related parameters have been changed. The acceptance test must be documented in the form of a report. The acceptance test reports are part of the machine documentation and must be archived accordingly.

The checksums (r9798 and r9898) ensure that subsequent changes to safety-related parameters can be identified.

What must be carried out when an acceptance test is performed for safety functions?

1. Machine documentation

Document the machine, including its fail-safe functions.

- Description of the machine and overview/block diagram
- Fail-safe functions for each drive
- Description of the fail-safe equipment

An empty document is provided as an example following this section.

2. Function test

Check each individual fail-safe function. An empty document is provided as an example following this section.

3. Complete the report

Document the commissioning period and sign the report.

- Check the parameters for fail-safe functions.
- Document the checksums.
- Provide evidence showing that the data has been backed up and archived.
- Sign the report.

An empty document is provided as an example following this section.

4. Enclosures with the report

Include records and printouts of measurements associated with the function test.

- Alarm reports
- Printouts of curve characteristics
- When required, you can create a list with all of the changed parameters of the inverter. Instructions on how to do this are available here: (http://support.automation.siemens.com/WW/view/en/29319456)

5.12.8.1 Documentation of the acceptance test

Overview



Acceptance test No.	
Date	
Person carrying out the test	

Table 5- 94 Description of the system and overview/block diagram

Designation				
Туре				
Serial number				
Manufacturer				
End customer				
Block diagram/overview diagram of the machine				

Table 5- 95Fail-safe functions for each drive

Drive No.	Firmware version	SI version	Fail-safe functions
	r0018 =	r9770 =	Example: STO

Table 5-96 Description of the fail-safe equipment/devices

Drive No.	Description
	Examples: Wiring of STO terminals (protective door, Emergency-Off) grouping of STO terminals

5.12.8.2 Function check of the acceptance test

Description



The function check must be carried out for each individual drive (under the assumption that the machine permits this).

Conducting the test

First commissioning	Please enter a	
Standard commissioning	check mark	

Function check, "Safe Torque Off" (STO)

This check involves the following steps:

Table 5- 97 Function, "Safe Torque Off" (STO)

No.	Description	Status
1.	 Initial state The inverter signals "ready for switching on" (P0010 = 0) No safety faults and alarms r9772.0 = r9772.1 = 0 (STO deselected and inactive) P9659 = time intervals for the forced checking procedure correctly set 	
2.	Switch on the motor	
3.	Check whether the motor involved rotates	
4.	Select STO while the ON command is being issued	
5.	 Check the following points: The motor coasts down to a standstill The motor is braked and held by the mechanical brake if a brake is being used No safety fault r9772.0 = r9772.1 = 1 (STO selected and active), r9772.14 = 1, if safe brake control is active 	
6.	Deselect STO	
7.	 Check the following points: No safety fault r9772.0 = r9772.1 = 0 (STO deselected and inactive), r9772.14 = 0 	
8.	 Check whether the motor involved is running. If yes, check the following points: That the cabling between the Control Unit and Power Module is correct Correct assignment, drive No inverter - Power Module - motor That the hardware is operating correctly That the shutdown paths are correctly wired Correct STO terminal assignment at the Control Unit Correct parameterization of the STO function Routine for the forced checking procedure of the shutdown paths 	

Function check, "Safe Stop 1" (SS1)

This check involves the following steps:

Table 5- 98	Function,	"Safe	Stop	1" ((SS1))
-------------	-----------	-------	------	------	-------	---

No.	Description	Status
1.	 Initial state The inverter signals "ready for switching on" (P0010 = 0) No safety faults and alarms r9772.0 = r9772.1 = 0 (STO deselected and inactive) r9772.2 = r9772.3 = 0 (SS1 deselected and inactive) 	
2.	Switch on the motor	
3.	Check whether the motor involved rotates	
4.	Select SS1 while the ON command is being issued	
5.	 Check the following points: The motor speed decelerates corresponding to the selected ramp time (if required, use a stopwatch) The motor coasts down to a standstill after the parameterized minimum speed has been fallen below The motor is braked and held by the mechanical brake if a brake is being used No safety fault r9772.1 = 1 (STO active) r9772.2 = 1 (SS1 selected) r9772.14 = 1, if the monitoring function of the safety-relevant brake is activated 	
6.	Cancel SS1	
7.	Check the following points: • No safety fault • r9772.1 = 0 (STO inactive) • r9772.2 = 0 (SS1 deselected) • r9772.14 = 0	
8.	 Check whether the motor involved rotates. If yes, check the following points: The cabling between the Control Unit and Power Module is correct Correct assignment, drive No inverter - Power Module - motor The hardware can function correctly Correct wiring of the shutdown paths Correct STO terminal assignment at the Control Unit Correct parameterization of the SS1 function 	

Functions

5.12 Safety functions

Function check, "Safely Limited Speed" (SLS)

This check involves the following steps:

No.	Description	Status
1.	 Initial state The inverter signals "ready for switching on" (P0010 = 0) No safety faults and alarms r9772.4 = r9772.5 = 0 (SLS deselected and inactive) 	
2.	Switch on the motor. The motor speed must be higher than the parameterized safely limited speed, if the machine permits this	
3.	Check whether the motor involved rotates	
4.	Select SLS while the ON command is being issued	
5.	 Check the following points: r9772.4 = 1 (SLS selected) The motor response depends on the selected mode of the SLS function SLS mode 0 The drive speed decreases corresponding to the selected ramp time and then the inverter is subsequently passivated SLS mode 1 The motor speed decelerates corresponding to the selected ramp time. The motor then rotates with the parameterized safely limited speed SLS mode 2 The inverter is immediately passivated, the motor coasts down SLS mode 3 The inverter is immediately passivated, the motor coasts down 	
6.	Deselect SLS	
0. 7.	 Deselect SLS Check the following points: No safety fault r9772.4 = r9772.5 = 0 (SLS deselected and inactive) 	
8.	 Check whether the drive involved is running. If yes, check the following points: The cabling between the Control Unit and Power Module is correct Correct assignment, drive No inverter - Power Module - motor The hardware can function correctly Correct wiring of the shutdown paths Correct parameterization of the SLS function 	

Table 5- 99 Function, "Safely Limited Speed" (SLS)

5.12.8.3 Filling in the acceptance report

Parameters of the fail-safe functions



	Comparison value of the checksums checked?		
	Yes	No	
Control Unit			

Checksums

Drive		Checksums of the Control Unit	
Name	Drive No.	r9798	r9898

Data backup/archiving

	Storage medium			Where is it kept
	Туре	Designation	Date	
Parameter				
PLC program				
Circuit diagrams				

Signatures

Commissioning engineer

Confirms that the checks and test listed above have been correctly conducted.

Date	Designation	Company/Dept.	Signature

Machinery construction OEM

Confirms the correctness of the parameterization documented above.

Date	Designation	Company/Dept.	Signature

Servicing and maintenance

6.1 Behavior of the frequency inverter when replacing components

Components should be replaced by the same type and the same version

To ensure maximum plant availability, the Control Unit and the Power Module can, when required, be replaced by a unit of the same type and the version without having to recommission the drive.

A memory card with a valid parameter set is required when replacing a Control Unit without having to re-commission it.

The details are described in the following sections.

Note

Valid parameter set

A valid parameter set is a parameter set that matches the type and software release of the Control Unit and that has been adapted to fit the particular application.

Message F0395

When switching-on the unit for the first time after replacing the Control Unit or Power Module, message F0395 is always displayed on the BOP (the SF on the CU lights up).

The message indicates that components were replaced. In this case, when switching-on the motor, check the direction of rotation and the response to control signals.

Replacing different components or version

If you replace different components (e.g. Profibus CU for Profinet CU) or components with different software releases, then the drive must always be re-commissioned.

Questions that can arise in conjunction with replacing components:

- How do I create a valid parameter set?
 When commissioning, you can create a valid parameter set either using the commissioning toolSTARTER (Page 58) or using the operator panel (Page 71).
- Which options are available for saving a valid parameter set? You can save a valid parameter set either on the memory card (Page 77) or on the computer (Page 58) that you use for commissioning with STARTER.
- How do I load a valid parameter set into my inverter? From the memory card when the inverter is powered-up or by manually downloading a parameters set either from the memory card (Page 78) or from the PC (Page 58).

Note

Standard commissioning

As a result of the similarity in the procedure to replace components, the standard commissioning with memory card is also described in this chapter.

6.2 Replacing the Power Module

6.2 Replacing the Power Module

When required, the Power Module can be replaced by an identical module (the same type and the same version) without having to recommission it.

If you replace a Power Module by one of the same type and the same format, however with a higher power rating, then re-parameterization is not absolutely necessary and you can acknowledge message F0395. However, this can have a negative impact on the open-loop / closed-loop control accuracy.

If you replace a Power Module by one with the same type and with a lower power rating, then then drive must be re-commissioned.

Before you replace the Power Module, ensure that all of the parameter settings are saved in the EEPROM of the Control Unit (refer to P0014 or P0971).

Replacing a Power Module

- 1. Switch-off the Power Module power supply and wait 5 minutes until the device has discharged itself.
- 2. Disconnect the Power Module connecting cable
- 3. Remove the Control Unit from the Power Module
- 4. Replace the Power Module
- 5. Mount the Control Unit onto the new Power Module
- 6. Connect the Power Module connecting cable
- Switch-on the Power Module power supply again Before switching-on the power supply again, ensure that the new Power Module is correctly installed and connected.
- 8. Wait until the inverter has completely booted (RDY-LED and SF-LED are lit, BOP returns to the standard display)
- 9. Acknowledge message F0395 (SF-LED off)
- 10. When switching-on the motor, check the direction of rotation and the response to control signals.
- 11.For fail-safe inverters, also check the safety functions that have been set.

6.3 Replacing the Control Unit

Under the prerequisite that you have a memory card with a valid parameter set, when required, you can replace a Control Unit for another one of the same type and the same software version without having to re-commission the inverter.

To do so, proceed as follows:

Procedure when replacing a Control Unit

- 1. Switch-off the inverter power supply and wait 5 minutes until the device has discharged itself.
- 2. Release the control cables from the Control Unit.
- 3. Remove the defective Control Unit from the Power Module.
- 4. Mount a new Control Unit on the Power Module.
- 5. Reconnect the control cables.
- 6. Insert a memory card with a valid parameter set into the new Control Unit.
- 7. Switch-on the inverter power supply again (the valid parameter set is then downloaded into the inverter from the memory card)
- 8. Wait until the inverter has completely booted (RDY-LED and SF-LED are lit, BOP returns to the standard display)
- 9. Remove the memory card and acknowledge message F0395 (SF-LED is dark)
- 10. When switching-on the motor, check the direction of rotation and the response to control signals.
- 11.For fail-safe inverters, also check the safety functions that have been set.

6.4 Standard commissioning

6.4 Standard commissioning

Standard commissioning with a valid parameter set

If you have a memory card with a valid parameter set, then you can also perform standard commissioning for several inverters.

Prerequisites

- Several inverters (Control Units and Power Modules of the same type) must be commissioned for the same application.
- A memory card with a valid parameter set is available.

Procedure for standard commissioning

- 1. Insert the memory card into the control unit of the first inverter.
- 2. Switch-on the inverter power supply (the valid parameter set is downloaded into the inverter from the memory card)
- 3. Wait until the inverter has completely booted (RDY-LED and SF-LED are lit, BOP returns to the standard display)
- 4. Remove the memory card and acknowledge message F0395 (SF-LED is dark)
- 5. Proceed with the next inverter

Messages and fault codes

Overview

The G120 inverter features the following diagnostic indicators:

• LEDs on the Control Unit

For a detailed overview of LED statuses, see "LED status indicators" (below).

- Fault and alarm numbers
 - Alarms provide warning information. They do not trigger any response from the system and do not need to be acknowledged.
 - If a fault occurs, the inverter shuts down and the "SF" LED on the Control Unit lights up. The inverter cannot be switched on again until the fault has been rectified. Once the fault has been rectified, it must be acknowledged.

Alarm and fault numbers are displayed on the operator panel, STARTER, or a higher-level control system.

Note

A description of all of the alarms and faults as well as the associated counter-measures are provided in the STARTER online help or in the List Manual in Section "Faults and alarm messages".

7.1 Status display using LEDs

LEDs on the inverter versions

Depending on their particular version, inverters are equipped with different LEDs to display operating states.




Figure 7-1 Status LED on the CU240S, CU240S DP, CU240S DP-F, CU240S PN

Diagnostics via LEDs

Note

"---" signals that the LED state (on, off or flashing) is not relevant for the corresponding state.

LED status display for standard inverters

Table 7-1 Status displays on the CU240S

LED d	isplays	Possible operating and fault states	
SF (red)	RDY (green)		
On / Off	Flashing	CommissioningRestoring the factory settingParameter download	
On	Off	General fault	
Off	On	Ready	

Table 7-2 Status displays on the CU240S DP

	LED displays		Possible operating and fault states
SF (red)	RDY (green)	BF (red)	
On / Off	Flashing		CommissioningRestoring the factory settingParameter download
On	Off		General fault
On / Off	On / Off	Flashing	Bus failure (no data)
On / Off	On / Off	On	Bus failure (searching for baud rate)
Off	On		Ready

Note

Control Unit with PROFIBUS DP interface - operation via terminals

If a Control Unit with a PROFIBUS DP interface is operated via terminals, in the standard setting the BF-LED indicates a fault (flashes). You can avoid this fault display by setting the fieldbus shutdown time in parameter P2040 to "0".

		LED displays		Possible operating and fault states	
SF (red)	RDY (green)	BF (red)	LNK (green)	ACT (yellow)	
On / Off	Flashing		On / Off	On / Off	CommissioningRestoring the factory settingParameter download
On	Off		On / Off	On / Off	General fault
On / Off	On / Off	Flashing	On	OFF	Bus failure (no data)
On / Off	On / Off	On	OFF	OFF	Bus failure (searching for baud rate)
On / Off	On / Off	OFF	On	On / Off	Connection established
On / Off	On / Off	On	OFF	OFF	No connection established
On / Off	On / Off	OFF	On	On	Data transfer active
Off	On		On / Off	On / Off	Ready

Table 7-3Status displays on the CU240S PN

LED status display for fail-safe inverters - CU240S DP-F

		L	Possible operating and fault states				
SF (red)	RDY (green)	BF (red)	ES (yellow)	STO (yellow)	SS1 (yellow)	SLS (yellow)	
On / Off	Flashing		On / Off				CommissioningRestoring the factory settingManual parameter download
On / Off	Flashing		Flashing	Flashing	Flashing	Flashing	Safety commissioningResetting the safety parameters
Flashing	Flashing		Flashing	Flashing	Flashing	Flashing	Parameter download from the memory card when switching-on
On	OFF		On / Off				General fault
OFF	On		On / Off				Ready

Table 7-5 Display of the communication states on the CU240S DP-F

	LED displays	Possible operating and fault states	
SF (red)	RDY (green)	BF (red)	
On / Off	On / Off	Flashing	Bus failure (no data)
On / Off	On / Off	On	Bus failure (searching for baud rate)

The "ES", "STO" and "SS1" LEDs have no significance for the communication status of the CU240S DP-F $\,$

Messages and fault codes

7.1 Status display using LEDs

		LED d	Possible operating and fault states			
SF (red)	RDY (green)	ES (yellow)	STO (yellow)	SS1 (yellow)	SLS (yellow)	
On / Off	On	OFF	On	On / Off	On / Off	STO parameterized
On / Off	On	On	Flashing			STO initiatedSTO reached
On / Off	On	OFF	On / Off	On / Off	On	SLS parameterized
On / Off	On	OFF			Flashing	SLS initiated
On / Off	On	On			Flashing	SLS reached
On / Off	On	OFF	On / Off	On	On / Off	SS1 parameterized
On / Off	On	OFF		Flashing		SS1 initiated
On / Off	On	On		Flashing		SS1 reached
On	OFF	On	OFF	OFF	OFF	Passivation

Table 7-6 Display of the fail-safe states on the CU240S DP-F

The "BF" LED has no significance for the fail-safe states of the CU240S DP-F.

LED status display for fail-safe inverters - CU240S PN-F

Table 7- 7	Display of the general states on the CU240S PN-F
------------	--

		LED di	Possible operating and fault states			
SF (red)	RDY (green)	ES (yellow)	STO (yellow)	SS1 (yellow)	SLS (yellow)	
On / Off	Flashing	On / Off				CommissioningRestoring the factory settingManual parameter download
On / Off	Flashing	Flashing	Flashing	Flashing	Flashing	Safety commissioningResetting the safety parameters
Flashing	Flashing	Flashing	Flashing	Flashing	Flashing	Parameter download from the memory card when switching-on
On	OFF	On / Off				General fault
OFF	On	On / Off				Ready

The "BF", "LNK" and "ACT" LEDs have no significance for the general state of the CU240S $\mathsf{PN}\text{-}\mathsf{F}$

		LED displays	Possible operating and fault states		
SF (red)	RDY (green)	BF (red)	LNK (green)	ACT (yellow)	
On / Off	On / Off	Flashing	On	OFF	Bus failure (no data)
On / Off	On / Off	On	OFF	OFF	Bus failure (searching for baud rate)
On	OFF		On / Off	On / Off	PROFIsafe failure
On / Off	On / Off	OFF	On	On / Off	Connection established
On / Off	On / Off	ON	OFF	OFF	No connection
On / Off	On / Off	OFF	On	On	Data transfer active

Table 7-8 Display of the communication states on the CU240S PN-F

The "ES", "STO" and "SS1" LEDs have no significance for the communication status of the CU240S PN-F

Table 7-9 Display of the fail-safe states on the CU240S PN-F

		LED d	Possible operating and fault states			
SF (red)	RDY (green)	ES (yellow)	STO (yellow)	SS1 (yellow)	SLS (yellow)	
On / Off	On	OFF	On	On / Off	On / Off	STO parameterized
On / Off	On	On	Flashing			STO initiatedSTO reached
On / Off	On	OFF	On / Off	On / Off	On	SLS parameterized
On / Off	On	OFF			Flashing	SLS initiated
On / Off	On	On			Flashing	SLS reached
On / Off	On	OFF	On / Off	On	On / Off	SS1 parameterized
On / Off	On	OFF		Flashing		SS1 initiated
On / Off	On	On		Flashing		SS1 reached
On	OFF	On	OFF	OFF	OFF	Passivation

The "BF", "LNK" and "ACT" LEDs have no significance for the fail-safe states of the CU240S $\mathsf{PN}\text{-}\mathsf{F}$

7.2 Alarm and error messages

7.2 Alarm and error messages

Diagnostics via alarm and fault numbers

If an alarm or fault condition occurs, the OP displays the corresponding alarm or fault number.

- If an alarm is present, the inverter continues to operate.
- If a fault occurs, the inverter shuts down.

Alarm number	Significan ce	
A0700	Cause	The parameter or configuration settings made by the PROFIBUS master are invalid.
	Remedy	Correct the PROFIBUS configuration.
A0702	Cause	The connection to PROFIBUS is interrupted.
	Remedy	Check the connector, cable, and PROFIBUS master.
A0703	Cause	The PROFIBUS master is either not receiving any setpoints or is only receiving invalid setpoints (control word = 0).
	Remedy	Check the setpoints of the PROFIBUS master. Switch the SIMATIC CPU to "RUN".
A0704	Cause	At least one transmitter between two nodes is not yet active or has failed.
	Remedy	Activate the transmitter between the two nodes.
A0705	Cause	The inverter is not receiving any actual values.
	Remedy	None (the inverter is faulty).
A0706	Cause	PROFIBUS DP software error.
	Remedy	No diagnostics parameter r2041.
A0710	Cause	The inverter has detected an error with the PROFIBUS data connection.
	Remedy	The Control Unit data interface may be interrupted.
A0711	Cause	Invalid PROFIBUS parameter.
	Remedy	Check addresses P0918 and P2041.
F0070	Cause	No communication via PROFIBUS. Initiated by A0702, A0703, and A0704. The telegram downtime set in P2040 has elapsed. For details, see "Faults and Alarms" in the List Manual.
	Remedy	Check the connection between the data transfer devices and make sure that a valid control word is used.

Table 7-10 Alarm and fault numbers – cause and remedy

Reading fault codes

The following parameters must be taken into account during troubleshooting:

- Stored in parameter r0947 under its code number, e.g. F0003 = 3
- Associated fault value; stored in parameter r0949 (0 = no fault value)
- The time stamp of the fault is stored in r0948 and can be read
- The number of fault codes (P0952) is stored in r0947 and can be read

7.2 Alarm and error messages

Reading messages

The following parameters must be taken into account when alarms are processed:

• Stored in parameter r2110 under the code number; can be read, e.g. A0503 = 503. The value 0 indicates that no alarm is generated. The index allows you to access the two current alarms and the two previous alarms.

General fault acknowledgement

You can use one of the following methods to reset the fault number:

- Press FN on the BOP.
- Factory settings: acknowledge via DI 2.
- Set bit 7 in control word 1 (r0054).
- Switch the inverter off and then on again.

(switch off the main power supply and the external 24 V supply for the Control Unit and switch it on again.)

Faults that can only be acknowledged by switching the device off and then on again

- F00051 Parameter EEPROM fault
- **F00052** Power Stack fault
- F00061 Automatic download, memory card is not used
- F00062 Automatic download, the contents of the memory card are invalid
- **F00063** Automatic download, the contents of the memory card are incompatible
- F00064 The drive has attempted to download data automatically while ramping up.
- F01601 System startup fault

Note

The drive cannot be operated until all active faults have been acknowledged. The procedure to delete F0395 is described in the Section "Coupling the CU and PM for the first time - Message F0395 (Page 46)" of this manual.

Motor failure without fault code or alarm

If the motor does not start once the ON command has been issued:

- Check whether P0010 = 0.
- Check the inverter status via r0052.
- Check the command and setpoint source (P0700 and P1000).
- Check whether the motor data refers to the inverter data "load range" and "voltage".

Technical data

8.1 Technical data, CU240S Control Unit

Technical data of the CU240S, CU240S DP, CU240S DP-F, CU240S PN and CU240S PN-F

Feature	Data		
Operating voltage	Supply from the Power Module or an external 24 V DC supply (20.4 V to 28.8 V, 0.5 A) via control terminals 31 and 32		
Heat loss	CU240S, CU240S DP: < 5.5 W		
Setpoint resolution	0.01 Hz		
Digital inputs (dependent on the CU type)	6 or 9, isolated; PNP Low < 5 V, High > 10 V, maximum input voltage 30 V, current drain 5.5 mA		
Analog inputs	2, with 10-bit resolution Al0: 0 V to 10 V, 0 mA to 20 mA and -10 V to+10 V Al1: 0 V to 10 V and 0 mA to 20 mA Both analog inputs can also be configured as digital inputs		
Digital outputs	3 relay outputs, 30 V DC / max. 0.5 A for a resistive load		
Analog outputs	2 AO0: 0 V to 10 V or 0 mA to 20 mA AO1: 0 mA to 20 mA		
Encoder input	5 V or 24 V power supply is set using the DIP switch, max. 300 mA, CU240S PN-F max. 200 mA		
Fail-safe inputs (dependent on the CU type)	2, two-channel, maximum input voltage 30 V, 5.5 mA		
PFH	5 × 10E-8 Valid for all safety functions STO, SS1, SLS and SBC		
Dimensions (WxHxD)	73 mm x 178 mm x 55 mm		
Weight	0.52 kg		

8.2 Technical data, CU240E Control Unit

8.2 Technical data, CU240E Control Unit

CU240E

Feature	Data
Operating voltage	Supply from the Power Module
Heat loss	< 5.5 W
Setpoint resolution	0.01 Hz
Digital inputs	6, isolated; PNP/NPN switchable Low < 5 V, High > 10 V, maximum input voltage 30 V,
Analog inputs	2, with 10-bit resolution Al0: 0 V to 10 V, 0 mA to 20 mA and -10 V to +10 V Al1: 0 V to 10 V and 0 mA to 20 mA Both analog inputs can also be configured as digital inputs
Digital outputs	3 relay outputs, 30 V DC / max. 0.5 A for a resistive load
Analog outputs	2 AO0: 0 V to 10 V or 0 mA to 20 mA AO1: 0 mA to 20 mA
Dimensions (WxHxD)	73 mm x 195 mm x 30 mm
Weight	0.21 kg

8.3 General technical data, PM240 Power Modules

8.3 General technical data, PM240 Power Modules

PM240

Feature	Version				
Line operating voltage	3 AC 380 V 480 V ± 10%	The permissible line operating voltage depends on the installation altitude			
Input frequency	47 Hz 63 Hz				
Power factor λ	0.7 0.85				
Overload capability	(HO) or low overload (LO). In or	either be operated with high overload der to avoid overtemperature of the ad, as a minimum its load must decrease load or LO base load).			
	HO base load 0.37 kW 75 kW	150% overload for 57 s 200% overload for 3 s 100% HO base load for 240 s			
	HO base load 90 kW 200 kW	136% overload for 57 s 160% overload for 3 s 100% HO base load for 240 s			
	LO base load 7.5 kW 90 kW	110% overload for 57 s 150% overload for 3 s 100% LO base load for 240 s			
	LO base load 110 kW 250 kW	110% overload for 59 s 150% overload for 1 s 100% LO base load for 240 s			
Pulse frequency	4 kHz for 0.37 kW 75 kW (HO) 2 kHz for 90 kW 200 kW (HO)				
	The pulse frequency can be inc frequency reduces the permissi	reased in 2 kHz steps. A higher pulse ble output current.			
Possible braking methods	DC brake, compound brake, dy chopper	namic brake with integrated braking			
Degree of protection	IP20				
Operating temperature	0.37 kW 110 kW (HO) -10 °C +50 °C (14 °F 122				
	132 kW 200 kW (HO) 10 °C +40 °C (14 °F 104	°F) when the rated power is reduced (derating)			
	(LO) -10 °C +40 °C (14 °F	104 °F)			
Bearing temperature	-40 °C +70 °C (-40 °F 158	°F)			
Relative humidity	< 95% RH - condensation not p	ermissible			
Installation altitude	0.37 kW 110 kW (HO) _Up to 1000 m (3300 ft) above so				
	132 kW 200 kW (HO) Up to 2000 m (6500 ft) above se	power is reduced (derating)			
Standards		ompliant, UL-certified fuses, overload afe motor protection devices must be			

8.4 Power-dependent technical data, PM240 Power Modules

8.4 Power-dependent technical data, PM240 Power Modules

General conditions

The input currents specified for the PM240 Power Modules is the technical data apply for a 400V line supply with $U_k = 1\%$ referred to the frequency inverter power rating. When using a line reactor, the currents are reduced by a few percent.

Order No.	6SL3224-0BE13- 7UA0	6SL3224-0BE15- 5UA0	6SL3224-0BE17- 5UA0	6SL3224-0BE21- 1UA0	6SL3224-0BE21- 5UA0
Power rating for HO base load	0.37 kW / 0.5 PS	0.55 kW / 0.75 PS	0.75 kW / 1 PS	1.1 kW / 1.5 PS	1.5 kW / 2 PS
Input current for HO base load	1.6 A	2.0 A	2.5 A	3.8	4.8
Output current for HO base load	1.3 A	1.7 A	2.2 A	3.1	4.1
Fuse	10 A	10 A	10 A	10 A	10 A
Heat loss	0.097 kW	0.099 kW	0.102 kW	0.108	0.114
Cooling air requirement	4.8 l/s / 10 CFM	4.8 l/s / 10 CFM	4.8 l/s / 10 CFM	4.8 l/s / 10 CFM	4.8 l/s / 10 CFM
Cable cross-section for line and motor connections	1 2.5 mm² <i>1</i> 18 14 AWG	1 2.5 mm²/ 18 14 AWG			
Weight	1.2 kg / 2.6 lb	1.2 kg / 2.6 lb	1.2 kg / 2.6 lb	1.2 kg / 2.6 lb	1.2 kg / 2.6 lb

Table 8-1 PM240 Frame Size A

Table 8-2 PM240 Frame Size B and C

Order No., unfiltered	6SL3224- 0BE22-2AA0	6SL3224- 0BE23-0AA0	6SL3224- 0BE24-0AA0	6SL3224- 0BE25-5AA0	6SL3224- 0BE27-5AA0	6SL3224- 0BE31-1AA0
Order No., filtered	6SL3224- 0BE22-2UA0	6SL3224- 0BE23-0UA0	6SL3224- 0BE24-0UA0	6SL3224- 0BE25-5UA0	6SL3224- 0BE27-5UA0	6SL3224- 0BE31-1UA0
Power rating for HO base load	2.2 kW / 3 PS	3 kW / 4 PS	4 kW / 5 PS	5.5 kW / 7.5 PS	7.5 kW / 10 PS	11 kW / 15 PS
Input current for HO base load	7.6 A	10.2 A	13.4 A	16.7 A	23.7 A	32.7 A
Output current for HO base load	5.9 A	7.7 A	10.2 A	13.2 A	19 A	26 A
Input current for LO base load	7.6 A	10.2 A	13.4 A	21.9 A	31.5 A	39.4 A
Output current for LO base load	5.9 A	7.7 A	10.2 A	18 A	25 A	32 A
Fuse	16 A	16 A	16 A	20 A	32 A	35 A
Heat loss	0.139 KW	0.158 KW	0.183 KW	0.240 KW	0.297 KW	0.396 KW
Cooling air requirement	24 l/s 50 CFM	24 l/s 50 CFM	24 l/s 50 CFM	55 l/s 120 CFM	55 l/s 120 CFM	55 l/s 120 CFM
Cable cross-section for line and motor connections	1.5 6 mm² 16 10 AWG	1.5 6 mm² 16 10 AWG	1.5 6 mm² 16 10 AWG	4 10 mm² 12 8 AWG	4 10 mm² 12 8 AWG	4 10 mm² 12 8 AWG
Weight	4.3 kg / 9.5 lb	4.3 kg / 9.5 lb	4.3 kg / 9.5 lb	6.5 kg / 14 lb	6.5 kg / 14 lb	6.5 kg / 14 lb

Technical data

8.4 Power-dependent technical data, PM240 Power Modules

Order No., unfiltered	6SL3224-0BE31- 5AA0	6SL3224-0BE31- 8AA0	6SL3224-0BE32- 2AA0	6SL3224-0BE33- 0AA0	6SL3224-0BE33- 7AA0
Order No., filtered	6SL3224-0BE31- 5UA0	6SL3224-0BE31- 8UA0	6SL3224-0BE32- 2UA0	6SL3224-0BE33- 0UA0	6SL3224-0BE33- 7UA0
Power rating for HO base load	15 kW / 20 PS	18.5 kW / 25 PS	22 kW / 30 PS	30 kW / 40 PS	37 kW / 50 PS
Input current for HO base load	40 A	46 A	56 A	73 A	90 A
Output current for HO base load	32 A	38 A	45 A	60 A	75 A
Input current for LO base load	46 A	53 A	72 A	88 A	105 A
Output current for LO base load	38 A	45 A	60 A	75 A	90 A
Fuse	50 A	63 A	80 A	100 A	125 A
Heat loss	0.44 KW	0.55 KW	0.72 KW	1.04 KW	1.2 KW
Cooling air requirement	55 l/s / 120 CFM	55 l/s / 120 CFM	55 l/s / 120 CFM	110 l/s / 240 CFM	110 l/s / 240 CFM
Cable cross-section for line and motor connections	10 35 mm² 7 2 AWG	10 35 mm² 7 2 AWG	10 35 mm² 7 2 AWG	25 35 mm² 3 2 AWG	25 35 mm² 3 2 AWG
Weight	Filtered: 16 kg / 35 lb; unfiltered: 13 kg / 29 lb	Filtered: 16 kg / 35 lb; unfiltered: 13 kg / 29 lb	Filtered: 16 kg / 35 lb; unfiltered: 13 kg / 29 lb	Filtered: 23 kg / 51 lb; unfiltered: 16 kg / 35 lb	Filtered: 23 kg / 51 lb; unfiltered: 16 kg / 35 lb

Table 8-3 PM240 Frame Size D and E

Technical data

8.4 Power-dependent technical data, PM240 Power Modules

Order No., unfiltered	6SL3224-0BE34- 5AA0	6SL3224-0BE35- 5AA0	6SL3224-0BE37- 5AA0	6SL3224-0BE38- 8UA0	6SL3224-0BE41- 1UA0
Order No., filtered	6SL3224-0BE34- 5UA0	6SL3224-0BE35- 5UA0	6SL3224-0BE37- 5UA0	-	-
Power rating for HO base load	45 kW / 60 PS	55 kW / 75 PS	75 kW / 100 PS	90 kW / 125 PS	110 kW / 150 PS
Input current for HO base load	108 A	132 A	169 A	205 A	235 A
Output current for HO base load	90 A	110 A	145 A	178 A	205 A
Input current for LO base load	129 A	168 A	204 A	234 A	284 A
Output current for LO base load	110 A	145 A	178 A	205 A	250 A
Fuse	160 A	200 A	250 A	250 A	315 A
Heat loss	1.5 KW	2.0 KW	2.4 KW	2.4 kW	2.5 kW
Cooling air requirement	150 l/s / 320 CFM	150 l/s / 320 CFM	150 l/s / 320 CFM	150 l/s / 320 CFM	150 l/s / 320 CFM
Cable cross-section for line and motor connections	35 120 mm² 2 4/0 AWG	35 120 mm² 2 4/0 AWG	35 120 mm² 2 4/0 AWG	35 120 mm² 2 4/0 AWG	35 120 mm² 2 4/0 AWG
Weight	Filtered: 52 kg / 115 lb; unfiltered: 36 kg / 80 lb	Filtered: 52 kg / 115 lb; unfiltered: 36 kg / 80 lb	Filtered: 52 kg / 115 lb; unfiltered: 36 kg / 80 lb	39 kg / 90 lb	39 kg / 90 lb

Table 8-4 PM240 Frame Size F

Table 8-5 PM240 Frame Size G

Order No.	6SL3224-0BE41-3UA0	6SL3224-0BE41-6UA0	6SL3224-0BE42-0UA0
Power rating for HO base load	132 kW / 177 PS	160 kW / 215 PS	200 kW / 268 PS
Input current for HO base load	245 A	297 A	354 A
Output current for HO base load	250 A	302 A	370 A
Input current for LO base load	297 A	354 A	442 A
Output current for LO base load	302 A	370 A	477 A
Fuse	355 A	400 A	630 A
Heat loss	3.9 KW	4.4 KW	5.5 KW
Cooling air requirement	360 l/s / 760 CFM	360 l/s / 760 CFM	360 l/s / 760 CFM
Cable cross-section for line and motor connections	95 240 mm² 3/0 600 AWG	120 240 mm² 4/0 600 AWG	185 240 mm² 6/0 600 AWG
Weight	176 kg / 388 lb	176 kg / 388 lb	176 kg / 388 lb

8.5 General technical data, PM250 Power Modules

8.5 General technical data, PM250 Power Modules

PM250

Feature	Version			
Line operating voltage	3 AC 380 V 480 V ± 10%	The permissible line operating voltage depends on the installation altitude		
Input frequency	47 Hz 63 Hz			
Power factor λ	0.9			
Overload capability	(HO) or low overload (LO). In orde	ither be operated with high overload er to avoid overtemperature of the l, as a minimum its load must decrease oad or LO base load).		
	HO base load 5.5 kW 75 kW	150% overload for 57 s 200% overload for 3 s 100% HO base load for 240 s		
	LO base load 7.5 kW 90 kW	110% overload for 57 s 150% overload for 3 s 100% LO base load for 240 s		
Pulse frequency	4 kHz The pulse frequency can be increased in 2 kHz steps. A higher pulse frequency reduces the permissible output current.			
Braking methods	Regenerative energy			
Degree of protection	IP20			
Operating temperature	HO base load -10 °C +50 °C (14 °F 122 °F			
	LO base load -10 °C +40 °C (14 °F 104 °F	power is reduced (derating)		
Bearing temperature	-40 °C +70 °C (-40 °F 158 °	F)		
Relative humidity	< 95% RH - condensation not per	rmissible		
Installation altitude	Up to 1000 m (3300 ft) above sea	a level Higher altitudes are possible when the rated power is reduced (derating)		
Standards	UL, cUL, CE, C-tick, SEMI F47 In order that the system is UL-compliant, UL-certified fuses, overload circuit-breakers or intrinsically safe motor protection devices must be used			

8.6 Power-dependent technical data, PM250 Power Modules

8.6 Power-dependent technical data, PM250 Power Modules

PM250 Power Module

Table 8- 6	PM250 Fra	ime Size C	and D

Order No.	6SL3225- 0BE25-5AA0	6SL3225- 0BE27-5AA0	6SL3225- 0BE31-1AA0	6SL3225- 0BE31-5AA0	6SL3225- 0BE31-8AA0	6SL3225- 0BE32-2AA0
Power rating for HO base load	5.5 kW 7.5 PS	7.5 kW 10.0 PS	11.0 kW 15 PS	15.0 kW 20 PS	18.5 kW 25 PS	22.0 kW 30 PS
Input current for HO base load	13.2 A	19.0 A	26.0 A	30.0 A	36.0 A	42.0 A
Output current for HO base load	13.2 A	19.0 A	26.0 A	32.0 A	38.0 A	45.0 A
Input current for LO base load	18.0 A	25.0 A	32.0 A	36.0 A	42.0 A	56.0 A
Output current for LO base load	18.0 A	25.0 A	32.0 A	38.0 A	45.0 A	60.0 A
Fuse	20 A	32 A	35 A	50 A	63 A	80 A
Heat loss	Available soon	Available soon	Available soon	0.44 kW	0.55 kW	0.72 kW
Cooling air requirement	38 l/s 0 CFM	38 l/s 80 CFM	38 l/s 80 CFM	22 l/s 46 CFM	22 l/s 46 CFM	39 l/s 82 CFM
Cable cross- section for line and motor connections	2.5 10 mm² 14 8 AWG	4 10 mm² 12 8 AWG	6 10 mm² 10 8 AWG	10 35 mm² 7 2 AWG	10 35 mm² 7 2 AWG	16 35 mm² 5 2 AWG
Weight	7.5 kg / 17 lb	7.5 kg / 17 lb	7.5 kg / 17 lb	15 kg / 33 lb	15 kg / 33 lb	16 kg / 35 lb

Table 8-7 PM240 Frame Size E and F

Order No.	6SL3225-0BE33- 0AA0	6SL3225-0BE33- 7AA0	6SL3225-0BE34- 5AA0	6SL3225-0BE35- 5AA0	6SL3225-0BE37- 5AA0
Power rating for HO base load	30.0 kW / 40 PS	37.0 kW / 50.0 PS	45.0 kW / 60 PS	55.0 kW / 75 PS	75 kW / 100 PS
Input current for HO base load	56 A	70 A	84 A	103 A	135 A
Output current for HO base load	60 A	75 A	90 A	110 A	145 A
Input current for LO base load	70 A	84 A	102 A	190 A	223 A
Output current for LO base load	75 A	90 A	110 A	145 A	178 A
Fuse	100 A	125 A	160 A	200 A	250 A
Heat loss	1 kW	1.3 kW	1.5 kW	2 kW	2.4 kW
Cooling air requirement	22 l/s / 46 CFM	39 l/s / 82 CFM	94 l/s / 200 CFM	94 l/s / 200 CFM	117 l/s / 250 CFM
Cable cross- section for line and motor connections	25 35 mm² 3 2 AWG	25 35 mm² 3 2 AWG	35 150 mm² 2 5 AWG	70 150 mm² - 2 5 AWG	95 150 mm² - 3 5 AWG
Weight	21 kg / 46 lb	21 kg / 46 lb	51.0 kg / 112 lb	51.0 kg / 112 lb	51.0 kg / 112 lb

8.7 General technical data, PM260 Power Modules

8.7 General technical data, PM260 Power Modules

PM260

Feature	Version					
Line operating voltage			he permissible operating voltage epends on the installation altitude			
	The power units can also be operated with a minimum voltage of 500 V – 10 %. In this case, the power is linearly reduced as required.					
Input frequency	47 Hz 63 Hz					
Power factor λ	0.95					
Overload capability	The Power Module PM260 can either be operated with high overload (HO) or low overload (LO). In order to avoid overtemperature of the Power Module, after the overload, as a minimum its load must decrease back to the base load (HO base load or LO base load).					
	HO base load 7.5 kW 37 kW	200%	% overload for 57 s % overload for 3 s % HO base load for 240 s			
	LO base load 11 kW 55 kW	110% overload for 57 s 140% overload for 3 s 100% LO base load for 240 s				
Pulse frequency	16 kHz					
Braking methods	Regenerative energy					
Degree of protection	IP20					
Operating temperature	HO base load -10 °C +50 °C (14 °F 122 °F)		Higher operating temperature are possible when the rated			
	LO base load -10 °C +40 °C (14 °F 104	°F)	power is reduced			
Bearing temperature	-40 °C +70 °C (-40 °F 158 °F)					
Relative humidity	< 95% RH - condensation not permissible					
Installation altitude	Up to 1000 m (3300 ft) above se	ea level	Higher altitudes are possible when the rated power is reduced			
Standards	CE					

8.8 Power-dependent technical data, PM260 Power Modules

8.8 Power-dependent technical data, PM260 Power Modules

PM260 Power Module

Order No., unfiltered	6SL3225- 0BH27-5UA0	6SL3225- 0BH31-1UA0	6SL3225- 0BH31-5UA0	6SL3225- 0BH32-2UA0	6SL3225- 0BH33-0UA0	6SL3225- 0BH33-7UA0
Order No., filtered	6SL3225- 0BH27-5AA0	6SL3225- 0BH31-1AA0	6SL3225- 0BH31-5AA0	6SL3225- 0BH32-2AA0	6SL3225- 0BH33-0AA0	6SL3225- 0BH33-7AA0
Power rating for HO base load	7.5 kW 10 PS	11 kW 15 PS	15 kW 20 PS	22 kW 30 PS	30 kW 41 PS	37 kW 50 PS
Input current for HO base load	10 A	13 A	18 A	26 A	34 A	41 A
Output current for HO base load	10 A	14 A	19 A	26 A	35 A	42 A
Input current for LO base load	13 A	18 A	22 A	34 A	41 A	60 A
Output current for LO base load	14 A	19 A	23 A	35 A	42 A	62 A
Fuse	20 A	20 A	32 A	50 A	50 A	80 A
Heat loss	Available soon	Available soon	Available soon	Available soon	Available soon	Available soon
Cooling air requirement	22 l/s 47 CFM	22 l/s 47 CFM	39 l/s 83 CFM	94 l/s 199 CFM	94 l/s 199 CFM	117 l/s 248 CFM
Cable cross- section for line and motor connections	2,5 16 mm² 14 6 AWG	4 16 mm² 12 6 AWG	6 16 mm² 10 6 AWG	10 35 mm² 8 2 AWG	16 35 mm² 6 2 AWG	25 35 mm² 4 2 AWG
Weight	Unfiltered: 20 kg / 44 lb; filtered: 21 kg / 46 lb	Unfiltered: 20 kg / lb; filtered: 21 kg / 46 lb	Unfiltered: 20 kg / lb; filtered: 21 kg / 46 lb	Unfiltered: 46 kg / lb; filtered: 48 kg / lb	Unfiltered: 46 kg / 100 lb; filtered: 48 kg / 105 lb	Unfiltered: 46 kg / 100 lb; filtered: 48 kg / 105 lb

Table 8-8 PM260 Frame Size D and F

Index

Α

Access level, 76 Adjustable parameters, 12 Alarms, 219 Ambient temperature, 51, 120 Analog inputs, 58 Analog outputs, 58 Functions of the, 127 Automatic mode, 105 Automatic restart, 142, 143, 144

В

Basic Operator Panel Operator controls of the, 74 Baud rates, 63 BICO parameters, 17 BICO technology, 16 Binectors, 16 Blocking protection, 123 Boost parameter, 112 BOP, 73 Operator controls of the, 74 Braking Regenerative, 135 Braking methods, 130 Braking resistor, 134 Break loose torque, 15

С

CDS, 105 Changing parameters using BOP, 75 Clearances to other devices, 34, 35, 36, 37 Closed-loop control type, 51 COM interface, 62, 63 Command Data Set, 105 Command data set switchover, 106 Command source, 52, 53, 77, 84 Default setting, 56 Selecting, 14 Selecting the, 95 Commissioning, 67, 76 Commissioning situations, 47 Commissioning the application, 72

CU240S and CU240E Control Units, FW 3.2 Operating Instructions, 03/2009, A5E02440075B AA Compound braking, 130, 131, 134 Connect the braking resistor, 40 Connectors, 16 Control commands, 86 Control Data Set, CDS, 105 Control mode, 15 Control terminal overview, 46 Control terminals, 43, 46, 54, 55 Control Units, 22, 24 Control word, 180 Control word 1, 180 Control word 2, 181 Controlling the motor, 52, 86 Current input, 99 Current output, 58, 127

D

Data backup, 47, 72, 79, 80 Data transfer, 79, 80 DC braking, 130, 131, 132 DC link voltage, 122 Default settings, 56 Default terminal settings, 57 Defining the telegram type, 170 Delta connection (Δ), 39, 51 Digital inputs, 57 Settings for the, 96 Digital outputs, 58 Functions of the, 126 DIP switch, 44, 153, 164 Direction reversal, 86 Display parameters, 13 Distances from other devices, 33 Down ramp, 15 Download, 79, 81 Drive Data Set, DDS, 149 Drive Data Sets, 149 Drive navigator, 72 Dynamic braking, 131

Ε

Efficient Infeed Technology, 25 Electromagnetic interference, 42 EMC-compliant shielding, 41 Encoder, 59 Encoder interface, 59 Energy recovery option, 122, 136 Enter clockwise or counter-clockwise rotation of the motor, 86 Environmental conditions, 76

F

F0395, 67 Factory pre-assignment, 54, 55 factory setting Restoring the, 49 Factory setting Control commands, 86 Factory settings, 56, 57 Fault acknowledgment, 226 Faults, 219 FCC Flux Current Control, 113 F-digital output module, 197 Filter, 27 Firmware version, 14 Flow control, 145 Flying restart, 140, 141, 142 Follow-on parameterization, 13 Force the brake open, 139 Frame sizes, 25 Frame sizes, 25 Function blocks Unassigned, 147, 148 functions Technological, 85 Functions Overview, 83

G

Going online, 65, 67 GSD, 167 GSDML, 173

Η

Hardware configuration, 165 HTL encoder, 118 HW Config, 165, 167, 172 Hardware configuration, 165

I

Imax controller, 120 Implementation of the extended PROFIBUS DP functions, 184 IND Parameter index, 178 Installation, 29, 32 Installation options, 32 Installing the Control Unit, 43 Interfaces, 44, 47, 57 Interlock, 19 Inverter control, 84

J

JOG function, 103 Jog mode, 74, 103

Κ

KTY 84 temperature sensor, 59, 119

L

LEDs, 44 Level control, 145 Line filter, 27, 30 Line reactor, 27, 30 Line supply connection, 40 Line supply faults, 143 Line undervoltage, 142

Μ

Manual mode, 105 Maximum current controller, 120 Maximum frequency, 15, 52, 78, 108 Message F0395, 67 Minimum frequency, 15, 52, 78, 108 MMC, 22, 47, 80 MMC memory card, 22, 47, 80 MOP, 100 Motor connection, 40 Motor control, 84 Motor data, 50, 77 Motor data identification, 69, 114, 115 Motor holding brake, 137, 138, 139 Motor rating plate, 50 Motor temperature sensor, 59, 120 Motorized potentiometer, 100

Ν

No-load monitoring, 123

0

Online connection, 65 Operator panel, 22, 47 Output filter, 76 Output reactor, 27, 30 Overload, 15, 121 Overview of the functions, 83 Overvoltage, 122

Ρ

Parameter assignment, 12, 76 Parameter channel, 176 Parameter filter, 76 Parameter set, 213 Parameter transfer, 79, 80, 81 Parameter types, 12 parameters Important, 56 Passivation, 194 PC connection kit, 22, 60 PID controller, 146 PKE Parameter ID, 176 PLC functionality, 18 Positioning function, 147 Power failure, 142 Power Module, 22, 25 Pre-assignment of the control terminals, 54, 55 Pressure control, 145 Process interfaces, 57 PROFIBUS, 171 PROFIBUS address, 163 PROFIBUS DP Implementation of the extended functions, 184 PROFIdrive profile, 174 PROFINET, 171 Project Wizard, 60 Protection functions, 84 PTC temperature sensor, 59, 119 PTC/KTY 84, 59 PWE Parameter value, 179

Q

Quick commissioning, 12, 78

R

Ramp-down time, 15, 52, 78, 109 Rampup time, 15, 52, 78, 109 Rating plate, 77 Reactors, 27 Regenerative braking, 131, 135 Regenerative energy, 129 Relay outputs, 58 Replacing the device, 79 Restore factory settings, 49 Restoring factory settings of the safety-related parameters, 197 Restoring the factory setting, 14 Restoring the factory settings, 49 Rounding, 109

S

Safety functions, 85, 192, 193 Controlling the, 194 Safety relay, 196 SBC, 192, 193 Safe Brake Control, 192 Scaling, 99, 100 of the analog output, 128 Selecting the setpoint source, 15 Sensor Electromechanical, 196 Electronic, 196 Setpoint calculation, 84, 108 Setpoint source, 52, 53, 77, 84 Default setting, 56 Setting up the PROFIBUS DP, 161 Setting-up the PG/PC interface, 61, 64 Shield connection kit, 41 Signal interconnection, 16, 19 SIMATIC, 162, 165, 172 Sine-wave filter, 27 SLS, 192, 193 Function test, 209 Safely Limited Speed, 192 Speed encoder, 51, 116 SS1, 192, 193 Safe Stop 1, 192 Stall protection, 123 Star connection (Y), 39, 51 STARTER, 47, 60

STARTER commissioning tool, 60 STARTER software, 47 Starting characteristics Optimizing the, 112 Status messages, 84 Status word, 180 Status word 1, 182 Status word 2, 183 STO, 192, 193, 199 Function test, 207 Safe Torque Off, 192 Storing data in a power-independent manner, 72 STW Control word, 175 STW1 Control word 1, 180 STW2 Control word 2, 181 Sub-chassis components, 30 Sub-D connection, 154, 161 System components, 30

Т

Technology controller, 145 Telegram types, 169, 175 Temperature monitoring, 119 Terminal overview, CU240E, 54 Terminal overview, CU240S, 55 Terminating resistor, 153 ThermoClick temperature sensor, 119 Three-wire control, 86, 88 Tightening torques, 33, 34, 35, 36, 37 Torque monitoring Frequency-dependent, 123 TTL encoder, 117 Two-wire control, 86, 87

U

Universal serial interface (USS), 152 Up ramp, 15 Upload, 79, 80 User access level, 76 User interfaces, 44 Using the factory settings, 53 USS protocol, 152

V

V/f control, 15, 76, 111, 114

V/f open-loop control, 51 Vector control, 15, 51, 114 Automatic restart, 143 Sensorless, 113 Vector control, 114 Voltage boost, 15, 112 voltage input Unipolar, 58 Voltage input, 99 Voltage output, 58, 127

W

Wizard, 60

Ζ

ZSW Status word, 175 ZSW1 Status word 1, 182 ZSW2 Status word 2, 183

Siemens AG Industry Sector P.O. Box 48 48 90026 NUREMBERG GERMANY Subject to change without prior notice © Siemens AG 2008

www.siemens.com/automation